



Cluster administration

ONTAP 9

NetApp
March 02, 2026

Table of Contents

- Cluster administration 1
 - Cluster management with System Manager 1
 - Learn about cluster administration with ONTAP System Manager 1
 - Use System Manager to access an ONTAP cluster 2
 - Configure protocols on your ONTAP cluster 3
 - Enable new features by adding license keys with ONTAP System Manager 4
 - Download a cluster configuration with ONTAP System Manager 4
 - Assign tags to a cluster with ONTAP System Manager 5
 - View and submit support cases with ONTAP System Manager 6
 - Manage the maximum capacity limit of a storage VM in ONTAP System Manager 6
 - Monitor cluster, tier, and SVM capacity in ONTAP System Manager 8
 - View hardware configurations to determine problems with ONTAP System Manager 10
 - Manage nodes using ONTAP System Manager 16
- License management 18
 - ONTAP licensing overview 18
 - Download NetApp license files (NLF) from NetApp Support Site 21
 - Install NetApp licenses in ONTAP 22
 - Manage ONTAP licenses 23
 - License types and licensed method 26
 - Commands for managing licenses in ONTAP 27
- Cluster management with the CLI 28
 - Learn about cluster administration with the ONTAP CLI 28
 - Cluster and SVM administrators 28
 - Access the cluster by using the CLI (cluster administrators only) 30
 - Use the ONTAP command-line interface 41
 - Record an ONTAP CLI session and manage the recorded sessions 55
 - Cluster management (cluster administrators only) 56
 - Manage nodes 61
 - Configure the SP/BMC network 85
 - Manage nodes remotely using the SP/BMC 91
 - Manage ONTAP cluster time (cluster administrators only) 119
 - Manage the banner and MOTD 121
 - Manage ONTAP jobs and job schedules 131
 - Back up and restore cluster configurations (cluster administrators only) 134
 - Manage node core dumps for an ONTAP cluster (cluster administrators only) 144
- Disk and tier management 145
 - Disks and ONTAP local tiers 145
 - Manage local tiers 147
 - Manage disks 187
 - Manage RAID configurations 218
 - Manage Flash Pool local tiers 224
- FabricPool tier management 239
 - Learn about data tiering with ONTAP FabricPool 239

Requirements for using ONTAP FabricPool	240
Tier data efficiently with ONTAP FabricPool policies	244
Learn about ONTAP FabricPool configuration and management tasks	248
Configure FabricPool	249
Manage FabricPool	266
Manage FabricPool mirrors	288
ONTAP commands for managing FabricPool resources	295
SVM data mobility	298
Learn about ONTAP SVM data mobility	298
Migrate an ONTAP SVM	307
Monitor ONTAP volume migration	309
Pause and resume an ONTAP SVM migration	309
Cancel an ONTAP SVM migration	310
Manually cut over clients after migration of an ONTAP SVM	310
Manually remove source ONTAP SVM after client cutover	311
HA pair management	311
Learn about HA pair management in ONTAP clusters	311
Learn about hardware-assisted takeovers in ONTAP clusters	312
Learn about automatic takeover and giveback in ONTAP clusters	313
ONTAP automatic takeover commands	317
ONTAP automatic giveback commands	318
ONTAP manual takeover commands	320
ONTAP manual giveback commands	323
Testing takeover and giveback in ONTAP clusters	325
ONTAP commands for monitoring an HA pair	327
ONTAP commands for enabling and disabling storage failover	331
Halt or reboot ONTAP nodes without initiating takeover in two-node clusters	332
Configure encryption for ONTAP HA traffic	335
REST API management with System Manager	336
REST API management with System Manager	336
Accessing the REST API log	336

Cluster administration

Cluster management with System Manager

Learn about cluster administration with ONTAP System Manager

System Manager is an HTML5-based graphical management interface that enables you to use a web browser to manage storage systems and storage objects (such as disks, volumes, and storage tiers) and perform common management tasks related to storage systems.



- System Manager is included with ONTAP software as a web service, enabled by default, and accessible by using a browser.
- The name of System Manager has changed beginning with ONTAP 9.6. In ONTAP 9.5 and earlier it was called OnCommand System Manager. Beginning with ONTAP 9.6 and later, it is called System Manager.
- If you are using the classic System Manager (available only in ONTAP 9.7 and earlier), refer to [System Manager Classic \(ONTAP 9.0 to 9.7\)](#)

Using the System Manager Dashboard, you can view at-a-glance information about important alerts and notifications, the efficiency and capacity of storage tiers and volumes, the nodes that are available in a cluster, the status of the nodes in an HA pair, the most active applications and objects, and the performance metrics of a cluster or a node.

With System Manager in ONTAP 9.7 and later releases, you can perform many common tasks such as the following:

- Create a cluster, configure a network, and set up support details for the cluster.
- Configure and manage storage objects, such as disks, local tiers, volumes, qtrees, and quotas.
- Configure protocols, such as SMB and NFS, and provision file sharing.
- Configure protocols such as FC, FCoE, NVMe, and iSCSI for block access.
- Create and configure network components, such as subnets, broadcast domains, data and management interfaces, and interface groups.
- Set up and manage mirroring and vaulting relationships.
- Perform cluster management, storage node management, and storage virtual machine (storage VM) management operations.
- Create and configure storage VMs, manage storage objects associated with storage VMs, and manage storage VM services.
- Monitor and manage high-availability (HA) configurations in a cluster.
- Configure service processors to remotely log in, manage, monitor, and administer the node, regardless of the state of the node.

System Manager terminology

System Manager uses different terminology than the CLI for some ONTAP key functionality.

- **Local tier:** A set of physical solid-state drives or hard-disk drives you store your data on. You might know these as aggregates. In fact, if you use the ONTAP CLI, you will still see the term *aggregate* used to represent a local tier.
- **Cloud tier:** Storage in the cloud used by ONTAP when you want to have some of your data off premises for one of several reasons. If you are thinking of the cloud part of a FabricPool, you've already figured it out. And if you are using a StorageGRID system, your cloud might not be off premises at all. (A cloud-like experience on premises is called a *private cloud*.)
- **Storage VM:** A virtual machine running within ONTAP that provides storage and data services to your clients. You might know this as an *SVM* or a *vserver*.
- **Network interface:** Address and properties assigned to a physical network port. You might know this as a *logical interface (LIF)*.
- **Pause:** An action that halts operations. Before ONTAP 9.8, you might have referred to *quiesce* in other versions of System Manager.

Use System Manager to access an ONTAP cluster

If you prefer to use a graphic interface instead of the command-line interface (CLI) for accessing and managing a cluster, you can do so by using System Manager, which is included with ONTAP as a web service, is enabled by default, and is accessible by using a browser.



Beginning with ONTAP 9.12.1, System Manager is fully integrated with the NetApp Console.

With the Console, you can manage your hybrid multicloud infrastructure from a single control plane while retaining the familiar System Manager dashboard.

See [System Manager integration with NetApp Console](#).

About this task

You can use a cluster management network interface (LIF) or node management network interface (LIF) to access System Manager. For uninterrupted access to System Manager, you should use a cluster management network interface (LIF).

Before you begin

- You must have a cluster user account that is configured with the “admin” role and the “http” and “console” application types.
- You must have enabled cookies and site data in the browser.

Steps

1. Point the web browser to the IP address of the cluster management network interface:

- If you are using IPv4: **`https://cluster-mgmt-LIF`**
- If you are using IPv6: **`https://[cluster-mgmt-LIF]`**



Only HTTPS is supported for browser access of System Manager.

If the cluster uses a self-signed digital certificate, the browser might display a warning indicating that the certificate is not trusted. You can either acknowledge the risk to continue the access or install a Certificate Authority (CA) signed digital certificate on the cluster for server authentication.

2. **Optional:** If you have configured an access banner by using the CLI, then read the message that is displayed in the **Warning** dialog box, and choose the required option to proceed.

This option is not supported on systems on which Security Assertion Markup Language (SAML) authentication is enabled.

- If you do not want to continue, click **Cancel**, and close the browser.
- If you want to continue, click **OK** to navigate to the System Manager login page.

3. Log in to System Manager by using your cluster administrator credentials.



Beginning with ONTAP 9.11.1, when you log in to System Manager, you can specify the locale. The locale specifies certain localization settings, such as language, currency, time and date format, and similar settings. For ONTAP 9.10.1 and earlier, the locale for System Manager is detected from the browser. To change the locale for System Manager, you have to change the locale of the browser.

4. **Optional:** Beginning with ONTAP 9.12.1, you can specify your preference for the appearance of System Manager:

- a. In the upper right corner of System Manager, click  to manage user options.
- b. Position the **System Theme** toggle switch to your preference:

Toggle position	Appearance setting
 (left)	Light theme (Light background with dark text)
OS (center)	Default to the theme preference that was set for the operating system's applications (usually the theme setting for the browser that is used to access System Manager).
 (right)	Dark theme (Dark background with light text)

Related information

[Managing access to web services](#)

[Accessing a node's log, core dump, and MIB files by using a web browser](#)

Configure protocols on your ONTAP cluster

Depending on the licenses enabled on your cluster, you can enable the desired protocols on your cluster. You then create network interfaces using which you can access the storage.

About this task

This procedure applies to FAS, AFF, and ASA systems. If you have an ASA r2 system (ASA A1K, ASA A90, ASA A70, ASA A50, ASA A30, ASA A20, or ASA C30), follow [these steps](#) to use System Manager to set up an ONTAP cluster. ASA r2 systems provide a simplified ONTAP experience specific to SAN-only customers.

Step

1. Select **Dashboard** and then click **Configure Protocols**.

- To enable NAS protocols, select **NFS** or **SMB**.
- To enable SAN protocols, select **iSCSI** or **FC**.
- To enable NVMe protocols, select **NVMe**.

Enable new features by adding license keys with ONTAP System Manager

In releases earlier than ONTAP 9.10.1, ONTAP features are enabled with license keys, and features in ONTAP 9.10.1 and later are enabled with a NetApp license file. You can add license keys and NetApp license files using System Manager.

Beginning with ONTAP 9.10.1, you use System Manager to install a NetApp License File to enable multiple licensed features all at once. Using a NetApp License File simplifies license installation because you no longer have to add separate feature license keys. You download the NetApp License File from the NetApp Support Site.

If you already have license keys for some features and you are upgrading to ONTAP 9.10.1, you can continue to use those license keys.

Steps

1. Select **Cluster > Settings**.
2. Under **Licenses**, select .
3. Select **Browse**. Choose the NetApp License File you downloaded.
4. If you have license keys you want to add, select **Use 28-character license keys** and enter the keys.

Download a cluster configuration with ONTAP System Manager

Beginning with ONTAP 9.11.1, you can use System Manager to download some configuration details about the cluster and its nodes. This information can be used for inventory management, hardware replacement, and lifecycle activities. This information is especially useful to sites that do not send AutoSupport (ASUP) data.

Cluster configuration details include the cluster name, cluster ONTAP version, cluster management LIF, volume, and LIF counts.

Node configuration details include the node name, system serial number, system ID, system model, ONTAP version, MetroCluster information, SP/BMC network information, and encryption configuration information.

Steps

1. Click **Cluster > Overview**.
2. Click  to display the drop-down menu.
3. Select **Download configuration**.
4. Select the HA pairs, then click **Download**.

The configuration is downloaded as an Excel spreadsheet.

- The first sheet contains cluster details.

- The other sheets contain node details.

Assign tags to a cluster with ONTAP System Manager

Beginning with ONTAP 9.14.1, you can use System Manager to assign tags to a cluster to identify objects as belonging to a category, such as projects or cost centers.

About this task

You can assign a tag to a cluster. First, you need to define and add the tag. Then, you can also edit or delete the tag.

Tags can be added when you create a cluster, or they can be added later.

You define a tag by specifying a key and associating a value to it using the format “key:value”. For example: “dept:engineering” or “location:san-jose”.

The following should be considered when you create tags:

- Keys have a minimum length of one character and cannot be null. Values can be null.
- A key can be paired with multiple values by separating the values with a comma, for example, “location:san-jose,toronto”
- Tags can be used for multiple resources.
- Keys must start with a lowercase letter.

Steps

To manage tags, performing the following steps:

1. In System Manager, click **Cluster** to view the overview page.

The tags are listed in the **Tags** section.

2. Click **Manage Tags** to modify existing tags or add new ones.

You can add, edit, or delete the tags.

To perform this action...	Perform these steps...
Add a tag	<ol style="list-style-type: none"> a. Click Add Tag. b. Specify a key and its value or values (separate multiple values with commas). c. Click Save.
Edit a tag	<ol style="list-style-type: none"> a. Modify the content in the Key and Values (optional) fields. b. Click Save.
Delete a tag	<ol style="list-style-type: none"> a. Click  next to the tag you want to delete.

View and submit support cases with ONTAP System Manager

Beginning with ONTAP 9.9.1, you can view support cases from Active IQ Digital Advisor (also known as Digital Advisor) associated with the cluster. You can also copy cluster details that you need to submit a new support case on the NetApp Support Site. Beginning with ONTAP 9.10.1, you can enable telemetry logging, which helps support personnel troubleshoot problems.



To receive alerts about firmware updates, you must be registered with Active IQ Unified Manager. Refer to [Active IQ Unified Manager documentation resources](#).

Steps

1. In System Manager, select **Support**.

A list of open support cases associated with this cluster is displayed.

2. Click on the following links to perform procedures:

- **Case Number:** See details about the case.
- **Go to NetApp Support Site:** Navigate to the **My AutoSupport** page on the NetApp Support Site to view knowledge base articles or submit a new support case.
- **View My Cases:** Navigate to the **My Cases** page on the NetApp Support Site.
- **View Cluster Details:** View and copy information you will need when you submit a new case.

Enable telemetry logging

Beginning with ONTAP 9.10.1, you can use System Manager to enable telemetry logging. When telemetry logging is allowed, messages that are logged by System Manager are given a specific telemetry identifier that indicates the exact process that triggered the message. All messages that are issued relating to that process have the same identifier, which consists of the name of the operational workflow and a number (for example "add-volume-1941290").

If you experience performance problems, you can enable telemetry logging, which allows support personnel to more easily identify the specific process for which a message was issued. When telemetry identifiers are added to the messages, the log file is only slightly enlarged.

Steps

1. In System Manager, select **Cluster > Settings**.
2. In **UI Settings** section, click the check box for **Allow telemetry logging**.

Manage the maximum capacity limit of a storage VM in ONTAP System Manager


Beginning with ONTAP 9.13.1, you can use System Manager to enable a maximum capacity limit for a storage VM and set a threshold to trigger alerts when the used storage reaches a certain percentage of the maximum capacity.

Enable a maximum capacity limit for a storage VM

Beginning with ONTAP 9.13.1, you can specify the maximum capacity that can be allocated for all volumes in a storage VM. You can enable the maximum capacity when you add a storage VM or when you edit an existing

storage VM.

Steps

1. Select **Storage > Storage VMs**.
2. Perform one of the following:
 - To add a storage VM, click  .
 - To edit a storage VM, click  next to the name of the storage VM, and then click **Edit**.
3. Enter or modify the settings for the storage VM, and select the check box labeled "Enable maximum capacity limit".
4. Specify the maximum capacity size.
5. Specify the percentage of the maximum capacity you want to use as a threshold to trigger alerts.
6. Click **Save**.

Edit the maximum capacity limit of a storage VM

Beginning with ONTAP 9.13.1, you can edit the maximum capacity limit of an existing storage VM, if the [maximum capacity limit has been enabled](#) already.

Steps

1. Select **Storage > Storage VMs**.
2. Click  next to the name of the storage VM, and then click **Edit**.

The check box labeled "Enable maximum capacity limit" is already checked.

3. Perform one of the following steps:

Action	Steps
Disable the maximum capacity limit	<ol style="list-style-type: none">1. Uncheck the check box.2. Click Save.
Modify the maximum capacity limit	<ol style="list-style-type: none">1. Specify the new maximum capacity size. (You cannot specify a size that is less than the already allocated space in the storage VM.)2. Specify the new percentage of the maximum capacity you want to use as a threshold to trigger alerts.3. Click Save.

Related information

- [View the maximum capacity limit of a storage VM](#)
- [Capacity measurements in System Manager](#)
- [Manage SVM capacity limits](#)

Monitor cluster, tier, and SVM capacity in ONTAP System Manager

Using System Manager, you can monitor how much storage capacity has been used and how much is still available for a cluster, a local tier, or a storage VM.

With each version of ONTAP, System Manager provides more robust capacity monitoring information:

- Beginning with ONTAP 9.13.1, you can enable a maximum capacity limit for a storage VM and set a threshold to trigger alerts when the used storage reaches a certain percentage of the maximum capacity.
- Beginning with ONTAP 9.12.1, System Manager displays the amount of committed capacity for a local tier.
- Beginning with ONTAP 9.10.1, System Manager lets you view historical data about the cluster's capacity and projections about how much capacity will be used or available in the future. You can also monitor the capacity of local tiers and volumes.



Measurements of used capacity are displayed differently depending on your ONTAP version. Learn more in [Capacity measurements in System Manager](#).

View the capacity of a cluster

You can view capacity measurements for a cluster on the Dashboard in System Manager.

Before you begin

To view data related to the capacity in the cloud, you must have an account with Digital Advisor and be connected.

Steps

1. In System Manager, click **Dashboard**.
2. In the **Capacity** section, you can view the following:
 - Total used capacity of the cluster
 - Total available capacity of the cluster
 - Percentages of used and available capacity.
 - Ratio of data reduction.
 - Amount of capacity used in the cloud.
 - History of capacity usage.
 - Projection of capacity usage



In System Manager, capacity representations do not account for root storage tier (aggregate) capacities.

3. Click the chart to view more details about the capacity of the cluster.

Capacity measurements are shown in two bar charts:

- The top chart displays the physical capacity: the size of physical used, reserved, and available space.
- The bottom chart displays the logical capacity: the size of client data, snapshots, and clones, and the total logical used space.

Below the bar charts are measurements for data reduction:

- Data reduction ratio for only the client data (snapshots and clones are not included).
- Overall data reduction ratio.

For more information, see [Capacity measurements in System Manager](#).

View the capacity of a local tier

You can view details about the capacity of local tiers. Beginning with ONTAP 9.12.1, the **Capacity** view also includes the amount of committed capacity for a local tier, enabling you to determine whether you need to add capacity to the local tier to accommodate the committed capacity and avoid running out of free space.

Steps

1. Click **Storage > Tiers**.
2. Select the name of the local tier.
3. On the **Overview** page, in the **Capacity** section, the capacity is shown in a bar chart with three measurements:
 - Used and reserved capacity
 - Available capacity
 - Committed capacity (beginning with ONTAP 9.12.1)
4. Click the chart to view details about the capacity of the local tier.

Capacity measurements are shown in two bar charts:

- The top bar chart displays physical capacity: the size of physical used, reserved, and available space.
- The bottom bar chart displays logical capacity: the size of client data, snapshots, and clones, and the total of logical used space.

Below the bar charts are measurements ratios for data reduction:

- Data reduction ratio for only the client data (snapshots and clones are not included).
- Overall data reduction ratio.

For more information, see [Capacity measurements in System Manager](#).

Optional actions

- If the committed capacity is larger than the capacity of the local tier, you might consider adding capacity to the local tier before it runs out of free space. See [Add capacity to a local tier \(add disks to an aggregate\)](#).
- You can also view the storage that specific volumes use in the local tier by selecting the **Volumes** tab.

View the capacity of the volumes in a storage VM

You can view how much storage is used by the volumes in a storage VM and how much capacity is still available. The total measurement of used and available storage is called "capacity across volumes".

Steps

1. Select **Storage > Storage VMs**.

2. Click on the name of the storage VM.
3. Scroll to the **Capacity** section, which shows a bar chart with the following measurements:
 - **Physical used:** Sum of physical used storage across all volumes in this storage VM.
 - **Available:** Sum of available capacity across all volumes in this storage VM.
 - **Logical used:** Sum of logical used storage across all volumes in this storage VM.

For more details about the measurements, see [Capacity measurements in System Manager](#).

View the maximum capacity limit of a storage VM

Beginning with ONTAP 9.13.1, you can view the maximum capacity limit of a storage VM.

Before you begin

You must [enable the maximum capacity limit of a storage VM](#) before you can view it.

Steps

1. Select **Storage > Storage VMs**.

You can view the maximum capacity measurements in two ways:

- In the row for the storage VM, view the **Maximum Capacity** column which contains a bar chart that shows the used capacity, available capacity, and maximum capacity.
- Click the name of the storage VM. On the **Overview** tab, scroll to view the maximum capacity, allocated capacity, and capacity alert threshold values in the left column.

Related information

- [Edit the maximum capacity limit of a storage VM](#)
- [Capacity measurements in System Manager](#)

View hardware configurations to determine problems with ONTAP System Manager

Beginning with ONTAP 9.8, you can use System Manager to view the configuration of hardware on your network and determine the health of your hardware systems and cabling configurations.

Steps

To view hardware configurations, perform the following steps:

1. In System Manager, select **Cluster > Hardware**.
2. Hover your mouse over components to view status and other details.

You can view various types of information:

- [Information about controllers](#)
- [Information about disk shelves](#)
- [Information about storage switches](#)

3. Beginning with ONTAP 9.12.1, you can view cabling information in System Manager. Click the **Show**

Cables check box to view cabling, then hover over a cable to view its connectivity information.

- [Information about cabling](#)

Information about controllers

You can view the following:

Nodes

- You can view the front and rear views.
- For models with an internal disk shelf, you can also view the disk layout in the front view.
- You can view the following platforms:

Platform	Supported in System Manager in ONTAP version...										
	9.18.1	9.17.1	9.16.1	9.15.1	9.14.1	9.13.1	9.12.1	9.11.1	9.10.1	9.9.1	9.8 (preview mode only)
AFF A20	Yes	Yes	Yes								
AFF A30	Yes	Yes	Yes								
AFF A50	Yes	Yes	Yes								
AFF A70	Yes	Yes	Yes	Yes							
AFF A90	Yes	Yes	Yes	Yes							
AFF A1K	Yes	Yes	Yes	Yes							
AFF A150				Yes	Yes	Yes					
AFF A220				Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
AFF A250				Yes	Yes	Yes	Yes	Yes	Yes	Yes	
AFF A300				Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
AFF A320				Yes	Yes	Yes	Yes	Yes	Yes	Yes	

AFF A400				Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
AFF A700				Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
AFF A700s				Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
AFF A800				Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
AFF A900	Yes	Yes	Yes									
AFF C30	Yes	Yes	Yes									
AFF C60	Yes	Yes	Yes									
AFF C80	Yes	Yes	Yes									
AFF C190				Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
AFF C250				Yes	Yes	Yes	Yes *	Yes *	Yes *			
AFF C400				Yes	Yes	Yes	Yes *	Yes *	Yes *			
AFF C800	Yes *	Yes *	Yes *									
ASA A150				Yes	Yes	Yes						
ASA A250				Yes	Yes	Yes						
ASA A400				Yes	Yes	Yes						
ASA A800				Yes	Yes	Yes						

ASA A900				Yes	Yes	Yes						
ASA C250	Yes	Yes	Yes	Yes	Yes	Yes						
ASA C400	Yes	Yes	Yes	Yes	Yes	Yes						
ASA C800	Yes	Yes	Yes	Yes	Yes	Yes						
AFX 1X	Yes	Yes										
FAS50	Yes	Yes	Yes									
FAS70	Yes	Yes	Yes	Yes								
FAS90	Yes	Yes	Yes	Yes								
FAS50 Of				Yes								
FAS27 20				Yes	Yes	Yes	Yes	Yes				
FAS27 50	Yes											
FAS83 00				Yes	Yes	Yes	Yes	Yes				
FAS87 00				Yes	Yes	Yes	Yes	Yes				
FAS90 00					Yes	Yes	Yes	Yes	Yes			
FAS95 00					Yes	Yes	Yes	Yes	Yes			

* Install the latest patch releases to view these devices.

Ports

- You will see a port highlighted in red if it is down.

- When you hover over the port, you can view the status of a port and other details.
- You cannot view console ports.

Notes:

- Beginning with ONTAP 9.11.1, you will see SAS ports highlighted in red only if they are in an error state or if a cabled port that is being used goes offline. The ports appear in white if they are offline and uncabled.
- For ONTAP 9.10.1 and earlier, you will see SAS ports highlighted in red when they are disabled.

FRUs

Information about FRUs appears only when the state of a FRU is non-optimal.

- Failed PSUs in nodes or chassis.
- High temperatures detected in nodes.
- Failed fans on the nodes or chassis.

Adapter cards

- Cards with defined part number fields display in the slots if external cards have been inserted.
- Ports display on the cards.
- For a supported card, you can view images of that card. If the card is not in the list of supported part numbers, then a generic graphic appears.

Information about disk shelves

You can view the following:

Disk shelves

- You can display the front and rear views.
- You can view the following disk shelf models:

If your system is running...	Then you can use System Manager to view...
ONTAP 9.9.1 and later	All shelves that have <i>not</i> been designated as "end of service" or "end of availability"
ONTAP 9.8	DS4243, DS4486, DS212C, DS2246, DS224C, and NS224

Shelf ports

- You can view port status.
- You can view remote port information if the port is connected.

Shelf FRUs

- PSU failure information displays.

Information about storage switches

You can view the following:

Storage switches

- The display shows switches that act as storage switches used to connect shelves to nodes.
- Beginning with ONTAP 9.9.1, System Manager displays information about a switch that acts as both a storage switch and a cluster, which can also be shared between nodes of an HA pair.
- The following information displays:
 - Switch name
 - IP address
 - Serial number
 - SNMP version
 - System version
- You can view the following storage switch models:

If your system is running...	Then you can use System Manager to view...
ONTAP 9.11.1 or later	Cisco Nexus 3232C Cisco Nexus 9336C-FX2 NVIDIA SN2100
ONTAP 9.10.1 and 9.9.1	Cisco Nexus 3232C Cisco Nexus 9336C-FX2
ONTAP 9.8	Cisco Nexus 3232C

Storage switch ports

- The following information displays:
 - Identity name
 - Identity index
 - State
 - Remote connection
 - Other details

Information about cabling

Beginning with ONTAP 9.12.1, you can view the following cabling information:

- **Cabling** between controllers, switches, and shelves when no storage bridges are used
- **Connectivity** that shows the IDs and MAC addresses of the ports on either end of the cable

Manage nodes using ONTAP System Manager

Using System Manager, you can add nodes to a cluster and rename them. You can also

reboot, take over, and give back nodes.

Add nodes to a cluster

You can increase the size and capabilities of your cluster by adding new nodes.

Before you Start

You should have already cabled the new nodes to the cluster.

About this task

There are separate processes for working with System Manager in ONTAP 9.8 and later, or ONTAP 9.7.

ONTAP 9.8 and later procedure

Adding nodes to a cluster with System Manager (ONTAP 9.8 and later)

Steps

1. Select **Cluster > Overview**.

The new controllers are shown as nodes connected to the cluster network but are not in the cluster.

2. Select **Add**.

- The nodes are added into the cluster.
- Storage is allocated implicitly.

ONTAP 9.7 procedure

Adding nodes to a cluster with System Manager (ONTAP 9.7)

Steps

1. Select **(Return to classic version)**.
2. Select **Configurations > Cluster Expansion**.

System Manager automatically discovers the new nodes.

3. Select **Switch to the new experience**.
4. Select **Cluster > Overview** to view the new nodes.

Shut down, reboot or edit service processor

When you reboot or shutdown a node, its HA partner automatically executes a takeover.



This procedure applies to FAS, AFF, and ASA systems. If you have an ASA r2 system (ASA A1K, ASA A90, ASA A70, ASA A50, ASA A30, ASA A20, or ASA C30), follow [these steps](#) to shutdown and reboot a node. ASA r2 systems provide a simplified ONTAP experience specific to SAN-only customers.

Steps

1. Select **Cluster > Overview**.
2. Under **Nodes**, select .

3. Select the node and then select **Shut down, Reboot**, or **Edit Service Processor**.

If a node has been rebooted and is waiting for giveback, the **Giveback** option is also available.

If you select **Edit Service Processor**, you can choose **Manual** to input the IP address, subnet mask and gateway, or you can choose **DHCP** for dynamic host configuration.

Rename nodes

Beginning with ONTAP 9.14.1, you can rename a node from the cluster overview page.



This procedure applies to FAS, AFF, and ASA systems. If you have an ASA r2 system (ASA A1K, ASA A90, ASA A70, ASA A50, ASA A30, ASA A20, or ASA C30), follow [these steps](#) to rename a node. ASA r2 systems provide a simplified ONTAP experience specific to SAN-only customers.

Steps

1. Select **Cluster**. The cluster overview page displays.
2. Scroll down to the **Nodes** section.
3. Next to the node that you want to rename, select , and select **Rename**.
4. Modify the node name, and then select **Rename**.

License management

ONTAP licensing overview

A license is a record of one or more software entitlements. Beginning with ONTAP 9.10.1, all licenses are delivered as a NetApp license file (NLF), which is a single file that enables multiple features. Beginning in May 2023, all AFF systems (both A-series and C-series) and FAS systems are sold with either the ONTAP One software suite or the ONTAP Base software suite, and beginning in June 2023, all ASA systems are sold with ONTAP One for SAN. Each software suite is delivered as a single NLF, replacing the separate NLF bundles first introduced in ONTAP 9.10.1.

Licenses included with ONTAP One

ONTAP One contains all available licensed functionality. It contains a combination of the contents of the former Core bundle, Data Protection bundle, Security and Compliance bundle, Hybrid Cloud bundle, and Encryption bundle, as shown in the table. Encryption is not available in restricted countries.

Former bundle name	ONTAP keys included
Core bundle	FlexClone
	SnapRestore
	NFS, SMB, S3
	FC, iSCSI
	NVME-oF

Security and Compliance bundle	Autonomous Ransomware Protection
	MTKM
	SnapLock
Data Protection bundle	SnapMirror (asynchronous, synchronous, active sync)
	SnapCenter
	SnapMirror S3 for NetApp targets
Hybrid Cloud bundle	SnapMirror cloud
	SnapMirror S3 for non-NetApp targets
Encryption bundle	NetApp Volume Encryption
	Trusted Platform module

Licenses not included with ONTAP One

ONTAP One does not include any of NetApp’s cloud-delivered services, including the following:

- NetApp Cloud Tiering
- Data Infrastructure Insights
- NetApp Backup and Recovery
- Data governance

ONTAP One for existing systems

If you have existing systems that are currently under NetApp support but have not been upgraded to ONTAP One, the existing licenses on those systems are still valid and continue to work as expected. For example, if the SnapMirror license is already installed on existing systems, it is not necessary to upgrade to ONTAP One to get a new SnapMirror license. However, if you do not have a SnapMirror license installed on an existing system, the only way to get that license is to upgrade to ONTAP One for an additional fee.

Beginning in June 2023, ONTAP systems using 28-character license keys can also [upgrade to the ONTAP One or ONTAP Base compatibility bundle](#).

Licenses included with ONTAP Base

ONTAP Base is an optional software suite that’s an alternative to ONTAP One for ONTAP systems. It is for specific use cases where data protection technologies such as SnapMirror and SnapCenter, as well as security features like Autonomous Ransomware, are not required, such as non-production systems for dedicated test or development environments. Additional licenses cannot be added to ONTAP Base. If you want additional licenses, such as SnapMirror, you must upgrade to ONTAP One.

Former bundle name	ONTAP keys included
--------------------	---------------------

Core bundle	FlexClone
	SnapRestore
	NFS, SMB, S3
	FC, iSCSI
	NVME-oF
Encryption bundle	NetApp Volume Encryption
	Trusted Platform module

Licenses included with ONTAP One for SAN

ONTAP One for SAN is available for ASAA-series and C-series systems. This is the only software suite available for SAN. ONTAP One for SAN contains the following licenses:

ONTAP keys included
FlexClone
SnapRestore
FC, iSCSI
NVME-oF
MTKM
SnapLock
SnapMirror (asynchronous, synchronous, active sync)
SnapCenter
SnapMirror cloud
NetApp Volume Encryption
Trusted Platform module

Other license delivery methods

In ONTAP 8.2 through ONTAP 9.9.1, license keys are delivered as 28-character strings, and there is one key per ONTAP feature. You use the ONTAP CLI to install license keys if you are using ONTAP 8.2 through ONTAP 9.9.1.



ONTAP 9.10.1 supports installing 28-character license keys using System Manager or the CLI. However, if an NLF license is installed for a feature, you cannot install a 28-character license key over the NetApp license file for the same feature. For information about installing NLFs or license keys using System Manager, see [Install ONTAP licenses](#).

Related information

[How to get an ONTAP One license when the system has NLFs already](#)

[How to verify ONTAP Software Entitlements and related License Keys using the Support Site](#)

[NetApp: ONTAP Entitlement Risk Status](#)

Download NetApp license files (NLF) from NetApp Support Site

If your system is running ONTAP 9.10.1 or later, you can upgrade the bundle license files on existing systems by downloading the NLF for ONTAP One or ONTAP Core from the NetApp Support Site.



The SnapMirror cloud and SnapMirror S3 licenses are not included with ONTAP One. They are part of the ONTAP One Compatibility bundle, which you can get for free if you have ONTAP One and [request separately](#).

Steps

You can download ONTAP One license files for systems with existing NetApp license file bundles and for systems with 28-character license keys that have been converted to NetApp license files on systems running ONTAP 9.10.1 and later. For a fee, you can also upgrade systems from ONTAP Base to ONTAP One. For more information about downloading NetApp license files, see the KB article [How to download NLF licenses from the NetApp Support Site](#).

Upgrade existing NLF

1. Contact your NetApp sales team and request the license file bundle you want to upgrade or convert (for example, ONTAP Base to ONTAP One, or Core Bundle and Data Protection bundle to ONTAP One).

When your request is processed, you will receive an email from netappsw@netapp.com with the subject "NetApp Software Licensing Notification for SO# [SO Number]" and the email will include a PDF attachment that includes your license serial number.

2. Log in to the [NetApp Support Site](#).
3. Select **Systems > Software Licenses**.
4. From the menu, choose **Serial Number**, enter the serial number you received, and click **New Search**.
5. Locate the license bundle you want to convert.
6. Click **Get NetApp License File** for each license bundle and download the NLFs when they're available.
7. [Install](#) the ONTAP One file.

Upgrade NLF converted from license key

1. Log in to the [NetApp Support Site](#).
2. Select **Systems > Software Licenses**.
3. From the menu, choose **Serial Number**, enter the system serial number, and click **New Search**.
4. Locate the license you want to convert, and in the **Eligibility** column click **Check**.
5. In the **Check Eligibility form**, click **Generate Licenses for 9.10.x and later**.
6. Close the **Check Eligibility form**.

You will need to wait at least 2 hours for the licenses to generate.

7. Repeat Steps 1 through 3.
8. Locate the ONTAP One license, click **Get NetApp License File**, and choose the delivery method.
9. [Install](#) the ONTAP One file.

Install NetApp licenses in ONTAP

You can install NetApp license files (NLFs) and license keys using System Manager, which is the preferred method for installing NLFs, or you can use the ONTAP CLI to install license keys. In ONTAP 9.10.1 and later, features are enabled with a NetApp license file, and in releases earlier than ONTAP 9.10.1, ONTAP features are enabled with license keys.

Steps

If you have already [downloaded NetApp license files](#) or license keys, you can use System Manager or the ONTAP CLI to install NLFs and 28-character license keys.

System Manager - ONTAP 9.8 and later

1. Select **Cluster > Settings**.
2. Under **Licenses**, select .
3. Select **Browse**. Choose the NetApp License File you downloaded.
4. If you have license keys you want to add, select **Use 28-character license keys** and enter the keys.

System Manager - ONTAP 9.7 and earlier

1. Select **Configuration > Cluster > Licenses**.
2. Under **Licenses**, select .
3. In the **Packages** window, click **Add**.
4. In the **Add License Packages** dialog box, click **Choose Files** to select the NetApp License File that you downloaded, and then click **Add** to upload the file to the cluster.

CLI

1. Add one or more license key:

```
system license add
```

The following example installs licenses from the local node `/mroot/etc/lic_file` if the file exists at this location:

```
cluster1::> system license add -use-license-file true
```

The following example adds a list of licenses with the keys `AAAAAAAAAAAAAAAAAAAAAAAAAAAA` and `BBBBBBBBBBBBBBBBBBBBBBBBBBBBBB` to the cluster:

```
cluster1::> system license add -license-code  
AAAAAAAAAAAAAAAAAAAAAAAAAAAA, BBBBBBBBBBBBBBBBBBBBBBBBBBBBB
```

Learn more about the `system license add` command in the ONTAP command reference.

Manage ONTAP licenses

You can use System Manager or the ONTAP CLI to view and manage licenses installed on your system, including viewing the license serial number, checking the status of a license, and removing a license.

View details about a license

Steps

How you view details about a license depends on what version of ONTAP you are using and whether you use System Manager or the ONTAP CLI.

System Manager - ONTAP 9.8 and later

1. To view details about a specific feature license, select **Cluster > Settings**.
2. Under **Licenses**, select .
3. Select **Features**.
4. Locate the licensed feature you want to view and select  to view the license details.

System Manager - ONTAP 9.7 and earlier

1. Select **Configuration > Cluster > Licenses**.
2. In the **Licenses** window, perform the appropriate action:
3. Click the **Details** tab.

CLI

1. Display details about an installed license:

```
system license show
```

Delete a license

System Manager - ONTAP 9.8 and later

1. To delete a license, select **Cluster > Settings**.
2. Under **Licenses**, select .
3. Select **Features**.
4. Select the licensed feature you want to delete and **Delete legacy key**.

System Manager - ONTAP 9.7 and earlier

1. Select **Configuration > Cluster > Licenses**.
2. In the **Licenses** window, perform the appropriate action:

If you want to...	Do this...
Delete a specific license package on a node or a master license	Click the Details tab.
Delete a specific license package across all of the nodes in the cluster	Click the Packages tab.

3. Select the software license package that you want to delete, and then click **Delete**.

You can delete only one license package at a time.

4. Select the confirmation check box, and then click **Delete**.

CLI

1. Delete a license:

```
system license delete
```

The following example deletes a license named CIFS and serial number 1-81-00000000000000000000123456 from the cluster:

```
cluster1::> system license delete -serial-number 1-81-00000000000000000000123456 -package CIFS
```

The following example deletes from the cluster all of the licenses under the installed-license Core Bundle for serial number 123456789:

```
cluster1::> system license delete { -serial-number 123456789 -installed-license "Core Bundle" }
```

Related information

[ONTAP CLI commands for managing licenses](#)

License types and licensed method

Understanding license types and the licensed method helps you manage the licenses in a cluster.

License types

A package can have one or more of the following license types installed in the cluster. The `system license show` command displays the installed license type or types for a package.

- Standard license (`license`)

A standard license is a node-locked license. It is issued for a node with a specific system serial number (also known as a *controller serial number*). A standard license is valid only for the node that has the matching serial number.

Installing a standard, node-locked license entitles a node to the licensed functionality. For the cluster to use licensed functionality, at least one node must be licensed for the functionality. It might be out of compliance to use licensed functionality on a node that does not have an entitlement for the functionality.

- Site license (`site`)

A site license is not tied to a specific system serial number. When you install a site license, all nodes in the cluster are entitled to the licensed functionality. The `system license show` command displays site licenses under the cluster serial number.

If your cluster has a site license and you remove a node from the cluster, the node does not carry the site license with it, and it is no longer entitled to the licensed functionality. If you add a node to a cluster that has a site license, the node is automatically entitled to the functionality granted by the site license.

- Evaluation license (`demo`)

An evaluation license is a temporary license that expires after a certain period of time (indicated by the `system license show` command). It enables you to try certain software functionality without purchasing an entitlement. It is a cluster-wide license, and it is not tied to a specific serial number of a node.

If your cluster has an evaluation license for a package and you remove a node from the cluster, the node does not carry the evaluation license with it.

Licensed method

It is possible to install both a cluster-wide license (the `site` or `demo` type) and a node-locked license (the `license` type) for a package. Therefore, an installed package can have multiple license types in the cluster. However, to the cluster, there is only one *licensed method* for a package. The `licensed method` field of the `system license status show` command displays the entitlement that is being used for a package. The command determines the licensed method as follows:

- If a package has only one license type installed in the cluster, the installed license type is the licensed method.
- If a package does not have any licenses installed in the cluster, the licensed method is `none`.

- If a package has multiple license types installed in the cluster, the licensed method is determined in the following priority order of the license type--`site`, `license`, and `demo`.

For example:

- If you have a site license, a standard license, and an evaluation license for a package, the licensed method for the package in the cluster is `site`.
- If you have a standard license and an evaluation license for a package, the licensed method for the package in the cluster is `license`.
- If you have only an evaluation license for a package, the licensed method for the package in the cluster is `demo`.

Commands for managing licenses in ONTAP

You can use the ONTAP CLI `system license` commands to manage feature licenses for the cluster. You use the `system feature-usage` commands to monitor feature usage.

Learn more about the commands described in this topic in the [ONTAP command reference](#).

The following table lists some of the common CLI commands for managing licenses and links to the command man pages for additional information.

If you want to...	Use this command...
Display all packages that require licenses and their current license status, including the following: <ul style="list-style-type: none"> • The package name • The licensed method • The expiration date, if applicable 	system license show-status
Display or remove expired or unused licenses	system license clean-up
Display summary of feature usage in the cluster on a per-node basis	system feature-usage show-summary
Display feature usage status in the cluster on a per-node and per-week basis	system feature-usage show-history
Display the status of license entitlement risk for each license package	system license entitlement-risk show

Related information

- [ONTAP command reference](#)
- [NetApp Knowledge Base: ONTAP 9.10.1 and later licensing overview](#)
- [Use System Manager to install a NetApp license file](#)
- [system feature](#)

Cluster management with the CLI

Learn about cluster administration with the ONTAP CLI

You can administer ONTAP systems with the command-line interface (CLI). You can use the ONTAP management interfaces, access the cluster, manage nodes, and much more.

You should use these procedures under the following circumstances:

- You want to understand the range of ONTAP administrator capabilities.
- You want to use the CLI, not System Manager or an automated scripting tool.

Related information

For details about CLI syntax and usage, see the [ONTAP command reference](#) documentation.

Cluster and SVM administrators

Learn about ONTAP cluster and SVM administrator roles

Cluster administrators administer the entire cluster and the storage virtual machines (SVMs, formerly known as Vservers) it contains. SVM administrators administer only their own data SVMs.

Cluster administrators can administer the entire cluster and its resources. They can also set up data SVMs and delegate SVM administration to SVM administrators. The specific capabilities that cluster administrators have depend on their access-control roles. By default, a cluster administrator with the “admin” account name or role name has all capabilities for managing the cluster and SVMs.

SVM administrators can administer only their own SVM storage and network resources, such as volumes, protocols, LIFs, and services. The specific capabilities that SVM administrators have depend on the access-control roles that are assigned by cluster administrators.



The ONTAP command-line interface (CLI) continues to use the term *Vserver* in the output, and `vserver` as a command or parameter name has not changed.

Enable or disable web browser access to ONTAP System Manager

You can enable or disable a web browser’s access to System Manager. You can also view the System Manager log.

You can control a web browser’s access to System Manager by using `vserver services web modify -name sysmgr -vserver <cluster_name> -enabled [true|false]`.

System Manager logging is recorded in the `/mroot/etc/log/mlog/sysmgr.log` files of the node that hosts the cluster management LIF at the time System Manager is accessed. You can view the log files by using a browser. The System Manager log is also included in AutoSupport messages.

Learn about the ONTAP cluster management server

The cluster management server, also called an *adminSVM*, is a specialized storage virtual machine (SVM) implementation that presents the cluster as a single manageable entity. In addition to serving as the highest-level administrative domain, the cluster management server owns resources that do not logically belong with a data SVM.

The cluster management server is always available on the cluster. You can access the cluster management server through the console or cluster management LIF.

Upon failure of its home network port, the cluster management LIF automatically fails over to another node in the cluster. Depending on the connectivity characteristics of the management protocol you are using, you might or might not notice the failover. If you are using a connectionless protocol (for example, SNMP) or have a limited connection (for example, HTTP), you are not likely to notice the failover. However, if you are using a long-term connection (for example, SSH), then you will have to reconnect to the cluster management server after the failover.

When you create a cluster, all of the characteristics of the cluster management LIF are configured, including its IP address, netmask, gateway, and port.

Unlike a data SVM or node SVM, a cluster management server does not have a root volume or host user volumes (though it can host system volumes). Furthermore, a cluster management server can only have LIFs of the cluster management type.

If you run the `vserver show` command, the cluster management server appears in the output listing for that command.

Types of SVMs in an ONTAP cluster

A cluster consists of four types of SVMs, which help in managing the cluster and its resources and data access to the clients and applications.

A cluster contains the following types of SVMs:

- Admin SVM

The cluster setup process automatically creates the admin SVM for the cluster. The admin SVM represents the cluster.

- Node SVM

A node SVM is created when the node joins the cluster, and the node SVM represents the individual nodes of the cluster.

- System SVM (advanced)

A system SVM is automatically created for cluster-level communications in an IPspace.

- Data SVM

A data SVM represents the data serving SVMs. After the cluster setup, a cluster administrator must create data SVMs and add volumes to these SVMs to facilitate data access from the cluster.

A cluster must have at least one data SVM to serve data to its clients.



Unless otherwise specified, the term SVM refers to a data (data-serving) SVM.

In the CLI, SVMs are displayed as Vservers.

Access the cluster by using the CLI (cluster administrators only)

Access an ONTAP cluster using the node serial port

You can access the cluster directly from a console that is attached to a node's serial port.

Steps

1. At the console, press Enter.

The system responds with the login prompt.

2. At the login prompt, do one of the following:

To access the cluster with...	Enter the following account name...
The default cluster account	admin
An alternative administrative user account	<i>username</i>

The system responds with the password prompt.

3. Enter the password for the admin or administrative user account, and then press Enter.

Access an ONTAP cluster using SSH requests

You can issue SSH requests to an ONTAP cluster to perform administrative tasks. SSH is enabled by default.

Before you begin

- You must have a user account that is configured to use `ssh` as an access method.

The `-application` parameter of the `security login` commands specifies the access method for a user account. Learn more about `security login` in the [ONTAP command reference](#).

- If you use an Active Directory (AD) domain user account to access the cluster, an authentication tunnel for the cluster must have been set up through a CIFS-enabled storage VM, and your AD domain user account must also have been added to the cluster with `ssh` as an access method and `domain` as the authentication method.

About this task

- You must use an OpenSSH 5.7 or later client.

- Only the SSH v2 protocol is supported; SSH v1 is not supported.
- ONTAP supports a maximum of 64 concurrent SSH sessions per node.

If the cluster management LIF resides on the node, it shares this limit with the node management LIF.

If the rate of incoming connections is higher than 10 per second, the service is temporarily disabled for 60 seconds.

- ONTAP supports only the AES and 3DES encryption algorithms (also known as *ciphers*) for SSH.

AES is supported with 128, 192, and 256 bits in key length. 3DES is 56 bits in key length as in the original DES, but it is repeated three times.

- When FIPS mode is on, SSH clients should negotiate with Elliptic Curve Digital Signature Algorithm (ECDSA) public key algorithms for the connection to be successful.
- If you want to access the ONTAP CLI from a Windows host, you can use a third-party utility such as PuTTY.
- If you use a Windows AD user name to log in to ONTAP, you should use the same uppercase or lowercase letters that were used when the AD user name and domain name were created in ONTAP.

AD user names and domain names are not case-sensitive. However, ONTAP user names are case-sensitive. Case mismatch between the user name created in ONTAP and the user name created in AD results in a login failure.

SSH Authentication options

- Beginning with ONTAP 9.3, you can [enable SSH multifactor authentication](#) for local administrator accounts.

When SSH multifactor authentication is enabled, users are authenticated by using a public key and a password.

- Beginning with ONTAP 9.4, you can [enable SSH multifactor authentication](#) for LDAP and NIS remote users.
- Beginning with ONTAP 9.13.1, you can optionally add certificate validation to the SSH authentication process to enhance login security. To do this, [associate an X.509 certificate with the public key](#) that an account uses. If you log in using SSH with both an SSH public key and an X.509 certificate, ONTAP checks the validity of the X.509 certificate before authenticating with the SSH public key. SSH login is refused if that certificate is expired or revoked, and the SSH public key is automatically disabled.
- Beginning with ONTAP 9.14.1, ONTAP administrators can [add Cisco Duo two-factor authentication to the SSH authentication process](#) to enhance login security. Upon first login after you enable Cisco Duo authentication, users will need to enroll a device to serve as an authenticator for SSH sessions.
- Beginning with ONTAP 9.15.1, administrators can [Configure dynamic authorization](#) to provide additional adaptive authentication to SSH users based on the user's trust score.

Steps

1. From a host with access to the ONTAP cluster's network, enter the `ssh` command in one of the following formats:

- `ssh username@hostname_or_IP [command]`
- `ssh -l username hostname_or_IP [command]`

If you are using an AD domain user account, you must specify `username` in the format of

domainname \\AD_ *accountname* (with double backslashes after the domain name) or "*domainname* \\AD_ *accountname*" (enclosed in double quotation marks and with a single backslash after the domain name).

hostname_or_IP is the host name or the IP address of the cluster management LIF or a node management LIF. Using the cluster management LIF is recommended. You can use an IPv4 or IPv6 address.

command is not required for SSH-interactive sessions.

Examples of SSH requests

The following examples show how the user account named "joe" can issue an SSH request to access a cluster whose cluster management LIF is 10.72.137.28:

```
$ ssh joe@10.72.137.28
Password:
cluster1::> cluster show
Node                Health  Eligibility
-----
node1                true   true
node2                true   true
2 entries were displayed.
```

```
$ ssh -l joe 10.72.137.28 cluster show
Password:
Node                Health  Eligibility
-----
node1                true   true
node2                true   true
2 entries were displayed.
```

The following examples show how the user account named "john" from the domain named "DOMAIN1" can issue an SSH request to access a cluster whose cluster management LIF is 10.72.137.28:

```
$ ssh DOMAIN1\\john@10.72.137.28
Password:
cluster1::> cluster show
Node                Health  Eligibility
-----
node1                true   true
node2                true   true
2 entries were displayed.
```

```
$ ssh -l "DOMAIN1\john" 10.72.137.28 cluster show
Password:
Node                Health  Eligibility
-----
node1               true   true
node2               true   true
2 entries were displayed.
```

The following example shows how the user account named “joe” can issue an SSH MFA request to access a cluster whose cluster management LIF is 10.72.137.32:

```
$ ssh joe@10.72.137.32
Authenticated with partial success.
Password:
cluster1::> cluster show
Node                Health  Eligibility
-----
node1               true   true
node2               true   true
2 entries were displayed.
```

Related information

[Administrator authentication and RBAC](#)

ONTAP SSH login security

Beginning with ONTAP 9.5, you can view information about previous logins, unsuccessful attempts to log in, and changes to your privileges since your last successful login.

Security-related information is displayed when you successfully log in as an SSH admin user. You are alerted about the following conditions:

- The last time your account name was logged in.
- The number of unsuccessful login attempts since the last successful login.
- Whether the role has changed since the last login (for example, if the admin account’s role changed from "admin" to "backup.")
- Whether the add, modify, or delete capabilities of the role were modified since the last login.



If any of the information displayed is suspicious, you should immediately contact your security department.

To obtain this information when you login, the following prerequisites must be met:

- Your SSH user account must be provisioned in ONTAP.
- Your SSH security login must be created.

- Your login attempt must be successful.

Restrictions and other considerations for SSH login security

The following restrictions and considerations apply to SSH login security information:

- The information is available only for SSH-based logins.
- For group-based admin accounts, such as LDAP/NIS and AD accounts, users can view the SSH login information if the group of which they are a member is provisioned as an admin account in ONTAP.

However, alerts about changes to the role of the user account cannot be displayed for these users. Also, users belonging to an AD group that has been provisioned as an admin account in ONTAP cannot view the count of unsuccessful login attempts that occurred since the last time they logged in.

- The information maintained for a user is deleted when the user account is deleted from ONTAP.
- The information is not displayed for connections to applications other than SSH.

Examples of SSH login security information

The following examples demonstrate the type of information displayed after you login.

- This message is displayed after each successful login:

```
Last Login : 7/19/2018 06:11:32
```

- These messages are displayed if there have been unsuccessful attempts to login since the last successful login:

```
Last Login : 4/12/2018 08:21:26
Unsuccessful login attempts since last login - 5
```

- These messages are displayed if there have been unsuccessful attempts to login and your privileges were modified since the last successful login:

```
Last Login : 8/22/2018 20:08:21
Unsuccessful login attempts since last login - 3
Your privileges have changed since last login
```

Enable Telnet or RSH access to an ONTAP cluster

As a security best practice, Telnet and RSH are disabled by default. To enable the cluster to accept Telnet or RSH requests, you must enable the service in the default management service policy.

Telnet and RSH are not secure protocols; you should consider using SSH to access the cluster. SSH provides a secure remote shell and interactive network session. For more information, refer to [Access the cluster using SSH](#).

About this task

- ONTAP supports a maximum of 50 concurrent Telnet or RSH sessions per node.

If the cluster management LIF resides on the node, it shares this limit with the node management LIF.

If the rate of incoming connections is higher than 10 per second, the service is temporarily disabled for 60 seconds.

- RSH commands require advanced privileges.

ONTAP 9.10.1 or later

Steps

1. Confirm that the RSH or Telnet security protocol is enabled:

```
security protocol show
```

- a. If the RSH or Telnet security protocol is enabled, continue to the next step.
- b. If the RSH or Telnet security protocol is not enabled, use the following command to enable it:

```
security protocol modify -application <rsh/telnet> -enabled true
```

Learn more about `security protocol show` and `security protocol modify` in the [ONTAP command reference](#).

2. Confirm that the `management-rsh-server` or `management-telnet-server` service exists on the management LIFs:

```
network interface show -services management-rsh-server
```

or

```
network interface show -services management-telnet-server
```

Learn more about `network interface show` in the [ONTAP command reference](#).

- a. If the `management-rsh-server` or `management-telnet-server` service exists, continue to the next step.
- b. If the `management-rsh-server` or `management-telnet-server` service does not exist, use the following command to add it:

```
network interface service-policy add-service -vserver cluster1 -policy  
default-management -service management-rsh-server
```

```
network interface service-policy add-service -vserver cluster1 -policy  
default-management -service management-telnet-server
```

Learn more about `network interface service-policy add-service` in the [ONTAP command reference](#).

ONTAP 9.9 or earlier

About this task

ONTAP prevents you from changing predefined firewall policies, but you can create a new policy by cloning the predefined `mgmt` management firewall policy, and then enabling Telnet or RSH under the new policy.

Steps

1. Enter the advanced privilege mode:

```
set advanced
```

2. Enable a security protocol (RSH or Telnet):

```
security protocol modify -application security_protocol -enabled true
```

3. Create a new management firewall policy based on the `mgmt` management firewall policy:

```
system services firewall policy clone -policy mgmt -destination-policy policy-name
```

4. Enable Telnet or RSH in the new management firewall policy:

```
system services firewall policy create -policy policy-name -service security_protocol -action allow -ip-list ip_address/netmask
```

To allow all IP addresses, you should specify `-ip-list 0.0.0.0/0`

5. Associate the new policy with the cluster management LIF:

```
network interface modify -vserver cluster_management_LIF -lif cluster_mgmt -firewall-policy policy-name
```

Learn more about `network interface modify` in the [ONTAP command reference](#).

Access an ONTAP cluster using Telnet requests

You can issue Telnet requests to the cluster to perform administrative tasks. Telnet is disabled by default.

Telnet and RSH are not secure protocols; you should consider using SSH to access the cluster. SSH provides a secure remote shell and interactive network session. For more information, refer to [Access the cluster using SSH](#).

Before you begin

The following conditions must be met before you can use Telnet to access the cluster:

- You must have a cluster local user account that is configured to use Telnet as an access method.

The `-application` parameter of the `security login` commands specifies the access method for a user account. Learn more about `security login` in the [ONTAP command reference](#).

About this task

- ONTAP supports a maximum of 50 concurrent Telnet sessions per node.

If the cluster management LIF resides on the node, it shares this limit with the node management LIF.

If the rate of in-coming connections is higher than 10 per second, the service is temporarily disabled for 60 seconds.

- If you want to access the ONTAP CLI from a Windows host, you can use a third-party utility such as PuTTY.
- RSH commands require advanced privileges.

ONTAP 9.10.1 or later

Steps

1. Confirm that the Telnet security protocol is enabled:

```
security protocol show
```

- a. If the Telnet security protocol is enabled, continue to the next step.
- b. If the Telnet security protocol is not enabled, use the following command to enable it:

```
security protocol modify -application telnet -enabled true
```

Learn more about `security protocol show` and `security protocol modify` in the [ONTAP command reference](#).

2. Confirm that the `management-telnet-server` service exists on the management LIFs:

```
network interface show -services management-telnet-server
```

Learn more about `network interface show` in the [ONTAP command reference](#).

- a. If the `management-telnet-server` service exists, continue to the next step.
- b. If the `management-telnet-server` service does not exist, use the following command to add it:

```
network interface service-policy add-service -vserver cluster1 -policy default-management -service management-telnet-server
```

Learn more about `network interface service-policy add-service` in the [ONTAP command reference](#).

ONTAP 9.9 or earlier

Before you begin

The following conditions must be met before you can use Telnet to access the cluster:

- Telnet must already be enabled in the management firewall policy that is used by the cluster or node management LIFs so that Telnet requests can go through the firewall.

By default, Telnet is disabled. The `system services firewall policy show` command with the `-service telnet` parameter displays whether Telnet has been enabled in a firewall policy. Learn more about `system services firewall policy` in the [ONTAP command reference](#).

- If you use IPv6 connections, IPv6 must already be configured and enabled on the cluster, and firewall policies must already be configured with IPv6 addresses.

The `network options ipv6 show` command displays whether IPv6 is enabled. Learn more about `network options ipv6 show` in the [ONTAP command reference](#). The `system services firewall policy show` command displays firewall policies.

Steps

1. From an administration host, enter the following command:

```
telnet hostname_or_IP
```

hostname_or_IP is the host name or the IP address of the cluster management LIF or a node management LIF. Using the cluster management LIF is recommended. You can use an IPv4 or IPv6 address.

Example of a Telnet request

The following example shows how the user named "joe", who has been set up with Telnet access, can issue a Telnet request to access a cluster whose cluster management LIF is 10.72.137.28:

```
admin_host$ telnet 10.72.137.28

Data ONTAP
login: joe
Password:

cluster1::>
```

Access an ONTAP cluster using RSH requests

You can issue RSH requests to the cluster to perform administrative tasks. RSH is not a secure protocol and is disabled by default.

Telnet and RSH are not secure protocols; you should consider using SSH to access the cluster. SSH provides a secure remote shell and interactive network session. For more information, refer to [Access the cluster using SSH](#).

Before you begin

The following conditions must be met before you can use RSH to access the cluster:

- You must have a cluster local user account that is configured to use RSH as an access method.

The `-application` parameter of the `security login` commands specifies the access method for a user account. Learn more about `security login` in the [ONTAP command reference](#).

About this task

- ONTAP supports a maximum of 50 concurrent RSH sessions per node.

If the cluster management LIF resides on the node, it shares this limit with the node management LIF.

If the rate of incoming connections is higher than 10 per second, the service is temporarily disabled for 60 seconds.

- RSH commands require advanced privileges.

ONTAP 9.10.1 or later

Steps

1. Confirm that the RSH security protocol is enabled:

```
security protocol show
```

- a. If the RSH security protocol is enabled, continue to the next step.
- b. If the RSH security protocol is not enabled, use the following command to enable it:

```
security protocol modify -application rsh -enabled true
```

Learn more about `security protocol show` and `security protocol modify` in the [ONTAP command reference](#).

2. Confirm that the `management-rsh-server` service exists on the management LIFs:

```
network interface show -services management-rsh-server
```

Learn more about `network interface show` in the [ONTAP command reference](#).

- a. If the `management-rsh-server` service exists, continue to the next step.
- b. If the `management-rsh-server` service does not exist, use the following command to add it:

```
network interface service-policy add-service -vserver cluster1 -policy default-management -service management-rsh-server
```

Learn more about `network interface service-policy add-service` in the [ONTAP command reference](#).

ONTAP 9.9 or earlier

Before you begin

The following conditions must be met before you can use RSH to access the cluster:

- RSH must already be enabled in the management firewall policy that is used by the cluster or node management LIFs so that RSH requests can go through the firewall.

By default, RSH is disabled. The `system services firewall policy show` command with the `-service rsh` parameter displays whether RSH has been enabled in a firewall policy. Learn more about `system services firewall policy` in the [ONTAP command reference](#).

- If you use IPv6 connections, IPv6 must already be configured and enabled on the cluster, and firewall policies must already be configured with IPv6 addresses.

The `network options ipv6 show` command displays whether IPv6 is enabled. Learn more about `network options ipv6 show` in the [ONTAP command reference](#). The `system services firewall policy show` command displays firewall policies.

Steps

1. From an administration host, enter the following command:

```
rsh hostname_or_IP -l username:passwordcommand
```

`hostname_or_IP` is the host name or the IP address of the cluster management LIF or a node management LIF. Using the cluster management LIF is recommended. You can use an IPv4 or IPv6 address.

`command` is the command you want to execute over RSH.

Example of an RSH request

The following example shows how the user named “joe”, who has been set up with RSH access, can issue an RSH request to run the `cluster show` command:

```
admin_host$ rsh 10.72.137.28 -l joe:password cluster show
```

```
Node                Health  Eligibility
-----
node1                true   true
node2                true   true
2 entries were displayed.

admin_host$
```

Learn more about `cluster show` in the [ONTAP command reference](#).

Use the ONTAP command-line interface

Learn about the ONTAP command-line interface

The ONTAP command-line interface (CLI) provides a command-based view of the management interface. You enter commands at the storage system prompt, and command results are displayed in text.

The CLI command prompt is represented as `cluster_name::>`.

If you set the privilege level (that is, the `-privilege` parameter of the `set` command) to advanced, the prompt includes an asterisk (*), for example:

```
cluster_name::*>
```

Learn more about `set` in the [ONTAP command reference](#).

Learn about the different ONTAP shells for CLI commands

The cluster has three different shells for CLI commands, the *clustershell*, the *nodeshell*, and the *systemshell*. The shells are for different purposes, and they each have a different command set.

- The clustershell is the native shell that is started automatically when you log in to the cluster.

It provides all the commands you need to configure and manage the cluster. The clustershell CLI help (triggered by `?` at the clustershell prompt) displays available clustershell commands. The `man` command in the clustershell displays the man page for the specified clustershell command (`man <command_name>`). Learn more about `man` in the [ONTAP command reference](#).

- The nodeshell is a special shell for commands that take effect only at the node level.

The nodeshell is accessible through the `system node run` command. Learn more about `system node run` in the [ONTAP command reference](#).

The nodeshell CLI help (triggered by `?` or `help` at the nodeshell prompt) displays available nodeshell commands. The `man` command in the nodeshell displays the man page for the specified nodeshell command.

Many commonly used nodeshell commands and options are tunneled or aliased into the clustershell and can be executed also from the clustershell.

- The systemshell is a low-level shell that is used only for diagnostic and troubleshooting purposes.

The systemshell and the associated `diag` account are intended for low-level diagnostic purposes. Their access requires the diagnostic privilege level and is reserved only for technical support to perform troubleshooting tasks.

Learn more about the commands described in this procedure in the [ONTAP command reference](#).

Access of nodeshell commands and options in the clustershell

Nodeshell commands and options are accessible through the nodeshell:

```
system node run -node nodename
```

Many commonly used nodeshell commands and options are tunneled or aliased into the clustershell and can be executed also from the clustershell.

Nodeshell options that are supported in the clustershell can be accessed by using the `vserver options clustershell` command. To see these options, you can query the clustershell CLI with `vserver options -vserver nodename_or_clustername -option-name ?`

If you enter a nodeshell or legacy command or option in the clustershell, and the command or option has an equivalent clustershell command, ONTAP informs you of the clustershell command to use.

If you enter a nodeshell or legacy command or option that is not supported in the clustershell, ONTAP informs you of the “not supported” status for the command or option.

Display available nodeshell commands

You can obtain a list of available nodeshell commands by using the CLI help from the nodeshell.

Steps

1. To access the nodeshell, enter the following command at the clustershell’s system prompt:

```
system node run -node {nodename|local}
```

`local` is the node you used to access the cluster.



The `system node run` command has an alias command, `run`.

2. Enter the following command in the nodeshell to see the list of available nodeshell commands:

```
[commandname] help
```

commandname is the name of the command whose availability you want to display. If you do not include *commandname*, the CLI displays all available nodeshell commands.

You enter `exit` or type Ctrl-d to return to the clustershell CLI.

Learn more about `exit` in the [ONTAP command reference](#).

Example of displaying available nodeshell commands

The following example accesses the nodeshell of a node named `node2` and displays information for the nodeshell command `environment`:

```
cluster1::> system node run -node node2
Type 'exit' or 'Ctrl-D' to return to the CLI

node2> environment help
Usage: environment status |
      [status] [shelf [<adapter>[.<shelf-number>]]] |
      [status] [shelf_log] |
      [status] [shelf_stats] |
      [status] [shelf_power_status] |
      [status] [chassis [all | list-sensors | Temperature | PSU 1 |
      PSU 2 | Voltage | SYS FAN | NVRAM6-temperature-3 | NVRAM6-battery-3]]
```

How to navigate through ONTAP CLI command directories

Commands in the CLI are organized into a hierarchy by command directories. You can run commands in the hierarchy either by entering the full command path or by navigating through the directory structure.

When using the CLI, you can access a command directory by typing the directory's name at the prompt and then pressing Enter. The directory name is then included in the prompt text to indicate that you are interacting with the appropriate command directory. To move deeper into the command hierarchy, you type the name of a command subdirectory followed by pressing Enter. The subdirectory name is then included in the prompt text and the context shifts to that subdirectory.

You can navigate through several command directories by entering the entire command. For example, you can display information about disk drives by entering the `storage disk show` command at the prompt. You can also run the command by navigating through one command directory at a time, as shown in the following example:

```
cluster1::> storage
cluster1::storage> disk
cluster1::storage disk> show
```

Learn more about `storage disk show` in the [ONTAP command reference](#).

You can abbreviate commands by entering only the minimum number of letters in a command that makes the command unique to the current directory. For example, to abbreviate the command in the previous example, you can enter `st d sh`. You can also use the Tab key to expand abbreviated commands and to display a command's parameters, including default parameter values.

You can use the `top` command to go to the top level of the command hierarchy, and the `up` command or `..` command to go up one level in the command hierarchy.



Commands and command options preceded by an asterisk (*) in the CLI can be executed only at the advanced privilege level or higher.

Related information

- [top](#)
- [up](#)

Understand the rules to specify values in ONTAP CLI

Most commands include one or more required or optional parameters. Many parameters require you to specify a value for them. A few rules exist for specifying values in the CLI.

- A value can be a number, a Boolean specifier, a selection from an enumerated list of predefined values, or a text string.

Some parameters can accept a comma-separated list of two or more values. Comma-separated lists of values do not need to be in quotation marks (" "). Whenever you specify text, a space, or a query character (when not meant as a query or text starting with a less-than or greater-than symbol), you must enclose the entity in quotation marks.

- The CLI interprets a question mark (?) as the command to display help information for a particular command.
- Some text that you enter in the CLI, such as command names, parameters, and certain values, is not case-sensitive.

For example, when you enter parameter values for the `vserver cifs` commands, capitalization is ignored. However, most parameter values, such as the names of nodes, storage virtual machines (SVMs), aggregates, volumes, and logical interfaces, are case-sensitive.

- If you want to clear the value of a parameter that takes a string or a list, you specify an empty set of quotation marks ("") or a dash ("-").
- The hash sign (#), also known as the pound sign, indicates a comment for a command-line input; if used, it should appear after the last parameter in a command line.

The CLI ignores the text between # and the end of the line.

In the following example, an SVM is created with a text comment. The SVM is then modified to delete the comment:

```
cluster1::> vserver create -vserver vs0 -subtype default -rootvolume
root_vs0
-aggregate aggr1 -rootvolume-security-style unix -language C.UTF-8 -is
-repository false -ipspace ipspaceA -comment "My SVM"
cluster1::> vserver modify -vserver vs0 -comment ""
```

In the following example, a command-line comment that uses the # sign indicates what the command does.

```
cluster1::> security login create -vserver vs0 -user-or-group-name new-
admin
-application ssh -authmethod password #This command creates a new user
account
```

Learn more about `security login create` in the [ONTAP command reference](#).

View ONTAP command history and rerun any command from the history

Each CLI session keeps a history of all commands issued in it. You can view the command history of the session that you are currently in. You can also reissue commands.

To view the command history, you can use the `history` command.

To reissue a command, you can use the `redo` command with one of the following arguments:

- A string that matches part of a previous command

For example, if the only `volume` command you have run is `volume show`, you can use the `redo volume` command to reexecute the command.

- The numeric ID of a previous command, as listed by the `history` command

For example, you can use the `redo 4` command to reissue the fourth command in the history list.

- A negative offset from the end of the history list

For example, you can use the `redo -2` command to reissue the command that you ran two commands ago.

For example, to redo the command that is third from the end of the command history, you would enter the following command:

```
cluster1::> redo -3
```

Related information

- [history](#)
- [redo](#)
- [volume](#)

ONTAP keyboard shortcuts for editing CLI commands

The command at the current command prompt is the active command. Using keyboard shortcuts enables you to edit the active command quickly. These keyboard shortcuts are similar to those of the UNIX tcsh shell and the Emacs editor.

The following table lists the keyboard shortcuts for editing CLI commands. `Ctrl-` indicates that you press and hold the Ctrl key while typing the character specified after it. `Esc-` indicates that you press and release the Esc key and then type the character specified after it.

If you want to...	Use one of these keyboard shortcuts...
Move the cursor back by one character	<ul style="list-style-type: none">• Ctrl-B• Back arrow
Move the cursor forward by one character	<ul style="list-style-type: none">• Ctrl-F• Forward arrow
Move the cursor back by one word	Esc-B
Move the cursor forward by one word	Esc-F
Move the cursor to the beginning of the line	Ctrl-A
Move the cursor to the end of the line	Ctrl-E
Remove the content of the command line from the beginning of the line to the cursor, and save it in the cut buffer. The cut buffer acts like temporary memory, similar to what is called a <i>clipboard</i> in some programs.	Ctrl-U
Remove the content of the command line from the cursor to the end of the line, and save it in the cut buffer	Ctrl-K
Remove the content of the command line from the cursor to the end of the following word, and save it in the cut buffer	Esc-D
Remove the word before the cursor, and save it in the cut buffer	Ctrl-W

If you want to...	Use one of these keyboard shortcuts...
Yank the content of the cut buffer, and push it into the command line at the cursor	Ctrl-Y
Delete the character before the cursor	<ul style="list-style-type: none"> • Ctrl-H • Backspace
Delete the character where the cursor is	Ctrl-D
Clear the line	Ctrl-C
Clear the screen	Ctrl-L
<p>Replace the current content of the command line with the previous entry on the history list.</p> <p>With each repetition of the keyboard shortcut, the history cursor moves to the previous entry.</p>	<ul style="list-style-type: none"> • Ctrl-P • Esc-P • Up arrow
<p>Replace the current content of the command line with the next entry on the history list. With each repetition of the keyboard shortcut, the history cursor moves to the next entry.</p>	<ul style="list-style-type: none"> • Ctrl-N • Esc-N • Down arrow
Expand a partially entered command or list valid input from the current editing position	<ul style="list-style-type: none"> • Tab • Ctrl-I
Display context-sensitive help	?
Escape the special mapping for the question mark (?) character. For instance, to enter a question mark into a command's argument, press Esc and then the ? character.	Esc-?
Start TTY output	Ctrl-Q
Stop TTY output	Ctrl-S

Understand the privilege levels for ONTAP CLI commands

ONTAP commands and parameters are defined at three privilege levels: *admin*, *advanced*, and *diagnostic*. The privilege levels reflect the skill levels required in performing the tasks.

- **admin**

Most commands and parameters are available at this level. They are used for common or routine tasks.

- **advanced**

Commands and parameters at this level are used infrequently, require advanced knowledge, and can cause problems if used inappropriately.

You use advanced commands or parameters only with the advice of support personnel.

- **diagnostic**

Diagnostic commands and parameters are potentially disruptive. They are used only by support personnel to diagnose and fix problems.

Set the privilege level in the ONTAP CLI

You can set the privilege level in the CLI by using the `set` command. Changes to privilege level settings apply only to the session you are in. They are not persistent across sessions.

Steps

1. To set the privilege level in the CLI, use the `set` command with the `-privilege` parameter.

Example of setting the privilege level

The following example sets the privilege level to advanced and then to admin:

```
cluster1::> set -privilege advanced
Warning: These advanced commands are potentially dangerous; use them only
when directed to do so by NetApp personnel.
Do you wish to continue? (y or n): y
cluster1::*> set -privilege admin
```

Learn more about `set` in the [ONTAP command reference](#).

Set display preferences for the ONTAP CLI

You can set display preferences for a CLI session by using the `set` command and `rows` command. The preferences you set apply only to the session you are in. They are not persistent across sessions.

About this task

You can set the following CLI display preferences:

- The privilege level of the command session
- Whether confirmations are issued for potentially disruptive commands
- Whether `show` commands display all fields
- The character or characters to use as the field separator

- The default unit when reporting data sizes
- The number of rows the screen displays in the current CLI session before the interface pauses output

If the preferred number of rows is not specified, it is automatically adjusted based on the actual height of the terminal. If the actual height is undefined, the default number of rows is 24.

- The default storage virtual machine (SVM) or node
- Whether a continuing command should stop if it encounters an error

Steps

1. To set CLI display preferences, use the `set` command.

To set the number of rows the screen displays in the current CLI session, you can also use the `rows` command.

Learn more about `set` and `rows` in the [ONTAP command reference](#).

Example of setting display preferences in the CLI

The following example sets a comma to be the field separator, sets GB as the default data-size unit, and sets the number of rows to 50:

```
cluster1::> set -showseparator "," -units GB
cluster1::> rows 50
```

Related information

- [show](#)
- [set](#)
- [rows](#)

Use query operators in the ONTAP CLI

The management interface supports queries and UNIX-style patterns and wildcards to enable you to match multiple values in command-parameter arguments.

The following table describes the supported query operators:

Operator	Description
*	Wildcard that matches all entries. For example, the command <code>volume show -volume *tmp*</code> displays a list of all volumes whose names include the string <code>tmp</code> .
!	NOT operator. Indicates a value that is not to be matched; for example, <code>!vs0</code> indicates not to match the value <code>vs0</code> .

Operator	Description
	OR operator. Separates two values that are to be compared; for example, vs0 vs2 matches either vs0 or vs2. You can specify multiple OR statements; for example, a b* *c* matches the entry a, any entry that starts with b, and any entry that includes c.
..	Range operator. For example, 5..10 matches any value from 5 to 10, inclusive.
<	Less-than operator. For example, <20 matches any value that is less than 20.
>	Greater-than operator. For example, >5 matches any value that is greater than 5.
<=	Less-than-or-equal-to operator. For example, ≤5 matches any value that is less than or equal to 5.
>=	Greater-than-or-equal-to operator. For example, ≥5 matches any value that is greater than or equal to 5.
{query}	Extended query. An extended query must be specified as the first argument after the command name, before any other parameters. For example, the command <code>volume modify {-volume *tmp*} -state offline sets offline</code> all volumes whose names include the string tmp.

If you want to parse query characters as literals, you must enclose the characters in double quotes (for example, "`<10`", "`0..100`", "`*abc*`", or "`a|b`") for the correct results to be returned.

You must enclose raw file names in double quotes to prevent the interpretation of special characters. This also applies to special characters used by the clustershell.

You can use multiple query operators in one command line. For example, the command `volume show -size >1GB -percent-used <50 -vserver !vs1` displays all volumes that are greater than 1 GB in size, less than 50% used, and not in the storage virtual machine (SVM) named "vs1".

Related information

[Keyboard shortcuts for editing CLI commands](#)

Use extended queries with modify and delete commands in the ONTAP CLI

You can use extended queries to match and perform operations on objects that have specified values.

You specify extended queries by enclosing them within curly brackets (`{}`). An extended query must be specified as the first argument after the command name, before any other parameters. For example, to set offline all volumes whose names include the string `tmp`, you run the command in the following example:

```
cluster1::> volume modify {-volume *tmp*} -state offline
```

Extended queries are generally useful only with `modify` and `delete` commands. They have no meaning in `create` or `show` commands.

The combination of queries and modify operations is a useful tool. However, it can potentially cause confusion and errors if implemented incorrectly. For example, using the (advanced privilege) `system node image modify` command to set a node's default software image automatically sets the other software image not to be the default. The command in the following example is effectively a null operation:

```
cluster1::*> system node image modify {-isdefault true} -isdefault false
```

This command sets the current default image as the non-default image, then sets the new default image (the previous non-default image) to the non-default image, resulting in the original default settings being retained. To perform the operation correctly, you can use the command as given in the following example:

```
cluster1::*> system node image modify {-iscurrent false} -isdefault true
```

Limit the output of the ONTAP show command using the fields parameter

When you use the `-instance` parameter with a `show` command to display details, the output can be lengthy and include more information than you need. The `-fields` parameter of a `show` command enables you to display only the information you specify.

For example, running `volume show -instance` is likely to result in several screens of information. You can use `volume show -fields fieldname[,fieldname...]` to customize the output so that it includes only the specified field or fields (in addition to the default fields that are always displayed.) You can use `-fields ?` to display valid fields for a `show` command.

The following example shows the output difference between the `-instance` parameter and the `-fields` parameter:

```

cluster1::> volume show -instance

                                Vserver Name: cluster1-1
                                Volume Name: vol0
                                Aggregate Name: aggr0
                                Volume Size: 348.3GB
                                Volume Data Set ID: -
                                Volume Master Data Set ID: -
                                Volume State: online
                                Volume Type: RW
                                Volume Style: flex
                                ...
                                Space Guarantee Style: volume
                                Space Guarantee in Effect: true
                                ...
Press <space> to page down, <return> for next line, or 'q' to quit...
...
cluster1::>

cluster1::> volume show -fields space-guarantee,space-guarantee-enabled

vserver  volume  space-guarantee  space-guarantee-enabled
-----  -
cluster1-1  vol0    volume          true
cluster1-2  vol0    volume          true
vs1        root_vol
          volume          true
vs2        new_vol
          volume          true
vs2        root_vol
          volume          true
...
cluster1::>

```

Use the ONTAP CLI positional parameters in command input

You can take advantage of the positional parameter functionality of the ONTAP CLI to increase efficiency in command input. You can query a command to identify parameters that are positional for the command.

What a positional parameter is

- A positional parameter is a parameter that does not require you to specify the parameter name before specifying the parameter value.
- A positional parameter can be interspersed with nonpositional parameters in the command input, as long as it observes its relative sequence with other positional parameters in the same command, as indicated in

the ***command_name*** ? output.

- A positional parameter can be a required or optional parameter for a command.
- A parameter can be positional for one command but nonpositional for another.



Using the positional parameter functionality in scripts is not recommended, especially when the positional parameters are optional for the command or have optional parameters listed before them.

Identify a positional parameter

You can identify a positional parameter in the ***command_name*** ? command output. A positional parameter has square brackets surrounding its parameter name, in one of the following formats:

- `[-parameter_name] parameter_value` shows a required parameter that is positional.
- `[[[-parameter_name] parameter_value]` shows an optional parameter that is positional.

For example, when displayed as the following in the ***command_name*** ? output, the parameter is positional for the command it appears in:

- `[-lif] <lif-name>`
- `[[[-lif] <lif-name>]`

However, when displayed as the following, the parameter is nonpositional for the command it appears in:

- `-lif <lif-name>`
- `[-lif <lif-name>]`

Examples of using positional parameters

In the following example, the ***volume create*** ? output shows that three parameters are positional for the command: `-volume`, `-aggregate`, and `-size`.

```

cluster1::> volume create ?
  -vserver <vserver name>           Vserver Name
  [-volume] <volume name>          Volume Name
  [-aggregate] <aggregate name>    Aggregate Name
  [[-size] {<integer>[KB|MB|GB|TB|PB]]] Volume Size
  [ -state {online|restricted|offline|force-online|force-offline|mixed} ]
                                     Volume State (default: online)
  [ -type {RW|DP|DC} ]              Volume Type (default: RW)
  [ -policy <text> ]                Export Policy
  [ -user <user name> ]            User ID
  ...
  [ -space-guarantee|-s {none|volume} ] Space Guarantee Style (default:
volume)
  [ -percent-snapshot-space <percent> ] Space Reserved for Snapshot
Copies
  ...

```

In the following example, the `volume create` command is specified without taking advantage of the positional parameter functionality:

```

cluster1::> volume create -vserver svml -volume vol1 -aggregate aggr1 -size 1g
-percent-snapshot-space 0

```

The following examples use the positional parameter functionality to increase the efficiency of the command input. The positional parameters are interspersed with nonpositional parameters in the `volume create` command, and the positional parameter values are specified without the parameter names. The positional parameters are specified in the same sequence indicated by the `volume create ?` output. That is, the value for `-volume` is specified before that of `-aggregate`, which is in turn specified before that of `-size`.

```

cluster1::> volume create vol2 aggr1 1g -vserver svml -percent-snapshot-space 0

```

```

cluster1::> volume create -vserver svml vol3 -snapshot-policy default aggr1
-nvfail off 1g -space-guarantee none

```

How to access the ONTAP CLI man pages

ONTAP manual (man) pages explain how to use ONTAP CLI commands. These pages are available at the command line and are also published in release-specific *command references*.

At the ONTAP command line, use the `man <command_name>` command to display the manual page of the specified command. If you do not specify a command name, the manual page index is displayed. You can use the `man man` command to view information about the `man` command itself. You can exit a man page by entering `q`.

Learn more about the admin-level and advanced-level ONTAP commands available in your release in the [ONTAP command reference](#).

Record an ONTAP CLI session and manage the recorded sessions

You can record a CLI session into a file with a specified name and size limit, then upload the file to an FTP or HTTP destination. You can also display or delete files in which you previously recorded CLI sessions.

Record a CLI session

A record of a CLI session ends when you stop the recording or end the CLI session, or when the file reaches the specified size limit. The default file size limit is 1 MB. The maximum file size limit is 2 GB.

Recording a CLI session is useful, for example, if you are troubleshooting an issue and want to save detailed information or if you want to create a permanent record of space usage at a specific point in time.

Steps

1. Start recording the current CLI session into a file:

```
system script start
```

Learn more about `system script start` in the [ONTAP command reference](#).

ONTAP starts recording your CLI session into the specified file.

2. Proceed with your CLI session.
3. When finished, stop recording the session:

```
system script stop
```

Learn more about `system script stop` in the [ONTAP command reference](#).

ONTAP stops recording your CLI session.

Commands for managing records of CLI sessions

You use the `system script` commands to manage records of CLI sessions.

If you want to...	Use this command...
Start recording the current CLI session in to a specified file	<code>system script start</code>
Stop recording the current CLI session	<code>system script stop</code>
Display information about records of CLI sessions	<code>system script show</code>

If you want to...	Use this command...
Upload a record of a CLI session to an FTP or HTTP destination	<code>system script upload</code>
Delete a record of a CLI session	<code>system script delete</code>

Related information

[ONTAP command reference](#)

Commands for managing the automatic timeout period of CLI sessions

The timeout value specifies how long a CLI session remains idle before being automatically terminated. The CLI timeout value is cluster-wide. That is, every node in a cluster uses the same CLI timeout value.

By default, the automatic timeout period of CLI sessions is 30 minutes.

You use the `system timeout` commands to manage the automatic timeout period of CLI sessions.

If you want to...	Use this command...
Display the automatic timeout period for CLI sessions	<code>system timeout show</code>
Modify the automatic timeout period for CLI sessions	<code>system timeout modify</code>

Related information

[ONTAP command reference](#)

Cluster management (cluster administrators only)

View node-level details in an ONTAP cluster

You can view node names, whether the nodes are healthy, and whether they are eligible to participate in the cluster. At the advanced privilege level, you can also display whether a node holds epsilon.

Steps

1. To view information about the nodes in a cluster, use the `cluster show` command.

If you want the output to show whether a node holds epsilon, run the command at the advanced privilege level.

Learn more about `cluster show` in the [ONTAP command reference](#).

Examples of displaying the nodes in a cluster

The following example displays information about all nodes in a four-node cluster:

```
cluster1::> cluster show
Node                Health  Eligibility
-----
node1                true   true
node2                true   true
node3                true   true
node4                true   true
```

The following example displays detailed information about the node named “node1” at the advanced privilege level:

```
cluster1::> set -privilege advanced
Warning: These advanced commands are potentially dangerous; use them only
when directed to do so by support personnel.
Do you want to continue? {y|n}: y

cluster1::*> cluster show -node node1

      Node: node1
Node UUID: a67f9f34-9d8f-11da-b484-000423b6f094
      Epsilon: false
Eligibility: true
      Health: true
```

View ONTAP cluster-level details

You can display a cluster’s unique identifier (UUID), name, serial number, location, and contact information.

Steps

1. To display a cluster’s attributes, use the `cluster identity show` command.

Example of displaying cluster attributes

The following example displays the name, serial number, location, and contact information of a cluster.

```
cluster1::> cluster identity show

      Cluster UUID: 1cd8a442-86d1-11e0-ae1c-123478563412
      Cluster Name: cluster1
Cluster Serial Number: 1-80-123456
      Cluster Location: Sunnyvale
      Cluster Contact: jsmith@example.com
```

Learn more about `cluster identity show` in the [ONTAP command reference](#).

Modify ONTAP cluster attributes

You can modify a cluster's attributes, such as the cluster name, location, and contact information as needed.

About this task

You cannot change a cluster's UUID, which is set when the cluster is created.

Steps

1. To modify cluster attributes, use the `cluster identity modify` command.

The `-name` parameter specifies the name of the cluster. Learn more about `cluster identity modify` and the rules for specifying the cluster's name in the [ONTAP command reference](#).

The `-location` parameter specifies the location for the cluster.

The `-contact` parameter specifies the contact information such as a name or e-mail address.

Example of renaming a cluster

The following command renames the current cluster ("cluster1") to "cluster2":

```
cluster1::> cluster identity modify -name cluster2
```

View the replication status of the ONTAP cluster rings

You can view the status of cluster replication rings to help you diagnose cluster-wide problems. If your cluster is experiencing problems, support personnel might ask you to perform this task to assist with troubleshooting efforts.

Steps

1. To display the status of cluster replication rings, use the `cluster ring show` command at the advanced privilege level.

Example of displaying cluster ring-replication status

The following example displays the status of the VLDB replication ring on a node named node0:

```

cluster1::> set -privilege advanced
Warning: These advanced commands are potentially dangerous; use them only
when directed to do so by support personnel.
Do you wish to continue? (y or n): y

cluster1::*> cluster ring show -node node0 -unitname vldb
      Node: node0
  Unit Name: vldb
    Status: master
      Epoch: 5
Master Node: node0
  Local Node: node0
    DB Epoch: 5
DB Transaction: 56
  Number Online: 4
    RDB UUID: e492d2c1-fc50-11e1-bae3-123478563412

```

Learn more about `cluster ring show` in the [ONTAP command reference](#).


ONTAP cluster health assessments using quorum and epsilon

Quorum and epsilon are important measures of cluster health and function that together indicate how clusters address potential communications and connectivity challenges.

Quorum is a precondition for a fully functioning cluster. When a cluster is in quorum, a simple majority of nodes are healthy and can communicate with each other. When quorum is lost, the cluster loses the ability to accomplish normal cluster operations. Only one collection of nodes can have quorum at any one time because all of the nodes collectively share a single view of the data. Therefore, if two non-communicating nodes are permitted to modify the data in divergent ways, it is no longer possible to reconcile the data into a single data view.

Each node in the cluster participates in a voting protocol that elects one node *master*; each remaining node is a *secondary*. The master node is responsible for synchronizing information across the cluster. When quorum is formed, it is maintained by continual voting. If the master node goes offline and the cluster is still in quorum, a new master is elected by the nodes that remain online.

Because there is the possibility of a tie in a cluster that has an even number of nodes, one node has an extra fractional voting weight called *epsilon*. If the connectivity between two equal portions of a large cluster fails, the group of nodes containing epsilon maintains quorum, assuming that all of the nodes are healthy. For example, the following illustration shows a four-node cluster in which two of the nodes have failed. However, because one of the surviving nodes holds epsilon, the cluster remains in quorum even though there is not a simple majority of healthy nodes.



Epsilon is automatically assigned to the first node when the cluster is created. If the node that holds epsilon becomes unhealthy, takes over its high-availability partner, or is taken over by its high-availability partner, then epsilon is automatically reassigned to a healthy node in a different HA pair.

Taking a node offline can affect the ability of the cluster to remain in quorum. Therefore, ONTAP issues a warning message if you attempt an operation that will either take the cluster out of quorum or else put it one outage away from a loss of quorum. You can disable the quorum warning messages by using the `cluster quorum-service options modify` command at the advanced privilege level. Learn more about `cluster quorum-service options modify` in the [ONTAP command reference](#).

In general, assuming reliable connectivity among the nodes of the cluster, a larger cluster is more stable than a smaller cluster. The quorum requirement of a simple majority of half the nodes plus epsilon is easier to maintain in a cluster of 24 nodes than in a cluster of two nodes.

A two-node cluster presents some unique challenges for maintaining quorum. Two-node clusters use *cluster HA*, in which neither node holds epsilon; instead, both nodes are continuously polled to ensure that if one node fails, the other has full read-write access to data, as well as access to logical interfaces and management functions.

View storage capacity utilization of system volumes in an ONTAP cluster

System volumes are FlexVol volumes that contain special metadata, such as metadata for file services audit logs. These volumes are visible in the cluster so that you can fully account for storage use in your cluster.

System volumes are owned by the cluster management server (also called the admin SVM), and they are created automatically when file services auditing is enabled.

You can view system volumes by using the `volume show` command, but most other volume operations are not permitted. For example, you cannot modify a system volume by using the `volume modify` command.

This example shows four system volumes on the admin SVM, which were automatically created when file services auditing was enabled for a data SVM in the cluster:

```

cluster1::> volume show -vserver cluster1
Vserver    Volume                Aggregate    State    Type    Size    Available
Used%
-----
-----
cluster1   MDV_aud_1d0131843d4811e296fc123478563412
          aggr0                online     RW      2GB    1.90GB
5%
cluster1   MDV_aud_8be27f813d7311e296fc123478563412
          root_vs0             online     RW      2GB    1.90GB
5%
cluster1   MDV_aud_9dc4ad503d7311e296fc123478563412
          aggr1                online     RW      2GB    1.90GB
5%
cluster1   MDV_aud_a4b887ac3d7311e296fc123478563412
          aggr2                online     RW      2GB    1.90GB
5%
4 entries were displayed.

```

Manage nodes

Add nodes to an ONTAP cluster

After a cluster is created, you can expand it by adding nodes to it. You add only one node at a time.

Before you begin

- Install and configure your new storage system by reviewing the hardware requirements, preparing your site, and installing and cabling the hardware components (controllers, storage shelves and switches). See the following ONTAP hardware systems documentation for details:
 - [AFF systems](#)
 - [ASA systems](#)
 - [AFX systems](#)
 - [ASA R2 systems](#)
 - [FAS systems](#)
- Review your cluster switch model's cabling and configuration considerations for the cluster ports on your new storage system. See the [Switch documentation for ONTAP hardware systems](#)
 - a. Select the **Cluster Switches** or **Shared Switches** in the **Supported switches** tile.
 - b. Select the **Install** documentation for your switch model.
 - c. Search for the **Review cabling and configuration considerations** topic and review it for your storage system.
- If you are adding nodes to a multiple-node cluster, all the existing nodes in the cluster must be healthy (indicated by `cluster show`). Learn more about `cluster show` in the [ONTAP command reference](#).

- If you are adding nodes to a two-node switchless cluster, you must convert your two-node switchless cluster to a switch-attached cluster using a NetApp supported cluster switch.

Switch model	Migration procedure
Broadcom BES-53248	Migrate to a switched NetApp cluster environment
Cisco Nexus 9336C-FX2	Migrate to a two-node switched cluster
Cisco Nexus 9336C-FX2 (Shared Cluster+Storage)	Migrate from a switchless cluster with direct-attached storage
NVIDIA SN2100	Migrate to a two-node switched cluster with NVIDIA SN2100 cluster switches

- If you are adding a second node to a single-node cluster, the second node must have been installed, and the cluster network must have been configured.
- If the cluster has SP automatic configuration enabled, the subnet specified for the SP must have available resources to allow the joining node to use the specified subnet to automatically configure the SP.
- You must have gathered the following information for the new node's node management LIF:
 - Port
 - IP address
 - Netmask
 - Default gateway

About this task

Nodes must be in even numbers so that they can form HA pairs. After you start to add a node to the cluster, you must complete the process. The node must be part of the cluster before you can start to add another node.

Steps

1. Power on the node that you want to add to the cluster.

The node boots, and the Node Setup wizard starts on the console.

```
Welcome to node setup.
```

```
You can enter the following commands at any time:
```

```
"help" or "?" - if you want to have a question clarified,
"back" - if you want to change previously answered questions, and
"exit" or "quit" - if you want to quit the setup wizard.
Any changes you made before quitting will be saved.
```

```
To accept a default or omit a question, do not enter a value.
```

```
Enter the node management interface port [e0M]:
```

2. Exit the Node Setup wizard: `exit`

The Node Setup wizard exits, and a login prompt appears, warning that you have not completed the setup tasks.

Learn more about `exit` in the [ONTAP command reference](#).

3. Log in to the admin account by using the admin user name.

4. Start the Cluster Setup wizard:

```
::> cluster setup
```

```
Welcome to the cluster setup wizard.
```

```
You can enter the following commands at any time:
```

```
"help" or "?" - if you want to have a question clarified,  
"back" - if you want to change previously answered questions, and  
"exit" or "quit" - if you want to quit the cluster setup wizard.  
Any changes you made before quitting will be saved.
```

```
You can return to cluster setup at any time by typing "cluster setup".  
To accept a default or omit a question, do not enter a value....
```

```
Use your web browser to complete cluster setup by accessing  
https://<node_mgmt_or_e0M_IP_address>
```

```
Otherwise, press Enter to complete cluster setup using the  
command line interface:
```



For more information on setting up a cluster using the setup GUI, see the [node management documentation](#). Learn more about cluster setup in the [ONTAP command reference](#).

5. Press Enter to use the CLI to complete this task. When prompted to create a new cluster or join an existing one, enter **join**.

```
Do you want to create a new cluster or join an existing cluster?  
{create, join}:  
join
```

If the ONTAP version running on the new node is different to the version running on the existing cluster, the system reports a `System checks Error: Cluster join operation cannot be performed at this time error`. This is the expected behavior. To continue, run the `cluster add-node -allow-mixed-version-join true -cluster-ips <IP address> -node-names <new_node_name>` command at the advanced privilege level from an existing node in the cluster.

6. Follow the prompts to set up the node and join it to the cluster:

- To accept the default value for a prompt, press Enter.
 - To enter your own value for a prompt, enter the value, and then press Enter.
7. Repeat the preceding steps for each additional node that you want to add.

After you finish

After adding nodes to the cluster, you should enable storage failover for each HA pair.

Related information

- [Mixed version clusters supported for ONTAP software upgrades](#)
- [cluster add-node](#)

Remove nodes from an ONTAP cluster

You can remove unwanted nodes from a cluster, one node at a time. After you remove a node, you must also remove its failover partner. If you are removing a node, then its data becomes inaccessible or erased.

Before you begin

You must satisfy the following conditions before you remove nodes from the cluster:

- More than half of the nodes in the cluster must be healthy.
- All data, volumes, and non-root aggregates must be relocated or removed from the node.
 - All of the data on the node that you want to remove must have been evacuated. This might include [purging data from an encrypted volume](#).
 - All non-root volumes have been [moved](#) from aggregates owned by the node.
 - All non-root aggregates have been [deleted](#) from the node.
- All LIFs and VLANs have been relocated or removed from the node.
 - Data LIFs have been [deleted](#) or [relocated](#) from the node.
 - Cluster management LIFs have been [relocated](#) from the node and the home ports changed.
 - All intercluster LIFs have been [removed](#). When you remove intercluster LIFs a warning is displayed that can be ignored.
 - All VLANs on the node have been [deleted](#).
- The node is not participating in any failover relationships.
 - Storage failover has been [disabled](#) for the node.
 - All LIF failover rules have been [modified](#) to remove ports on the node.
- If the node owns Federal Information Processing Standards (FIPS) disks or self-encrypting disks (SEDs), [disk encryption has been removed](#) by returning the disks to unprotected mode.
 - You might also want to [sanitize FIPS drives or SEDs](#).
- If you have LUNs on the node to be removed, you should [modify the Selective LUN Map \(SLM\) reporting-nodes list](#) before you remove the node.

If you do not remove the node and its HA partner from the SLM reporting-nodes list, access to the LUNs previously on the node can be lost even though the volumes containing the LUNs were moved to another node.

It is recommended that you issue an AutoSupport message to notify NetApp technical support that node removal is underway.



Do not perform operations such as `cluster remove-node`, `cluster unjoin`, and `node rename` when an automated ONTAP upgrade is in progress.

About this task

- If you are running a mixed-version cluster, you can remove the last low-version node by using one of the advanced privilege commands beginning with ONTAP 9.3:
 - ONTAP 9.3: `cluster unjoin -skip-last-low-version-node-check`
 - ONTAP 9.4 and later: `cluster remove-node -skip-last-low-version-node-check`
- If you remove two nodes from a four-node cluster, cluster HA is automatically enabled on the two remaining nodes.



All system and user data, from all disks that are connected to the node, must be made inaccessible to users before removing a node from the cluster.

If a node was incorrectly removed from a cluster, contact NetApp Support for assistance with options for recovery.

Steps

1. Change the privilege level to advanced:

```
set -privilege advanced
```

2. Identify the node in the cluster that has epsilon:

```
cluster show
```

In the following example, "node0" currently holds epsilon:

```
cluster::*>
Node                Health  Eligibility  Epsilon
-----
node0                true    true         true
node1                true    true         false
node2                true    true         false
node3                true    true         false
```

3. If the node that you are removing holds epsilon:
 - a. Move epsilon from the node you are removing:

```
cluster modify -node <name_of_node_to_be_removed> -epsilon false
```

- b. Move epsilon to a node that you are not removing:

```
cluster modify -node <node_name> -epsilon true
```

4. Identify the current master node:

```
cluster ring show
```

The master node is the node that holds processes such as `mgmt`, `vldb`, `vifmgr`, `bcomd`, and `crs`.

5. If the node you are removing is the current master node, enable another node in the cluster to be elected as the master node:

- a. Make the current master node ineligible to participate in the cluster:

```
cluster modify -node <node_name> -eligibility false
```

The node is marked unhealthy until eligibility is restored. When the master node becomes ineligible, one of the remaining nodes is elected by the cluster quorum as the new master.



If you are performing this step on the first node in an HA pair, you should mark only that node as ineligible. Do not modify the status of the HA partner.

If the partner node is selected as the new master, you need to verify if it holds epsilon before making it ineligible. If the partner node holds epsilon, you need to move epsilon to a different node that is remaining in the cluster before making it ineligible. You do this when you repeat these steps to remove the partner node.

- b. Make the previous master node eligible to participate in the cluster again:

```
cluster modify -node <node_name> -eligibility true
```

6. Log into the remote node management LIF or the cluster-management LIF on a node that you are not removing from the cluster.

7. Remove the nodes from the cluster:

For this ONTAP version...	Use this command...
ONTAP 9.3	<pre>cluster unjoin</pre>

For this ONTAP version...	Use this command...
ONTAP 9.4 and later	<p>With node name:</p> <pre>cluster remove-node -node <node_name></pre> <p>With node IP:</p> <pre>cluster remove-node -cluster_ip <node_ip></pre>

If you have a mixed version cluster and you are removing the last lower version node, use the `-skip-last-low-version-node-check` parameter with these commands.

The system informs you of the following:

- You must also remove the node's failover partner from the cluster.
- After the node is removed and before it can rejoin a cluster, you must use boot menu option **(4) Clean configuration and initialize all disks** or option **(9) Configure Advanced Drive Partitioning** to erase the node's configuration and initialize all disks.

A failure message is generated if you have conditions that you must address before removing the node. For example, the message might indicate that the node has shared resources that you must remove or that the node is in a cluster HA configuration or storage failover configuration that you must disable.

If the node is the quorum master, the cluster will briefly lose and then return to quorum. This quorum loss is temporary and does not affect any data operations.

8. If a failure message indicates error conditions, address those conditions and rerun the `cluster remove-node` or `cluster unjoin` command.

The node automatically reboots after it is successfully removed from the cluster.

9. If you are repurposing the node, erase the node configuration and initialize all disks:
 - a. During the boot process, press Ctrl-C to display the boot menu when prompted to do so.
 - b. Select the boot menu option **(4) Clean configuration and initialize all disks**.
10. Return to admin privilege level:

```
set -privilege admin
```

11. Repeat Steps 1 to 9 to remove the failover partner from the cluster.

Related information

- [cluster remove-node](#)

Access ONTAP node logs, core dumps, and MIB files using a web browser

The Service Processor Infrastructure (`spi`) web service is enabled by default to enable a web browser to access the log, core dump, and MIB files of a node in the cluster. The files remain accessible even when the node is down, provided that the node is taken over by its partner.

Before you begin

- The cluster management LIF must be up.

You can use the management LIF of the cluster or a node to access the `spi` web service. However, using the cluster management LIF is recommended.

The `network interface show` command displays the status of all LIFs in the cluster.

Learn more about `network interface show` in the [ONTAP command reference](#).

- You must use a local user account to access the `spi` web service, domain user accounts are not supported.
- If your user account does not have the `admin` role (which has access to the `spi` web service by default), your access-control role must be granted access to the `spi` web service.

The `vserver services web access show` command shows what roles are granted access to which web services.

- If you are not using the `admin` user account (which includes the `http` access method by default), your user account must be set up with the `http` access method.

The `security login show` command shows user accounts' access and login methods and their access-control roles.

Learn more about `security login show` in the [ONTAP command reference](#).

- If you want to use HTTPS for secure web access, SSL must be enabled and a digital certificate must be installed.

The `system services web show` command displays the configuration of the web protocol engine at the cluster level.

About this task

The `spi` web service is enabled by default, and the service can be disabled manually (`vserver services web modify -vserver * -name spi -enabled false`).

The `admin` role is granted access to the `spi` web service by default, and the access can be disabled manually (`services web access delete -vserver cluster_name -name spi -role admin`).

Steps

1. Point the web browser to the `spi` web service URL in one of the following formats:

- `http://cluster-mgmt-LIF/spi/`
- `https://cluster-mgmt-LIF/spi/`

`cluster-mgmt-LIF` is the IP address of the cluster management LIF.

2. When prompted by the browser, enter your user account and password.

After your account is authenticated, the browser displays links to the `/mroot/etc/log/`, `/mroot/etc/crash/`, and `/mroot/etc/mib/` directories of each node in the cluster.

Access the system console of an ONTAP node

If a node is hanging at the boot menu or the boot environment prompt, you can access it only through the system console (also called the *serial console*). You can access the system console of a node from an SSH connection to the node's SP or to the cluster.

About this task

Both the SP and ONTAP offer commands that enable you to access the system console. However, from the SP, you can access only the system console of its own node. From the cluster, you can access the system console of any other node in the cluster (other than the local node).

Steps

1. Access the system console of a node:

If you are in the...	Enter this command...
SP CLI of the node	<code>system console</code>
ONTAP CLI	<code>system node run-console</code>

2. Log in to the system console when you are prompted to do so.
3. To exit the system console, press Ctrl-D.

Examples of accessing the system console

The following example shows the result of entering the `system console` command at the "SP node2" prompt. The system console indicates that node2 is hanging at the boot environment prompt. The `boot_ontap` command is entered at the console to boot the node to ONTAP. Ctrl-D is then pressed to exit the console and return to the SP.

```
SP node2> system console
Type Ctrl-D to exit.
```

```
LOADER>
LOADER> boot_ontap
...
*****
*                                     *
* Press Ctrl-C for Boot Menu. *
*                                     *
*****
...
```

(Ctrl-D is pressed to exit the system console.)

```
Connection to 123.12.123.12 closed.
SP node2>
```

The following example shows the result of entering the `system node run-console -node node2` command from ONTAP to access the system console of node2, which is hanging at the boot environment prompt. The `boot_ontap` command is entered at the console to boot node2 to ONTAP. Ctrl-D is then pressed to exit the console and return to ONTAP.

```
cluster1::> system node run-console -node node2
Pressing Ctrl-D will end this session and any further sessions you might
open on top of this session.
Type Ctrl-D to exit.

LOADER>
LOADER> boot_ontap
...
*****
*                                     *
* Press Ctrl-C for Boot Menu. *
*                                     *
*****
...
```

(Ctrl-D is pressed to exit the system console.)

```
Connection to 123.12.123.12 closed.
cluster1::>
```

Manage ONTAP node root volumes and root aggregates

A node's root volume is a FlexVol volume that is installed at the factory or by setup software. It is reserved for system files, log files, and core files. The directory name is `/mroot`, which is accessible only through the systemshell by technical support. The minimum size for a node's root volume depends on the platform model.

Rules governing node root volumes and root aggregates overview

A node's root volume contains special directories and files for that node. The root aggregate contains the root volume. A few rules govern a node's root volume and root aggregate.

- The following rules govern the node's root volume:
 - Unless technical support instructs you to do so, do not modify the configuration or content of the root volume.
 - Do not store user data in the root volume.

Storing user data in the root volume increases the storage giveback time between nodes in an HA pair.

- You can move the root volume to another aggregate. See [Relocate root volumes to new aggregates](#).
- The root aggregate is dedicated to the node's root volume only.

ONTAP prevents you from creating other volumes in the root aggregate.

NetApp Hardware Universe

Free up space on a node's root volume

A warning message appears when a node's root volume has become full or almost full. The node cannot operate properly when its root volume is full. You can free up space on a node's root volume by deleting core dump files, packet trace files, and root volume snapshots.

Steps

1. Display the node's core dump files and their names:

```
system node coredump show
```

2. Delete unwanted core dump files from the node:

```
system node coredump delete
```

3. Access the nodeshell:

```
system node run -node nodename
```

nodename is the name of the node whose root volume space you want to free up.

4. Switch to the nodeshell advanced privilege level from the nodeshell:

```
priv set advanced
```

5. Display and delete the node's packet trace files through the nodeshell:

a. Display all files in the node's root volume:

```
ls /etc
```

b. If any packet trace files (*.trc) are in the node's root volume, delete them individually:

```
rm /etc/log/packet_traces/file_name.trc
```

6. Identify and delete the node's root volume snapshots through the nodeshell:

a. Identify the root volume name:

```
vol status
```

The root volume is indicated by the word "root" in the "Options" column of the `vol status` command output.

In the following example, the root volume is `vol10`:

```
node1*> vol status
```

Volume	State	Status	Options
vol10	online	raid_dp, flex 64-bit	root, nvfail=on

b. Display root volume snapshots:

```
snap list root_vol_name
```

c. Delete unwanted root volume snapshots:

```
snap delete root_vol_namesnapshot_name
```

7. Exit the nodeshell and return to the clustershell:

```
exit
```

Relocate root volumes to new aggregates

The root replacement procedure migrates the current root aggregate to another set of disks without disruption.

About this task

Storage failover must be enabled to relocate root volumes. You can use the `storage failover modify -node nodename -enable true` command to enable failover.

You can change the location of the root volume to a new aggregate in the following scenarios:

- When the root aggregates are not on the disk you prefer
- When you want to rearrange the disks connected to the node
- When you are performing a shelf replacement of the EOS disk shelves

Steps

1. Set the privilege level to advanced:

```
set privilege advanced
```

2. Relocate the root aggregate:

```
system node migrate-root -node nodename -disklist disklist -raid-type raid-type
```

- **-node**

Specifies the node that owns the root aggregate that you want to migrate.

- **-disklist**

Specifies the list of disks on which the new root aggregate will be created. All disks must be spares and owned by the same node. The minimum number of disks required is dependent on the RAID type.

- **-raid-type**

Specifies the RAID type of the root aggregate. The default value is `raid-dp`.

3. Monitor the progress of the job:

```
job show -id jobid -instance
```

Results

If all of the pre-checks are successful, the command starts a root volume replacement job and exits. Expect the node to restart.

Related information

- [storage failover modify](#)

Start or stop an ONTAP node for maintenance or troubleshooting

You might need to start or stop a node for maintenance or troubleshooting reasons. You can do so from the ONTAP CLI, the boot environment prompt, or the SP CLI.

Using the SP CLI command `system power off` or `system power cycle` to turn off or power-cycle a node might cause an improper shutdown of the node (also called a *dirty shutdown*) and is not a substitute for a graceful shutdown using the ONTAP `system node halt` command.

Reboot a node at the system prompt

You can reboot a node in normal mode from the system prompt. A node is configured to boot from the boot device, such as a PC CompactFlash card.

Steps

1. If the cluster contains four or more nodes, verify that the node to be rebooted does not hold epsilon:
 - a. Set the privilege level to advanced:

```
set -privilege advanced
```

b. Determine which node holds epsilon:

```
cluster show
```

The following example shows that “node1” holds epsilon:

```
cluster1::*> cluster show
Node                Health  Eligibility  Epsilon
-----
node1                true    true         true
node2                true    true         false
node3                true    true         false
node4                true    true         false
4 entries were displayed.
```

c. If the node to be rebooted holds epsilon, then remove epsilon from the node:

```
cluster modify -node node_name -epsilon false
```

d. Assign epsilon to a different node that will remain up:

```
cluster modify -node node_name -epsilon true
```

e. Return to the admin privilege level:

```
set -privilege admin
```

2. Use the `system node reboot` command to reboot the node.

If you do not specify the `-skip-lif-migration` parameter, the command attempts to migrate data and cluster management LIFs synchronously to another node prior to the reboot. If the LIF migration fails or times out, the rebooting process is aborted, and ONTAP displays an error to indicate the LIF migration failure.

```
cluster1::> system node reboot -node node1 -reason "software upgrade"
```

The node begins the reboot process. The ONTAP login prompt appears, indicating that the reboot process is complete.

Boot ONTAP at the boot environment prompt

You can boot the current release or the backup release of ONTAP when you are at the boot environment prompt of a node.

Steps

1. Access the boot environment prompt from the storage system prompt by using the `system node halt` command.

The storage system console displays the boot environment prompt.

2. At the boot environment prompt, enter one of the following commands:

To boot...	Enter...
The current release of ONTAP	<code>boot_ontap</code>
The ONTAP primary image from the boot device	<code>boot_primary</code>
The ONTAP backup image from the boot device	<code>boot_backup</code>

If you are unsure about which image to use, you should use `boot_ontap` in the first instance.

Shut down a node

You can shut down a node if it becomes unresponsive or if support personnel direct you to do so as part of troubleshooting efforts.

Steps

1. If the cluster contains four or more nodes, verify that the node to be shut down does not hold epsilon:
 - a. Set the privilege level to advanced:

```
set -privilege advanced
```

- b. Determine which node holds epsilon:

```
cluster show
```

The following example shows that “node1” holds epsilon:

```
cluster1::*> cluster show
Node           Health Eligibility Epsilon
-----
node1          true   true        true
node2          true   true        false
node3          true   true        false
node4          true   true        false
4 entries were displayed.
```

- c. If the node to be shut down holds epsilon, then remove epsilon from the node:

```
cluster modify -node node_name -epsilon false
```

- d. Assign epsilon to a different node that will remain up:

```
cluster modify -node node_name -epsilon true
```

e. Return to the admin privilege level:

```
set -privilege admin
```

2. Use the `system node halt` command to shut down the node.

If you do not specify the `-skip-lif-migration` parameter, the command attempts to migrate data and cluster management LIFs synchronously to another node prior to the shutdown. If the LIF migration fails or times out, the shutdown process is aborted, and ONTAP displays an error to indicate the LIF migration failure.

You can manually trigger a core dump with the shutdown by using both the `-dump` parameter.

The following example shuts down the node named “node1” for hardware maintenance:

```
cluster1::> system node halt -node node1 -reason 'hardware maintenance'
```

Manage an ONTAP node using the boot menu

You can use the boot menu to correct configuration problems on a node, reset the admin password, initialize disks, reset the node configuration, and restore the node configuration information back to the boot device.



If an HA pair is using [encrypting SAS or NVMe drives \(SED, NSE, FIPS\)](#), you must follow the instructions in the topic [Returning a FIPS drive or SED to unprotected mode](#) for all drives within the HA pair prior to initializing the system (boot options 4 or 9). Failure to do this may result in future data loss if the drives are repurposed.

Steps

1. Reboot the node to access the boot menu by using the `system node reboot` command at the system prompt.

The node begins the reboot process.

2. During the reboot process, press Ctrl-C to display the boot menu when prompted to do so.

The node displays the following options for the boot menu:

- (1) Normal Boot.
 - (2) Boot without /etc/rc.
 - (3) Change password.
 - (4) Clean configuration and initialize all disks.
 - (5) Maintenance mode boot.
 - (6) Update flash from backup config.
 - (7) Install new software first.
 - (8) Reboot node.
 - (9) Configure Advanced Drive Partitioning.
 - (10) Set onboard key management recovery secrets.
 - (11) Configure node for external key management.
- Selection (1-11)?



Boot menu option (2) Boot without /etc/rc is obsolete and takes no effect on the system.

3. Select one of the following options by entering the corresponding number:

To...	Select...
Continue to boot the node in normal mode	1) Normal Boot
Change the password of the node, which is also the “admin” account password	3) Change Password
Initialize the node’s disks and create a root volume for the node	<p>4) Clean configuration and initialize all disks</p> <div style="border-left: 1px solid #ccc; padding-left: 10px; margin-top: 10px;">  This menu option erases all data on the disks of the node and resets your node configuration to the factory default settings. </div> <p>Only select this menu item after the node has been removed from a cluster and is not joined to another cluster.</p> <p>For a node with internal or external disk shelves, the root volume on the internal disks is initialized. If there are no internal disk shelves, then the root volume on the external disks is initialized.</p> <p>If the node you want to initialize has disks that are partitioned for root-data partitioning, the disks must be unpartitioned before the node can be initialized, see 9) Configure Advanced Drive Partitioning and Disks and aggregates management.</p>
Perform aggregate and disk maintenance operations and obtain detailed aggregate and disk information.	<p>5) Maintenance mode boot</p> <p>You exit Maintenance mode by using the <code>halt</code> command.</p>

To...	Select...
Restore the configuration information from the node's root volume to the boot device, such as a PC CompactFlash card	<p>6) Update flash from backup config</p> <p>ONTAP stores some node configuration information on the boot device. When the node reboots, the information on the boot device is automatically backed up onto the node's root volume. If the boot device becomes corrupted or needs to be replaced, you must use this menu option to restore the configuration information from the node's root volume back to the boot device.</p>
Install new software on the node	<p>7) Install new software first</p> <p>If the ONTAP software on the boot device does not include support for the storage array that you want to use for the root volume, you can use this menu option to obtain a version of the software that supports your storage array and install it on the node.</p> <p>This menu option is only for installing a newer version of ONTAP software on a node that has no root volume installed. Do <i>not</i> use this menu option to upgrade ONTAP.</p>
Reboot the node	<p>8) Reboot node</p>
Unpartition all disks and remove their ownership information or clean the configuration and initialize the system with whole or partitioned disks	<p>9) Configure Advanced Drive Partitioning</p> <p>The Advanced Drive Partitioning option provides additional management features for disks that are configured for root-data or root-data-data partitioning. The following options are available from Boot Option 9:</p> <div style="border: 1px solid gray; padding: 10px; margin-top: 10px;"> <p>(9a) Unpartition all disks and remove their ownership information.</p> <p>(9b) Clean configuration and initialize system with partitioned disks.</p> <p>(9c) Clean configuration and initialize system with whole disks.</p> <p>(9d) Reboot the node.</p> <p>(9e) Return to main boot menu.</p> </div>

View the attributes of the nodes in an ONTAP cluster

You can view the attributes of one or more nodes in the cluster, for example, the name, owner, location, model number, serial number, how long the node has been running, health state, and eligibility to participate in a cluster.

Steps

1. To display the attributes of a specified node or about all nodes in a cluster, use the `system node show`

command.

Example of displaying information about a node

The following example displays detailed information about node1:

```
cluster1::> system node show -node node1
      Node: node1
      Owner: Eng IT
      Location: Lab 5
      Model: model_number
      Serial Number: 12345678
      Asset Tag: -
      Uptime: 23 days 04:42
      NVRAM System ID: 118051205
      System ID: 0118051205
      Vendor: NetApp
      Health: true
      Eligibility: true
      Differentiated Services: false
      All-Flash Optimized: true
      Capacity Optimized: false
      QLC Optimized: false
      All-Flash Select Optimized: false
      SAS2/SAS3 Mixed Stack Support: none
```

Modify the attributes of an ONTAP node

You can modify the attributes of a node as required. The attributes that you can modify include the node's owner information, location information, asset tag, and eligibility to participate in the cluster.

About this task

A node's eligibility to participate in the cluster can be modified at the advanced privilege level by using the `-eligibility` parameter of the `system node modify` or `cluster modify` command. If you set a node's eligibility to `false`, the node becomes inactive in the cluster.



You cannot modify node eligibility locally. It must be modified from a different node. Node eligibility also cannot be modified with a cluster HA configuration.



You should avoid setting a node's eligibility to `false`, except for situations such as restoring the node configuration or prolonged node maintenance. SAN and NAS data access to the node might be impacted when the node is ineligible.

Steps

1. Use the `system node modify` command to modify a node's attributes.

Example of modifying node attributes

The following command modifies the attributes of the “node1” node. The node’s owner is set to “Joe Smith” and its asset tag is set to “js1234”:

```
cluster1::> system node modify -node node1 -owner "Joe Smith" -assettag js1234
```

Related information

- [system node modify](#)
- [cluster modify](#)

Rename an ONTAP node

You can change a node’s name as required.

Steps

1. To rename a node, use the `system node rename` command.

The `-newname` parameter specifies the new name for the node. Learn more about `system node rename` in the [ONTAP command reference](#).

If you want to rename multiple nodes in the cluster, you must run the command for each node individually.



Node name cannot be “all” because “all” is a system reserved name.

Example of renaming a node

The following command renames node “node1” to “node1a”:

```
cluster1::> system node rename -node node1 -newname node1a
```

Manage a single-node ONTAP cluster

A single-node cluster is a special implementation of a cluster running on a standalone node. Single-node clusters are not recommended because they do not provide redundancy. If the node goes down, data access is lost.



For fault tolerance and nondisruptive operations, it is highly recommended that you configure your cluster with [high-availability \(HA pairs\)](#).

If you choose to configure or upgrade a single-node cluster, you should be aware of the following:

- Root volume encryption is not supported on single-node clusters.
- If you remove nodes to have a single-node cluster, you should modify the cluster ports to serve data traffic by modifying the cluster ports to be data ports, and then creating data LIFs on the data ports.
- For single-node clusters, you can specify the configuration backup destination during software setup. After setup, those settings can be modified using ONTAP commands.


- If there are multiple hosts connecting to the node, each host can be configured with a different operating system such as Windows or Linux. If there are multiple paths from the host to the controller, then ALUA must be enabled on the host.

Ways to configure iSCSI SAN hosts with single nodes

You can configure iSCSI SAN hosts to connect directly to a single node or to connect through one or more IP switches. The node can have multiple iSCSI connections to the switch.


Direct-attached single-node configurations

In direct-attached single-node configurations, one or more hosts are directly connected to the node.




Single-network single-node configurations

In single-network single-node configurations, one switch connects a single node to one or more hosts. Because there is a single switch, this configuration is not fully redundant.



Multi-network single-node configurations

In multi-network single-node configurations, two or more switches connect a single node to one or more hosts. Because there are multiple switches, this configuration is fully redundant.



Ways to configure FC and FC-NVMe SAN hosts with single nodes

You can configure FC and FC-NVMe SAN hosts with single nodes through one or more fabrics. N-Port ID Virtualization (NPIV) is required and must be enabled on all FC switches in the fabric. You cannot directly attach FC or FC-NMVE SAN hosts to single nodes without using an FC switch.

Single-fabric single-node configurations


In single-fabric single-node configurations, there is one switch connecting a single node to one or more hosts. Because there is a single switch, this configuration is not fully redundant.

In single-fabric single-node configurations, multipathing software is not required if you only have a single path from the host to the node.

Multifabric single-node configurations

In multifabric single-node configurations, there are two or more switches connecting a single node to one or more hosts. For simplicity, the following figure shows a multifabric single-node configuration with only two fabrics, but you can have two or more fabrics in any multifabric configuration. In this figure, the storage controller is mounted in the top chassis and the bottom chassis can be empty or can have an IOMX module, as it does in this example.

The FC target ports (0a, 0c, 0b, 0d) in the illustrations are examples. The actual port numbers vary depending on the model of your storage node and whether you are using expansion adapters.



Related information

[NetApp Technical Report 4684: Implementing and Configuring Modern SANs with NVMe-oF](#)

ONTAP upgrade for single-node cluster

You can use the ONTAP CLI to perform an automated update of a single-node cluster. Single-node clusters lack redundancy, this means that updates are always disruptive. You can't perform disruptive upgrades using System Manager.

Before you begin

You must complete upgrade [preparation](#) steps.

Steps

1. Delete the previous ONTAP software package:

```
cluster image package delete -version <previous_package_version>
```

2. Download the target ONTAP software package:

```
cluster image package get -url location
```

```
cluster1::> cluster image package get -url
http://www.example.com/software/9.7/image.tgz
```

```
Package download completed.
Package processing completed.
```

3. Verify that the software package is available in the cluster package repository:

```
cluster image package show-repository
```

```
cluster1::> cluster image package show-repository
Package Version  Package Build Time
-----
9.7              M/DD/YYYY 10:32:15
```

4. Verify that the cluster is ready to be upgraded:

```
cluster image validate -version <package_version_number>
```

```
cluster1::> cluster image validate -version 9.7
```

```
WARNING: There are additional manual upgrade validation checks that must
be performed after these automated validation checks have completed...
```

5. Monitor the progress of the validation:

```
cluster image show-update-progress
```

6. Complete all required actions identified by the validation.

7. Optionally, generate a software upgrade estimate:

```
cluster image update -version <package_version_number> -estimate-only
```

The software upgrade estimate displays details about each component to be updated, and the estimated duration of the upgrade.

8. Perform the software upgrade:

```
cluster image update -version <package_version_number>
```



If an issue is encountered, the update pauses and prompts you to take corrective action. You can use the `cluster image show-update-progress` command to view details about any issues and the progress of the update. After correcting the issue, you can resume the update by using the `cluster image resume-update` command.

9. Display the cluster update progress:

```
cluster image show-update-progress
```

The node is rebooted as part of the update and cannot be accessed while rebooting.

10. Trigger a notification:

```
autosupport invoke -node * -type all -message "Finishing_Upgrade"
```


If your cluster is not configured to send messages, a copy of the notification is saved locally.

Configure the SP/BMC network

Isolate ONTAP management traffic in the network

It is a best practice to configure SP/BMC and the e0M management interface on a subnet dedicated to management traffic. Running data traffic over the management network can cause performance degradation and routing problems.

The management Ethernet port on most storage controllers (indicated by a wrench icon on the rear of the chassis) is connected to an internal Ethernet switch. The internal switch provides connectivity to SP/BMC and to the e0M management interface, which you can use to access the storage system via TCP/IP protocols like Telnet, SSH, and SNMP.



If you plan to use both the remote management device and e0M, you must configure them on the same IP subnet. Since these are low-bandwidth interfaces, the best practice is to configure SP/BMC and e0M on a subnet dedicated to management traffic.

If you cannot isolate management traffic, or if your dedicated management network is unusually large, you should try to keep the volume of network traffic as low as possible. Excessive ingress broadcast or multicast traffic may degrade SP/BMC performance.



Some storage controllers, such as the AFF A800, have two external ports, one for BMC and the other for e0M. For these controllers, there is no requirement to configure BMC and e0M on the same IP subnet.

Learn about ONTAP SP/BMC network configuration

You can enable cluster-level, automatic network configuration for the SP (recommended). You can also leave the SP automatic network configuration disabled (the default) and manage the SP network configuration manually at the node level. A few considerations exist for each case.



This topic applies to both the SP and the BMC.

The SP automatic network configuration enables the SP to use address resources (including the IP address, subnet mask, and gateway address) from the specified subnet to set up its network automatically. With the SP automatic network configuration, you do not need to manually assign IP addresses for the SP of each node. By default, the SP automatic network configuration is disabled; this is because enabling the configuration requires that the subnet to be used for the configuration be defined in the cluster first.

If you enable the SP automatic network configuration, the following scenarios and considerations apply:

- If the SP has never been configured, the SP network is configured automatically based on the subnet specified for the SP automatic network configuration.
- If the SP was previously configured manually, or if the existing SP network configuration is based on a different subnet, the SP network of all nodes in the cluster are reconfigured based on the subnet that you specify in the SP automatic network configuration.

The reconfiguration could result in the SP being assigned a different address, which might have an impact on your DNS configuration and its ability to resolve SP host names. As a result, you might need to update your DNS configuration.

- A node that joins the cluster uses the specified subnet to configure its SP network automatically.
- The `system service-processor network modify` command does not enable you to change the SP IP address.

When the SP automatic network configuration is enabled, the command only allows you to enable or disable the SP network interface.

- If the SP automatic network configuration was previously enabled, disabling the SP network interface results in the assigned address resource being released and returned to the subnet.
- If you disable the SP network interface and then reenabling it, the SP might be reconfigured with a different address.

If the SP automatic network configuration is disabled (the default), the following scenarios and considerations apply:

- If the SP has never been configured, SP IPv4 network configuration defaults to using IPv4 DHCP, and IPv6 is disabled.

A node that joins the cluster also uses IPv4 DHCP for its SP network configuration by default.

- The `system service-processor network modify` command enables you to configure a node's SP IP address.

A warning message appears when you attempt to manually configure the SP network with addresses that are allocated to a subnet. Ignoring the warning and proceeding with the manual address assignment might result in a scenario with duplicate addresses.

If the SP automatic network configuration is disabled after having been enabled previously, the following scenarios and considerations apply:

- If the SP automatic network configuration has the IPv4 address family disabled, the SP IPv4 network defaults to using DHCP, and the `system service-processor network modify` command enables you to modify the SP IPv4 configuration for individual nodes.
- If the SP automatic network configuration has the IPv6 address family disabled, the SP IPv6 network is also disabled, and the `system service-processor network modify` command enables you to enable and modify the SP IPv6 configuration for individual nodes.

Enable ONTAP SP/BMC automatic network configuration

Enabling the SP to use automatic network configuration is preferred over manually configuring the SP network. Because the SP automatic network configuration is cluster wide, you do not need to manually manage the SP network for individual nodes.



This task applies to both the SP and the BMC.

- The subnet you want to use for the SP automatic network configuration must already be defined in the cluster and must have no resource conflicts with the SP network interface.

The `network subnet show` command displays subnet information for the cluster.

Learn more about `network subnet show` in the [ONTAP command reference](#).

The parameter that forces subnet association (the `-force-update-lif-associations` parameter of the `network subnet` commands) is supported only on network LIFs and not on the SP network interface.

- If you want to use IPv6 connections for the SP, IPv6 must already be configured and enabled for ONTAP.

The `network options ipv6 show` command displays the current state of IPv6 settings for ONTAP. Learn more about `network options ipv6 show` in the [ONTAP command reference](#).

Steps

1. Specify the IPv4 or IPv6 address family and name for the subnet that you want the SP to use by using the `system service-processor network auto-configuration enable` command.
2. Display the SP automatic network configuration by using the `system service-processor network auto-configuration show` command.
3. If you subsequently want to disable or reenabling the SP IPv4 or IPv6 network interface for all nodes that are in quorum, use the `system service-processor network modify` command with the `-address -family [IPv4|IPv6]` and `-enable [true|false]` parameters.

When the SP automatic network configuration is enabled, you cannot modify the SP IP address for a node

that is in quorum. You can only enable or disable the SP IPv4 or IPv6 network interface.

If a node is out of quorum, you can modify the node's SP network configuration, including the SP IP address, by running `system service-processor network modify` from the node and confirming that you want to override the SP automatic network configuration for the node. However, when the node joins the quorum, the SP automatic reconfiguration takes place for the node based on the specified subnet.

Configure the ONTAP SP/BMC network manually

If you do not have automatic network configuration set up for the SP, you must manually configure a node's SP network for the SP to be accessible by using an IP address.

Before you begin

If you want to use IPv6 connections for the SP, IPv6 must already be configured and enabled for ONTAP. The `network options ipv6` commands manage IPv6 settings for ONTAP. Learn more about `network options ipv6` in the [ONTAP command reference](#).



This task applies to both the SP and the BMC.

You can configure the SP to use IPv4, IPv6, or both. The SP IPv4 configuration supports static and DHCP addressing, and the SP IPv6 configuration supports static addressing only.

If the SP automatic network configuration has been set up, you do not need to manually configure the SP network for individual nodes, and the `system service-processor network modify` command allows you to only enable or disable the SP network interface.

Steps

1. Configure the SP network for a node by using the `system service-processor network modify` command.
 - The `-address-family` parameter specifies whether the IPv4 or IPv6 configuration of the SP is to be modified.
 - The `-enable` parameter enables the network interface of the specified IP address family.
 - The `-dhcp` parameter specifies whether to use the network configuration from the DHCP server or the network address that you provide.

You can enable DHCP (by setting `-dhcp` to `v4`) only if you are using IPv4. You cannot enable DHCP for IPv6 configurations.

- The `-ip-address` parameter specifies the public IP address for the SP.

A warning message appears when you attempt to manually configure the SP network with addresses that are allocated to a subnet. Ignoring the warning and proceeding with the manual address assignment might result in a duplicate address assignment.

- The `-netmask` parameter specifies the netmask for the SP (if using IPv4.)
- The `-prefix-length` parameter specifies the network prefix-length of the subnet mask for the SP (if using IPv6.)
- The `-gateway` parameter specifies the gateway IP address for the SP.

2. Configure the SP network for the remaining nodes in the cluster by repeating the step 1.

3. Display the SP network configuration and verify the SP setup status by using the `system service-processor network show` command with the `-instance` or `-field setup-status` parameters.

The SP setup status for a node can be one of the following:

- `not-setup` — Not configured
- `succeeded` — Configuration succeeded
- `in-progress` — Configuration in progress
- `failed` — Configuration failed

Example of configuring the SP network

The following example configures the SP of a node to use IPv4, enables the SP, and displays the SP network configuration to verify the settings:

```
cluster1::> system service-processor network modify -node local
-address-family IPv4 -enable true -ip-address 192.168.123.98
-netmask 255.255.255.0 -gateway 192.168.123.1

cluster1::> system service-processor network show -instance -node local

                Node: node1
                Address Type: IPv4
                Interface Enabled: true
                Type of Device: SP
                Status: online
                Link Status: up
                DHCP Status: none
                IP Address: 192.168.123.98
                MAC Address: ab:cd:ef:fe:ed:02
                Netmask: 255.255.255.0
                Prefix Length of Subnet Mask: -
                Router Assigned IP Address: -
                Link Local IP Address: -
                Gateway IP Address: 192.168.123.1
                Time Last Updated: Thu Apr 10 17:02:13 UTC 2014
                Subnet Name: -
                Enable IPv6 Router Assigned Address: -
                SP Network Setup Status: succeeded
                SP Network Setup Failure Reason: -

1 entries were displayed.

cluster1::>
```

Modify the ONTAP Service Processor API configuration

The SP API is a secure network API that enables ONTAP to communicate with the SP over the network. You can change the port used by the SP API service, renew the certificates the service uses for internal communication, or disable the service entirely. You need to modify the configuration only in rare situations.

About this task

- The SP API service uses port 50000 by default.

You can change the port value if, for example, you are in a network setting where port 50000 is used for communication by another networking application, or you want to differentiate between traffic from other applications and traffic generated by the SP API service.

- The SSL and SSH certificates used by the SP API service are internal to the cluster and not distributed externally.

In the unlikely event that the certificates are compromised, you can renew them.

- The SP API service is enabled by default.

You only need to disable the SP API service in rare situations, such as in a private LAN where the SP is not configured or used and you want to disable the service.

If the SP API service is disabled, the API does not accept any incoming connections. In addition, functionality such as network-based SP firmware updates and network-based SP “down system” log collection becomes unavailable. The system switches to using the serial interface.

Steps

1. Switch to the advanced privilege level by using the `set -privilege advanced` command.
2. Modify the SP API service configuration:

If you want to...	Use the following command...
Change the port used by the SP API service	<code>system service-processor api-service modify with the -port {49152..65535} parameter</code>

If you want to...	Use the following command...
Renew the SSL and SSH certificates used by the SP API service for internal communication	<ul style="list-style-type: none"> • For ONTAP 9.5 or later use <code>system service-processor api-service renew-internal-certificate</code> • For ONTAP 9.4 and earlier use • <code>system service-processor api-service renew-certificates</code> <p>If no parameter is specified, only the host certificates (including the client and server certificates) are renewed.</p> <p>If the <code>-renew-all true</code> parameter is specified, both the host certificates and the root CA certificate are renewed.</p>
comm	
Disable or reenable the SP API service	<code>system service-processor api-service modify with the -is-enabled {true false} parameter</code>

3. Display the SP API service configuration by using the `system service-processor api-service show` command.

Manage nodes remotely using the SP/BMC

Manage an ONTAP node remotely using the SP/BMC

You can manage a node remotely using an onboard controller, called a Service Processor (SP) or Baseboard Management Controller (BMC). This remote management controller is included in all current platform models. The controller stays operational regardless of the operating state of the node.

For a full breakdown of platform SP and BMC support, refer to the [Support Matrix](#) on the NetApp Support site.

Remote node management with the ONTAP Service Processor

The Service Processor (SP) is a remote management device that enables you to access, monitor, and troubleshoot a node remotely.

The key capabilities of the SP include the following:

- The SP enables you to access a node remotely to diagnose, shut down, power-cycle, or reboot the node, regardless of the state of the node controller.

The SP is powered by a standby voltage, which is available as long as the node has input power from at least one of its power supplies.

You can log in to the SP by using a Secure Shell client application from an administration host. You can then use the SP CLI to monitor and troubleshoot the node remotely. In addition, you can use the SP to access the serial console and run ONTAP commands remotely.

You can access the SP from the serial console or access the serial console from the SP. The SP enables you to open both an SP CLI session and a separate console session simultaneously.

For instance, when a temperature sensor becomes critically high or low, ONTAP triggers the SP to shut down the motherboard gracefully. The serial console becomes unresponsive, but you can still press Ctrl-G on the console to access the SP CLI. You can then use the `system power on` or `system power cycle` command from the SP to power on or power-cycle the node.

- The SP monitors environmental sensors and logs events to help you take timely and effective service actions.

The SP monitors environmental sensors such as the node temperatures, voltages, currents, and fan speeds. When an environmental sensor has reached an abnormal condition, the SP logs the abnormal readings, notifies ONTAP of the issue, and sends alerts and “down system” notifications as necessary through an AutoSupport message, regardless of whether the node can send AutoSupport messages.

The SP also logs events such as boot progress, Field Replaceable Unit (FRU) changes, events generated by ONTAP, and SP command history. You can manually invoke an AutoSupport message to include the SP log files that are collected from a specified node.

Other than generating these messages on behalf of a node that is down and attaching additional diagnostic information to AutoSupport messages, the SP has no effect on the AutoSupport functionality. The AutoSupport configuration settings and message content behavior are inherited from ONTAP.



The SP does not rely on the `-transport` parameter setting of the `system node autosupport modify` command to send notifications. The SP only uses the Simple Mail Transport Protocol (SMTP) and requires its host's AutoSupport configuration to include mail host information.

If SNMP is enabled, the SP generates SNMP traps to configured trap hosts for all “down system” events.

- The SP has a nonvolatile memory buffer that stores up to 4,000 events in a system event log (SEL) to help you diagnose issues.

The SEL stores each audit log entry as an audit event. It is stored in onboard flash memory on the SP. The event list from the SEL is automatically sent by the SP to specified recipients through an AutoSupport message.

The SEL contains the following information:

- Hardware events detected by the SP—for example, sensor status about power supplies, voltage, or other components
 - Errors detected by the SP—for example, a communication error, a fan failure, or a memory or CPU error
 - Critical software events sent to the SP by the node—for example, a panic, a communication failure, a boot failure, or a user-triggered “down system” as a result of issuing the SP `system reset` or `system power cycle` command
- The SP monitors the serial console regardless of whether administrators are logged in or connected to the console.


When messages are sent to the console, the SP stores them in the console log. The console log persists as long as the SP has power from either of the node power supplies. Because the SP operates with standby power, it remains available even when the node is power-cycled or turned off.

- Hardware-assisted takeover is available if the SP is configured.
- The SP API service enables ONTAP to communicate with the SP over the network.

The service enhances ONTAP management of the SP by supporting network-based functionality such as using the network interface for the SP firmware update, enabling a node to access another node's SP functionality or system console, and uploading the SP log from another node.

You can modify the configuration of the SP API service by changing the port the service uses, renewing the SSL and SSH certificates that are used by the service for internal communication, or disabling the service entirely.

The following diagram illustrates access to ONTAP and the SP of a node. The SP interface is accessed through the Ethernet port (indicated by a wrench icon on the rear of the chassis):



Use the ONTAP Baseboard Management Controller to remotely manage a node

On certain hardware platforms, software is customized to support a new onboard controller in the Baseboard Management Controller (BMC). The BMC has command-line interface (CLI) commands you can use to manage the device remotely.

The BMC works similarly to the Service Processor (SP) and uses many of the same commands. The BMC allows you to do the following:

- Configure the BMC network settings.
- Access a node remotely and perform node management tasks such as diagnose, shut down, power-cycle, or reboot the node.

There are some differences between the SP and BMC:

- The BMC completely controls the environmental monitoring of power supply elements, cooling elements, temperature sensors, voltage sensors, and current sensors. The BMC reports sensor information to ONTAP through IPMI.
- Some of the high-availability (HA) and storage commands are different.
- The BMC does not send AutoSupport messages.

Automatic firmware updates are also available when running ONTAP with the following requirements:

- BMC firmware revision 1.15 or later must be installed.



A manual update is required to upgrade BMC firmware from 1.12 to 1.15 or later.

- BMC automatically reboots after a firmware update is completed.



Node operations are not impacted during a BMC reboot.

Manage ONTAP SP/BMC firmware updates

ONTAP includes an SP firmware image that is called the *baseline image*. If a new version of the SP firmware becomes subsequently available, you have the option to download it and update the SP firmware to the downloaded version without upgrading the ONTAP version.



This topic applies to both the SP and the BMC.

ONTAP offers the following methods for managing SP firmware updates:

- The SP automatic update functionality is enabled by default, allowing the SP firmware to be automatically updated in the following scenarios:
 - When you upgrade to a new version of ONTAP

The ONTAP upgrade process automatically includes the SP firmware update, provided that the SP firmware version bundled with ONTAP is newer than the SP version running on the node.



ONTAP detects a failed SP automatic update and triggers a corrective action to retry the SP automatic update up to three times. If all three retries fail, see the [NetApp Knowledge Base: Health Monitor SPAutoUpgradeFailedMajorAlert SP upgrade fails - AutoSupport Message](#).

- When you download a version of the SP firmware from the NetApp Support Site and the downloaded version is newer than the one that the SP is currently running
- When you downgrade or revert to an earlier version of ONTAP

The SP firmware is automatically updated to the newest compatible version that is supported by the ONTAP version you reverted or downgraded to. A manual SP firmware update is not required.

You have the option to disable the SP automatic update functionality by using the `system service-processor image modify` command. However, it is recommended that you leave the functionality enabled. Disabling the functionality can result in suboptimal or nonqualified combinations between the ONTAP image and the SP firmware image.

- ONTAP enables you to trigger an SP update manually and specify how the update should take place by using the `system service-processor image update` command.

You can specify the following options:

- The SP firmware package to use (`-package`)

You can update the SP firmware to a downloaded package by specifying the package file name. The `advance system image package show` command displays all package files (including the files for the SP firmware package) that are available on a node.

- Whether to use the baseline SP firmware package for the SP update (`-baseline`)

You can update the SP firmware to the baseline version that is bundled with the currently running version of ONTAP.



If you use some of the more advanced update options or parameters, the BMC's configuration settings may be temporarily cleared. After reboot, it can take up to 10 minutes for ONTAP to restore the BMC configuration.

- ONTAP enables you to display the status for the latest SP firmware update triggered from ONTAP by using the `system service-processor image update-progress show` command.

Any existing connection to the SP is terminated when the SP firmware is being updated. This is the case whether the SP firmware update is automatically or manually triggered.

Related information

[NetApp Downloads: System Firmware and Diagnostics](#)

ONTAP SP/BMC and network interface use for firmware updates

An SP firmware update that is triggered from ONTAP with the SP running version 1.5, 2.5, 3.1, or later supports using an IP-based file transfer mechanism over the SP network interface.



This topic applies to both the SP and the BMC.

An SP firmware update over the network interface is faster than an update over the serial interface. It reduces the maintenance window during which the SP firmware is being updated, and it is also nondisruptive to ONTAP operation. The SP versions that support this capability are included with ONTAP. They are also available on the NetApp Support Site and can be installed on controllers that are running a compatible version of ONTAP.

When you are running SP version 1.5, 2.5, 3.1, or later, the following firmware upgrade behaviors apply:

- An SP firmware update that is *automatically* triggered by ONTAP defaults to using the network interface for the update; however, the SP automatic update switches to using the serial interface for the firmware update if one of the following conditions occurs:
 - The SP network interface is not configured or not available.
 - The IP-based file transfer fails.
 - The SP API service is disabled.

Regardless of the SP version you are running, an SP firmware update triggered from the SP CLI always uses the SP network interface for the update.

Related information

[NetApp Downloads: System Firmware and Diagnostics](#)

Access the ONTAP Service Processor using a cluster user account

When you try to access the SP, you are prompted for credential. Cluster user accounts that are created with the `service-processor` application type have access to the SP CLI on any node of the cluster. SP user accounts are managed from ONTAP and authenticated by password. Beginning with ONTAP 9.9.1, SP user accounts must have the `admin` role.

User accounts for accessing the SP are managed from ONTAP instead of the SP CLI. A cluster user account can access the SP if it is created with the `-application` parameter of the `security login create` command set to `service-processor` and the `-authmethod` parameter set to `password`. The SP supports only password authentication.

You must specify the `-role` parameter when creating an SP user account.

- In ONTAP 9.9.1 and later releases, you must specify `admin` for the `-role` parameter, and any modifications to an account require the `admin` role. Other roles are no longer permitted for security reasons.
 - If you are upgrading to ONTAP 9.9.1 or later releases, see [Change in user accounts that can access the Service Processor](#).
 - If you are reverting to ONTAP 9.8 or earlier releases, see [Verify user accounts that can access the Service Processor](#).
- In ONTAP 9.8 and earlier releases, any role can access the SP, but `admin` is recommended.

By default, the cluster user account named “admin” includes the `service-processor` application type and has access to the SP.

ONTAP prevents you from creating user accounts with names that are reserved for the system (such as “root” and “naroot”). You cannot use a system-reserved name to access the cluster or the SP.

You can display current SP user accounts by using the `-application service-processor` parameter of the `security login show` command.

Learn more about `security login show` in the [ONTAP command reference](#).

Access the ONTAP SP/BMC of a node from an administration host

You can log in to the SP of a node from an administration host to perform node management tasks remotely.

Before you begin

The following conditions must be met:

- The administration host you use to access the SP must support SSHv2.
- Your user account must already be set up for accessing the SP.

To access the SP, your user account must have been created with the `-application` parameter of the `security login create` command set to `service-processor` and the `-authmethod` parameter set to `password`.



This task applies to both the SP and the BMC.

If the SP is configured to use an IPv4 or IPv6 address, and if five SSH login attempts from a host fail consecutively within 10 minutes, the SP rejects SSH login requests and suspends the communication with the IP address of the host for 15 minutes. The communication resumes after 15 minutes, and you can try to log in to the SP again.

ONTAP prevents you from creating or using system-reserved names (such as “root” and “naroot”) to access the cluster or the SP.

Steps

1. From the administration host, log in to the SP:

```
ssh username@SP_IP_address
```

2. When you are prompted, enter the password for `username`.

The SP prompt appears, indicating that you have access to the SP CLI.

Examples of SP access from an administration host

The following example shows how to log in to the SP with a user account `joe`, which has been set up to access the SP.

```
[admin_host]$ ssh joe@192.168.123.98
joe@192.168.123.98's password:
SP>
```

The following examples show how to use the IPv6 global address or IPv6 router-advertised address to log in to the SP on a node that has SSH set up for IPv6 and the SP configured for IPv6.

```
[admin_host]$ ssh joe@fd22:8b1e:b255:202::1234
joe@fd22:8b1e:b255:202::1234's password:
SP>
```

```
[admin_host]$ ssh joe@fd22:8b1e:b255:202:2a0:98ff:fe01:7d5b
joe@fd22:8b1e:b255:202:2a0:98ff:fe01:7d5b's password:
SP>
```

Access the ONTAP SP/BMC of a node from the system console

You can access the SP from the system console (also called *serial console*) to perform monitoring or troubleshooting tasks.

About this task

This task applies to both the SP and the BMC.

Steps

1. Access the SP CLI from the system console by pressing Ctrl-G at the prompt.
2. Log in to the SP CLI when you are prompted.

The SP prompt appears, indicating that you have access to the SP CLI.

3. Exit the SP CLI and return to the system console by pressing Ctrl-D, and then press Enter.

Example of accessing the SP CLI from the system console

The following example shows the result of pressing Ctrl-G from the system console to access the SP CLI. The `help system power` command is entered at the SP prompt, followed by pressing Ctrl-D and then Enter to return to the system console.

```
cluster1::>
```

(Press Ctrl-G to access the SP CLI.)

```
Switching console to Service Processor
Service Processor Login:
Password:
SP>
SP> help system power
system power cycle - power the system off, then on
system power off - power the system off
system power on - power the system on
system power status - print system power status
SP>
```

(Press Ctrl-D and then Enter to return to the system console.)

```
cluster1::>
```

Learn how the ONTAP SP CLI, SP console, and system console sessions are related

You can open an SP CLI session to manage a node remotely and open a separate SP console session to access the console of the node. The SP console session mirrors output displayed in a concurrent system console session. The SP and the system console have independent shell environments with independent login authentication.

Understanding how the SP CLI, SP console, and system console sessions are related helps you manage a node remotely. The following describes the relationship among the sessions:

- Only one administrator can log in to the SP CLI session at a time; however, the SP enables you to open both an SP CLI session and a separate SP console session simultaneously.

The SP CLI is indicated with the SP prompt (`SP>`). From an SP CLI session, you can use the `SP system`

`console` command to initiate an SP console session. At the same time, you can start a separate SP CLI session through SSH. If you press Ctrl-D to exit from the SP console session, you automatically return to the SP CLI session. If an SP CLI session already exists, a message asks you whether to terminate the existing SP CLI session. If you enter “y”, the existing SP CLI session is terminated, enabling you to return from the SP console to the SP CLI. This action is recorded in the SP event log.

In an ONTAP CLI session that is connected through SSH, you can switch to the system console of a node by running the ONTAP `system node run-console` command from another node.

- For security reasons, the SP CLI session and the system console session have independent login authentication.

When you initiate an SP console session from the SP CLI (by using the SP `system console` command), you are prompted for the system console credential. When you access the SP CLI from a system console session (by pressing Ctrl-G), you are prompted for the SP CLI credential.

- The SP console session and the system console session have independent shell environments.

The SP console session mirrors output that is displayed in a concurrent system console session. However, the concurrent system console session does not mirror the SP console session.

The SP console session does not mirror output of concurrent SSH sessions.

Add the administration host IP address to access the ONTAP Service Processor

By default, the SP accepts SSH connection requests from administration hosts of any IP addresses. You can configure the SP to accept SSH connection requests from only the administration hosts that have the IP addresses you specify. The changes you make apply to SSH access to the SP of any nodes in the cluster.

Steps

1. Grant SP access to only the IP addresses you specify by using the `system service-processor ssh add-allowed-addresses` command with the `-allowed-addresses` parameter.

- The value of the `-allowed-addresses` parameter must be specified in the format of `address/netmask`, and multiple `address/netmask` pairs must be separated by commas, for example, `10.98.150.10/24, fd20:8b1e:b255:c09b::/64`.

Setting the `-allowed-addresses` parameter to `0.0.0.0/0, ::/0` enables all IP addresses to access the SP (the default).

- When you change the default by limiting SP access to only the IP addresses you specify, ONTAP prompts you to confirm that you want the specified IP addresses to replace the “allow all” default setting (`0.0.0.0/0, ::/0`).
 - The `system service-processor ssh show` command displays the IP addresses that can access the SP.
2. If you want to block a specified IP address from accessing the SP, use the `system service-processor ssh remove-allowed-addresses` command with the `-allowed-addresses` parameter.

If you block all IP addresses from accessing the SP, the SP becomes inaccessible from any administration hosts.

Examples of managing the IP addresses that can access the SP

The following examples show the default setting for SSH access to the SP, change the default by limiting SP access to only the specified IP addresses, remove the specified IP addresses from the access list, and then restore SP access for all IP addresses:

```
cluster1::> system service-processor ssh show
  Allowed Addresses: 0.0.0.0/0, ::/0

cluster1::> system service-processor ssh add-allowed-addresses -allowed
-addresses 192.168.1.202/24, 192.168.10.201/24

Warning: The default "allow all" setting (0.0.0.0/0, ::/0) will be
replaced
      with your changes. Do you want to continue? {y|n}: y

cluster1::> system service-processor ssh show
  Allowed Addresses: 192.168.1.202/24, 192.168.10.201/24

cluster1::> system service-processor ssh remove-allowed-addresses -allowed
-addresses 192.168.1.202/24, 192.168.10.201/24

Warning: If all IP addresses are removed from the allowed address list,
all IP
      addresses will be denied access. To restore the "allow all"
default,
      use the "system service-processor ssh add-allowed-addresses
      -allowed-addresses 0.0.0.0/0, ::/0" command. Do you want to
continue?
      {y|n}: y

cluster1::> system service-processor ssh show
  Allowed Addresses: -

cluster1::> system service-processor ssh add-allowed-addresses -allowed
-addresses 0.0.0.0/0, ::/0

cluster1::> system service-processor ssh show
  Allowed Addresses: 0.0.0.0/0, ::/0
```

View the help information in the ONTAP SP/BMC CLI

The online help displays the SP/BMC CLI commands and options.

About this task

This task applies to both the SP and the BMC.

Steps

1. To display help information for the SP/BMC commands, enter the following:

To access SP help...	To access BMC help...
Type <code>help</code> at the SP prompt.	Type <code>system</code> at the BMC prompt.

The following example shows the SP CLI online help.

```
SP> help
date - print date and time
exit - exit from the SP command line interface
events - print system events and event information
help - print command help
priv - show and set user mode
sp - commands to control the SP
system - commands to control the system
version - print SP version
```

The following example shows the BMC CLI online help.

```
BMC> system
system acp - acp related commands
system battery - battery related commands
system console - connect to the system console
system core - dump the system core and reset
system cpld - cpld commands
system log - print system console logs
system power - commands controlling system power
system reset - reset the system using the selected firmware
system sensors - print environmental sensors status
system service-event - print service-event status
system fru - fru related commands
system watchdog - system watchdog commands

BMC>
```

2. To display help information for the option of an SP/BMC command, enter `help` before or after the SP/BMC command.

The following example shows the SP CLI online help for the SP `events` command.

```
SP> help events
events all - print all system events
events info - print system event log information
events newest - print newest system events
events oldest - print oldest system events
events search - search for and print system events
```

The following example shows the BMC CLI online help for the BMC `system power` command.

```
BMC> system power help
system power cycle - power the system off, then on
system power off - power the system off
system power on - power the system on
system power status - print system power status

BMC>
```

Learn more about the commands described in this procedure in the [ONTAP command reference](#).

Related information

- [events](#)
- [system power](#)

ONTAP commands for remote node management

You can remotely perform node-management tasks by either accessing its SP and running SP CLI commands, or accessing the BMC and running BMC CLI commands. For several commonly performed remote node-management tasks, you can also use ONTAP commands from another node in the cluster. Some SP and BMC commands are platform-specific and might not be available on your platform.

Certain command types can be used in both SP and BMC command sets. The differences between them will be shown when entering the command line.

Examples

- The `help` command in SP: `SP> help`
- The `help` command in BMC: `BMC> help`

Learn more about the `help` command options available for SP and BMC in [View the help information in the ONTAP SP/BMC CLI](#).

Learn more about corresponding ONTAP BMC CLI in [Supported CLI commands for the ONTAP Baseboard Management Controller](#).

If you want to...	Use this SP command...	Use this BMC command...	Use this ONTAP command...
Display available commands or subcommands of a specified command for SP/BMC/ONTAP	help [command]	help [command]	N/A
Display the current privilege level for the SP/BMC/ONTAP CLI	priv show	priv show	N/A
Set the privilege level to access the specified mode for the SP/BMC/ONTAP CLI	priv set {admin advanced diag}	priv set {admin advanced diag test}	N/A
Display system date and time	date	date	date
Display events that are logged by the SP/BMC/ONTAP	events {all info newest number oldest number search keyword}	events {all info newest oldest search }	N/A
Display SP/BMC/ONTAP status and network configuration information	sp status [-v -d] <ul style="list-style-type: none"> • The -v option displays SP statistics in verbose form. • The -d option adds the SP debug log to the display. 	bmc status [-v -d] <ul style="list-style-type: none"> • The -v option displays SP statistics in verbose form. • The -d option adds the SP debug log to the display. 	system service-processor show
Display the length of time the SP/BMC/ONTAP has been up and the average number of jobs in the run queue over the last 1, 5, and 15 minutes	sp uptime	bmc uptime	N/A

If you want to...	Use this SP command...	Use this BMC command...	Use this ONTAP command...
Display system console logs	system log	system log [-a]	system log (prints system console logs)
Display the SP/BMC/ONTAP log archives or the files in an archive	sp log history show [-archive {latest all archive-name}] [-dump {all file-name}]	bmc log history show [-archive {latest all archive-name}] [-dump {all file-name}]	N/A
Display the power status for the controller of a node	system power status	system power status	system node power show
Display battery information	system battery show	system battery show	N/A
Display ACP information or the status for expander sensors	system acp [show sensors show]	N/A	N/A
List all system FRUs and their IDs	system fru list	system fru list	N/A
Display product information for the specified FRU	system fru show fru_id	system fru show [show <id>]	N/A
Display the FRU data history log	system fru log show (advanced privilege level)	system fru log show	N/A
Display the status for the environmental sensors, including their states and current values	system sensors or system sensors show	system sensors {show filter <sensor_string>}	system node environment sensors show

If you want to...	Use this SP command...	Use this BMC command...	Use this ONTAP command...
Display the status and details for the specified sensor	<pre>system sensors get sensor_name</pre> <p>You can obtain <code>sensor_name</code> by using the <code>system sensors</code> or the <code>system sensors show</code> command.</p>	<pre>system sensors [get]</pre>	N/A
Display the SP/BMC/ONTAP firmware version information	<pre>version</pre>	<pre>version</pre>	<pre>system service-processor image show</pre>
Display the SP/BMC/ONTAP command history	<pre>sp log audit</pre> <p>(advanced privilege level)</p>	<pre>bmc log audit</pre> <p>(advanced privilege level)</p>	N/A
Display the SP/BMC/ONTAP debug information	<pre>sp log debug</pre> <p>(advanced privilege level)</p>	<pre>bmc log debug</pre> <p>(advanced privilege level)</p>	N/A
Display the SP/BMC/ONTAP messages file	<pre>sp log messages</pre> <p>(advanced privilege level)</p>	<pre>bmc log messages</pre> <p>(advanced privilege level)</p>	N/A
Display the settings for collecting system forensics on a watchdog reset event, display system forensics information collected during a watchdog reset event, or clear the collected system forensics information	<pre>system forensics</pre> <p>[show log dump log clear]</p>	N/A	N/A
Log in to the system console	<pre>system console</pre>	<pre>system console</pre>	<pre>system node run-console</pre>
You should press Ctrl-D to exit the system console session.			

If you want to...	Use this SP command...	Use this BMC command...	Use this ONTAP command...
Turn the node on or off, or perform a power-cycle (turning the power off and then back on)	system power on	system power on	system node power on (advanced privilege level)
	system power off	system power off	N/A
	system power cycle	system power cycle	N/A
<p>The standby power stays on to keep the SP running without interruption. During the power-cycle, a brief pause occurs before power is turned back on.</p> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;">  <p>Using these commands to turn off or power-cycle the node might cause an improper shutdown of the node (also called a <i>dirty shutdown</i>) and is not a substitute for a graceful shutdown using the ONTAP <code>system node halt</code> command.</p> </div>			
Create a core dump and reset the node	<p>system core [-f]</p> <p>The -f option forces the creation of a core dump and the reset of the node.</p>	system core	<p>system node coredump trigger</p> <p>(advanced privilege level)</p>
	<p>These commands have the same effect as pressing the Non-maskable Interrupt (NMI) button on a node, causing a dirty shutdown of the node and forcing a dump of the core files when halting the node. These commands are helpful when ONTAP on the node is hung or does not respond to commands such as <code>system node shutdown</code>. The generated core dump files are displayed in the output of the <code>system node coredump show</code> command. The SP stays operational as long as the input power to the node is not interrupted.</p>		
Reboot the node with an optionally specified BIOS firmware image (primary, backup, or current) to recover from issues such as a corrupted image of the node's boot device	<p>system reset</p> <p>{primary backup current}</p>	<p>system reset</p> <p>{current primary backup}</p>	<p>system node reset with the -firmware {primary backup current} parameter</p> <p>(advanced privilege level)</p>
	<div style="border: 1px solid gray; padding: 5px; margin: 10px 0;">  <p>This operation causes a dirty shutdown of the node.</p> </div> <p>If no BIOS firmware image is specified, the current image is used for the reboot. The SP stays operational as long as the input power to the node is not interrupted.</p>		

If you want to...	Use this SP command...	Use this BMC command...	Use this ONTAP command...
Compare the current battery firmware image against a specified firmware image	<pre>system battery verify [image_URL]</pre> <p>(advanced privilege level)</p> <p>If <code>image_URL</code> is not specified, the default battery firmware image is used for comparison.</p>	<pre>system battery verify [image_URL]</pre> <p>(advanced privilege level)</p> <p>If <code>image_URL</code> is not specified, the default battery firmware image is used for comparison.</p>	N/A
Update the battery firmware from the image at the specified location	<pre>system battery flash [image_URL]</pre> <p>(advanced privilege level)</p> <p>You use this command if the automatic battery firmware upgrade process has failed for some reason.</p>	N/A	N/A
Update the SP/BMC/ONTAP firmware by using the image at the specified location	<pre>sp update image_URL</pre> <p><code>image_URL</code> must not exceed 200 characters.</p>	<pre>bmc update image_URL</pre> <p><code>image_URL</code> must not exceed 200 characters.</p>	<pre>system service-processor image update</pre>
Reboot the SP/BMC/ONTAP	<pre>sp reboot</pre>	<pre>bmc reboot</pre>	<pre>system service-processor reboot-sp</pre>
Erase the NVRAM flash content	<pre>system nvram flash clear</pre> <p>(advanced privilege level)</p> <p>This command cannot be initiated when the controller power is off (<code>system power off</code>).</p>	N/A	N/A
Exit the SP/BMC/ONTAP CLI	<pre>exit</pre>	<pre>exit</pre>	N/A

Related information

- [ONTAP command reference](#)

ONTAP node health monitoring using threshold-based SP sensor readings and status

Threshold-based sensors take periodic readings of a variety of system components. The SP compares the reading of a threshold-based sensor against its preset threshold limits that define a component's acceptable operating conditions.

Based on the sensor reading, the SP displays the sensor state to help you monitor the condition of the component.

Examples of threshold-based sensors include sensors for the system temperatures, voltages, currents, and fan speeds. The specific list of threshold-based sensors depends on the platform.


Threshold-based sensors have the following thresholds, displayed in the output of the `SP system sensors` command:

- Lower critical (LCR)
- Lower noncritical (LNC)
- Upper noncritical (UNC)
- Upper critical (UCR)

A sensor reading between LNC and LCR or between UNC and UCR means that the component is showing signs of a problem and a system failure might occur as a result. Therefore, you should plan for component service soon.

A sensor reading below LCR or above UCR means that the component is malfunctioning and a system failure is about to occur. Therefore, the component requires immediate attention.

The following diagram illustrates the severity operating ranges that are specified by the thresholds:



You can find the reading of a threshold-based sensor under the `Current` column in the `system sensors` command output. The `system sensors get sensor_name` command displays additional details for the specified sensor. As the reading of a threshold-based sensor crosses the noncritical and critical threshold ranges, the sensor reports a problem of increasing severity. When the reading exceeds a threshold limit, the sensor's status in the `system sensors` command output changes from `ok` to `nc` (noncritical) or `cr` (critical) depending on the exceeded threshold, and an event message is logged in the SEL event log.

Some threshold-based sensors do not have all four threshold levels. For those sensors, the missing thresholds show `na` as their limits in the `system sensors` command output, indicating that the particular sensor has no limit or severity concern for the given threshold and the SP does not monitor the sensor for that threshold.

Example of the `system sensors` command output

The following example shows some of the information displayed by the `system sensors` command in the SP CLI:

```
SP nodel> system sensors
```

Sensor Name	Current	Unit	Status	LCR	LNC
UNC	UCR				
CPU0_Temp_Margin	-55.000	degrees C	ok	na	na
-5.000	0.000				
CPU1_Temp_Margin	-56.000	degrees C	ok	na	na
-5.000	0.000				
In_Flow_Temp	32.000	degrees C	ok	0.000	10.000
42.000	52.000				
Out_Flow_Temp	38.000	degrees C	ok	0.000	10.000
59.000	68.000				
CPU1_Error	0x0	discrete	0x0180	na	na
na	na				
CPU1_Therm_Trip	0x0	discrete	0x0180	na	na
na	na				
CPU1_Hot	0x0	discrete	0x0180	na	na
na	na				
IO_Mid1_Temp	30.000	degrees C	ok	0.000	10.000
55.000	64.000				
IO_Mid2_Temp	30.000	degrees C	ok	0.000	10.000
55.000	64.000				
CPU_VTT	1.106	Volts	ok	1.028	1.048
1.154	1.174				
CPU0_VCC	1.154	Volts	ok	0.834	0.844
1.348	1.368				
3.3V	3.323	Volts	ok	3.053	3.116
3.466	3.546				
5V	5.002	Volts	ok	4.368	4.465
5.490	5.636				
STBY_1.8V	1.794	Volts	ok	1.678	1.707
1.892	1.911				
...					

Example of the system sensors sensor_name command output for a threshold-based sensor

The following example shows the result of entering `system sensors get sensor_name` in the SP CLI for the threshold-based sensor 5V:

```

SP node1> system sensors get 5V

Locating sensor record...
Sensor ID           : 5V (0x13)
Entity ID           : 7.97
Sensor Type (Analog) : Voltage
Sensor Reading      : 5.002 (+/- 0) Volts
Status              : ok
Lower Non-Recoverable : na
Lower Critical       : 4.246
Lower Non-Critical   : 4.490
Upper Non-Critical   : 5.490
Upper Critical       : 5.758
Upper Non-Recoverable : na
Assertion Events     :
Assertions Enabled    : lnc- lcr- ucr+
Deassertions Enabled : lnc- lcr- ucr+

```

ONTAP SP sensor status values in the system sensor command output

Discrete sensors do not have thresholds. Their readings, displayed under the `Current` column in the SP CLI `system sensors` command output, do not carry actual meanings and thus are ignored by the SP. The `Status` column in the `system sensors` command output displays the status values of discrete sensors in hexadecimal format.

Examples of discrete sensors include sensors for the fan, power supply unit (PSU) fault, and system fault. The specific list of discrete sensors depends on the platform.

You can use the SP CLI `system sensors get sensor_name` command for help with interpreting the status values for most discrete sensors. The following examples show the results of entering `system sensors get sensor_name` for the discrete sensors `CPU0_Error` and `IO_Slot1_Present`:

```

SP node1> system sensors get CPU0_Error

Locating sensor record...
Sensor ID           : CPU0_Error (0x67)
Entity ID           : 7.97
Sensor Type (Discrete): Temperature
States Asserted     : Digital State
                    : [State Deasserted]

```

```

SP node1> system sensors get IO_Slot1_Present
Locating sensor record...
Sensor ID           : IO_Slot1_Present (0x74)
Entity ID          : 11.97
Sensor Type (Discrete): Add-in Card
States Asserted    : Availability State
                   [Device Present]

```

Although the `system sensors get sensor_name` command displays the status information for most discrete sensors, it does not provide status information for the `System_FW_Status`, `System_Watchdog`, `PSU1_Input_Type`, and `PSU2_Input_Type` discrete sensors. You can use the following information to interpret these sensors' status values.

System_FW_Status

The `System_FW_Status` sensor's condition appears in the form of `0xAABB`. You can combine the information of `AA` and `BB` to determine the condition of the sensor.

`AA` can have one of the following values:

Values	Condition of the sensor
01	System firmware error
02	System firmware hang
04	System firmware progress

`BB` can have one of the following values:

Values	Condition of the sensor
00	System software has properly shut down
01	Memory initialization in progress
02	NVMEM initialization in progress (when NVMEM is present)
04	Restoring memory controller hub (MCH) values (when NVMEM is present)
05	User has entered Setup
13	Booting the operating system or LOADER

Values	Condition of the sensor
1F	BIOS is starting up
20	LOADER is running
21	LOADER is programming the primary BIOS firmware. You must not power down the system.
22	LOADER is programming the alternate BIOS firmware. You must not power down the system.
2F	ONTAP is running
60	SP has powered off the system
61	SP has powered on the system
62	SP has reset the system
63	SP watchdog power cycle
64	SP watchdog cold reset

For instance, the System_FW_Status sensor status 0x042F means "system firmware progress (04), ONTAP is running (2F)."

System_Watchdog

The System_Watchdog sensor can have one of the following conditions:

- **0x0080**

The state of this sensor has not changed

Values	Condition of the sensor
0x0081	Timer interrupt
0x0180	Timer expired
0x0280	Hard reset
0x0480	Power down
0x0880	Power cycle

For instance, the System_Watchdog sensor status 0x0880 means a watchdog timeout occurs and causes a system power cycle.

PSU1_Input_Type and PSU2_Input_Type

For direct current (DC) power supplies, the PSU1_Input_Type and PSU2_Input_Type sensors do not apply. For alternating current (AC) power supplies, the sensors' status can have one of the following values:

Values	Condition of the sensor
0x01 xx	220V PSU type
0x02 xx	110V PSU type

For instance, the PSU1_Input_Type sensor status 0x0280 means that the sensor reports that the PSU type is 110V.

ONTAP commands for Service Processor management

ONTAP provides commands for managing the SP, including the SP network configuration, SP firmware image, SSH access to the SP, and general SP administration.

Commands for managing the SP network configuration

If you want to...	Run this ONTAP command...
Enable the SP automatic network configuration for the SP to use the IPv4 or IPv6 address family of the specified subnet	<code>system service-processor network auto-configuration enable</code>
Disable the SP automatic network configuration for the IPv4 or IPv6 address family of the subnet specified for the SP	<code>system service-processor network auto-configuration disable</code>
Display the SP automatic network configuration	<code>system service-processor network auto-configuration show</code>

If you want to...	Run this ONTAP command...
<p>Manually configure the SP network for a node, including the following:</p> <ul style="list-style-type: none"> • The IP address family (IPv4 or IPv6) • Whether the network interface of the specified IP address family should be enabled • If you are using IPv4, whether to use the network configuration from the DHCP server or the network address that you specify • The public IP address for the SP • The netmask for the SP (if using IPv4) • The network prefix-length of the subnet mask for the SP (if using IPv6) • The gateway IP address for the SP 	<pre>system service-processor network modify</pre>
<p>Display the SP network configuration, including the following:</p> <ul style="list-style-type: none"> • The configured address family (IPv4 or IPv6) and whether it is enabled • The remote management device type • The current SP status and link status • Network configuration, such as IP address, MAC address, netmask, prefix-length of subnet mask, router-assigned IP address, link local IP address, and gateway IP address • The time the SP was last updated • The name of the subnet used for SP automatic configuration • Whether the IPv6 router-assigned IP address is enabled • SP network setup status • Reason for the SP network setup failure 	<pre>system service-processor network show</pre> <p>Displaying complete SP network details requires the <code>-instance</code> parameter.</p>
<p>Modify the SP API service configuration, including the following:</p> <ul style="list-style-type: none"> • Changing the port used by the SP API service • Enabling or disabling the SP API service 	<pre>system service-processor api-service modify</pre> <p>(advanced privilege level)</p>

If you want to...	Run this ONTAP command...
Display the SP API service configuration	<pre>system service-processor api-service show</pre> <p>(advanced privilege level)</p>
Renew the SSL and SSH certificates used by the SP API service for internal communication	<ul style="list-style-type: none"> • For ONTAP 9.5 or later: <pre>system service-processor api-service renew-internal-certificates</pre> • For ONTAP 9.4 or earlier: <pre>system service-processor api-service renew-certificates</pre> <p>(advanced privilege level)</p>

Commands for managing the SP firmware image

If you want to...	Run this ONTAP command...
Display the details of the currently installed SP firmware image, including the following: <ul style="list-style-type: none"> • The remote management device type • The image (primary or backup) that the SP is booted from, its status, and firmware version • Whether the firmware automatic update is enabled and the last update status 	<pre>system service-processor image show</pre> <p>The <code>-is-current</code> parameter indicates the image (primary or backup) that the SP is currently booted from, not if the installed firmware version is most current.</p>
Enable or disable the SP automatic firmware update	<pre>system service-processor image modify</pre> <p>By default, the SP firmware is automatically updated with the update of ONTAP or when a new version of the SP firmware is manually downloaded. Disabling the automatic update is not recommended because doing so can result in suboptimal or nonqualified combinations between the ONTAP image and the SP firmware image.</p>

If you want to...	Run this ONTAP command...
Manually download an SP firmware image on a node	<pre>system node image get</pre> <div style="border: 1px solid #ccc; padding: 10px; margin: 10px 0;">  <p>Before you run the <code>system node image</code> commands, you must set the privilege level to advanced (<code>set -privilege advanced</code>), entering y when prompted to continue.</p> </div> <p>The SP firmware image is packaged with ONTAP. You do not need to download the SP firmware manually, unless you want to use an SP firmware version that is different from the one packaged with ONTAP.</p>
Display the status for the latest SP firmware update triggered from ONTAP, including the following information: <ul style="list-style-type: none"> • The start and end time for the latest SP firmware update • Whether an update is in progress and the percentage that is complete 	<pre>system service-processor image update-progress show</pre>

Commands for managing SSH access to the SP

If you want to...	Run this ONTAP command...
Grant SP access to only the specified IP addresses	<pre>system service-processor ssh add-allowed-addresses</pre>
Block the specified IP addresses from accessing the SP	<pre>system service-processor ssh remove-allowed-addresses</pre>
Display the IP addresses that can access the SP	<pre>system service-processor ssh show</pre>

Commands for general SP administration

If you want to...	Run this ONTAP command...
Display general SP information, including the following: <ul style="list-style-type: none"> • The remote management device type • The current SP status • Whether the SP network is configured • Network information, such as the public IP address and the MAC address • The SP firmware version and Intelligent Platform Management Interface (IPMI) version • Whether the SP firmware automatic update is enabled 	<code>system service-processor show</code> Displaying complete SP information requires the <code>-instance</code> parameter.
Reboot the SP on a node	<code>system service-processor reboot-sp</code>
Generate and send an AutoSupport message that includes the SP log files collected from a specified node	<code>system node autosupport invoke-splog</code>
Display the allocation map of the collected SP log files in the cluster, including the sequence numbers for the SP log files that reside in each collecting node	<code>system service-processor log show-allocations</code>

Related information

[ONTAP command reference](#)

ONTAP commands for BMC management

These ONTAP commands are supported on the Baseboard Management Controller (BMC).

The BMC uses some of the same commands as the Service Processor (SP). The following SP commands are supported on the BMC.

If you want to...	Use this command
Display the BMC information	<code>system service-processor show</code>
Display/modify the BMC network configuration	<code>system service-processor network show/modify</code>
Reset the BMC	<code>system service-processor reboot-sp</code>

If you want to...	Use this command
Display/modify the details of the currently installed BMC firmware image	<code>system service-processor image show/modify</code>
Update BMC firmware	<code>system service-processor image update</code>
Display the status for the latest BMC firmware update	<code>system service-processor image update-progress show</code>
Enable the automatic network configuration for the BMC to use an IPv4 or IPv6 address on the specified subnet	<code>system service-processor network auto-configuration enable</code>
Disable the automatic network configuration for an IPv4 or IPv6 address on the subnet specified for the BMC	<code>system service-processor network auto-configuration disable</code>
Display the BMC automatic network configuration	<code>system service-processor network auto-configuration show</code>

For commands that are not supported by the BMC firmware, the following error message is returned.

```
::> Error: Command not supported on this platform.
```

Related information

- [system service-processor](#)

Supported CLI commands for the ONTAP Baseboard Management Controller

You can log into the BMC using SSH. The following commands are supported from the BMC command line.

Command	Function
<code>system</code>	Display a list of all commands.
<code>system console</code>	Connect to the system's console. Use <code>Ctrl+D</code> to exit the session.
<code>system core</code>	Dump the system core and reset.
<code>system power cycle</code>	Power the system off, then on.
<code>system power off</code>	Power the system off.

Command	Function
system power on	Power the system on.
system power status	Print system power status.
system reset	Reset the system.
system log	Print system console logs
system fru show [id]	Dump all/selected field replaceable unit (FRU) info.

Manage ONTAP cluster time (cluster administrators only)

Problems can occur when the cluster time is inaccurate. Although ONTAP enables you to manually set the time zone, date, and time on the cluster, you should configure the Network Time Protocol (NTP) servers to synchronize the cluster time.

Beginning with ONTAP 9.5, you can configure your NTP server with symmetric authentication.

NTP is always enabled. However, configuration is still required for the cluster to synchronize with an external time source. ONTAP enables you to manage the cluster's NTP configuration in the following ways:

- You can associate a maximum of 10 external NTP servers with the cluster (`cluster time-service ntp server create`).
 - For redundancy and quality of time service, you should associate at least three external NTP servers with the cluster.
 - You can specify an NTP server by using its IPv4 or IPv6 address or fully qualified host name.
 - You can manually specify the NTP version (v3 or v4) to use.

By default, ONTAP automatically selects the NTP version that is supported for a given external NTP server.

If the NTP version you specify is not supported for the NTP server, time exchange cannot take place.

- At the advanced privilege level, you can specify an external NTP server that is associated with the cluster to be the primary time source for correcting and adjusting the cluster time.
- You can display the NTP servers that are associated with the cluster (`cluster time-service ntp server show`).
- You can modify the cluster's NTP configuration (`cluster time-service ntp server modify`).
- You can disassociate the cluster from an external NTP server (`cluster time-service ntp server delete`).
- At the advanced privilege level, you can reset the configuration by clearing all external NTP servers' association with the cluster (`cluster time-service ntp server reset`).

A node that joins a cluster automatically adopts the NTP configuration of the cluster.

In addition to using NTP, ONTAP also enables you to manually manage the cluster time. This capability is helpful when you need to correct erroneous time (for example, a node's time has become significantly incorrect after a reboot). In that case, you can specify an approximate time for the cluster until NTP can synchronize with an external time server. The time you manually set takes effect across all nodes in the cluster.

You can manually manage the cluster time in the following ways:

- You can set or modify the time zone, date, and time on the cluster (`cluster date modify`).
- You can display the current time zone, date, and time settings of the cluster (`cluster date show`).



Job schedules do not adjust to manual cluster date and time changes. These jobs are scheduled to run based on the current cluster time when the job was created or when the job most recently ran. Therefore, if you manually change the cluster date or time, you must use the `job show` and `job history show` commands to verify that all scheduled jobs are queued and completed according to your requirements.

Commands for managing the cluster time

You use the `cluster time-service ntp server` commands to manage the NTP servers for the cluster. You use the `cluster date` commands to manage the cluster time manually.

Beginning with ONTAP 9.5, you can configure your NTP server with symmetric authentication.

The following commands enable you to manage the NTP servers for the cluster:

If you want to...	Use this command...
Associate the cluster with an external NTP server without symmetric authentication	<code>cluster time-service ntp server create -server server_name</code>
Associate the cluster with an external NTP server with symmetric authentication Available in ONTAP 9.5 or later	<code>cluster time-service ntp server create -server server_ip_address -key-id key_id</code>  The <code>key_id</code> must refer to an existing shared key configured with <code>'cluster time-service ntp key'</code> .
Enable symmetric authentication for an existing NTP server An existing NTP server can be modified to enable authentication by adding the required key-id. Available in ONTAP 9.5 or later	<code>cluster time-service ntp server modify -server server_name -key-id key_id</code>
Disable symmetric authentication	<code>cluster time-service ntp server modify -server server_name -is-authentication -enabled false</code>

If you want to...	Use this command...
Configure a shared NTP key	<pre>cluster time-service ntp key create -id shared_key_id -type shared_key_type -value shared_key_value</pre> <div style="display: flex; align-items: center; margin-top: 10px;">  <p>Shared keys are referred to by an ID. The ID, its type, and value must be identical on both the node and the NTP server</p> </div>
Display information about the NTP servers that are associated with the cluster	<pre>cluster time-service ntp server show</pre>
Modify the configuration of an external NTP server that is associated with the cluster	<pre>cluster time-service ntp server modify</pre>
Dissociate an NTP server from the cluster	<pre>cluster time-service ntp server delete</pre>
Reset the configuration by clearing all external NTP servers' association with the cluster	<pre>cluster time-service ntp server reset</pre> <div style="display: flex; align-items: center; margin-top: 10px;">  <p>This command requires the advanced privilege level.</p> </div>

The following commands enable you to manage the cluster time manually:

If you want to...	Use this command...
Set or modify the time zone, date, and time	<pre>cluster date modify</pre>
Display the time zone, date, and time settings for the cluster	<pre>cluster date show</pre>

Related information

- [cluster date show](#)
- [cluster date modify](#)
- [cluster time-service ntp](#)
- [job show](#)

Manage the banner and MOTD

Learn about the ONTAP login banner and message-of-the-day text

ONTAP enables you to configure a login banner or a message of the day (MOTD) to communicate administrative information to System Manager and CLI users of the cluster or storage virtual machine (SVM).

A banner is displayed in a console session (for cluster access only) or an SSH session (for cluster or SVM access) before a user is prompted for authentication such as a password. For example, you can use the banner to display a warning message such as the following to someone who attempts to log in to the system:

```
$ ssh admin@cluster1-01
```

```
This system is for authorized users only. Your IP Address has been logged.
```

```
Password:
```

An MOTD is displayed in a console session (for cluster access only) or an SSH session (for cluster or SVM access) after a user is authenticated but before the clustershell prompt appears. For example, you can use the MOTD to display a welcome or informational message such as the following that only authenticated users will see:

```
$ ssh admin@cluster1-01
```

```
Password:
```

```
Greetings. This system is running ONTAP 9.0.
```

```
Your user name is 'admin'. Your last login was Wed Apr 08 16:46:53 2015  
from 10.72.137.28.
```

You can create or modify the content of the banner or MOTD by using the `security login banner modify` or `security login motd modify` command, respectively, in the following ways:

- You can use the CLI interactively or noninteractively to specify the text to use for the banner or MOTD.

The interactive mode, launched when the command is used without the `-message` or `-uri` parameter, enables you to use newlines (also known as end of lines) in the message.

The noninteractive mode, which uses the `-message` parameter to specify the message string, does not support newlines.

- You can upload content from an FTP or HTTP location to use for the banner or MOTD.
- You can configure the MOTD to display dynamic content.

Examples of what you can configure the MOTD to display dynamically include the following:

- Cluster name, node name, or SVM name
- Cluster date and time
- Name of the user logging in
- Last login for the user on any node in the cluster
- Login device name or IP address
- Operating system name
- Software release version

- Effective cluster version string

The banner does not support dynamic content. Learn more about `security login motd modify` and the escape sequences that you can use to enable the MOTD to display dynamically generated content in the [ONTAP command reference](#).

You can manage the banner and MOTD at the cluster or SVM level:

- The following facts apply to the banner:
 - The banner configured for the cluster is also used for all SVMs that do not have a banner message defined.
 - An SVM-level banner can be configured for each SVM.

If a cluster-level banner has been configured, it is overridden by the SVM-level banner for the given SVM.

- The following facts apply to the MOTD:
 - By default, the MOTD configured for the cluster is also enabled for all SVMs.
 - Additionally, an SVM-level MOTD can be configured for each SVM.

In this case, users logging in to the SVM will see two MOTDs, one defined at the cluster level and the other at the SVM level.

- The cluster-level MOTD can be enabled or disabled on a per-SVM basis by the cluster administrator.

If the cluster administrator disables the cluster-level MOTD for an SVM, a user logging in to the SVM does not see the cluster-level MOTD.

Create an ONTAP login banner

You can create a banner to display a message to someone who attempts to access the cluster or SVM. The banner is displayed in a console session (for cluster access only) or an SSH session (for cluster or SVM access) before a user is prompted for authentication.

Steps

1. Use the `security login banner modify` command to create a banner for the cluster or SVM:

If you want to...	Then...
Specify a message that is a single line	Use the <code>-message "<text>"</code> parameter to specify the text.
Include newlines (also known as end of lines) in the message	Use the command without the <code>-message</code> or <code>-uri</code> parameter to launch the interactive mode for editing the banner.
Upload content from a location to use for the banner	Use the <code>-uri</code> parameter to specify the content's FTP or HTTP location.

The maximum size for a banner is 2,048 bytes, including newlines.

A banner created by using the `-uri` parameter is static. It is not automatically refreshed to reflect subsequent changes of the source content.

The banner created for the cluster is displayed also for all SVMs that do not have an existing banner. Any subsequently created banner for an SVM overrides the cluster-level banner for that SVM. Specifying the `-message` parameter with a hyphen within double quotes ("`-`") for the SVM resets the SVM to use the cluster-level banner.

2. Verify that the banner has been created by displaying it with the `security login banner show` command.

Specifying the `-message` parameter with an empty string ("`''`") displays banners that have no content.

Specifying the `-message` parameter with "`-`" displays all (admin or data) SVMs that do not have a banner configured.

Examples of creating banners

The following example uses the noninteractive mode to create a banner for the "cluster1" cluster:

```
cluster1::> security login banner modify -message "Authorized users only!"  
  
cluster1::>
```

The following example uses the interactive mode to create a banner for the `svm1` SVM:

```
cluster1::> security login banner modify -vserver svm1  
  
Enter the message of the day for Vserver "svm1".  
Max size: 2048. Enter a blank line to terminate input. Press Ctrl-C to  
abort.  
0          1          2          3          4          5          6          7  
8  
12345678901234567890123456789012345678901234567890123456789012345678901234  
567890  
The svm1 SVM is reserved for authorized users only!  
  
cluster1::>
```

The following example displays the banners that have been created:

```

cluster1::> security login banner show
Vserver: cluster1
Message
-----
---
Authorized users only!

Vserver: svm1
Message
-----
---
The svm1 SVM is reserved for authorized users only!

2 entries were displayed.

cluster1::>

```

Related information

- [Managing the banner](#)
- [security login banner modify](#)
- [security login banner show](#)

Manage the banner text displayed at the ONTAP cluster and SVM level

You can manage the banner at the cluster or SVM level. The banner configured for the cluster is also used for all SVMs that do not have a banner message defined. A subsequently created banner for an SVM overrides the cluster banner for that SVM.

Choices

- Manage the banner at the cluster level:

If you want to...	Then...
Create a banner to display for all login sessions	Set a cluster-level banner: <pre>security login banner modify -vserver <cluster_name> { [-message "text"] [-uri <ftp_or_http_addr>] }</pre>
Remove the banner for all (cluster and SVM) logins	Set the banner to an empty string (`): <pre>security login banner modify -vserver * -message</pre>

If you want to...	Then...
Override a banner created by an SVM administrator	Modify the SVM banner message: <pre>security login banner modify -vserver <svm_name> { [-message "<text>"] [- uri <ftp_or_http_addr>] }</pre>

- Manage the banner at the SVM level:

Specifying `-vserver <svm_name>` is not required in the SVM context.

If you want to...	Then...
Override the banner supplied by the cluster administrator with a different banner for the SVM	Create a banner for the SVM: <pre>security login banner modify -vserver <svm_name> { [-message "text"] [-uri <ftp_or_http_addr>] }</pre>
Suppress the banner supplied by the cluster administrator so that no banner is displayed for the SVM	Set the SVM banner to an empty string for the SVM: <pre>security login banner modify -vserver <svm_name> -message</pre>
Use the cluster-level banner when the SVM currently uses an SVM-level banner	Set the SVM banner to -: <pre>security login banner modify -vserver <svm_name> -message -</pre>

Related information

- [security login banner modify](#)

Create message-of-the-day text for ONTAP users

You can create a message of the day (MOTD) to communicate information to authenticated CLI users. The MOTD is displayed in a console session (for cluster access only) or an SSH session (for cluster or SVM access) after a user is authenticated but before the `clustershell` prompt appears.

Steps

1. Use the `security login motd modify` command to create an MOTD for the cluster or SVM:

If you want to...	Then...
Specify a message that is a single line	Use the <code>-message "text"</code> parameter to specify the text.

If you want to...	Then...
Include newlines (also known as end of lines)	Use the command without the <code>-message</code> or <code>-uri</code> parameter to launch the interactive mode for editing the MOTD.
Upload content from a location to use for the MOTD	Use the <code>-uri</code> parameter to specify the content's FTP or HTTP location.

The maximum size for an MOTD is 2,048 bytes, including newlines.

`security login motd modify` describes the escape sequences that you can use to enable the MOTD to display dynamically generated content.

An MOTD created by using the `-uri` parameter is static. It is not automatically refreshed to reflect subsequent changes of the source content.

An MOTD created for the cluster is displayed also for all SVM logins by default, along with an SVM-level MOTD that you can create separately for a given SVM. Setting the `-is-cluster-message-enabled` parameter to `false` for an SVM prevents the cluster-level MOTD from being displayed for that SVM.

2. Verify that the MOTD has been created by displaying it with the `security login motd show` command.

Specifying the `-message` parameter with an empty string (```) displays MOTDs that are not configured or have no content.

Learn more about `security login motd modify` and parameters to enable the MOTD to display dynamically generated content in the [ONTAP command reference](#).

Examples of creating MOTDs

The following example uses the noninteractive mode to create an MOTD for the `cluster1` cluster:

```
cluster1::> security login motd modify -message "Greetings!"
```

The following example uses the interactive mode to create an MOTD for the `svm1` SVM that uses escape sequences to display dynamically generated content:

```

cluster1::> security login motd modify -vserver svm1

Enter the message of the day for Vserver "svm1".
Max size: 2048. Enter a blank line to terminate input. Press Ctrl-C to
abort.
0           1           2           3           4           5           6           7
8
12345678901234567890123456789012345678901234567890123456789012345678901234
567890
Welcome to the \n SVM.  Your user ID is '\N'. Your last successful login
was \L.

```

The following example displays the MOTDs that have been created:

```

cluster1::> security login motd show
Vserver: cluster1
Is the Cluster MOTD Displayed?: true
Message
-----
---
Greetings!

Vserver: svm1
Is the Cluster MOTD Displayed?: true
Message
-----
---
Welcome to the \n SVM.  Your user ID is '\N'. Your last successful login
was \L.

2 entries were displayed.

```

Learn more about `security login motd show` in the [ONTAP command reference](#).

Manage the message-of-the-day text displayed at ONTAP cluster and SVM levels

You can manage the message of the day (MOTD) at the cluster or SVM level. By default, the MOTD configured for the cluster is also enabled for all SVMs. Additionally, an SVM-level MOTD can be configured for each SVM. The cluster-level MOTD can be enabled or disabled for each SVM by the cluster administrator.

Learn more about the [escape sequences](#) that can be used to dynamically generate content for the MOTD in the ONTAP command reference.

Choices

- Manage the MOTD at the cluster level:

If you want to...	Then...
Create an MOTD for all logins when there is no existing MOTD	Set a cluster-level MOTD: <pre>security login motd modify -vserver <cluster_name> { [-message "<text>"] [-uri <ftp_or_http_addr>] }</pre>
Change the MOTD for all logins when no SVM-level MOTDs are configured	Modify the cluster-level MOTD: <pre>security login motd modify -vserver <cluster_name> { [-message "<text>"] } [-uri <ftp_or_http_addr>] }</pre>
Remove the MOTD for all logins when no SVM-level MOTDs are configured	Set the cluster-level MOTD to an empty string (""): <pre>security login motd modify -vserver <cluster_name> -message ""</pre>
Have every SVM display the cluster-level MOTD instead of using the SVM-level MOTD	Set a cluster-level MOTD, then set all SVM-level MOTDs to an empty string with the cluster-level MOTD enabled: <ol style="list-style-type: none"> 1. <pre>security login motd modify -vserver <cluster_name> { [-message "<text>"] [-uri <ftp_or_http_addr>] }</pre> 2. <pre>security login motd modify { -vserver !"<cluster_name>" } -message "" -is-cluster-message -enabled true</pre>
Have an MOTD displayed for only selected SVMs, and use no cluster-level MOTD	Set the cluster-level MOTD to an empty string, then set SVM-level MOTDs for selected SVMs: <ol style="list-style-type: none"> 1. <pre>security login motd modify -vserver <cluster_name> -message ""</pre> 2. <pre>security login motd modify -vserver <svm_name> { [-message "<text>"] [-uri <ftp_or_http_addr>] }</pre> <p>You can repeat this step for each SVM as needed.</p>

If you want to...	Then...
Use the same SVM-level MOTD for all (data and admin) SVMs	<p>Set the cluster and all SVMs to use the same MOTD:</p> <pre>security login motd modify -vserver * { [-message "<text>"] [-uri <ftp_or_http_addr>] }</pre> <div style="border: 1px solid #ccc; padding: 10px; margin-top: 10px;">  <p>If you use the interactive mode, the CLI prompts you to enter the MOTD individually for the cluster and each SVM. You can paste the same MOTD into each instance when you are prompted to.</p> </div>
Have a cluster-level MOTD optionally available to all SVMs, but do not want the MOTD displayed for cluster logins	<p>Set a cluster-level MOTD, but disable its display for the cluster:</p> <pre>security login motd modify -vserver <cluster_name> { [-message "<text>"] [-uri <ftp_or_http_addr>] } -is -cluster-message-enabled false</pre>
Remove all MOTDs at the cluster and SVM levels when only some SVMs have both cluster-level and SVM-level MOTDs	<p>Set the cluster and all SVMs to use an empty string for the MOTD:</p> <pre>security login motd modify -vserver * -message ""</pre>
Modify the MOTD only for the SVMs that have a non-empty string, when other SVMs use an empty string, and when a different MOTD is used at the cluster level	<p>Use extended queries to modify the MOTD selectively:</p> <pre>security login motd modify { -vserver !"<cluster_name>" -message !"" } { [- message "<text>"] [-uri <ftp_or_http_addr>] }</pre>
Display all MOTDs that contain specific text (for example, "January" followed by "2015") anywhere in a single or multiline message, even if the text is split across different lines	<p>Use a query to display MOTDs:</p> <div style="border: 1px solid #ccc; padding: 10px; margin-top: 10px;"> <pre>security login motd show -message *"January"*"2015"*</pre> </div>
Interactively create an MOTD that includes multiple and consecutive newlines (also known as end of lines, or EOLs)	<p>In the interactive mode, press the space bar followed by Enter to create a blank line without terminating the input for the MOTD.</p>

- Manage the MOTD at the SVM level:

Specifying `-vserver <svm_name>` is not required in the SVM context.

If you want to...	Then...
Use a different SVM-level MOTD, when the SVM already has an existing SVM-level MOTD	Modify the SVM-level MOTD: <pre>security login motd modify -vserver <svm_name> { [-message "<text>"] [-uri <ftp_or_http_addr>] }</pre>
Use only the cluster-level MOTD for the SVM, when the SVM already has an SVM-level MOTD	Set the SVM-level MOTD to an empty string, then have the cluster administrator enable the cluster-level MOTD for the SVM: <ol style="list-style-type: none">1. <pre>security login motd modify -vserver <svm_name> -message ""</pre>2. (For the cluster administrator) <pre>security login motd modify -vserver <svm_name> -is-cluster-message -enabled true</pre>
Not have the SVM display any MOTD, when both the cluster-level and SVM-level MOTDs are currently displayed for the SVM	Set the SVM-level MOTD to an empty string, then have the cluster administrator disable the cluster-level MOTD for the SVM: <ol style="list-style-type: none">1. <pre>security login motd modify -vserver <svm_name> -message ""</pre>2. (For the cluster administrator) <pre>security login motd modify -vserver <svm_name> -is-cluster-message -enabled false</pre>

Related information

- [security login motd modify](#)
- [security login motd show](#)

Manage ONTAP jobs and job schedules

Jobs are placed into a job queue and run in the background when resources are available. If a job is consuming too many cluster resources, you can stop it or pause it until there is less demand on the cluster. You can also monitor and restart jobs.

Job categories

There are three categories of jobs that you can manage: server-affiliated, cluster-affiliated, and private.

A job can be in any of the following categories:

- **Server-Affiliated jobs**

These jobs are queued by the management framework to a specific node to be run.

- **Cluster-Affiliated jobs**

These jobs are queued by the management framework to any node in the cluster to be run.

- **Private jobs**

These jobs are specific to a node and do not use the replicated database (RDB) or any other cluster mechanism. The commands that manage private jobs require the advanced privilege level or higher.

Commands for managing jobs

When you enter a command that invokes a job, typically, the command informs you that the job has been queued and then returns to the CLI command prompt. However, some commands instead report job progress and do not return to the CLI command prompt until the job has been completed. In these cases, you can press Ctrl-C to move the job to the background.

If you want to...	Use this command...
Display information about all jobs	<code>job show</code>
Display information about jobs on a per-node basis	<code>job show bynode</code>
Display information about cluster-affiliated jobs	<code>job show-cluster</code>
Display information about completed jobs	<code>job show-completed</code>
Display information about job history	<code>job history show</code> Up to 25,000 job records are stored for each node in the cluster. Consequently, attempting to display the full job history could take a long time. To avoid potentially long wait times, you should display jobs by node, storage virtual machine (SVM), or record ID.
Display the list of private jobs	<code>job private show</code> (advanced privilege level)
Display information about completed private jobs	<code>job private show-completed</code> (advanced privilege level)
Display information about the initialization state for job managers	<code>job initstate show</code> (advanced privilege level)
Monitor the progress of a job	<code>job watch-progress</code>

If you want to...	Use this command...
Monitor the progress of a private job	<code>job private watch-progress</code> (advanced privilege level)
Pause a job	<code>job pause</code>
Pause a private job	<code>job private pause</code> (advanced privilege level)
Resume a paused job	<code>job resume</code>
Resume a paused private job	<code>job private resume</code> (advanced privilege level)
Stop a job	<code>job stop</code>
Stop a private job	<code>job private stop</code> (advanced privilege level)
Delete a job	<code>job delete</code>
Delete a private job	<code>job private delete</code> (advanced privilege level)
Disassociate a cluster-affiliated job with an unavailable node that owns it, so that another node can take ownership of that job	<code>job unclaim</code> (advanced privilege level)



You can use the `event log show` command to determine the outcome of a completed job. Learn more about `event log show` in the [ONTAP command reference](#).

Commands for managing job schedules

Many tasks—for instance, volume snapshots—can be configured to run on specified schedules. Schedules that run at specific times are called *cron* schedules (similar to UNIX `cron` schedules). Schedules that run at intervals are called *interval* schedules. You use the `job schedule` commands to manage job schedules.

Job schedules do not adjust to manual changes to the cluster date and time. These jobs are scheduled to run based on the current cluster time when the job was created or when the job most recently ran. Therefore, if you manually change the cluster date or time, you should use the `job show` and `job history show` commands to verify that all scheduled jobs are queued and completed according to your requirements.

If the cluster is part of a MetroCluster configuration, then the job schedules on both clusters must be identical. Therefore, if you create, modify, or delete a job schedule, you must perform the same operation on the remote cluster.

If you want to...	Use this command...
Display information about all schedules	<code>job schedule show</code>

If you want to...	Use this command...
Display the list of jobs by schedule	<code>job schedule show-jobs</code>
Display information about cron schedules	<code>job schedule cron show</code>
Display information about interval schedules	<code>job schedule interval show</code>
Create a cron schedule	<code>job schedule cron create</code> Beginning with ONTAP 9.10.1, you can include the SVM for your job schedule.
Create an interval schedule	<code>job schedule interval create</code> You must specify at least one of the following parameters: <code>-days</code> , <code>-hours</code> , <code>-minutes</code> , or <code>-seconds</code> .
Modify a cron schedule	<code>job schedule cron modify</code>
Modify an interval schedule	<code>job schedule interval modify</code>
Delete a schedule	<code>job schedule delete</code>
Delete a cron schedule	<code>job schedule cron delete</code>
Delete an interval schedule	<code>job schedule interval delete</code>

Related information

- [job](#)

Back up and restore cluster configurations (cluster administrators only)

Learn about ONTAP configuration backup files

Configuration backup files are archive files (.7z) that contain information for all configurable options that are necessary for the cluster, and the nodes within it, to operate properly.

These files store the local configuration of each node, plus the cluster-wide replicated configuration. You use configuration backup files to back up and restore the configuration of your cluster.

There are two types of configuration backup files:

- **Node configuration backup file**

Each healthy node in the cluster includes a node configuration backup file, which contains all of the configuration information and metadata necessary for the node to operate healthy in the cluster.

- **Cluster configuration backup file**

These files include an archive of all of the node configuration backup files in the cluster, plus the replicated cluster configuration information (the replicated database, or RDB file). Cluster configuration backup files enable you to restore the configuration of the entire cluster, or of any node in the cluster. The cluster configuration backup schedules create these files automatically and store them on several nodes in the cluster.



Configuration backup files contain configuration information only. They do not include any user data. For information about restoring user data, see [Data Protection](#).

Learn about scheduling backups of ONTAP cluster and node configuration backup files

Three separate schedules automatically create cluster and node configuration backup files and replicate them among the nodes in the cluster.

The configuration backup files are automatically created according to the following schedules:

- Every 8 hours
- Daily
- Weekly

At each of these times, a node configuration backup file is created on each healthy node in the cluster. All of these node configuration backup files are then collected in a single cluster configuration backup file along with the replicated cluster configuration and saved on one or more nodes in the cluster.

ONTAP commands for managing configuration backup schedules

You can use the `system configuration backup settings` commands to manage configuration backup schedules.

These commands are available at the advanced privilege level.

If you want to...	Use this command...
<p>Change the settings for a configuration backup schedule:</p> <ul style="list-style-type: none"> • Specify a remote URL (HTTP, HTTPS, FTP, or FTPS) where the configuration backup files will be uploaded in addition to the default locations in the cluster • Specify a user name to be used to log in to the remote URL • Set the number of backups to keep for each configuration backup schedule 	<p><code>system configuration backup settings modify</code></p> <p>When you use HTTPS in the remote URL, use the <code>-validate-certification</code> option to enable or disable digital certificate validation. Certificate validation is disabled by default.</p> <div style="border: 1px solid #ccc; padding: 10px; margin-top: 10px;"> <p> The web server to which you are uploading the configuration backup file must have PUT operations enabled for HTTP and POST operations enabled for HTTPS. For more information, see your web server's documentation.</p> </div>
<p>Set the password to be used to log in to the remote URL</p>	<p><code>system configuration backup settings set-password</code></p>
<p>View the settings for the configuration backup schedule</p>	<p><code>system configuration backup settings show</code></p> <div style="border: 1px solid #ccc; padding: 10px; margin-top: 10px;"> <p> You set the <code>-instance</code> parameter to view the user name and the number of backups to keep for each schedule.</p> </div>

ONTAP commands for managing node configuration backup files

You use the `system configuration backup` commands to manage cluster and node configuration backup files.

These commands are available at the advanced privilege level.

If you want to...	Use this command...
<p>Create a new node or cluster configuration backup file</p>	<p><code>system configuration backup create</code></p>
<p>Copy a configuration backup file from a node to another node in the cluster</p>	<p><code>system configuration backup copy</code></p>

If you want to...	Use this command...
Upload a configuration backup file from a node in the cluster to a remote URL (FTP, HTTP, HTTPS, or FTPS)	<pre>system configuration backup upload</pre> <p>When you use HTTPS in the remote URL, use the <code>-validate-certification</code> option to enable or disable digital certificate validation. Certificate validation is disabled by default.</p> <div style="border-left: 1px solid #ccc; padding-left: 10px; margin-top: 10px;"> <p> The web server to which you are uploading the configuration backup file must have PUT operations enabled for HTTP and POST operations enabled for HTTPS. You might need to install an additional module on some web servers. For more information, see your web server's documentation. Supported URL formats vary by ONTAP release. Learn more about system configuration commands in the ONTAP command reference.</p> </div>
Download a configuration backup file from a remote URL to a node in the cluster, and, if specified, validate the digital certificate	<pre>system configuration backup download</pre> <p>When you use HTTPS in the remote URL, use the <code>-validate-certification</code> option to enable or disable digital certificate validation. Certificate validation is disabled by default.</p>
Rename a configuration backup file on a node in the cluster	<pre>system configuration backup rename</pre>
View the node and cluster configuration backup files for one or more nodes in the cluster	<pre>system configuration backup show</pre>
Delete a configuration backup file on a node	<pre>system configuration backup delete</pre> <div style="border-left: 1px solid #ccc; padding-left: 10px; margin-top: 10px;"> <p> This command deletes the configuration backup file on the specified node only. If the configuration backup file also exists on other nodes in the cluster, it remains on those nodes.</p> </div>

Related information

- [system configuration backup](#)

Locate the ONTAP node configuration backup file to restore a node

You use a configuration backup file located at a remote URL or on a node in the cluster to

recover a node configuration.

About this task

You can use either a cluster or node configuration backup file to restore a node configuration.

Step

1. Make the configuration backup file available to the node for which you need to restore the configuration.

If the configuration backup file is located...	Then...
At a remote URL	Use the <code>system configuration backup download</code> command at the advanced privilege level to download it to the recovering node.
On a node in the cluster	<ol style="list-style-type: none">a. Use the <code>system configuration backup show</code> command at the advanced privilege level to view the list of configuration backup files available in the cluster that contains the recovering node's configuration.b. If the configuration backup file you identify does not exist on the recovering node, then use the <code>system configuration backup copy</code> command to copy it to the recovering node.

If you previously re-created the cluster, you should choose a configuration backup file that was created after the cluster recreation. If you must use a configuration backup file that was created prior to the cluster recreation, then after recovering the node, you must re-create the cluster again.

Related information

- [system configuration backup copy](#)

Restore a node using the ONTAP node configuration backup file

You restore the node configuration using the configuration backup file that you identified and made available to the recovering node.

About this task

You should only perform this task to recover from a disaster that resulted in the loss of the node's local configuration files.

Steps

1. Change to the advanced privilege level:

```
set -privilege advanced
```

2. If the node is healthy, then at the advanced privilege level of a different node, use the `cluster modify` command with the `-node` and `-eligibility` parameters to mark it ineligible and isolate it from the cluster.

If the node is not healthy, then you should skip this step.

This example modifies node2 to be ineligible to participate in the cluster so that its configuration can be restored:

```
cluster1::*> cluster modify -node node2 -eligibility false
```

Learn more about `cluster modify` in the [ONTAP command reference](#).

3. Use the `system configuration recovery node restore` command at the advanced privilege level to restore the node's configuration from a configuration backup file.

If the node lost its identity, including its name, then you should use the `-nodename-in-backup` parameter to specify the node name in the configuration backup file.

This example restores the node's configuration using one of the configuration backup files stored on the node:

```
cluster1::*> system configuration recovery node restore -backup
cluster1.8hour.2011-02-22.18_15_00.7z
```

```
Warning: This command overwrites local configuration files with
         files contained in the specified backup file. Use this
         command only to recover from a disaster that resulted
         in the loss of the local configuration files.
         The node will reboot after restoring the local configuration.
         Do you want to continue? {y|n}: y
```

The configuration is restored, and the node reboots.

4. If you marked the node ineligible, then use the `system configuration recovery cluster sync` command to mark the node as eligible and synchronize it with the cluster.
5. If you are operating in a SAN environment, use the `system node reboot` command to reboot the node and reestablish SAN quorum.

After you finish

If you previously re-created the cluster, and if you are restoring the node configuration by using a configuration backup file that was created prior to that cluster re-creation, then you must re-create the cluster again.

Locate the ONTAP cluster configuration backup file to restore a cluster

You use the configuration from either a node in the cluster or a cluster configuration backup file to recover a cluster.

Steps

1. Choose a type of configuration to recover the cluster.
 - A node in the cluster

If the cluster consists of more than one node, and one of the nodes has a cluster configuration from when the cluster was in the desired configuration, then you can recover the cluster using the

configuration stored on that node.

In most cases, the node containing the replication ring with the most recent transaction ID is the best node to use for restoring the cluster configuration. The `cluster ring show` command at the advanced privilege level enables you to view a list of the replicated rings available on each node in the cluster.

- A cluster configuration backup file

If you cannot identify a node with the correct cluster configuration, or if the cluster consists of a single node, then you can use a cluster configuration backup file to recover the cluster.

If you are recovering the cluster from a configuration backup file, any configuration changes made since the backup was taken will be lost. You must resolve any discrepancies between the configuration backup file and the present configuration after recovery. See the [NetApp Knowledge Base: ONTAP Configuration Backup Resolution Guide](#) for troubleshooting guidance.

2. If you chose to use a cluster configuration backup file, then make the file available to the node you plan to use to recover the cluster.

If the configuration backup file is located...	Then...
At a remote URL	Use the <code>system configuration backup download</code> command at the advanced privilege level to download it to the recovering node.
On a node in the cluster	<ol style="list-style-type: none">a. Use the <code>system configuration backup show</code> command at the advanced privilege level to find a cluster configuration backup file that was created when the cluster was in the desired configuration.b. If the cluster configuration backup file is not located on the node you plan to use to recover the cluster, then use the <code>system configuration backup copy</code> command to copy it to the recovering node.

Related information

- [cluster ring show](#)
- [system configuration backup copy](#)

Restore a cluster using the ONTAP cluster configuration backup file

To restore a cluster configuration from an existing configuration after a cluster failure, you re-create the cluster using the cluster configuration that you chose and made available to the recovering node, and then rejoin each additional node to the new cluster.

About this task

You should only perform this task to recover from a disaster that resulted in the loss of the cluster's configuration.



If you are re-creating the cluster from a configuration backup file, you must contact technical support to resolve any discrepancies between the configuration backup file and the configuration present in the cluster.

If you are recovering the cluster from a configuration backup file, any configuration changes made since the backup was taken will be lost. You must resolve any discrepancies between the configuration backup file and the present configuration after recovery. See the [NetApp Knowledge Base: ONTAP Configuration Backup Resolution Guide](#) for troubleshooting guidance.

Steps

1. Disable storage failover for each HA pair:

```
storage failover modify -node node_name -enabled false
```

You only need to disable storage failover once for each HA pair. When you disable storage failover for a node, storage failover is also disabled on the node's partner.

2. Halt each node except for the recovering node:

```
system node halt -node node_name -reason "text"
```

```
cluster1::*> system node halt -node node0 -reason "recovering cluster"

Warning: Are you sure you want to halt the node? {y|n}: y
```

3. Set the privilege level to advanced:

```
set -privilege advanced
```

4. On the recovering node, use the **system configuration recovery cluster recreate** command to re-create the cluster.

This example re-creates the cluster using the configuration information stored on the recovering node:

```
cluster1::*> configuration recovery cluster recreate -from node

Warning: This command will destroy your existing cluster. It will
        rebuild a new single-node cluster consisting of this node
        and its current configuration. This feature should only be
        used to recover from a disaster. Do not perform any other
        recovery operations while this operation is in progress.
Do you want to continue? {y|n}: y
```

A new cluster is created on the recovering node.

5. If you are re-creating the cluster from a configuration backup file, verify that the cluster recovery is still in progress:

system configuration recovery cluster show

You do not need to verify the cluster recovery state if you are re-creating the cluster from a healthy node.

```
cluster1::*> system configuration recovery cluster show
Recovery Status: in-progress
Is Recovery Status Persisted: false
```

6. Boot each node that needs to be rejoined to the re-created cluster.

You must reboot the nodes one at a time.

7. For each node that needs to be joined to the re-created cluster, do the following:

a. From a healthy node on the re-created cluster, rejoin the target node:

```
system configuration recovery cluster rejoin -node node_name
```

This example rejoins the “node2” target node to the re-created cluster:

```
cluster1::*> system configuration recovery cluster rejoin -node node2

Warning: This command will rejoin node "node2" into the local
cluster, potentially overwriting critical cluster
configuration files. This command should only be used
to recover from a disaster. Do not perform any other
recovery operations while this operation is in progress.
This command will cause node "node2" to reboot.
Do you want to continue? {y|n}: y
```

The target node reboots and then joins the cluster.

b. Verify that the target node is healthy and has formed quorum with the rest of the nodes in the cluster:

```
cluster show -eligibility true
```

The target node must rejoin the re-created cluster before you can rejoin another node.

```
cluster1::*> cluster show -eligibility true
Node           Health Eligibility  Epsilon
-----
node0          true   true        false
node1          true   true        false
2 entries were displayed.
```

8. If you re-created the cluster from a configuration backup file, set the recovery status to be complete:

```
system configuration recovery cluster modify -recovery-status complete
```

9. Return to the admin privilege level:

```
set -privilege admin
```

10. If the cluster consists of only two nodes, use the `cluster ha modify` command to reenables cluster HA.

11. Use the `storage failover modify` command to reenables storage failover for each HA pair.

After you finish

If the cluster has SnapMirror peer relationships, then you also need to re-create those relationships. For more information, see [Data Protection](#).

Related information

- [ONTAP command reference](#)
- [storage failover modify](#)

Synchronize a node with the ONTAP cluster to ensure cluster-wide quorum

If cluster-wide quorum exists, but one or more nodes are out of sync with the cluster, then you must synchronize the node to restore the replicated database (RDB) on the node and bring it into quorum.

Step

1. From a healthy node, use the `system configuration recovery cluster sync` command at the advanced privilege level to synchronize the node that is out of sync with the cluster configuration.

This example synchronizes a node (*node2*) with the rest of the cluster:

```
cluster1::*> system configuration recovery cluster sync -node node2
```

```
Warning: This command will synchronize node "node2" with the cluster
configuration, potentially overwriting critical cluster
configuration files on the node. This feature should only be
used to recover from a disaster. Do not perform any other
recovery operations while this operation is in progress. This
command will cause all the cluster applications on node
"node2" to restart, interrupting administrative CLI and Web
interface on that node.
```

```
Do you want to continue? {y|n}: y
```

```
All cluster applications on node "node2" will be restarted. Verify that
the cluster applications go online.
```

Result

The RDB is replicated to the node, and the node becomes eligible to participate in the cluster.

Manage node core dumps for an ONTAP cluster (cluster administrators only)

When a node panics, a core dump occurs and the system creates a core dump file that technical support can use to troubleshoot the problem. You can configure or display core dump attributes. You can also save, display, segment, upload, or delete a core dump file.

You can manage core dumps in the following ways:

- Configuring core dumps and displaying the configuration settings
- Displaying basic information, the status, and attributes of core dumps

Core dump files and reports are stored in the `/mroot/etc/crash/` directory of a node. You can display the directory content by using the `system node coredump` commands or a web browser.

- Saving the core dump content and uploading the saved file to a specified location or to technical support

ONTAP prevents you from initiating the saving of a core dump file during a takeover, an aggregate relocation, or a giveback.

- Deleting core dump files that are no longer needed

Commands for managing core dumps

You use the `system node coredump config` commands to manage the configuration of core dumps, the `system node coredump` commands to manage the core dump files, and the `system node coredump reports` commands to manage application core reports.

Learn more about the commands described in this topic in the [ONTAP command reference](#).

If you want to...	Use this command...
Configure core dumps	<code>system node coredump config modify</code>
Display the configuration settings for core dumps	<code>system node coredump config show</code>
Display basic information about core dumps	<code>system node coredump show</code>
Manually trigger a core dump when you reboot a node	<code>system node reboot</code> with both the <code>-dump</code> and <code>-skip-lif-migration-before-reboot</code> parameters  The <code>skip-lif-migration-before-reboot</code> parameter specifies that LIF migration prior to a reboot will be skipped.

If you want to...	Use this command...
Manually trigger a core dump when you shut down a node	<pre>system node halt</pre> with both the <code>-dump</code> and <code>-skip-lif-migration-before-shutdown</code> parameters <div style="border-left: 1px solid #ccc; padding-left: 10px; margin-top: 10px;">  <p>The <code>skip-lif-migration-before-shutdown</code> parameter specifies that LIF migration prior to a shutdown will be skipped.</p> </div>
Save a specified core dump	<pre>system node coredump save</pre>
Save all unsaved core dumps that are on a specified node	<pre>system node coredump save-all</pre>
Generate and send an AutoSupport message with a core dump file you specify	<pre>system node autosupport invoke-core-upload</pre> <div style="border-left: 1px solid #ccc; padding-left: 10px; margin-top: 10px;">  <p>The <code>-uri</code> optional parameter specifies an alternate destination for the AutoSupport message.</p> </div>
Display status information about core dumps	<pre>system node coredump status</pre>
Delete a specified core dump	<pre>system node coredump delete</pre>
Delete all unsaved core dumps or all saved core files on a node	<pre>system node coredump delete-all</pre>
Display application core dump reports	<pre>system node coredump reports show</pre>
Delete an application core dump report	<pre>system node coredump reports delete</pre>

Related information

[ONTAP command reference](#)

Disk and tier management


Disks and ONTAP local tiers

Local tiers, also called *aggregates*, are logical containers for the disks managed by a node. You can use local tiers to isolate workloads with different performance demands, to tier data with different access patterns, or to segregate data for regulatory purposes.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*.

- For business-critical applications that need the lowest possible latency and the highest possible performance, you might create a local tier consisting entirely of SSDs.
- To tier data with different access patterns, you can create a *hybrid local tier*, deploying flash as high-performance cache for a working data set, while using lower-cost HDDs or object storage for less frequently accessed data.
 - A *Flash Pool* consists of both SSDs and HDDs.
 - A *FabricPool* consists of an all-SSD local tier with an attached object store.
- If you need to segregate archived data from active data for regulatory purposes, you can use a local tier consisting of capacity HDDs, or a combination of performance and capacity HDDs.



You can use a FabricPool to tier data with different access patterns, deploying SSDs for frequently accessed “hot” data and object storage for rarely accessed “cold” data.

Working with local tiers in a MetroCluster configuration

If you have a MetroCluster configuration, you should following the procedures in the [MetroCluster](#) documentation for initial configuration and guidelines for local tiers and disk management.

Related information

- [Manage local tiers](#)
- [Manage disks](#)
- [Manage RAID configurations](#)
- [Manage Flash Pool tiers](#)
- [Manage FabricPool cloud tiers](#)

Manage local tiers

Learn about ONTAP local tier management

You can use System Manager or the ONTAP CLI to add local tiers, manage their usage, and add capacity (disks) to them.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

You can perform the following tasks:

- [Add \(create\) a local tier](#)

To add a local tier, you follow a specific workflow. You determine the number of disks or disk partitions that you need for the local tier and decide which method to use to create the local tier. You can add local tiers automatically by letting ONTAP assign the configuration, or you can manually specify the configuration.

- [Manage the use of local tiers](#)

For existing local tiers, you can rename them, set their media costs, or determine their drive and RAID group information. You can modify the RAID configuration of a local tier and assign local tiers to storage VMs (SVMs).

You can modify the RAID configuration of a local tier and assign local tiers to storage VMs (SVMs). You can determine which volumes reside on a local tier and how much space they use on a local tier. You can control how much space that volumes can use. You can relocate local tier ownership with an HA pair. You can also delete a local tier.

- [Add capacity \(disks\) to a local tier](#)

Using different methods, you follow a specific workflow to add capacity. You can add disks to a local tier and add drives to a node or shelf. If needed, you can correct misaligned spare partitions.

Add (create) a local tier

Workflow to add an ONTAP local tier

Creating local tiers provides storage to volumes on your system.




Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

The workflow for creating local tiers is specific to the interface you use: System Manager or the CLI.

System Manager


System Manager creates local tiers based on recommended best practices for configuring local tiers.

Beginning with ONTAP 9.11.1, you can decide to configure local tiers manually if you want a different configuration than the one recommended during the automatic process to add a local tier.



CLI

ONTAP can provide recommended configurations when you create local tiers (auto-provisioning). If the recommended configurations, based on best practices, are appropriate in your environment, you can accept them to create the local tier. Otherwise, you can create local tiers manually.



Determine the number of disks or disk partitions required for an ONTAP local tier

You must have enough disks or disk partitions in your local tier to meet system and business requirements. You should also have the recommended number of hot spare disks or hot spare disk partitions to minimize the potential of data loss.

Root-data partitioning is enabled by default on certain configurations. Systems with root-data partitioning enabled use disk partitions to create local tiers. Systems that do not have root-data partitioning enabled use unpartitioned disks.

You must have enough disks or disk partitions to meet the minimum number required for your RAID policy and enough to meet your minimum capacity requirements.



In ONTAP, the usable space of the drive is less than the physical capacity of the drive. You can find the usable space of a specific drive and the minimum number of disks or disk partitions required for each RAID policy in the [Hardware Universe](#).

Determine usable space of a specific disk

The procedure you follow depends on the interface you use—System Manager or the CLI:

System Manager

Use System Manager to determine usable space of disks

Perform the following steps to view the usable size of a disk:

Steps

1. Go to **Storage > Tiers**
2. Click  next to the name of the local tier.
3. Select the **Disk Information** tab.

CLI

Use the CLI to determine usable space of disks

Perform the following step to view the usable size of a disk:

Step

1. Display spare disk information:

```
storage aggregate show-spare-disks
```

In addition to the number of disks or disk partitions necessary to create your RAID group and meet your capacity requirements, you should also have the minimum number of hot spare disks or hot spare disk partitions recommended for your local tier:

- For all flash local tiers, you should have a minimum of one hot spare disk or disk partition.



The AFF C190 defaults to no spare drive. This exception is fully supported.

- For non-flash homogenous local tiers, you should have a minimum of two hot spare disks or disk partitions.
- For SSD storage pools, you should have a minimum of one hot spare disk for each HA pair.
- For Flash Pool local tiers, you should have a minimum of two spare disks for each HA pair. You can find more information on the supported RAID policies for Flash Pool local tiers in the [Hardware Universe](#).
- To support the use of the Maintenance Center and to avoid issues caused by multiple concurrent disk failures, you should have a minimum of four hot spares in multi-disk carriers.

Related information

- [NetApp Hardware Universe](#)
- [NetApp Technical Report 3838: Storage Subsystem Configuration Guide](#)
- [storage aggregate show](#)

Decide which method to use to create ONTAP local tiers

Although ONTAP provides best-practice recommendations for adding local tiers automatically, you must determine whether the recommended configurations are supported in your environment. If they are not, you must make decisions about RAID policy and disk configuration and then create the local tiers manually.

When a local tier is created automatically, ONTAP analyzes available spare disks in the cluster and generates a recommendation about how spare disks should be used to add local tiers according to best practices. ONTAP displays the recommended configurations. You can accept the recommendations or add the local tiers manually.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Before you can accept ONTAP recommendations

If any of the following disk conditions are present, they must be addressed before accepting the recommendations from ONTAP:

- Missing disks
- Fluctuation in spare disk numbers
- Unassigned disks
- Non-zeroed spares
- Disks undergoing maintenance testing

When you must use the manual method

In many cases, the recommended layout of the local tier will be optimal for your environment. However, if your environment includes the following configurations, you must create the local tier using the manual method.



Beginning with ONTAP 9.11.1, you can manually add local tiers with System Manager.

- Local tiers using third-party array LUNs
- Virtual disks with Cloud Volumes ONTAP or ONTAP Select
- MetroCluster system
- SyncMirror
- MSATA disks
- Flash Pool tiers
- Multiple disk types or sizes are connected to the node

Select the method to create local tiers

Choose which method you want to use:

- [Add \(create\) local tiers automatically](#)
- [Add \(create\) local tiers manually](#)

Related information

- [ONTAP command reference](#)
- [storage aggregate auto-provision](#)

Add ONTAP local tiers automatically

If the best-practice recommendation that ONTAP provides for automatically adding a local tier is appropriate in your environment, you can accept the recommendation and let ONTAP add the local tier.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Before you begin

Disks must be owned by a node before they can be used in a local tier. If your cluster is not configured to use automatic disk ownership assignment, you must [assign ownership manually](#).

Learn more about the commands described in this procedure in the [ONTAP command reference](#).

System Manager

Steps

1. In System Manager, click **Storage > Tiers**.
2. From the **Tiers** page, click [+ Add Local Tier](#) to create a new local tier:

The **Add Local Tier** page shows the recommended number of local tiers that can be created on the nodes and the usable storage available.

3. Click **Recommended details** to view the configuration recommended by System Manager.

System Manager displays the following information beginning with ONTAP 9.8:

- **Local tier name** (you can edit the local tier name beginning with ONTAP 9.10.1)
- **Node name**
- **Usable size**
- **Type of storage**

Beginning with ONTAP 9.10.1, additional information is displayed:

- **Disks:** showing the number, size, and type of the disks
- **Layout:** showing the RAID group layout, including which disks are parity or data and which slots are unused.
- **Spare disks:** showing the node name, the number and size of spare disks, and the type of storage.

4. Perform one of the following steps:

If you want to...	Then do this...
Accept the recommendations from System Manager.	Proceed to the step for configuring the Onboard Key Manager for encryption .
Manually configure the local tiers and not use the recommendations from System Manager.	Proceed to Add a local tier manually : <ul style="list-style-type: none">• For ONTAP 9.10.1 and earlier, follow the steps to use the CLI.• Beginning with ONTAP 9.11.1, follow the steps to use System Manager.

5. (Optional): If the Onboard Key Manager has been installed, you can configure it for encryption. Check the **Configure Onboard Key Manager for encryption** check box.
 - a. Enter a passphrase.
 - b. Enter the passphrase again to confirm it.
 - c. Save the passphrase for future use in case the system needs to be recovered.
 - d. Back up the key database for future use.
6. Click **Save** to create the local tier and add it to your storage solution.

CLI

You run the `storage aggregate auto-provision` command to generate local tier layout recommendations. You can then create local tiers after reviewing and approving ONTAP recommendations.

About this task

The default summary generated with the `storage aggregate auto-provision` command lists the recommended local tiers to be created, including names and usable size. You can view the list and determine whether you want to create the recommended local tiers when prompted.

You can also display a detailed summary by using the `-verbose` option, which displays the following reports:

- Per node summary of new local tiers to create, discovered spares, and remaining spare disks and partitions after local tier creation
- New data local tiers to create with counts of disks and partitions to be used
- RAID group layout showing how spare disks and partitions will be used in new data local tiers to be created
- Details about spare disks and partitions remaining after local tier creation

If you are familiar with the auto-provision method and your environment is correctly prepared, you can use the `-skip-confirmation` option to create the recommended local tier without display and confirmation. The `storage aggregate auto-provision` command is not affected by the CLI session `-confirmations` setting.

Learn more about `storage aggregate auto-provision` in the [ONTAP command reference](#).

Steps

1. Run the `storage aggregate auto-provision` command with the desired display options.
 - no options: Display standard summary
 - `-verbose` option: Display detailed summary
 - `-skip-confirmation` option: Create recommended local tiers without display or confirmation
2. Perform one of the following steps:

If you want to...	Then do this...
-------------------	-----------------

Accept the recommendations from ONTAP.

Review the display of recommended local tiers, and then respond to the prompt to create the recommended local tiers.

```
myA400-44556677::> storage aggregate auto-
provision
Node                               New Data Aggregate
Usable Size
-----
-----
myA400-364                          myA400_364_SSD_1
3.29TB
myA400-363                          myA400_363_SSD_1
1.46TB
-----
-----
Total:                               2    new data aggregates
4.75TB

Do you want to create recommended
aggregates? {y|n}: y

Info: Aggregate auto provision has
started. Use the "storage aggregate
      show-auto-provision-progress"
command to track the progress.

myA400-44556677::>
```

Manually configure the local tiers and **not** use the recommendations from ONTAP.

Proceed to [Add a local tier manually](#).

Related information

- [ONTAP command reference](#)

Add ONTAP local tiers manually

If you do not want to add a local tier using the best-practice recommendations from ONTAP, you can perform the process manually.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Before you begin

Disks must be owned by a node before they can be used in a local tier. If your cluster is not configured to use automatic disk ownership assignment, you must [assign ownership manually](#).

Learn more about the commands described in this procedure in the [ONTAP command reference](#).

System Manager

Beginning with ONTAP 9.11.1, if you do not want to use the configuration recommended by System Manager to create a local tier, you can specify the configuration you want.

Steps

1. In System Manager, click **Storage > Tiers**.
2. From the **Tiers** page, click **+ Add Local Tier** to create a new local tier:

The **Add Local Tier** page shows the recommended number of local tiers that can be created on the nodes and the usable storage available.

3. When System Manager displays the storage recommendation for the local tier, click **Switch to Manual Local Tier Creation** in the **Spare Disks** section.

The **Add Local Tier** page displays fields that you use to configure the local tier.

4. In the first section of the **Add Local Tier** page, complete the following:
 - a. Enter the name of the local tier.
 - b. (Optional): Check the **Mirror this local tier** check box if you want to mirror the local tier.
 - c. Select a disk type.
 - d. Select the number of disks.
5. In the **RAID Configuration** section, complete the following:
 - a. Select the RAID type.
 - b. Select the RAID group size.
 - c. Click RAID allocation to view how the disks are allocated in the group.
6. (Optional): If the Onboard Key Manager has been installed, you can configure it for encryption in the **Encryption** section of the page. Check the **Configure Onboard Key Manager for encryption** check box.
 - a. Enter a passphrase.
 - b. Enter the passphrase again to confirm it.
 - c. Save the passphrase for future use in case the system needs to be recovered.
 - d. Back up the key database for future use.
7. Click **Save** to create the local tier and add it to your storage solution.

CLI

Before you create local tiers manually, you should review disk configuration options and simulate creation.

Then you can issue the `storage aggregate create` command and verify the results.

Before you begin

You must have determined the number of disks and the number of hot spare disks you need in the local tier.

About this task

If root-data-data partitioning is enabled and you have 24 solid-state drives (SSDs) or fewer in your configuration, it is recommended that your data partitions be assigned to different nodes.

The procedure for creating local tiers on systems with root-data partitioning and root-data-data partitioning enabled is the same as the procedure for creating local tiers on systems using unpartitioned disks. If root-data partitioning is enabled on your system, you should use the number of disk partitions for the `-diskcount` option. For root-data-data partitioning, the `-diskcount` option specifies the count of disks to use.



When creating multiple local tiers for use with FlexGroup volumes, local tiers should be as close in size as possible.

Learn more about `storage aggregate create` and local tier creation options and requirements in the [ONTAP command reference](#).

Steps

1. View the list of spare disk partitions to verify that you have enough to create your local tier:

```
storage aggregate show-spare-disks -original-owner node_name
```

Data partitions are displayed under `Local Data Usable`. A root partition cannot be used as a spare.

2. Simulate the creation of the local tier:

```
storage aggregate create -aggregate aggregate_name -node node_name  
-raidtype raid_dp -diskcount number_of_disks_or_partitions -simulate true
```

3. If any warnings are displayed from the simulated command, adjust the command and repeat the simulation.
4. Create the local tier:

```
storage aggregate create -aggregate aggr_name -node node_name -raidtype  
raid_dp -diskcount number_of_disks_or_partitions
```

5. Display the local tier to verify that it was created:

```
storage aggregate show-status aggregate_name
```

Related information

- [storage aggregate show](#)

Add ONTAP local tiers with SyncMirror enabled

You can enable SyncMirror when you manually create a local tier to synchronously mirror local tier data.

Learn more about [mirrored and unmirrored local tiers](#).

Before you begin

- The cluster must be initialized with only internal storage.
- Cluster setup must have been completed on both nodes.

About this task

This procedure creates mirrored data local tiers of equal size on each cluster node, and each local tier has a disk count of 44.

Steps

1. Disable storage auto-assignment:

```
storage disk option modify -node * -autoassign off
```

2. Confirm that auto-assignment is disabled:

```
storage disk option show
```

3. Attach the external shelf.

4. Assign the external drives to each node specifying pool 1:

```
storage disk assign -disk <disk ID> -owner <node name> -pool 1
```

5. Mirror the root local tier on each node:

```
storage aggregate mirror -aggregate <node1 root-aggr>
```

```
storage aggregate mirror -aggregate <node2 root-aggr>
```



Drives in pool 1 are automatically partitioned to match those in plex 0.

6. On node 1, create a mirrored data local tier using a disk count of 44. This selects 22 partitions from pool 0 and 22 partitions from pool 1.

```
storage aggregate create -node <node1 name> -aggregate <node1 aggr-name>  
-diskcount 44 -mirror true
```

7. On node 2, create a mirrored data local tier using a disk count of 44. This selects 22 partitions from pool 0 and 22 partitions from pool 1.

```
storage aggregate create -node <node2 name> -aggregate <node2 aggr-name>  
-diskcount 44 -mirror true
```

8. Verify that local tiers of equal size were successfully created:

```
storage aggregate show
```

Related information

- [storage disk assign](#)
- [storage disk option modify](#)
- [storage disk option show](#)

Manage the use of local tiers

Rename an ONTAP local tier

You can rename a local tier. The method you follow depends on the interface you use—System Manager or the CLI.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

System Manager

Use System Manager to rename a local tier

Beginning with ONTAP 9.10.1, you can modify the name of a local tier.

Steps

1. In System Manager, click **Storage > Tiers**.
2. Click  next to the name of the local tier.
3. Select **Rename**.
4. Specify a new name for the local tier.

CLI

Use the CLI to rename a local tier

Step

1. Using the CLI, rename the local tier:

```
storage aggregate rename -aggregate aggr-name -newname aggr-new-name
```

The following example renames an aggregate named “aggr5” as “sales-aggr”:

```
> storage aggregate rename -aggregate aggr5 -newname sales-aggr
```

Related information

- [storage aggregate rename](#)

Set media cost of an ONTAP local tier

Beginning with ONTAP 9.11.1, you can use System Manager to set the media cost of a local tier.

Steps

1. In System Manager, click **Storage > Tiers**, then click **Set Media Cost** in the desired local tier tiles.
2. Select **active and inactive tiers** to enable comparison.
3. Enter a currency type and amount.

When you enter or change the media cost, the change is made in all media types.

Manually fast zero ONTAP drives

On systems freshly installed with ONTAP 9.4 or later and systems reinitialized with ONTAP 9.4 or later, *fast zeroing* is used to zero drives.

With *fast zeroing*, drives are zeroed in seconds. This is done automatically before provisioning and greatly reduces the time it takes to initialize the system, create local tiers, or expand local tiers when spare drives are added.

Fast zeroing is supported on both SSDs and HDDs.



Fast zeroing is not supported on systems upgraded from ONTAP 9.3 or earlier. ONTAP 9.4 or later must be freshly installed or the system must be reinitialized. In ONTAP 9.3 and earlier, drives are also automatically zeroed by ONTAP; however, the process takes longer.

If you need to manually zero a drive, you can use one of the following methods. In ONTAP 9.4 and later, manually zeroing a drive also takes only seconds.

CLI command

Use a CLI command to fast-zero drives

About this task

Admin privileges are required to use this command.

Steps

1. Enter the CLI command:

```
storage disk zerospares
```

Boot menu options

Select options from the boot menu to fast-zero drives

About this task

- The fast zeroing enhancement does not support systems upgraded from a release earlier than ONTAP 9.4.

Steps

1. From the boot menu, select one of the following options:
 - (4) Clean configuration and initialize all disks
 - (9a) Unpartition all disks and remove their ownership information
 - (9b) Clean configuration and initialize node with whole disks

Related information

- [storage disk zerospares](#)

Manually assign ONTAP disk ownership

Disks must be owned by a node before they can be used in a local tier.

About this task

- If you are manually assigning ownership in an HA pair that is not being initialized and does not have only DS460C shelves, use option 1.
- If you are initializing an HA pair that has only DS460C shelves, use option 2 to manually assign ownership for the root drives.

Option 1: Most HA pairs

For an HA pair that is not being initialized and does not have only DS460C shelves, use this procedure to manually assigning ownership.

About this task

- The disks you are assigning ownership for must be in a shelf that is physically cabled to the node you are assigning ownership to.
- If you are using disks in a local tier (aggregate):
 - Disks must be owned by a node before they can be used in a local tier (aggregate).
 - You cannot reassign ownership of a disk that is in use in a local tier (aggregate).

Steps

1. Use the CLI to display all unowned disks:

```
storage disk show -container-type unassigned
```

2. Assign each disk:

```
storage disk assign -disk disk_name -owner owner_name
```

You can use the wildcard character to assign more than one disk at once. If you are reassigning a spare disk that is already owned by a different node, you must use the “-force” option.

Option 2: An HA pair with only DS460C shelves

For an HA pair that you are initializing and that only has DS460C shelves, use this procedure to manually assign ownership for the root drives.

About this task

- When you initialize an HA pair that has only DS460C shelves, you must manually assign the root drives to conform to the half-drawer policy.

After HA pair initialization (boot up), automatic assignment of disk ownership is automatically enabled and uses the half-drawer policy to assign ownership to the remaining drives (other than the root drives) and any drives added in the future, such as replacing failed disks, responding to a "low spares" message, or adding capacity.

[Learn about the half-drawer policy.](#)

- RAID needs a minimum of 10 drives for each HA pair (5 for each node) for any greater than 8TB NL-SAS drives in a DS460C shelf.

Steps


1. If your DS460C shelves are not fully populated, complete the following substeps; otherwise, go to the next step.
 - a. First, install drives in the front row (drive bays 0, 3, 6, and 9) of each drawer.

Installing drives in the front row of each drawer allows for proper air flow and prevents overheating.

- b. For the remaining drives, evenly distribute them across each drawer.

Fill drawer rows from front to back. If you don't have enough drives to fill rows, then install them in pairs so that drives occupy the left and right side of a drawer evenly.

The following illustration shows the drive bay numbering and locations in a DS460C drawer.



2. Log into the clustershell using the node-management LIF or cluster-management LIF.

3. Manually assign the root drives in each drawer to conform to the half-drawer policy using the following substeps:

The half-drawer policy has you assign the left half of a drawer's drives (bays 0 to 5) to node A, and the right half of a drawer's drives (bays 6 to 11) to node B.

- a. Display all unowned disks:

```
storage disk show -container-type unassigned
```

- b. Assign the root disks:

```
storage disk assign -disk disk_name -owner owner_name
```

You can use the wildcard character to assign more than one disk at a time.

Learn more about `storage disk` in the [ONTAP command reference](#).

Related information

- [storage disk assign](#)
- [storage disk show](#)

Determine drive and RAID group information for an ONTAP local tier

Some local tier administration tasks require that you know what types of drives compose the local tier, their size, checksum, and status, whether they are shared with other local tiers, and the size and composition of the RAID groups.

Step

1. Show the drives for the local tier, by RAID group:

```
storage aggregate show-status aggr_name
```

The drives are displayed for each RAID group in the local tier.

You can see the RAID type of the drive (data, parity, dparity) in the `Position` column. If the `Position` column displays `shared`, then the drive is shared: if it is an HDD, it is a partitioned disk; if it is an SSD, it is part of a storage pool.

Example: A Flash Pool local tier using an SSD storage pool and data partitions

```
cluster1::> storage aggregate show-status nodeA_fp_1
```

```
Owner Node: cluster1-a
```

```
Aggregate: nodeA_fp_1 (online, mixed_raid_type, hybrid) (block checksums)
```

```
Plex: /nodeA_fp_1/plex0 (online, normal, active, pool0)
```

```
RAID Group /nodeA_fp_1/plex0/rg0 (normal, block checksums, raid_dp)
```

Position	Disk	Pool	Type	RPM	Usable Size	Physical Size	Status
shared	2.0.1	0	SAS	10000	472.9GB	547.1GB	(normal)
shared	2.0.3	0	SAS	10000	472.9GB	547.1GB	(normal)
shared	2.0.5	0	SAS	10000	472.9GB	547.1GB	(normal)
shared	2.0.7	0	SAS	10000	472.9GB	547.1GB	(normal)
shared	2.0.9	0	SAS	10000	472.9GB	547.1GB	(normal)
shared	2.0.11	0	SAS	10000	472.9GB	547.1GB	(normal)

```
RAID Group /nodeA_flashpool_1/plex0/rg1
```

```
(normal, block checksums, raid4) (Storage Pool: SmallSP)
```

Position	Disk	Pool	Type	RPM	Usable Size	Physical Size	Status
shared	2.0.13	0	SSD	-	186.2GB	745.2GB	(normal)
shared	2.0.12	0	SSD	-	186.2GB	745.2GB	(normal)

```
8 entries were displayed.
```

Related information

- [storage aggregate show-status](#)

Assign ONTAP local tiers to storage VMs (SVMs)

If you assign one or more local tiers to a storage virtual machine (storage VM or SVM, formerly known as Vserver), then you can use only those local tiers to contain volumes for that storage VM (SVM).



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Before you begin

The storage VM and the local tiers you want to assign to that storage VM must already exist.

About this task

Assigning local tiers to your storage VMs helps you keep your storage VMs isolated from each other; this is especially important in a multi-tenancy environment.

Steps

1. Check the list of local tiers already assigned to the SVM:

```
vserver show -fields aggr-list
```

The local tiers currently assigned to the SVM are displayed. If there are no local tiers assigned, - is displayed.

2. Add or remove assigned local tiers, depending on your requirements:

If you want to...	Use this command...
Assign additional local tiers	<code>vserver add-aggregates</code>
Unassign local tiers	<code>vserver remove-aggregates</code>

The listed local tiers are assigned to or removed from the SVM. If the SVM already has volumes that use an aggregate that is not assigned to the SVM, a warning message is displayed, but the command is completed successfully. Any local tiers that were already assigned to the SVM and that were not named in the command are unaffected.

Example

In the following example, the local tiers `aggr1` and `aggr2` are assigned to SVM `svm1`:

```
vserver add-aggregates -vserver svm1 -aggregates aggr1,aggr2
```

Determine which volumes reside on an ONTAP local tier

You might need to determine which volumes reside on a local tier before performing operations on the local tier, such as relocating it or taking it offline.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Steps

1. To display the volumes that reside on a local tier, enter

```
volume show -aggregate aggregate_name
```

All volumes that reside on the specified local tier are displayed.

Determine and control space usage of a volume in an ONTAP local tier

You can determine which FlexVol volumes are using the most space in a local tier and specifically which features within the volume.

The `volume show-footprint` command provides information about a volume's footprint, or its space usage within the containing local tier.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

The `volume show-footprint` command shows details about the space usage of each volume in a local tier, including offline volumes. This command bridges the gap between the output of the `volume show-space` and `aggregate show-space` commands. All percentages are calculated as a percent of local tier size.

The following example shows the `volume show-footprint` command output for a volume called `testvol`:

```
cluster1::> volume show-footprint testvol

Vserver : thevs
Volume  : testvol

Feature                               Used      Used%
-----
Volume Data Footprint                 120.6MB   4%
Volume Guarantee                      1.88GB    71%
Flexible Volume Metadata              11.38MB   0%
Delayed Frees                         1.36MB    0%
Total Footprint                       2.01GB    76%
```

The following table explains some of the key rows of the output of the `volume show-footprint` command and what you can do to try to decrease space usage by that feature:

Row/feature name	Description/contents of row	Some ways to decrease
Volume Data Footprint	The total amount of space used in the containing local tier by a volume's data in the active file system and the space used by the volume's snapshots. This row does not include reserved space.	<ul style="list-style-type: none"> Deleting data from the volume. Deleting snapshots from the volume.
Volume Guarantee	The amount of space reserved by the volume in the local tier for future writes. The amount of space reserved depends on the guarantee type of the volume.	Changing the type of guarantee for the volume to <code>none</code> .
Flexible Volume Metadata	The total amount of space used in the local tier by the volume's metadata files.	No direct method to control.

Delayed Frees	Blocks that ONTAP used for performance and cannot be immediately freed. For SnapMirror destinations, this row has a value of 0 and is not displayed.	No direct method to control.
File Operation Metadata	The total amount of space reserved for file operation metadata.	No direct method to control.
Total Footprint	The total amount of space that the volume uses in the local tier. It is the sum of all of the rows.	Any of the methods used to decrease space used by a volume.

Related information

[NetApp Technical Report 3483: Thin Provisioning in a NetApp SAN or IP SAN Enterprise Environment](#)

Determine space usage in an ONTAP local tier

You can view how much space is used by all volumes in one or more local tiers so that you can take actions to free more space.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

WAFL reserves a percentage of the total disk space for local tier level metadata and performance. The space used for maintaining the volumes in the local tier comes out of the WAFL reserve and cannot be changed.

In local tiers smaller than 30 TB, WAFL reserves 10% of the total disk space for local tier level metadata and performance.

Beginning with ONTAP 9.12.1, in local tiers that are 30 TB or larger, the amount of reserved disk space for local tier level metadata and performance is reduced, resulting in 5% more usable space in local tiers. The availability of this space savings varies based on your platform and version of ONTAP.

Disk space reserved by ONTAP in local tiers 30 TB or greater	Applies to platforms	In ONTAP versions
5%	All AFF and FAS platforms	ONTAP 9.14.1 and later
5%	AFF platforms and FAS500f platforms	ONTAP 9.12.1 and later
10%	All platforms	ONTAP 9.11.1 and later

You can view space usage by all volumes in one or more local tiers with the `aggregate show-space` command. This helps you see which volumes are consuming the most space in their containing local tiers so that you can take actions to free more space.

The used space in an local tier is directly affected by the space used in the FlexVol volumes it contains. Measures that you take to increase space in a volume also affect space in the local tier.



Beginning with ONTAP 9.15.1, two new metadata counters are available. Together with changes to several existing counters, you can get a clearer view of the amount of user data allocated. See [Determine space usage in a volume or local tier](#) for more information.

The following rows are included in the `aggregate show-space` command output:

- **Volume Footprints**

The total of all volume footprints within the local tier. It includes all of the space that is used or reserved by all data and metadata of all volumes in the containing local tier.

- **Aggregate Metadata**

The total file system metadata required by the local tier, such as allocation bitmaps and inode files.

- **Snapshot Reserve**

The amount of space reserved for local tier snapshots, based on volume size. It is considered used space and is not available to volume or local tier data or metadata.

- **Snapshot Reserve Unusable**

The amount of space originally allocated for local tier snapshot reserve that is unavailable for local tier snapshots because it is being used by volumes associated with the local tier. Can occur only for local tiers with a non-zero local tier snapshot reserve.

- **Total Used**

The sum of all space used or reserved in the local tier by volumes, metadata, or snapshots.

- **Total Physical Used**

The amount of space being used for data now (rather than being reserved for future use). Includes space used by local tier snapshots.

The following example shows the `aggregate show-space` command output for an local tier whose snapshot reserve is 5%. If the snapshot reserve was 0, the row would not be displayed.

```
cluster1::> storage aggregate show-space

Aggregate : wqa_gx106_aggr1

Feature                               Used           Used%
-----                               -
Volume Footprints                      101.0MB        0%
Aggregate Metadata                     300KB          0%
Snapshot Reserve                       5.98GB         5%

Total Used                             6.07GB         5%
Total Physical Used                    34.82KB        0%
```

Related Information

- [Knowledge Base article: Space Usage](#)
- [Free up 5% of your storage capacity by upgrading to ONTAP 9.12.1](#)
- [storage aggregate show-space](#)

Relocate ownership of an ONTAP local tier within an HA pair

You can change the ownership of local tiers among the nodes in an HA pair without interrupting service from the local tiers.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Both nodes in an HA pair are physically connected to each other's disks or array LUNs. Each disk or array LUN is owned by one of the nodes.

Ownership of all disks or array LUNs within a local tier changes temporarily from one node to the other when a takeover occurs. However, local tiers relocation operations can also permanently change the ownership (for example, if done for load balancing). The ownership changes without any data-copy processes or physical movement of the disks or array LUNs.

About this task

- Because volume count limits are validated programmatically during local tier relocation operations, it is not necessary to check for this manually.

If the volume count exceeds the supported limit, the local tier relocation operation fails with a relevant error message.

- You should not initiate local tier relocation when system-level operations are in progress on either the source or the destination node; likewise, you should not start these operations during the local tier relocation.

These operations can include the following:

- Takeover
- Giveback
- Shutdown
- Another local tier relocation operation
- Disk ownership changes
- Local tier or volume configuration operations
- Storage controller replacement
- ONTAP upgrade
- ONTAP revert
- If you have a MetroCluster configuration, you should not initiate local tier relocation while disaster recovery operations (*switchover*, *healing*, or *switchback*) are in progress.
- If you have a MetroCluster configuration and initiate local tier relocation on a switched-over local tier, the operation might fail because it exceeds the DR partner's volume limit count.

- You should not initiate local tier relocation on local tiers that are corrupt or undergoing maintenance.
- Before initiating the local tier relocation, you should save any core dumps on the source and destination nodes.

Steps

1. View the local tiers on the node to confirm which local tiers to move and ensure they are online and in good condition:

```
storage aggregate show -node source-node
```

The following command shows six local tiers on the four nodes in the cluster. All local tiers are online. Node1 and Node3 form an HA pair and Node2 and Node4 form an HA pair.

```
cluster::> storage aggregate show
Aggregate      Size Available Used% State  #Vols  Nodes  RAID Status
-----
aggr_0        239.0GB   11.13GB   95% online    1 node1  raid_dp,
normal
aggr_1        239.0GB   11.13GB   95% online    1 node1  raid_dp,
normal
aggr_2        239.0GB   11.13GB   95% online    1 node2  raid_dp,
normal
aggr_3        239.0GB   11.13GB   95% online    1 node2  raid_dp,
normal
aggr_4        239.0GB   238.9GB    0% online    5 node3  raid_dp,
normal
aggr_5        239.0GB   239.0GB    0% online    4 node4  raid_dp,
normal

6 entries were displayed.
```

2. Issue the command to start the local tier relocation:

```
storage aggregate relocation start -aggregate-list aggregate-1, aggregate-2...
-node source-node -destination destination-node
```

The following command moves the local tier aggr_1 and aggr_2 from Node1 to Node3. Node3 is Node1's HA partner. The local tiers can be moved only within the HA pair.

```
cluster::> storage aggregate relocation start -aggregate-list aggr_1,
aggr_2 -node node1 -destination node3
Run the storage aggregate relocation show command to check relocation
status.
node1::storage aggregate>
```

3. Monitor the progress of the local tier relocation with the storage aggregate relocation show command:

```
storage aggregate relocation show -node source-node
```

The following command shows the progress of the local tiers that are being moved to Node3:

```
cluster::> storage aggregate relocation show -node node1
Source Aggregate      Destination      Relocation Status
-----
node1
      aggr_1          node3           In progress, module: waf1
      aggr_2          node3           Not attempted yet
2 entries were displayed.
node1::storage aggregate>
```

When the relocation is complete, the output of this command shows each local tier with a relocation status of “Done”.

Related information

- [storage aggregate relocation show](#)
- [storage aggregate relocation start](#)
- [storage aggregate show](#)

Delete an ONTAP local tier

You can delete a local tier if there are no volumes on the local tier.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

The `storage aggregate delete` command deletes a storage local tier. The command fails if there are volumes present on the local tier. If the local tier has an object store attached to it, then in addition to deleting the local, the command deletes the objects in the object store as well. No changes are made to the object store configuration as part of this command.

The following example deletes an local tier named “aggr1”:

```
> storage aggregate delete -aggregate aggr1
```

Related information

- [storage aggregate delete](#)

ONTAP commands for a local tier relocation

There are specific ONTAP commands for relocating local tier ownership within an HA pair.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

If you want to...	Use this command...
Start the local tier relocation process	<code>storage aggregate relocation start</code>
Monitor the local tier relocation process	<code>storage aggregate relocation show</code>

Related information

- [storage aggregate relocation show](#)
- [storage aggregate relocation start](#)

ONTAP commands for managing local tiers

You use the `storage aggregate` command to manage your local tiers.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

If you want to...	Use this command...
Display the size of the cache for all Flash Pool local tiers	<code>storage aggregate show -fields hybrid-cache-size-total -hybrid-cache-size -total >0</code>
Display disk information and status for an local tier	<code>storage aggregate show-status</code>
Display spare disks by node	<code>storage aggregate show-spare-disks</code>
Display the root local tiers in the cluster	<code>storage aggregate show -has-mroot true</code>
Display basic information and status for local tiers	<code>storage aggregate show</code>
Display the type of storage used in an local tiers	<code>storage aggregate show -fields storage-type</code>
Bring an local tier online	<code>storage aggregate online</code>
Delete an local tier	<code>storage aggregate delete</code>
Put an local tier into the restricted state	<code>storage aggregate restrict</code>

If you want to...	Use this command...
Rename an local tier	<code>storage aggregate rename</code>
Take an local tier offline	<code>storage aggregate offline</code>
Change the RAID type for a local tier	<code>storage aggregate modify -raidtype</code>

Related information


- [storage aggregate delete](#)
- [storage aggregate modify](#)
- [storage aggregate offline](#)
- [storage aggregate online](#)
- [storage aggregate rename](#)
- [storage aggregate restrict](#)
- [storage aggregate show](#)

Add capacity (disks) to a local tier

Workflow to add capacity to an ONTAP local tier

To add capacity to a local tier you must first identify which local tier you want to add to, determine how much new storage is needed, install new disks, assign disk ownership, and create a new RAID group, if needed.

You can use either System Manager or the ONTAP CLI to add capacity.



Methods to create space in an ONTAP local tier

If a local tier runs out of free space, various problems can result that range from loss of data to disabling a volume's guarantee. There are multiple ways to make more space in a local tier.

All of the methods have various consequences. Prior to taking any action, you should read the relevant section in the documentation.

The following are some common ways to make space in local tier, in order of least to most consequences:

- Add disks to the local tier.
- Move some volumes to another local tier with available space.
- Shrink the size of volume-guaranteed volumes in the local tier.
- Delete unneeded volume snapshots if the volume's guarantee type is "none".
- Delete unneeded volumes.
- Enable space-saving features, such as deduplication or compression.
- (Temporarily) disable features that are using a large amount of metadata .

Add capacity to an ONTAP local tier

You can add disks to an local tier so that it can provide more storage to its associated volumes.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

System Manager (ONTAP 9.8 and later)



Beginning with ONTAP 9.12.1, you can use System Manager to view the committed capacity of a local tier to determine if additional capacity is required for the local tier. See [Monitor capacity in System Manager](#).

Steps

1. Select **Storage > Tiers**.
2. Select  next to the name of the local tier to which you want to add capacity.
3. Select **Add Capacity**.



If there are no spare disks that you can add, then the **Add Capacity** option is not shown, and you cannot increase the capacity of the local tier.

4. Perform the following steps, based on the version of ONTAP that is installed:

If this version of ONTAP is installed...	Perform these steps...
Beginning with ONTAP 9.11.1	<ol style="list-style-type: none">1. Select the disk type and number of disks.2. If you want to add disks to a new RAID group, check the check box. The RAID allocation is displayed.3. Select Save.
ONTAP 9.10.1, 9.9, or 9.8	<ol style="list-style-type: none">1. If the node contains multiple storage tiers, then select the number of disks you want to add to the local tier. Otherwise, if the node contains only a single storage tier, the added capacity is estimated automatically.2. Select Add.

5. (Optional) The process takes some time to complete. If you want to run the process in the background, select **Run in Background**.
6. After the process completes, you can view the increased capacity amount in the local tier information at **Storage > Tiers**.

System Manager (ONTAP 9.7 and earlier)

Steps

1. (For ONTAP 9.7 only) Select **(Return to classic version)**.
2. Select **Hardware and Diagnostics > Aggregates**.
3. Select the local tier to which you want to add capacity disks, and then select **Actions > Add Capacity**.



You should add disks that are of the same size as the other disks in the local tier.

4. (For ONTAP 9.7 only) Select **Switch to the new experience**.
5. Select **Storage > Tiers** to verify the size of the new local tier.

CLI

Before you begin

You must know what the RAID group size is for the local tier you are adding the storage to.

About this task

This procedure for adding partitioned disks to a local tier is similar to the procedure for adding unpartitioned disks.

When you expand a local tier, you should be aware of whether you are adding partition or unpartitioned disks to the local tier. When you add unpartitioned drives to an existing local tier, the size of the existing RAID groups is inherited by the new RAID group, which can affect the number of parity disks required. If an unpartitioned disk is added to a RAID group composed of partitioned disks, the new disk is partitioned, leaving an unused spare partition.

When you provision partitions, you must ensure that you do not leave the node without a drive with both partitions as spare. If you do, and the node experiences a controller disruption, valuable information about the problem (the core file) might not be available to provide to the technical support.

Steps

1. Show the available spare storage on the system that owns the local tier:

```
storage aggregate show-spare-disks -original-owner node_name
```

You can use the `-is-disk-shared` parameter to show only partitioned drives or only unpartitioned drives.

```
cl1-s2::> storage aggregate show-spare-disks -original-owner cl1-s2
-is-disk-shared true
```

Original Owner: cl1-s2

Pool0

Shared HDD Spares

Local Local
Local Data

Root Physical

Disk	Type	RPM	Checksum	Usable
Usable	Size	Status		

1.0.1	BSAS	7200	block	753.8GB
73.89GB	828.0GB	zeroed		

1.0.2	BSAS	7200	block	753.8GB
0B	828.0GB	zeroed		

1.0.3	BSAS	7200	block	753.8GB
0B	828.0GB	zeroed		

1.0.4	BSAS	7200	block	753.8GB
0B	828.0GB	zeroed		

1.0.8	BSAS	7200	block	753.8GB
0B	828.0GB	zeroed		

1.0.9	BSAS	7200	block	753.8GB
0B	828.0GB	zeroed		

1.0.10	BSAS	7200	block	0B
73.89GB	828.0GB	zeroed		

2 entries were displayed.

2. Show the current RAID groups for the local tier:

```
storage aggregate show-status <aggr_name>
```

```
cl1-s2::> storage aggregate show-status -aggregate data_1
```

```
Owner Node: cl1-s2
```

```
Aggregate: data_1 (online, raid_dp) (block checksums)
```

```
Plex: /data_1/plex0 (online, normal, active, pool0)
```

```
RAID Group /data_1/plex0/rg0 (normal, block checksums)
```

	Position	Disk	Pool	Type	RPM	Usable Size	Physical Size	Status
	-----	-----	-----	-----	-----	-----	-----	-----
	shared	1.0.10	0	BSAS	7200	753.8GB	828.0GB	(normal)
	shared	1.0.5	0	BSAS	7200	753.8GB	828.0GB	(normal)
	shared	1.0.6	0	BSAS	7200	753.8GB	828.0GB	(normal)
	shared	1.0.11	0	BSAS	7200	753.8GB	828.0GB	(normal)
	shared	1.0.0	0	BSAS	7200	753.8GB	828.0GB	(normal)

5 entries were displayed.

3. Simulate adding the storage to the aggregate:

```
storage aggregate add-disks -aggregate <aggr_name> -diskcount  
<number_of_disks_or_partitions> -simulate true
```

You can see the result of the storage addition without actually provisioning any storage. If any warnings are displayed from the simulated command, you can adjust the command and repeat the simulation.

```
cl1-s2::> storage aggregate add-disks -aggregate aggr_test
-diskcount 5 -simulate true
```

Disks would be added to aggregate "aggr_test" on node "cl1-s2" in the following manner:

First Plex

```
RAID Group rg0, 5 disks (block checksum, raid_dp)
Usable
Physical
Position  Disk                               Type  Size
Size
-----  -
shared    1.11.4                             SSD   415.8GB
415.8GB
shared    1.11.18                            SSD   415.8GB
415.8GB
shared    1.11.19                            SSD   415.8GB
415.8GB
shared    1.11.20                            SSD   415.8GB
415.8GB
shared    1.11.21                            SSD   415.8GB
415.8GB
```

Aggregate capacity available for volume use would be increased by 1.83TB.

4. Add the storage to the aggregate:

```
storage aggregate add-disks -aggregate <aggr_name> -raidgroup new
-diskcount <number_of_disks_or_partitions>
```

When creating a Flash Pool local tier, if you are adding disks with a different checksum than the local tier, or if you are adding disks to a mixed checksum local tier, you must use the `-checksumstyle` parameter.

If you are adding disks to a Flash Pool local tier, you must use the `-disktype` parameter to specify the disk type.

You can use the `-disksize` parameter to specify a size of the disks to add. Only disks with approximately the specified size are selected for addition to the local tier.

```
c11-s2::> storage aggregate add-disks -aggregate data_1 -raidgroup
new -diskcount 5
```

5. Verify that the storage was added successfully:

```
storage aggregate show-status -aggregate <aggr_name>
```

```
c11-s2::> storage aggregate show-status -aggregate data_1
```

Owner Node: c11-s2

Aggregate: data_1 (online, raid_dp) (block checksums)

Plex: /data_1/plex0 (online, normal, active, pool0)

RAID Group /data_1/plex0/rg0 (normal, block checksums)

					Usable	
Physical	Position	Disk	Pool	Type	RPM	Size
Size	Status					

shared	1.0.10		0	BSAS	7200	753.8GB
828.0GB (normal)						
shared	1.0.5		0	BSAS	7200	753.8GB
828.0GB (normal)						
shared	1.0.6		0	BSAS	7200	753.8GB
828.0GB (normal)						
shared	1.0.11		0	BSAS	7200	753.8GB
828.0GB (normal)						
shared	1.0.0		0	BSAS	7200	753.8GB
828.0GB (normal)						
shared	1.0.2		0	BSAS	7200	753.8GB
828.0GB (normal)						
shared	1.0.3		0	BSAS	7200	753.8GB
828.0GB (normal)						
shared	1.0.4		0	BSAS	7200	753.8GB
828.0GB (normal)						
shared	1.0.8		0	BSAS	7200	753.8GB
828.0GB (normal)						
shared	1.0.9		0	BSAS	7200	753.8GB
828.0GB (normal)						

10 entries were displayed.

6. Verify that the node still has at least one drive with both the root partition and the data partition as spare:

```
storage aggregate show-spare-disks -original-owner <node_name>
```

```
cl1-s2::> storage aggregate show-spare-disks -original-owner cl1-s2  
-is-disk-shared true
```

```
Original Owner: cl1-s2
```

```
Pool0
```

```
Shared HDD Spares
```

```
Local
```

```
Local
```

```
Data
```

```
Root Physical
```

```
Disk          Type      RPM Checksum  Usable  
Usable      Size Status
```

```
-----  
-----
```

```
1.0.1          BSAS      7200 block    753.8GB
```

```
73.89GB  828.0GB zeroed
```

```
1.0.10          BSAS      7200 block    0B
```

```
73.89GB  828.0GB zeroed
```

```
2 entries were displayed.
```

Related information

- [storage aggregate add-disks](#)
- [storage aggregate show-spare-disks](#)
- [storage aggregate show-status](#)

Add drives to an ONTAP node or shelf

You add drives to a node or shelf to increase the number of hot spares or to add space to local tier.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Before you begin

The drive you want to add must be supported by your platform. You can confirm using the [NetApp Hardware Universe](#).

The minimum number of drives you should add in a single procedure is six. Adding a single drive might reduce performance.

Steps for the NetApp Hardware Universe

1. In the **Products** dropdown menu, select your hardware configuration
2. Select your platform.
3. Select the version of ONTAP you are running then **Show Results**.
4. Beneath the graphic, select **Click here to see alternate views**. Choose the view that matches your configuration.



Steps to install the drives

1. Check the [NetApp Support Site](#) for newer drive and shelf firmware and Disk Qualification Package files.

If your node or shelf does not have the latest versions, update them before installing the new drive.

Drive firmware is automatically updated (nondisruptively) on new drives that do not have current firmware versions.

2. Properly ground yourself.
3. Gently remove the bezel from the front of the platform.
4. Identify the correct slot for the new drive.



The correct slots for adding drives vary depending on the platform model and ONTAP version. In some cases you need to add drives to specific slots in sequence. For example, in an AFF A800 you add the drives at specific intervals leaving clusters of empty slots. Whereas, in an AFF A220 you add new drives to the next empty slots running from the outside towards the middle of the shelf.

Refer to the steps in **Before you begin** to identify the correct slots for your configuration in the [NetApp Hardware Universe](#).

5. Insert the new drive:
 - a. With the cam handle in the open position, use both hands to insert the new drive.
 - b. Push until the drive stops.
 - c. Close the cam handle so that the drive is fully seated into the mid plane and the handle clicks into place. Be sure to close the cam handle slowly so that it aligns correctly with the face of the drive.
6. Verify that the drive's activity LED (green) is illuminated.

When the drive's activity LED is solid, it means that the drive has power. When the drive's activity LED is blinking, it means that the drive has power and I/O is in progress. If the drive firmware is automatically updating, the LED blinks.

7. To add another drive, repeat Steps 4 through 6.

The new drives are not recognized until they are assigned to a node. You can assign the new drives

manually, or you can wait for ONTAP to automatically assign the new drives if your node follows the rules for drive auto-assignment.

8. After the new drives have all been recognized, verify that they have been added and their ownership is specified correctly.

Steps to confirm installation

1. Display the list of disks:

```
storage aggregate show-spare-disks
```

You should see the new drives, owned by the correct node.

2. **Optionally (for ONTAP 9.3 and earlier only)**, zero the newly added drives:

```
storage disk zerospares
```

Drives that have been used previously in an ONTAP local tier must be zeroed before they can be added to another local tier. In ONTAP 9.3 and earlier, zeroing can take hours to complete, depending on the size of the non-zeroed drives in the node. Zeroing the drives now can prevent delays in case you need to quickly increase the size of a local tier. This is not an issue in ONTAP 9.4 or later where drives are zeroed using *fast zeroing* which takes only seconds.

Results

The new drives are ready. You can add them to a local tier, place them onto the list of hot spares, or add them when you create a new local tier.

Related information

- [storage aggregate show-spare-disks](#)
- [storage disk zerospares](#)

Correct misaligned ONTAP spare partitions

When you add partitioned disks to a local tier, you must leave a disk with both the root and data partition available as a spare for every node. If you do not and your node experiences a disruption, ONTAP cannot dump the core to the spare data partition.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Before you begin

You must have both a spare data partition and a spare root partition on the same type of disk owned by the same node.

Steps

1. Using the CLI, display the spare partitions for the node:

```
storage aggregate show-spare-disks -original-owner node_name
```

Note which disk has a spare data partition (`spare_data`) and which disk has a spare root partition

(`spare_root`). The spare partition will show a non-zero value under the `Local Data Usable` or `Local Root Usable` column.

2. Replace the disk with a spare data partition with the disk with the spare root partition:

```
storage disk replace -disk spare_data -replacement spare_root -action start
```

You can copy the data in either direction; however, copying the root partition takes less time to complete.

3. Monitor the progress of the disk replacement:

```
storage aggregate show-status -aggregate aggr_name
```

4. After the replacement operation is complete, display the spares again to confirm that you have a full spare disk:

```
storage aggregate show-spare-disks -original-owner node_name
```

You should see a spare disk with usable space under both “Local Data Usable” and `Local Root Usable`.

Example

You display your spare partitions for node `c1-01` and see that your spare partitions are not aligned:

```
c1::> storage aggregate show-spare-disks -original-owner c1-01
```

```
Original Owner: c1-01
```

```
Pool0
```

```
Shared HDD Spares
```

Disk	Type	RPM	Checksum	Local	Local	Physical
				Data Usable	Root Usable	
1.0.1	BSAS	7200	block	753.8GB	0B	828.0GB
1.0.10	BSAS	7200	block	0B	73.89GB	828.0GB

You start the disk replacement job:

```
c1::> storage disk replace -disk 1.0.1 -replacement 1.0.10 -action start
```

While you are waiting for the replacement operation to finish, you display the progress of the operation:

```
c1::> storage aggregate show-status -aggregate aggr0_1

Owner Node: c1-01
Aggregate: aggr0_1 (online, raid_dp) (block checksums)
Plex: /aggr0_1/plex0 (online, normal, active, pool0)
RAID Group /aggr0_1/plex0/rg0 (normal, block checksums)
          Usable Physical
Position Disk    Pool Type    RPM    Size    Size Status
-----
shared  1.0.1      0  BSAS  7200  73.89GB  828.0GB (replacing, copy in
progress)
shared  1.0.10     0  BSAS  7200  73.89GB  828.0GB (copy 63% completed)
shared  1.0.0      0  BSAS  7200  73.89GB  828.0GB (normal)
shared  1.0.11     0  BSAS  7200  73.89GB  828.0GB (normal)
shared  1.0.6      0  BSAS  7200  73.89GB  828.0GB (normal)
shared  1.0.5      0  BSAS  7200  73.89GB  828.0GB (normal)
```

After the replacement operation is complete, confirm that you have a full spare disk:

```
ie2220::> storage aggregate show-spare-disks -original-owner c1-01

Original Owner: c1-01
Pool0
  Shared HDD Spares
          Local    Local
          Data    Root    Physical
Disk    Type    RPM Checksum Usable  Usable  Size
-----
1.0.1  BSAS  7200 block   753.8GB  73.89GB  828.0GB
```

Related information

- [storage aggregate show](#)
- [storage disk replace](#)

Manage disks

How ONTAP hot spare disks work

A hot spare disk is a disk that is assigned to a storage system and is ready for use, but is not in use by a RAID group and does not hold any data.

If a disk failure occurs within a RAID group, the hot spare disk is automatically assigned to the RAID group to replace the failed disks. The data of the failed disk is reconstructed on the hot spare replacement disk in the background from the RAID parity disk. The reconstruction activity is logged in the `/etc/message` file and an AutoSupport message is sent.

If the available hot spare disk is not the same size as the failed disk, a disk of the next larger size is chosen and then downsized to match the size of the disk that it is replacing.

Spare requirements for multi-disk carrier disk

Maintaining the proper number of spares for disks in multi-disk carriers is critical for optimizing storage redundancy and minimizing the amount of time that ONTAP must spend copying disks to achieve an optimal disk layout.

You must maintain a minimum of two hot spares for multi-disk carrier disks at all times. To support the use of the Maintenance Center and to avoid issues caused by multiple concurrent disk failures, you should maintain at least four hot spares for steady state operation, and replace failed disks promptly.

If two disks fail at the same time with only two available hot spares, ONTAP might not be able to swap the contents of both the failed disk and its carrier mate to the spare disks. This scenario is called a stalemate. If this happens, you are notified through EMS messages and AutoSupport messages. When the replacement carriers become available, you must follow the instructions that are provided by the EMS messages. For more information, see the [NetApp Knowledge Base: RAID Layout Cannot Be Autocorrected - AutoSupport message](#)

How low spare warnings can help you manage your ONTAP spare disks

By default, warnings are issued to the console and logs if you have fewer than one hot spare drive that matches the attributes of each drive in your storage system.

You can change the threshold value for these warning messages to ensure that your system adheres to best practices.

About this task

You should set the “min_spare_count” RAID option to “2” to ensure that you always have the minimum recommended number of spare disks.

Step

1. Set the option to “2”:

```
storage raid-options modify -node nodename -name min_spare_count -value 2
```

Related information

- [storage raid-options modify](#)

Additional ONTAP root-data partitioning management options

A root-data partitioning option is available from the Boot Menu that provides additional management features for disks that are configured for root-data partitioning.

The following management features are available under the Boot Menu Option 9.

- **Unpartition all disks and remove their ownership information**

This option is useful if your system is configured for root-data partitioning and you need to reinitialize it with a different configuration.

- **Clean configuration and initialize node with partitioned disks**

This option is useful for the following:

- Your system is not configured for root-data partitioning and you would like to configure it for root-data partitioning
- Your system is incorrectly configured for root-data partitioning and you need to correct it
- You have an AFF platform or a FAS platform with only SSDs attached that is configured for the previous version of root-data partitioning and you want to upgrade it to the newer version of root-data partitioning to gain increased storage efficiency

- **Clean configuration and initialize node with whole disks**

This option is useful if you need to:

- Unpartition existing partitions
- Remove local disk ownership
- Reinitialize your system with whole disks using RAID-DP

Learn when to update the ONTAP Disk Qualification Package

The Disk Qualification Package (DQP) adds full support for newly qualified drives. Before you update drive firmware or add new drive types or sizes to a cluster, you must update the DQP. A best practice is to also update the DQP regularly; for example, every quarter or semi-annually.

You need to download and install the DQP in the following situations:

- Whenever you add a new drive type or size to the node

For example, if you already have 1-TB drives and add 2-TB drives, you need to check for the latest DQP update.

- Whenever you update the disk firmware
- Whenever newer disk firmware or DQP files are available
- Whenever you upgrade to a new version of ONTAP.

The DQP is not updated as part of an ONTAP upgrade.

Related information

[NetApp Downloads: Disk Qualification Package](#)

[NetApp Downloads: Disk Drive Firmware](#)

Disk and partition ownership

Manage the ownership of ONTAP disks and partitions

You can manage the ownership of disks and partitions.

You can perform the following tasks:

- [Display disk and partition ownership](#)

You can view disk ownership to determine which node controls the storage. You can also view the partition ownership on systems that use shared disks.

- **Change settings for automatic assignment of disk ownership**

You can select a non-default policy for automatically assigning disk ownership or disable automatic assignment of disk ownership.

- **Manually assign ownership of unpartitioned disks**

If your cluster is not configured to use automatic disk ownership assignment, you must assign ownership manually.

- **Manually assign ownership of partitioned disks**

You can set the ownership of the container disk or the partitions manually or by using auto-assignment—just as you do for unpartitioned disks.

- **Remove a failed disk**

A disk that has failed completely is no longer considered by ONTAP to be a usable disk, and you can immediately disconnect the disk from the shelf.

- **Remove ownership from a disk**

ONTAP writes disk ownership information to the disk. Before you remove a spare disk or its shelf from a node, you should remove its ownership information so that it can be properly integrated into another node.

Learn about automatic assignment of ONTAP disk ownership

The automatic assignment of unowned disks is enabled by default. Automatic disk ownership assignments occur 10 minutes after HA pair initialization and every five minutes during normal system operation.

When you add a new disk to an HA pair, for example, when replacing a failed disk, responding to a "low spares" message, or adding capacity, the default auto-assignment policy assigns ownership of the disk to a node as a spare.

The default auto-assignment policy is based on platform-specific characteristics, or the DS460C shelf if your HA pair has only these shelves, and it uses one of the following methods (policies) to assign disk ownership:

Assignment method	Effect on node assignments	Platform configurations that default to the assignment method
bay	Even-numbered bays are assigned to node A and odd-numbered bays to node B.	Entry-level systems in an HA pair configuration with a single, shared shelf.

shelf	All disks in the shelf are assigned to node A.	Entry-level systems in an HA pair configuration with one stack of two or more shelves, and MetroCluster configurations with one stack per node, two or more shelves.
split shelf This policy falls under the “default” value for the <code>-autoassign -policy</code> parameter of the <code>storage disk option</code> command for applicable platform and shelf configurations.	Disks on the left side of the shelf are assigned to node A and on the right side to Node B. Partial shelves on HA pairs are shipped from the factory with disks populated from the shelf edge toward the center.	Most AFF platforms and some MetroCluster configurations.
stack	All disks in the stack are assigned to node A.	Stand-alone entry-level systems and all other configurations.
half-drawer This policy falls under the “default” value for the <code>-autoassign -policy</code> parameter of the <code>storage disk option</code> command for applicable platform and shelf configurations.	All drives in the left half of a DS460C drawer (drive bays 0 to 5) are assigned to node A; all drives in the right half of a drawer (drive bays 6 to 11) are assigned to node B. When initializing an HA pair with only DS460C shelves, automatic assignment of disk ownership is not supported. You must manually assign ownership for drives containing root/container drives that have the root partition by conforming to the half-drawer policy.	HA pairs with only DS460C shelves, after HA pair initialization (boot up). After an HA pair boots up, automatic assignment of disk ownership is automatically enabled and uses the half-drawer policy to assign ownership to the remaining drives (other than the root drives/container drives that have the root partition) and any drives added in the future. If your HA pair has DS460C shelves in addition to other shelf models, the half-drawer policy is not used. The default policy used is dictated by platform-specific characteristics.

Auto-assignment settings and modifications:

- You can display the current auto-assignment settings (on/off) with the `storage disk option show` command.
- You can disable automatic assignment by using the `storage disk option modify` command.
- If the default auto-assignment policy is not desirable in your environment, you can specify (change) the bay, shelf, or stack assignment method using the `-autoassign-policy` parameter in the `storage disk option modify` command.

Learn how to [Change settings for automatic assignment of disk ownership](#).



The half-drawer and split-shelf default auto-assignment policies are unique because they cannot be set by users like the bay, shelf, and stack policies can.

In Advanced Drive Partitioning (ADP) systems, to make auto-assign work on half-populated shelves, drives must be installed in the correct shelf bays based on what type of shelf you have:

- If your shelf is not a DS460C shelf, install drives equally on the far left side and far right side moving toward the middle. For example, six drives in bays 0-5 and six drives in bays 18-23 of a DS224C shelf.
- If your shelf is a DS460C shelf, install drives in the front row (drive bays 0, 3, 6, and 9) of each drawer. For the remaining drives, evenly distribute them across each drawer by filling drawer rows from front to back. If you don't have enough drives to fill rows, then install them in pairs so that drives occupy the left and right side of a drawer evenly.

Installing drives in the front row of each drawer allows for proper air flow and prevents overheating.



If drives are not installed in the correct shelf bays on half-populated shelves, when a container drive fails and is replaced, ONTAP does not auto-assign ownership. In this case, assignment of the new container drive needs to be done manually. After you have assigned ownership for the container drive, ONTAP automatically handles any drive partitioning and partitioning assignments that are required.

In some situations where auto-assignment will not work, you need to manually assign disk ownership using the `storage disk assign` command:

- If you disable auto-assignment, new disks are not available as spares until they are manually assigned to a node.
- If you want disks to be auto-assigned and you have multiple stacks or shelves that must have different ownership, one disk must have been manually assigned on each stack or shelf so that automatic ownership assignment works on each stack or shelf.
- If auto-assignment is enabled and you manually assign a single drive to a node that isn't specified in the active policy, auto-assignment stops working and an EMS message is displayed.

Learn how to [Manually assign disk ownership of unpartitioned disks](#).

Learn how to [Manually assign disk ownership of partitioned disks](#).

Related information

- [storage disk assign](#)
- [storage disk option modify](#)
- [storage disk option show](#)

Display ONTAP disk and partition ownership

You can view disk ownership to determine which node controls the storage. You can also view the partition ownership on systems that use shared disks.

Steps

1. Display the ownership of physical disks:

```
storage disk show -ownership
```

```
cluster::> storage disk show -ownership
Disk      Aggregate Home      Owner    DR Home  Home ID      Owner ID    DR
Home ID   Reserver  Pool
-----
-----
1.0.0     aggr0_2  node2    node2    -        2014941509  2014941509  -
2014941509 Pool0
1.0.1     aggr0_2  node2    node2    -        2014941509  2014941509  -
2014941509 Pool0
1.0.2     aggr0_1  node1    node1    -        2014941219  2014941219  -
2014941219 Pool0
1.0.3     -         node1    node1    -        2014941219  2014941219  -
2014941219 Pool0
```

2. If you have a system that uses shared disks, you can display the partition ownership:

```
storage disk show -partition-ownership
```

```
cluster::> storage disk show -partition-ownership
Container Container
Disk      Aggregate Root Owner  Owner ID  Data Owner  Owner ID  Owner
Owner ID
-----
-----
1.0.0     -         node1    1886742616  node1    1886742616  node1
1886742616
1.0.1     -         node1    1886742616  node1    1886742616  node1
1886742616
1.0.2     -         node2    1886742657  node2    1886742657  node2
1886742657
1.0.3     -         node2    1886742657  node2    1886742657  node2
1886742657
```

Related information

- [storage disk show](#)

Change settings for automatic assignment of ONTAP disk ownership

You can use the `storage disk option modify` command to select a non-default policy for automatically assigning disk ownership or to disable automatic assignment of disk ownership.

Learn about [automatic assignment of disk ownership](#).

About this task

If you have an HA pair with only DS460C shelves, the default auto-assignment policy is half-drawer. You cannot change to a non-default policy (bay, shelf, stack).

Steps

1. Modify automatic disk assignment:

a. If you want to select a non-default policy, enter:

```
storage disk option modify -autoassign-policy autoassign_policy -node
node_name
```

- Use *stack* as the *autoassign_policy* to configure automatic ownership at the stack or loop level.
- Use *shelf* as the *autoassign_policy* to configure automatic ownership at the shelf level.
- Use *bay* as the *autoassign_policy* to configure automatic ownership at the bay level.

b. If you want to disable automatic disk ownership assignment, enter:

```
storage disk option modify -autoassign off -node node_name
```

2. Verify the automatic assignment settings for the disks:

```
storage disk option show
```

```
cluster1::> storage disk option show
```

Node	BKg. FW. Upd.	Auto Copy	Auto Assign	Auto Assign Policy
cluster1-1	on	on	on	default
cluster1-2	on	on	on	default

Related information

- [storage disk option modify](#)
- [storage disk option show](#)

Manually assign ONTAP disk ownership of unpartitioned disks

If your HA pair is not configured to use automatic disk ownership assignment, you must manually assign ownership. If you are initializing an HA pair that has only DS460C shelves, you must manually assign ownership for the root drives.

About this task

- If you are manually assigning ownership in an HA pair that is not being initialized and does not have only DS460C shelves, use option 1.

- If you are initializing an HA pair that has only DS460C shelves, use option 2 to manually assign ownership for the root drives.

Option 1: Most HA pairs

For an HA pair that is not being initialized and does not have only DS460C shelves, use this procedure to manually assigning ownership.

About this task

- The disks you are assigning ownership for must be in a shelf that is physically cabled to the node you are assigning ownership to.
- If you are using disks in a local tier (aggregate):
 - Disks must be owned by a node before they can be used in a local tier (aggregate).
 - You cannot reassign ownership of a disk that is in use in a local tier (aggregate).

Steps

1. Use the CLI to display all unowned disks:

```
storage disk show -container-type unassigned
```

2. Assign each disk:

```
storage disk assign -disk disk_name -owner owner_name
```

You can use the wildcard character to assign more than one disk at once. If you are reassigning a spare disk that is already owned by a different node, you must use the “-force” option.

Option 2: An HA pair with only DS460C shelves

For an HA pair that you are initializing and that only has DS460C shelves, use this procedure to manually assign ownership for the root drives.

About this task

- When you initialize an HA pair that has only DS460C shelves, you must manually assign the root drives to conform to the half-drawer policy.

After HA pair initialization (boot up), automatic assignment of disk ownership is automatically enabled and uses the half-drawer policy to assign ownership to the remaining drives (other than the root drives) and any drives added in the future, such as replacing failed disks, responding to a "low spares" message, or adding capacity.

[Learn about the half-drawer policy.](#)

- RAID needs a minimum of 10 drives for each HA pair (5 for each node) for any greater than 8TB NL-SAS drives in a DS460C shelf.

Steps

1. If your DS460C shelves are not fully populated, complete the following substeps; otherwise, go to the next step.
 - a. First, install drives in the front row (drive bays 0, 3, 6, and 9) of each drawer.

Installing drives in the front row of each drawer allows for proper air flow and prevents overheating.

- b. For the remaining drives, evenly distribute them across each drawer.

Fill drawer rows from front to back. If you don't have enough drives to fill rows, then install them in pairs so that drives occupy the left and right side of a drawer evenly.

The following illustration shows the drive bay numbering and locations in a DS460C drawer.



2. Log into the clustershell using the node-management LIF or cluster-management LIF.

3. Manually assign the root drives in each drawer to conform to the half-drawer policy using the following substeps:

The half-drawer policy has you assign the left half of a drawer's drives (bays 0 to 5) to node A, and the right half of a drawer's drives (bays 6 to 11) to node B.

- a. Display all unowned disks:

```
storage disk show -container-type unassigned
```

- b. Assign the root disks:

```
storage disk assign -disk disk_name -owner owner_name
```

You can use the wildcard character to assign more than one disk at a time.

Learn more about `storage disk` in the [ONTAP command reference](#).

Related information

- [storage disk assign](#)
- [storage disk show](#)

Manually assign ownership of ONTAP partitioned disks

You can manually assign the ownership of the container disk or the partitions on Advanced Drive Partitioning (ADP) systems. If you are initializing an HA pair that only has DS460C shelves, you must manually assign ownership for the container drives that will include root partitions.

About this task

- The type of storage system you have determines which method of ADP is supported, root-data (RD) or root-data-data (RD2).

FAS storage systems use RD and AFF storage systems use RD2.

- If you are manually assigning ownership in an HA pair that is not being initialized and does not have only DS460C shelves, use option 1 to manually assign disks with root-data (RD) partitioning or use option 2 to manually assign disks with root-data-data (RD2) partitioning.
- If you are initializing an HA pair that has only DS460C shelves, use option 3 to manually assign ownership for the container drives that have the root partition.

Option 1: Manually assign disks with root-data (RD) partitioning

For root-data partitioning, there are three owned entities (the container disk and the two partitions) collectively owned by the HA pair.

About this task

- The container disk and the two partitions do not all need to be owned by the same node in the HA pair as long as they are all owned by one of the nodes in the HA pair. However, when you use a partition in a local tier, it must be owned by the same node that owns the local tier.
- If a container disk fails in a half-populated shelf and is replaced, you might need to manually assign disk ownership because ONTAP does not always auto-assign ownership in this case.
- After the container disk is assigned, ONTAP's software automatically handles any partitioning and partition assignments that are required.

Steps

1. Use the CLI to display the current ownership for the partitioned disk:

```
storage disk show -disk disk_name -partition-ownership
```

2. Set the CLI privilege level to advanced:

```
set -privilege advanced
```

3. Enter the appropriate command, depending on which ownership entity you want to assign ownership for:

If any of the ownership entities are already owned, then you must include the `-force` option.

If you want to assign ownership for the...	Use this command...
Container disk	<code>storage disk assign -disk <i>disk_name</i> -owner <i>owner_name</i></code>
Data partition	<code>storage disk assign -disk <i>disk_name</i> -owner <i>owner_name</i> -data true</code>
Root partition	<code>storage disk assign -disk <i>disk_name</i> -owner <i>owner_name</i> -root true</code>

Option 2: Manually assign disks with root-data-data (RD2) partitioning

For root-data-data partitioning, there are four owned entities (the container disk and the three partitions) collectively owned by the HA pair. Root-data-data partitioning creates one small partition as the root partition and two larger, equally sized partitions for data.

About this task

- Parameters must be used with the `disk assign` command to assign the proper partition of a root-data-data partitioned disk. You cannot use these parameters with disks that are part of a storage pool. The default value is `false`.
 - The `-data1 true` parameter assigns the `data1` partition of a root-data1-data2 partitioned disk.
 - The `-data2 true` parameter assigns the `data2` partition of a root-data1-data2 partitioned disk.
- If a container disk fails in a half-populated shelf and is replaced, you might need to manually assign disk ownership because ONTAP does not always auto-assign ownership in this case.
- After the container disk is assigned, ONTAP's software automatically handles any partitioning and partition assignments that are required.

Steps

1. Use the CLI to display the current ownership for the partitioned disk:

```
storage disk show -disk disk_name -partition-ownership
```

2. Set the CLI privilege level to advanced:

```
set -privilege advanced
```

3. Enter the appropriate command, depending on which ownership entity you want to assign ownership for:

If any of the ownership entities are already owned, then you must include the `-force` option.

If you want to assign ownership for the...	Use this command...
Container disk	<code>storage disk assign -disk <i>disk_name</i> -owner <i>owner_name</i></code>
Data1 partition	<code>storage disk assign -disk <i>disk_name</i> -owner <i>owner_name</i> -data1 true</code>
Data2 partition	<code>storage disk assign -disk <i>disk_name</i> -owner <i>owner_name</i> -data2 true</code>
Root partition	<code>storage disk assign -disk <i>disk_name</i> -owner <i>owner_name</i> -root true</code>

Option 3: Manually assign DS460C container drives that have the root partition

If you are initializing an HA pair that has only DS460C shelves, you must manually assign ownership for the container drives that have the root partition by conforming to the half-drawer policy.

About this task

- When you initialize an HA pair that has only DS460C shelves, the ADP boot menu options 9a and 9b do not support automatic drive ownership assignment. You must manually assign the container drives that have the root partition by conforming to the half-drawer policy.

After HA pair initialization (boot up), automatic assignment of disk ownership is automatically enabled and uses the half-drawer policy to assign ownership to the remaining drives (other than the container drives that have the root partition) and any drives added in the future, such as replacing failed drives, responding to a "low spares" message, or adding capacity.

- [Learn about the half-drawer policy.](#)

Steps

1. If your DS460C shelves are not fully populated, complete the following substeps; otherwise, go to the next step.
 - a. First, install drives in the front row (drive bays 0, 3, 6, and 9) of each drawer.

Installing drives in the front row of each drawer allows for proper air flow and prevents overheating.

- b. For the remaining drives, evenly distribute them across each drawer.

Fill drawer rows from front to back. If you don't have enough drives to fill rows, then install them in pairs so that drives occupy the left and right side of a drawer evenly.

The following illustration shows the drive bay numbering and locations in a DS460C drawer.



2. Log into the clustershell using the node-management LIF or cluster-management LIF.
3. For each drawer, manually assign the container drives that have the root partition by conforming to the half-drawer policy using the following substeps:

The half-drawer policy has you assign the left half of a drawer's drives (bays 0 to 5) to node A, and the right half of a drawer's drives (bays 6 to 11) to node B.

a. Display all unowned disks:

```
storage disk show -container-type unassigned
```

b. Assign the container drives that have the root partition:

```
storage disk assign -disk disk_name -owner owner_name
```

You can use the wildcard character to assign more than one drive at a time.

Related information

- [storage disk assign](#)
- [storage disk show](#)

Set up an active-passive configuration on ONTAP nodes using root-data partitioning

When an HA pair is configured to use root-data partitioning by the factory, ownership of the data partitions is split between both nodes in the pair for use in an active-active configuration. If you want to use the HA pair in an active-passive configuration, you must update partition ownership before creating your data local tier.

Before you begin

- You should have decided which node will be the active node and which node will be the passive node.
- Storage failover must be configured on the HA pair.

About this task

This task is performed on two nodes: Node A and Node B.

This procedure is designed for nodes for which no data local tier has been created from the partitioned disks.

Learn about [advanced disk partitioning](#).

Steps

All commands are inputted at the cluster shell.

1. View the current ownership of the data partitions:

```
storage aggregate show-spare-disks
```

The output shows that half of the data partitions are owned by one node and half are owned by the other node. All of the data partitions should be spare.

```
cluster1::> storage aggregate show-spare-disks
```

```
Original Owner: cluster1-01
```

```
Pool0
```

```
Partitioned Spares
```

```
Local
```

```

Local
Data
Root Physical
Disk          Type      RPM Checksum  Usable
Usable      Size
-----
1.0.0        BSAS    7200 block    753.8GB
0B 828.0GB
1.0.1        BSAS    7200 block    753.8GB
73.89GB 828.0GB
1.0.5        BSAS    7200 block    753.8GB
0B 828.0GB
1.0.6        BSAS    7200 block    753.8GB
0B 828.0GB
1.0.10       BSAS    7200 block    753.8GB
0B 828.0GB
1.0.11       BSAS    7200 block    753.8GB
0B 828.0GB

```

```

Original Owner: cluster1-02
Pool0
Partitioned Spares

```

```

Local
Data
Root Physical
Disk          Type      RPM Checksum  Usable
Usable      Size
-----
1.0.2        BSAS    7200 block    753.8GB
0B 828.0GB
1.0.3        BSAS    7200 block    753.8GB
0B 828.0GB
1.0.4        BSAS    7200 block    753.8GB
0B 828.0GB
1.0.7        BSAS    7200 block    753.8GB
0B 828.0GB
1.0.8        BSAS    7200 block    753.8GB
73.89GB 828.0GB
1.0.9        BSAS    7200 block    753.8GB
0B 828.0GB
12 entries were displayed.

```

2. Enter the advanced privilege level:


```

0B 828.0GB
 1.0.11          BSAS    7200 block          753.8GB
0B 828.0GB

Original Owner: cluster1-02
  Pool0
  Partitioned Spares

Local
Local
Root Physical
Disk
Usable      Size
-----
-----
 1.0.8          BSAS    7200 block          0B
73.89GB 828.0GB
13 entries were displayed.

```

Note that cluster1-02 still owns a spare root partition.

5. Return to administrative privilege:

```
set admin
```

6. Create your data local tier, leaving at least one data partition as spare:

```
storage aggregate create new_aggr_name -diskcount number_of_partitions -node
active_node_name
```

The data local tier is created and is owned by the active node.

Related information

- [storage aggregate create](#)
- [storage aggregate show](#)
- [storage disk assign](#)

Set up an active-passive configuration on ONTAP nodes using root-data-data partitioning

When an HA pair is configured to use root-data-data partitioning by the factory, ownership of the data partitions is split between both nodes in the pair for use in an active-active configuration. If you want to use the HA pair in an active-passive configuration, you must update partition ownership before creating your data local tier.

Before you begin

- You should have decided which node will be the active node and which node will be the passive node.
- Storage failover must be configured on the HA pair.


```
storage aggregate create new_aggr_name -diskcount number_of_partitions -node
active_node_name
```

The data aggregate is created and is owned by the active node.

8. Alternatively, you can use ONTAP's recommended local tier layout which includes best practices for RAID group layout and spare counts:

```
storage aggregate auto-provision
```

Related information

- [storage aggregate auto-provision](#)
- [storage aggregate create](#)
- [storage aggregate show](#)
- [storage disk assign](#)

Remove ONTAP ownership from a disk

ONTAP writes disk ownership information to the disk. Before you remove a spare disk or its shelf from a node, you should remove its ownership information so that it can be properly integrated into another node.



If the disk is partitioned for root-data partitioning and you are running ONTAP 9.10.1 or later, contact NetApp Technical Support for assistance in removing ownership. For more information see the [Knowledge Base article: Failed to remove the owner of disk](#).

Before you begin

The disk you want to remove ownership from must meet the following requirements:

- It must be a spare disk.

You cannot remove ownership from a disk that is being used in an local tier.

- It cannot be in the maintenance center.
- It cannot be undergoing sanitization.
- It cannot have failed.

It is not necessary to remove ownership from a failed disk.

About this task

If you have automatic disk assignment enabled, ONTAP could automatically reassign ownership before you remove the disk from the node. For this reason, you disable the automatic ownership assignment until the disk is removed, and then you re-enable it.

Steps

1. If disk ownership automatic assignment is on, use the CLI to turn it off:

```
storage disk option modify -node node_name -autoassign off
```

2. If needed, repeat the previous step for the node's HA partner.
3. Remove the software ownership information from the disk:

```
storage disk removeowner disk_name
```

To remove ownership information from multiple disks, use a comma-separated list.

Example:

```
storage disk removeowner sys1:0a.23,sys1:0a.24,sys1:0a.25
```

4. If the disk is partitioned for root-data partitioning and you are running ONTAP 9.9.1 or earlier, remove ownership from the partitions:

```
storage disk removeowner -disk disk_name -root true
```

```
storage disk removeowner -disk disk_name -data true
```

Both partitions are no longer owned by any node.

5. If you previously turned off automatic assignment of disk ownership, turn it on after the disk has been removed or reassigned:

```
storage disk option modify -node node_name -autoassign on
```

6. If needed, repeat the previous step for the node's HA partner.

Related information

- [storage disk option modify](#)
- [storage disk removeowner](#)

Remove a failed ONTAP disk

A disk that has completely failed is no longer counted by ONTAP as a usable disk, and you can immediately disconnect the disk from the disk shelf. However, you should leave a partially failed disk connected long enough for the Rapid RAID Recovery process to complete.

About this task

If you are removing a disk because it has failed or because it is producing excessive error messages, you should not use the disk again in this or any other storage system.

Steps

1. Use the CLI to find the disk ID of the failed disk:

```
storage disk show -broken
```

If the disk does not appear in the list of failed disks, it might have partially failed, with a Rapid RAID Recovery in process. In this case, you should wait until the disk is present in the list of failed disks (which means that the Rapid RAID Recovery process is complete) before removing the disk.

2. Determine the physical location of the disk you want to remove:

```
storage disk set-led -action on -disk disk_name 2
```

The fault LED on the face of the disk is lit.

3. Remove the disk from the disk shelf, following the instructions in the hardware guide for your disk shelf model.

Related information

- [storage disk set-led](#)
- [storage disk show](#)

Disk sanitization

Learn about ONTAP disk sanitization

Disk sanitization is the process of physically obliterating data by overwriting disks or SSDs with specified byte patterns or random data so that recovery of the original data becomes impossible. Using the sanitization process ensures that no one can recover the data on the disks.

This functionality is available through the nodeshell in all ONTAP 9 releases, and starting with ONTAP 9.6 in maintenance mode.

The disk sanitization process uses three successive default or user-specified byte overwrite patterns for up to seven cycles per operation. The random overwrite pattern is repeated for each cycle.

Depending on the disk capacity, the patterns, and the number of cycles, the process can take several hours. Sanitization runs in the background. You can start, stop, and display the status of the sanitization process. The sanitization process contains two phases: the "Formatting phase" and the "Pattern overwrite phase".

Formatting phase

The operation performed for the formatting phase depends on the class of disk being sanitized, as shown in the following table:

Disk class	Formatting phase operation
Capacity HDDs	Skipped
Performance HDDs	SCSI format operation
SSDs	SCSI sanitize operation

Pattern overwrite phase

The specified overwrite patterns are repeated for the specified number of cycles.

When the sanitization process is complete, the specified disks are in a sanitized state. They are not returned to spare status automatically. You must return the sanitized disks to the spare pool before the newly sanitized disks are available to be added to another local tier.

Learn about when ONTAP disk sanitization cannot be performed

Disk sanitization cannot be performed under these circumstances.

- It is not supported in takeover mode for systems in an HA pair.
- It cannot be performed on disks that were failed due to readability or writability problems.
- If you are using the random pattern, it cannot be performed on more than 100 disks at one time.
- It is not supported on array LUNs.

What happens if ONTAP disk sanitization is interrupted

If disk sanitization is interrupted by user intervention or an unexpected event such as a power outage, ONTAP takes action to return the disks that were being sanitized to a known state, but you must also take action before the sanitization process can finish.

Disk sanitization is a long-running operation. If the sanitization process is interrupted by power failure, system panic, or manual intervention, the sanitization process must be repeated from the beginning. The disk is not designated as sanitized.

If the formatting phase of disk sanitization is interrupted, ONTAP must recover any disks that were corrupted by the interruption. After a system reboot and once every hour, ONTAP checks for any sanitization target disk that did not complete the formatting phase of its sanitization. If any such disks are found, ONTAP recovers them. The recovery method depends on the type of the disk. After a disk is recovered, you can rerun the sanitization process on that disk; for HDDs, you can use the `-s` option to specify that the formatting phase is not repeated again.

Tips for creating and backing up ONTAP local tiers containing data to be sanitized

If you are creating or backing up local tiers to contain data that might need to be sanitized, following some simple guidelines will reduce the time it takes to sanitize your data.

- Make sure your local tiers containing sensitive data are not larger than they need to be.
If they are larger than needed, sanitization requires more time, disk space, and bandwidth.
- When you back up local tiers containing sensitive data, avoid backing them up to local tier that also contain large amounts of nonsensitive data.

This reduces the resources required to move nonsensitive data before sanitizing sensitive data.

Sanitize an ONTAP disk

Sanitizing a disk allows you to remove data from a disk or a set of disks on decommissioned or inoperable systems so that the data can never be recovered.

Two methods are available to sanitize disks using the CLI:

Sanitize a disk with “maintenance mode” commands

Beginning with ONTAP 9.6, you can perform disk sanitization in maintenance mode.

Before you begin

- The disks cannot be self-encrypting disks (SED).

You must use the `storage encryption disk sanitize` command to sanitize an SED.

[Encryption of data at rest](#)

Learn more about `storage encryption disk sanitize` in the [ONTAP command reference](#).

Steps

1. Boot into maintenance mode.

- a. Exit the current shell by entering `halt`.

The `LOADER` prompt is displayed.

- b. Enter maintenance mode by entering `boot_ontap maint`.

After some information is displayed, the maintenance mode prompt is displayed.

2. If the disks you want to sanitize are partitioned, unpartition each disk:



The command to unpartition a disk is only available at the `diag` level and should be performed only under NetApp Support supervision. It is highly recommended that you contact NetApp Support before you proceed. You can also refer to the [NetApp Knowledge Base: How to unpartition a spare drive in ONTAP](#)

```
disk unpartition <disk_name>
```

3. Sanitize the specified disks:

```
disk sanitize start [-p <pattern1>|-r [-p <pattern2>|-r [-p <pattern3>|-r]]] [-c <cycle_count>] <disk_list>
```



Do not turn off power to the node, disrupt the storage connectivity, or remove target disks while sanitizing. If sanitizing is interrupted during the formatting phase, the formatting phase must be restarted and allowed to finish before the disks are sanitized and ready to be returned to the spare pool. If you need to abort the sanitization process, you can do so by using the `disk sanitize abort` command. If the specified disks are undergoing the formatting phase of sanitization, the abort does not occur until the phase is complete.

`-p <pattern1> -p <pattern2> -p <pattern3>` specifies a cycle of one to three user-defined hex byte overwrite patterns that can be applied in succession to the disks being sanitized. The default pattern is three passes, using `0x55` for the first pass, `0xaa` for the second pass, and `0x3c` for the third pass.

-r replaces a patterned overwrite with a random overwrite for any or all of the passes.

-c <cycle_count> specifies the number of times that the specified overwrite patterns are applied. The default value is one cycle. The maximum value is seven cycles.

<disk_list> specifies a space-separated list of the IDs of the spare disks to be sanitized.

4. If desired, check the status of the disk sanitization process:

```
disk sanitize status [<disk_list>]
```

5. After the sanitization process is complete, return the disks to spare status for each disk:

```
disk sanitize release <disk_name>
```

6. Exit maintenance mode.

Sanitize a disk with “nodeshell” commands (all ONTAP 9 releases)

After the disk sanitization feature is enabled using nodeshell commands on a node, it cannot be disabled.

Before you begin

- The disks must be spare disks; they must be owned by a node, but not used in a local tier.

If the disks are partitioned, neither partition can be in use in a local tier.

- The disks cannot be self-encrypting disks (SED).

You must use the `storage encryption disk sanitize` command to sanitize an SED.

Encryption of data at rest

- The disks cannot be part of a storage pool.

Steps

1. If the disks you want to sanitize are partitioned, unpartition each disk:



The command to unpartition a disk is only available at the diag level and should be performed only under NetApp Support supervision. **It is highly recommended that you contact NetApp Support before you proceed.** You can also refer to the [NetApp Knowledge Base: How to unpartition a spare drive in ONTAP](#).

```
disk unpartition <disk_name>
```

2. Enter the nodeshell for the node that owns the disks you want to sanitize:

```
system node run -node <node_name>
```

3. Enable disk sanitization:

```
options licensed_feature.disk_sanitization.enable on
```

You are asked to confirm the command because it is irreversible.

4. Switch to the nodeshell advanced privilege level:

```
priv set advanced
```

5. Sanitize the specified disks:

```
disk sanitize start [-p <pattern1>|-r [-p <pattern2>|-r [-p <pattern3>|-r]]] [-c <cycle_count>] <disk_list>
```



Do not turn off power to the node, disrupt the storage connectivity, or remove target disks while sanitizing. If sanitizing is interrupted during the formatting phase, the formatting phase must be restarted and allowed to finish before the disks are sanitized and ready to be returned to the spare pool. If you need to abort the sanitization process, you can do so by using the `disk sanitize abort` command. If the specified disks are undergoing the formatting phase of sanitization, the abort does not occur until the phase is complete.

`-p <pattern1> -p <pattern2> -p <pattern3>` specifies a cycle of one to three user-defined hex byte overwrite patterns that can be applied in succession to the disks being sanitized. The default pattern is three passes, using 0x55 for the first pass, 0xaa for the second pass, and 0x3c for the third pass.

`-r` replaces a patterned overwrite with a random overwrite for any or all of the passes.

`-c <cycle_count>` specifies the number of times that the specified overwrite patterns are applied.

The default value is one cycle. The maximum value is seven cycles.

`<disk_list>` specifies a space-separated list of the IDs of the spare disks to be sanitized.

6. If you want to check the status of the disk sanitization process:

```
disk sanitize status [<disk_list>]
```

7. After the sanitization process is complete, return the disks to spare status:

```
disk sanitize release <disk_name>
```

8. Return to the nodeshell admin privilege level:

```
priv set admin
```

9. Return to the ONTAP CLI:

```
exit
```

10. Determine whether all of the disks were returned to spare status:

```
storage aggregate show-spare-disks
```

If...	Then...
All of the sanitized disks are listed as spares	You are done. The disks are sanitized and in spare status.

Some of the sanitized disks are not listed as spares

Complete the following steps:

a. Enter advanced privilege mode:

```
set -privilege advanced
```

b. Assign the unassigned sanitized disks to the appropriate node for each disk:

```
storage disk assign -disk <disk_name> -owner <node_name>
```

c. Return the disks to spare status for each disk:

```
storage disk unfailed -disk <disk_name> -s -q
```

d. Return to administrative mode:

```
set -privilege admin
```

Learn more about `storage aggregate show-spare-disks` in the [ONTAP command reference](#).

Result

The specified disks are sanitized and designated as hot spares. The serial numbers of the sanitized disks are written to `/etc/log/sanitized_disks`.

The specified disks' sanitization logs, which show what was completed on each disk, are written to `/mroot/etc/log/sanitization.log`.

Related information

- [storage aggregate show](#)
- [storage disk assign](#)
- [storage disk unfailed](#)
- [storage encryption disk sanitize](#)

ONTAP commands for managing disks

You can use the `storage disk` and `storage aggregate` commands to manage your disks.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

If you want to...

Use this command...

Display a list of spare disks, including partitioned disks, by owner	<code>storage aggregate show-spare-disks</code>
Display the disk RAID type, current usage, and RAID group by local tier	<code>storage aggregate show-status</code>
Display the RAID type, current usage, local tier, and RAID group, including spares, for physical disks	<code>storage disk show -raid</code>
Display a list of failed disks	<code>storage disk show -broken</code>
Display the pre-cluster (nodescope) drive name for a disk	<code>storage disk show -primary-paths (advanced)</code>
Illuminate the LED for a particular disk or shelf	<code>storage disk set-led</code>
Display the checksum type for a specific disk	<code>storage disk show -fields checksum-compatibility</code>
Display the checksum type for all spare disks	<code>storage disk show -fields checksum-compatibility -container-type spare</code>
Display disk connectivity and placement information	<code>storage disk show -fields disk,primary-port,secondary-name,secondary-port,shelf,bay</code>
Display the pre-cluster disk names for specific disks	<code>storage disk show -disk diskname -fields diskpathnames</code>
Display the list of disks in the maintenance center	<code>storage disk show -maintenance</code>
Display SSD wear life	<code>storage disk show -ssd-wear</code>
Unpartition a shared disk	<code>storage disk unpartition (available at diagnostic level)</code>
Zero all non-zeroed disks	<code>storage disk zerospares</code>
Stop an ongoing sanitization process on one or more specified disks	<code>system node run -node nodename -command disk sanitize</code>
Display storage encryption disk information	<code>storage encryption disk show</code>

Retrieve authentication keys from all linked key management servers	<code>security key-manager restore</code>
---	---

Related information

- [storage aggregate show](#)
- [storage disk set-led](#)
- [storage disk show](#)
- [storage disk zerospares](#)
- [storage encryption disk show](#)

ONTAP commands for displaying space usage information

You use the `storage aggregate` and `volume` commands to see how space is being used in your local tiers and volumes and their snapshots.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

To display information about...	Use this command...
Local tier, including details about used and available space percentages, snapshot reserve size, and other space usage information	<code>storage aggregate show</code> <code>storage aggregate show-space -fields snap-size-total,used-including-snapshot-reserve</code>
How disks and RAID groups are used in an local tier, and RAID status	<code>storage aggregate show-status</code>
The amount of disk space that would be reclaimed if you deleted a specific snapshot	<code>volume snapshot compute-reclaimable</code>
The amount of space used by a volume	<code>volume show -fields size,used,available,percent-used</code> <code>volume show-space</code>
The amount of space used by a volume in the containing local tier	<code>volume show-footprint</code>

Related information

- [storage aggregate show](#)
- [storage aggregate show-space](#)
- [storage aggregate show-status](#)

ONTAP commands for displaying information about storage shelves

You use the `storage shelf show` command to display configuration and error information for your disk shelves.

If you want to display...	Use this command...
General information about shelf configuration and hardware status	<code>storage shelf show</code>
Detailed information for a specific shelf, including stack ID	<code>storage shelf show -shelf</code>
Unresolved, customer actionable, errors by shelf	<code>storage shelf show -errors</code>
Bay information	<code>storage shelf show -bay</code>
Connectivity information	<code>storage shelf show -connectivity</code>
Cooling information, including temperature sensors and cooling fans	<code>storage shelf show -cooling</code>
Information about I/O modules	<code>storage shelf show -module</code>
Port information	<code>storage shelf show -port</code>
Power information, including PSUs (power supply units), current sensors, and voltage sensors	<code>storage shelf show -power</code>

Related information

- [storage shelf show](#)

Manage RAID configurations

Default RAID policies for ONTAP local tiers

Either RAID-DP or RAID-TEC is the default RAID policy for all new local tiers. The RAID policy determines the parity protection you have in the event of a disk failure.

RAID-DP provides double-parity protection in the event of a single or double disk failure. RAID-DP is the default RAID policy for the following local tier types:

- All Flash local tiers
- Flash Pool local tiers
- Performance hard disk drive (HDD) local tiers

RAID-TEC is supported on all disk types and all platforms, including AFF. Local tiers that contain larger disks have a higher possibility of concurrent disk failures. RAID-TEC helps to mitigate this risk by providing triple-

parity protection so that your data can survive up to three simultaneous disk failures. RAID-TEC is the default RAID policy for capacity HDD local tiers with disks that are 6 TB or larger.

Each RAID policy type requires a minimum number of disks:

- RAID-DP: minimum of 5 disks
- RAID-TEC: minimum of 7 disks

ONTAP RAID protection levels for disks

ONTAP supports three levels of RAID protection for local tiers. The level of RAID protection determines the number of parity disks available for data recovery in the event of disk failures.

With RAID protection, if there is a data disk failure in a RAID group, ONTAP can replace the failed disk with a spare disk and use parity data to reconstruct the data of the failed disk.

- **RAID4**

With RAID4 protection, ONTAP can use one spare disk to replace and reconstruct the data from one failed disk within the RAID group.

- **RAID-DP**

With RAID-DP protection, ONTAP can use up to two spare disks to replace and reconstruct the data from up to two simultaneously failed disks within the RAID group.

- **RAID-TEC**

With RAID-TEC protection, ONTAP can use up to three spare disks to replace and reconstruct the data from up to three simultaneously failed disks within the RAID group.

Drive and RAID group information for an ONTAP local tier

Some local tier administration tasks require that you know what types of drives compose the local tier, their size, checksum, and status, whether they are shared with other local tiers, and the size and composition of the RAID groups.

Step

1. Show the drives for the local tier, by RAID group:

```
storage aggregate show-status aggr_name
```

The drives are displayed for each RAID group in the local tier.

You can see the RAID type of the drive (data, parity, dparity) in the `Position` column. If the `Position` column displays `shared`, then the drive is shared: if it is an HDD, it is a partitioned disk; if it is an SSD, it is part of a storage pool.

Example: A Flash Pool local tier using an SSD storage pool and data partitions

```
cluster1::> storage aggregate show-status nodeA_fp_1

Owner Node: cluster1-a
Aggregate: nodeA_fp_1 (online, mixed_raid_type, hybrid) (block checksums)
Plex: /nodeA_fp_1/plex0 (online, normal, active, pool0)
RAID Group /nodeA_fp_1/plex0/rg0 (normal, block checksums, raid_dp)

      Position Disk      Pool Type      RPM      Usable Physical
      -----  -
      shared  2.0.1      0  SAS  10000  472.9GB  547.1GB (normal)
      shared  2.0.3      0  SAS  10000  472.9GB  547.1GB (normal)
      shared  2.0.5      0  SAS  10000  472.9GB  547.1GB (normal)
      shared  2.0.7      0  SAS  10000  472.9GB  547.1GB (normal)
      shared  2.0.9      0  SAS  10000  472.9GB  547.1GB (normal)
      shared  2.0.11     0  SAS  10000  472.9GB  547.1GB (normal)

RAID Group /nodeA_flashpool_1/plex0/rg1
(normal, block checksums, raid4) (Storage Pool: SmallSP)

      Position Disk      Pool Type      RPM      Usable Physical
      -----  -
      shared  2.0.13     0  SSD    -  186.2GB  745.2GB (normal)
      shared  2.0.12     0  SSD    -  186.2GB  745.2GB (normal)

8 entries were displayed.
```

Related information

- [storage aggregate show-status](#)

Convert from ONTAP RAID-DP to RAID-TEC

If you want the added protection of triple-parity, you can convert from RAID-DP to RAID-TEC. RAID-TEC is recommended if the size of the disks used in your local tier is greater than 4 TiB.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Before you begin

The local tier that is to be converted must have a minimum of seven disks.

About this task

- Hard disk drive (HDD) local tiers can be converted from RAID-DP to RAID-TEC. This includes HDD tiers in Flash Pool local tiers.

Process for flashpools/hybrid aggregates where `-disktype` needs to be used to change each disk type

`[-T, -disktype {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}] - Disk Type`

This parameter specifies the disk type of the RAID groups to be modified. In case of Flash Pool, it specifies either the HDD tier or the SSD tier. If the HDD tier is composed of more than one type of disk, specifying any of the disk types in use causes that tier to be modified. If the current aggregate RAID type is `mixed_raid_type`, this parameter is mandatory.

Steps

1. Verify that the local tier is online and has a minimum of six disks:

```
storage aggregate show-status -aggregate aggregate_name
```

2. Convert the local tier from RAID-DP to RAID-TEC:

```
storage aggregate modify -aggregate aggregate_name -raidtype raid_tec
```

3. Verify that the local tier RAID policy is RAID-TEC:

```
storage aggregate show aggregate_name
```

Related information

- [storage aggregate modify](#)
- [storage aggregate show-status](#)

Convert from ONTAP RAID-TEC to RAID-DP

If you reduce the size of your local tier and no longer need triple parity, you can convert your RAID policy from RAID-TEC to RAID-DP and reduce the number of disks you need for RAID parity.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Before you begin

The maximum RAID group size for RAID-TEC is larger than the maximum RAID group size for RAID-DP. If the largest RAID-TEC group size is not within the RAID-DP limits, you cannot convert to RAID-DP.

About this task

To understand the implications of converting between RAID types, refer to the [parameters](#) for the `storage aggregate modify` command.

Steps

1. Verify that the local tier is online and has a minimum of six disks:

```
storage aggregate show-status -aggregate aggregate_name
```

2. Convert the local tier from RAID-TEC to RAID-DP:

```
storage aggregate modify -aggregate aggregate_name -raidtype raid_dp
```

3. Verify that the local tier RAID policy is RAID-DP:

```
storage aggregate show aggregate_name
```

Related information

- [storage aggregate modify](#)
- [storage aggregate show-status](#)

Considerations for sizing ONTAP RAID groups

Configuring an optimum RAID group size requires a trade-off of factors. You must decide which factors—speed of RAID rebuild, assurance against risk of data loss due to drive failure, optimizing I/O performance, and maximizing data storage space—are most important for the (local tier) aggregate that you are configuring.

When you create larger RAID groups, you maximize the space available for data storage for the same amount of storage used for parity (also known as the “parity tax”). On the other hand, when a disk fails in a larger RAID group, reconstruction time is increased, impacting performance for a longer period of time. In addition, having more disks in a RAID group increases the probability of a multiple disk failure within the same RAID group.

HDD or array LUN RAID groups

You should follow these guidelines when sizing your RAID groups composed of HDDs or array LUNs:

- All RAID groups in an local tier (aggregate) should have the same number of disks.

While you can have up to 50% less or more than the number of disks in different raid groups on one local tier, this might lead to performance bottlenecks in some cases, so it is best avoided.

- The recommended range of RAID group disk numbers is between 12 and 20.

The reliability of performance disks can support a RAID group size of up to 28, if needed.

- If you can satisfy the first two guidelines with multiple RAID group disk numbers, you should choose the larger number of disks.

SSD RAID groups in Flash Pool local tiers (aggregates)

The SSD RAID group size can be different from the RAID group size for the HDD RAID groups in a Flash Pool local tier (aggregate). Usually, you should ensure that you have only one SSD RAID group for a Flash Pool local tier, to minimize the number of SSDs required for parity.

SSD RAID groups in SSD local tiers (aggregates)

You should follow these guidelines when sizing your RAID groups composed of SSDs:

- All RAID groups in a local tier (aggregate) should have a similar number of drives.

The RAID groups do not have to be exactly the same size, but you should avoid having any RAID group

that is less than one half the size of other RAID groups in the same local tier when possible.

- For RAID-DP, the recommended range of RAID group size is between 20 and 28.

Customize the size of your ONTAP RAID groups

You can customize the size of your RAID groups to ensure that your RAID group sizes are appropriate for the amount of storage you plan to include for a local tier.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

About this task

For standard local tiers, you change the size of RAID groups for each local tier separately. For Flash Pool local tiers, you can change the RAID group size for the SSD RAID groups and the HDD RAID groups independently.

The following list outlines some facts about changing the RAID group size:

- By default, if the number of disks or array LUNs in the most recently created RAID group is less than the new RAID group size, disks or array LUNs will be added to the most recently created RAID group until it reaches the new size.
- All other existing RAID groups in that local tier remain the same size, unless you explicitly add disks to them.
- You can never cause a RAID group to become larger than the current maximum RAID group size for the local tier.
- You cannot decrease the size of already created RAID groups.
- The new size applies to all RAID groups in that local tier (or, in the case of a Flash Pool local tier, all RAID groups for the affected RAID group type—SSD or HDD).

Steps

1. Use the applicable command:

If you want to...	Enter the following command...
Change the maximum RAID group size for the SSD RAID groups of a Flash Pool local tier	<code>storage aggregate modify -aggregate aggr_name -cache-raid-group-size size</code>
Change the maximum size of any other RAID groups	<code>storage aggregate modify -aggregate aggr_name -maxraidsize size</code>

Examples

The following command changes the maximum RAID group size of the local tier n1_a4 to 20 disks or array LUNs:

```
storage aggregate modify -aggregate n1_a4 -maxraidsize 20
```

The following command changes the maximum RAID group size of the SSD cache RAID groups of the Flash Pool local tier n1_cache_a2 to 24:

```
storage aggregate modify -aggregate n1_cache_a2 -cache-raid-group-size 24
```

Related information

- [storage aggregate modify](#)

Manage Flash Pool local tiers

Flash Pool ONTAP local tier caching policies

Caching policies for the volumes in a Flash Pool local tier let you deploy Flash as a high performance cache for your working data set while using lower-cost HDDs for less frequently accessed data. If you are providing cache to two or more Flash Pool local tiers, you should use Flash Pool SSD partitioning to share SSDs across the local tiers in the Flash Pool.

Caching policies are applied to volumes that reside in Flash Pool local tiers. You should understand how caching policies work before changing them.

In most cases, the default caching policy of `auto` is the best caching policy to use. The caching policy should be changed only if a different policy provides better performance for your workload. Configuring the wrong caching policy can severely degrade volume performance; the performance degradation could increase gradually over time.

Caching policies combine a read caching policy and a write caching policy. The policy name concatenates the names of the read caching policy and the write caching policy, separated by a hyphen. If there is no hyphen in the policy name, the write caching policy is `none`, except for the `auto` policy.

Read caching policies optimize for future read performance by placing a copy of the data in the cache in addition to the stored data on HDDs. For read caching policies that insert data into the cache for write operations, the cache operates as a *write-through* cache.

Data inserted into the cache by using the write caching policy exists only in cache; there is no copy in HDDs. Flash Pool cache is RAID protected. Enabling write caching makes data from write operations available for reads from cache immediately, while deferring writing the data to HDDs until it ages out of the cache.

If you move a volume from a Flash Pool local tier to a single-tier local tier, it loses its caching policy; if you later move it back to a Flash Pool local tier, it is assigned the default caching policy of `auto`. If you move a volume between two Flash Pool local tier, the caching policy is preserved.

Change a caching policy

You can use the CLI to change the caching policy for a volume that resides on a Flash Pool local tier by using the `-caching-policy` parameter with the `volume create` command.

When you create a volume on a Flash Pool local tier, by default, the `auto` caching policy is assigned to the volume.

Manage Flash Pool caching policies

Determine whether to modify the ONTAP caching policy of Flash Pool local tiers

You can assign cache-retention policies to volumes in Flash Pool local tiers to determine

how long the volume data remains in the Flash Pool cache. However, in some cases changing the cache-retention policy might not impact the amount of time the volume's data remains in the cache.

About this task

If your data meets any of the following conditions, changing your cache-retention policy might not have an impact:

- Your workload is sequential.
- Your workload does not reread the random blocks cached in the solid state drives (SSDs).
- The cache size of the volume is too small.

Steps

The following steps check for the conditions that must be met by the data. The task must be done using the CLI in advanced privilege mode.

1. Use the CLI to view the workload volume:

```
statistics start -object workload_volume
```

2. Determine the workload pattern of the volume:

```
statistics show -object workload_volume -instance volume-workload -counter sequential_reads
```

3. Determine the hit rate of the volume:

```
statistics show -object waf1_hya_vvol -instance volume -counter read_ops_replaced_percent|wc_write_blks_overwritten_percent
```

4. Determine the Cacheable Read and Project Cache Alloc of the volume:

```
system node run -node node_name waf1 awa start aggr_name
```

5. Display the AWA summary:

```
system node run -node node_name waf1 awa print aggr_name
```

6. Compare the volume's hit rate to the Cacheable Read.

If the hit rate of the volume is greater than the Cacheable Read, then your workload does not reread random blocks cached in the SSDs.

7. Compare the volume's current cache size to the Project Cache Alloc.

If the current cache size of the volume is greater than the Project Cache Alloc, then the size of your volume cache is too small.

Related information

- [statistics show](#)
- [statistics start](#)

Modify caching policies of ONTAP Flash Pool local tiers

You should modify the caching policy of a volume only if a different caching policy is expected to provide better performance. You can modify the caching policy of a volume on a Flash Pool local tier.

Before you begin

You must determine whether you want to modify your caching policy.

About this task

In most cases, the default caching policy of `auto` is the best caching policy that you can use. The caching policy should be changed only if a different policy provides better performance for your workload. Configuring the wrong caching policy can severely degrade volume performance; the performance degradation could increase gradually over time. You should use caution when modifying caching policies. If you experience performance issues with a volume for which the caching policy has been changed, you should return the caching policy to `auto`.

Step

1. Use the CLI to modify the volume's caching policy:

```
volume modify -volume volume_name -caching-policy policy_name
```

Example

The following example modifies the caching policy of a volume named `vol2` to the policy `none`:

```
volume modify -volume vol2 -caching-policy none
```

Set the cache-retention policy for ONTAP Flash Pool local tiers

You can assign cache-retention policies to volumes in Flash Pool local tiers. Data in volumes with a high cache-retention policy remains in cache longer and data in volumes with a low cache-retention policy is removed sooner. This increases performance of your critical workloads by making high priority information accessible at a faster rate for a longer period of time.

Before you begin

You should know whether your system has any conditions that might prevent the cache-retention policy from having an impact on how long your data remains in cache.

Steps

Use the CLI in advanced privilege mode to perform the following steps:

1. Change the privilege setting to advanced:

```
set -privilege advanced
```

2. Verify the volume's cache-retention policy:

By default the cache retention policy is "normal".

3. Set the cache-retention policy:

```
volume modify -volume volume_name -vserver vserver_name -caching-policy
policy_name
```

4. Verify that the volume's cache-retention policy is changed to the option you selected.
5. Return the privilege setting to admin:

```
set -privilege admin
```

Flash Pool SSD partitioning for ONTAP Flash Pool local tiers using storage pools


If you are providing cache to two or more Flash Pool local tiers, you should use Flash Pool Solid-State Drive (SSD) partitioning. Flash Pool SSD partitioning allows SSDs to be shared by all the local tiers that use the Flash Pool. This spreads the cost of parity over multiple local tiers, increases SSD cache allocation flexibility, and maximizes SSD performance.

For an SSD to be used in a Flash Pool local tier, the SSD must be placed in a storage pool. You cannot use SSDs that have been partitioned for root-data partitioning in a storage pool. After the SSD is placed in the storage pool, the SSD can no longer be managed as a stand-alone disk and cannot be removed from the storage pool unless you destroy the local tiers associated with the Flash Pool and you destroy the storage pool.

SSD storage pools are divided into four equal allocation units. SSDs added to the storage pool are divided into four partitions and one partition is assigned to each of the four allocation units. The SSDs in the storage pool must be owned by the same HA pair. By default, two allocation units are assigned to each node in the HA pair. Allocation units must be owned by the node that owns the local tier it is serving. If more Flash cache is required for local tiers on one of the nodes, the default number of allocation units can be shifted to decrease the number on one node and increase the number on the partner node.

You use spare SSDs to add to an SSD storage pool. If the storage pool provides allocation units to Flash Pool local tiers owned by both nodes in the HA pair, then the spare SSDs can be owned by either node. However, if the storage pool provides allocation units only to Flash Pool local tiers owned by one of the nodes in the HA pair, then the SSD spares must be owned by that same node.

The following illustration is an example of Flash Pool SSD partitioning. The SSD storage pool provides cache to two Flash Pool local tiers:



Storage pool SP1 is composed of five SSDs and a hot spare SSD. Two of the storage pool's allocation units are allocated to Flash Pool FP1, and two are allocated to Flash Pool FP2. FP1 has a cache RAID type of RAID4. Therefore, the allocation units provided to FP1 contain only one partition designated for parity. FP2 has a cache RAID type of RAID-DP. Therefore, the allocation units provided to FP2 include a parity partition and a double-parity partition.

In this example, two allocation units are allocated to each Flash Pool local tier. However, if one Flash Pool local tier required a larger cache, you could allocate three of the allocation units to that Flash Pool local tier, and only one to the other.

Determine ONTAP Flash Pool candidacy and optimal cache size

Before converting an existing local tier to a Flash Pool local tier, you can determine whether the local tier is I/O bound and the best Flash Pool cache size for your workload and budget. You can also check whether the cache of an existing Flash Pool local tier is sized correctly.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Before you begin

You should know approximately when the local tier you are analyzing experiences its peak load.

Steps

1. Enter advanced mode:

```
set advanced
```

2. If you need to determine whether an existing local tier would be a good candidate for conversion to a Flash Pool local tier, determine how busy the disks in the local tier are during a period of peak load, and how that is affecting latency:

```
statistics show-periodic -object disk:raid_group -instance raid_group_name
-counter disk_busy|user_read_latency -interval 1 -iterations 60
```

You can decide whether reducing latency by adding Flash Pool cache makes sense for this local tier.

The following command shows the statistics for the first RAID group of the local tier “aggr1”:

```
statistics show-periodic -object disk:raid_group -instance /aggr1/plex0/rg0
-counter disk_busy|user_read_latency -interval 1 -iterations 60
```

3. Start Automated Workload Analyzer (AWA):

```
storage automated-working-set-analyzer start -node node_name -aggregate
aggr_name
```

AWA begins collecting workload data for the volumes associated with the specified local tier.

4. Exit advanced mode:

```
set admin
```

Allow AWA to run until one or more intervals of peak load have occurred. AWA collects workload statistics for the volumes associated with the specified local tier, and analyzes data for up to one rolling week in duration. Running AWA for more than one week will report only on data collected from the most recent week. Cache size estimates are based on the highest loads seen during the data collection period; the load does not need to be high for the entire data collection period.

5. Enter advanced mode:

```
set advanced
```

6. Display the workload analysis:

```
storage automated-working-set-analyzer show -node node_name -instance
```

7. Stop AWA:

```
storage automated-working-set-analyzer stop node_name
```

All workload data is flushed and is no longer available for analysis.

8. Exit advanced mode:

```
set admin
```

Related information

- [statistics show-periodic](#)
- [storage automated-working-set-analyzer show](#)

- [storage automated-working-set-analyzer start](#)
- [storage automated-working-set-analyzer stop](#)

Create an ONTAP Flash Pool local tier using physical SSDs

You create a Flash Pool local tier by enabling the feature on an existing local tier composed of HDD RAID groups, and then adding one or more SSD RAID groups to that local tier. This results in two sets of RAID groups for that local tier: SSD RAID groups (the SSD cache) and HDD RAID groups.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

About this task

After you add an SSD cache to an local tier to create a Flash Pool local tier, you cannot remove the SSD cache to convert the local tier back to its original configuration.

By default, the RAID level of the SSD cache is the same as the RAID level of the HDD RAID groups. You can override this default selection by specifying the `raidtype` option when you add the first SSD RAID groups.

Before you begin

- You must have identified a valid local tier composed of HDDs to convert to a Flash Pool local tier.
- You must have determined write-caching eligibility of the volumes associated with the local tier, and completed any required steps to resolve eligibility issues.
- You must have determined the SSDs you will be adding, and these SSDs must be owned by the node on which you are creating the Flash Pool local tier.
- You must have determined the checksum types of both the SSDs you are adding and the HDDs already in the local tier.
- You must have determined the number of SSDs you are adding and the optimal RAID group size for the SSD RAID groups.

Using fewer RAID groups in the SSD cache reduces the number of parity disks required, but larger RAID groups require RAID-DP.

- You must have determined the RAID level you want to use for the SSD cache.
- You must have determined the maximum cache size for your system and determined that adding SSD cache to your local tier will not cause you to exceed it.
- You must have familiarized yourself with the configuration requirements for Flash Pool local tiers.

Steps

You can create a Flash Pool local tier using System Manager or the ONTAP CLI.

System Manager

Beginning with ONTAP 9.12.1, you can use System Manager to create a Flash Pool local tier using physical SSDs.

Steps

1. Select **Storage > Tiers** then select an existing local HDD storage tier.
2. Select **⋮** then **Add Flash Pool Cache**.
3. Select **Use dedicated SSDs as cache**.
4. Select a disk type and the number of disks.
5. Choose a RAID type.
6. Select **Save**.
7. Locate the storage tier then select **⋮**.
8. Select **More Details**. Verify that Flash Pool shows as **Enabled**.

CLI

Steps

1. Mark the local tier as eligible to become a Flash Pool local tier:

```
storage aggregate modify -aggregate aggr_name -hybrid-enabled true
```

If this step does not succeed, determine write-caching eligibility for the target local tier.

2. Add the SSDs to the local tier by using the `storage aggregate add` command.
 - You can specify the SSDs by ID or by using the `diskcount` and `disktype` parameters.
 - If the HDDs and the SSDs do not have the same checksum type, or if the local tier is a mixed-checksum local tier, then you must use the `checksumstyle` parameter to specify the checksum type of the disks you are adding to the local tier.
 - You can specify a different RAID type for the SSD cache by using the `raidtype` parameter.
 - If you want the cache RAID group size to be different from the default for the RAID type you are using, you should change it now, by using the `-cache-raid-group-size` parameter.

Related information

- [storage aggregate add](#)
- [storage aggregate modify](#)

Create a Flash Pool local tier using SSD storage pools

Determine whether an ONTAP Flash Pool local tier is using an SSD storage pool

You can configure a Flash Pool local tier by adding one or more allocation units from an SSD storage pool to an existing HDD local tier.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

You manage Flash Pool local tiers differently when they use SSD storage pools to provide their cache than when they use discrete SSDs.

Step

1. Display the local tier's drives by RAID group:

```
storage aggregate show-status aggr_name
```

If the local tier is using one or more SSD storage pools, the value for the `Position` column for the SSD RAID groups is displayed as `Shared`, and the name of the storage pool is displayed next to the RAID group name.

Related information

- [storage aggregate show-status](#)

Add cache to an ONTAP local tier by creating an SSD storage pool

You can provision cache by converting an existing local tier to a Flash Pool local tier by adding solid state drives (SSDs).

You can create solid state drive (SSD) storage pools to provide SSD cache for two to four Flash Pool local tiers. Flash Pool local tiers enable you to deploy flash as high performance cache for your working data set while using lower-cost HDDs for less frequently accessed data.

About this task

- You must supply a disk list when creating or adding disks to a storage pool.

Storage pools do not support a `diskcount` parameter.

- The SSDs used in the storage pool should be the same size.

System Manager

Use System Manager to add an SSD cache (ONTAP 9.12.1 and later)

Beginning with ONTAP 9.12.1, you can use System Manager to add an SSD cache.



Storage pool options are not available on AFF systems.

Steps

1. Click **Cluster > Disks** and then click **Show/Hide**.
2. Select **Type** and verify that spare SSDs exist on the cluster.
3. Click to **Storage > Tiers** and click **Add Storage Pool**.
4. Select the disk type.
5. Enter a disk size.
6. Select the number of disks to add to the storage pool.
7. Review the estimated cache size.

Use System Manager to add an SSD cache (ONTAP 9.7 only)



Use the CLI procedure if you are using an ONTAP version later than ONTAP 9.7 or earlier than ONTAP 9.12.1.

Steps

1. Click **(Return to classic version)**.
2. Click **Storage > Aggregates & Disks > Aggregates**.
3. Select the local tier, and then click **Actions > Add Cache**.
4. Select the cache source as "storage pools" or "dedicated SSDs".
5. Click **(Switch to the new experience)**.
6. Click **Storage > Tiers** to verify the size of the new local tier.

CLI

Use the CLI to create an SSD storage pool

Steps

1. Determine the names of the available spare SSDs:

```
storage aggregate show-spare-disks -disk-type SSD
```

The SSDs used in a storage pool can be owned by either node of an HA pair.

2. Create the storage pool:

```
storage pool create -storage-pool sp_name -disk-list disk1,disk2,...
```

3. **Optional:** Verify the newly created storage pool:

```
storage pool show -storage-pool sp_name
```

Results

After the SSDs are placed into the storage pool, they no longer appear as spares on the cluster, even though the storage provided by the storage pool has not yet been allocated to any Flash Pool caches. You cannot add SSDs to a RAID group as discrete drives; their storage can be provisioned only by using the allocation units of the storage pool to which they belong.

Related information

- [storage aggregate show](#)
- [storage pool create](#)
- [storage pool show](#)

Create an ONTAP Flash Pool local tier using SSD storage pool allocation units

You can configure a Flash Pool local tier by adding one or more allocation units from an SSD storage pool to an existing HDD local tier.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Beginning with ONTAP 9.12.1, you can use the redesigned System Manager to create a Flash Pool local tier using storage pool allocation units.

Before you begin

- You must have identified a valid local tier composed of HDDs to convert to a Flash Pool local tier.
- You must have determined write-caching eligibility of the volumes associated with the local tier, and completed any required steps to resolve eligibility issues.
- You must have created an SSD storage pool to provide the SSD cache to this Flash Pool local tier.

Any allocation unit from the storage pool that you want to use must be owned by the same node that owns the Flash Pool local tier.

- You must have determined how much cache you want to add to the local tier.

You add cache to the local tier by allocation units. You can increase the size of the allocation units later by adding SSDs to the storage pool if there is room.

- You must have determined the RAID type you want to use for the SSD cache.

After you add a cache to the local tier from SSD storage pools, you cannot change the RAID type of the cache RAID groups.

- You must have determined the maximum cache size for your system and determined that adding SSD cache to your local tier will not cause you to exceed it.

You can see the amount of cache that will be added to the total cache size by using the `storage pool show` command.

- You must have familiarized yourself with the configuration requirements for Flash Pool local tier.

About this task

If you want the RAID type of the cache to be different from that of the HDD RAID groups, you must specify the cache RAID type when you add the SSD capacity. After you add the SSD capacity to the local tier, you can no longer change the RAID type of the cache.

After you add an SSD cache to a local tier to create a Flash Pool local tier, you cannot remove the SSD cache to convert the local tier back to its original configuration.

System Manager

Beginning with ONTAP 9.12.1, you can use System Manager to add SSDs to an SSD storage pool.

Steps

1. Click **Storage > Tiers** and select an existing local HDD storage tier.
2. Click  and select **Add Flash Pool Cache**.
3. Select **Use Storage Pools**.
4. Select a storage pool.
5. Select a cache size and RAID configuration.
6. Click **Save**.
7. Locate the storage tier again and click .
8. Select **More Details** and verify that the Flash Pool shows as **Enabled**.

CLI

Steps

1. Mark the local tier as eligible to become a Flash Pool local tier:

```
storage aggregate modify -aggregate aggr_name -hybrid-enabled true
```

If this step does not succeed, determine write-caching eligibility for the target local tier.

2. Show the available SSD storage pool allocation units:

```
storage pool show-available-capacity
```

3. Add the SSD capacity to the local tier:

```
storage aggregate add aggr_name -storage-pool sp_name -allocation-units  
number_of_units
```

If you want the RAID type of the cache to be different from that of the HDD RAID groups, you must change it when you enter this command by using the `raidtype` parameter.

You do not need to specify a new RAID group; ONTAP automatically puts the SSD cache into separate RAID groups from the HDD RAID groups.

You cannot set the RAID group size of the cache; it is determined by the number of SSDs in the storage pool.

The cache is added to the local tier and the local tier is now a Flash Pool local tier. Each allocation unit added to the local tier becomes its own RAID group.

4. Confirm the presence and size of the SSD cache:

```
storage aggregate show aggregate_name
```

The size of the cache is listed under `Total Hybrid Cache Size`.

Related information

- [NetApp Technical Report 4070: Flash Pool Design and Implementation Guide](#)
- [storage aggregate add](#)
- [storage aggregate modify](#)
- [storage pool show](#)
- [storage pool show-available-capacity](#)

Determine the impact on ONTAP cache size when SSDs are added to an SSD storage pool

If adding SSDs to a storage pool causes your platform model's cache limit to be exceeded, ONTAP does not allocate the newly added capacity to any Flash Pool local tiers. This can result in some or all of the newly added capacity being unavailable for use.

About this task

When you add SSDs to an SSD storage pool that has allocation units already allocated to Flash Pool local tiers, you increase the cache size of each of those local tiers and the total cache on the system. If none of the storage pool's allocation units have been allocated, adding SSDs to that storage pool does not affect the SSD cache size until one or more allocation units are allocated to a cache.

Steps

1. Determine the usable size of the SSDs you are adding to the storage pool:

```
storage disk show disk_name -fields usable-size
```

2. Determine how many allocation units remain unallocated for the storage pool:

```
storage pool show-available-capacity sp_name
```

All unallocated allocation units in the storage pool are displayed.

3. Calculate the amount of cache that will be added by applying the following formula:

$(4 - \text{number of unallocated allocation units}) \times 25\% \times \text{usable size} \times \text{number of SSDs}$

Related information

- [storage disk show](#)
- [storage pool show-available-capacity](#)

Add SSDs to an ONTAP SSD storage pool

When you add solid state drives (SSDs) to an SSD storage pool, you increase the storage pool's physical and usable sizes and allocation unit size. The larger allocation unit size also affects allocation units that have already been allocated to local tiers.

Before you begin

You must have determined that this operation will not cause you to exceed the cache limit for your HA pair. ONTAP does not prevent you from exceeding the cache limit when you add SSDs to an SSD storage pool, and doing so can render the newly added storage capacity unavailable for use.

About this task

When you add SSDs to an existing SSD storage pool, the SSDs must be owned by one node or the other of the same HA pair that already owned the existing SSDs in the storage pool. You can add SSDs that are owned by either node of the HA pair.

The SSD you add to the storage pool must be the same size as disk currently used in the storage pool.

System Manager

Beginning with ONTAP 9.12.1, you can use System Manager to add SSDs to an SSD storage pool.

Steps

1. Click **Storage > Tiers** and locate the **Storage Pools** section.
2. Locate the storage pool, click , and select **Add Disks**.
3. Choose the disk type and select the number of disks.
4. Review the estimate cache size.

CLI

Steps

1. **Optional:** View the current allocation unit size and available storage for the storage pool:

```
storage pool show -instance sp_name
```

2. Find available SSDs:

```
storage disk show -container-type spare -type SSD
```

3. Add the SSDs to the storage pool:

```
storage pool add -storage-pool sp_name -disk-list disk1,disk2...
```

The system displays which Flash Pool local tiers will have their size increased by this operation and by how much, and prompts you to confirm the operation.

Related information

- [storage disk show](#)
- [storage pool show](#)
- [storage pool add](#)

ONTAP commands for managing SSD storage pools

ONTAP provides the `storage pool` command for managing SSD storage pools.

If you want to...	Use this command...
Display how much storage a storage pool is providing to which local tier	<code>storage pool show-aggregate</code>

Display how much cache would be added to the overall cache capacity for both RAID types (allocation unit data size)	<code>storage pool show -instance</code>
Display the disks in a storage pool	<code>storage pool show-disks</code>
Display the unallocated allocation units for a storage pool	<code>storage pool show-available-capacity</code>
Change the ownership of one or more allocation units of a storage pool from one HA partner to the other	<code>storage pool reassign</code>

Related information

- [storage pool reassign](#)
- [storage pool show](#)
- [storage pool show-aggregate](#)
- [storage pool show-available-capacity](#)
- [storage pool show-disks](#)

FabricPool tier management

Learn about data tiering with ONTAP FabricPool

You can use FabricPool to automatically tier data depending on how frequently the data is accessed.

FabricPool is a hybrid storage solution that on AFF systems uses an all flash (all SSD) aggregate, and on FAS systems uses either an all flash (all SSD) or HDD aggregate as the performance tier and an object store as the cloud tier. Using a FabricPool helps you reduce storage cost without compromising performance, efficiency, or protection.

The cloud tier can be located on NetApp StorageGRID or ONTAP S3 (beginning with ONTAP 9.8), or one of the following service providers:

- Alibaba cloud
- Amazon S3
- Amazon Commercial Cloud Services
- Google Cloud
- IBM cloud
- Microsoft Azure Blob Storage



Beginning with ONTAP 9.7, additional object store providers that support generic S3 APIs can be used by selecting the S3_Compatible object store provider.

Related information

- [NetApp cloud tiering documentation](#)

Requirements for using ONTAP FabricPool

To help ensure that you optimize your FabricPool configurations, you should familiarize yourself with a few considerations and requirements about using FabricPool.

General considerations and requirements

ONTAP 9.4

- You must be running ONTAP 9.4 or later releases for the following FabricPool functionality:
 - The `auto` [tiering policy](#)
 - Specifying the tiering minimum cooling period
 - Inactive data reporting (IDR)
 - Using Microsoft Azure Blob Storage for the cloud as the cloud tier for FabricPool
 - Using FabricPool with ONTAP Select

ONTAP 9.5

- You must be running ONTAP 9.5 or later releases for the following FabricPool functionality:
 - Specifying the tiering fullness threshold
 - Using IBM Cloud Object Storage as the cloud tier for FabricPool
 - NetApp Volume Encryption (NVE) of the cloud tier, enabled by default.

ONTAP 9.6

- You must be running ONTAP 9.6 or later releases for the following FabricPool functionality:
 - The `all` tiering policy
 - Inactive data reporting enabled manually on HDD aggregates
 - Inactive data reporting enabled automatically for SSD aggregates when you upgrade to ONTAP 9.6 and at time aggregate is created, except on low end systems with less than 4 CPU, less than 6 GB of RAM, or when WAFL-buffer-cache size is less than 3 GB.

ONTAP monitors system load, and if the load remains high for 4 continuous minutes, IDR is disabled, and is not automatically enabled. You can reenable IDR manually; however, manually enabled IDR is not automatically disabled.

- Using Alibaba Cloud Object Storage as the cloud tier for FabricPool
- Using Google Cloud Platform as the cloud tier for FabricPool
- Volume move without cloud tier data copy

ONTAP 9.7

- You must be running ONTAP 9.7 or later releases for the following FabricPool functionality:
 - Non transparent HTTP and HTTPS proxy to provide access to only whitelisted access points, and to provide auditing and reporting capabilities.

- FabricPool mirroring to tier cold data to two object stores simultaneously
- FabricPool mirrors on MetroCluster configurations
- NDMP dump and restore enabled by default on FabricPool attached aggregates.



If the backup application uses a protocol other than NDMP, such as NFS or SMB, all data being backed up in the performance tier becomes hot and can affect tiering of that data to the cloud tier. Non-NDMP reads can cause data migration from the cloud tier back to the performance tier.

NDMP Backup and Restore Support for FabricPool

ONTAP 9.8

- You must be running ONTAP 9.8 or later for the following FabricPool functionality:
 - Cloud retrieval
 - FabricPool with SnapLock Enterprise. FabricPool with SnapLock Enterprise requires a Feature Product Variance Request (FPVR). To create an FPVR, contact your sales team.
 - Minimum cooling period maximum of 183 days
 - Object tagging using user-created custom tags
 - HDD FabricPool aggregates

HDD FabricPools are supported with SAS, FSAS, BSAS and MSATA disks only on systems with 6 or more CPU cores.

Check [Hardware Universe](#) for the latest supported models.

ONTAP 9.10.1

- You must be running ONTAP 9.10.1 or later for the following FabricPool functionality:
 - PUT throttling
 - Temperature-sensitive storage efficiency (TSSE).

ONTAP 9.12.1

- You must be running ONTAP 9.12.1 or later for the following FabricPool functionality:
 - SVM Migrate
 - Support for FabricPool, FlexGroup, and SVM-DR working in conjunction. (Prior to 9.12.1 any two of these features worked together, but not all three in conjunction.)

ONTAP 9.14.1

- You must be running ONTAP 9.14.1 or later for the following FabricPool functionality:
 - Cloud Write
 - Aggressive Readahead

Local tiers (aggregates)

FabricPool supports the following aggregate types:

- On AFF systems, you can only use SSD aggregates for FabricPool.
- On FAS systems, you can use either SSD or HDD aggregates for FabricPool.
- On Cloud Volumes ONTAP and ONTAP Select, you can use either SSD or HDD aggregates for FabricPool. Using SSD aggregates is recommended.



Flash Pool aggregates, which contain both SSDs and HDDs, are not supported.

Cloud tiers

FabricPool supports using the following object stores as the cloud tier:

- Alibaba Cloud Object Storage Service (Standard, Infrequent Access)
- Amazon S3 (Standard, Standard-IA, One Zone-IA, Intelligent-Tiering, Glacier Instant Retrieval)
- Amazon Commercial Cloud Services (C2S)
- Google Cloud Storage (Multi-Regional, Regional, Nearline, Coldline, Archive)
- IBM Cloud Object Storage (Standard, Vault, Cold Vault, Flex)
- Microsoft Azure Blob Storage (Hot and Cool)
- NetApp ONTAP S3 (ONTAP 9.8 and later)
- NetApp StorageGRID (StorageGRID 10.3 and later)



Glacier Flexible Retrieval and Glacier Deep Archive are not supported.

- The object store “bucket” (container) you plan to use must have already been set up, must have at least 10 GB of storage space, and must not be renamed.
- You cannot detach a cloud tier from a local tier after it is attached; however, you can use [FabricPool mirror](#) to attach a local tier to a different cloud tier.

Intercluster LIFs

Cluster high-availability (HA) pairs that use FabricPool require two intercluster LIFs to communicate with the cloud tier. NetApp recommends creating an intercluster LIF on additional HA pairs to seamlessly attach cloud tiers to local tiers on those nodes as well.

Disabling or deleting an intercluster LIF interrupts communication to the cloud tier.



Because concurrent SnapMirror and SnapVault replication operations share the network link to the cloud tier, initialization and RTO are dependent on the available bandwidth and latency to the cloud tier. Performance degradation might occur if connectivity resources become saturated. Proactive configuration of multiple LIFs can significantly decrease this type of network saturation.

If you are using more than one intercluster LIF on a node with different routing, NetApp recommends placing them in different IPspaces. During configuration, FabricPool can select from multiple IPspaces, but it is unable to select specific intercluster LIFs within an IPspace.

Network Time Protocol (NTP)

Network Time Protocol (NTP) configuration is required to ensure the time is synchronized between clusters. [Learn about how to configure NTP.](#)

ONTAP storage efficiencies

Storage efficiencies such as compression, deduplication, and compaction are preserved when moving data to the cloud tier, reducing required object storage capacity and transport costs.



Beginning with ONTAP 9.15.1, FabricPool supports Intel QuickAssist Technology (QAT4) which provides more aggressive, and more performant, storage efficiency savings.

Aggregate inline deduplication is supported on the local tier, but associated storage efficiencies are not carried over to objects stored on the cloud tier.

When using the All volume tiering policy, storage efficiencies associated with background deduplication processes might be reduced as data is likely to be tiered before the additional storage efficiencies can be applied.

NetApp Cloud Tiering license

FabricPool requires a capacity-based license when attaching third-party object storage providers (such as Amazon S3) as cloud tiers for AFF and FAS systems. A Cloud Tiering license is not required when using StorageGRID or ONTAP S3 as the cloud tier or when tiering with Cloud Volumes ONTAP, Amazon FSx for NetApp ONTAP, or Azure NetApp files.

NetApp Cloud Tiering licenses (including add-on or extensions to preexisting FabricPool licenses) are activated in the NetApp Console. Learn more about [setting up Cloud Tiering licenses](#).

StorageGRID consistency controls

StorageGRID's consistency controls affects how the metadata that StorageGRID uses to track objects is distributed between nodes and the availability of objects for client requests. NetApp recommends using the default, read-after-new-write, consistency control for buckets used as FabricPool targets.



Do not use the available consistency control for buckets used as FabricPool targets.

Additional considerations for tiering data accessed by SAN protocols

When tiering data that is accessed by SAN protocols, NetApp recommends using private clouds, like ONTAP S3 or StorageGRID, due to connectivity considerations.



You should be aware that when using FabricPool in a SAN environment with a Windows host, if the object storage becomes unavailable for an extended period of time when tiering data to the cloud, files on the NetApp LUN on the Windows host might become inaccessible or disappear. See the [NetApp Knowledge Base: During FabricPool S3 object store unavailable Windows SAN host reported filesystem corruption](#).

Quality of Service

- If you use throughput floors (QoS Min), the tiering policy on the volumes must be set to `none` before the aggregate can be attached to FabricPool.

Other tiering policies prevent the aggregate from being attached to FabricPool. A QoS policy will not enforce throughput floors when FabricPool is enabled.

Functionality or features not supported by FabricPool

- Object stores with WORM enabled and object versioning enabled.
- Information lifecycle management (ILM) policies that are applied to object store buckets

FabricPool supports StorageGRID's Information Lifecycle Management policies only for data replication and erasure coding to protect cloud tier data from failure. However, FabricPool does *not* support advanced ILM rules such as filtering based on user metadata or tags. ILM typically includes various movement and deletion policies. These policies can be disruptive to the data in the cloud tier of FabricPool. Using FabricPool with ILM policies that are configured on object stores can result in data loss.

- 7-Mode data transition using the ONTAP CLI commands or the 7-Mode Transition Tool
- RAID SyncMirror, except in a MetroCluster configuration
- SnapLock volumes when using ONTAP 9.7 and earlier releases
- [Tamperproof snapshots](#)

Tamperproof snapshots provide immutable protections that cannot be deleted. Because FabricPool requires the ability to delete data, FabricPool and snapshot locks cannot be enabled on the same volume.

- Tape backup using SMTape for FabricPool-enabled aggregates
- The Auto Balance functionality
- Volumes using a space guarantee other than `none`

With the exception of root SVM volumes and CIFS audit staging volumes, FabricPool does not support attaching a cloud tier to an aggregate that contains volumes using a space guarantee other than `none`. For example, a volume using a space guarantee of `volume (-space-guarantee volume)` is not supported.

- Clusters with [DP_Optimized license](#)
- Flash Pool aggregates

Tier data efficiently with ONTAP FabricPool policies

FabricPool tiering policies enable you to move data efficiently across tiers as data becomes hot or cold. Understanding the tiering policies helps you select the right policy that suits your storage management needs.

Types of FabricPool tiering policies

FabricPool tiering policies determine when or whether the user data blocks of a volume in FabricPool are moved to the cloud tier, based on the volume “temperature” of hot (active) or cold (inactive). The volume “temperature” increases when it is accessed frequently and decreases when it is not. Some tiering policies have an associated tiering minimum cooling period, which sets the time that user data in a volume of FabricPool must remain inactive for the data to be considered “cold” and moved to the cloud tier.

After a block has been identified as cold, it is marked as eligible to be tiered. A daily background tiering scan looks for cold blocks. When enough 4KB blocks from the same volume have been collected, they are concatenated into a 4MB object and moved to the cloud tier based on the volume tiering policy.



Data in volumes using the `all` tiering policy is immediately marked as cold and begins tiering to the cloud tier as soon as possible. It does not need to wait for the daily tiering scan to run.

You can use the `volume object-store tiering show` command to view the tiering status of a FabricPool volume.

Learn more about `volume object-store tiering show` in the [ONTAP command reference](#).

The FabricPool tiering policy is specified at the volume level. Four options are available:

- The `snapshot-only` tiering policy (the default) moves user data blocks of the volume snapshots that are not associated with the active file system to the cloud tier.

The tiering minimum cooling period is 2 days. You can modify the default setting for the tiering minimum cooling period with the `-tiering-minimum-cooling-days` parameter in the advanced privilege level of the `volume create` and `volume modify` commands. Valid values are 2 to 183 days using ONTAP 9.8 and later. If you are using a version of ONTAP earlier than 9.8, valid values are 2 to 63 days.

- The `auto` tiering policy, supported only on ONTAP 9.4 and later releases, moves cold user data blocks in both the snapshots and the active file system to the cloud tier.

The default tiering minimum cooling period is 31 days and applies to the entire volume, for both the active file system and the snapshots.

You can modify the default setting for the tiering minimum cooling period with the `-tiering-minimum-cooling-days` parameter in the advanced privilege level of the `volume create` and `volume modify` commands. Valid values are 2 to 183 days.

- The `all` tiering policy, supported only with ONTAP 9.6 and later, moves all user data blocks in both the active file system and snapshots to the cloud tier. It replaces the `backup` tiering policy.

The `all` volume tiering policy should not be used on read/write volumes that have normal client traffic.

The tiering minimum cooling period does not apply because the data moves to the cloud tier as soon as the tiering scan runs, and you cannot modify the setting.

- The `none` tiering policy keeps a volume's data in the performance tier and does not move cold to the cloud tier.

Setting the tiering policy to `none` prevents new tiering. Volume data that has previously been moved to the cloud tier remains in the cloud tier until it becomes hot and is automatically moved back to the local tier.

The tiering minimum cooling period does not apply because the data never moves to the cloud tier, and you cannot modify the setting.

When cold blocks in a volume with a tiering policy set to `none` are read, they are made hot and written to the local tier.

The `volume show` command output shows the tiering policy of a volume. A volume that has never been used with FabricPool shows the `none` tiering policy in the output.



When in an SVM DR relationship, source and destination volumes do not need to use FabricPool aggregates, but they must use the same tiering policy.

What happens when you modify the tiering policy of a volume in FabricPool

You can modify the tiering policy of a volume by performing a `volume modify` operation. You must understand how changing the tiering policy might affect how long it takes for data to become cold and be moved to the cloud tier.

- Changing the tiering policy from `snapshot-only` or `none` to `auto` causes ONTAP to send user data blocks in the active file system that are already cold to the cloud tier, even if those user data blocks were not previously eligible for the cloud tier.
- Changing the tiering policy to `all` from another policy causes ONTAP to move all user blocks in the active file system and in the snapshots to the cloud as soon as possible. Prior to ONTAP 9.8, blocks needed to wait until the next tiering scan ran.

Moving blocks back to the performance tier is not allowed.

- Changing the tiering policy from `auto` to `snapshot-only` or `none` does not cause active file system blocks that are already moved to the cloud tier to be moved back to the performance tier.

Volume reads are needed for the data to be moved back to the performance tier.

- Any time you change the tiering policy on a volume, the tiering minimum cooling period is reset to the default value for the policy.

What happens to the tiering policy when you move a volume

- Unless you explicitly specify a different tiering policy, a volume retains its original tiering policy when it is moved in and out of a FabricPool-enabled aggregate.

However, the tiering policy takes effect only when the volume is in a FabricPool-enabled aggregate.

- The existing value of the `-tiering-minimum-cooling-days` parameter for a volume moves with the volume unless you specify a different tiering policy for the destination.

If you specify a different tiering policy, then the volume uses the default tiering minimum cooling period for that policy. This is the case whether the destination is FabricPool or not.

- You can move a volume across aggregates and at the same time modify the tiering policy.
- You should pay special attention when a `volume move` operation involves the `auto` tiering policy.

Assuming that both the source and the destination are FabricPool-enabled aggregates, the following table summarizes the outcome of a `volume move` operation that involves policy changes related to `auto`:

When you move a volume that has a tiering policy of...	And you change the tiering policy with the move to...	Then after the volume move...
<code>all</code>	<code>auto</code>	All data is moved to the performance tier.
<code>snapshot-only</code> , <code>none</code> , or <code>auto</code>	<code>auto</code>	Data blocks are moved to the same tier of the destination as they previously were on the source.

auto or all	snapshot-only	All data is moved to the performance tier.
auto	all	All user data is moved to the cloud tier.
snapshot-only,auto or all	none	All data is kept at the performance tier.

What happens to the tiering policy when you clone a volume

- Beginning with ONTAP 9.8, a clone volume always inherits both the tiering policy and the cloud retrieval policy from the parent volume.

In releases earlier than ONTAP 9.8, a clone inherits the tiering policy from the parent except when the parent has the `all` tiering policy.

- If the parent volume has the `never` cloud retrieval policy, its clone volume must have either the `never` cloud retrieval policy or the `all` tiering policy, and a corresponding cloud retrieval policy `default`.
- The parent volume cloud retrieval policy cannot be changed to `never` unless all its clone volumes have a cloud retrieval policy `never`.

When you clone volumes, keep the following best practices in mind:

- The `-tiering-policy` option and `tiering-minimum-cooling-days` option of the clone only controls the tiering behavior of blocks unique to the clone. Therefore, we recommend using tiering settings on the parent FlexVol that are either move the same amount of data or move less data than any of the clones
- The cloud retrieval policy on the parent FlexVol should either move the same amount of data or should move more data than the retrieval policy of any of the clones

How tiering policies work with cloud migration

FabricPool cloud data retrieval is controlled by tiering policies that determine data retrieval from the cloud tier to performance tier based on the read pattern. Read patterns can be either sequential or random.

The following table lists the tiering policies and the cloud data retrieval rules for each policy.

Tiering policy	Retrieval behavior
none	Sequential and random reads
snapshot-only	Sequential and random reads
auto	Random reads
all	No data retrieval

Beginning with ONTAP 9.8, the cloud migration control `cloud-retrieval-policy` option overrides the

default cloud migration or retrieval behavior controlled by the tiering policy.


The following table lists the supported cloud retrieval policies and their retrieval behavior.

Cloud retrieval policy	Retrieval behavior
default	Tiering policy decides what data should be pulled back, so there is no change to cloud data retrieval with “default,” <code>cloud-retrieval-policy</code> . This policy is the default value for any volume regardless of the hosted aggregate type.
on-read	All client-driven data read is pulled from cloud tier to performance tier.
never	No client-driven data is pulled from cloud tier to performance tier
promote	<ul style="list-style-type: none"> • For tiering policy “none,” all cloud data is pulled from the cloud tier to the performance tier • For tiering policy “snapshot-only,” AFS data is pulled.

Learn more about the commands described in this procedure in the [ONTAP command reference](#).

Learn about ONTAP FabricPool configuration and management tasks

You can use the FabricPool workflow diagram to help you plan the configuration and management tasks.



Configure FabricPool

Prepare for FabricPool configuration

Get started with ONTAP FabricPool

Configuring FabricPool helps you manage which storage tier (the local performance tier or the cloud tier) data should be stored based on whether the data is frequently accessed.

The preparation required for FabricPool configuration depends on the object store you use as the cloud tier.

Install a FabricPool license on an ONTAP cluster

The FabricPool license you might have used in the past is changing and is being retained only for configurations that aren't supported within the NetApp Console. Beginning August 21, 2021, NetApp Cloud Tiering BYOL licensing was introduced for tiering configurations that are supported within the NetApp Console using NetApp Cloud Tiering.

[Learn more about NetApp Cloud Tiering BYOL licensing.](#)

Configurations that are supported by the NetApp Console must use the Console to license tiering for ONTAP clusters. This requires you to set up a NetApp Console account and set up tiering for the particular object storage provider you plan to use. The Console currently supports tiering to the following object storage: Amazon S3, Azure Blob storage, Google Cloud Storage, S3-compatible object storage, and StorageGRID.

[Learn more about the NetApp Cloud Tiering service.](#)

You can download and activate a FabricPool license using System Manager if you have one of the configurations that is not supported within the Console:

- ONTAP installations in Dark Sites
- ONTAP clusters that are tiering data to IBM Cloud Object Storage or Alibaba Cloud Object Storage

The FabricPool license is a cluster-wide license. It includes an entitled usage limit that you purchase for object storage that is associated with FabricPool in the cluster. The usage across the cluster must not exceed the capacity of the entitled usage limit. If you need to increase the usage limit of the license, you should contact your sales representative.

FabricPool licenses are available in perpetual or term-based, 1- or 3- year, formats.

A term-based FabricPool license with 10 TB of free capacity is available for first time FabricPool orders for existing clusters configurations not supported within the NetApp Console. Free capacity is not available with perpetual licenses.

A license is not required if you use NetApp StorageGRID or ONTAP S3 for the cloud tier. Cloud Volumes ONTAP does not require a FabricPool license, regardless of the provider you are using.

This task is supported only by uploading the license file to the cluster using System Manager.

Steps

1. Download the NetApp License File (NLF) for the FabricPool license from the [NetApp Support Site](#).
2. Perform the following actions using System Manager to upload the FabricPool license to the cluster:

- a. In the **Cluster > Settings** pane, on the **Licenses** card, click [→](#).
- b. On the **License** page, click [+ Add](#).
- c. In the **Add License** dialog box, click **Browse** to select the NLF you downloaded, and then click **Add** to upload the file to the cluster.

Related information

[ONTAP FabricPool \(FP\) Licensing Overview](#)

[NetApp Software License Search](#)

[NetApp TechComm TV: FabricPool playlist](#)

Install a CA certificate on an ONTAP cluster for StorageGRID

Using CA certificates creates a trusted relationship between client applications and StorageGRID.

Unless you plan to disable certificate checking for StorageGRID, you must install a StorageGRID CA certificate on the cluster so that ONTAP can authenticate with StorageGRID as the object store for FabricPool.

Although StorageGRID can generate self-signed certificates, using signed certificates from a third-party certificate authority is the recommended best practice.

About this task

Although installation and use of certificate authority (CA) certificates are recommended best practices, beginning with ONTAP 9.4, installation of CA certificates is not required for StorageGRID.

Steps

1. Contact your StorageGRID administrator to obtain the [StorageGRID system's CA certificate](#).
2. Use the `security certificate install` command with the `-type server-ca` parameter to install the StorageGRID CA certificate on the cluster.

The fully qualified domain name (FQDN) you enter must match the custom common name on the StorageGRID CA certificate.

Update an expired certificate

To update an expired certificate, the best practice is to use a trusted CA to generate the new server certificate. In addition, you should ensure that the certificate is updated on the StorageGRID server and on the ONTAP cluster at the same time to keep any downtime to a minimum.

Related information

- [StorageGRID Resources](#)
- [security certificate install](#)

Install a CA certificate on a cluster for ONTAP S3

Using CA certificates creates a trusted relationship between client applications and the ONTAP S3 object store server. A CA certificate should be installed on ONTAP before using it as an object store that is accessible to remote clients.

Unless you plan to disable certificate checking for ONTAP S3, you must install a ONTAP S3 CA certificate on the cluster so that ONTAP can authenticate with ONTAP S3 as the object store for FabricPool.

Although ONTAP can generate self-signed certificates, using signed certificates from a third-party certificate authority is the recommended best practice.

Steps

1. Obtain the ONTAP S3 system's CA certificate.
2. Use the `security certificate install` command with the `-type server-ca` parameter to install the ONTAP S3 CA certificate on the cluster.

The fully qualified domain name (FQDN) you enter must match the custom common name on the ONTAP S3 CA certificate.

Update an expired certificate

To update an expired certificate, the best practice is to use a trusted CA to generate the new server certificate. In addition, you should ensure that the certificate is updated on the ONTAP S3 server and on the ONTAP cluster at the same time to keep any downtime to a minimum.

You can use System Manager to renew an expired certificate on an ONTAP cluster.

Steps

1. Navigate to **Cluster > Settings**.
2. Scroll to the **Security** section, locate the **Certificates** pane, and click [→](#).
3. In the **Trusted certificate authorities** tab, locate the name of the certificate you want to renew.
4. Next to the certificate name click [⋮](#) and select **Renew**.
5. In the **Renew trusted certificate authority** window, copy and paste or import the certificate information into the **Certificate details** area.
6. Click **Renew**.

Related information

- [S3 configuration](#)
- [security certificate install](#)

Set up an object store as the cloud tier for FabricPool

Set up an object store as the cloud tier for FabricPool overview

Setting up FabricPool involves specifying the configuration information of the object store (StorageGRID, ONTAP S3, Alibaba Cloud Object Storage, Amazon S3, Google Cloud Storage, IBM Cloud Object Storage, or Microsoft Azure Blob Storage for the cloud) that you plan to use as the cloud tier for FabricPool.

Set up StorageGRID as the ONTAP FabricPool cloud tier

You can set up StorageGRID as the cloud tier for FabricPool. When tiering data that is accessed by SAN protocols, NetApp recommends using private clouds, like StorageGRID, due to connectivity considerations.

Considerations for using StorageGRID with FabricPool

- You need to install a CA certificate for StorageGRID, unless you explicitly disable certificate checking.
- Do not enable StorageGRID object versioning on the object store bucket.
- A FabricPool license is not required.
- If a StorageGRID node is deployed in a virtual machine with storage assigned from a NetApp AFF system, confirm that the volume does not have a FabricPool tiering policy enabled.

Disabling FabricPool tiering for volumes used with StorageGRID nodes simplifies troubleshooting and storage operations.



Never use FabricPool to tier any data related to StorageGRID back to StorageGRID itself. Tiering StorageGRID data back to StorageGRID increases troubleshooting and operational complexity.

About this task

Load balancing is enabled for StorageGRID in ONTAP 9.8 and later. When the server's hostname resolves to more than one IP address, ONTAP establishes client connections with all the IP addresses returned (up to a maximum of 16 IP addresses). The IP addresses are picked up in a round-robin method when connections are established.

Steps

You can set up StorageGRID as the cloud tier for FabricPool with ONTAP System Manager or the ONTAP CLI.

System Manager

1. Click **Storage > Tiers > Add Cloud Tier** and select StorageGRID as the object store provider.
2. Complete the requested information.
3. If you want to create a cloud mirror, click **Add as FabricPool Mirror**.

A FabricPool mirror provides a method for you to seamlessly replace a data store, and it helps to ensure that your data is available in the event of disaster.

CLI

1. Specify the StorageGRID configuration information by using the `storage aggregate object-store config create` command with the `-provider-type SGWS` parameter.

- The `storage aggregate object-store config create` command fails if ONTAP cannot access StorageGRID with the provided information.
- You use the `-access-key` parameter to specify the access key for authorizing requests to the StorageGRID object store.
- You use the `-secret-password` parameter to specify the password (secret access key) for authenticating requests to the StorageGRID object store.
- If the StorageGRID password is changed, you should update the corresponding password stored in ONTAP immediately.

Doing so enables ONTAP to access the data in StorageGRID without interruption.

- Setting the `-is-certificate-validation-enabled` parameter to `false` disables certificate checking for StorageGRID. Using signed certificates (`-is-certificate-validation-enabled true`) from a third-party certificate authority is a recommended best practice.

```
cluster1::> storage aggregate object-store config create
-object-store-name mySGWS -provider-type SGWS -server mySGWSserver
-container-name mySGWScontainer -access-key mySGWSkey
-secret-password mySGWSpass
```

2. Display and verify the StorageGRID configuration information by using the `storage aggregate object-store config show` command.

The `storage aggregate object-store config modify` command enables you to modify the StorageGRID configuration information for FabricPool.

Related information

- [storage aggregate object-store config create](#)
- [storage aggregate object-store config modify](#)
- [storage aggregate object-store config show](#)

Set up ONTAP S3 as the FabricPool cloud tier

If you are running ONTAP 9.8 or later, you can set up ONTAP S3 as the cloud tier for FabricPool.

Before you begin

- You must have the ONTAP S3 server name and the IP address of its associated LIFs on the remote cluster.



The server name is used as the fully qualified domain name (FQDN) by client applications. Outside of ONTAP, confirm DNS records point to the SVM data LIFs being used.

- There must be [intracluster LIFs](#) on the local cluster.

When configured for local cluster tiering, a local tier (also known as a storage aggregate in the ONTAP CLI) is attached to a local bucket. FabricPool uses cluster LIFs for intracluster traffic.



Performance degradation might occur if cluster LIF resources become saturated. To avoid this, NetApp recommends using four-node or greater clusters when tiering to a local bucket along with an HA pair for the local tier and an HA pair for the local bucket. Tiering to local buckets on a single HA pair is not recommended.

- To enable remote FabricPool capacity (cloud) tiering using ONTAP S3, you must [configure intercluster LIFs](#) on the FabricPool client and [configure data LIFs](#) on the object store server.

About this task

Load balancing is enabled for ONTAP S3 servers in ONTAP 9.8 and later. When the server's hostname resolves to more than one IP address, ONTAP establishes client connections with all the IP addresses returned (up to a maximum of 16 IP addresses). The IP addresses are picked up in a round-robin method when connections are established.

Steps

You can set up ONTAP S3 as the cloud tier for FabricPool with ONTAP System Manager or the ONTAP CLI.

System Manager

1. Click **Storage > Tiers > Add Cloud Tier** and select ONTAP S3 as the object store provider.
2. Complete the requested information.
3. If you want to create a cloud mirror, click **Add as FabricPool Mirror**.

A FabricPool mirror provides a method for you to seamlessly replace a data store, and it helps to ensure that your data is available in the event of disaster.

CLI

1. Add entries for the S3 server and LIFs to your DNS server.

Option	Description
If you use an external DNS server	Give the S3 server name and IP addresses to the DNS server administrator.
If you use your local system's DNS hosts table	Enter the following command: <pre>dns host create -vserver <svm_name> -address ip_address -hostname <s3_server_name></pre>

2. Specify the ONTAP S3 configuration information by using the `storage aggregate object-store config create` command with the `-provider-type ONTAP_S3` parameter.
 - The `storage aggregate object-store config create` command fails if the local ONTAP system cannot access the ONTAP S3 server with the information provided.
 - You use the `-access-key` parameter to specify the access key for authorizing requests to the ONTAP S3 server.
 - You use the `-secret-password` parameter to specify the password (secret access key) for authenticating requests to the ONTAP S3 server.
 - If the ONTAP S3 server password is changed, you should immediately update the corresponding password stored in the local ONTAP system.

Doing so enables access to the data in the ONTAP S3 object store without interruption.

- Setting the `-is-certificate-validation-enabled` parameter to `false` disables certificate checking for ONTAP S3. Using signed certificates (`-is-certificate-validation-enabled true`) from a third-party certificate authority is a recommended best practice.

```
cluster1::> storage aggregate object-store config create  
-object-store-name myS3 -provider-type ONTAP_S3 -server myS3server  
-container-name myS3container -access-key myS3key  
-secret-password myS3pass
```

3. Display and verify the ONTAP_S3 configuration information by using the `storage aggregate object-store config show` command.

The `storage aggregate object-store config modify` command enables you to modify the ONTAP_S3 configuration information for FabricPool.

Related information

- [Create LIF for SMB](#)
- [Create LIF for NFS](#)
- [storage aggregate object-store config create](#)
- [storage aggregate object-store config modify](#)
- [storage aggregate object-store config show](#)

Set up Alibaba Cloud Object Storage as the ONTAP FabricPool cloud tier

If you are running ONTAP 9.6 or later, you can set up Alibaba Cloud Object Storage as the cloud tier for FabricPool.

Considerations for using Alibaba Cloud Object Storage with FabricPool

- A [NetApp Cloud Tiering license](#) is required when tiering to Alibaba Cloud Object Storage. For more information, see [Install a FabricPool license on an ONTAP cluster](#).
- On AFF and FAS systems and ONTAP Select, FabricPool supports the following Alibaba Object Storage Service classes:
 - Alibaba Object Storage Service Standard
 - Alibaba Object Storage Service Infrequent Access

[Alibaba Cloud: Introduction to storage classes](#)

Contact your NetApp sales representative for information about storage classes not listed.

Steps

1. Specify the Alibaba Cloud Object Storage configuration information by using the `storage aggregate object-store config create` command with the `-provider-type AliCloud` parameter.
 - The `storage aggregate object-store config create` command fails if ONTAP cannot access Alibaba Cloud Object Storage with the provided information.
 - You use the `-access-key` parameter to specify the access key for authorizing requests to the Alibaba Cloud Object Storage object store.
 - If the Alibaba Cloud Object Storage password is changed, you should update the corresponding password stored in ONTAP immediately.

Doing so enables ONTAP to access the data in Alibaba Cloud Object Storage without interruption.

```
storage aggregate object-store config create my_ali_oss_store_1
-provider-type AliCloud -server oss-us-east-1.aliyuncs.com
-container-name my-ali-oss-bucket -access-key DXJRXHPXHYXA9X31X3JX
```

2. Display and verify the Alibaba Cloud Object Storage configuration information by using the `storage aggregate object-store config show` command.

The `storage aggregate object-store config modify` command enables you to modify the Alibaba Cloud Object Storage configuration information for FabricPool.

Related information

- [storage aggregate object-store config create](#)
- [storage aggregate object-store config modify](#)
- [storage aggregate object-store config show](#)

Set up Amazon S3 as the ONTAP FabricPool cloud tier

You can set up Amazon S3 as the cloud tier for FabricPool. If you are running ONTAP 9.5 or later, you can set up Amazon Commercial Cloud Services (C2S) for FabricPool.

Considerations for using Amazon S3 with FabricPool

- A [NetApp Cloud Tiering license](#) is required when tiering to Amazon S3.
- It is recommended that the LIF that ONTAP uses to connect with the Amazon S3 object server be on a 10 Gbps port.
- On AFF and FAS systems and ONTAP Select, FabricPool supports the following Amazon S3 storage classes:
 - Amazon S3 Standard
 - Amazon S3 Standard - Infrequent Access (Standard - IA)
 - Amazon S3 One Zone - Infrequent Access (One Zone - IA)
 - Amazon S3 Intelligent-Tiering
 - Amazon Commercial Cloud Services
 - Beginning with ONTAP 9.11.1, Amazon S3 Glacier Instant Retrieval (FabricPool does not support Glacier Flexible Retrieval or Glacier Deep Archive)

[Amazon Web Services Documentation: Amazon S3 Storage Classes](#)

Contact your sales representative for information about storage classes not listed.

- On Cloud Volumes ONTAP, FabricPool supports tiering from General Purpose SSD (gp2) and Throughput Optimized HDD (st1) volumes of Amazon Elastic Block Store (EBS).

Steps

1. Specify the Amazon S3 configuration information by using the `storage aggregate object-store config create` command with the `-provider-type AWS_S3` parameter.
 - You use the `-auth-type CAP` parameter to obtain credentials for C2S access.

When you use the `-auth-type CAP` parameter, you must use the `-cap-url` parameter to specify the full URL to request temporary credentials for C2S access.

- The `storage aggregate object-store config create` command fails if ONTAP cannot access Amazon S3 with the provided information.
- You use the `-access-key` parameter to specify the access key for authorizing requests to the Amazon S3 object store.
- You use the `-secret-password` parameter to specify the password (secret access key) for authenticating requests to the Amazon S3 object store.
- If the Amazon S3 password is changed, you should update the corresponding password stored in ONTAP immediately.

Doing so enables ONTAP to access the data in Amazon S3 without interruption.

```
cluster1::> storage aggregate object-store config create
-object-store-name my_aws_store -provider-type AWS_S3
-server s3.amazonaws.com -container-name my-aws-bucket
-access-key DXJRXHPXHYXA9X31X3JX
```

```
cluster1::> storage aggregate object-store config create -object
-store-name my_c2s_store -provider-type AWS_S3 -auth-type CAP -cap
-url
https://123.45.67.89/api/v1/credentials?agency=XYZ&mission=TESTACCT&r
ole=S3FULLACCESS -server my-c2s-s3server-fqdn -container my-c2s-s3-
bucket
```

2. Display and verify the Amazon S3 configuration information by using the `storage aggregate object-store config show` command.

The `storage aggregate object-store config modify` command enables you to modify the Amazon S3 configuration information for FabricPool.

Related information

- [storage aggregate object-store config create](#)
- [storage aggregate object-store config modify](#)
- [storage aggregate object-store config show](#)

Set up Google Cloud Storage as the ONTAP FabricPool cloud tier

If you are running ONTAP 9.6 or later, you can set up Google Cloud Storage as the cloud tier for FabricPool.

Additional considerations for using Google Cloud Storage with FabricPool

- A [NetApp Cloud Tiering license](#) is required when tiering to Google Cloud Storage.

- It is recommended that the LIF that ONTAP uses to connect with the Google Cloud Storage object server be on a 10 Gbps port.
- On AFF and FAS systems and ONTAP Select, FabricPool supports the following Google Cloud Object storage classes:
 - Google Cloud Multi-Regional
 - Google Cloud Regional
 - Google Cloud Nearline
 - Google Cloud Coldline

[Google Cloud: Storage Classes](#)

Steps

1. Specify the Google Cloud Storage configuration information by using the `storage aggregate object-store config create` command with the `-provider-type GoogleCloud` parameter.
 - The `storage aggregate object-store config create` command fails if ONTAP cannot access Google Cloud Storage with the provided information.
 - You use the `-access-key` parameter to specify the access key for authorizing requests to the Google Cloud Storage object store.
 - If the Google Cloud Storage password is changed, you should update the corresponding password stored in ONTAP immediately.

Doing so enables ONTAP to access the data in Google Cloud Storage without interruption.

```
storage aggregate object-store config create my_gcp_store_1 -provider
-type GoogleCloud -container-name my-gcp-bucket1 -access-key
GOOGAUZZUV2USCFGHGQ511I8
```

2. Display and verify the Google Cloud Storage configuration information by using the `storage aggregate object-store config show` command.

The `storage aggregate object-store config modify` command enables you to modify the Google Cloud Storage configuration information for FabricPool.

Related information

- [storage aggregate object-store config create](#)
- [storage aggregate object-store config modify](#)
- [storage aggregate object-store config show](#)

Set up IBM Cloud Object Storage as the ONTAP FabricPool cloud tier

If you are running ONTAP 9.5 or later, you can set up IBM Cloud Object Storage as the cloud tier for FabricPool.

Considerations for using IBM Cloud Object Storage with FabricPool

- A [NetApp Cloud Tiering license](#) is required when tiering to IBM Cloud Object Storage.
- It is recommended that the LIF that ONTAP uses to connect with the IBM Cloud object server be on a 10 Gbps port.

Steps

1. Specify the IBM Cloud Object Storage configuration information by using the `storage aggregate object-store config create` command with the `-provider-type IBM_COS` parameter.
 - The `storage aggregate object-store config create` command fails if ONTAP cannot access IBM Cloud Object Storage with the provided information.
 - You use the `-access-key` parameter to specify the access key for authorizing requests to the IBM Cloud Object Storage object store.
 - You use the `-secret-password` parameter to specify the password (secret access key) for authenticating requests to the IBM Cloud Object Storage object store.
 - If the IBM Cloud Object Storage password is changed, you should update the corresponding password stored in ONTAP immediately.

Doing so enables ONTAP to access the data in IBM Cloud Object Storage without interruption.

```
storage aggregate object-store config create
-object-store-name MyIBM -provider-type IBM_COS
-server s3.us-east.objectstorage.softlayer.net
-container-name my-ibm-cos-bucket -access-key DXJRXHPXHYXA9X31X3JX
```

2. Display and verify the IBM Cloud Object Storage configuration information by using the `storage aggregate object-store config show` command.

The `storage aggregate object-store config modify` command enables you to modify the IBM Cloud Object Storage configuration information for FabricPool.

Related information

- [storage aggregate object-store config create](#)
- [storage aggregate object-store config modify](#)
- [storage aggregate object-store config show](#)

Set up Azure Blob Storage as the ONTAP FabricPool cloud tier

If you are running ONTAP 9.4 or later, you can set up Azure Blob Storage as the cloud tier for FabricPool.

Considerations for using Microsoft Azure Blob Storage with FabricPool

- A [NetApp Cloud Tiering license](#) is required when tiering to Azure Blob Storage.
- A FabricPool license is not required if you are using Azure Blob Storage with Cloud Volumes ONTAP.
- It is recommended that the LIF that ONTAP uses to connect with the Azure Blob Storage object server be on a 10 Gbps port.
- FabricPool currently does not support Azure Stack, which is on-premises Azure services.

- At the account level in Microsoft Azure Blob Storage, FabricPool supports only hot and cool storage tiers.

FabricPool does not support blob-level tiering. It also does not support tiering to Azure's archive storage tier.

About this task

FabricPool currently does not support Azure Stack, which is on-premises Azure services.

Steps

1. Specify the Azure Blob Storage configuration information by using the `storage aggregate object-store config create` command with the `-provider-type Azure_Cloud` parameter.
 - The `storage aggregate object-store config create` command fails if ONTAP cannot access Azure Blob Storage with the provided information.
 - You use the `-azure-account` parameter to specify the Azure Blob Storage account.
 - You use the `-azure-private-key` parameter to specify the access key for authenticating requests to Azure Blob Storage.
 - If the Azure Blob Storage password is changed, you should update the corresponding password stored in ONTAP immediately.

Doing so enables ONTAP to access the data in Azure Blob Storage without interruption.

```
cluster1::> storage aggregate object-store config create
-object-store-name MyAzure -provider-type Azure_Cloud
-server blob.core.windows.net -container-name myAzureContainer
-azure-account myAzureAcct -azure-private-key myAzureKey
```

2. Display and verify the Azure Blob Storage configuration information by using the `storage aggregate object-store config show` command.

The `storage aggregate object-store config modify` command enables you to modify the Azure Blob Storage configuration information for FabricPool.

Related information

- [storage aggregate object-store config create](#)
- [storage aggregate object-store config modify](#)
- [storage aggregate object-store config show](#)

Set up object stores for ONTAP FabricPool in a MetroCluster configuration

If you are running ONTAP 9.7 or later, you can set up a mirrored FabricPool on a MetroCluster configuration to tier cold data to object stores in two different fault zones.

About this task

- FabricPool in MetroCluster requires that the underlying mirrored aggregate and the associated object store configuration must be owned by the same MetroCluster configuration.

- You cannot attach an aggregate to an object store that is created in the remote MetroCluster site.
- You must create object store configurations on the MetroCluster configuration that owns the aggregate.

Before you begin

- The MetroCluster configuration is set up and properly configured.
- Two object stores are set up on the appropriate MetroCluster sites.
- Containers are configured on each of the object stores.
- IP spaces are created or identified on the two MetroCluster configurations and their names match.

Step

1. Specify the object store configuration information on each MetroCluster site by using the `storage object-store config create` command.

In this example, FabricPool is required on only one cluster in the MetroCluster configuration. Two object store configurations are created for that cluster, one for each object store bucket.

```
storage aggregate
  object-store config create -object-store-name mcc1-ostore-config-s1
-provider-type SGWS -server
  <SGWS-server-1> -container-name <SGWS-bucket-1> -access-key <key>
-secret-password <password> -encrypt
  <true|false> -provider <provider-type> -is-ssl-enabled <true|false>
ipspace
  <IPSpace>
```

```
storage aggregate object-store config create -object-store-name mcc1-
ostore-config-s2
  -provider-type SGWS -server <SGWS-server-2> -container-name <SGWS-
bucket-2> -access-key <key> -secret-password <password> -encrypt
<true|false> -provider <provider-type>
  -is-ssl-enabled <true|false> ipspace <IPSpace>
```

This example sets up FabricPool on the second cluster in the MetroCluster configuration.

```
storage aggregate
  object-store config create -object-store-name mcc2-ostore-config-s1
-provider-type SGWS -server
  <SGWS-server-1> -container-name <SGWS-bucket-3> -access-key <key>
-secret-password <password> -encrypt
  <true|false> -provider <provider-type> -is-ssl-enabled <true|false>
ipspace
  <IPSpace>
```

```
storage aggregate
  object-store config create -object-store-name mcc2-ostore-config-s2
  -provider-type SGWS -server
    <SGWS-server-2> -container-name <SGWS-bucket-4> -access-key <key>
  -secret-password <password> -encrypt
    <true|false> -provider <provider-type> -is-ssl-enabled <true|false>
  ipspace
    <IPSpace>
```

Related information

- [storage object-store config create](#)

Test the ONTAP cloud tier latency and throughput performance

Before you attach an object store to a local tier, you can test the object store's latency and throughput performance by using object store profiler.



Object store profiler results are a measurement of connectivity between ONTAP and the cloud tier object store using 4MB PUTs and random-read byte-ranged GETs ranging from 4MB to 256KB. (Only internal ONTAP features, such as SnapMirror, can make use of GETs larger than 32KB.)

Because they do not account for competing workloads or unique client application behavior, object store profiler results are not a perfect indicator of tiering performance.

Before you begin

- You must add the cloud tier to ONTAP before you can use it with the object store profiler.
- You must be at the ONTAP CLI advanced privilege mode.

Steps

1. Start the object store profiler:

```
storage aggregate object-store profiler start -object-store-name <name> -node
<name>
```

2. View the results:

```
storage aggregate object-store profiler show
```

Related information

- [storage aggregate object-store profiler show](#)
- [storage aggregate object-store profiler start](#)

Associate the ONTAP cloud tier with a local tier

After setting up an object store as the cloud tier, you specify the local tier to use by attaching it to FabricPool. In ONTAP 9.5 and later, you can also attach local tiers that

contain qualified FlexGroup volume constituents.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

About this task

Attaching a cloud tier to a local tier is a permanent action. A cloud tier cannot be unattached from a local tier after being attached. However, you can use [FabricPool mirror](#) to attach a local tier to a different cloud tier.

Before you begin

When you use the ONTAP CLI to set up an local tier for FabricPool, the local tier must already exist.



When you use System Manager to set up a local tier for FabricPool, you can create the local tier and set it up to use for FabricPool at the same time.

Steps

You can attach a local tier to a FabricPool object store with ONTAP System Manager or the ONTAP CLI.

System Manager

1. Navigate to **Storage > Tiers**, select a cloud tier, then click .
2. Select **Attach local tiers**.
3. Under **Add as Primary** verify that the volumes are eligible to attach.
4. If necessary, select **Convert volumes to thin provisioned**.
5. Click **Save**.

CLI

To attach an object store to an aggregate with the CLI:

1. **Optional:** To see how much data in a volume is inactive, follow the steps in [Determining how much data in a volume is inactive by using inactive data reporting](#).

Seeing how much data in a volume is inactive can help you decide which aggregate to use for FabricPool.

2. Attach the object store to an aggregate by using the `storage aggregate object-store attach` command.

If the aggregate has never been used with FabricPool and it contains existing volumes, then the volumes are assigned the default `snapshot-only` tiering policy.

```
cluster1::> storage aggregate object-store attach -aggregate myaggr
-object-store-name Amazon01B1
```

You can use the `allow-flexgroup true` option to attach aggregates that contain FlexGroup volume constituents.

3. Display the object store information and verify that the attached object store is available by using the `storage aggregate object-store show` command.

```
cluster1::> storage aggregate object-store show

Aggregate      Object Store Name      Availability State
-----
myaggr        Amazon01B1             available
```

Related information

- [storage aggregate object-store attach](#)
- [storage aggregate object-store show](#)

Tier data to a local ONTAP S3 bucket

Beginning with ONTAP 9.8, you can tier data to local object storage using ONTAP S3.

Tiering data to a local bucket provides a simple alternative to moving data to a different local tier. This procedure uses either an existing bucket on the local cluster, or you can let ONTAP automatically create a new storage VM and a new bucket.

Keep in mind that once you attach the primary local bucket it cannot be unattached.

Before you begin

- An S3 license is required for this workflow, which creates a new S3 server and new bucket, or uses existing ones. This license is included in [ONTAP One](#). A FabricPool license is not required for this workflow.
- [Enable ONTAP S3 access for local FabricPool tiering](#).

Steps

1. Tier data to a local bucket: click **Storage > Tiers**, in the **SSD** pane, select a local tier, click , and select **Tier to local bucket**.
2. In the **Primary tier** section, choose either **Existing** or **New**.
3. Click **Save**.

Manage FabricPool

Analyze inactive ONTAP data with inactive data reporting

Seeing how much data in a volume is inactive enables you to make good use of storage tiers. Information in inactive data reporting helps you decide which aggregate to use for FabricPool, whether to move a volume in to or out of FabricPool, or whether to modify the tiering policy of a volume.

Before you begin

You must be running ONTAP 9.4 or later to use the inactive data reporting functionality.

About this task

- Inactive data reporting is not supported on some aggregates.

You cannot enable inactive data reporting when FabricPool cannot be enabled, including the following instances:

- Root aggregates
- MetroCluster aggregates running ONTAP versions earlier than 9.7
- Flash Pool (hybrid aggregates, or SnapLock aggregates)
- Inactive data reporting is enabled by default on aggregates where any volumes have adaptive compression enabled.
- Inactive data reporting is enabled by default on all SSD aggregates in ONTAP 9.6.
- Inactive data reporting is enabled by default on FabricPool aggregate in ONTAP 9.4 and ONTAP 9.5.
- You can enable inactive data reporting on non-FabricPool aggregates using the ONTAP CLI, including HDD aggregates, beginning with ONTAP 9.6.

Procedure

You can determine how much data is inactive with ONTAP System Manager or the ONTAP CLI.

System Manager

1. Choose one of the following options:

- When you have existing HDD aggregates, navigate to **Storage > Tiers** and click  for the aggregate on which you want to enable inactive data reporting.
- When no cloud tiers are configured, navigate to **Dashboard** and click the **Enable inactive data reporting** link under **Capacity**.

CLI

To enable inactive data reporting with the CLI:

1. If the aggregate for which you want to see inactive data reporting is not used in FabricPool, enable inactive data reporting for the aggregate by using the `storage aggregate modify` command with the `-is-inactive-data-reporting-enabled true` parameter.

```
cluster1::> storage aggregate modify -aggregate aggr1 -is-inactive
-data-reporting-enabled true
```

You need to explicitly enable the inactive data reporting functionality on an aggregate that is not used for FabricPool.

You cannot and do not need to enable inactive data reporting on a FabricPool-enabled aggregate because the aggregate already comes with inactive data reporting. The `-is-inactive-data-reporting-enabled` parameter does not work on FabricPool-enabled aggregates.

The `-fields is-inactive-data-reporting-enabled` parameter of the `storage aggregate show` command shows whether inactive data reporting is enabled on an aggregate.

2. To display how much data is inactive on a volume, use the `volume show` command with the `-fields performance-tier-inactive-user-data,performance-tier-inactive-user-data-percent` parameter.

```
cluster1::> volume show -fields performance-tier-inactive-user-
data,performance-tier-inactive-user-data-percent

vserver volume performance-tier-inactive-user-data performance-tier-
inactive-user-data-percent
-----
-----
vsim1   vol0   0B                               0%
vs1     vs1rv1 0B                               0%
vs1     vv1    10.34MB                          0%
vs1     vv2    10.38MB                          0%
4 entries were displayed.
```

- The `performance-tier-inactive-user-data` field displays how much user data stored in the aggregate is inactive.

- The `performance-tier-inactive-user-data-percent` field displays what percent of the data is inactive across the active file system and snapshots.
- For an aggregate that is not used for FabricPool, inactive data reporting uses the tiering policy to decide how much data to report as cold.
 - For the `none` tiering policy, 31 days is used.
 - For the `snapshot-only` and `auto`, inactive data reporting uses `tiering-minimum-cooling-days`.
 - For the `ALL` policy, inactive data reporting assumes the data will tier within a day.

Until the period is reached, the output shows “-” for the amount of inactive data instead of a value.
- On a volume that is part of FabricPool, what ONTAP reports as inactive depends on the tiering policy that is set on a volume.
 - For the `none` tiering policy, ONTAP reports the amount of the entire volume that is inactive for at least 31 days. You cannot use the `-tiering-minimum-cooling-days` parameter with the `none` tiering policy.
 - For the `ALL`, `snapshot-only`, and `auto` tiering policies, inactive data reporting is not supported.

Related information

- [storage aggregate modify](#)

Manage volumes for FabricPool

Create a volume on a FabricPool-enabled ONTAP local tier

You can add volumes to FabricPool by creating new volumes directly in the FabricPool-enabled local tier or by moving existing volumes from another local tier to the FabricPool-enabled local tier.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

When you create a volume for FabricPool, you have the option to specify a tiering policy. If no tiering policy is specified, the created volume uses the default `snapshot-only` tiering policy. For a volume with the `snapshot-only` or `auto` tiering policy, you can also specify the tiering minimum cooling period.

Before you begin

- Setting a volume to use the `auto` tiering policy or specifying the tiering minimum cooling period requires ONTAP 9.4 or later.
- Using FlexGroup volumes requires ONTAP 9.5 or later.
- Setting a volume to use the `all` tiering policy requires ONTAP 9.6 or later.
- Setting a volume to use the `-cloud-retrieval-policy` parameter requires ONTAP 9.8 or later.

Steps

1. Create a new volume for FabricPool by using the `volume create` command.

- The `-tiering-policy` optional parameter enables you to specify the tiering policy for the volume.

You can specify one of the following tiering policies:

- `snapshot-only` (default)
- `auto`
- `all`
- `backup` (deprecated)
- `none`

Types of FabricPool tiering policies

- The `-cloud-retrieval-policy` optional parameter enables cluster administrators with the advanced privilege level to override the default cloud migration or retrieval behavior controlled by the tiering policy.

You can specify one of the following cloud retrieval policies:

- `default`

The tiering policy determines what data is pulled back, so there is no change to cloud data retrieval with `default` cloud-retrieval-policy. This means the behavior is the same as in pre-ONTAP 9.8 releases:

- If the tiering policy is `none` or `snapshot-only`, then “default” means that any client-driven data read is pulled from the cloud tier to performance tier.
- If the tiering policy is `auto`, then any client-driven random read is pulled but not sequential reads.
- If the tiering policy is `all` then no client-driven data is pulled from the cloud tier.

- `on-read`

All client-driven data reads are pulled from the cloud tier to performance tier.

- `never`

No client-driven data is pulled from the cloud tier to performance tier

- `promote`

- For tiering policy `none`, all cloud data is pulled from the cloud tier to the performance tier
- For tiering policy `snapshot-only`, all active filesystem data is pulled from the cloud tier to the performance tier.

- The `-tiering-minimum-cooling-days` optional parameter in the advanced privilege level enables you to specify the tiering minimum cooling period for a volume that uses the `snapshot-only` or `auto` tiering policy.

Beginning with ONTAP 9.8, you can specify a value between 2 and 183 for the tiering minimum cooling days. If you are using a version of ONTAP earlier than 9.8, you can specify a value between 2 and 63

for the tiering minimum cooling days.

Example of creating a volume for FabricPool

The following example creates a volume called “myvol1” in the “myFabricPool” FabricPool-enabled local tier. The tiering policy is set to `auto` and the tiering minimum cooling period is set to 45 days:

```
cluster1::*> volume create -vserver myVS -aggregate myFabricPool  
-volume myvol1 -tiering-policy auto -tiering-minimum-cooling-days 45
```

Related information

[FlexGroup volumes management](#)

Move a volume to a FabricPool-enabled ONTAP local tier

A [volume move](#) is the way that ONTAP moves a volume nondisruptively from one local tier (source) to another (destination). Volume moves can be performed for a variety of reasons, although the most common reasons are hardware lifecycle management, cluster expansion, and load balancing.

It is important to understand how volume move works with FabricPool because the changes that take place at both the local tier, the attached cloud tier, and the volume (volume tiering policies) can have a major impact on functionality.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

Destination local tier

If a volume move’s destination local tier does not have an attached cloud tier, data on the source volume that is stored on the cloud tier is written to the local tier on the destination local tier.

Beginning with ONTAP 9.8, when a volume has [inactive data reporting](#) enabled, FabricPool will use the volume’s heat map to immediately queue cold data to begin tiering as soon as it is written to the destination local tier.

Prior to ONTAP 9.8, moving a volume to another local tier resets the inactivity period of blocks on the local tier. For example, a volume using the Auto volume tiering policy with data on the local tier that has been inactive for 20 days, but had not yet tiered, will have the temperature of the data reset to 0 days after a volume move.

Optimized volume moves

Beginning with ONTAP 9.6, if a volume move’s destination local tier uses the same bucket as the source local tier, data on the source volume that is stored in the bucket does not move back to the local tier. Tiered data stays at rest and only hot data needs to be moved from one local tier to another. This optimized volume move results in significant network efficiencies.

For example, a 300TB optimized volume move means that even though 300TB of cold data moves from one local tier to another, it will not trigger 300TB of reads and 300TB of writes to the object store.

Unoptimized volume moves generate additional network and compute traffic (reads/GETs and writes/PUTs), increasing demands on the ONTAP cluster and object store, potentially raising costs when tiering to public object stores.

Some configurations are incompatible with optimized volume moves:



- Changing tiering policy during volume move
- Source and destination local tiers using different encryption keys
- FlexClone volumes
- FlexClone parent volumes
- MetroCluster (supports optimized volume moves in ONTAP 9.8 and later)
- Unsynchronized FabricPool Mirror buckets

If a volume move's destination local tier has an attached cloud tier, data on the source volume that is stored on the cloud tier is first written to the local tier on the destination local tier. It is then written to the cloud tier on the destination local tier if this approach is appropriate for the volume's tiering policy.

Writing data to the local tier first improves the performance of the volume move and reduces cutover time. If a volume tiering policy is not specified when performing a volume move, the destination volume uses the tiering policy of the source volume.

If a different tiering policy is specified when performing the volume move, the destination volume is created with the specified tiering policy and the volume move is not optimized.

Volume metadata

Regardless of whether a volume move is optimized, ONTAP stores a significant amount of metadata about the location, storage efficiency, permissions, usage patterns, etc., of all data, both local and tiered. Metadata always stays on the local tier and is not tiered. When a volume is moved from one local tier to another, this information needs to be moved to the destination local tier as well.

Duration

Volume moves still take time to complete and the expectation should be that an optimized volume move will take approximately the same amount of time as moving an equal amount of non-tiered data.

It is important to understand that "throughput" reported by the `volume move show` command does not represent throughput in terms of data being moved from the cloud tier, but volume data being updated locally.



When in an SVM DR relationship, source and destination volumes must use the same tiering policy.

Steps

1. Use the `volume move start` command to move a volume from a source local tier to a destination local tier.

Example of moving a volume

The following example moves a volume named `myvol2` of `vs1` SVM to `dest_FabricPool`, a FabricPool-enabled local tier.

```
cluster1::> volume move start -vserver vs1 -volume myvol2
-destination-aggregate dest_FabricPool
```

Enable ONTAP volumes in FabricPool to write directly to the cloud

Beginning with ONTAP 9.14.1, you can enable and disable writing directly to the cloud on a new or existing volume in a FabricPool to allow NFS clients to write data directly to the cloud without waiting for tiering scans. SMB clients still write to the performance tier in a cloud write enabled volume. Cloud-write mode is disabled by default.

Having the ability to write directly to the cloud is helpful for cases like migrations, for example, where large amounts of data are transferred to a cluster than the cluster can support on the local tier. Without cloud write mode, during a migration, smaller amounts of data are transferred, then tiered, then transferred and tiered again, until the migration is complete. Using cloud write mode, this type of management is no longer required because the data is never transferred to the local tier.

Before you begin

- You should be a cluster or SVM administrator.
- You must be at the advanced privilege level.
- The volume must be a read-write type volume.
- The volume must have the ALL tiering policy.

Enable writing directly to the cloud during volume creation

Steps

1. Set the privilege level to advanced:

```
set -privilege advanced
```

2. Create a volume and enable cloud write mode:

```
volume create -vserver <svm name> -volume <volume name> -is-cloud-write
-enabled <true|false> -aggregate <local tier name>
```

The following example creates a volume named vol1 with cloud write enabled on the FabricPool local tier (aggr1):

```
volume create -vserver vs1 -volume vol1 -is-cloud-write-enabled true
-aggregate aggr1
```

Enable writing directly to the cloud on an existing volume

Steps

1. Set the privilege level to advanced:

```
set -privilege advanced
```

2. Modify a volume to enable cloud write mode:

```
volume modify -vserver <svm name> -volume <volume name> -is-cloud-write-enabled true
```

The following example modifies the volume named vol1 to enable cloud write:

```
volume modify -vserver vs1 -volume vol1 -is-cloud-write-enabled true
```

Disable writing directly to the cloud on a volume

Steps

1. Set the privilege level to advanced:

```
set -privilege advanced
```

2. Disable cloud write mode on a volume:

```
volume modify -vserver <svm name> -volume <volume name> -is-cloud-write-enabled false
```

The following example disables cloud write mode on the volume named vol1:

```
volume modify -vserver vs1 -volume vol1 -is-cloud-write-enabled false
```

Enable ONTAP volumes in FabricPool to perform aggressive read-aheads

Beginning with ONTAP 9.14.1, you can enable and disable aggressive read-ahead mode on volumes in FabricPools. In ONTAP 9.13.1, aggressive read-ahead mode was introduced only on cloud platforms. Beginning with ONTAP 9.14.1, aggressive read-ahead mode is available on all platforms that FabricPool supports, including on-premises platforms. The feature is disabled by default.

When aggressive read-ahead is *disabled*, FabricPool only reads the file blocks that a client application needs; it does not need to read the entire file. This can result in reduced network traffic, especially for large GB-sized and TB-sized files. *Enabling* aggressive read-ahead on a volume turns this functionality off, and FabricPool preemptively reads the entire file sequentially from the object store, increasing GET throughput and reducing

the latency of client reads on the file. By default, when tiered data is read sequentially it stays cold and is not written to the local tier.

Aggressive read-ahead trades network efficiency for increased performance of tiered data.

About this task

The `aggressive-readahead-mode` command has two options:

- `none`: read-ahead is disabled.
- `file_prefetch`: the system reads the entire file into memory ahead of the client application.

Before you begin

- You should be a cluster or SVM administrator.
- You must be at the advanced privilege level.

Enable aggressive read-ahead mode during volume creation

Steps

1. Set the privilege level to advanced:

```
set -privilege advanced
```

2. Create a volume and enable aggressive read-ahead mode:

```
volume create -volume <volume name> -aggressive-readahead-mode  
<none|file_prefetch>
```

The following example creates a volume named `vol1` with aggressive read-ahead enabled with the `file_prefetch` option:

```
volume create -volume vol1 -aggressive-readahead-mode file_prefetch
```

Disable aggressive read-ahead mode

Steps

1. Set the privilege level to advanced:

```
set -privilege advanced
```

2. Disable aggressive read-ahead mode:

```
volume modify -volume <volume name> -aggressive-readahead-mode none
```

The following example modifies a volume named vol1 to disable aggressive read-ahead mode:

```
volume modify -volume vol1 -aggressive-readahead-mode none
```

View aggressive read-ahead mode on a volume

Steps

1. Set the privilege level to advanced:

```
set -privilege advanced
```

2. View the aggressive read-ahead mode:

```
volume show -fields aggressive-readahead-mode
```

Manage ONTAP FabricPool volumes with user-created custom tags

Beginning with ONTAP 9.8, FabricPool supports object tagging using user-created custom tags to enable you to classify and sort objects for easier management. If you are a user with the admin privilege level, you can create new object tags, and modify, delete, and view existing tags.

Assign a new tag during volume creation

You can create a new object tag when you want to assign one or more tags to new objects that are tiered from a new volume you create. You can use tags to help you classify and sort tiering objects for easier data management. Beginning with ONTAP 9.8, you can use System Manager to create object tags.

About this task

You can set tags only on FabricPool volumes attached to StorageGRID. These tags are retained during a volume move.

- A maximum of four tags per volume is allowed.
- In the CLI, each object tag must be a key-value pair separated by an equal sign.
- In the CLI, multiple tags must be separated by a comma.
- Each tag value can contain a maximum of 127 characters.
- Each tag key must start with either an alphabetic character or an underscore.

Keys must contain only alphanumeric characters and underscores, and the maximum number of characters allowed is 127.

You can assign object tags with ONTAP System Manager or the ONTAP CLI.

Example 1. Steps

System Manager

1. Navigate to **Storage > Tiers**.
2. Locate a storage tier with volumes you want to tag.
3. Click the **Volumes** tab.
4. Locate the volume you want to tag and in the **Object Tags** column select **Click to enter tags**.
5. Enter a key and value.
6. Click **Apply**.

CLI

1. Use the `volume create` command with the `-tiering-object-tags` option to create a new volume with the specified tags. You can specify multiple tags in comma-separated pairs:

```
volume create [ -vserver <vserver name> ] -volume <volume_name>
-tiering-object-tags <key1=value1>
[ ,<key2=value2>,<key3=value3>,<key4=value4> ]
```

The following example creates a volume named `fp_volume1` with three object tags.

```
vol create -volume fp_volume1 -vserver vs0 -tiering-object-tags
project=fabricpool,type=abc,content=data
```

Modify an existing tag

You can change the name of a tag, replace tags on existing objects in the object store, or add a different tag to new objects that you plan to add later.

Example 2. Steps

System Manager

1. Navigate to **Storage > Tiers**.
2. Locate a storage tier with volumes containing tags you want to modify.
3. Click the **Volumes** tab.
4. Locate the volume with tags you want to modify, and in the **Object Tags** column click the tag name.
5. Modify the tag.
6. Click **Apply**.

CLI

1. Use the `volume modify` command with the `-tiering-object-tags` option to modify an existing tag.

```
volume modify [ -vserver <vserver name> ] -volume <volume_name>
-tiering-object-tags <key1=value1> [ ,<key2=value2>,
<key3=value3>,<key4=value4> ]
```

The following example changes the name of the existing tag `type=abc` to `type=xyz`.

```
vol modify -volume fp_volume1 -vserver vs0 -tiering-object-tags
project=fabricpool,type=xyz,content=data
```

Delete a tag

You can delete object tags when you no longer want them set on a volume or on objects in the object store.

Example 3. Steps

System Manager

1. Navigate to **Storage > Tiers**.
2. Locate a storage tier with volumes containing tags you want to delete.
3. Click the **Volumes** tab.
4. Locate the volume with tags you want to delete, and in the **Object Tags** column click the tag name.
5. To delete the tag, click the trash can icon.
6. Click **Apply**.

CLI

1. Use the `volume modify` command with the `-tiering-object-tags` option followed by an empty value ("") to delete an existing tag.

The following example deletes the existing tags on `fp_volume1`.

```
vol modify -volume fp_volume1 -vserver vs0 -tiering-object-tags ""
```

View existing tags on a volume

You can view the existing tags on a volume to see what tags are available before appending new tags to the list.

Steps

1. Use the `volume show` command with the `tiering-object-tags` option to view existing tags on a volume.

```
volume show [ -vserver <vserver name> ] -volume <volume_name> -fields  
tiering-object-tags
```

Check object tagging status on FabricPool volumes

You can check if tagging is complete on one or more FabricPool volumes.

Steps

1. Use the `vol show` command with the `-fields needs-object-retagging` option to see if tagging is in progress, if it has completed, or if tagging is not set.

```
vol show -fields needs-object-retagging [ -instance | -volume <volume  
name>]
```

One of the following values is displayed:

- `true`: the object tagging scanner has not yet to run or needs to run again for this volume
- `false`: the object tagging scanner has completed tagging for this volume
- `<->`: the object tagging scanner is not applicable for this volume. This happens for volumes that are not residing on FabricPools.

Monitor space utilization of a FabricPool-enabled ONTAP local tier

You need to know how much data is stored in the performance and cloud tiers for FabricPool. That information helps you determine whether you need to change the tiering policy of a volume, increase the FabricPool licensed usage limit, or increase the storage space of the cloud tier.



Prior to ONTAP 9.7, System Manager uses the term *aggregate* to describe a *local tier*. Regardless of your ONTAP version, the ONTAP CLI uses the term *aggregate*. To learn more about local tiers, see [Disks and local tiers](#).

About this task

Beginning with ONTAP 9.18.1, the `storage aggregate show-space` command changes how Logical Referenced Capacity and Logical Unreferenced Capacity is reported. Logical Referenced Capacity reports referenced blocks in all objects and unreferenced blocks in fragmented objects. Logical Unreferenced Capacity reports only unreferenced blocks in objects that have crossed the fullness threshold and are eligible for object deletion and defragmentation.

For example, when you use the default aggregate fullness threshold of 40% for ONTAP S3 and StorageGRID, 60% of the blocks in an object must be unreferenced before the blocks are reported as unreferenced capacity.

In releases earlier than ONTAP 9.18.1, Logical Referenced Capacity reports referenced blocks in all objects (both full and fragmented objects). Logical Unreferenced Capacity reports unreferenced blocks in all objects.

Steps

1. Monitor the space utilization for FabricPool-enabled local tiers by using one of the following commands to display the information:

If you want to display...	Then use this command:
The used size of the cloud tier in a local tier	<code>storage aggregate show</code> with the <code>-instance</code> parameter
Details of space utilization within an local tiers, including the object store's referenced capacity	<code>storage aggregate show-space</code> with the <code>-instance</code> parameter
Space utilization of the object stores that are attached to the local tiers, including how much license space is being used	<code>storage aggregate object-store show-space</code>
A list of volumes in a local tier and the footprints of their data and metadata	<code>volume show-footprint</code>

In addition to using CLI commands, you can use Active IQ Unified Manager (formerly OnCommand Unified

Manager), along with FabricPool Advisor, which is supported on ONTAP 9.4 and later clusters, or System Manager to monitor the space utilization.

The following example shows ways of displaying space utilization and related information for FabricPool:

```
cluster1::> storage aggregate show-space -instance

Aggregate: MyFabricPool
...
Aggregate Display Name:
MyFabricPool
...
Total Object Store Logical Referenced
Capacity: -
Object Store Logical Referenced Capacity
Percentage: -
...
Object Store
Size: -
Object Store Space Saved by Storage
Efficiency: -
Object Store Space Saved by Storage Efficiency
Percentage: -
Total Logical Used
Size: -
Logical Used
Percentage: -
Logical Unreferenced
Capacity: -
Logical Unreferenced
Percentage: -
```

```
cluster1::> storage aggregate show -instance

Aggregate: MyFabricPool
...
Composite: true
Capacity Tier Used Size:
...
```

```

cluster1::> volume show-footprint

Vserver : vs1
Volume  : rootvol

Feature                               Used      Used%
-----
Volume Footprint                      KB        %
Volume Guarantee                      MB        %
Flexible Volume Metadata              KB        %
Delayed Frees                         KB        %
Total Footprint                       MB        %

Vserver : vs1
Volume  : vol

Feature                               Used      Used%
-----
Volume Footprint                      KB        %
Footprint in Performance Tier         KB        %
Footprint in Amazon01                KB        %
Flexible Volume Metadata              MB        %
Delayed Frees                         KB        %
Total Footprint                       MB        %
...

```

2. Take one of the following actions as needed:

If you want to...	Then...
Change the tiering policy of a volume	Follow the procedure in Managing storage tiering by modifying a volume's tiering policy or tiering minimum cooling period.
Increase the FabricPool licensed usage limit	Contact your NetApp or partner sales representative. NetApp Support
Increase the storage space of the cloud tier	Contact the provider of the object store that you use for the cloud tier.

Related information

- [storage aggregate object](#)
- [storage aggregate show](#)

- [storage aggregate show-space](#)

Modify an ONTAP volume's tiering policy and minimum cooling period

You can change the tiering policy of a volume to control whether data is moved to the cloud tier when it becomes inactive (*cold*). For a volume with the `snapshot-only` or `auto` tiering policy, you can also specify the tiering minimum cooling period that user data must remain inactive before it is moved to the cloud tier.

Before you begin

Changing a volume to the `auto` tiering policy or modifying the tiering minimum cooling period requires ONTAP 9.4 or later.

About this task

Changing the tiering policy of a volume changes only the subsequent tiering behavior for the volume. It does not retroactively move data to the cloud tier.

Changing the tiering policy might affect how long it takes for data to become cold and be moved to the cloud tier.

What happens when you modify the tiering policy of a volume in FabricPool



When in an SVM DR relationship, source and destination volumes do not need to use FabricPool aggregates, but they must use the same tiering policy.

Steps

1. Modify the tiering policy for an existing volume by using the `volume modify` command with the `-tiering-policy` parameter:

You can specify one of the following tiering policies:

- `snapshot-only` (default)
- `auto`
- `all`
- `none`

Types of FabricPool tiering policies

2. If the volume uses the `snapshot-only` or `auto` tiering policy and you want to modify the tiering minimum cooling period, use the `volume modify` command with the `-tiering-minimum-cooling-days` optional parameter in the advanced privilege level.

You can specify a value between 2 and 183 for the tiering minimum cooling days. If you are using a version of ONTAP earlier than 9.8, you can specify a value between 2 and 63 for the tiering minimum cooling days.

Example of modifying the tiering policy and the tiering minimum cooling period of a volume

The following example changes the tiering policy of the volume "myvol" in the SVM "vs1" to `auto` and the tiering minimum cooling period to 45 days:

```
cluster1::> volume modify -vserver vs1 -volume myvol
-tiering-policy auto -tiering-minimum-cooling-days 45
```

Archive volumes with FabricPool (video)

This video shows a quick overview of using System Manager to archive a volume to a cloud tier with FabricPool.

[NetApp video: Archiving volumes with FabricPool \(backup + volume move\)](#)

Related information

[NetApp TechComm TV: FabricPool playlist](#)

Modify an ONTAP volume's default FabricPool tiering policy

You can change a volume's default tiering policy for controlling user data retrieval from the cloud tier to performance tier by using the `-cloud-retrieval-policy` option introduced in ONTAP 9.8.

Before you begin

- Modifying a volume using the `-cloud-retrieval-policy` option requires ONTAP 9.8 or later.
- You must have the advanced privilege level to perform this operation.
- You should understand the behavior of tiering policies with `-cloud-retrieval-policy`.

[How tiering policies work with cloud migration](#)

Step

1. Modify the tiering policy behavior for an existing volume by using the `volume modify` command with the `-cloud-retrieval-policy` option:

```
volume create -volume <volume_name> -vserver <vserver_name> - tiering-
policy <policy_name> -cloud-retrieval-policy
```

```
vol modify -volume fp_volume4 -vserver vs0 -cloud-retrieval-policy
promote
```

Set thresholds on ONTAP FabricPool per-node put rate

As a storage admin, you can use PUT throttling to set an upper threshold on the maximum per-node put rate.

PUT throttling is useful when network resources or the object store endpoint are resource constrained. Although rare, resource constraints can occur with underpowered object stores or during the first days of FabricPool usage when TB or PB of cold data begins to tier out.

PUT throttling is per node. The minimum PUT throttling `put-rate-limit` is 8MB/s. Setting the `put-rate-limit` to a value less than 8MB/s will result in 8MB/s throughput on that node. Multiple nodes, tiering concurrently, might consume more bandwidth and potentially saturate a network link with extremely limited capacity.



FabricPool PUT operations do not compete for resources with other applications. FabricPool PUT operations are automatically placed at a lower priority ("bullied") by client applications and other ONTAP workloads, such as SnapMirror. PUT throttling using `put-rate-limit` might be useful for reducing network traffic associated with FabricPool tiering, but it is unrelated to concurrent ONTAP traffic.

Before you begin

Advanced privilege level is required.

Steps

1. Throttle FabricPool PUT operations using the ONTAP CLI:

```
storage aggregate object-store put-rate-limit modify -node <name>
-default <true|false> -put-rate-bytes-limit <integer>[KB|MB|GB|TB|PB]
```

Related information

- [storage aggregate object-store put-rate-limit modify](#)

Customize ONTAP FabricPool object deletion and defragmentation

FabricPool does not delete blocks from attached object stores. Instead, FabricPool deletes objects after a certain percentage of the blocks in the object are no longer referenced by ONTAP.

For example, there are 1,024 4KB blocks in a 4MB object tiered to Amazon S3. Defragmentation and deletion do not occur until less than 205 4KB blocks (20% of 1,024) are being referenced by ONTAP. When enough (1,024) blocks have zero references, their original 4MB objects are deleted, and a new object is created.

You can customize the unreclaimed space threshold percentage and set it to different default levels for different object stores. The default settings are:

Object Store	ONTAP 9.8 and later	ONTAP 9.7 to 9.4	ONTAP 9.3 and earlier	Cloud Volumes ONTAP
Amazon S3	20%	20%	0%	30%
Google Cloud Storage	20%	12%	n/a	35%
Microsoft Azure Blob Storage	25%	15%	n/a	35%
NetApp ONTAP S3	40%	n/a	n/a	n/a

NetApp StorageGRID	40%	40%	0%	n/a
--------------------	-----	-----	----	-----

Unreclaimed space threshold

Changing the default unreclaimed space threshold settings will increase or decrease the accepted amount of object fragmentation. Reducing fragmentation will reduce the amount of physical capacity used by the cloud tier at the expense of additional object store resources (reads and writes).

Threshold reduction

To avoid additional expenses, consider reducing the unreclaimed space thresholds when using object store pricing schemes that reduce the cost of storage but increase the cost of reads. Examples include Amazon's Standard-IA and Azure Blob Storage's Cool.

For example, tiering a volume of 10-year-old projects that has been saved for legal reasons might be less expensive when using a pricing scheme such as Standard-IA or Cool than it would be when using standard pricing schemes. Although reads are more expensive for such a volume, including reads required by object defragmentation, they are unlikely to occur frequently.

Threshold increases

Alternatively, consider increasing unreclaimed space thresholds if object fragmentation causes significantly more object store capacity to be used than necessary for the data being referenced by ONTAP. For example, using an unreclaimed space threshold of 20% in a worst-case scenario where all objects are equally fragmented to the maximum allowable extent means that it is possible for 80% of total capacity in the cloud tier to be unreferenced by ONTAP. For example:

2TB referenced by ONTAP + 8TB unreferenced by ONTAP = 10TB total capacity used by the cloud tier.

In this situation, it might be advantageous to increase the unreclaimed space threshold or increase volume minimum cooling days to reduce the capacity used by unreferenced blocks.



As the system defragments objects and increases their storage efficiency, it might fragment the underlying files by writing referenced blocks to new, more efficient objects. If you significantly increase the unreclaimed space threshold, you can create objects that are more storage efficient but have reduced sequential read performance.

This additional activity results in increased costs from third party S3 providers, such as AWS, Azure, and Google.

NetApp recommends avoiding increasing the unreclaimed space threshold above 60%.

Change the unreclaimed space threshold

You can customize the unreclaimed space threshold percentage for different object stores.

Before you begin

Advanced privilege level is required.

Steps

1. To change the default unreclaimed space threshold, customize and run the following command:

```
storage aggregate object-store modify -aggregate <name> -object-store
-name <name> -unreclaimed-space-threshold <%> (0%-99%)
```

Related information

- [storage aggregate object-store modify](#)

Promote ONTAP data to the performance tier

Beginning with ONTAP 9.8, if you are a cluster administrator at the advanced privilege level, you can proactively promote data to the performance tier from the cloud tier using a combination of the `tiering-policy` and the `cloud-retrieval-policy` setting.

About this task

You might do this if you want to stop using FabricPool on a volume, or if you have a `snapshot-only` tiering policy and you want to bring restored snapshot data back to the performance tier.

Promote all data from a FabricPool volume to the performance tier

You can proactively retrieve all data on a FabricPool volume in the cloud tier and promote it to the performance tier.

Steps

1. Use the `volume modify` command to set `tiering-policy` to `none` and `cloud-retrieval-policy` to `promote`.

```
volume modify -vserver <vserver-name> -volume <volume-name> -tiering
-policy none -cloud-retrieval-policy promote
```

Promote file system data to the performance tier

You can proactively retrieve active file system data from a restored snapshot in the cloud tier and promote it to the performance tier.

Steps

1. Use the `volume modify` command to set `tiering-policy` to `snapshot-only` and `cloud-retrieval-policy` to `promote`.

```
volume modify -vserver <vserver-name> -volume <volume-name> -tiering
-policy snapshot-only cloud-retrieval-policy promote
```

Check the status of a performance tier promotion

You can check the status of performance tier promotion to determine when the operation is complete.

Steps

1. Use the `volume object-store tiering show` command with the `tiering` option to check the status of the performance tier promotion.

```
volume object-store tiering show [ -instance | -fields <fieldname>, ...
] [ -vserver <vserver name> ] *Vserver
[[-volume] <volume name>] *Volume [ -node <nodename> ] *Node Name [ -vol
-dsid <integer> ] *Volume DSID
[ -aggregate <aggregate name> ] *Aggregate Name
```

```
volume object-store tiering show v1 -instance

                Vserver: vs1
                Volume: v1
                Node Name: node1
                Volume DSID: 1023
                Aggregate Name: a1
                State: ready
                Previous Run Status: completed
                Aborted Exception Status: -
                Time Scanner Last Finished: Mon Jan 13 20:27:30 2020
                Scanner Percent Complete: -
                Scanner Current VBN: -
                Scanner Max VBNs: -
                Time Waiting Scan will be scheduled: -
                Tiering Policy: snapshot-only
                Estimated Space Needed for Promotion: -
                Time Scan Started: -
                Estimated Time Remaining for scan to complete: -
                Cloud Retrieve Policy: promote
```

Trigger scheduled migration and tiering

Beginning with ONTAP 9.8, you can trigger a tiering scan request at any time when you prefer not to wait for the default tiering scan.

Steps

1. Use the `volume object-store tiering trigger` command with the `trigger` option to request migration and tiering.

```
volume object-store tiering trigger [ -vserver <vserver name> ] *VServer
Name [-volume] <volume name> *Volume Name
```

Manage FabricPool mirrors

Learn about ONTAP FabricPool mirrors

To ensure data is accessible in data stores in the event of a disaster, and to enable you to replace a data store, you can configure a FabricPool mirror by adding a second data store to synchronously tier data to two data stores. You can add a second data store to new or existing FabricPool configurations, monitor the mirror status, display FabricPool mirror details, promote a mirror, and remove a mirror. You must be running ONTAP 9.7 or later.

Create an ONTAP FabricPool mirror

To create a FabricPool mirror, you attach two object stores to a single FabricPool. You can create a FabricPool mirror either by attaching a second object store to an existing, single object store FabricPool configuration, or you can create a new, single object store FabricPool configuration and then attach a second object store to it. You can also create FabricPool mirrors on MetroCluster configurations.

Before you begin

- You must have already created the two object stores using the `storage aggregate object-store config` command.
- If you are creating FabricPool mirrors on MetroCluster configurations:
 - You must have already set up and configured the MetroCluster
 - You must have created the object store configurations on the selected cluster.

If you are creating FabricPool mirrors on both clusters in a MetroCluster configuration, you must have created object store configurations on both of the clusters.

- If you are not using on premises object stores for MetroCluster configurations, you should ensure that one of the following scenarios exists:
 - Object stores are in different availability zones
 - Object stores are configured to keep copies of objects in multiple availability zones

[Setting up object stores for FabricPool in a MetroCluster configuration](#)

About this task

The object store you use for the FabricPool mirror must be different from the primary object store.

The procedure for creating a FabricPool mirror is the same for both MetroCluster and non-MetroCluster configurations.

Steps

1. If you are not using an existing FabricPool configuration, create a new one by attaching an object store to an local tier using the `storage aggregate object-store attach` command.

This example creates a new FabricPool by attaching an object store to an local tier.

```
cluster1::> storage aggregate object-store attach -aggregate aggr1 -name my-store-1
```

2. Attach a second object store to the local tier using the `storage aggregate object-store mirror` command.

This example attaches a second object store to an local tier to create a FabricPool mirror.

```
cluster1::> storage aggregate object-store mirror -aggregate aggr1 -name my-store-2
```

Related information

- [storage aggregate object-store attach](#)
- [storage aggregate object-store config](#)
- [storage aggregate object-store mirror](#)

Display ONTAP FabricPool mirror details

You can display details about a FabricPool mirror to see what object stores are in the configuration and whether the object store mirror is in sync with the primary object store.

Step

1. Display information about a FabricPool mirror using the `storage aggregate object-store show` command.

This example displays the details about the primary and mirror object stores in a FabricPool mirror.

```
cluster1::> storage aggregate object-store show
```

Aggregate	Object Store Name	Availability	Mirror Type
aggr1	my-store-1	available	primary
	my-store-2	available	mirror

This example displays details about the FabricPool mirror, including whether the mirror is degraded due to a resync operation.

```
cluster1::> storage aggregate object-store show -fields mirror-type,is-mirror-degraded
```

```

aggregate      object-store-name mirror-type      is-mirror-degraded
-----
aggr1          my-store-1         primary          -
               my-store-2         mirror           false

```

Related information

- [storage aggregate object-store show](#)

Promote an ONTAP FabricPool mirror

You can reassign the object store mirror as the primary object store by promoting it. When the object store mirror becomes the primary, the original primary automatically becomes the mirror.

Before you begin

- The FabricPool mirror must be in sync
- The object store must be operational

About this task

You can replace the original object store with an object store from a different cloud provider. For instance, your original mirror might be an AWS object store, but you can replace it with an Azure object store.

Steps

1. Verify that the FabricPool mirror is in sync using the `storage aggregate object-store show-resync-status` command. If the FabricPool mirror is in sync, no entries are displayed. If the mirror is not in sync, wait for the resync to complete.

```

cluster1::> storage aggregate object-store show-resync-status
-aggregate aggr1

```

```

Aggregate      Primary      Mirror      Complete
-----
aggr1          my-store-1   my-store-2   Percentage
               my-store-2   my-store-2   40%

```

2. Promote an object store mirror by using the `storage aggregate object-store modify -aggregate` command.

```

cluster1::> storage aggregate object-store modify -aggregate aggr1 -name
my-store-2 -mirror-type primary

```

Related information

- [storage aggregate object-store modify](#)
- [storage aggregate object-store show-resync-status](#)

Remove an ONTAP FabricPool mirror

You can remove a FabricPool mirror if you no longer need to replicate an object store.

Before you begin

The primary object store must be operational; otherwise, the command fails.

Step

1. Remove an object store mirror in a FabricPool by using the `storage aggregate object-store unmirror -aggregate` command.

```
cluster1::> storage aggregate object-store unmirror -aggregate aggr1
```

Related information

- [storage aggregate object-store unmirror](#)

Replace an existing object store with an ONTAP FabricPool mirror

You can use FabricPool mirror technology to replace one object store with another one. The new object store does not have to use the same cloud provider as the original object store.

About this task

You can replace the original object store with an object store that uses a different cloud provider. For instance, your original object store might use AWS as the cloud provider, but you can replace it with an object store that uses Azure as the cloud provider, and vice versa. However, the new object store must retain the same object size as the original.

Steps

1. Create a FabricPool mirror by adding a new object store to an existing FabricPool using the `storage aggregate object-store mirror` command.

```
cluster1::> storage aggregate object-store mirror -aggregate aggr1  
-object-store-name my-AZURE-store
```

2. Monitor the mirror resync status using the `storage aggregate object-store show-resync-status` command.

```
cluster1::> storage aggregate object-store show-resync-status -aggregate  
aggr1
```

Aggregate	Primary	Mirror	Complete Percentage
-----	-----	-----	-----
aggr1	my-AWS-store	my-AZURE-store	40%

3. Verify the mirror is in sync using the `storage aggregate object-store> show -fields mirror-type, is-mirror-degraded` command.

```
cluster1::> storage aggregate object-store show -fields mirror-type, is-mirror-degraded
```

aggregate	object-store-name	mirror-type	is-mirror-degraded
-----	-----	-----	-----
aggr1	my-AWS-store	primary	-
	my-AZURE-store	mirror	false

4. Swap the primary object store with the mirror object store using the `storage aggregate object-store modify` command.

```
cluster1::> storage aggregate object-store modify -aggregate aggr1 -object-store-name my-AZURE-store -mirror-type primary
```

5. Display details about the FabricPool mirror using the `storage aggregate object-store show -fields mirror-type, is-mirror-degraded` command.

This example displays the information about the FabricPool mirror, including whether the mirror is degraded (not in sync).

```
cluster1::> storage aggregate object-store show -fields mirror-type, is-mirror-degraded
```

aggregate	object-store-name	mirror-type	is-mirror-degraded
-----	-----	-----	-----
aggr1	my-AZURE-store	primary	-
	my-AWS-store	mirror	false

6. Remove the FabricPool mirror using the `storage aggregate object-store unmirror` command.

```
cluster1::> storage aggregate object-store unmirror -aggregate aggr1
```

7. Verify that the FabricPool is back in a single object store configuration using the `storage aggregate object-store show -fields mirror-type,is-mirror-degraded` command.

```
cluster1::> storage aggregate object-store show -fields mirror-type,is-  
mirror-degraded
```

aggregate	object-store-name	mirror-type	is-mirror-degraded
aggr1	my-AZURE-store	primary	-

Related information

- [storage aggregate object-store mirror](#)
- [storage aggregate object-store modify](#)
- [storage aggregate object-store show-resync-status](#)
- [storage aggregate object-store show](#)
- [storage aggregate object-store unmirror](#)

Replace a FabricPool mirror in an ONTAP MetroCluster configuration

If one of the object stores in a FabricPool mirror is destroyed or becomes permanently unavailable on a MetroCluster configuration, you can make the object store the mirror if it is not the mirror already, remove the damaged object store from FabricPool mirror, and then add a new object store mirror to the FabricPool.

Steps

1. If the damaged object store is not already the mirror, make the object store the mirror with the `storage aggregate object-store modify` command.

```
storage aggregate object-store modify -aggregate -aggregate fp_aggr1_A01  
-name mccl_ostore1 -mirror-type mirror
```

2. Remove the object store mirror from the FabricPool by using the `storage aggregate object-store unmirror` command.

```
storage aggregate object-store unmirror -aggregate <aggregate name>  
-name mccl_ostore1
```

3. You can force tiering to resume on the primary data store after you remove the mirror data store by using the `storage aggregate object-store modify` with the `-force-tiering-on-metrocluster true` option.

The absence of a mirror interferes with the replication requirements of a MetroCluster configuration.

```
storage aggregate object-store modify -aggregate <aggregate name> -name
mcc1_ostore1 -force-tiering-on-metrocluster true
```

4. Create a replacement object store by using the `storage aggregate object-store config create` command.

```
storage aggregate object-store config create -object-store-name
mcc1_ostore3 -cluster clusterA -provider-type SGWS -server <SGWS-server-
1> -container-name <SGWS-bucket-1> -access-key <key> -secret-password
<password> -encrypt <true|false> -provider <provider-type> -is-ssl
-enabled <true|false> ipspace <IPSpace>
```

5. Add the object store mirror to the FabricPool mirror using the `storage aggregate object-store mirror` command.

```
storage aggregate object-store mirror -aggregate aggr1 -name
mcc1_ostore3-mc
```

6. Display the object store information using the `storage aggregate object-store show` command.

```
storage aggregate object-store show -fields mirror-type,is-mirror-
degraded
```

aggregate	object-store-name	mirror-type	is-mirror-degraded
aggr1	mcc1_ostore1-mc	primary	-
	mcc1_ostore3-mc	mirror	true

7. Monitor the mirror resync status using the `storage aggregate object-store show-resync-status` command.

```
storage aggregate object-store show-resync-status -aggregate aggr1
```

Aggregate	Primary	Mirror	Complete Percentage
aggr1	mcc1_ostore1-mc	mcc1_ostore3-mc	40%

Related information

- [storage aggregate object-store config create](#)
- [storage aggregate object-store mirror](#)
- [storage aggregate object-store modify](#)
- [storage aggregate object-store show](#)
- [storage aggregate object-store show-resync-status](#)
- [storage aggregate object-store unmirror](#)

ONTAP commands for managing FabricPool resources

You use the `storage aggregate object-store` commands to manage object stores for FabricPool. You use the `storage aggregate` commands to manage aggregates for FabricPool. You use the `volume` commands to manage volumes for FabricPool.

If you want to...	Use this command:
Define the configuration for an object store so that ONTAP can access it	<code>storage aggregate object-store config create</code>
Modify object store configuration attributes	<code>storage aggregate object-store config modify</code>
Rename an existing object store configuration	<code>storage aggregate object-store config rename</code>
Delete the configuration of an object store	<code>storage aggregate object-store config delete</code>
Display a list of object store configurations	<code>storage aggregate object-store config show</code>
Attach a second object store to a new or existing FabricPool as a mirror	<code>storage aggregate object-store mirror</code> with the <code>-aggregate</code> and <code>-name</code> parameter in the admin privilege level
Remove an object store mirror from an existing FabricPool mirror	<code>storage aggregate object-store unmirror</code> with the <code>-aggregate</code> and <code>-name</code> parameter in the admin privilege level
Monitor FabricPool mirror resync status	<code>storage aggregate object-store show-resync-status</code>
Display FabricPool mirror details	<code>storage aggregate object-store show</code>

Promote an object store mirror to replace a primary object store in a FabricPool mirror configuration	<code>storage aggregate object-store modify with the -aggregate parameter in the admin privilege level</code>
Test the latency and performance of an object store without attaching the object store to an aggregate	<code>storage aggregate object-store profiler start with the -object-store-name and -node parameter in the advanced privilege level</code>
Monitor the object store profiler status	<code>storage aggregate object-store profiler show with the -object-store-name and -node parameter in the advanced privilege level</code>
Abort the object store profiler when it is running	<code>storage aggregate object-store profiler abort with the -object-store-name and -node parameter in the advanced privilege level</code>
Attach an object store to an aggregate for using FabricPool	<code>storage aggregate object-store attach</code>
Attach an object store to an aggregate that contains a FlexGroup volume for using FabricPool	<code>storage aggregate object-store attach with the allow-flexgroup true</code>
Display details of the object stores that are attached to FabricPool-enabled aggregates	<code>storage aggregate object-store show</code>
Display the aggregate fullness threshold used by the tiering scan	<code>storage aggregate object-store show with the -fields tiering-fullness-threshold parameter in the advanced privilege level</code>
Display space utilization of the object stores that are attached to FabricPool-enabled aggregates	<code>storage aggregate object-store show-space</code>
Enable inactive data reporting on an aggregate that is not used for FabricPool	<code>storage aggregate modify with the -is -inactive-data-reporting-enabled true parameter</code>
Display whether inactive data reporting is enabled on an aggregate	<code>storage aggregate show with the -fields is-inactive-data-reporting-enabled parameter</code>
Display information about how much user data is cold within an aggregate	<code>storage aggregate show-space with the -fields performance-tier-inactive-user-data,performance-tier-inactive-user-data-percent parameter</code>

<p>Create a volume for FabricPool, including specifying the following:</p> <ul style="list-style-type: none"> • The tiering policy • The tiering minimum cooling period (for the <code>snapshot-only</code> or <code>auto</code> tiering policy) 	<p><code>volume create</code></p> <ul style="list-style-type: none"> • You use the <code>-tiering-policy</code> parameter to specify the tiering policy. • You use the <code>-tiering-minimum-cooling-days</code> parameter in the advanced privilege level to specify the tiering minimum cooling period.
<p>Modify a volume for FabricPool, including modifying the following:</p> <ul style="list-style-type: none"> • The tiering policy • The tiering minimum cooling period (for the <code>snapshot-only</code> or <code>auto</code> tiering policy) 	<p><code>volume modify</code></p> <ul style="list-style-type: none"> • You use the <code>-tiering-policy</code> parameter to specify the tiering policy. • You use the <code>-tiering-minimum-cooling-days</code> parameter in the advanced privilege level to specify the tiering minimum cooling period.
<p>Display FabricPool information related to a volume, including the following:</p> <ul style="list-style-type: none"> • The tiering minimum cooling period • How much user data is cold 	<p><code>volume show</code></p> <ul style="list-style-type: none"> • You use the <code>-fields tiering-minimum-cooling-days</code> parameter in the advanced privilege level to display the tiering minimum cooling period. • You use the <code>-fields performance-tier-inactive-user-data,performance-tier-inactive-user-data-percent</code> parameter to display how much user data is cold.
<p>Move a volume in to or out of FabricPool</p>	<p><code>volume move start</code> You use the <code>-tiering-policy</code> optional parameter to specify the tiering policy for the volume.</p>
<p>Modify the threshold for reclaiming unreferenced space (the defragmentation threshold) for FabricPool</p>	<p><code>storage aggregate object-store modify</code> with the <code>-unreclaimed-space-threshold</code> parameter in the advanced privilege level</p>
<p>Modify the threshold for the percent full the aggregate becomes before the tiering scan begins tiering data for FabricPool</p> <p>FabricPool continues to tier cold data to a cloud tier until the local tier reaches 98% capacity.</p>	<p><code>storage aggregate object-store modify</code> with the <code>-tiering-fullness-threshold</code> parameter in the advanced privilege level</p>
<p>Display the threshold for reclaiming unreferenced space for FabricPool</p>	<p><code>storage aggregate object-store show</code> or <code>storage aggregate object-store show-space</code> command with the <code>-unreclaimed-space-threshold</code> parameter in the advanced privilege level</p>

Related information

- [storage aggregate modify](#)
- [storage aggregate object](#)
- [storage aggregate show-space](#)

SVM data mobility

Learn about ONTAP SVM data mobility

Beginning with ONTAP 9.10.1, cluster administrators can non-disruptively relocate an SVM from a source cluster to a destination cluster to manage capacity and load balancing, or to enable equipment upgrades or data center consolidations.


Non-disruptive SVM relocation is supported on AFF systems in ONTAP 9.10.1 and 9.11.1. Beginning with ONTAP 9.12.1, this capability is supported on both FAS and AFF systems and on hybrid aggregates.

The SVM's name and UUID remain unchanged after migration, as well as the data LIF name, IP address, and object names, such as the volume name. The UUID of the objects in the SVM will be different.

Beginning with ONTAP 9.18.1, SVM migration is supported from ASA storage systems to ASA r2 storage systems. If you have an ASA r2 storage system (ASAA1K, ASAA90, ASAA70, ASAA50, ASAA30, ASAA20, or ASA C30) and you would like to migrate an SVM to your ASA r2 system from an ASA system, follow [these steps](#).

SVM migration workflow

The diagram depicts the typical workflow for an SVM migration. You start an SVM migration from the destination cluster. You can monitor the migration from either the source or the destination. You can perform a manual cutover or an automatic cutover. An automatic cutover is performed by default.



SVM migration system support

Controller family	ONTAP versions supported
ASA	ONTAP 9.18.1 and later Follow these steps for SVM migration from ASA to ASA r2 systems.
AFF C-series	ONTAP 9.12.1 patch 4 and later
FAS	ONTAP 9.12.1 and later
AFF A-series	ONTAP 9.10.1 and later



When migrating from an AFF cluster to a FAS cluster with hybrid aggregates, auto volume placement attempts to perform a like-to-like aggregate match. For example, if the source cluster has 60 volumes, the volume placement tries to find an AFF aggregate on the destination to place the volumes. When there is not sufficient space on the AFF aggregates, the volumes are placed on aggregates with non-flash disks.

Scalability support by ONTAP version

ONTAP version	HA pairs in source and destination
ONTAP 9.14.1 and later	12
ONTAP 9.13.1	6
ONTAP 9.11.1	3

ONTAP 9.10.1	1
--------------	---

Network infrastructure performance requirements for TCP round trip time (RTT) between the source and the destination cluster

Depending on the ONTAP version installed on the cluster, the network connecting the source and destination clusters must have a maximum round trip time as indicated:

ONTAP version	Maximum RTT
ONTAP 9.12.1 and later	10 ms
ONTAP 9.11.1 and earlier	2 ms

Maximum supported volumes per SVM



The maximum number of volumes that you can migrate per SVM in a mixed or hybrid cluster is based on the cluster member that supports the lower number of volumes.

Source	Destination	ONTAP 9.14.1 and later	ONTAP 9.13.1	ONTAP 9.12.1	ONTAP 9.11.1 and earlier
AFF	AFF	400	200	100	100
FAS	FAS	80	80	80	N/A
FAS	AFF	80	80	80	N/A
AFF	FAS	80	80	80	N/A

Prerequisites

Before initiating an SVM migration, you must meet the following prerequisites:

- You are a cluster administrator.
- [The source and destination clusters are peered to each other.](#)
- The source and destination clusters have the SnapMirror synchronous [license installed](#). This license is included with [ONTAP One](#).
- All nodes in the source cluster are running ONTAP 9.10.1 or later. For specific ONTAP array controller support, see [Hardware Universe](#).
- All nodes in the source cluster are running the same ONTAP version.
- All nodes in the destination cluster are running the same ONTAP version.
- The destination cluster ONTAP version is at the same or no more than two major newer versions as the source cluster.
- The source and destination clusters support the same IP subnet for data LIF access.
- Both the source and destination clusters must have at least one interface that has access to all the migrating SVM's networks, otherwise the migration precheck will fail.
- The source SVM contains fewer than the [maximum number of supported data volumes for the release](#).
- Sufficient space for volume placement is available on the destination.

- The Onboard Key Manager or external key management is configured at the cluster level on the destination if the source SVM has encrypted volumes.
 - In this case, key managers configured at the SVM level on the source do not migrate to the destination. The destination uses the cluster-level key manager.
- If the source has encrypted volumes and is configured for NetApp Aggregate Encryption (NAE), the destination must also be configured for NAE.
- If you are migrating an SVM between a non-MetroCluster configuration and a MetroCluster configuration, or between two MetroCluster configurations, verify that your configuration meets the following requirements:



Migrating an SVM between the local and partner cluster in a MetroCluster configuration is not supported.

- The source and destination MetroCluster clusters are in a "normal" state. This means that they cannot be in switchover mode or in the "waiting-for-switchback" state.
- The source and destination MetroCluster clusters aren't in the process of an FC-to-IP transition or a hardware refresh.
- The source and destination cluster must both be running ONTAP 9.16.1 or later.
- If the source is a MetroCluster cluster, the SVM subtype is "sync-source" (not "sync-destination").



If the destination is a MetroCluster cluster, the SVM created on the destination is always "sync-source". If the destination is a non-MetroCluster cluster, the SVM subtype is always "default".

Best practice

When performing an SVM migration, it is a best practice to leave 30% CPU headroom on both the source cluster and the destination cluster to enable the CPU workload to execute.

SVM operations

Check for operations that can conflict with an SVM migration:

- No failover operations are in progress
- WAFLIRON cannot be running
- Fingerprint is not in progress
- Vol move, rehost, clone, create, convert, or analytics are not running
- No SVM migration is running on the destination cluster. Only one SVM migration is allowed at any given time.

Supported and unsupported features

The table indicates the ONTAP features supported by SVM data mobility and the ONTAP releases in which support is available.

For information about ONTAP version interoperability between a source and destination in an SVM migration, see [Compatible ONTAP versions for SnapMirror relationships](#).

Feature	Release first supported	Comments
Audit logs (NFS and SMB)	ONTAP 9.13.1	 <p data-bbox="964 237 1455 373">For on-premises SVM migration with audit enabled, you should disable audit on the source SVM and then perform the migration.</p> <p data-bbox="816 415 1101 447">Before SVM migration:</p> <ul data-bbox="841 485 1463 632" style="list-style-type: none"> <li data-bbox="841 485 1419 548">• Audit log must be enabled on the destination cluster. <li data-bbox="841 569 1463 632">• The audit log destination path from the source SVM must be created on the destination cluster.
Autonomous Ransomware Protection	ONTAP 9.12.1	
Cloud instances	Not supported	Migrating SVMs to or from on-prem instances to the cloud is not supported.
Cloud Volumes ONTAP	Not supported	
External key manager	ONTAP 9.11.1	
FabricPool	Not supported	
Fanout relationship (the migrating source has a SnapMirror source volume with more than one destination)	ONTAP 9.11.1	
FC SAN	Not supported	
Flash Pool	ONTAP 9.12.1	
FlexCache volumes	Not supported	
FlexGroup volumes	Not supported	
IPsec policies	Not supported	
IPv6 LIFs	Not supported	
iSCSI SAN	Not supported	

Job schedule replication	ONTAP 9.11.1	In ONTAP 9.10.1, job schedules are not replicated during migration and must be manually created on the destination. Beginning with ONTAP 9.11.1, job schedules used by the source are replicated automatically during migration.
Load-sharing mirrors	Not supported	
MetroCluster SVMs	ONTAP 9.16.1	<p>Beginning with ONTAP 9.16.1, the following MetroCluster SVM migrations are supported:</p> <ul style="list-style-type: none"> • Migrating an SVM between a non-MetroCluster configuration and a MetroCluster IP configuration • Migrating an SVM between two MetroCluster IP configurations • Migrating an SVM between a MetroCluster FC configuration and a MetroCluster IP configuration <p>Note: The source and destination cluster must both be running ONTAP 9.16.1 or later to support SVM migration.</p> <p>The following MetroCluster SVM migrations are not supported for all ONTAP versions:</p> <ul style="list-style-type: none"> • Migrating an SVM between two MetroCluster FC configurations • Migrating an SVM between a non-MetroCluster configuration and a MetroCluster FC configuration • Migrating an SVM between the local and partner cluster in the same MetroCluster configuration. <p>See the prerequisites to migrate an SVM in a MetroCluster configuration.</p>
NetApp Aggregate Encryption (NAE)	ONTAP 9.11.1	NAE volumes must be placed on NAE supporting destination. If no NAE destination is available, the migration operation fails.
NDMP configurations	Not supported	
NetApp Volume Encryption (NVE)	ONTAP 9.10.1	NVE volumes are migrated as NVE volumes on the destination.
NFS v3, NFS v4.1, and NFS v4.2	ONTAP 9.10.1	
NFS v4.0	ONTAP 9.12.1	
NFSv4.1 with pNFS	ONTAP 9.14.1	

NVMe over Fabric	Not supported	
Onboard key manager (OKM) with Common Criteria mode enabled on source cluster	Not supported	
ONTAP Select	Not supported	Migrating SVMs to or from ONTAP Select instances is not supported.
Qtrees	ONTAP 9.14.1	
Quotas	ONTAP 9.14.1	
S3	Not supported	
SMB protocol	ONTAP 9.12.1 However, SMB1 protocol is not supported.	SMB migrations are disruptive and require a client refresh after the migration.
SnapMirror cloud relationships	ONTAP 9.12.1	Beginning with ONTAP 9.12.1, when you migrate an on-premises SVM with SnapMirror cloud relationships, the destination cluster must have the SnapMirror cloud license installed, and it must have enough capacity available to support moving the capacity in the volumes that are being mirrored to the cloud.
SnapMirror asynchronous destination	ONTAP 9.12.1	

SnapMirror asynchronous source	ONTAP 9.11.1	<ul style="list-style-type: none"> • Transfers can continue as normal on FlexVol SnapMirror relationships during most of the migration. • Any ongoing transfers are canceled during cutover and new transfers fail during cutover. They cannot be restarted until the migration completes. • Scheduled transfers that were canceled or missed during the migration are not automatically started after the migration completes. <div style="border: 1px solid gray; padding: 5px; margin-top: 10px;">  <p>When a SnapMirror source is migrated, ONTAP does not prevent deletion of the volume after migration until the SnapMirror update takes place. This happens because SnapMirror-related information for migrated SnapMirror source volumes is available only after migration is complete, and after the first update takes place.</p> </div>
SMTape settings	Not supported	
SnapLock	Not supported	
SnapMirror active sync	Not supported	
SnapMirror SVM peer relationships	ONTAP 9.12.1	
SnapMirror SVM disaster recovery	Not supported	
SnapMirror synchronous	Not supported	
Snapshots	ONTAP 9.10.1	
Tamperproof snapshot locking	ONTAP 9.14.1	Tamperproof snapshot locking is not equivalent to SnapLock. SnapLock Enterprise and SnapLock Compliance remain unsupported.
Virtual IP LIFs/BGP	Not supported	
Virtual Storage Console 7.0 and later	Not supported	
Volume clones	Not supported	

Vscan	Not supported	Migration of Vscan-enabled SVMs is not supported.
vStorage	Not supported	Migration is not allowed when vStorage is enabled. To perform a migration, disable the vStorage option, and then reenable it after migration is completed.

Supported operations during migration

The following table indicates volume operations supported within the migrating SVM based on migration state:

Volume operation	SVM migration state		
	In progress	Paused	Cutover
Create	Not allowed	Allowed	Not supported
Delete	Not allowed	Allowed	Not supported
File System Analytics disable	Allowed	Allowed	Not supported
File System Analytics enable	Not allowed	Allowed	Not supported
Modify	Allowed	Allowed	Not supported
Offline/Online	Not allowed	Allowed	Not supported
Move/rehost	Not allowed	Allowed	Not supported
Qtree create/modify	Not allowed	Allowed	Not supported
Quota create/modify	Not allowed	Allowed	Not supported
Rename	Not allowed	Allowed	Not supported
Resize	Allowed	Allowed	Not supported
Restrict	Not allowed	Allowed	Not supported
Snapshot attributes modify	Allowed	Allowed	Not supported
Snapshot autodelete modify	Allowed	Allowed	Not supported
Snapshot create	Allowed	Allowed	Not supported
Snapshot delete	Allowed	Allowed	Not supported
Restore file from snapshot	Allowed	Allowed	Not supported

Post-migration information

- After migration, local snapshot policies have the extension -MIG that might break some automation. You should search for this extension and rename the policies and needed.
- Migrated vault destination SnapMirror volumes must perform a resync to reactivate protection. The vault resync is necessary because the migration creates a new baseline between the migration SVMs that is more recent than the vault's previous baseline. Performing a resync reactivates the vault, which will also deletes any data newer than the current vault baseline, specifically the snapshot that was generated during the migration.

Migrate an ONTAP SVM

After an SVM migration has completed, clients are cut over to the destination cluster automatically and the unnecessary SVM is removed from the source cluster. Automatic cutover and automatic source cleanup are enabled by default. If necessary, you can disable client auto-cutover to suspend the migration before cutover occurs and you can also disable automatic source SVM cleanup.

About this task

This procedure applies to FAS, AFF, and ASA systems. If you have an ASA r2 system (ASA A1K, ASA A90, ASA A70, ASA A50, ASA A30, ASA A20, or ASA C30), follow [these steps](#) to migrate an SVM. ASA r2 systems provide a simplified ONTAP experience specific to SAN-only customers.

- You can use the `-auto-cutover false` option to suspend the migration when automatic client cutover normally occurs and then manually perform the cutover later.

[Manually cutover clients after SVM migration](#)

- You can use the advance privilege `-auto-source-cleanup false` option to disable the removal of the source SVM after cutover and then trigger source cleanup manually later, after cutover.

[Manually remove source SVM after cutover](#)

Migrate an ONTAP SVM with automatic cutover enabled

By default, clients are cut over to the destination cluster automatically when the migration is complete, and the unnecessary SVM is removed from the source cluster.

Steps

1. From the destination cluster, run the migration prechecks:

```
vserver migrate start -vserver <SVM_name> -source-cluster <cluster_name>
-check-only true`
```

2. From the destination cluster, start the SVM migration:

```
vserver migrate start -vserver <SVM_name> -source-cluster <cluster_name>
```

3. Check the migration status:

```
vserver migrate show
```

The status displays `migrate-complete` when the SVM migration is finished.

Migrate an ONTAP SVM with automatic client cutover disabled

You can use the `-auto-cutover false` option to suspend the migration when automatic client cutover normally occurs and then manually perform the cutover later. See [Manually cutover clients after SVM migration](#).

Steps

1. From the destination cluster, run the migration prechecks:

```
vserver migrate start -vserver <SVM_name> -source-cluster <cluster_name>
-check-only true`
```

2. From the destination cluster, start the SVM migration:

```
vserver migrate start -vserver <SVM_name> -source-cluster <cluster_name>
-auto-cutover false`
```

3. Check the migration status:

```
vserver migrate show
```

The status displays `ready-for-cutover` when SVM migration completes the asynchronous data transfers, and it is ready for cutover operation.

Migrate an ONTAP SVM with source cleanup disabled

You can use the advance privilege `-auto-source-cleanup false` option to disable the removal of the source SVM after cutover and then trigger source cleanup manually later, after cutover. See [Manually remove source SVM](#).

Steps

1. From the destination cluster, run the migration prechecks:

```
vserver migrate start -vserver <SVM_name> -source-cluster <cluster_name>
-check-only true`
```

2. From the destination cluster, start the SVM migration:

```
vserver migrate start -vserver <SVM_name> -source-cluster <cluster_name>
-auto-source-cleanup false`
```

3. Check the migration status:

```
vserver migrate show
```

The status displays ready-for-source-cleanup when SVM migration cutover is complete, and it is ready to remove the SVM on the source cluster.

Monitor ONTAP volume migration

In addition to monitoring the overall SVM migration with the `vserver migrate show` command, you can monitor the migration status of the volumes the SVM contains.

Steps

1. On the destination cluster, check the volume migration status:

```
vserver migrate show-volume
```

Pause and resume an ONTAP SVM migration

You might want to pause an SVM migration before the migration cutover begins. You can pause an SVM migration using the `vserver migrate pause` command.

Pause migration

You can pause an SVM migration before client cutover starts by using the `vserver migrate pause` command.

Some configuration changes are restricted when a migration operation is in progress; however, beginning with ONTAP 9.12.1, you can pause a migration to fix some restricted configurations and for some failed states so that you can fix configuration issues that might have caused the failure. Some of the failed states that you can fix when you pause SVM migration include the following:

- setup-configuration-failed
- migrate-failed

Steps

1. From the destination cluster, pause the migration:

```
vserver migrate pause -vserver <vserver name>
```

Resume migrations

When you're ready to resume a paused SVM migration or when an SVM migration has failed, you can use the `vserver migrate resume` command.

Steps

1. From the destination cluster, resume the SVM migration:

```
vserver migrate resume
```

2. Verify that the SVM migration has resumed, and monitor the progress:

```
vserver migrate show
```

Cancel an ONTAP SVM migration

If you need to cancel an SVM migration before it completes, you can use the `vserver migrate abort` command. You can cancel an SVM migration only when the operation is in the paused or failed state. You cannot cancel an SVM migration when the status is "cutover-started" or after cutover is complete. You cannot use the `abort` option when an SVM migration is in progress.

Steps

1. On the destination cluster, check the migration status:

```
vserver migrate show -vserver <SVM_name>
```

2. Cancel the migration:

```
vserver migrate abort -vserver <SVM_name>
```

3. Check the progress of the cancel operation:

```
vserver migrate show
```

The migration status shows `migrate-aborting` while the cancel operation is in progress. When the cancel operation completes, the migration status shows nothing.

Manually cut over clients after migration of an ONTAP SVM

By default, client cutover to the destination cluster is performed automatically after the SVM migration reaches "ready-for-cutover" state. If you choose to disable automatic client cutover, you need to perform the client cutover manually.

Steps

1. Manually execute client cutover:

```
vserver migrate cutover -vserver <SVM_name>
```

2. Check the status of the cutover operation:

```
vserver migrate show
```

Manually remove source ONTAP SVM after client cutover

If you performed the SVM migration with source cleanup disabled, you can remove the source SVM manually after client cutover is complete.

Steps

1. Verify the status is ready for source cleanup:

```
vserver migrate show
```

2. Clean up the source:

```
vserver migrate source-cleanup -vserver <SVM_name>
```

HA pair management

Learn about HA pair management in ONTAP clusters

Cluster nodes are configured in high-availability (HA) pairs for fault tolerance and nondisruptive operations. If a node fails or if you need to bring a node down for routine maintenance, its partner can take over its storage and continue to serve data from it. The partner gives back storage when the node is brought back online.

The HA pair controller configuration consists of a pair of matching storage controllers (local node and partner node). Each of these nodes is connected to the other's disk shelves. When one node in an HA pair encounters an error and stops processing data, its partner detects the failed status of the partner and takes over all data processing from that controller.

Takeover is the process in which a node assumes control of its partner's storage.

Giveback is the process in which the storage is returned to the partner.

By default, takeovers occur automatically in any of the following situations:

- A software or system failure occurs on a node that leads to a panic. The HA pair controllers automatically fail over to their partner node. After the partner has recovered from the panic and booted up, the node automatically performs a giveback, returning the partner to normal operation.
- A system failure occurs on a node, and the node cannot reboot. For example, when a node fails because of a power loss, HA pair controllers automatically fail over to their partner node and serve data from the surviving storage controller.



If the storage for a node also loses power at the same time, a standard takeover is not possible.

- Heartbeat messages are not received from the node's partner. This could happen if the partner experienced a hardware or software failure (for example, an interconnect failure) that did not result in a panic but still prevented it from functioning correctly.
- You halt one of the nodes without using the `-f` or `-inhibit-takeover true` parameter.



In a two-node cluster with cluster HA enabled, halting or rebooting a node using the `-inhibit-takeover true` parameter causes both nodes to stop serving data unless you first disable cluster HA and then assign epsilon to the node that you want to remain online.

- You reboot one of the nodes without using the `-inhibit-takeover true` parameter. (The `-onboot` parameter of the `storage failover` command is enabled by default.)
- The remote management device (Service Processor) detects failure of the partner node. This is not applicable if you disable hardware-assisted takeover.

You can also manually initiate takeovers with the `storage failover takeover` command.

Beginning with ONTAP 9.18.1, you can configure encrypted communication between HA pair nodes. For more information, refer to [Configure encryption for ONTAP HA traffic](#).

Cluster resiliency and diagnostic improvements

Beginning with ONTAP 9.9.1, the following resiliency and diagnostic additions improve cluster operation:

- **Port monitoring and avoidance:** In two-node switchless cluster configurations, the system avoids ports that experience total packet loss (connectivity loss). In ONTAP 9.8.1 and earlier, this functionality was only available in switched configurations.
- **Automatic node failover:** If a node cannot serve data across its cluster network, that node should not own any disks. Instead its HA partner should take over, if the partner is healthy.
- **Commands to analyze connectivity issues:** Use the following command to display which cluster paths are experiencing packet loss: `network interface check cluster-connectivity show`

Learn more about `network interface check cluster-connectivity show` in the [ONTAP command reference](#).

Learn about hardware-assisted takeovers in ONTAP clusters

Enabled by default, the hardware-assisted takeover feature can speed up the takeover process by using a node's remote management device (Service Processor).

When the remote management device detects a failure, it quickly initiates the takeover rather than waiting for ONTAP to recognize that the partner's heartbeat has stopped. If a failure occurs without this feature enabled, the partner waits until it notices that the node is no longer giving a heartbeat, confirms the loss of heartbeat, and then initiates the takeover.

The hardware-assisted takeover feature uses the following process to avoid that wait:

1. The remote management device monitors the local system for certain types of failures.
2. If a failure is detected, the remote management device immediately sends an alert to the partner node.
3. Upon receiving the alert, the partner initiates takeover.

System events that trigger hardware-assisted takeover

The partner node might generate a takeover depending on the type of alert it receives from the remote management device (Service Processor).

Alert	Takeover initiated upon receipt?	Description
abnormal_reboot	No	An abnormal reboot of the node occurred.
l2_watchdog_reset	Yes	The system watchdog hardware detected an L2 reset. The remote management device detected a lack of response from the system CPU and reset the system.
loss_of_heartbeat	No	The remote management device is no longer receiving the heartbeat message from the node. This alert does not refer to the heartbeat messages between the nodes in the HA pair; it refers to the heartbeat between the node and its local remote management device.
periodic_message	No	A periodic message is sent during a normal hardware-assisted takeover operation.
power_cycle_via_sp	Yes	The remote management device cycled the system power off and on.
power_loss	Yes	A power loss occurred on the node. The remote management device has a power supply that maintains power for a short period after a power loss, allowing it to report the power loss to the partner.
power_off_via_sp	Yes	The remote management device powered off the system.
reset_via_sp	Yes	The remote management device reset the system.
test	No	A test message is sent to verify a hardware-assisted takeover operation.

Related information

[Hardware-assisted \(HWassist\) takeover - Resolution guide](#)

Learn about automatic takeover and giveback in ONTAP clusters

The automatic takeover and giveback operations can work together to reduce and avoid client outages.

By default, if one node in the HA pair panics, reboots, or halts, the partner node automatically takes over and then returns storage when the affected node reboots. The HA pair then resumes a normal operating state.

Automatic takeovers may also occur if one of the nodes become unresponsive.

Automatic giveback occurs by default. If you would rather control giveback impact on clients, you can disable automatic giveback and use the `storage failover modify -auto-giveback false -node <node>` command. Before performing the automatic giveback (regardless of what triggered it), the partner node waits for a fixed amount of time as controlled by the `-delay-` seconds parameter of the `storage failover`

`modify` command. The default delay is 600 seconds.

This process avoids a single, prolonged outage that includes time required for:

- The takeover operation
- The taken-over node to boot up to the point at which it is ready for the giveback
- The giveback operation

If the automatic giveback fails for any of the non-root aggregates, the system automatically makes two additional attempts to complete the giveback.



During the takeover process, the automatic giveback process starts before the partner node is ready for the giveback. When the time limit of the automatic giveback process expires and the partner node is still not ready, the timer restarts. As a result, the time between the partner node being ready and the actual giveback being performed might be shorter than the automatic giveback time.

What happens during takeover

When a node takes over its partner, it continues to serve and update data in the partner's aggregates and volumes.

The following steps occur during the takeover process:

1. If the negotiated takeover is user-initiated, aggregated data is moved from the partner node to the node that is performing the takeover. A brief outage occurs as the current owner of each aggregate (except for the root aggregate) changes over to the takeover node. This outage is briefer than an outage that occurs during a takeover without aggregate relocation.



A negotiated takeover during panic cannot occur in the case of a panic. A takeover can result from a failure not associated with a panic. A failure is experienced when communication is lost between a node and its partner, also called a heartbeat loss. If a takeover occurs because of a failure, the outage might be longer because the partner node needs time to detect the heartbeat loss.

- You can monitor the progress using the `storage failover show-takeover` command.
- You can avoid the aggregate relocation during this takeover instance by using the `-bypass -optimization` parameter with the `storage failover takeover` command.

Aggregates are relocated serially during planned takeover operations to reduce client outage. If aggregate relocation is bypassed, longer client outage occurs during planned takeover events.

2. If the user-initiated takeover is a negotiated takeover, the target node gracefully shuts down, followed by takeover of the target node's root aggregate and any aggregates that were not relocated in the first step.
3. Data LIFs (logical interfaces) migrate from the target node to the takeover node, or to any other node in the cluster based on LIF failover rules. You can avoid the LIF migration by using the `-skip-lif-migration` parameter with the `storage failover takeover` command. In the case of a user-initiated takeover, data LIFs are migrated before storage takeover begins. In the event of a panic or failure, depending upon your configuration, data LIFs could be migrated with the storage, or after takeover is complete.
4. Existing SMB sessions are disconnected when takeover occurs.



Due to the nature of the SMB protocol, all SMB sessions are disrupted (except for SMB 3.0 sessions connected to shares with the Continuous Availability property set). SMB 1.0 and SMB 2.x sessions cannot reconnect open file handles after a takeover event; therefore, takeover is disruptive and some data loss could occur.

5. SMB 3.0 sessions that are established to shares with the Continuous Availability property enabled can reconnect to the disconnected shares after a takeover event. If your site uses SMB 3.0 connections to Microsoft Hyper-V and the Continuous Availability property is enabled on the associated shares, takeovers are non-disruptive for those sessions.

What happens if a node performing a takeover panics

If the node that is performing the takeover panics within 60 seconds of initiating takeover, the following events occur:

- The node that panicked reboots.
- After it reboots, the node performs self-recovery operations and is no longer in takeover mode.
- Failover is disabled.
- If the node still owns some of the partner's aggregates, after enabling storage failover, return these aggregates to the partner using the `storage failover giveback` command.

What happens during giveback

The local node returns ownership to the partner node when issues are resolved, when the partner node boots up, or when giveback is initiated.

The following process takes place in a normal giveback operation. In this discussion, Node A has taken over Node B. Any issues on Node B have been resolved and it is ready to resume serving data.

1. Any issues on Node B are resolved and it displays the following message: `Waiting for giveback`
2. The giveback is initiated by the `storage failover giveback` command or by automatic giveback if the system is configured for it. This initiates the process of returning ownership of Node B's aggregates and volumes from Node A back to Node B.
3. Node A returns control of the root aggregate first.
4. Node B completes the process of booting up to its normal operating state.
5. As soon as Node B reaches the point in the boot process where it can accept the non-root aggregates, Node A returns ownership of the other aggregates, one at a time, until giveback is complete. You can monitor the progress of the giveback by using the `storage failover show-giveback` command.



The `storage failover show-giveback` command does not (nor is it intended to) display information about all operations occurring during the storage failover giveback operation. You can use the `storage failover show` command to display additional details about the current failover status of the node, such as if the node is fully functional, takeover is possible, and giveback is complete.

I/O resumes for each aggregate after giveback is complete for that aggregate, which reduces its overall outage window.

HA policy and its effect on takeover and giveback

ONTAP automatically assigns an HA policy of CFO (controller failover) and SFO (storage failover) to an aggregate. This policy determines how storage failover operations occur for the aggregate and its volumes.

The two options, CFO and SFO, determine the aggregate control sequence ONTAP uses during storage failover and giveback operations.

Although the terms CFO and SFO are sometimes used informally to refer to storage failover (takeover and giveback) operations, they actually represent the HA policy assigned to the aggregates. For example, the terms SFO aggregate or CFO aggregate simply refer to the aggregate's HA policy assignment.

HA policies affect takeover and giveback operations as follows:

- Aggregates created on ONTAP systems (except for the root aggregate containing the root volume) have an HA policy of SFO. Manually initiated takeover is optimized for performance by relocating SFO (non-root) aggregates serially to the partner before takeover. During the giveback process, aggregates are given back serially after the taken-over system boots and the management applications come online, enabling the node to receive its aggregates.
- Because aggregate relocation operations entail reassigning aggregate disk ownership and shifting control from a node to its partner, only aggregates with an HA policy of SFO are eligible for aggregate relocation.
- The root aggregate always has an HA policy of CFO and is given back at the start of the giveback operation. This is necessary to allow the taken-over system to boot. All other aggregates are given back serially after the taken-over system completes the boot process and the management applications come online, enabling the node to receive its aggregates.



Changing the HA policy of an aggregate from SFO to CFO is a Maintenance mode operation. Do not modify this setting unless directed to do so by a customer support representative.

How background updates affect takeover and giveback

Background updates of the disk firmware will affect HA pair takeover, giveback, and aggregate relocation operations differently, depending on how those operations are initiated.

The following list describes how background disk firmware updates affect takeover, giveback, and aggregate relocation:

- If a background disk firmware update occurs on a disk on either node, manually initiated takeover operations are delayed until the disk firmware update finishes on that disk. If the background disk firmware update takes longer than 120 seconds, takeover operations are aborted and must be restarted manually after the disk firmware update finishes. If the takeover was initiated with the `-bypass-optimization` parameter of the `storage failover takeover` command set to `true`, the background disk firmware update occurring on the destination node does not affect the takeover.
- If a background disk firmware update is occurring on a disk on the source (or takeover) node and the takeover was initiated manually with the `-options` parameter of the `storage failover takeover` command set to `immediate`, takeover operations start immediately.
- If a background disk firmware update is occurring on a disk on a node and it panics, takeover of the panicked node begins immediately.
- If a background disk firmware update is occurring on a disk on either node, giveback of data aggregates is delayed until the disk firmware update finishes on that disk.
- If the background disk firmware update takes longer than 120 seconds, giveback operations are aborted

and must be restarted manually after the disk firmware update completes.

- If a background disk firmware update is occurring on a disk on either node, aggregate relocation operations are delayed until the disk firmware update finishes on that disk. If the background disk firmware update takes longer than 120 seconds, aggregate relocation operations are aborted and must be restarted manually after the disk firmware update finishes. If aggregate relocation was initiated with the `-override -destination-checks` of the `storage aggregate relocation` command set to `true`, the background disk firmware update occurring on the destination node does not affect aggregate relocation.

Related information

- [storage aggregate relocation](#)
- [storage failover giveback](#)
- [storage failover modify](#)
- [storage failover show-giveback](#)
- [storage failover takeover](#)

ONTAP automatic takeover commands

Automatic takeover is enabled by default on all supported NetApp FAS, AFF, and ASA platforms. You might need to change the default behavior and control when automatic takeovers occur when the partner node reboots, panics, or halts.

If you want takeover to occur automatically when the partner node...	Use this command...
Reboots or halts	<code>storage failover modify -node nodename -onreboot true</code>
Panics	<code>storage failover modify -node nodename -onpanic true</code>

Enable email notification if the takeover capability is disabled

To receive prompt notification if the takeover capability becomes disabled, you should configure your system to enable automatic email notification for the “takeover impossible” EMS messages:

- `ha.takeoverImpVersion`
- `ha.takeoverImpLowMem`
- `ha.takeoverImpDegraded`
- `ha.takeoverImpUnsync`
- `ha.takeoverImpIC`
- `ha.takeoverImpHotShelf`
- `ha.takeoverImpNotDef`

Related information

- [storage failover modify](#)

ONTAP automatic giveback commands

By default, the take-over partner node automatically gives back storage when the off-line node is brought back on line, thus restoring the high-availability pair relationship. In most cases, this is the desired behavior. If you need to disable automatic giveback - for example, if you want to investigate the cause of the takeover before giving back – you need to be aware of the interaction of non-default settings.

If you want to...	Use this command...
Enable automatic giveback so that giveback occurs as soon as the taken-over node boots, reaches the Waiting for Giveback state, and the Delay before Auto Giveback period has expired. The default setting is true.	<pre>storage failover modify -node <i>nodename</i> -auto-giveback true</pre>
Disable automatic giveback. The default setting is true. Note: Setting this parameter to false does not disable automatic giveback after takeover on panic; automatic giveback after takeover on panic must be disabled by setting the <code>-auto-giveback-after-panic</code> parameter to false.	<pre>storage failover modify -node <i>nodename</i> -auto-giveback false</pre>
Disable automatic giveback after takeover on panic (this setting is enabled by default).	<pre>storage failover modify -node <i>nodename</i> -auto-giveback-after-panic false</pre>
Delay automatic giveback for a specified number of seconds (the default is 600). This option determines the minimum time that a node remains in takeover before performing an automatic giveback.	<pre>storage failover modify -node <i>nodename</i> -delay-seconds <i>seconds</i></pre>

How variations of the storage failover modify command affect automatic giveback

The operation of automatic giveback depends on how you configure the parameters of the storage failover modify command.

The following table lists the default settings for the `storage failover modify` command parameters that apply to takeover events not caused by a panic.

Parameter	Default setting
<code>-auto-giveback <i>true</i> <i>false</i></code>	<i>true</i>
<code>-delay-seconds <i>integer</i> (seconds)</code>	600
<code>-onreboot <i>true</i> <i>false</i></code>	<i>true</i>

The following table describes how combinations of the `-onreboot` and `-auto-giveback` parameters affect automatic giveback for takeover events not caused by a panic.

storage failover modify parameters used	Cause of takeover	Does automatic giveback occur?
<code>-onreboot true</code>	reboot command	Yes
<code>-auto-giveback true</code>	halt command, or power cycle operation issued from the Service Processor	Yes
<code>-onreboot true</code>	reboot command	Yes
<code>-auto-giveback false</code>	halt command, or power cycle operation issued from the Service Processor	No
<code>-onreboot false</code>	reboot command	N/A In this case, takeover does not occur
<code>-auto-giveback true</code>	halt command, or power cycle operation issued from the Service Processor	Yes
<code>-onreboot false</code>	reboot command	No
<code>-auto-giveback false</code>	halt command, or power cycle operation issued from the Service Processor	No

The `-auto-giveback` parameter controls giveback after panic and all other automatic takeovers. If the `-onreboot` parameter is set to `true` and a takeover occurs due to a reboot, then automatic giveback is always performed, regardless of whether the `-auto-giveback` parameter is set to `true`.

The `-onreboot` parameter applies to reboots and halt commands issued from ONTAP. When the `-onreboot` parameter is set to `false`, a takeover does not occur in the case of a node reboot. Therefore, automatic giveback cannot occur, regardless of whether the `-auto-giveback` parameter is set to `true`. A client disruption occurs.

The effects of automatic giveback parameter combinations that apply to panic situations.

The following table lists the `storage failover modify` command parameters that apply to panic situations:

Parameter	Default setting
<code>-onpanic true false</code>	<code>true</code>
<code>-auto-giveback-after-panic true false</code> (Privilege: Advanced)	<code>true</code>

<code>-auto-giveback true false</code>	<code>true</code>
--	-------------------

The following table describes how parameter combinations of the `storage failover modify` command affect automatic giveback in panic situations.

storage failover parameters used	Does automatic giveback occur after panic?
<code>-onpanic true</code> <code>-auto-giveback true</code> <code>-auto-giveback-after-panic true</code>	Yes
<code>-onpanic true</code> <code>-auto-giveback true</code> <code>-auto-giveback-after-panic false</code>	Yes
<code>-onpanic true</code> <code>-auto-giveback false</code> <code>-auto-giveback-after-panic true</code>	Yes
<code>-onpanic true</code> <code>-auto-giveback false</code> <code>-auto-giveback-after-panic false</code>	No
<code>-onpanic false</code> If <code>-onpanic</code> is set to <code>false</code> , takeover/giveback does not occur, regardless of the value set for <code>-auto-giveback</code> or <code>-auto-giveback-after-panic</code>	No



A takeover can result from a failure not associated with a panic. A *failure* is experienced when communication is lost between a node and its partner, also called a *heartbeat loss*. If a takeover occurs because of a failure, giveback is controlled by the `-onfailure` parameter instead of the `-auto-giveback-after-panic` parameter.



When a node panics, it sends a panic packet to its partner node. If for any reason the panic packet is not received by the partner node, the panic can be misinterpreted as a failure. Without receipt of the panic packet, the partner node knows only that communication has been lost, and does not know that a panic has occurred. In this case, the partner node processes the loss of communication as a failure instead of a panic, and giveback is controlled by the `-onfailure` parameter (and not by the `-auto-giveback-after-panic` parameter).

Learn more about `storage failover modify` in the [ONTAP command reference](#).

ONTAP manual takeover commands

You can perform a takeover manually when maintenance is required on the partner, and in other similar situations. Depending on the state of the partner, the command you use to perform the takeover varies.

If you want to...	Use this command...
-------------------	---------------------

Take over the partner node	<code>storage failover takeover</code>
Monitor the progress of the takeover as the partner's aggregates are moved to the node doing the takeover	<code>storage failover show-takeover</code>
Display the storage failover status for all nodes in the cluster	<code>storage failover show</code>
Take over the partner node without migrating LIFs	<code>storage failover takeover -skip-lif -migration-before-takeover true</code>
Take over the partner node even if there is a disk mismatch	<code>storage failover takeover -allow-disk -inventory-mismatch true</code>
Take over the partner node even if there is an ONTAP version mismatch	<code>storage failover takeover -option allow -version-mismatch</code>
Note: This option is only used during the nondisruptive ONTAP upgrade process.	
Take over the partner node without performing aggregate relocation	<code>storage failover takeover -bypass -optimization true</code>
Take over the partner node before the partner has time to close its storage resources gracefully	<code>storage failover takeover -option immediate</code>

Before you issue the storage failover command with the `immediate` option, you must migrate the data LIFs to another node by using the following command: `network interface migrate-all -node node`

Learn more about `network interface migrate-all` in the [ONTAP command reference](#).



If you specify the `storage failover takeover -option immediate` command without first migrating the data LIFs, data LIF migration from the node is significantly delayed even if the `skip-lif-migration-before-takeover` option is not specified.

Similarly, if you specify the `immediate` option, negotiated takeover optimization is bypassed even if the `bypass-optimization` option is set to `false`.

Moving epsilon for certain manually initiated takeovers

You should move epsilon if you expect that any manually initiated takeovers could result in your storage system being one unexpected node failure away from a cluster-wide loss of quorum.

About this task

To perform planned maintenance, you must take over one of the nodes in an HA pair. Cluster-wide quorum must be maintained to prevent unplanned client data disruptions for the remaining nodes. In some instances, performing the takeover can result in a cluster that is one unexpected node failure away from cluster-wide loss of quorum.

This can occur if the node being taken over holds epsilon or if the node with epsilon is not healthy. To maintain a more resilient cluster, you can transfer epsilon to a healthy node that is not being taken over. Typically, this would be the HA partner.

Only healthy and eligible nodes participate in quorum voting. To maintain cluster-wide quorum, more than $N/2$

votes are required (where N represents the sum of healthy, eligible, online nodes). In clusters with an even number of online nodes, epsilon adds additional voting weight toward maintaining quorum for the node to which it is assigned.



Although cluster formation voting can be modified by using the `cluster modify -eligibility false` command, you should avoid this except for situations such as restoring the node configuration or prolonged node maintenance. If you set a node as ineligible, it stops serving SAN data until the node is reset to eligible and rebooted. NAS data access to the node might also be affected when the node is ineligible.

Steps

1. Verify the cluster state and confirm that epsilon is held by a healthy node that is not being taken over:
 - a. Change to the advanced privilege level, confirming that you want to continue when the advanced mode prompt appears (*>):

```
set -privilege advanced
```

- b. Determine which node holds epsilon:

```
cluster show
```

In the following example, Node1 holds epsilon:

Node	Health	Eligibility	Epsilon
Node1	true	true	true
Node2	true	true	false

If the node you want to take over does not hold epsilon, proceed to Step 4.

Learn more about `cluster show` in the [ONTAP command reference](#).

2. Remove epsilon from the node that you want to take over:

```
cluster modify -node Node1 -epsilon false
```
3. Assign epsilon to the partner node (in this example, Node2):

```
cluster modify -node Node2 -epsilon true
```

4. Perform the takeover operation:

```
storage failover takeover -ofnode node_name
```

5. Return to the admin privilege level:

```
set -privilege admin
```

Related information

- [storage failover show](#)
- [storage failover takeover](#)

ONTAP manual giveback commands

You can perform a normal giveback, a giveback in which you terminate processes on the partner node, or a forced giveback.



Prior to performing a giveback, you must remove the failed drives in the taken-over system as described in [Disks and aggregates management](#).

If giveback is interrupted

If the takeover node experiences a failure or a power outage during the giveback process, that process stops and the takeover node returns to takeover mode until the failure is repaired or the power is restored.

However, this depends upon the stage of giveback in which the failure occurred. If the node encountered failure or a power outage during partial giveback state (after it has given back the root aggregate), it will not return to takeover mode. Instead, the node returns to partial-giveback mode. If this occurs, complete the process by repeating the giveback operation.

If giveback is vetoed

If giveback is vetoed, you must check the EMS messages to determine the cause. Depending on the reason or reasons, you can decide whether you can safely override the vetoes.

The `storage failover show-giveback` command displays the giveback progress and shows which subsystem vetoed the giveback, if any. Soft vetoes can be overridden, while hard vetoes cannot be, even if forced. The following tables summarize the soft vetoes that should not be overridden, along with recommended workarounds.

You can review the EMS details for any giveback vetoes by using the following command:

```
event log show -node * -event gb*
```

Learn more about `event log show` in the [ONTAP command reference](#).

Giveback of the root aggregate

These vetoes do not apply to aggregate relocation operations:

Vetoing subsystem module	Workaround
vfiler_low_level	<p>Terminate the SMB sessions causing the veto, or shutdown the SMB application that established the open sessions.</p> <p>Overriding this veto might cause the application using SMB to disconnect abruptly and lose data.</p>
Disk Check	<p>All failed or bypassed disks should be removed before attempting giveback. If disks are sanitizing, you should wait until the operation completes.</p> <p>Overriding this veto might cause an outage caused by aggregates or volumes going offline due to reservation conflicts or inaccessible disks.</p>

Giveback of the SFO aggregates

These vetoes do not apply to aggregate relocation operations:

Vetoing subsystem module	Workaround
Lock Manager	<p>Gracefully shutdown the SMB applications that have open files, or move those volumes to a different aggregate.</p> <p>Overriding this veto results in loss of SMB lock state, causing disruption and data loss.</p>
Lock Manager NDO	<p>Wait until the locks are mirrored.</p> <p>Overriding this veto causes disruption to Microsoft Hyper-V virtual machines.</p>
RAID	<p>Check the EMS messages to determine the cause of the veto:</p> <p>If the veto is due to nfile, bring the offline volumes and aggregates online.</p> <p>If disk add or disk ownership reassignment operations are in progress, wait until they complete.</p> <p>If the veto is due to an aggregate name or UUID conflict, troubleshoot and resolve the issue.</p> <p>If the veto is due to mirror resync, mirror verify, or offline disks, the veto can be overridden and the operation restarts after giveback.</p>
Disk Inventory	<p>Troubleshoot to identify and resolve the cause of the problem.</p> <p>The destination node might be unable to see disks belonging to an aggregate being migrated.</p> <p>Inaccessible disks can result in inaccessible aggregates or volumes.</p>
Volume Move Operation	<p>Troubleshoot to identify and resolve the cause of the problem.</p> <p>This veto prevents the volume move operation from aborting during the important cutover phase. If the job is aborted during cutover, the volume might become inaccessible.</p>

Commands for performing a manual giveback

You can manually initiate a giveback on a node in an HA pair to return storage to the original owner after completing maintenance or resolving any issues that caused the takeover.

If you want to...	Use this command...
-------------------	---------------------

Give back storage to a partner node	<code>storage failover giveback -ofnode nodename</code>
Give back storage even if the partner is not in the waiting for giveback mode	<code>storage failover giveback -ofnode nodename -require-partner-waiting false</code> Do not use this option unless a longer client outage is acceptable.
Give back storage even if processes are vetoing the giveback operation (force the giveback)	<code>storage failover giveback -ofnode nodename -override-vetoes true</code> Use of this option can potentially lead to longer client outage, or aggregates and volumes not coming online after the giveback.
Give back only the CFO aggregates (the root aggregate)	<code>storage failover giveback -ofnode nodename -only-cfo-aggregates true</code>
Monitor the progress of giveback after you issue the giveback command	<code>storage failover show-giveback</code>

Related information

- [storage failover giveback](#)
- [storage failover show-giveback](#)

Testing takeover and giveback in ONTAP clusters

After you configure all aspects of your HA pair, you need to verify that it is operating as expected in maintaining uninterrupted access to both nodes' storage during takeover and giveback operations. Throughout the takeover process, the local (or takeover) node should continue serving the data normally provided by the partner node. During giveback, control and delivery of the partner's storage should return to the partner node.

Steps

1. Check the cabling on the HA interconnect cables to make sure that they are secure.
2. Verify that you can create and retrieve files on both nodes for each licensed protocol.
3. Enter the following command:

```
storage failover takeover -ofnode partnernode
```

Learn more about `storage failover takeover` in the [ONTAP command reference](#).

4. Enter either of the following commands to confirm that takeover occurred:

```
storage failover show-takeover
```

```
storage failover show
```

If you have the `storage failover` command's `-auto-giveback` option enabled:

Node	Partner	Takeover Possible	State Description
node 1	node 2	-	Waiting for giveback
node 2	node 1	false	In takeover, Auto giveback will be initiated in number of seconds

If you have the `storage failover` command's `-auto-giveback` option disabled:

Node	Partner	Takeover Possible	State Description
node 1	node 2	-	Waiting for giveback
node 2	node 1	false	In takeover

5. Display all the disks that belong to the partner node (Node2) that the takeover node (Node1) can detect:

```
storage disk show -home node2 -ownership
```

The following command displays all disks belonging to Node2 that Node1 can detect:

```
cluster::> storage disk show -home node2 -ownership
```

Disk	Aggregate	Home	Owner	DR Home	Home ID	Owner ID	DR Home ID	Reserve r	Pool
1.0.2	-	node2	node2	-	4078312453	4078312453	-	4078312452	Pool0
1.0.3	-	node2	node2	-	4078312453	4078312453	-	4078312452	Pool0

6. Confirm that the takeover node (Node1) controls the partner node's (Node2) aggregates:

```
aggr show -fields home-id,home-name,is-home
```

aggregate	home-id	home-nameh	is-home
aggr0_1	2014942045	node1	true
aggr0_2	4078312453	node2	false
aggr1_1	2014942045	node1	true
aggr1_2	4078312453	node2	false

During takeover, the "is-home" value of the partner node's aggregates is false.

7. Give back the partner node's data service after it displays the "Waiting for giveback" message:

```
storage failover giveback -ofnode partnernode
```

8. Enter either of the following commands to observe the progress of the giveback operation:

```
storage failover show-giveback
```

```
storage failover show
```

9. Proceed, depending on whether you saw the message that giveback was completed successfully:

If takeover and giveback...	Then...
Are completed successfully	Repeat Step 2 through Step 8 on the partner node.
Fail	Correct the takeover or giveback failure and then repeat this procedure.

Related information

- [storage disk show](#)
- [storage failover giveback](#)
- [storage failover show](#)
- [storage failover show-giveback](#)

ONTAP commands for monitoring an HA pair

You can use ONTAP commands to monitor the status of the HA pair. If a takeover occurs, you can also determine what caused the takeover.

If you want to check	Use this command
Whether failover is enabled or has occurred, or reasons why failover is not currently possible	<code>storage failover show</code>
View the nodes on which the storage failover HA-mode setting is enabled You must set the value to ha for the node to participate in a storage failover (HA pair) configuration.	<code>storage failover show -fields mode</code>
Whether hardware-assisted takeover is enabled	<code>storage failover hwassist show</code>
The history of hardware-assisted takeover events that have occurred	<code>storage failover hwassist stats show</code>
The progress of a takeover operation as the partner's aggregates are moved to the node doing the takeover	<code>storage failover show-takeover</code>
The progress of a giveback operation in returning aggregates to the partner node	<code>storage failover show-giveback</code>
Whether an aggregate is home during takeover or giveback operations	<code>aggregate show -fields home-id,owner-id,home-name,owner-name,is-home</code>

Whether cluster HA is enabled (applies only to two node clusters)	<code>cluster ha show</code>
The HA state of the components of an HA pair (on systems that use the HA state)	<code>ha-config show</code> This is a Maintenance mode command.

Node states displayed by storage failover show-type commands

The following list describes the node states that the `storage failover show` command displays.

Node State	Description
Connected to partner_name, Automatic takeover disabled.	The HA interconnect is active and can transmit data to the partner node. Automatic takeover of the partner is disabled.
Waiting for partner_name, Giveback of partner spare disks pending.	The local node cannot exchange information with the partner node over the HA interconnect. Giveback of SFO aggregates to the partner is done, but partner spare disks are still owned by the local node. <ul style="list-style-type: none"> • Run the <code>storage failover show-giveback</code> command for more information.
Waiting for partner_name. Waiting for partner lock synchronization.	The local node cannot exchange information with the partner node over the HA interconnect, and is waiting for partner lock synchronization to occur.
Waiting for partner_name. Waiting for cluster applications to come online on the local node.	The local node cannot exchange information with the partner node over the HA interconnect, and is waiting for cluster applications to come online.
Takeover scheduled. target node relocating its SFO aggregates in preparation of takeover.	Takeover processing has started. The target node is relocating ownership of its SFO aggregates in preparation for takeover.
Takeover scheduled. target node has relocated its SFO aggregates in preparation of takeover.	Takeover processing has started. The target node has relocated ownership of its SFO aggregates in preparation for takeover.
Takeover scheduled. Waiting to disable background disk firmware updates on local node. A firmware update is in progress on the node.	Takeover processing has started. The system is waiting for background disk firmware update operations on the local node to complete.
Relocating SFO aggregates to taking over node in preparation of takeover.	The local node is relocating ownership of its SFO aggregates to the taking-over node in preparation for takeover.

<p>Relocated SFO aggregates to taking over node. Waiting for taking over node to takeover.</p>	<p>Relocation of ownership of SFO aggregates from the local node to the taking-over node has completed. The system is waiting for takeover by the taking-over node.</p>
<p>Relocating SFO aggregates to partner_name. Waiting to disable background disk firmware updates on the local node. A firmware update is in progress on the node.</p>	<p>Relocation of ownership of SFO aggregates from the local node to the taking-over node is in progress. The system is waiting for background disk firmware update operations on the local node to complete.</p>
<p>Relocating SFO aggregates to partner_name. Waiting to disable background disk firmware updates on partner_name. A firmware update is in progress on the node.</p>	<p>Relocation of ownership of SFO aggregates from the local node to the taking-over node is in progress. The system is waiting for background disk firmware update operations on the partner node to complete.</p>
<p>Connected to partner_name. Previous takeover attempt was aborted because reason. Local node owns some of partner's SFO aggregates. Reissue a takeover of the partner with the <code>-bypass-optimization</code> parameter set to true to takeover remaining aggregates, or issue a giveback of the partner to return the relocated aggregates.</p>	<p>The HA interconnect is active and can transmit data to the partner node. The previous takeover attempt was aborted because of the reason displayed under reason. The local node owns some of its partner's SFO aggregates.</p> <ul style="list-style-type: none"> • Either reissue a takeover of the partner node, setting the <code>-bypass-optimization</code> parameter to true to takeover the remaining SFO aggregates, or perform a giveback of the partner to return relocated aggregates.
<p>Connected to partner_name. Previous takeover attempt was aborted. Local node owns some of partner's SFO aggregates. Reissue a takeover of the partner with the <code>-bypass-optimization</code> parameter set to true to takeover remaining aggregates, or issue a giveback of the partner to return the relocated aggregates.</p>	<p>The HA interconnect is active and can transmit data to the partner node. The previous takeover attempt was aborted. The local node owns some of its partner's SFO aggregates.</p> <ul style="list-style-type: none"> • Either reissue a takeover of the partner node, setting the <code>-bypass-optimization</code> parameter to true to takeover the remaining SFO aggregates, or perform a giveback of the partner to return relocated aggregates.
<p>Waiting for partner_name. Previous takeover attempt was aborted because reason. Local node owns some of partner's SFO aggregates. Reissue a takeover of the partner with the <code>"-bypass-optimization"</code> parameter set to true to takeover remaining aggregates, or issue a giveback of the partner to return the relocated aggregates.</p>	<p>The local node cannot exchange information with the partner node over the HA interconnect. The previous takeover attempt was aborted because of the reason displayed under reason. The local node owns some of its partner's SFO aggregates.</p> <ul style="list-style-type: none"> • Either reissue a takeover of the partner node, setting the <code>-bypass-optimization</code> parameter to true to takeover the remaining SFO aggregates, or perform a giveback of the partner to return relocated aggregates.

<p>Waiting for partner_name. Previous takeover attempt was aborted. Local node owns some of partner's SFO aggregates. Reissue a takeover of the partner with the "-bypass-optimization" parameter set to true to takeover remaining aggregates, or issue a giveback of the partner to return the relocated aggregates.</p>	<p>The local node cannot exchange information with the partner node over the HA interconnect. The previous takeover attempt was aborted. The local node owns some of its partner's SFO aggregates.</p> <ul style="list-style-type: none"> • Either reissue a takeover of the partner node, setting the -bypass-optimization parameter to true to takeover the remaining SFO aggregates, or perform a giveback of the partner to return relocated aggregates.
<p>Connected to partner_name. Previous takeover attempt was aborted because failed to disable background disk firmware update (BDFU) on local node.</p>	<p>The HA interconnect is active and can transmit data to the partner node. The previous takeover attempt was aborted because the background disk firmware update on the local node was not disabled.</p>
<p>Connected to partner_name. Previous takeover attempt was aborted because reason.</p>	<p>The HA interconnect is active and can transmit data to the partner node. The previous takeover attempt was aborted because of the reason displayed under reason.</p>
<p>Waiting for partner_name. Previous takeover attempt was aborted because reason.</p>	<p>The local node cannot exchange information with the partner node over the HA interconnect. The previous takeover attempt was aborted because of the reason displayed under reason.</p>
<p>Connected to partner_name. Previous takeover attempt by partner_name was aborted because reason.</p>	<p>The HA interconnect is active and can transmit data to the partner node. The previous takeover attempt by the partner node was aborted because of the reason displayed under reason.</p>
<p>Connected to partner_name. Previous takeover attempt by partner_name was aborted.</p>	<p>The HA interconnect is active and can transmit data to the partner node. The previous takeover attempt by the partner node was aborted.</p>
<p>Waiting for partner_name. Previous takeover attempt by partner_name was aborted because reason.</p>	<p>The local node cannot exchange information with the partner node over the HA interconnect. The previous takeover attempt by the partner node was aborted because of the reason displayed under reason.</p>
<p>Previous giveback failed in module: module name. Auto giveback will be initiated in number of seconds seconds.</p>	<p>The previous giveback attempt failed in module module_name. Auto giveback will be initiated in number of seconds seconds.</p> <ul style="list-style-type: none"> • Run the <code>storage failover show-giveback</code> command for more information.
<p>Node owns partner's aggregates as part of the non-disruptive controller upgrade procedure.</p>	<p>The node owns its partner's aggregates due to the non- disruptive controller upgrade procedure currently in progress.</p>

Connected to partner_name. Node owns aggregates belonging to another node in the cluster.	The HA interconnect is active and can transmit data to the partner node. The node owns aggregates belonging to another node in the cluster.
Connected to partner_name. Waiting for partner lock synchronization.	The HA interconnect is active and can transmit data to the partner node. The system is waiting for partner lock synchronization to complete.
Connected to partner_name. Waiting for cluster applications to come online on the local node.	The HA interconnect is active and can transmit data to the partner node. The system is waiting for cluster applications to come online on the local node.
Non-HA mode, reboot to use full NVRAM.	Storage failover is not possible. The HA mode option is configured as non_ha. <ul style="list-style-type: none"> You must reboot the node to use all of its NVRAM.
Non-HA mode. Reboot node to activate HA.	Storage failover is not possible. <ul style="list-style-type: none"> The node must be rebooted to enable HA capability.
Non-HA mode.	Storage failover is not possible. The HA mode option is configured as non_ha. <ul style="list-style-type: none"> You must run the <code>storage failover modify -mode ha -node nodename</code> command on both nodes in the HA pair and then reboot the nodes to enable HA capability.

Related information

- [ONTAP command reference](#)
- [cluster ha show](#)
- [storage failover hwassist](#)
- [storage failover modify](#)
- [storage failover show](#)
- [storage failover show-giveback](#)

ONTAP commands for enabling and disabling storage failover

Use the following commands to enable and disable storage failover functionality.

If you want to...	Use this command...
Enable takeover	<code>storage failover modify -enabled true -node nodename</code>

Disable takeover	<code>storage failover modify -enabled false -node <i>nodename</i></code>
------------------	---



You should only disable storage failover if required as part of a maintenance procedure.

Related information

- [storage failover modify](#)

Halt or reboot ONTAP nodes without initiating takeover in two-node clusters

You halt or reboot a node in a two-node cluster without initiating takeover when you perform certain hardware maintenance on a node or a shelf and you want to limit down time by keeping the partner node up, or when there are issues preventing a manual takeover and you want to keep the partner node's aggregates up and serving data. Additionally, if technical support is assisting you with troubleshooting problems, they might have you perform this procedure as part of those efforts.

About this task

- Before you inhibit takeover (using the `-inhibit-takeover true` parameter), you disable cluster HA.



- In a two-node cluster, cluster HA ensures that the failure of one node does not disable the cluster. However, if you do not disable cluster HA before using the `-inhibit-takeover true` parameter, both nodes stop serving data.
- If you attempt to halt or reboot a node before disabling cluster HA, ONTAP issues a warning and instructs you to disable cluster HA.

- You migrate LIFs (logical interfaces) to the partner node that you want to remain online.
- If on the node you are halting or rebooting there are aggregates you want to keep, you move them to the node that you want to remain online.

Steps

1. Verify both nodes are healthy:

```
cluster show
```

For both nodes, `true` appears in the `Health` column.

```
cluster::> cluster show
Node          Health  Eligibility
-----
node1         true   true
node2         true   true
```

Learn more about `cluster show` in the [ONTAP command reference](#).

2. Migrate all LIFs from the node that you will halt or reboot to the partner node:

```
network interface migrate-all -node node_name
```

Learn more about `network interface migrate-all` in the [ONTAP command reference](#).

3. If on the node you will halt or reboot there are aggregates you want to keep online when the node is down, relocate them to the partner node; otherwise, go to the next step.

- a. Show the aggregates on the node you will halt or reboot:

```
storage aggregates show -node node_name
```

For example, `node1` is the node that will be halted or rebooted:

```
cluster::> storage aggregates show -node node1
Aggregate Size Available Used% State #Vols Nodes RAID
Status
-----
-----
aggr0_node_1_0
      744.9GB 32.68GB 96% online      2 node1 raid_dp,
normal
aggr1      2.91TB 2.62TB 10% online      8 node1 raid_dp,
normal
aggr2      4.36TB 3.74TB 14% online     12 node1 raid_dp,
normal
test2_aggr 2.18TB 2.18TB 0% online      7 node1 raid_dp,
normal
4 entries were displayed.
```

- b. Move the aggregates to the partner node:

```
storage aggregate relocation start -node node_name -destination node_name
-aggregate-list aggregate_name
```

For example, aggregates `aggr1`, `aggr2` and `test2_aggr` are being moved from `node1` to `node2`:

```
storage aggregate relocation start -node node1 -destination node2 -aggregate
-list aggr1,aggr2,test2_aggr
```

4. Disable cluster HA:

```
cluster ha modify -configured false
```

The return output confirms HA is disabled: Notice: HA is disabled



This operation does not disable storage failover.

5. Halt or reboot and inhibit takeover of the target node, by using the appropriate command:

- `system node halt -node node_name -inhibit-takeover true`
- `system node reboot -node node_name -inhibit-takeover true`



In the command output, you will see a warning asking you if you want to proceed, enter `y`.

6. Verify that the node that is still online is in a healthy state (while the partner is down):

```
cluster show
```

For the online node, `true` appears in the `Health` column.



In the command output, you will see a warning that cluster HA is not configured. You can ignore the warning at this time.

7. Perform the actions that required you to halt or reboot the node.

8. Boot the offlined node from the `LOADER` prompt:

```
boot_ontap
```

9. Verify both nodes are healthy:

```
cluster show
```

For both nodes, `true` appears in the `Health` column.



In the command output, you will see a warning that cluster HA is not configured. You can ignore the warning at this time.

10. Reenable cluster HA:

```
cluster ha modify -configured true
```

11. If earlier in this procedure you relocated aggregates to the partner node, move them back to their home node; otherwise, go to the next step:

```
storage aggregate relocation start -node node_name -destination node_name
-aggregate-list aggregate_name
```

For example, aggregates `aggr1`, `aggr2` and `test2_aggr` are being moved from node `node2` to node `node1`:

```
storage aggregate relocation start -node node2 -destination node1 -aggregate
-list aggr1,aggr2,test2_aggr
```

12. Revert LIFs to their home ports:

- a. View LIFs that are not at home:

```
network interface show -is-home false
```

Learn more about `network interface show` in the [ONTAP command reference](#).

- b. If there are non-home LIFs that were not migrated from the down node, verify it is safe to move them before reverting.

- c. If it is safe to do so, revert all LIFs home.

```
network interface revert *
```

Learn more about `network interface revert` in the [ONTAP command reference](#).

Related information

- [cluster ha modify](#)
- [storage aggregate relocation start](#)

Configure encryption for ONTAP HA traffic

Beginning with ONTAP 9.18.1, you can configure encryption for network traffic between high-availability (HA) pair nodes. This encryption protects customer data and metadata sent between nodes in an HA pair.

About this task

- Encryption for HA traffic is disabled by default.
- Enabling or disabling HA traffic encryption affects all HA pairs in the cluster. You cannot enable or disable encryption for individual nodes.
- When you enable HA traffic encryption, all customer data and metadata transmitted between HA pair nodes is encrypted. Some HA traffic, such as filesystem metadata and heartbeat messages, is not encrypted.
- When HA traffic encryption is enabled and new HA pairs are added to the cluster, you need to manually enable HA traffic encryption for the new nodes by rerunning the `security ha-network modify -enabled true` command.

Before you begin

- You must be an ONTAP administrator at the `admin` privilege level to perform the following procedure.
- Before enabling HA traffic encryption, you must [Configure external key management](#).
- All nodes in the cluster must be running ONTAP 9.18.1 or later to enable HA traffic encryption.

Steps

1. View the current encryption status for HA traffic:

```
security ha-network show
```

This command shows the current status of HA traffic encryption for each node:

```
security ha-network show
Node                Enabled
-----
node1               true
node2               true
node3               true
node4               true
4 entries were displayed.
```

2. Enable or disable encryption for HA traffic:

```
security ha-network modify -enabled <true|false>
```

This command enables or disables encrypted HA traffic for all nodes in the cluster. When new HA pairs are added to the cluster, you will need to rerun this command to enable HA traffic encryption for the new nodes.

REST API management with System Manager

REST API management with System Manager

The REST API log captures the API calls that System Manager issues to ONTAP. You can use the log to understand the nature and sequence of the calls needed to perform the various ONTAP administrative tasks.

How System Manager uses the REST API and API log

There are several ways that REST API calls are issued by System Manager to ONTAP.

When does System Manager issue API calls

Here are the most important examples of when System Manager issues ONTAP REST API calls.

Automatic page refresh

System Manager automatically issues API calls in the background to refresh the displayed information, such as on the dashboard page.

Display action by user

One or more API calls are issued when you display a specific storage resource or a collection of resources from the System Manager UI.

Update action by user

An API call is issued when you add, modify, or delete an ONTAP resource from the System Manager UI.

Reissuing an API call

You can also manually reissue an API call by clicking a log entry. This displays the raw JSON output from the call.

More information

- [ONTAP 9 Automation docs](#)

Accessing the REST API log

You can access the log containing a record of the ONTAP REST API calls made by System Manager. When displaying the log, you can also reissue API calls and review the output.

Steps

1. At the top of the page, click  to display the REST API log.

The most recent entries are displayed at the bottom of the page.

2. On the left, click **DASHBOARD** and observe the new entries being created for the API calls issued to refresh the page.
3. Click **STORAGE** and then click **Qtrees**.

This causes System Manager to issue a specific API call to retrieve a list of the Qtrees.

4. Locate the log entry describing the API call which has the form:

```
GET /api/storage/qtrees
```

You will see additional HTTP query parameters included with the entry, such as `max_records`.

5. Click the log entry to reissue the GET API call and display the raw JSON output.

Example

```
1 {
2   "records": [
3     {
4       "svm": {
5         "uuid": "19507946-e801-11e9-b984-00a0986ab770",
6         "name": "SMQA",
7         "_links": {
8           "self": {
9             "href": "/api/svm/svms/19507946-e801-11e9-b984-
10            00a0986ab770"
11           }
12         },
13         "volume": {
14           "uuid": "1e173258-f98b-11e9-8f05-00a0986abd71",
15           "name": "vol_vol_test2_dest_dest",
16           "_links": {
17             "self": {
18               "href": "/api/storage/volumes/1e173258-f98b-11e9-8f05-
19              00a0986abd71"
20             }
21           },
22           "id": 1,
23           "name": "test2",
24           "security_style": "mixed",
25           "unix_permissions": 777,
```

```
26     "export_policy": {
27         "name": "default",
28         "id": 12884901889,
29         "_links": {
30             "self": {
31                 "href": "/api/protocols/nfs/export-policies/12884901889"
32             }
33         }
34     },
35     "path": "/vol_vol_test2_dest_dest/test2",
36     "_links": {
37         "self": {
38             "href": "/api/storage/qtrees/1e173258-f98b-11e9-8f05-
00a0986abd71/1"
39         }
40     }
41 },
42 ],
43 "num_records": 1,
44 "_links": {
45     "self": {
46         "href":
47         "/api/storage/qtrees?max_records=20&fields=*&name=!%22%22"
48     }
49 }
```

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.