



# List of events and severity types

## Active IQ Unified Manager 9.11

NetApp

November 12, 2024

# Table of Contents

- List of events and severity types ..... 1
  - Aggregate events ..... 1
  - Cluster events ..... 5
  - Disks events ..... 10
  - Enclosures events ..... 11
  - Fans events ..... 12
  - Flash card events ..... 13
  - Inodes events ..... 13
  - Network interface (LIF) events ..... 13
  - LUN events ..... 15
  - Management station events ..... 19
  - MetroCluster Bridge events ..... 21
  - MetroCluster Connectivity events ..... 21
  - MetroCluster switch events ..... 23
  - NVMe Namespace events ..... 24
  - Node events ..... 26
  - NVRAM battery events ..... 31
  - Port events ..... 31
  - Power supplies events ..... 32
  - Protection events ..... 33
  - Qtree events ..... 33
  - Service processor events ..... 34
  - SnapMirror relationship events ..... 34
  - Asynchronous Mirror and Vault relationship events ..... 36
  - Snapshot events ..... 38
  - SnapVault relationship events ..... 38
  - Storage failover settings events ..... 39
  - Storage services events ..... 40
  - Storage shelf events ..... 41
  - Storage VM events ..... 41
  - User and group quota events ..... 45
  - Volume events ..... 46
  - Volume move status events ..... 55

# List of events and severity types

You can use the list of events to become more familiar with event categories, event names, and the severity type of each event that you might see in Unified Manager. Events are listed in alphabetical order by object category.

## Aggregate events

Aggregate events provide you with information about the status of aggregates so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

An asterisk (\*) identifies EMS events that have been converted to Unified Manager events.

Event name(Trap name)	Impact level	Source type	Severity
Aggregate Offline(ocumEvtAggregateStateOffline)	Incident	Aggregate	Critical
Aggregate Failed(ocumEvtAggregateStateFailed)	Incident	Aggregate	Critical
Aggregate Restricted(ocumEvtAggregateStateRestricted)	Risk	Aggregate	Warning
Aggregate Reconstructing(ocumEvtAggregateRaidStateReconstructing)	Risk	Aggregate	Warning
Aggregate Degraded(ocumEvtAggregateRaidStateDegraded)	Risk	Aggregate	Warning
Cloud Tier Partially Reachable(ocumEventCloudTierPartiallyReachable)	Risk	Aggregate	Warning
Cloud Tier Unreachable(ocumEventCloudTierUnreachable)	Risk	Aggregate	Error

Event name(Trap name)	Impact level	Source type	Severity
Cloud Tier Access Denied for Aggregate Relocation *(arINetraCaCheckFailed)	Risk	Aggregate	Error
Cloud Tier Access Denied for Aggregate Relocation During Storage Failover *(gbNetraCaCheckFailed)	Risk	Aggregate	Error
MetroCluster Aggregate Left Behind(ocumEvtMetroClusterAggregateLeftBehind)	Risk	Aggregate	Error
MetroCluster Aggregate Mirroring Degraded(ocumEvtMetroClusterAggregateMirrorDegraded)	Risk	Aggregate	Error

### Impact area: capacity

Event name(Trap name)	Impact level	Source type	Severity
Aggregate Space Nearly Full(ocumEvtAggregateNearlyFull)	Risk	Aggregate	Warning
Aggregate Space Full(ocumEvtAggregateFull)	Risk	Aggregate	Error
Aggregate Days Until Full(ocumEvtAggregateDaysUntilFullSoon)	Risk	Aggregate	Error
Aggregate Overcommitted(ocumEvtAggregateOvercommitted)	Risk	Aggregate	Error
Aggregate Nearly Overcommitted(ocumEvtAggregateAlmostOvercommitted)	Risk	Aggregate	Warning

Event name(Trap name)	Impact level	Source type	Severity
Aggregate Snapshot Reserve Full(ocumEvtAggregateSnapshotReserveFull)	Risk	Aggregate	Warning
Aggregate Growth Rate Abnormal(ocumEvtAggregateGrowthRateAbnormal)	Risk	Aggregate	Warning

### Impact area: configuration

Event name(Trap name)	Impact level	Source type	Severity
Aggregate Discovered(Not applicable)	Event	Aggregate	Information
Aggregate Renamed(Not applicable)	Event	Aggregate	Information
Aggregate Deleted(Not applicable)	Event	Node	Information

### Impact area: performance

Event name(Trap name)	Impact level	Source type	Severity
Aggregate IOPS Critical Threshold Breached(ocumAggregateIopsIncident)	Incident	Aggregate	Critical
Aggregate IOPS Warning Threshold Breached(ocumAggregateIopsWarning)	Risk	Aggregate	Warning
Aggregate MB/s Critical Threshold Breached(ocumAggregateMbpsIncident)	Incident	Aggregate	Critical
Aggregate MB/s Warning Threshold Breached(ocumAggregateMbpsWarning)	Risk	Aggregate	Warning

<b>Event name(Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
Aggregate Latency Critical Threshold Breached(ocumAggregateLatencyIncident)	Incident	Aggregate	Critical
Aggregate Latency Warning Threshold Breached(ocumAggregateLatencyWarning)	Risk	Aggregate	Warning
Aggregate Performance Capacity Used Critical Threshold Breached(ocumAggregatePerfCapacityUsedIncident)	Incident	Aggregate	Critical
Aggregate Performance Capacity Used Warning Threshold Breached(ocumAggregatePerfCapacityUsedWarning)	Risk	Aggregate	Warning
Aggregate Utilization Critical Threshold Breached (ocumAggregateUtilizationIncident)	Incident	Aggregate	Critical
Aggregate Utilization Warning Threshold Breached (ocumAggregateUtilizationWarning)	Risk	Aggregate	Warning
Aggregate Disks Over-utilized Threshold Breached (ocumAggregateDisksOverUtilizedWarning)	Risk	Aggregate	Warning
Aggregate Dynamic Threshold Breached (ocumAggregateDynamicEventWarning)	Risk	Aggregate	Warning

# Cluster events

Cluster events provide information about the status of clusters, which enables you to monitor the clusters for potential problems. The events are grouped by impact area, and include the event name, trap name, impact level, source type, and severity.

## Impact area: availability

An asterisk (\*) identifies EMS events that have been converted to Unified Manager events.

Event name (Trap name)	Impact level	Source type	Severity
Cluster Lacks Spare Disks(ocumEvtDisksNoSpares)	Risk	Cluster	Warning
Cluster Not Reachable(ocumEvtClusterUnreachable)	Risk	Cluster	Error
Cluster Monitoring Failed(ocumEvtClusterMonitoringFailed)	Risk	Cluster	Warning
Cluster FabricPool License Capacity Limits Breached (ocumEvtExternalCapacityTierSpaceFull)	Risk	Cluster	Warning
NVMe-oF Grace Period Started *(nvmfGracePeriodStart)	Risk	Cluster	Warning
NVMe-oF Grace Period Active *(nvmfGracePeriodActive)	Risk	Cluster	Warning
NVMe-oF Grace Period Expired *(nvmfGracePeriodExpired)	Risk	Cluster	Warning
Object Maintenance Window Started(objectMaintenanceWindowStarted)	Event	Cluster	Critical

Event name (Trap name)	Impact level	Source type	Severity
Object Maintenance Window Ended(objectMaintenanceWindowEnded)	Event	Cluster	Information
MetroCluster Spare Disks Left Behind(ocumEvtSpareDiskLeftBehind)	Risk	Cluster	Error
MetroCluster Automatic Unplanned Switchover Disabled(ocumEvtMccAutomaticUnplannedSwitchoverDisabled)	Risk	Cluster	Warning
Cluster user password changed *(cluster.passwd.changed)	Event	Cluster	Information

### Impact area: capacity

Event name(Trap name)	Impact level	Source type	Severity
Cluster Capacity Imbalance Threshold Breached(ocumConformanceNodeImbalanceWarning)	Risk	Cluster	Warning
Cluster Cloud Tier Planning (clusterCloudTierPlanningWarning)	Risk	Cluster	Warning
FabricPool Mirror Replication Resync Completed *(wafIcaResyncComplete)	Event	Cluster	Warning
FabricPool Space Nearly Full *(fabricpoolNearlyFull)	Risk	Cluster	Error



## Impact area: configuration

Event name(Trap name)	Impact level	Source type	Severity
Node Added(Not applicable)	Event	Cluster	Information
Node Removed(Not applicable)	Event	Cluster	Information
Cluster Removed(Not applicable)	Event	Cluster	Information
Cluster Add Failed(Not applicable)	Event	Cluster	Error
Cluster Name Changed(Not applicable)	Event	Cluster	Information
Emergency EMS received (Not applicable)	Event	Cluster	Critical
Critical EMS received (Not applicable)	Event	Cluster	Critical
Alert EMS received (Not applicable)	Event	Cluster	Error
Error EMS received (Not applicable)	Event	Cluster	Warning
Warning EMS received (Not applicable)	Event	Cluster	Warning
Debug EMS received (Not applicable)	Event	Cluster	Warning
Notice EMS received (Not applicable)	Event	Cluster	Warning
Informational EMS received (Not applicable)	Event	Cluster	Warning

ONTAP EMS events are categorized into three Unified Manager event severity levels.

Unified Manager event severity level	ONTAP EMS event severity level
--------------------------------------	--------------------------------

Critical	Emergency Critical
Error	Alert
Warning	Error Warning Debug Notice Informational

### Impact area: performance

Event name(Trap name)	Impact level	Source type	Severity
Cluster Load Imbalance Threshold Breached()	Risk	Cluster	Warning
Cluster IOPS Critical Threshold Breached(ocumClusterIopsIncident)	Incident	Cluster	Critical
Cluster IOPS Warning Threshold Breached(ocumClusterIopsWarning)	Risk	Cluster	Warning
Cluster MB/s Critical Threshold Breached(ocumClusterMbpsIncident)	Incident	Cluster	Critical
Cluster MB/s Warning Threshold Breached(ocumClusterMbpsWarning)	Risk	Cluster	Warning
Cluster Dynamic Threshold Breached(ocumClusterDynamicEventWarning)	Risk	Cluster	Warning

## Impact area: security

Event name(Trap name)	Impact level	Source type	Severity
AutoSupport HTTPS Transport Disabled(ocumClusterASUPHttpsConfiguredDisabled)	Risk	Cluster	Warning
Log Forwarding Not Encrypted(ocumClusterAuditLogUnencrypted)	Risk	Cluster	Warning
Default Local Admin User Enabled(ocumClusterDefaultAdminEnabled)	Risk	Cluster	Warning
FIPS Mode Disabled(ocumClusterFipsDisabled)	Risk	Cluster	Warning
Login Banner Disabled(ocumClusterLoginBannerDisabled)	Risk	Cluster	Warning
Login Banner Changed(ocumClusterLoginBannerChanged)	Risk	Cluster	Warning
Log Forwarding Destinations Changed(ocumLogForwardDestinationsChanged)	Risk	Cluster	Warning
NTP Server Names Changed(ocumNtpServerNamesChanged)	Risk	Cluster	Warning
NTP Server Count is Low(securityConfigNTPServerCountLowRisk)	Risk	Cluster	Warning
Cluster Peer Communication Not Encrypted(ocumClusterPeerEncryptionDisabled)	Risk	Cluster	Warning

Event name(Trap name)	Impact level	Source type	Severity
SSH is Using Insecure Ciphers(ocumClusterSSH Insecure)	Risk	Cluster	Warning
Telnet Protocol Enabled(ocumClusterTelnetEnabled)	Risk	Cluster	Warning
Passwords of some ONTAP user accounts use the less secure MD5 hash function(ocumClusterMD5 PasswordHashUsed)	Risk	Cluster	Warning
Cluster uses self-signed Certificate(ocumClusterSelfSignedCertificate)	Risk	Cluster	Warning
Cluster Remote Shell is Enabled(ocumClusterRsh Disabled)	Risk	Cluster	Warning
Cluster Certificate About to Expire(ocumEvtClusterCertificateAboutToExpire)	Risk	Cluster	Warning
Cluster Certificate Expired(ocumEvtClusterCertificateExpired)	Risk	Cluster	Error

## Disks events

Disks events provide you with information about the status of disks so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Flash Disks - Spare Blocks Almost Consumed(ocumEvtClusterFlashDiskFewerSpareBlockError)	Risk	Cluster	Error
Flash Disks - No Spare Blocks(ocumEvtClusterFlashDiskNoSpareBlockCritical)	Incident	Cluster	Critical
Some Unassigned Disks(ocumEvtClusterUnassignedDisksSome)	Risk	Cluster	Warning
Some Failed Disks(ocumEvtDisksSomeFailed)	Incident	Cluster	Critical

## Enclosures events

Enclosures events provide you with information about the status of disk shelf enclosures in your data center so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Disk Shelf Fans Failed(ocumEvtShelfFanFailed)	Incident	Storage shelf	Critical
Disk Shelf Power Supplies Failed(ocumEvtShelfPowerSupplyFailed)	Incident	Storage shelf	Critical

Event name (Trap name)	Impact level	Source type	Severity
Disk Shelf Multipath Not Configured(ocumDiskShelfConnectivityNotInMultiPath)  This event does not apply to:  <ul style="list-style-type: none"> <li>• Clusters that are in a MetroCluster configuration</li> <li>• The following platforms: FAS2554, FAS2552, FAS2520, and FAS2240</li> </ul>	Risk	Node	Warning
Disk Shelf Path Failure(ocumDiskShelfConnectivityPathFailure)	Risk	Storage Shelf	Warning

### Impact area: configuration

Event name (Trap name)	Impact level	Source type	Severity
Disk Shelf Discovered(Not applicable)	Event	Node	Information
Disk Shelves Removed(Not applicable)	Event	Node	Information

## Fans events

Fans events provide you with information about the status fans on nodes in your data center so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
One or More Failed Fans(ocumEvtFansOneOrMoreFailed)	Incident	Node	Critical

## Flash card events

Flash card events provide you with information about the status of the flash cards installed on nodes in your data center so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Flash Cards Offline(ocumEvtFlashCardOffline)	Incident	Node	Critical

## Inodes events

Inode events provide information when the inode is full or nearly full so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: capacity

Event name (Trap name)	Impact level	Source type	Severity
Inodes Nearly Full(ocumEvtInodesAlmostFull)	Risk	Volume	Warning
Inodes Full(ocumEvtInodesFull)	Risk	Volume	Error

## Network interface (LIF) events

Network interface events provide information about the status of your network interface (LIFs), so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Network Interface Status Down(ocumEvtLifStatusDown)	Risk	Interface	Error

Event name (Trap name)	Impact level	Source type	Severity
FC/FCoE Network Interface Status Down(ocumEvtFCLifStatusDown)	Risk	Interface	Error
Network Interface Failover Not Possible(ocumEvtLifFailoverNotPossible)	Risk	Interface	Warning
Network Interface Not At Home Port(ocumEvtLifNotAtHomePort)	Risk	Interface	Warning

### Impact area: configuration

Event name (Trap name)	Impact level	Source type	Severity
Network Interface Route Not Configured(Not applicable)	Event	Interface	Information

### Impact area: performance

Event name (Trap name)	Impact level	Source type	Severity
Network Interface MB/s Critical Threshold Breached(ocumNetworkLifMbpsIncident)	Incident	Interface	Critical
Network Interface MB/s Warning Threshold Breached(ocumNetworkLifMbpsWarning)	Risk	Interface	Warning
FC Network Interface MB/s Critical Threshold Breached(ocumFcpLifMbpsIncident)	Incident	Interface	Critical
FC Network Interface MB/s Warning Threshold Breached(ocumFcpLifMbpsWarning)	Risk	Interface	Warning



Event name (Trap name)	Impact level	Source type	Severity
NVMf FC Network Interface MB/s Critical Threshold Breached(ocumNvmfFcLifMbpsIncident)	Incident	Interface	Critical
NVMf FC Network Interface MB/s Warning Threshold Breached(ocumNvmfFcLifMbpsWarning)	Risk	Interface	Warning

## LUN events

LUN events provide you with information about the status of your LUNs, so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

An asterisk (\*) identifies EMS events that have been converted to Unified Manager events.

Event name (Trap name)	Impact level	Source type	Severity
LUN Offline(ocumEvtLunOffline)	Incident	LUN	Critical
LUN Destroyed *(lunDestroy)	Event	LUN	Information
LUN mapped with unsupported operating system in igroup(igroupUnsupportedOsType)	Incident	LUN	Warning
Single Active Path To Access LUN(ocumEvtLunSingleActivePath)	Risk	LUN	Warning
No Active Paths To Access LUN(ocumEvtLunNotReachable)	Incident	LUN	Critical

Event name (Trap name)	Impact level	Source type	Severity
No Optimized Paths To Access LUN(ocumEvtLunOptimizedPathInactive)	Risk	LUN	Warning
No Paths To Access LUN From HA Partner(ocumEvtLunHaPathInactive)	Risk	LUN	Warning
No Path to Access LUN from one Node in HA-pair(ocumEvtLunNodePathStatusDown)	Risk	LUN	Error

### Impact area: capacity

Event name (Trap name)	Impact level	Source type	Severity
Insufficient Space For LUN Snapshot Copy(ocumEvtLunSnapshotNotPossible)	Risk	Volume	Warning

### Impact area: configuration

Event name (Trap name)	Impact level	Source type	Severity
LUN mapped with unsupported operating system in igroup(igroupUnsupportedOsType)	Risk	LUN	Warning

### Impact area: performance

Event name (Trap name)	Impact level	Source type	Severity
LUN IOPS Critical Threshold Breached(ocumLunIopsIncident)	Incident	LUN	Critical
LUN IOPS Warning Threshold Breached(ocumLunIopsWarning)	Risk	LUN	Warning

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
LUN MB/s Critical Threshold Breached(ocumLunMbpsIncident)	Incident	LUN	Critical
LUN MB/s Warning Threshold Breached(ocumLunMbpsWarning)	Risk	LUN	Warning
LUN Latency ms/op Critical Threshold Breached(ocumLunLatencyIncident)	Incident	LUN	Critical
LUN Latency ms/op Warning Threshold Breached(ocumLunLatencyWarning)	Risk	LUN	Warning
LUN Latency and IOPS Critical Threshold Breached(ocumLunLatencyIopsIncident)	Incident	LUN	Critical
LUN Latency and IOPS Warning Threshold Breached(ocumLunLatencyIopsWarning)	Risk	LUN	Warning
LUN Latency and MB/s Critical Threshold Breached(ocumLunLatencyMbpsIncident)	Incident	LUN	Critical
LUN Latency and MB/s Warning Threshold Breached(ocumLunLatencyMbpsWarning)	Risk	LUN	Warning
LUN Latency and Aggregate Performance Capacity Used Critical Threshold Breached(ocumLunLatencyAggregatePerfCapacityUsedIncident)	Incident	LUN	Critical

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
LUN Latency and Aggregate Performance Capacity Used Warning Threshold Breached(ocumLunLatencyAggregatePerfCapacityUsedWarning)	Risk	LUN	Warning
LUN Latency and Aggregate Utilization Critical Threshold Breached(ocumLunLatencyAggregateUtilizationIncident)	Incident	LUN	Critical
LUN Latency and Aggregate Utilization Warning Threshold Breached(ocumLunLatencyAggregateUtilizationWarning)	Risk	LUN	Warning
LUN Latency and Node Performance Capacity Used Critical Threshold Breached(ocumLunLatencyNodePerfCapacityUsedIncident)	Incident	LUN	Critical
LUN Latency and Node Performance Capacity Used Warning Threshold Breached(ocumLunLatencyNodePerfCapacityUsedWarning)	Risk	LUN	Warning
LUN Latency and Node Performance Capacity Used - Takeover Critical Threshold Breached(ocumLunLatencyAggregatePerfCapacityUsedTakeoverIncident)	Incident	LUN	Critical

Event name (Trap name)	Impact level	Source type	Severity
LUN Latency and Node Performance Capacity Used - Takeover Warning Threshold Breached(ocumLunLatencyAggregatePerfCapacityUsedTakeoverWarning)	Risk	LUN	Warning
LUN Latency and Node Utilization Critical Threshold Breached(ocumLunLatencyNodeUtilizationIncident)	Incident	LUN	Critical
LUN Latency and Node Utilization Warning Threshold Breached(ocumLunLatencyNodeUtilizationWarning)	Risk	LUN	Warning
QoS LUN Max IOPS Warning Threshold Breached(ocumQosLunMaxIopsWarning)	Risk	LUN	Warning
QoS LUN Max MB/s Warning Threshold Breached(ocumQosLunMaxMbpsWarning)	Risk	LUN	Warning
Workload LUN Latency Threshold Breached as defined by Performance Service Level Policy(ocumConformanceLatencyWarning)	Risk	LUN	Warning

## Management station events

Management station events provide you with information about the status of server on which Unified Manager is installed so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

## Impact area: configuration

Event name (Trap name)	Impact level	Source type	Severity
Management Server Disk Space Nearly Full(ocumEvtUnifiedManagerDiskSpaceNearlyFull)	Risk	Management station	Warning
Management Server Disk Space Full(ocumEvtUnifiedManagerDiskSpaceFull)	Incident	Management station	Critical
Management Server Low On Memory(ocumEvtUnifiedManagerMemoryLow)	Risk	Management station	Warning
Management Server Almost Out Of Memory(ocumEvtUnifiedManagerMemoryAlmostOut)	Incident	Management station	Critical
MySQL Log File Size Increased; Restart Required(ocumEvtMySQLLogFileSizeWarning)	Incident	Management station	Warning
Total Audit Log Size Allocation is About to Get Full	Risk	Management station	Warning
Syslog Server Certificate About to Expire	Risk	Management station	Warning
Syslog Server Certificate Expired	Risk	Management station	Error
Audit Log File Tampered	Risk	Management station	Warning
Audit Log File Deleted	Risk	Management station	Warning
Syslog Server Connection Error	Risk	Management station	Error
Syslog Server Configuration Changed	Event	Management station	Warning

## Impact area: performance

Event name (Trap name)	Impact level	Source type	Severity
Performance Data Analysis Is Impacted(ocumEvtUnifiedManagerDataMissingAnalyze)	Risk	Management station	Warning
Performance Data Collection Is Impacted(ocumEvtUnifiedManagerDataMissingCollection)	Incident	Management station	Critical



These last two performance events were available for Unified Manager 7.2 only. If either of these events exist in the New state, and then you upgrade to a newer version of Unified Manager software, the events will not be purged automatically. You will need to move the events to the Resolved state manually.

## MetroCluster Bridge events

MetroCluster Bridge events provide you with information about the status of the bridges so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Bridge Unreachable(ocumEvtBridgeUnreachable)	Incident	MetroCluster Bridge	Critical
Bridge Temperature Abnormal(ocumEvtBridgeTemperatureAbnormal)	Incident	MetroCluster Bridge	Critical

## MetroCluster Connectivity events

Connectivity events provide you with information about the connectivity between the components of a cluster and between clusters in a MetroCluster configuration so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

## Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
All Inter-Switch Links Down(ocumEvtMetroClusterAllISLBetweenSwitchesDown)	Incident	MetroCluster inter-switch connection	Critical
All Links Between MetroCluster Partners Down(ocumEvtMetroClusterAllLinksBetweenPartnersDown)	Incident	MetroCluster relationship	Critical
FC-SAS Bridge To Storage Stack Link Down(ocumEvtBridgeSasPortDown)	Incident	MetroCluster bridge stack connection	Critical
MetroCluster Configuration Switched Over(ocumEvtMetroClusterDRStatusImpacted)	Risk	MetroCluster relationship	Warning
MetroCluster Configuration Partially Switched Over(ocumEvtMetroClusterDRStatusPartiallyImpacted)	Risk	MetroCluster relationship	Error
MetroCluster Disaster Recovery Capability Impacted(ocumEvtMetroClusterDRStatusImpacted)	Risk	MetroCluster relationship	Critical
MetroCluster Partners Not Reachable Over Peering Network(ocumEvtMetroClusterPartnersNotReachableOverPeeringNetwork)	Incident	MetroCluster relationship	Critical
Node To FC Switch All FC-VI Interconnect Links Down(ocumEvtMccNodeSwitchFcviLinksDown)	Incident	MetroCluster node switch connection	Critical



Event name (Trap name)	Impact level	Source type	Severity
Node To FC Switch One Or More FC-Initiator Links Down(ocumEvtMccNodeSwitchFcLinksOneOrMoreDown)	Risk	MetroCluster node switch connection	Warning
Node To FC Switch All FC-Initiator Links Down(ocumEvtMccNodeSwitchFcLinksDown)	Incident	MetroCluster node switch connection	Critical
Switch To FC-SAS Bridge FC Link Down (ocumEvtMccSwitchBridgeFcLinksDown)	Incident	MetroCluster switch bridge connection	Critical
Inter Node All FC VI InterConnect Links Down (ocumEvtMccInterNodeLinksDown)	Incident	Inter-node connection	Critical
Inter Node One Or More FC VI InterConnect Links Down (ocumEvtMccInterNodeLinksOneOrMoreDown)	Risk	Inter-node connection	Warning
Node To Bridge Link Down (ocumEvtMccNodeBridgeLinksDown)	Incident	Node bridge connection	Critical
Node to Storage Stack All SAS Links Down ( ocumEvtMccNodeStackLinksDown)	Incident	Node stack connection	Critical
Node to Storage Stack One Or More SAS Links Down ( ocumEvtMccNodeStackLinksOneOrMoreDown)	Risk	Node stack connection	Warning


## MetroCluster switch events

MetroCluster switch events provide you with information about the status of the MetroCluster switches so that you can monitor for potential problems. Events are

grouped by impact area and include the event and trap name, impact level, source type, and severity.

**Impact area: availability**

Event name (Trap name)	Impact level	Source type	Severity
Switch Temperature Abnormal(ocumEvtSwitchTemperatureAbnormal)	Incident	MetroCluster Switch	Critical
Switch Unreachable(ocumEvtSwitchUnreachable)	Incident	MetroCluster Switch	Critical
Switch Fans Failed(ocumEvtSwitchFansOneOrMoreFailed)	Incident	MetroCluster Switch	Critical
Switch Power Supplies Failed(ocumEvtSwitchPowerSuppliesOneOrMoreFailed)	Incident	MetroCluster Switch	Critical
Switch Temperature Sensors Failed(ocumEvtSwitchTemperatureSensorFailed)	Incident	MetroCluster Switch	Critical



This event is applicable only for Cisco switches.

**NVMe Namespace events**

NVMe Namespace events provide you with information about the status of your namespaces, so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

An asterisk (\*) identifies EMS events that have been converted to Unified Manager events.

**Impact area: availability**

Event name (Trap name)	Impact level	Source type	Severity
NVMeNS Offline *(nvmeNamespaceStatusOffline)	Event	Namespace	Information
NVMeNS Online *(nvmeNamespaceStatusOnline)	Event	Namespace	Information
NVMeNS Out of Space *(nvmeNamespaceSpaceOutOfSpace)	Risk	Namespace	Warning
NVMeNS Destroy *(nvmeNamespaceDestroy)	Event	Namespace	Information

### Impact area: performance

Event name (Trap name)	Impact level	Source type	Severity
NVMe Namespace IOPS Critical Threshold Breached(ocumNvmeNamespaceIopsIncident)	Incident	Namespace	Critical
NVMe Namespace IOPS Warning Threshold Breached(ocumNvmeNamespaceIopsWarning)	Risk	Namespace	Warning
NVMe Namespace MB/s Critical Threshold Breached(ocumNvmeNamespaceMbpsIncident)	Incident	Namespace	Critical
NVMe Namespace MB/s Warning Threshold Breached(ocumNvmeNamespaceMbpsWarning)	Risk	Namespace	Warning
NVMe Namespace Latency ms/op Critical Threshold Breached(ocumNvmeNamespaceLatencyIncident)	Incident	Namespace	Critical

Event name (Trap name)	Impact level	Source type	Severity
NVMe Namespace Latency ms/op Warning Threshold Breached(ocumNvmeNamespaceLatencyWarning)	Risk	Namespace	Warning
NVMe Namespace Latency and IOPS Critical Threshold Breached(ocumNvmeNamespaceLatencyIopsIncident)	Incident	Namespace	Critical
NVMe Namespace Latency and IOPS Warning Threshold Breached(ocumNvmeNamespaceLatencyIopsWarning)	Risk	Namespace	Warning
NVMe Namespace Latency and MB/s Critical Threshold Breached(ocumNvmeNamespaceLatencyMbpsIncident)	Incident	Namespace	Critical
NVMe Namespace Latency and MB/s Warning Threshold Breached(ocumNvmeNamespaceLatencyMbpsWarning)	Risk	Namespace	Warning

## Node events

Node events provide you with information about node status so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

An asterisk (\*) identifies EMS events that have been converted to Unified Manager events.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Node Root Volume Space Nearly Full(ocumEvtClusterNodeRootVolumeSpaceNearlyFull)	Risk	Node	Warning
Cloud AWS MetaDataConnFail *(ocumCloudAwsMetadatanConnFail)	Risk	Node	Error
Cloud AWS IAMCredsExpired *(ocumCloudAwsIamCredsExpired)	Risk	Node	Error
Cloud AWS IAMCredsInvalid *(ocumCloudAwsIamCredsInvalid)	Risk	Node	Error
Cloud AWS IAMCredsNotFound *(ocumCloudAwsIamCredsNotFound)	Risk	Node	Error
Cloud AWS IAMCredsNotInitialized *(ocumCloudAwsIamCredsNotInitialized)	Event	Node	Information
Cloud AWS IAMRoleInvalid *(ocumCloudAwsIamRoleInvalid)	Risk	Node	Error
Cloud AWS IAMRoleNotFound *(ocumCloudAwsIamRoleNotFound)	Risk	Node	Error
Cloud Tier Host Unresolvable *(ocumObjstoreHostUnresolvable)	Risk	Node	Error

Event name (Trap name)	Impact level	Source type	Severity
Cloud Tier Intercluster LIF Down *(ocumObjstoreInterClusterLifDown)	Risk	Node	Error
One of NFSv4 Pools Exhausted *(nbladeNfsv4PoolEXhaust)	Incident	Node	Critical
Request Mismatch Cloud Tier Signature *(oscSignatureMismatch)	Risk	Node	Error

### Impact area: capacity

Event name (Trap name)	Impact level	Source type	Severity
QoS Monitor Memory Maxed *(ocumQosMonitorMemoryMaxed)	Risk	Node	Error
QoS Monitor Memory Abated *(ocumQosMonitorMemoryAbated)	Event	Node	Information

### Impact area: configuration

Event name (Trap name)	Impact level	Source type	Severity
Node Renamed(Not applicable)	Event	Node	Information

### Impact area: performance

Event name (Trap name)	Impact level	Source type	Severity
Node IOPS Critical Threshold Breached(ocumNodeIopsIncident)	Incident	Node	Critical

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
Node IOPS Warning Threshold Breached(ocumNodeIopsWarning)	Risk	Node	Warning
Node MB/s Critical Threshold Breached(ocumNodeMbpsIncident)	Incident	Node	Critical
Node MB/s Warning Threshold Breached(ocumNodeMbpsWarning)	Risk	Node	Warning
Node Latency ms/op Critical Threshold Breached(ocumNodeLatencyIncident)	Incident	Node	Critical
Node Latency ms/op Warning Threshold Breached(ocumNodeLatencyWarning)	Risk	Node	Warning
Node Performance Capacity Used Critical Threshold Breached(ocumNodePerfCapacityUsedIncident)	Incident	Node	Critical
Node Performance Capacity Used Warning Threshold Breached(ocumNodePerfCapacityUsedWarning)	Risk	Node	Warning
Node Performance Capacity Used - Takeover Critical Threshold Breached(ocumNodePerfCapacityUsedTakeoverIncident)	Incident	Node	Critical

Event name (Trap name)	Impact level	Source type	Severity
Node Performance Capacity Used - Takeover Warning Threshold Breached(ocumNodePerfCapacityUsedTakeoverWarning)	Risk	Node	Warning
Node Utilization Critical Threshold Breached (ocumNodeUtilizationIncident)	Incident	Node	Critical
Node Utilization Warning Threshold Breached (ocumNodeUtilizationWarning)	Risk	Node	Warning
Node HA Pair Over-utilized Threshold Breached (ocumNodeHaPairOverUtilizedInformation)	Event	Node	Information
Node Disk Fragmentation Threshold Breached (ocumNodeDiskFragmentationWarning)	Risk	Node	Warning
Performance Capacity Used Threshold Breached (ocumNodeOverUtilizedWarning)	Risk	Node	Warning
Node Dynamic Threshold Breached (ocumNodeDynamicEventWarning)	Risk	Node	Warning

### Impact area: security

Event name (Trap name)	Impact level	Source type	Severity
Advisory ID: NTAP- <advisory ID>(ocumx)	Risk	Node	Critical



## NVRAM battery events

NVRAM battery events provide you with information about the status of your batteries so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
NVRAM Battery Low(ocumEvtNvramBatteryLow)	Risk	Node	Warning
NVRAM Battery Discharged(ocumEvtNvramBatteryDischarged)	Risk	Node	Error
NVRAM Battery Overly Charged(ocumEvtNvramBatteryOverCharged)	Incident	Node	Critical

## Port events

Port events provide you with status about cluster ports so that you can monitor changes or problems on the port, like whether the port is down.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Port Status Down(ocumEvtPortStatusDown)	Incident	Node	Critical

### Impact area: performance

Event name (Trap name)	Impact level	Source type	Severity
Network Port MB/s Critical Threshold Breached(ocumNetworkPortMbpsIncident)	Incident	Port	Critical

Event name (Trap name)	Impact level	Source type	Severity
Network Port MB/s Warning Threshold Breached(ocumNetworkPortMbpsWarning)	Risk	Port	Warning
FCP Port MB/s Critical Threshold Breached(ocumFcpPortMbpsIncident)	Incident	Port	Critical
FCP Port MB/s Warning Threshold Breached(ocumFcpPortMbpsWarning)	Risk	Port	Warning
Network Port Utilization Critical Threshold Breached(ocumNetworkPortUtilizationIncident)	Incident	Port	Critical
Network Port Utilization Warning Threshold Breached(ocumNetworkPortUtilizationWarning)	Risk	Port	Warning
FCP Port Utilization Critical Threshold Breached(ocumFcpPortUtilizationIncident)	Incident	Port	Critical
FCP Port Utilization Warning Threshold Breached(ocumFcpPortUtilizationWarning)	Risk	Port	Warning

## Power supplies events

Power supplies events provide you with information about the status of your hardware so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
One or More Failed Power Supplies(ocumEvtPowerSupplyOneOrMoreFailed)	Incident	Node	Critical

## Protection events

Protection events tell you if a job has failed or been aborted so that you can monitor for problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: protection

Event name (Trap name)	Impact level	Source type	Severity
Protection Job Failed(ocumEvtProtectionJobTaskFailed)	Incident	Volume or storage service	Critical
Protection Job Aborted(ocumEvtProtectionJobAborted)	Risk	Volume or storage service	Warning

## Qtree events

Qtree events provide you with information about the qtree capacity and the file and disk limits so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: capacity

Event name (Trap name)	Impact level	Source type	Severity
Qtree Space Nearly Full(ocumEvtQtreeSpaceNearlyFull)	Risk	Qtree	Warning
Qtree Space Full(ocumEvtQtreeSpaceFull)	Risk	Qtree	Error
Qtree Space Normal(ocumEvtQtreeSpaceThresholdOk)	Event	Qtree	Information

Event name (Trap name)	Impact level	Source type	Severity
Qtree Files Hard Limit Reached(ocumEvtQtreeFilesHardLimitReached)	Incident	Qtree	Critical
Qtree Files Soft Limit Breached(ocumEvtQtreeFilesSoftLimitBreached)	Risk	Qtree	Warning
Qtree Space Hard Limit Reached(ocumEvtQtreeSpaceHardLimitReached)	Incident	Qtree	Critical
Qtree Space Soft Limit Breached(ocumEvtQtreeSpaceSoftLimitBreached)	Risk	Qtree	Warning

## Service processor events

Service processor events provide you with information about the status of your processor so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Service Processor Not Configured(ocumEvtServiceProcessorNotConfigured)	Risk	Node	Warning
Service Processor Offline(ocumEvtServiceProcessorOffline)	Risk	Node	Error

## SnapMirror relationship events

SnapMirror relationship events provide you with information about the status of your Asynchronous and Synchronous SnapMirror relationships so that you can monitor for potential problems. Asynchronous SnapMirror relationship events are generated for both Storage VMs and volumes but Synchronous SnapMirror relationship events are generated only for volume relationships. There are no events generated for constituent volumes that are part of Storage VM disaster recovery relationships. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

## Impact area: protection

An asterisk (\*) identifies EMS events that have been converted to Unified Manager events.



The SnapMirror relationships events are generated for Storage VMs that are protected by Storage VM disaster recovery but not for any constituent object relationships.

Event name (Trap name)	Impact level	Source type	Severity
Mirror Replication Unhealthy(ocumEvtSnapmirrorRelationshipUnhealthy)	Risk	SnapMirror relationship	Warning
Mirror Replication Broken-off(ocumEvtSnapmirrorRelationshipStateBrokenoff)	Risk	SnapMirror relationship	Error
Mirror Replication Initialize Failed(ocumEvtSnapmirrorRelationshipInitializeFailed)	Risk	SnapMirror relationship	Error
Mirror Replication Update Failed(ocumEvtSnapmirrorRelationshipUpdateFailed)	Risk	SnapMirror relationship	Error
Mirror Replication Lag Error(ocumEvtSnapMirrorRelationshipLagError)	Risk	SnapMirror relationship	Error
Mirror Replication Lag Warning(ocumEvtSnapMirrorRelationshipLagWarning)	Risk	SnapMirror relationship	Warning
Mirror Replication Resync Failed(ocumEvtSnapmirrorRelationshipResyncFailed)	Risk	SnapMirror relationship	Error
Synchronous Replication Out Of Sync *(syncSnapmirrorRelationshipOutofsync)	Risk	SnapMirror relationship	Warning

Event name (Trap name)	Impact level	Source type	Severity
Synchronous Replication Restored *(syncSnapmirrorRelationshipInSync)	Event	SnapMirror relationship	Information
Synchronous Replication Auto Resync Failed *(syncSnapmirrorRelationshipAutoSyncRetryFailed)	Risk	SnapMirror relationship	Error
Ontap Mediator is added on the Cluster (snapmirrorMediatorAdded)	Event	Cluster	Information
Ontap Mediator is removed from the Cluster (snapmirrorMediatorRemoved)	Event	Cluster	Information
Ontap Mediator is unreachable from the cluster (snapmirrorMediatorUnreachable)	Risk	Mediator	Warning
Ontap Mediator is not accessible from the cluster (snapmirrorMediatorMisconfigured)	Risk	Mediator	Error
Ontap Mediator Connectivity has been reestablished, and is resynced and ready for SMBC (snapmirrorMediatorInQuorum)	Event	Mediator	Information

## Asynchronous Mirror and Vault relationship events

Asynchronous Mirror and Vault relationship events provide you with information about the status of your Asynchronous SnapMirror and Vault relationships so that you can monitor for potential problems. Asynchronous Mirror and Vault relationship events are supported for both volume and Storage VM protection relationships. But only Vault relationships are not supported for Storage VM disaster recovery. Events are grouped by impact area and

include the event and trap name, impact level, source type, and severity.

### Impact area: protection



The SnapMirror and Vault relationships events are also generated for Storage VMs that are protected by Storage VM disaster recovery but not for any constituent object relationships.

Event name (Trap name)	Impact level	Source type	Severity
Asynchronous Mirror and Vault Unhealthy(ocumEvtMirrorVaultRelationshipUnhealthy)	Risk	SnapMirror relationship	Warning
Asynchronous Mirror and Vault Broken-off(ocumEvtMirrorVaultRelationshipStateBrokenoff)	Risk	SnapMirror relationship	Error
Asynchronous Mirror and Vault Initialize Failed(ocumEvtMirrorVaultRelationshipInitializeFailed)	Risk	SnapMirror relationship	Error
Asynchronous Mirror and Vault Update Failed(ocumEvtMirrorVaultRelationshipUpdateFailed)	Risk	SnapMirror relationship	Error
Asynchronous Mirror and Vault Lag Error(ocumEvtMirrorVaultRelationshipLagError)	Risk	SnapMirror relationship	Error
Asynchronous Mirror and Vault Lag Warning(ocumEvtMirrorVaultRelationshipLagWarning)	Risk	SnapMirror relationship	Warning
Asynchronous Mirror and Vault Resync Failed(ocumEvtMirrorVaultRelationshipResyncFailed)	Risk	SnapMirror relationship	Error



"SnapMirror update failure" event is raised by Active IQ portal (Config Advisor).

## Snapshot events

Snapshot events provide information about the status of snapshots which enables you to monitor the snapshots for potential problems. The events are grouped by impact area, and include the event name, trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Snapshot Auto-delete Disabled(Not applicable)	Event	Volume	Information
Snapshot Auto-delete Enabled(Not applicable)	Event	Volume	Information
Snapshot Auto-delete Configuration Modified(Not applicable)	Event	Volume	Information

## SnapVault relationship events

SnapVault relationship events provide you with information about the status of your SnapVault relationships so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: protection

Event name (Trap name)	Impact level	Source type	Severity
Asynchronous Vault Unhealthy(ocumEvtSnapVaultRelationshipUnhealthy)	Risk	SnapMirror relationship	Warning
Asynchronous Vault Broken-off(ocumEvtSnapVaultRelationshipStateBrokenoff)	Risk	SnapMirror relationship	Error
Asynchronous Vault Initialize Failed(ocumEvtSnapVaultRelationshipInitializeFailed)	Risk	SnapMirror relationship	Error



Event name (Trap name)	Impact level	Source type	Severity
Asynchronous Vault Update Failed(ocumEvtSnapVaultRelationshipUpdateFailed)	Risk	SnapMirror relationship	Error
Asynchronous Vault Lag Error(ocumEvtSnapVaultRelationshipLagError)	Risk	SnapMirror relationship	Error
Asynchronous Vault Lag Warning(ocumEvtSnapVaultRelationshipLagWarning)	Risk	SnapMirror relationship	Warning
Asynchronous Vault Resync Failed(ocumEvtSnapvaultRelationshipResyncFailed)	Risk	SnapMirror relationship	Error

## Storage failover settings events

Storage failover (SFO) settings events provide you with information about whether your storage failover is disabled or not configured so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Storage Failover Interconnect One Or More Links Down(ocumEvtSfoInterconnectOneOrMoreLinksDown)	Risk	Node	Warning
Storage Failover Disabled(ocumEvtSfoSettingsDisabled)	Risk	Node	Error
Storage Failover Not Configured(ocumEvtSfoSettingsNotConfigured)	Risk	Node	Error

Event name (Trap name)	Impact level	Source type	Severity
Storage Failover State - Takeover(ocumEvtSfoStateTakeover)	Risk	Node	Warning
Storage Failover State - Partial Giveback(ocumEvtSfoStatePartialGiveback)	Risk	Node	Error
Storage Failover Node Status Down(ocumEvtSfoNodeStatusDown)	Risk	Node	Error
Storage Failover Takeover Not Possible(ocumEvtSfoTakeoverNotPossible)	Risk	Node	Error

## Storage services events

Storage services events provide you with information about the creation and subscription of storage services so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: configuration

Event name (Trap name)	Impact level	Source type	Severity
Storage Service Created(Not applicable)	Event	Storage service	Information
Storage Service Subscribed(Not applicable)	Event	Storage service	Information
Storage Service Unsubscribed(Not applicable)	Event	Storage service	Information

### Impact area: protection

Event name (Trap name)	Impact level	Source type	Severity
Unexpected Deletion of Managed SnapMirror Relationship(ocumEvtStorageServiceUnsupportedRelationshipDeletion)	Risk	Storage service	Warning
Unexpected Deletion of Storage Service Member Volume(ocumEvtStorageServiceUnexpectedVolumeDeletion)	Incident	Storage service	Critical

## Storage shelf events

Storage shelf events tell you if your storage shelf has abnormal so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Abnormal Voltage Range(ocumEvtShelfVoltageAbnormal)	Risk	Storage shelf	Warning
Abnormal Current Range(ocumEvtShelfCurrentAbnormal)	Risk	Storage shelf	Warning
Abnormal Temperature(ocumEvtShelfTemperatureAbnormal)	Risk	Storage shelf	Warning

## Storage VM events

Storage VM (storage virtual machine, also known as SVM) events provide you with information about the status of your storage VMs (SVMs) so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

An asterisk (\*) identifies EMS events that have been converted to Unified Manager events.

## Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
SVM CIFS Service Down(ocumEvtVserverCifsServiceStatusDown)	Incident	SVM	Critical
SVM CIFS Service Not Configured(Not applicable)	Event	SVM	Information
Attempts to Connect Nonexistent CIFS Share *(nbladeCifsNoPrivShare)	Incident	SVM	Critical
CIFS NetBIOS Name Conflict *(nbladeCifsNbNameConflict)	Risk	SVM	Error
CIFS Shadow Copy Operation Failed *(cifsShadowCopyFailure)	Risk	SVM	Error
Many CIFS Connections *(nbladeCifsManyAuths)	Risk	SVM	Error
Max CIFS Connection Exceeded *(nbladeCifsMaxOpenSameFile)	Risk	SVM	Error
Max Number of CIFS Connection Per User Exceeded *(nbladeCifsMaxSessPerUsrConn)	Risk	SVM	Error
SVM FC/FCoE Service Down(ocumEvtVserverFcServiceStatusDown)	Incident	SVM	Critical
SVM iSCSI Service Down(ocumEvtVserverIscsiServiceStatusDown)	Incident	SVM	Critical

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
SVM NFS Service Down(ocumEvtVserverNfsServiceStatusDown)	Incident	SVM	Critical
SVM FC/FCoE Service Not Configured(Not applicable)	Event	SVM	Information
SVM iSCSI Service Not Configured(Not applicable)	Event	SVM	Information
SVM NFS Service Not Configured(Not applicable)	Event	SVM	Information
SVM Stopped(ocumEvtVserver Down)	Risk	SVM	Warning
AV Server too Busy to Accept New Scan Request *(nbladeVscanConnBack Pressure)	Risk	SVM	Error
No AV Server Connection for Virus Scan *(nbladeVscanNoScanner Conn)	Incident	SVM	Critical
No AV Server Registered *(nbladeVscanNoRegdScanner)	Risk	SVM	Error
No Responsive AV Server Connection *(nbladeVscanConnInactive)	Event	SVM	Information
Unauthorized User Attempt to AV Server *(nbladeVscanBadUserPrivAccess)	Risk	SVM	Error

Event name (Trap name)	Impact level	Source type	Severity
Virus Found By AV Server *(nbladeVscanVirusDetected)	Risk	SVM	Error

### Impact area: configuration

Event name (Trap name)	Impact level	Source type	Severity
SVM Discovered(Not applicable)	Event	SVM	Information
SVM Deleted(Not applicable)	Event	Cluster	Information
SVM Renamed(Not applicable)	Event	SVM	Information

### Impact area: performance

Event name (Trap name)	Impact level	Source type	Severity
SVM IOPS Critical Threshold Breached(ocumSvmIopsIncident)	Incident	SVM	Critical
SVM IOPS Warning Threshold Breached(ocumSvmIopsWarning)	Risk	SVM	Warning
SVM MB/s Critical Threshold Breached(ocumSvmMbpsIncident)	Incident	SVM	Critical
SVM MB/s Warning Threshold Breached(ocumSvmMbpsWarning)	Risk	SVM	Warning
SVM Latency Critical Threshold Breached(ocumSvmLatencyIncident)	Incident	SVM	Critical

Event name (Trap name)	Impact level	Source type	Severity
SVM Latency Warning Threshold Breached(ocumSvmLatencyWarning)	Risk	SVM	Warning

### Impact area: security

Event name (Trap name)	Impact level	Source type	Severity
Audit Log Disabled(ocumVserverAuditLogDisabled)	Risk	SVM	Warning
Login Banner Disabled(ocumVserverLoginBannerDisabled)	Risk	SVM	Warning
SSH is Using Insecure Ciphers(ocumVserverSSHInsecure)	Risk	SVM	Warning
Login Banner Changed(ocumVserverLoginBannerChanged)	Risk	SVM	Warning
Storage VM anti-ransomware monitoring is Disabled (antiRansomwareSvmStateDisabled)	Risk	SVM	Warning
Storage VM anti-ransomware monitoring is Enabled (Learning Mode) (antiRansomwareSvmStateDryrun)	Event	SVM	Information
Storage VM suitable for anti-ransomware monitoring (Learning Mode) (ocumEvtSvmArwCandidate)	Event	SVM	Information

## User and group quota events

User and group quota events provide you with information about the capacity of the user

and user group quota as well as the file and disk limits so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: capacity

Event name (Trap name)	Impact level	Source type	Severity
User or Group Quota Disk Space Soft Limit Breached(ocumEvtUserOrGroupQuotaDiskSpaceSoftLimitBreached)	Risk	User or group quota	Warning
User or Group Quota Disk Space Hard Limit Reached(ocumEvtUserOrGroupQuotaDiskSpaceHardLimitReached)	Incident	User or group quota	Critical
User or Group Quota File Count Soft Limit Breached(ocumEvtUserOrGroupQuotaFileCountSoftLimitBreached)	Risk	User or group quota	Warning
User or Group Quota File Count Hard Limit Reached(ocumEvtUserOrGroupQuotaFileCountHardLimitReached)	Incident	User or group quota	Critical

## Volume events

Volume events provide information about the status of volumes which enables you to monitor for potential problems. The events are grouped by impact area, and include the event name, trap name, impact level, source type, and severity.

An asterisk (\*) identifies EMS events that have been converted to Unified Manager events.

### Impact area: availability

Event name (Trap name)	Impact level	Source type	Severity
Volume Restricted(ocumEvtVolumeRestricted)	Risk	Volume	Warning



Event name (Trap name)	Impact level	Source type	Severity
Volume Offline(ocumEvtVolumeOffline)	Incident	Volume	Critical
Volume Partially Available(ocumEvtVolumePartiallyAvailable)	Risk	Volume	Error
Volume Unmounted(Not applicable)	Event	Volume	Information
Volume Mounted(Not applicable)	Event	Volume	Information
Volume Remounted(Not applicable)	Event	Volume	Information
Volume Junction Path Inactive(ocumEvtVolumeJunctionPathInactive)	Risk	Volume	Warning
Volume Autosize Enabled(Not applicable)	Event	Volume	Information
Volume Autosize-Disabled(Not applicable)	Event	Volume	Information
Volume Autosize Maximum Capacity Modified(Not applicable)	Event	Volume	Information
Volume Autosize Increment Size Modified(Not applicable)	Event	Volume	Information

### Impact area: capacity

Event name (Trap name)	Impact level	Source type	Severity
Thin-Provisioned Volume Space At Risk(ocumThinProvisionVolumeSpaceAtRisk)	Risk	Volume	Warning
Volume Space Full(ocumEvtVolumeFull)	Risk	Volume	Error

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
Volume Space Nearly Full(ocumEvtVolumeNearlyFull)	Risk	Volume	Warning
Volume Logical Space Full*(volumeLogicalSpaceFull)	Risk	Volume	Error
Volume Logical Space Nearly Full*(volumeLogicalSpaceNearlyFull)	Risk	Volume	Warning
Volume Logical Space Normal*(volumeLogicalSpaceAllOK)	Event	Volume	Information
Volume Snapshot Reserve Space Full(ocumEvtSnapshotFull)	Risk	Volume	Warning
Too Many Snapshot Copies(ocumEvtSnapshotTooMany)	Risk	Volume	Error
Volume Qtree Quota Overcommitted(ocumEvtVolumeQtreeQuotaOvercommitted)	Risk	Volume	Error
Volume Qtree Quota Nearly Overcommitted(ocumEvtVolumeQtreeQuotaAlmostOvercommitted)	Risk	Volume	Warning
Volume Growth Rate Abnormal(ocumEvtVolumeGrowthRateAbnormal)	Risk	Volume	Warning
Volume Days Until Full(ocumEvtVolumeDaysUntilFullSoon)	Risk	Volume	Error

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
Volume Space Guarantee Disabled(Not applicable)	Event	Volume	Information
Volume Space Guarantee Enabled(Not Applicable)	Event	Volume	Information
Volume Space Guarantee Modified(Not applicable)	Event	Volume	Information
Volume Snapshot Reserve Days Until Full(ocumEvtVolumeSnapshotReserveDaysUntilFull Soon)	Risk	Volume	Error
FlexGroup Constituents Have Space Issues *(flexGroupConstituentsHaveSpaceIssues)	Risk	Volume	Error
FlexGroup Constituents Space Status All OK *(flexGroupConstituentsSpaceStatusAllOK)	Event	Volume	Information
FlexGroup Constituents Have Inodes Issues *(flexGroupConstituentsHaveInodesIssues)	Risk	Volume	Error
FlexGroup Constituents Inodes Status All OK *(flexGroupConstituentsInodesStatusAllOK)	Event	Volume	Information
WAFL Volume AutoSize Fail *(wafIVolAutoSizeFail)	Risk	Volume	Error
WAFL Volume AutoSize Done *(wafIVolAutoSizeDone)	Event	Volume	Information
FlexGroup Volume Is Over 80% Utilized*	Incident	Volume	Error

Event name (Trap name)	Impact level	Source type	Severity
FlexGroup Volume Is Over 90% Utilized*	Incident	Volume	Critical
Volume storage efficiency anomaly (ocumVolumeAbnormalStorageEfficiencyWarning)	Risk	Volume	Warning
Volume Snapshot Reserve Under-utilized (volumeSnaphotReserveUnderutilizedWarning)	Event	Volume	Warning
Volume Snapshot Reserve Under-utilized (volumeSnaphotReserveUnderutilizedCleared)	Event	Volume	Warning

### Impact area: configuration

Event name (Trap name)	Impact level	Source type	Severity
Volume Renamed(Not applicable)	Event	Volume	Information
Volume Discovered(Not applicable)	Event	Volume	Information
Volume Deleted(Not applicable)	Event	Volume	Information

### Impact area: performance

Event name (Trap name)	Impact level	Source type	Severity
QoS Volume Max IOPS Warning Threshold Breached(ocumQosVolumeMaxIopsWarning)	Risk	Volume	Warning
QoS Volume Max MB/s Warning Threshold Breached(ocumQosVolumeMaxMbpsWarning)	Risk	Volume	Warning

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
QoS Volume Max IOPS/TB Warning Threshold Breached(ocumQosVolumeMaxIopsPerTbWarning)	Risk	Volume	Warning
Workload Volume Latency Threshold Breached as defined by Performance Service Level Policy(ocumConformanceLatencyWarning)	Risk	Volume	Warning
Volume IOPS Critical Threshold Breached(ocumVolumeIopsIncident)	Incident	Volume	Critical
Volume IOPS Warning Threshold Breached(ocumVolumeIopsWarning)	Risk	Volume	Warning
Volume MB/s Critical Threshold Breached(ocumVolumeMbpsIncident)	Incident	Volume	Critical
Volume MB/s Warning Threshold Breached(ocumVolumeMbpsWarning)	Risk	Volume	Warning
Volume Latency ms/op Critical Threshold Breached(ocumVolumeLatencyIncident)	Incident	Volume	Critical
Volume Latency ms/op Warning Threshold Breached(ocumVolumeLatencyWarning)	Risk	Volume	Warning
Volume Cache Miss Ratio Critical Threshold Breached(ocumVolumeCacheMissRatioIncident)	Incident	Volume	Critical

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
Volume Cache Miss Ratio Warning Threshold Breached(ocumVolumeCacheMissRatioWarning)	Risk	Volume	Warning
Volume Latency and IOPS Critical Threshold Breached(ocumVolumeLatencyIopsIncident)	Incident	Volume	Critical
Volume Latency and IOPS Warning Threshold Breached(ocumVolumeLatencyIopsWarning)	Risk	Volume	Warning
Volume Latency and MB/s Critical Threshold Breached(ocumVolumeLatencyMbpsIncident)	Incident	Volume	Critical
Volume Latency and MB/s Warning Threshold Breached(ocumVolumeLatencyMbpsWarning)	Risk	Volume	Warning
Volume Latency and Aggregate Performance Capacity Used Critical Threshold Breached(ocumVolumeLatencyAggregatePerfCapacityUsedIncident)	Incident	Volume	Critical
Volume Latency and Aggregate Performance Capacity Used Warning Threshold Breached(ocumVolumeLatencyAggregatePerfCapacityUsedWarning)	Risk	Volume	Warning
Volume Latency and Aggregate Utilization Critical Threshold Breached(ocumVolumeLatencyAggregateUtilizationIncident)	Incident	Volume	Critical

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
Volume Latency and Aggregate Utilization Warning Threshold Breached(ocumVolumeLatencyAggregateUtilizationWarning)	Risk	Volume	Warning
Volume Latency and Node Performance Capacity Used Critical Threshold Breached(ocumVolumeLatencyNodePerfCapacityUsedIncident)	Incident	Volume	Critical
Volume Latency and Node Performance Capacity Used Warning Threshold Breached(ocumVolumeLatencyNodePerfCapacityUsedWarning)	Risk	Volume	Warning
Volume Latency and Node Performance Capacity Used - Takeover Critical Threshold Breached(ocumVolumeLatencyAggregatePerfCapacityUsedTakeoverIncident)	Incident	Volume	Critical
Volume Latency and Node Performance Capacity Used - Takeover Warning Threshold Breached(ocumVolumeLatencyAggregatePerfCapacityUsedTakeoverWarning)	Risk	Volume	Warning
Volume Latency and Node Utilization Critical Threshold Breached(ocumVolumeLatencyNodeUtilizationIncident)	Incident	Volume	Critical

Event name (Trap name)	Impact level	Source type	Severity
Volume Latency and Node Utilization Warning Breached(ocumVolumeLatencyNodeUtilizationWarning)	Risk	Volume	Warning

### Impact area: security

Event name (Trap name)	Impact level	Source type	Severity
Volume anti-ransomware monitoring is Enabled (Active Mode) (antiRansomwareVolumeStateEnabled)	Event	Volume	Information
Volume anti-ransomware monitoring is Disabled (antiRansomwareVolumeStateDisabled)	Risk	Volume	Warning
Volume anti-ransomware monitoring is Enabled (Learning Mode) (antiRansomwareVolumeStateDryrun)	Event	Volume	Information
Volume anti-ransomware monitoring is Paused (Learning Mode) (antiRansomwareVolumeStateDryrunPaused)	Risk	Volume	Warning
Volume anti-ransomware monitoring is Paused (Active Mode) (antiRansomwareVolumeStateEnablePaused)	Risk	Volume	Warning
Volume anti-ransomware monitoring is Disabling (antiRansomwareVolumeStateDisableInProgress)	Risk	Volume	Warning



Event name (Trap name)	Impact level	Source type	Severity
Ransomware Activity Seen (callHomeRansomwareActivitySeen)	Incident	Volume	Critical
Volume suitable for anti-ransomware monitoring (Learning Mode) (ocumEvtVolumeArwCandidate)	Event	Volume	Information
Volume suitable for anti-ransomware monitoring (Active Mode) (ocumVolumeSuitedForActiveAntiRansomwareDetection)	Risk	Volume	Warning
Volume exhibits noisy anti-ransomware alerting (antiRansomwareFeatureNoisyVolume)	Risk	Volume	Warning

### Impact area: data protection

Event name (Trap name)	Impact level	Source type	Severity
Volume Has Insufficient Local Snapshot Protection (volumeLacksLocalProtectionWarning)	Risk	Volume	Warning
Volume Has Insufficient Local Snapshot Protection (volumeLacksLocalProtectionCleared)	Risk	Volume	Warning

## Volume move status events

Volume move status events tell you about the status of your volume move so that you can monitor for potential problems. Events are grouped by impact area and include the event and trap name, impact level, source type, and severity.

### Impact area: capacity

<b>Event name (Trap name)</b>	<b>Impact level</b>	<b>Source type</b>	<b>Severity</b>
Volume Move Status: In Progress(Not applicable)	Event	Volume	Information
Volume Move Status - Failed(ocumEvtVolumeMoveFailed)	Risk	Volume	Error
Volume Move Status: Completed(Not applicable)	Event	Volume	Information
Volume Move - Cutover Deferred(ocumEvtVolumeMoveCutoverDeferred)	Risk	Volume	Warning

## Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.