



## Get help

ASA r2

NetApp

February 04, 2026

This PDF was generated from <https://docs.netapp.com/us-en/asa-r2/get-help/manage-autosupport.html> on February 04, 2026. Always check [docs.netapp.com](https://docs.netapp.com) for the latest.

# Table of Contents

|  |   |
|--|---|
| Get help .....   | 1 |
| Manage AutoSupport on ASA r2 storage systems .....             | 1 |
| Test AutoSupport connectivity .....                            | 1 |
| Add AutoSupport recipients .....                               | 1 |
| Send AutoSupport data .....                                    | 2 |
| Suppress support case generation .....                         | 2 |
| Resume support case generation .....                           | 2 |
| Submit and view support cases for ASA r2 storage systems ..... | 2 |

# Get help

## Manage AutoSupport on ASA r2 storage systems

AutoSupport is a mechanism that proactively monitors the health of your system and automatically sends messages to NetApp technical support, your internal support organization, and a support partner.

AutoSupport messages to technical support are enabled by default when you set up your cluster. You must set the correct options and have a valid mail host to have messages sent to your internal support organization. ONTAP begins sending AutoSupport messages 24 hours after it is enabled.

### Before you begin

You must be a cluster administrator to manage AutoSupport.

### Test AutoSupport connectivity

After you have set up your cluster, you should test your AutoSupport connectivity to verify that technical support will receive messages generated by AutoSupport.

#### Steps

1. In System Manager, select **Cluster >Settings**.
2. Next to **AutoSupport** select ; then select **Test connectivity**.
3. Enter a subject for the AutoSupport message; then select **Send test AutoSupport message**.

#### What's next?

You have confirmed that technical support can receive AutoSupport messages from your ASA r2 system, ensuring they have the necessary data to assist you in case of any issues.

### Add AutoSupport recipients

Add members of your internal support organization to the list of email addresses that receive AutoSupport messages.

#### Steps

1. In System Manager, select **Cluster >Settings**.
2. Next to **AutoSupport** select ; then select **More options**.
3. Next to **Email**, select ; then select  **Add**.
4. Enter the email address for the recipient; then the the recipient category.

For partners, select **Partner** for the recipient category. Select **General** for members of your internal support organization.

5. Select **Save**.

#### What's next?

The email addresses you have added will receive new AutoSupport messages for their specific recipient category.

## Send AutoSupport data

Should a problem occur on your ASA r2 system, AutoSupport data can significantly decrease the time it takes to identify and resolve issues.

### Steps

1. In System Manager, select **Cluster >Settings**.
2. Next to **AutoSupport** select ; then select **Generate and send**.
3. Enter a subject for the AutoSupport message; then select **Send**.

### What's next?

Your AutoSupport data is sent to technical support.

## Suppress support case generation

If you are performing an upgrade or maintenance on your ASA r2 system, you might want to suppress AutoSupport generation of support cases until your upgrade or maintenance is complete.

### Steps

1. In System Manager, select **Cluster >Settings**.
2. Next to **AutoSupport** select ; then select **Suppress support case generation**.
3. Specify the number of hours to suppress the generation of support cases; then select the nodes for which you do not want cases generated.
4. Select **Send**.

### What's next?

AutoSupport cases will not be generated during the time you specified. If you complete your upgrade or maintenance before the specified time expires, you should resume support case generation immediately.

## Resume support case generation

If you have suppressed the generation of support cases during an upgrade or maintenance window, you should resume support case generation immediately after your upgrade or maintenance is complete.

### Steps

1. In System Manager, select **Cluster >Settings**.
2. Next to **AutoSupport** select ; then select **Resume support case generation**.
3. Select the nodes for which you want to resume AutoSupport cases generated.
4. Select **Send**.

### Result

AutoSupport cases are autogenerated for your ASA r2 system as needed.

## Submit and view support cases for ASA r2 storage systems

If you have an issue that requires assistance, you can use ONTAP System Manager to submit a case to technical support. You can also use ONTAP System Manager to view cases that are closed or in progress.

You must be [registered with Active IQ](#) to view support cases for your ASA r2 system.

## Steps

1. To submit a support case, in System Manager, select **Cluster >Support**; then select **Go to NetApp Support**.
2. To view a previously submitted case, in System Manager, select **Cluster >Support**; then select **View my cases**.

## Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—with prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

**LIMITED RIGHTS LEGEND:** Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.