



2. Configure Data Switches

NetApp Solutions

Kevin Hoke
April 20, 2021

Table of Contents

- 2. Configure Data Switches 1
 - Create MLAG cluster to provide fault tolerance 1
 - Configure ports to connect to storage and compute hosts 3
 - Create uplink ports for the switches 7

2. Configure Data Switches

Mellanox SN2010 switches provide 25Gbps connectivity for the data plane of the compute and storage nodes. To configure the switches to provide data connectivity to the infrastructure, complete the following steps:

Create MLAG cluster to provide fault tolerance

1. Run the following commands on each Mellanox SN210 switch for general configuration:

a. Enter configuration mode.

```
Switch-01 enable  
Switch-01 configure terminal
```

b. Enable the LACP required for the Inter-Peer Link (IPL).

```
Switch-01 (config) # lacp
```

c. Enable the Link Layer Discovery Protocol (LLDP).

```
Switch-01 (config) # lldp
```

d. Enable IP routing.

```
Switch-01 (config) # ip routing
```

e. Enable the MLAG protocol.

```
Switch-01 (config) # protocol mlag
```

f. Enable global QoS.

```
Switch-01 (config) # dcb priority-flow-control enable force
```

2. For MLAG to function, the switches must be made peers to each other through an IPL. This should consist of two or more physical links for redundancy. The MTU for the IPL is set for jumbo frames (9216), and all VLANs are enabled by default. Run the following commands on each switch in the domain:

a. Create port channel 10 for the IPL.

```
Switch-01 (config) # interface port-channel 10
Switch-01 (config interface port-channel 10) # description IPL
Switch-01 (config interface port-channel 10) # exit
```

- b. Add interfaces ETH 1/20 and 1/22 to the port channel.

```
Switch-01 (config) # interface ethernet 1/20 channel-group 10 mode
active
Switch-01 (config) # interface ethernet 1/20 description ISL-SWB_01
Switch-01 (config) # interface ethernet 1/22 channel-group 10 mode
active
Switch-01 (config) # interface ethernet 1/22 description ISL-SWB_02
```

- c. Create a VLAN outside of the standard range dedicated to IPL traffic.

```
Switch-01 (config) # vlan 4000
Switch-01 (config vlan 4000) # name IPL VLAN
Switch-01 (config vlan 4000) # exit
```

- d. Define the port channel as the IPL.

```
Switch-01 (config) # interface port-channel 10 ipl 1
Switch-01 (config) # interface port-channel 10 dcb priority-flow-
control mode on force
```

- e. Set an IP for each IPL member (non-routable; it is not advertised outside of the switch).

```
Switch-01 (config) # interface vlan 4000
Switch-01 (config vlan 4000) # ip address 10.0.0.1 255.255.255.0
Switch-01 (config vlan 4000) # ipl 1 peer-address 10.0.0.2
Switch-01 (config vlan 4000) # exit
```

3. Create a unique MLAG domain name for the two switches and assign an MLAG virtual IP (VIP). This IP is used for keep-alive heartbeat messages between the two switches. Run these commands on each switch in the domain:

- a. Create the MLAG domain and set the IP address and subnet.

```
Switch-01 (config) # mlag-vip MLAG-VIP-DOM ip a.b.c.d /24 force
```

- b. Create a virtual MAC address for the system MLAG.

```
Switch-01 (config) # mlag system-mac AA:BB:CC:DD:EE:FF
```

- c. Configure the MLAG domain so that it is active globally.

```
Switch-01 (config) # no mlag shutdown
```



The IP used for the MLAG VIP must be in the same subnet as the switch management network (mgmt0).



The MAC address used can be any unicast MAC address and must be set to the same value on both switches in the MLAG domain.

Configure ports to connect to storage and compute hosts

1. Create each of the VLANs needed to support the services for NetApp HCI. Run these commands on each switch in the domain:

- a. Create VLANs.

```
Switch-01 (config) # vlan 1172
Switch-01 (config vlan 1172) exit
Switch-01 (config) # vlan 3480-3482
Switch-01 (config vlan 3480-3482) exit
```

- b. Create names for each VLAN for easier accounting.

```
Switch-01 (config) # vlan 1172 name "VM_Network"
Switch-01 (config) # vlan 3480 name "MGMT_Network"
Switch-01 (config) # vlan 3481 name "Storage_Network"
Switch-01 (config) # vlan 3482 name "vMotion_Network"
+
```

2. Create hybrid VLAN ports on ports ETH1/9-10 so that you can tag the appropriate VLANs for the NetApp HCI compute nodes.

- a. Select the ports you want to work with.

```
Switch-01 (config) # interface ethernet 1/9-1/10
```

- b. Set the MTU for each port.

```
Switch-01 (config interface ethernet 1/9-1/10) # mtu 9216 force
```

c. Modify spanning-tree settings for each port.

```
Switch-01 (config interface ethernet 1/9-1/10) # spanning-tree  
bpdufilter enable  
Switch-01 (config interface ethernet 1/9-1/10) # spanning-tree port  
type edge  
Switch-01 (config interface ethernet 1/9-1/10) # spanning-tree  
bpduguard enable
```

d. Set the switchport mode to hybrid.

```
Switch-01 (config interface ethernet 1/9-1/10 ) # switchport mode  
hybrid  
Switch-01 (config interface ethernet 1/9-1/10 ) # exit
```

e. Create descriptions for each port being modified.

```
Switch-01 (config) # interface ethernet 1/9 description HCI-CMP-01  
PortD  
Switch-01 (config) # interface ethernet 1/10 description HCI-CMP-02  
PortD
```

f. Tag the appropriate VLANs for the NetApp HCI environment.

```
Switch-01 (config) # interface ethernet 1/9 switchport hybrid  
allowed-vlan add 1172  
Switch-01 (config) # interface ethernet 1/9 switchport hybrid  
allowed-vlan add 3480-3482  
Switch-01 (config) # interface ethernet 1/10 switchport hybrid  
allowed-vlan add 1172  
Switch-01 (config) # interface ethernet 1/10 switchport hybrid  
allowed-vlan add 3480-3482
```

3. Create MLAG interfaces and hybrid VLAN ports on ports ETH1/5-8 so that you can distribute connectivity between the switches and tag the appropriate VLANs for the NetApp HCI storage nodes.

a. Select the ports that you want to work with.

```
Switch-01 (config) # interface ethernet 1/5-1/8
```

b. Set the MTU for each port.

```
Switch-01 (config interface ethernet 1/5-1/8) # mtu 9216 force
```

c. Modify spanning tree settings for each port.

```
Switch-01 (config interface ethernet 1/5-1/8) # spanning-tree  
bpdufilter enable  
Switch-01 (config interface ethernet 1/5-1/8) # spanning-tree port  
type edge  
Switch-01 (config interface ethernet 1/5-1/8) # spanning-tree  
bpduguard enable
```

d. Set the switchport mode to hybrid.

```
Switch-01 (config interface ethernet 1/5-1/8 ) # switchport mode  
hybrid  
Switch-01 (config interface ethernet 1/5-1/8 ) # exit
```

e. Create descriptions for each port being modified.

```
Switch-01 (config) # interface ethernet 1/5 description HCI-STG-01  
PortD  
Switch-01 (config) # interface ethernet 1/6 description HCI-STG-02  
PortD  
Switch-01 (config) # interface ethernet 1/7 description HCI-STG-03  
PortD  
Switch-01 (config) # interface ethernet 1/8 description HCI-STG-04  
PortD
```

f. Create and configure the MLAG port channels.

```

Switch-01 (config) # interface mlag-port-channel 115-118
Switch-01 (config interface mlag-port-channel 115-118) # exit
Switch-01 (config) # interface mlag-port-channel 115-118 no shutdown
Switch-01 (config) # interface mlag-port-channel 115-118 mtu 9216
force
Switch-01 (config) # interface mlag-port-channel 115-118 lacp-
individual enable force
Switch-01 (config) # interface ethernet 1/5-1/8 lacp port-priority 10
Switch-01 (config) # interface ethernet 1/5-1/8 lacp rate fast
Switch-01 (config) # interface ethernet 1/5 mlag-channel-group 115
mode active
Switch-01 (config) # interface ethernet 1/6 mlag-channel-group 116
mode active
Switch-01 (config) # interface ethernet 1/7 mlag-channel-group 117
mode active
Switch-01 (config) # interface ethernet 1/8 mlag-channel-group 118
mode active

```

g. Tag the appropriate VLANs for the storage environment.

```

Switch-01 (config) # interface mlag-port-channel 115-118 switchport
mode hybrid
Switch-01 (config) # interface mlag-port-channel 115 switchport
hybrid allowed-vlan add 1172 Switch-01 (config) # interface mlag-
port-channel 116 switchport hybrid allowed-vlan add 1172
Switch-01 (config) # interface mlag-port-channel 117 switchport
hybrid allowed-vlan add 1172
Switch-01 (config) # interface mlag-port-channel 118 switchport
hybrid allowed-vlan add 1172
Switch-01 (config) # interface mlag-port-channel 115 switchport
hybrid allowed-vlan add 3481
Switch-01 (config) # interface mlag-port-channel 116 switchport
hybrid allowed-vlan add 3481
Switch-01 (config) # interface mlag-port-channel 117 switchport
hybrid allowed-vlan add 3481
Switch-01 (config) # interface mlag-port-channel 118 switchport
hybrid allowed-vlan add 3481

```



The configurations in this section must also be run on the second switch in the MLAG domain. NetApp recommends that the descriptions for each port are updated to reflect the device ports that are cabled and configured on the other switch.

Create uplink ports for the switches

1. Create an MLAG interface to provide uplinks to both Mellanox SN2010 switches from the core network.

```
Switch-01 (config) # interface mlag port-channel 101
Switch-01 (config interface mlag port-channel) # description Uplink
CORE-SWITCH port PORT
Switch-01 (config interface mlag port-channel) # exit
```

2. Configure the MLAG members.

```
Switch-01 (config) # interface ethernet 1/18 description Uplink to CORE-
SWITCH port PORT
Switch-01 (config) # interface ethernet 1/18 speed 10000 force
Switch-01 (config) # interface mlag-port-channel 101 mtu 9216 force
Switch-01 (config) # interface ethernet 1/18 mlag-channel-group 101 mode
active
```

3. Set the switchport mode to hybrid and allow all VLANs from the core uplink switches.

```
Switch-01 (config) # interface mlag-port-channel switchport mode hybrid
Switch-01 (config) # interface mlag-port-channel switchport hybrid
allowed-vlan all
```

4. Verify that the MLAG interface is up.

```
Switch-01 (config) # interface mlag-port-channel 101 no shutdown
Switch-01 (config) # exit
```

[Next: Deploy NetApp HCI with the NetApp Deployment Engine](#)

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.