



## **storage commands**

### ONTAP commands

NetApp

February 03, 2026

This PDF was generated from <https://docs.netapp.com/us-en/ontap-cli-9111/storage-aggregate-add-disks.html> on February 03, 2026. Always check [docs.netapp.com](https://docs.netapp.com) for the latest.

# Table of Contents

storage commands .....	1
storage aggregate commands .....	1
storage aggregate add-disks .....	1
storage aggregate auto-provision .....	4
storage aggregate create .....	6
storage aggregate delete .....	10
storage aggregate mirror .....	11
storage aggregate modify .....	12
storage aggregate offline .....	16
storage aggregate online .....	16
storage aggregate remove-stale-record .....	17
storage aggregate rename .....	17
storage aggregate restrict .....	18
storage aggregate scrub .....	18
storage aggregate show-auto-provision-progress .....	20
storage aggregate show-cumulated-efficiency .....	21
storage aggregate show-efficiency .....	25
storage aggregate show-resync-status .....	31
storage aggregate show-scrub-status .....	32
storage aggregate show-space .....	34
storage aggregate show-spare-disks .....	40
storage aggregate show-status .....	47
storage aggregate show .....	49
storage aggregate verify .....	61
storage aggregate efficiency show .....	62
storage aggregate efficiency stat .....	63
storage aggregate efficiency cross-volume-dedupe revert-to .....	64
storage aggregate efficiency cross-volume-dedupe show .....	65
storage aggregate efficiency cross-volume-dedupe start .....	68
storage aggregate efficiency cross-volume-dedupe stop .....	69
storage aggregate encryption show-key-id .....	69
storage aggregate inode-upgrade resume .....	70
storage aggregate inode-upgrade show .....	71
storage aggregate object-store attach .....	72
storage aggregate object-store mirror .....	73
storage aggregate object-store modify .....	74
storage aggregate object-store show-freeing-status .....	75
storage aggregate object-store show-resync-status .....	76
storage aggregate object-store show-space .....	77
storage aggregate object-store show .....	78
storage aggregate object-store unmirror .....	80
storage aggregate object-store config create .....	80
storage aggregate object-store config delete .....	83

storage aggregate object-store config modify . . . . .	84
storage aggregate object-store config rename . . . . .	86
storage aggregate object-store config show . . . . .	87
storage aggregate object-store profiler abort . . . . .	89
storage aggregate object-store profiler show . . . . .	90
storage aggregate object-store profiler start . . . . .	92
storage aggregate object-store put-rate-limit modify . . . . .	92
storage aggregate object-store put-rate-limit show . . . . .	93
storage aggregate plex delete . . . . .	94
storage aggregate plex offline . . . . .	94
storage aggregate plex online . . . . .	95
storage aggregate plex show . . . . .	95
storage aggregate reallocation quiesce . . . . .	98
storage aggregate reallocation restart . . . . .	98
storage aggregate reallocation schedule . . . . .	99
storage aggregate reallocation show . . . . .	100
storage aggregate reallocation start . . . . .	101
storage aggregate reallocation stop . . . . .	102
storage aggregate relocation show . . . . .	103
storage aggregate relocation start . . . . .	104
storage aggregate resynchronization modify . . . . .	105
storage aggregate resynchronization show . . . . .	106
storage aggregate resynchronization options modify . . . . .	107
storage aggregate resynchronization options show . . . . .	108
storage array commands . . . . .	109
storage array modify . . . . .	109
storage array remove . . . . .	110
storage array rename . . . . .	111
storage array show . . . . .	112
storage array config show . . . . .	114
storage array disk paths show . . . . .	117
storage array port modify . . . . .	122
storage array port remove . . . . .	122
storage array port show . . . . .	123
storage automated-working-set-analyzer commands . . . . .	126
storage automated-working-set-analyzer show . . . . .	126
storage automated-working-set-analyzer start . . . . .	129
storage automated-working-set-analyzer stop . . . . .	130
storage automated-working-set-analyzer volume show . . . . .	130
storage disk commands . . . . .	132
storage disk assign . . . . .	132
storage disk fail . . . . .	136
storage disk reassign . . . . .	136
storage disk refresh-ownership . . . . .	137
storage disk remove-reservation . . . . .	138

storage disk remove	138
storage disk removeowner	139
storage disk replace	140
storage disk set-foreign-lun	141
storage disk set-led	142
storage disk show	144
storage disk unfail	168
storage disk updatefirmware	169
storage disk zerospares	170
storage disk error show	171
storage disk firmware revert	172
storage disk firmware show-update-status	175
storage disk firmware update	176
storage disk option modify	180
storage disk option show	182
storage dqp commands	183
storage dqp show	183
storage encryption commands	185
storage encryption disk destroy	185
storage encryption disk modify	187
storage encryption disk revert-to-original-state	189
storage encryption disk sanitize	190
storage encryption disk show-status	192
storage encryption disk show	195
storage errors commands	199
storage errors show	199
storage failover commands	200
storage failover giveback	200
storage failover modify	202
storage failover show-giveback	205
storage failover show-takeover	206
storage failover show	210
storage failover takeover	228
storage failover hwassist show	230
storage failover hwassist test	232
storage failover hwassist stats clear	233
storage failover hwassist stats show	233
storage failover internal-options show	235
storage failover mailbox-disk show	239
storage failover progress-table show	241
storage firmware commands	242
storage firmware download	242
storage firmware acp delete	243
storage firmware acp rename	244
storage firmware acp show	244

storage firmware disk delete . . . . .	245
storage firmware disk rename . . . . .	246
storage firmware disk show . . . . .	246
storage firmware hba show . . . . .	247
storage firmware shelf delete . . . . .	248
storage firmware shelf rename . . . . .	249
storage firmware shelf show . . . . .	249
storage iscsi-initiator commands . . . . .	250
storage iscsi-initiator add-target . . . . .	250
storage iscsi-initiator connect . . . . .	251
storage iscsi-initiator disconnect . . . . .	252
storage iscsi-initiator remove-target . . . . .	253
storage iscsi-initiator show . . . . .	253
storage path commands . . . . .	255
storage path quiesce . . . . .	255
storage path resume . . . . .	256
storage path show-by-initiator . . . . .	257
storage path show . . . . .	259
storage pool commands . . . . .	265
storage pool add . . . . .	265
storage pool create . . . . .	267
storage pool delete . . . . .	269
storage pool reassign . . . . .	269
storage pool rename . . . . .	270
storage pool show-aggregate . . . . .	271
storage pool show-available-capacity . . . . .	272
storage pool show-disks . . . . .	274
storage pool show . . . . .	275
storage port commands . . . . .	278
storage port disable . . . . .	278
storage port enable . . . . .	279
storage port modify . . . . .	279
storage port rescan . . . . .	281
storage port reset-device . . . . .	282
storage port reset . . . . .	283
storage port show . . . . .	283
storage raid-options commands . . . . .	288
storage raid-options modify . . . . .	288
storage raid-options show . . . . .	289
storage shelf commands . . . . .	290
storage shelf show . . . . .	290
storage shelf acp configure . . . . .	319
storage shelf acp show . . . . .	320
storage shelf acp module show . . . . .	322
storage shelf drawer show-phy . . . . .	328

storage shelf drawer show-slot .....	332
storage shelf drawer show .....	334
storage shelf firmware show-update-status .....	337
storage shelf firmware update .....	338
storage shelf location-led modify .....	339
storage shelf location-led show .....	340
storage shelf port show .....	341
storage tape commands .....	345
storage tape offline .....	345
storage tape online .....	346
storage tape position .....	346
storage tape reset .....	348
storage tape show-errors .....	348
storage tape show-media-changer .....	350
storage tape show-supported-status .....	352
storage tape show-tape-drive .....	354
storage tape show .....	356
storage tape trace .....	361
storage tape alias clear .....	361
storage tape alias set .....	362
storage tape alias show .....	363
storage tape config-file delete .....	365
storage tape config-file get .....	365
storage tape config-file show .....	366
storage tape library config show .....	367
storage tape library path show-by-initiator .....	368
storage tape library path show .....	370
storage tape load-balance modify .....	373
storage tape load-balance show .....	373

# storage commands

## storage aggregate commands

### storage aggregate add-disks

Add disks to an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The `storage aggregate add-disks` command adds disks to an existing aggregate. You must specify the number of disks or provide a list of disks to be added. If you specify the number of disks without providing a list of disks, the system selects the disks.

#### Parameters

##### **-aggregate <aggregate name>** - Aggregate

This parameter specifies the aggregate to which disks are to be added.

##### **[-diskcount <integer>]** - Disk Count

This parameter specifies the number of disks that are to be added to the aggregate.

##### **{ [-T, -disktype {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}] - Disk Type**

This parameter specifies the type of disk that is to be added. It must be specified with the `-diskcount` parameter when adding disks to a Flash Pool.

Use this parameter when adding spare SSDs to an aggregate to convert it to a Flash Pool.



Only the aggregates marked as hybrid-enabled can be converted to Flash Pools. Use [storage aggregate modify](#) command to mark the aggregate as hybrid-enabled.



When this parameter is used, disk selection is not influenced by RAID options `raid.mix.hdd.disktype.capacity`, `raid.mix.hdd.disktype.performance`, or `raid.mix.disktype.solid_state`. Only disks of the specified type are considered eligible for selection.

##### **| [-C, -diskclass {capacity | performance | archive | solid-state | array | virtual}] - Disk Class**

This parameter specifies the class of disk that is to be added. All disks that belong to the specified class are considered eligible for selection. The possible values are:

- `capacity` = Capacity-oriented, near-line disk types. Includes disk types FSAS, BSAS and ATA.
- `performance` = Performance-oriented, enterprise class disk types. Includes disk types FCAL and SAS.
- `archive` = Archive class SATA disks in multi-disk carrier storage shelves. Includes disk type MSATA.
- `solid-state` = Solid-state drives. Includes disk type SSD, SSD-CAP and SSD-NVM.

- array = Logical storage devices backed by storage arrays and used by Data ONTAP as disks. Includes disk type LUN.
- virtual = Virtual disks that are formatted and managed by the hypervisor. Includes disk type VMDISK.



When this parameter is used, disk selection is not influenced by RAID options `raid.mix.hdd.disktype.capacity`, `raid.mix.hdd.disktype.performance`, or `raid.mix.disktype.solid_state`.

#### **`[-chksumstyle <aggrChecksumStyle>]` - Checksum Style**

This parameter specifies the checksum style for the disks to be added to an aggregate. It is not applicable if `-disklist` or `-mirror-disklist` is specified. The possible values are `block` for block checksum and `advanced_zoned` for advanced zoned checksum (AZCS). By default, disks with the same checksum style as the aggregate are selected. This behavior can be overridden by using this parameter to create a mixed checksum aggregate. A mixed checksum aggregate can support only the `block` and `advanced_zoned` checksum styles.

#### **`[-disksize <integer>]` - Disk Size(GB)**

This parameter specifies the size, in GB, of the disks that are to be added to the aggregate. Disks with a usable size between 90% and 105% of the specified size are selected.

##### **`| [-d, -disklist <disk path name>,...]` - Disks**

This parameter specifies a list of disks to be added. If you specify the `-disklist` parameter, you cannot further qualify the list of disks to be added by count, checksum style, size or type.

##### **`[-mirror-disklist <disk path name>,...]` - Disks for Mirrored Plex**

This parameter specifies a list of mirror disks to be added. It must contain the same number of disks specified in `-disklist` parameter. If you specify the `-mirror-disklist` parameter, you cannot further qualify the list of disks to be added by count, checksum style or type.

##### **`{ [-ignore-pool-checks <true>]` - Don't Enforce Plex Pool Best Practices**

The disks in a plex are normally required to come from the same SyncMirror pool. This behavior can be overridden with this parameter when it is set to `true`.

##### **`[-f, -allow-mixed-rpm <true>]` - Allow Disks With Different RPM Values**

This parameter specifies whether disks that have different RPM values can be added. For example, SAS disks can rotate at 10,000 or 15,000 RPM. If this parameter is set to `true` and a list of disks are provided by using the `-disklist` parameter, the disks will be added even if the SAS disks you specify have different RPM values. This parameter works similarly for ATA disks, which can rotate at 5,400 or 7,200 RPM.

+

NOTE: This parameter is applicable only when the `-disklist` or `-mirror-disklist` parameter is used.

##### **`[-allow-same-carrier <true>]` - Allow Same RAID Group Within Carrier**

This parameter can be used to allow two disks housed in the same carrier to be in the same RAID group when you add disks to an aggregate.

Having disks in the same carrier in the same RAID group is not desirable because a carrier failure can cause a simultaneous outage for two disks in the same RAID group. You can add a disk to an aggregate that causes this situation, but when an alternate disk becomes available, Data ONTAP automatically

initiates a series of disk copy operations to put the disks into different RAID groups. For this reason, you should use this parameter only when necessary. When possible, allow Data ONTAP to choose disks that need to be added to the aggregate.

This parameter affects only the add-disks operation. It is not a persistent attribute of the aggregate.

#### **[-storage-pool <storage pool name>] - Storage Pool**

This parameter specifies the name of the SSD storage pool from which available allocation units are added to a given aggregate. This parameter cannot be used with the `-disk-list` or `-disk-count` parameters.

#### **[-allocation-units <integer>] - Allocation Units }**

This parameter specifies the number of allocation units to be added to a given aggregate from an SSD storage pool. Number of allocation units available and size of each unit can be found using the [storage pool show-available-capacity](#) command. This parameter works only when you also use the `-storage-pool` parameter.

#### **[-n, -simulate <true>] - Simulate Addition of Disks**

This parameter is used with the `disktype` and `diskcount` parameters to determine which disks would be added without actually performing the addition of disks operation.

#### **[-g, -raidgroup {new|all|<raidgroup>}] - RAID Group**

This parameter enables the administrator to specify which RAID group will receive the added disks. If this parameter is not used, the disks are added to the most recently created RAID group until it is full, then new RAID groups are created and filled until all the disks are added. If a RAID group name `rgX` is specified, the disks are added to that RAID group. If `new` is specified, the disks are added to a new RAID group, even if the disks would fit into an existing RAID group. If `all` is specified, the disks are added to existing RAID groups until all existing RAID groups are full. Then Data ONTAP creates one or more new RAID groups and adds the remaining disks to the new groups. If the disk type or checksum style parameters are specified with this parameter, the command operates only on the RAID groups with the matching disk type or checksum style, even if `all` is specified.

#### **[-cache-raid-group-size <integer>] - RAID Group Size for Cache Tier**

This parameter specifies the maximum number of disks that can be included in an SSD RAID group for this aggregate.



This parameter is applicable only when adding SSDs for the first time to a hybrid-enabled aggregate. If this parameter is not used when the first SSDs are added to the aggregate, the maximum RAID group size for the SSD cache is set to the default SSD RAID group size for the RAID type of the SSD cache.

#### **[-t, -raidtype {raid\_tec|raid\_dp|raid4|raid\_ep}] - RAID Type**

This parameter specifies the type for the new RAID groups that would be created while adding disks to the aggregate. Use this parameter when you add the first RAID group comprised of SSDs to a hybrid-enabled aggregate. The values are `raid4` for RAID4, `raid_dp` for RAID Double Parity, and `raid_tec` for RAID-TEC. The default value is the type of RAID groups of the aggregate, except for RAID-TEC hybrid-enabled aggregates where the SSD tier will default to `raid_dp`. An aggregate might include a mix of different RAID types.

## **Examples**

The following example adds 10 disks to an aggregate named `aggr0`. The disks are added to a RAID group named `rg1`:

```
cluster1::> storage aggregate add-disks -aggregate aggr0 -diskcount 10  
-raidgroup rg1
```

In this example, an aggregate is converted to a Flash Pool aggregate using SSD capacity from a storage pool. The aggregate was created using RAID-DP for the hard disks and the SSDs are added using RAID4.

```
cluster1::> storage aggregate add-disks -aggregate FlashPool -storage-pool  
SP1 -allocation-units 1 -raidtype raid4
```

## Related Links

- [storage aggregate modify](#)
- [storage pool show-available-capacity](#)

## storage aggregate auto-provision

Recommend and create new aggregates in the cluster

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

This command analyzes available spare disks in the cluster, and it provides a recommendation how spare disks should be used to create aggregates according to best practices. The command prints the summary of recommended aggregates including their names and usable size. It then prompts the user whether or not the aggregates should be created as recommended. On positive response, ONTAP creates the aggregates as described in the recommendation.

The command parameters allow to restrict the command to some nodes in the cluster, print more details about recommended aggregates, and to skip the prompt.

### Parameters

#### **[-nodes {<nodename>|local}] - List of Nodes**

Comma separated list of node names to which the command applies. If this parameter is not used, the command applies to all nodes in the cluster.

#### **[-verbose <true>] - Report More Details**

Report additional details about recommended aggregates and spare disks. Per node summary shows number and total size of aggregates to create, discovered spares, and also remaining spare disks and partitions after aggregate creation. RAID group layout shows how spare disks and partitions will be used in new data aggregates to be created. The last table shows spare disks and partitions remaining unused after aggregate creation.

#### **[-skip-confirmation <true>] - Skip the Confirmation and Create Recommended Aggregates**

When this parameter is used, the command automatically creates the recommended aggregates. When this parameter is not used, the command checks to proceed with aggregate creation or not.



The command is not affected by the CLI session setting: `set-confirmation on/off`.

## Examples

```
cluster1::storage aggregate> auto-provision
Node           New Data Aggregate           Usable Size
-----
node1          node1_SSD_1                 3.66TB
node2          node2_SSD_1                 3.66TB
-----
Total:        2 new data aggregates      7.32TB

Do you want to create recommended aggregates? {y|n}: n

cluster1::storage aggregate> auto-provision -verbose
Per node summary of new aggregates to create, discovered spares, and also
remaining spare disks and partitions after aggregate creation:
New      Total New -Discovered Spare- -Remaining Spare-
Node           Aggrs  Usable Size  Disks  Partitions  Disks  Partitions
-----
node1          1      3.66TB   6      48      1      0
node2          1      3.66TB   6      48      1      0
-----
Total:        2      7.32TB  12      96      2      0

New data aggregates to create with counts of
disks and partitions to be used:
Is      Usable  -Devices To Use-
Node           New Data Aggregate           Mirrored      Size  Disks
Partitions
-----
-----
node1          node1_SSD_1                 false     3.66TB   5
48
node2          node2_SSD_1                 false     3.66TB   5
48

RAID group layout showing how spare disks and partitions will be used
in new data aggregates to be created:

RAID Group In New           Disk           Usable Disk Or
---Count---
Data Aggregate To Be Created  Type           Size Partition Data
Parity
-----
```

```
-----
/node1_SSD_1/plex0/rg0           SSD      81.97GB partition  22
2
/node1_SSD_1/plex0/rg1           SSD      81.97GB partition  22
2
/node1_SSD_1/plex0/rg2           SSD      185.5GB disk      3
2
/node2_SSD_1/plex0/rg0           SSD      81.97GB partition  22
2
/node2_SSD_1/plex0/rg1           SSD      81.97GB partition  22
2
/node2_SSD_1/plex0/rg2           SSD      185.5GB disk      3
2
```

Details about spare disks and partitions remaining after aggregate creation:

Disk Node	Device Type	Disk Or Usable Size	Pool Partition Number	Remaining Spares
node1	SSD	185.5GB disk	Pool0	1
node2	SSD	185.5GB disk	Pool0	1

Do you want to create recommended aggregates? {y|n}: y

Info: Aggregate auto provision has started. Use the "storage aggregate show-auto-provision-progress" command to track the progress.

## Related Links

- [set](#)

## storage aggregate create

### Create an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate create` command creates an aggregate. An aggregate consists of disks. You must specify the number of disks or provide a list of disks to be added to the new aggregate. If you specify the number of disks without providing a list of disks, the system selects the disks.

When creating an aggregate, you can optionally specify the aggregate's home node, the RAID type for RAID groups on the aggregate, and the maximum number of disks that can be included in a RAID group.

## Parameters

### **-aggregate <aggregate name> - Aggregate**

This parameter specifies the name of the aggregate that is to be created.

### **[-checksumstyle <aggrChecksumStyle>] - Checksum Style**

This parameter specifies the checksum style for the aggregate. The values are *block* for Block Checksum and *advanced\_zoned* for Advanced Zoned Checksum (AZCS).

### **-diskcount <integer> - Number Of Disks**

This parameter specifies the number of disks that are to be included in the aggregate, including the parity disks. The disks in this newly created aggregate come from the pool of spare disks. The smallest disks in this pool are added to the aggregate first, unless you specify the **-disksize** parameter.

### **[-R, -diskrpm <integer>] - Disk RPM**

This parameter specifies the RPM of the disks on which the aggregate is to be created. The possible values include 5400, 7200, 10000, and 15000.

### **[-disksize <integer>] - Disk Size(GB)**

This parameter specifies the size, in GB, of the disks on which the aggregate is to be created. Disks with a usable size between 90% and 105% of the specified size are selected.

### **{ [-T, -disktype {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}] - Disk Type**

This parameter specifies the type of disk on which the aggregate is to be created.



When this parameter is used, disk selection is not influenced by RAID options `raid.mix.hdd.disktype.capacity`, `raid.mix.hdd.disktype.performance`, or `raid.mix.disktype.solid_state`. Only disks of the specified type are considered eligible for selection.

### **| [-C, -diskclass {capacity | performance | archive | solid-state | array | virtual}] - Disk Class**

This parameter specifies the class of disks on which the aggregate is to be created. All disks that belong to the specified class are considered eligible for selection. The possible values are:

- **capacity** = Capacity-oriented, near-line disk types. Includes disk types FSAS, BSAS and ATA.
- **performance** = Performance-oriented, enterprise class disk types. Includes disk types FCAL and SAS.
- **archive** = Archive class SATA disks in multi-disk carrier storage shelves. Includes disk type MSATA.
- **solid-state** = Solid-state drives. Includes disk type SSD, SSD-CAP and SSD-NVM.
- **array** = Logical storage devices backed by storage arrays and used by Data ONTAP as disks. Includes disk type LUN.
- **virtual** = Virtual disks that are formatted and managed by the hypervisor. Includes disk type VMDISK.



When this parameter is used, disk selection is not influenced by RAID options `raid.mix.hdd.disktype.capacity`, `raid.mix.hdd.disktype.performance`, or `raid.mix.disktype.solid_state`.

**[-m, -mirror <true>] - Is Mirrored**

This parameter specifies that the new aggregate be mirrored (have two plexes). If this parameter is set to *true*, the specified disks are split between the two plexes. By default, the new aggregate will not be mirrored. You cannot use the *-mirror* parameter when supplying a specific list of disks with either the *-disklist* or *-mirror-disklist* parameters.

**[-pool <aggrSparePool>] - Spare Pool**

This parameter specifies the SyncMirror pool to be used to supply the disks for the aggregate. Valid values are Pool0 or Pool1.

**| -d, -disklist <disk path name>, ... - Disks for First Plex**

This parameter specifies a list of disks to be added to the new aggregate. If you specify the *-disklist* parameter, you cannot further qualify the list of disks to be added by count, checksum style, type, size, or RPM. You cannot use the *-disklist* parameter when the *-mirror* parameter is set to *true*.

**[-mirror-disklist <disk path name>, ...] - Disks for Mirrored Plex**

This parameter specifies a list of mirror disks to be added to the new mirrored aggregate. It must contain the same number of disks specified in *-disklist* parameter. If you specify the *-mirror-disklist* parameter, you cannot further qualify the list of disks to be added by count, checksum style, type, size, or RPM. You cannot use the *-mirror-disklist* parameter when the *-mirror* parameter is set to *true*.

**[-ignore-pool-checks <true>] - Don't Enforce Plex Pool Best Practices**

The disks in a plex are normally required to come from the same SyncMirror pool. This behavior can be overridden with this parameter when it is set to *true*. This option cannot be used when the *-mirror* option is set to *true*.

**[-f, -allow-mixed-rpm <true>] - Allow Disks With Different RPM Values**

This parameter specifies whether the aggregate can contain disks that have different RPM values. For example, SAS disks can rotate at 10,000 or 15,000 RPM. If this parameter is set to *true* and a list of disks are provided by using the *-disklist* parameter, the aggregate will be created even if the SAS disks you specify have different RPM values. This parameter works similarly for ATA disks, which can rotate at 5,400 or 7,200 RPM.

**[-allow-same-carrier <true>] - Allow Same RAID Group Within Carrier**

This parameter can be used to allow two disks housed in the same carrier to be in the same RAID group when you add disks to an aggregate.

Having disks in the same carrier in the same RAID group is not desirable because a carrier failure can cause a simultaneous outage for two disks in the same RAID group. You create an aggregate with this characteristic, but when an alternate disk becomes available, Data ONTAP automatically initiates a series of disk copy operations to put the disks into different RAID groups. For this reason, you should use this parameter only when necessary. When possible, allow Data ONTAP to choose the disks from which to create the aggregate.

This parameter affects only the aggregate creation operation. It is not a persistent attribute of the aggregate.

**[-node {<nodename>|local}] - Node**

This parameter specifies the home node for the aggregate. If this parameter is not specified, Data ONTAP selects the node where the aggregate is created.

**[-s, -maxraidsize <integer>] - Max RAID Size**

This parameter specifies the maximum number of disks that can be included in a RAID group.

**[-t, -raidtype {raid\_tec|raid\_dp|raid4|raid\_ep}] - RAID Type**

This parameter specifies the type for RAID groups on the aggregate. The values are *raid4* for RAID4 of disks other than *SSD-ZNS*, *raid\_ep* for RAID4 of *SSD-ZNS* disks plus RAID4 inside each *SSD-ZNS* disk, *raid4* for RAID4, *raid\_dp* for RAID Double Parity, and *raid\_tec* for RAID Triple-Erasure-Code. The default setting is *raid\_dp* for disks other than *SSD-ZNS* unless the disks are HDDs with a capacity larger than 4 TB, in which case the default will be *raid\_tec*. For *SSD-ZNS* disks the default setting will be *raid\_ep*. This parameter is not needed for array LUNs because they are always created with the *raid0* raidtype. *raid4* and *raid\_ep* are not compatible with shared disks unless the shared disks belong to a storage pool.

**[-simulate <true>] - Simulate Aggregate Provisioning Operation**

This option simulates the aggregate creation and prints the layout of the new aggregate.

**[-force-small-aggregate <true>] - Force the Creation of a Small Aggregate (privilege: advanced)**

This parameter can be used to force the creation of a 2-disk RAID4 and RAID-EP aggregates, or a 3-disk or 4-disk RAID-DP aggregate.

**[-is-autobalance-eligible {true|false}] - Is Eligible for Auto Balance Aggregate (privilege: advanced)**

This specifies whether the aggregate will be considered by the Auto Balance Aggregate feature. If the Auto Balance Aggregate feature is not used, this field is not used. When this parameter is set to *true* the Auto Balance Aggregate feature might recommend moving volumes to or from this aggregate in order to balance system workload. When this parameter is set to *false* the aggregate will not be considered as a destination for the Auto Balance Aggregate feature allowing for predictability in data placement. The default value is *false*.

**[-L, -snaplock-type {non-snaplock|compliance|enterprise}] - SnapLock Type**

This parameter specifies the type of SnapLock aggregate to be created. In order to create a SnapLock Compliance aggregate, specify *compliance*. To create a SnapLock Enterprise aggregate, specify *enterprise*.

**[-autobalance-unbalanced-threshold-percent <integer>] - Threshold When Aggregate Is Considered Unbalanced (%) (privilege: advanced)**

This parameter specifies the space used threshold percentage that will cause the Auto Balance Aggregate feature to consider an aggregate as unbalanced.

**[-autobalance-available-threshold-percent <integer>] - Threshold When Aggregate Is Considered Balanced (%) (privilege: advanced)**

This parameter specifies the threshold percentage which will determine if an aggregate is a target destination for a move. The Auto Balance Aggregate feature will attempt to move volumes from an unbalanced aggregate until it is under this percentage.

**[-encrypt-with-aggr-key {true|false}] - Enable Aggregate level Encryption**

This parameter specifies the data encryption policy for the contained volumes. If this parameter is set to *true*, then by default, the volumes created in this aggregate will be encrypted, using the aggregate level encryption keys.

## Examples

The following example creates an aggregate named aggr0 on a home node named node0. The aggregate contains 20 disks and uses RAID-DP. The aggregate contains regular FlexVol volumes:

```
cluster1::> storage aggregate create -aggregate aggr0 -nodes node0  
-diskcount 20 -raidtype raid_dp -volume-style flex
```

The following example creates an aggregate named aggr0 on a home node named node0. The aggregate contains the disks specified and uses RAID-DP

```
cluster1::> storage aggregate create -aggregate aggr0 -nodes node0  
-disklist 1.0.15,1.0.16,1.0.17,1.0.18,1.0.19 -raidtype raid_dp
```

The following example creates an aggregate named aggr0 on a home node named node0. The aggregate contains 20 disks of size 6 TB and of type FSAS and uses RAID-TEC:

```
cluster1::> storage aggregate create -aggregate aggr0 -nodes node0  
-diskcount 20 -raidtype raid_tec -disksize 6000 -disktype FSAS
```

The following example creates a mirrored aggregate named aggr0 on the local node. The aggregate contains 10 disks in each plex:

```
cluster1::> storage aggregate create -aggregate aggr0 -mirror  
-diskcount 20
```

## storage aggregate delete

### Delete an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The *storage aggregate delete* command deletes a storage aggregate. The command fails if there are volumes present on the aggregate. If the aggregate has an object store attached to it, then in addition to deleting the aggregate the command deletes the objects in the object store as well. No changes are made to the object store configuration as part of this command.

#### Parameters

##### **-aggregate <aggregate name> - Aggregate**

This parameter specifies the aggregate that is to be deleted.

## **[-preserve-config-data <true>] - Delete Physical Aggregate but Preserve Configuration Data (privilege: advanced)**

Deletes the physical aggregate, but preserves the aggregate configuration data. The aggregate must not have any disks associated with it. If the parameter `-preserve-config-data` is specified without a value, the default value is `true`; if this parameter is not specified, the default value is `false`.

### **Examples**

The following example deletes an aggregate named aggr1:

```
cluster1::> storage aggregate delete -aggregate aggr1
```

## **storage aggregate mirror**

### **Mirror an existing aggregate**

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### **Description**

The `storage aggregate mirror` command adds a plex to an existing unmirrored aggregate. You can specify a list of disks to be used for the mirrored plex. If you do not specify the disks, the system automatically selects the disks based on the aggregate's existing plex.

#### **Parameters**

##### **-aggregate <aggregate name> - Aggregate**

This parameter specifies the aggregate to mirror.

##### **[-f, -allow-mixed-rpm <true>] - Allow Disks With Different RPM Values**

This parameter specifies whether disks that have different RPM values can be used. For example, SAS disks can rotate at 10,000 or 15,000 RPM. If this parameter is set to `true` and a list of disks are provided by using the `-mirror-disklist` parameter, the disks will be added even if the SAS disks you specify have different RPM values. This parameter works similarly for ATA disks, which can rotate at 5,400 or 7,200 RPM.

+

NOTE: This parameter is only applicable when the `-mirror-disklist` parameter is used.

##### **[-d, -mirror-disklist <disk path name>, ...] - Disks for Mirrored Plex**

This parameter specifies a list of disks to be used for the plex to be added. It must contain the same number of disks as the existing plex of the unmirrored aggregate specified using the `-aggregate` parameter.

##### **[-ignore-pool-checks <true>] - Don't Enforce Plex Pool Best Practices**

For maximum reliability, all disks from a plex should come from the same SyncMirror pool, and the disks for the second plex should all come from the other pool. If needed, this behavior can be overridden by setting this parameter to `true`. This parameter can be used only with the `-mirror-disklist` parameter.

## **[-f, -allow-same-carrier <true>] - Allow Same RAID Group Within Carrier**

This parameter can be used to allow two disks housed in the same carrier to be in the same RAID group for a mirrored aggregate. Having disks in the same carrier in the same RAID group is not desirable, because a carrier failure can cause a simultaneous outage for two disks in the same RAID group. For this reason, this configuration is not allowed by default. This restriction can be overridden by setting this parameter to *true*.

+

NOTE: This parameter is accepted only when the *-mirror-disklist* parameter is used.

## **[-n, -simulate <true>] - Simulate Mirroring of an Existing Aggregate**

This option simulates the mirroring of an existing aggregate and prints the layout of the new plex.

### **Examples**

The following example mirrors an unmirrored aggregate *aggr1*:

```
cluster1::> storage aggregate mirror -aggregate aggr1
```

The following example mirrors an unmirrored aggregate *aggr1*. The specified disks are used for the new plex.

```
cluster1::> storage aggregate mirror -aggregate aggr1 -mirror-disklist
1.2.12, 1.2.14, 1.2.16
```

## **storage aggregate modify**

### **Modify aggregate attributes**

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### **Description**

The *storage aggregate modify* command can be used to modify attributes of an aggregate such as RAID type and maximum RAID group size.

Changing the RAID type immediately changes the RAID group type for all RAID groups in the aggregate.

Changing the maximum RAID size does not cause existing RAID groups to grow or to shrink; rather, it affects the size of RAID groups created in the future, and determines whether more disks can be added to the RAID group that was most recently created.

#### **Parameters**

##### **-aggregate <aggregate name> - Aggregate**

This parameter specifies the storage aggregate that is to be modified.

##### **[-T, -disktype {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}] - Disk Type**

This parameter specifies the disk type of the RAID groups to be modified. In case of Flash Pool, it specifies either the HDD tier or the SSD tier. If the HDD tier is composed of more than one type of disk, specifying

any of the disk types in use causes that tier to be modified. If the current aggregate RAID type is mixed\_raid\_type, this parameter is mandatory.

#### **[-free-space-realloc {on|off}] - Free Space Reallocation**

This parameter specifies whether free space reallocation is enabled on the aggregate.

Free space reallocation optimizes the free space in an aggregate immediately before Data ONTAP writes data to the blocks in that aggregate. This field is not allowed on aggregates with SSD-ZNS disks.

The default setting is off.

#### **[-ha-policy {sfo|cfo}] - HA Policy**

This parameter specifies the high-availability policy to be used in the context of a root recovery procedure. Do not modify this setting unless directed to do so by a customer support representative.

#### **[-percent-snapshot-space <percent>] - Space Reserved for Snapshot Copies**

This parameter is used to set the space reserved for Snapshot copies to the specified value. For example, to set the snapshot reserve to 5%, you should enter -percent-snapshot-space 5.

#### **[-space-nearly-full-threshold-percent <percent>] - Aggregate Nearly Full Threshold Percent**

This optionally specifies the percentage at which the aggregate is considered nearly full, and above which an EMS warning will be generated. The default value is 95%. The maximum value for this option is 99%. Setting this threshold to 0 disables the aggregate nearly full space alerts.

#### **[-space-full-threshold-percent <percent>] - Aggregate Full Threshold Percent**

This optionally specifies the percentage at which the aggregate is considered full, and above which a critical EMS error will be generated. The default value is 98%. The maximum value for this option is 100%. Setting this threshold to 0 disables the aggregate full space alerts.

#### **[-hybrid-enabled {true|false}] - Hybrid Enabled**

If the hybrid-enabled option is set to "true", the aggregate is marked as hybrid\_enabled, that is, the aggregate can contain a mix of SSDs and HDDs (Hard Disk Drives, e.g., SAS, SATA, and/or FC). By default, aggregates cannot be marked "hybrid\_enabled" if the aggregate contains FlexVols that cannot be write cached. A FlexVol cannot be write-cached if it is part of an aggregate created in Data ONTAP 7. Use -force-hybrid-enabled to over-ride this behavior.

#### **[-f, -force-hybrid-enabled <true>] - Force Marking of Aggregate as Hybrid Enabled**

By default, aggregates cannot be marked "hybrid\_enabled" if the aggregate contains FlexVols that cannot be write cached. A FlexVol cannot be write-cached if it is part of an aggregate created in Data ONTAP 7. Use -force-hybrid-enabled to over-ride this behavior. Note that read caching will be enabled on these FlexVols, but write caching will be disabled.

#### **[-s, -maxraidsize <integer>] - Max RAID Size**

This parameter specifies the maximum number of disks that can be included in a RAID group for this aggregate.



For Flash Pools, this option controls the maximum size of the HDD RAID groups.

#### **[-cache-raid-group-size <integer>] - Flash Pool SSD Tier Maximum RAID Group Size**

This parameter specifies the maximum number of disks that can be included in a SSD RAID group for this Flash Pool.



This parameter is applicable only for Flash Pools.

#### **[-t, -raidtype {raid\_tec|raid\_dp|raid4|raid\_ep}] - RAID Type**

This parameter specifies the RAID type for RAID groups on the aggregate. The possible values are *raid4* for RAID4 of disks other than *SSD-ZNS*, *raid\_ep* for RAID4 of *SSD-ZNS* disks with additional RAID4 protection inside each disk, *raid\_dp* for RAID-DP, and *raid\_tec* for RAID-TEC. If you change the RAID type from RAID4 or RAID-EP to RAID-DP, each RAID group allocates a spare disk for the group's second parity disk and begins a reconstruction process. If you change the RAID type from RAID-DP to RAID-TEC, each RAID group allocates a spare disk for the group's third parity disk and begins a reconstruction process. Changing the RAID type from RAID4 and RAID-EP to RAID-TEC or vice-versa is not supported. To change the RAID type from RAID4 or RAID-EP to RAID-TEC, first change from RAID4 or RAID-EP to RAID-DP and then to RAID-TEC.

#### **[-resyncsnaptime <integer>] - SyncMirror Resync Snapshot Frequency in Minutes**

This parameter sets the mirror resynchronization snapshot frequency to be the given number of minutes. The default value is 60 (minutes).

#### **[-state <aggregate state>] - State**

This deprecated parameter specifies the state of the aggregate. The possible values are as follows:

- online - Immediately sets the aggregate online. All volumes on the aggregate are set to the state they were in when the aggregate was taken offline or restricted. The preferred command to bring an aggregate online is `storage aggregate online`.
- offline - Takes an aggregate offline. You cannot take an aggregate offline if any of its volumes are online. The preferred command to take an aggregate offline is `storage aggregate offline`.
- restricted - Restricts the aggregate. You cannot restrict an aggregate if any of its volumes are online. The preferred command to restrict an aggregate is `storage aggregate restrict`.

#### **[-is-autobalance-eligible {true|false}] - Is Eligible for Auto Balance Aggregate (privilege: advanced)**

This specifies whether the aggregate is considered by the Auto Balance Aggregate feature. If the Auto Balance Aggregate feature is not used, this field is not used. When this parameter is set to *true* the Auto Balance Aggregate feature might recommend moving volumes to or from this aggregate in order to balance system workload. When this parameter is set to *false* the aggregate will not be considered as a destination for the Auto Balance Aggregate feature allowing for predictability in data placement. The default value is *false*.

#### **[-autobalance-unbalanced-threshold-percent <integer>] - Threshold When Aggregate Is Considered Unbalanced (%) (privilege: advanced)**

This parameter sets the space used threshold percentage that will cause the Auto Balance Aggregate feature to consider an aggregate as unbalanced.

#### **[-autobalance-available-threshold-percent <integer>] - Threshold When Aggregate Is Considered Balanced (%) (privilege: advanced)**

This parameter sets the threshold percentage which will determine if an aggregate is a target destination for a move. The Auto Balance Aggregate feature will attempt to move volumes from an unbalanced aggregate until it is under this percentage.

#### **[-resync-priority {high(fixed)|high|medium|low}] - Resynchronization Priority**

This parameter specifies the new resynchronization priority value for the specified aggregate. This field

cannot be modified for unmirrored or Data ONTAP system aggregates.

Possible values for this parameter are:

- high: Mirrored data aggregates with this priority value start resynchronization first.
- medium: Mirrored data aggregates with this priority value start resynchronization after all the system aggregates and data aggregates with 'high' priority value have started resynchronization.
- low: Mirrored data aggregates with this priority value start resynchronization only after all the other aggregates have started resynchronization.

#### **[-single-instance-data-logging {off|on}] - Enable SIDL**

This parameter specifies whether Single Instance Data Logging feature is enabled on the aggregate and the constituent volumes on the aggregate. This feature improves user write performance by optimizing the amount of data logged by user writes on platforms where NVRAM and secondary storage are of same media type.

#### **[-is-inactive-data-reporting-enabled {true|false}] - Inactive Data Reporting Enabled**

This parameter specifies whether the reporting of how much user data is inactive should be enabled on the aggregate and volumes on the aggregate. This parameter is not allowed on FabricPools.

#### **[-encrypt-with-aggr-key {true|false}] - Enable Aggregate level Encryption**

This parameter specifies that the volumes within the new aggregate can be encrypted with aggregate keys. If this parameter is set to `true`, the aggregate will support encryption with aggregate keys.

#### **[-force-disable-encrypt-with-aggr-key <true>] - Force disable NAE. Skip aggregate snapshot check.**

This parameter allows disabling NetApp Aggregate Encryption (NAE) on an aggregate if the user is certain there is no aggregate snapshot for that aggregate containing NAE volumes. If the parameter is set to `true`, aggregate snapshot check is skipped and NAE is disabled.

#### **[-azcs-read-optimization {on|off}] - azcs read optimization**

This parameter specifies whether azcs read optimization is enabled on the aggregate. This feature improves read performance on cloud platforms.

## **Examples**

The following example changes all RAID groups on an aggregate named aggr0 to use RAID-DP:

```
cluster1::> storage aggregate modify -aggregate aggr0 -raidtype raid_dp
```

The following example changes all RAID groups with FSAS disks in an aggregate named aggr0 to use RAID-TEC:

```
cluster1::> storage aggregate modify -aggregate aggr0 -disktype FSAS  
-raidtype raid_tec
```

## storage aggregate offline

### Offline an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The `storage aggregate offline` command takes an aggregate offline.

If you are taking a root aggregate offline, the node owning the aggregate must be in maintenance mode.

#### Parameters

##### **-aggregate <aggregate name> - Aggregate**

The name of the aggregate to be taken offline.

#### Examples

The following example takes an aggregate named `aggr1` offline:

```
cluster1::> storage aggregate offline -aggregate aggr1
```

## storage aggregate online

### Online an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The `storage aggregate online` command brings an aggregate online if the aggregate is in offline or restricted state. If an aggregate is in an inconsistent state, it must be brought to a consistent state before it can be brought online. If you have an aggregate that is in an inconsistent state, contact technical support.

#### Parameters

##### **-aggregate <aggregate name> - Aggregate**

The name of the aggregate to be brought online.

#### Examples

The following example brings an aggregate named `aggr1` online:

```
cluster1::> storage aggregate online -aggregate aggr1
```

## storage aggregate remove-stale-record

Remove a stale aggregate record

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage aggregate remove-stale-record` command removes a stale storage aggregate record on disk. A stale aggregate record refers to an aggregate that has been removed from the storage system, but whose information remains recorded on disk. Stale aggregate records are displayed in the `nodeshell aggr status -r` command, but the `storage aggregate show` command does not show the aggregate as hosted on that node.

### Parameters

#### **-aggregate <aggregate name> - Aggregate (privilege: advanced)**

This parameter specifies the aggregate that corresponds to the stale aggregate record that is to be deleted.

#### **-nodename {<nodename>|local} - Node Name (privilege: advanced)**

This parameter specifies the node that contains the aggregate.

### Examples

The following example removes a stale aggregate record that refers to aggregate "aggr1":

```
cluster1::> storage aggregate remove-stale-record -aggregate aggr1  
-nodename node1
```

## storage aggregate rename

Rename an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate rename` command renames an aggregate.

### Parameters

#### **-aggregate <aggregate name> - Aggregate**

This parameter specifies the aggregate to be renamed.

#### **-newname <aggregate name> - New Name**

This parameter specifies the new name for the aggregate.

### Examples

The following example renames an aggregate named aggr5 as sales-aggr:

```
cluster1::> storage aggregate rename -aggregate aggr5 -newname sales-aggr
```

## storage aggregate restrict

Restrict an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate restrict` command puts an aggregate in restricted state to make data in the aggregate's volumes unavailable to clients. When an aggregate is in restricted state data access is not allowed. However, few operations such as aggregate copy, parity recomputation, scrub and RAID reconstruction are allowed. You can also use this command if you want the aggregate to be the target of an aggregate copy or SnapMirror replication operation.

### Parameters

#### **-aggregate <aggregate name> - Aggregate**

The name of the aggregate to be restricted.

### Examples

The following example restricts an aggregate named aggr1:

```
cluster1::> storage aggregate restrict -aggregate aggr1
```

## storage aggregate scrub

Aggregate parity scrubbing

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate scrub` command scrubs an aggregate for media and parity errors. Parity scrubbing compares the data disks to the parity disks in their RAID group and corrects the parity disks contents, as required. If no name is given, parity scrubbing is started on all online aggregates.



By default, scrubs are scheduled to run for a specified time on a weekly basis. However, you can use this command to run scrubs manually to check for errors and data inconsistencies.

### Parameters

#### { **-aggregate <aggregate name> - Aggregate**

This parameter specifies the aggregate to be scrubbed for errors.

#### **[-plex <text>] - Plex**

This parameter specifies the name of the plex to scrub. If this parameter is not specified, the command scrubs the entire aggregate.

#### **[-raidgroup <text>] - RAID Group**

This parameter specifies the RAID group to be scrubbed. If this parameter is not specified, the command scrubs the entire aggregate.

+

NOTE: This parameter is only applicable when the `-plex` parameter is used.

#### **| -node {<nodename>|local} - Node }**

This parameter specifies the name of the node associated with the aggregate to be scrubbed. The value `local` specifies the current node.

#### **-action {start|stop|resume|suspend|status} - Action**

This parameter specifies the action to be taken. The possible actions are:

- `start` - Starts a scrub.
- `stop` - Permanently stops a scrub. A stopped scrub cannot be resumed.
- `resume` - Resumes a suspended parity scrub.
- `suspend` - Suspends a parity scrub.
- `status` - Displays the current status of a scrub.

### **Examples**

The following example starts a scrub on a RAID group named `rg0` of plex named `plex0` on an aggregate named `aggr0`:

```
cluster1::> storage aggregate scrub -aggregate aggr0 -raidgroup rg0 -plex plex0 -action start
```

The following example queries the status of a scrub:

```
cluster1::> storage aggregate scrub -aggregate aggr0 -raidgroup rg0 -plex plex0 -action status

Raid Group:/aggr0/plex0/rg0, Is Suspended:false, Last Scrub:Sun Nov 13
01:30:55 2011
, Percentage Completed:7%
```

The following example starts a scrub on `plex1` of an aggregate named `aggr1`:

```
cluster1::> storage aggregate scrub -aggregate aggr1 -plex plex1 -action start
```

The following example queries the status of plex1 of an aggregate named aggr1:

```
cluster1::> storage aggregate scrub -aggregate aggr1 -plex plex1 -action status
```

```
Raid Group:/aggr1/plex1/rg0, Is Suspended:false, Last Scrub:Sun Nov 13
02:07:29
2011
, Percentage Completed:1%
```

The following example queries the status of all the plexes for an aggregate named aggr1:

```
cluster1::> storage aggregate scrub -aggregate aggr1 -action status

Raid Group:/aggr1/plex0/rg0, Is Suspended:false, Last Scrub:Sun Nov 13
01:58:06
2011

Raid Group:/aggr1/plex1/rg0, Is Suspended:false, Last Scrub:Sun Nov 13
02:07:29
2011
, Percentage Completed:4%
```

## **storage aggregate show-auto-provision-progress**

**Display aggregate auto provision status**

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `storage aggregate show-auto-provision-progress` command displays the status of the most recent auto provision operation. The command output displays the progress for all the aggregates included in the provisioning operation. The command displays the following information about each aggregate:

- Aggregate
- Current Usable Size
- Target Usable Size
- Provisioning Progress

## Examples

The following example displays the information about all aggregates that are provisioned during the aggregate auto provision operation:

```
cluster1::> aggr auto-provision
Node           New Data Aggregate           Usable Size
-----
node1          node1_SSD_1                 23.65GB
node2          node2_SSD_1                 23.65GB
-----
Total:        2  new data aggregates      47.30GB

Do you want to create recommended aggregates? {y|n}: y

Info: Aggregate auto provision has started. Use the "storage aggregate
      show-auto-provision-progress" command to track the progress.

cluster1::> storage aggregate show-auto-provision-progress
                  Current      Target
Aggregate        Usable Size  Usable Size Provisioning
Progress
-----
-----
node1_SSD_1      0B          23.65GB Creating
node2_SSD_1      0B          23.65GB Creating

cluster1::> storage aggregate show-auto-provision-progress
                  Current      Target
Aggregate        Usable Size  Usable Size Provisioning
Progress
-----
-----
node1_SSD_1      23.65GB    23.65GB Completed
node2_SSD_1      23.65GB    23.65GB Completed
```

## storage aggregate show-cumulated-efficiency

Display cumulated storage efficiency details

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The *storage aggregate show-cumulated-efficiency* command displays information about the cumulated storage efficiency of all the aggregates. The storage efficiency is displayed at four different levels:

- Total
- Aggregate
- Volume
- Snapshot and FlexClone volume

## Parameters

{ [-fields <fieldname>, ...]

If you specify the -fields <fieldname>, ... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-details ]

Use this parameter to show additional Storage Efficiency Ratios.

| [-all-details ] (privilege: advanced)

Use this parameter to show additional Storage Efficiency Ratios and size values.

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-aggregates <aggregate name>, ...] - List of Aggregates to cumulate Storage Efficiency ratio**

If this parameter is specified, the command calculates the cumulated storage efficiency of the specified list of aggregates.

**[-nodes {<nodename>|local}] - List of Aggregates to cumulate Storage Efficiency ratio**

If this parameter is specified, the command calculates the cumulated storage efficiency of aggregates that are located on the specified list of node.

**[-total-logical-used {<integer>[KB|MB|GB|TB|PB]}] - Logical Size Used by volumes, clones, Snapshot copies in the Aggregate (privilege: advanced)**

Displays the total logical size used in all the specified aggregates. This includes Volumes, Clones and Snapshots in all the specified aggregates. The logical size is computed based on physical usage and savings obtained in all the specified aggregates.

**[-total-physical-used {<integer>[KB|MB|GB|TB|PB]}] - Total Physical Used (privilege: advanced)**

Displays the physical size used by all the specified aggregates.

**[-total-storage-efficiency-ratio <text>] - Total Storage Efficiency Ratio**

Displays the total storage efficiency ratio of the aggregate.

**[-total-data-reduction-logical-used-wo-snapshots {<integer>[KB|MB|GB|TB|PB]}] - Total Data Reduction Logical Used Without Snapshots (privilege: advanced)**

Displays the total logical size used in all the specified aggregates excluding Snapshot copies.

**[-total-data-reduction-physical-used-wo-snapshots {<integer>[KB|MB|GB|TB|PB]}] - Total Data Reduction Physical Used Without Snapshots (privilege: advanced)**

Displays the total physical size used by all the specified aggregates aggregates excluding Snapshot copies.

**[-total-data-reduction-efficiency-ratio-wo-snapshots <text>] - Total Data Reduction Efficiency Ratio Without Snapshots**

Displays the total storage efficiency ratio obtained by Deduplication, Compression, Data Compaction, Pattern Detection and FlexClone data reduction technologies excluding snapshot copies on the specified aggregates.

**[-total-data-reduction-logical-used-wo-snapshots-flexclones {<integer>[KB|MB|GB|TB|PB]}] - Total Data Reduction Logical Used without snapshots and flexclones (privilege: advanced)**

Displays the total logical size used in all the specified aggregates excluding Snapshot copies and FlexClones.

**[-total-data-reduction-physical-used-wo-snapshots-flexclones {<integer>[KB|MB|GB|TB|PB]}] - Total Data Reduction Physical Used without snapshots and flexclones (privilege: advanced)**

Displays the total physical size used by all the specified aggregates aggregates excluding Snapshot copies and FlexClones.

**[-total-data-reduction-efficiency-ratio-wo-snapshots-flexclones <text>] - Total Data Reduction Efficiency Ratio without snapshots and flexclones**

Displays the total storage efficiency ratio obtained by Deduplication, Compression, Data Compaction, Pattern Detection data reduction technologies excluding snapshot copies on the specified aggregates.

**[-total-performance-tier-data-reduction-physical-used-wo-snapshots-flexclones {<integer>[KB|MB|GB|TB|PB]}] - Total Data Reduction Physical Used without snapshots and flexclones in the FabricPool Performance Tier**

Displays the total performance tier physical size used by all the specified aggregates aggregates excluding Snapshot copies and FlexClones.

**[-volume-logical-used {<integer>[KB|MB|GB|TB|PB]}] - Logical Space Used for All volumes (privilege: advanced)**

Displays the total logical size used by all the volumes in all the specified aggregates.

**[-volume-physical-used {<integer>[KB|MB|GB|TB|PB]}] - Physical Space Used for All volumes (privilege: advanced)**

Displays the total physical size used by all volumes in all the specified aggregates.

**[-volume-dedupe-zero-pattern-saved {<integer>[KB|MB|GB|TB|PB]}] - Space Saved by volume Deduplication and pattern detection (privilege: advanced)**

Displays the total disk space that is saved by deduplication, Zero pattern detection and FlexClone for files, LUNs or NVMe namespaces by all volumes in all the specified aggregates.

**[-volume-efficiency-saved-ratio <text>] - Volume Deduplication Savings ratio**

Displays the storage efficiency ratio for savings by deduplication and FlexClone for files, LUNs or NVMe namespaces by all volumes in all the specified aggregates.

**[-volume-compression-saved {<integer>[KB|MB|GB|TB|PB]}] - Space Saved by volume Compression (privilege: advanced)**

Displays the total disk space that is saved by compressing blocks by all volumes in all the specified aggregates.

**[-volume-compression-saved-ratio <text>] - Volume Compression Savings ratio**

Displays the storage efficiency ratio for savings by compressing blocks on all volumes in all the specified aggregates.

**[-volume-data-reduction-storage-efficiency-ratio <text>] - Volume Data Reduction SE Ratio**

Displays the storage efficiency ratio of all the volumes in all the specified aggregates.

**[-aggr-logical-used {<integer>[KB|MB|GB|TB|PB]}] - Logical Space Used by the Aggregate (privilege: advanced)**

Displays the logical size used by all the specified aggregates.

**[-aggr-physical-used {<integer>[KB|MB|GB|TB|PB]}] - Physical Space Used by the Aggregate (privilege: advanced)**

Displays the physical size used by all the specified aggregates.

**[-aggr-data-reduction-storage-efficiency-ratio <text>] - Aggregate Data Reduction SE Ratio**

Displays the storage efficiency ratio of the aggregate.

**[-snapshot-logical-used {<integer>[KB|MB|GB|TB|PB]}] - Logical Size Used by Snapshot copies (privilege: advanced)**

Displays the logical size used by all Volume Snapshots residing in all the specified aggregates.

**[-snapshot-physical-used {<integer>[KB|MB|GB|TB|PB]}] - Physical Size Used by Snapshot copies (privilege: advanced)**

Displays the physical size used by all Volume Snapshots residing in all the specified aggregates.

**[-snapshot-volume-data-reduction-storage-efficiency-ratio <text>] - Snapshot volume Data Reduction Ratio**

Displays the Snapshot volume storage efficiency ratio of the aggregate.

**[-flexclone-volume-logical-used {<integer>[KB|MB|GB|TB|PB]}] - Logical Size Used by FlexClone volumes (privilege: advanced)**

Displays the logical size used by all FlexClone volumes residing in all the specified aggregates.

**[-flexclone-volume-physical-used {<integer>[KB|MB|GB|TB|PB]}] - Physical Sized Used by FlexClone volumes (privilege: advanced)**

Displays the physical size used by all FlexClone volumes in all the specified aggregates.

**[-flexclone-volume-data-reduction-storage-efficiency-ratio <text>] - FlexClone volume Data Reduction Ratio**

Displays the FlexClone volume storage efficiency ratio of the aggregate.

**[-snapshot-flexclone-volume-data-reduction-storage-efficiency-ratio <text>] - Snapshot And FlexClone volume Data Reduction SE Ratio**

Displays the Snapshot and FlexClone volume storage efficiency ratio of the aggregate.

**[-number-of-offline-volumes <integer>] - Number of volumes Offline**

Displays the number of volumes that are offline in all the specified aggregates.

**[-number-of-sis-disabled-volumes <integer>] - Number of SIS Disabled volumes**

Displays the number of volumes on which volume efficiency is disabled in all the specified aggregates.

**[-number-of-sis-change-log-disabled-volumes <integer>] - Number of SIS Change Log Disabled volumes (privilege: advanced)**

Displays the number of volumes on which efficiency change log is disabled in all the specified aggregates. The scheduled background Deduplication will be disabled on these volumes.

**[-number-of-skipped-aggregates <integer>] - Number of Skipped Aggregates**

Displays the number of aggregates that were skipped for calculating the cumulated storage efficiency.

**[-skipped-aggregates <aggregate name>, ...] - List of Aggregates skipped**

Displays the list of aggregates that were skipped for calculating the cumulated storage efficiency.

## Examples

The following example displays information about all aggregates that are owned by nodes in the local cluster:

```
cluster::> aggr show-cumulated-efficiency
Total Data Reduction Efficiency Ratio: 5.00:1
Total Storage Efficiency Ratio: 6.97:1

cluster::> aggr show-cumulated-efficiency -details
          Total Data Reduction Ratio: 8.44:1
          Total Storage Efficiency Ratio: 6.97:1
Aggregate level Storage Efficiency
(Aggregate Deduplication and Data Compaction): 1.00:1
          Volume Deduplication Efficiency: 1.12:1
          Compression Efficiency: 5.73:1
Snapshot Volume Storage Efficiency: 1.00:1
          FlexClone Volume Storage Efficiency: 1.00:1
          Number of Offline Volumes: 0
          Number of Skipped Aggregates: 0
          Number of Efficiency Disabled Volumes: 0

cluster::> aggr show-cumulated-efficiency -aggregates aggr1
Total Data Reduction Efficiency Ratio: 6.00:1
Total Storage Efficiency Ratio: 7.41:1
```

## storage aggregate show-efficiency

Display aggregate storage efficiency details

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The storage aggregate show-efficiency command displays information about the storage efficiency of all the aggregates. The storage efficiency is displayed at four different levels:

- Total
- Aggregate
- Volume
- Snapshot and FlexClone volume

## Parameters

{ [-fields <fieldname>,...]

If you specify the -fields <fieldname>, ... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-details ]

Use this parameter to show additional Storage Efficiency Ratios.

| [-advanced ] (privilege: advanced)

Use this parameter to show additional Storage Efficiency Ratios and size values.

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-aggregate <aggregate name>] - Name of the Aggregate**

Displays the aggregate name. If this parameter is specified, the command displays detailed information about the storage efficiency of the specified aggregate.

**[-node {<nodename>|local}] - Node where Aggregate Resides**

Displays the node which owns the aggregate. If this parameter is specified, the command displays storage efficiency information only about the aggregates that are located on the specified node.

**[-total-logical-used {<integer>[KB|MB|GB|TB|PB]}] - Logical Size Used by Volumes, Clones, Snapshot Copies in the Aggregate (privilege: advanced)**

Displays the logical size used in the aggregate. This includes Volumes, Clones and Snapshots in the aggregate. The logical size is computed based on physical usage and savings obtained in the aggregate.

**[-total-physical-used {<integer>[KB|MB|GB|TB|PB]}] - Total Physical Used (privilege: advanced)**

Displays the physical size used by the aggregate.

**[-total-storage-efficiency-ratio <text>] - Total Storage Efficiency Ratio**

Displays the total storage efficiency ratio of the aggregate.

**[-total-data-reduction-logical-used-wo-snapshots {<integer>[KB|MB|GB|TB|PB]}] - Total Data Reduction Logical Used Without Snapshots (privilege: advanced)**

Displays the logical size used in the aggregate excluding Snapshot copies.

**[-total-data-reduction-physical-used-wo-snapshots {<integer>[KB|MB|GB|TB|PB]} ] - Total Data Reduction Physical Used Without Snapshots (privilege: advanced)**

Displays the physical size used by the aggregate excluding Snapshot copies.

**[-total-data-reduction-efficiency-ratio-wo-snapshots <text>] - Total Data Reduction Efficiency Ratio Without Snapshots**

Displays the total storage efficiency ratio obtained by Deduplication, Compression, Data Compaction, Pattern Detection and FlexClone data reduction technologies excluding snapshot copies on the aggregate.

**[-total-data-reduction-logical-used-wo-snapshots-flexclones {<integer>[KB|MB|GB|TB|PB]} ] - Total Data Reduction Logical Used without snapshots and flexclones (privilege: advanced)**

Displays the logical size used in the aggregate excluding Snapshot copies and FlexClones.

**[-total-data-reduction-physical-used-wo-snapshots-flexclones {<integer>[KB|MB|GB|TB|PB]} ] - Total Data Reduction Physical Used without snapshots and flexclones (privilege: advanced)**

Displays the physical size used by the aggregate excluding Snapshot copies and FlexClones.

**[-total-data-reduction-efficiency-ratio-wo-snapshots-flexclones <text>] - Total Data Reduction Efficiency Ratio without snapshots and flexclones**

Displays the total storage efficiency ratio obtained by Deduplication, Compression, Data Compaction, Pattern Detection data reduction technologies excluding snapshot copies and flexclones on the aggregate.

**[-volume-logical-used {<integer>[KB|MB|GB|TB|PB]} ] - Logical Space Used for All Volumes**

Displays the logical size used by all the volumes in the aggregate.

**[-volume-physical-used {<integer>[KB|MB|GB|TB|PB]} ] - Physical Space Used for All Volumes**

Displays the physical size used by all volumes in the aggregate.

**[-volume-efficiency-saved {<integer>[KB|MB|GB|TB|PB]} ] - Space Saved by Volume Deduplication (privilege: advanced)**

Displays the total disk space that is saved by deduplication and FlexClone for files, LUNs or NVMe namespaces by all volumes in the aggregate.

**[-volume-dedupe-zero-pattern-saved {<integer>[KB|MB|GB|TB|PB]} ] - Space Saved by Volume Deduplication and pattern detection (privilege: advanced)**

Displays the total disk space that is saved by deduplication, Zero pattern detection and FlexClone for files, LUNs or NVMe namespaces by all volumes in the aggregate.

**[-volume-efficiency-saved-ratio <text>] - Volume Deduplication Savings ratio**

Displays the storage efficiency ratio for savings by deduplication and FlexClone for files, LUNs or NVMe namespaces by all volumes in the aggregate.

**[-volume-compression-saved {<integer>[KB|MB|GB|TB|PB]} ] - Space Saved by Volume Compression (privilege: advanced)**

Displays the total disk space that is saved by compressing blocks by all volumes in the aggregate.

**[-volume-compression-saved-ratio <text>] - Volume Compression Savings ratio**

Displays the storage efficiency ratio for savings by compressing blocks on all volumes in the aggregate.

**[-volume-vbn-zero-saved {<integer>[KB|MB|GB|TB|PB]} ] - Space Saved by Inline Zero Pattern Detection**

Displays the total disk space that is saved by inline zero pattern detection by all the volumes in the aggregate.

**[-volume-data-reduction-storage-efficiency-ratio <text>] - Volume Data Reduction SE Ratio**

Displays the storage efficiency ratio of all the volumes in the aggregate.

**[-aggr-logical-used {<integer>[KB|MB|GB|TB|PB]} ] - Logical Space Used by the Aggregate (privilege: advanced)**

Displays the logical size used by the aggregate.

**[-aggr-physical-used {<integer>[KB|MB|GB|TB|PB]} ] - Physical Space Used by the Aggregate (privilege: advanced)**

Displays the physical size used by the aggregate.

**[-aggr-compaction-saved {<integer>[KB|MB|GB|TB|PB]} ] - Space Saved by Aggregate Data Reduction (privilege: advanced)**

Displays the total disk space that is saved by data compaction, cross volume sharing at the aggregate level.

**[-aggr-data-reduction-storage-efficiency-ratio <text>] - Aggregate Data Reduction SE Ratio (privilege: advanced)**

Displays the storage efficiency ratio of the aggregate.

**[-snapshot-logical-used {<integer>[KB|MB|GB|TB|PB]} ] - Logical Size Used by Snapshot Copies (privilege: advanced)**

Displays the logical size used by all Volume Snapshots residing in the aggregate.

**[-snapshot-physical-used {<integer>[KB|MB|GB|TB|PB]} ] - Physical Size Used by Snapshot Copies (privilege: advanced)**

Displays the physical size used by all Volume Snapshots residing in the aggregate.

**[-snapshot-volume-data-reduction-storage-efficiency-ratio <text>] - Snapshot Volume Data Reduction Ratio**

Displays the Snapshot volume storage efficiency ratio of the aggregate.

**[-flexclone-volume-logical-used {<integer>[KB|MB|GB|TB|PB]} ] - Logical Size Used by FlexClone Volumes (privilege: advanced)**

Displays the logical size used by all FlexClone volumes residing in the aggregate.

**[-flexclone-volume-physical-used {<integer>[KB|MB|GB|TB|PB]} ] - Physical Sized Used by FlexClone Volumes (privilege: advanced)**

Displays the physical size used by all FlexClone volumes in the aggregate.

**[-flexclone-volume-data-reduction-storage-efficiency-ratio <text>] - FlexClone Volume Data Reduction Ratio**

Displays the FlexClone volume storage efficiency ratio of the aggregate.

**`[-snapshot-flexclone-volume-data-reduction-storage-efficiency-ratio <text>]` - Snapshot And FlexClone Volume Data Reduction SE Ratio**

Displays the Snapshot and FlexClone volume storage efficiency ratio of the aggregate.

**`[-number-of-offline-volumes <integer>]` - Number of Volumes Offline**

Displays the number of volumes that are offline in the aggregate.

**`[-number-of-sis-disabled-volumes <integer>]` - Number of SIS Disabled Volumes**

Displays the number of volumes on which volume efficiency is disabled in the aggregate.

**`[-number-of-sis-change-log-disabled-volumes <integer>]` - Number of SIS Change Log Disabled Volumes (privilege: advanced)**

Displays the number of volumes on which efficiency change log is disabled in the aggregate. The scheduled background Deduplication will be disabled on these volumes.

## Examples

The following example displays information about all aggregates that are owned by nodes in the local cluster:

```
cluster::*> aggr show-efficiency

Aggregate: aggr1
  Node: node1

  Total Data Reduction Efficiency Ratio: 3.29:1
  Total Storage Efficiency Ratio: 4.29:1

Aggregate: aggr2
  Node: node1

  Total Data Reduction Efficiency Ratio: 4.50:1
  Total Storage Efficiency Ratio: 5.49:1

cluster::*> aggr show-efficiency -details

Aggregate: aggr1
  Node: node1

  Total Data Reduction Ratio: 2.39:1
  Total Storage Efficiency Ratio: 4.29:1

  Aggregate level Storage Efficiency
  (Aggregate Deduplication and Data Compaction): 1.00:1
  Volume Deduplication Efficiency: 5.03:1
  Compression Efficiency: 1.00:1

  Snapshot Volume Storage Efficiency: 8.81:1
  FlexClone Volume Storage Efficiency: 1.00:1
  Number of Efficiency Disabled Volumes: 1

Aggregate: aggr2
  Node: node1

  Total Data Reduction Ratio: 2.39:1
  Total Storage Efficiency Ratio: 4.29:1

  Aggregate level Storage Efficiency
  (Aggregate Deduplication and Data Compaction): 1.00:1
  Volume Deduplication Efficiency: 5.03:1
  Compression Efficiency: 1.00:1

  Snapshot Volume Storage Efficiency: 8.81:1
  FlexClone Volume Storage Efficiency: 1.00:1
  Number of Efficiency Disabled Volumes: 1
```

## storage aggregate show-resync-status

Display aggregate resynchronization status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The storage aggregate show-resync-status command displays resync status information for each plex. The command output depends on the parameter or parameters specified with the command. If no parameters are specified, the command displays the following information about all aggregates:

- Aggregate Name
- Resyncing Plex Name
- Resyncing Percentage

### Parameters

{ [-fields <fieldname>, ...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-aggregate <aggregate name>] - Aggregate**

This parameter specifies the name of the aggregate.

**[-plex <text>] - Plex Name**

This parameter specifies the name of the plex.

**[-status <text>] - Status**

Displays plex status. Possible values are:

- *normal*
- *failed*
- *empty*
- *invalid*
- *uninitialized*
- *failed assimilation*
- *limbo*
- *active*
- *inactive*
- *resyncing*

These values may appear by themselves or in combination separated by commas; for example, "*normal*

,active".

#### **[-is-online {true|false}] - Is Online**

Indicates whether the plex is online.

#### **[-in-progress {true|false}] - Resync is in Progress**

Indicates whether the plex is currently resyncing.

#### **[-resyncing-percent <percent>] - Resyncing Percentage**

Displays the resynchronization completion percentage if the plex is currently being resynced, '-' otherwise.

#### **[-resync-level <integer>] - Resync Level**

Displays the resync level if the plex is currently being resynced, '-' otherwise.

#### **[-pool <integer>] - Pool**

The pool number to which the majority of disks in the plex belong.

## **Examples**

The following example displays resynchronization status for all the aggregates:

```
cluster1::> storage aggregate show-resync-status
                           Complete
Aggregate Resyncing Plex      Percentage
----- -----
aggr0    plex0               -
aggr1    plex0               -
aggr1    plex1               10.00
aggr2    plex0               -
aggr2    plex2               -
5 entries were displayed.
```

## **storage aggregate show-scrub-status**

Display aggregate scrubbing status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## **Description**

The *storage aggregate show-scrub-status* command displays the following information about the scrub status of aggregates:

- Aggregate name
- RAID groups
- Whether the scrub is suspended
- Percentage of the scrub that is completed

- Last scrub time of the aggregate

## Parameters

{ [-fields <fieldname>,...]

If you specify the -fields <fieldname>,... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-aggregate <aggregate name>] - Aggregate**

If this parameter is specified, the command displays detailed scrub-status information about the specified aggregate.

**[-raidgroup <text>] - RAID Group**

If this parameter is specified, the command displays information only about the aggregate that contains the specified RAID group.

**[-node {<nodename>|local}] - Node**

If this parameter is specified, the command displays information only about the aggregates on the specified node. The value *local* specifies the current node.

**[-suspended {true|false}] - Is Suspended**

If this parameter is specified, the command displays information only about the aggregates that have the specified scrub-suspension state (true or false).

**[-complete-percentage <percent>] - Percentage Completed**

If this parameter is specified, the command displays information only about the aggregates whose scrubs have the specified completed percentage.

**[-last-scrub-time <MM/DD/YYYY HH:MM:SS>] - Last Scrub Time**

If this parameter is specified, the command displays information only about the aggregates that have the specified last-scrub time, in the format *MM/DD/YYYY HH:MM:SS* .

## Examples

The following example displays scrub-status information for all the aggregates:

```
cluster1::> storage aggregate show-scrub-status
Aggregate RAID Groups          Suspended  Percentage Last Scrub Time
-----  -----  -----  -----  -----  -----
aggr0    /aggr0/plex0/rg0      true      0%  3/31/2011  21:23:02
aggr1    /aggr1/plex0/rg1      true      45% 3/30/2011  01:05:00
aggr2    /aggr2/plex0/rg0      true      33% 3/30/2011  23:43:34
aggr3    /aggr3/plex0/rg1      true      79% 3/29/2011  00:34:36
4 entries were displayed.
```

The following example displays detailed information about the aggregate named aggr1:

```
cluster1::> storage aggregate show-scrub-status -instance -aggregate aggr1
    Aggregate: aggr1
    RAID Group: /aggr1/plex0/rg0
    Is Suspended: false
    Percentage Completed: 2%
    Last Scrub Time: 3/31/2011 22:02:50
```

## storage aggregate show-space

Display details of space utilization within an aggregate.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The *storage aggregate show-space* command displays information about space utilization within aggregates and any attached external capacity tier. The command output breaks down space usage in the specified aggregate by feature. If no parameters are specified, the command displays this information about all aggregates. Note that used percentage for an external capacity tier will be non-zero only if a size limit was set for that aggregate's attached tier.

### Parameters

{ [-fields <fieldname>,...]

If you specify the *-fields <fieldname>,...* parameter, the command output also includes the specified field or fields. You can use '*-fields ?*' to display the fields to specify.

| [-instance ] }

If you specify the *-instance* parameter, the command displays detailed information about all fields.

[-aggregate-name <aggregate name>] - Aggregate

If this parameter is specified, the command displays information only about the specified aggregates.

[-bin-num <integer>] - Bin Number

If this parameter is specified, the command displays information only about the aggregates whose bin number for the storage tier matches the specified value. Typically, bin 0 refers to the performance tier or active file system and bin numbers greater than 0 refer to the external capacity tiers attached to the aggregate.

[-tier-name <text>] - Tier Name For Show Command

If this parameter is specified, the command displays information only about the aggregates whose attached storage tier name matches the specified value.

[-aggregate <aggregate name>] - Aggregate Display Name

If this parameter is specified, the command displays information only about space used in the specified aggregate or aggregates.

**[-aggregate-uuid <UUID>] - Uuid of the Aggregate**

If this parameter is specified, the command displays information only about the aggregates whose UUID matches the specified value.

**[-volume-footprints {<integer>[KB|MB|GB|TB|PB]}] - Volume Footprints**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified amount of space in use by volume footprints. A volume's footprint is the overall amount of space that a volume occupies in the aggregate, including the volume metadata and data.

**[-volume-footprints-percent <percent\_no\_limit>] - Volume Footprints Percent**

If this parameter is specified, the command displays information only about the aggregate or aggregates whose volume footprints occupy the specified percentage of space.

**[-snap-size-total {<integer>[KB|MB|GB|TB|PB]}] - Total Space for Snapshot Copies in Bytes**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified amount of space in use by aggregate Snapshot copies. This field includes the space that is reserved for Snapshot copies and is not available to volumes or aggregate data and metadata. It is set to 0 by default.

**[-percent-snapshot-space <percent>] - Space Reserved for Snapshot Copies**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified percentage of space in use by aggregate Snapshot copies.

**[-aggregate-metadata {<integer>[KB|MB|GB|TB|PB]}] - Aggregate Metadata**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified amount of space in use by aggregate metadata.

**[-aggregate-metadata-percent <percent\_no\_limit>] - Aggregate Metadata Percent**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified percentage of space in use by aggregate metadata.

**[-used-including-snapshot-reserve {<integer>[KB|MB|GB|TB|PB]}] - Total Used**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified amount of space in use in the aggregate.

It is important to note that this parameter treats the entire Snapshot reserve as used space since it is not available for volumes.

**[-used-including-snapshot-reserve-percent <percent\_no\_limit>] - Total Used Percent**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified percentage of space in use in the aggregate and its Snapshot reserve.

**[-aggregate-size {<integer>[KB|MB|GB|TB|PB]}] - Size**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified size.

**[-snapshot-reserve-unusable {<integer>[KB|MB|GB|TB|PB]}] - Snapshot Reserve Unusable**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified amount of space reserved but unusable in the volume.

Snapshot reserve can be diminished under certain conditions to accomodate volume metadata. Creating

space in the aggregate will make this space available.

#### **[-snapshot-reserve-unusable-percent <percent\_no\_limit>] - Snapshot Reserve Unusable Percent**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified percentage of space reserved but unusable.

#### **[-physical-used {<integer>[KB|MB|GB|TB|PB]}] - Total Physical Used Size**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified amount of physical space in use by the aggregate.

This differs from *total-used* space by the space that is guaranteed for future writes. The value includes blocks in use by Snapshot copies.

#### **[-physical-used-percent <percent\_no\_limit>] - Physical Used Percentage**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified percentage of physical space in use in the aggregates.

#### **[-performance-tier-inactive-user-data {<integer>[KB|MB|GB|TB|PB]}] - Performance Tier Inactive User Data**

If this parameter is specified, the command displays information only about the aggregates whose amount of inactive user data in the performance tier matches the specified value. The inactive user data can be tiered out to a capacity tier if the aggregate is a FabricPool.

#### **[-performance-tier-inactive-user-data-percent <percent>] - Performance Tier Inactive User Data Percent**

If this parameter is specified, the command displays information only about the aggregates whose percentage of inactive user data in the performance tier matches the specified value.

#### **[-cross-volume-dedupe-metadata {<integer>[KB|MB|GB|TB|PB]}] - Aggregate Dedupe Metadata**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified amount of space in use by cross volume deduplication metadata.

#### **[-cross-volume-dedupe-metadata-percent <percent\_no\_limit>] - Aggregate Dedupe Metadata Percent**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified percentage of space in use by cross volume deduplication metadata.

#### **[-cross-volume-dedupe-temp-metadata {<integer>[KB|MB|GB|TB|PB]}] - Aggregate Dedupe Temporary Metadata**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified amount of space in use by cross volume deduplication temporary metadata.

#### **[-cross-volume-dedupe-temp-metadata-percent <percent\_no\_limit>] - Aggregate Dedupe Temporary Metadata Percent**

If this parameter is specified, the command displays information only about the aggregate or aggregates that have the specified percentage of space in use by cross volume deduplication temporary metadata.

#### **[-total-provisioned-space {<integer>[KB|MB|GB|TB|PB]}] - Total Space Provisioned inside Aggregate**

If this parameter is specified, the command displays information about the total provisioned space across all

the volumes in the aggr.

**[-total-provisioned-space-percent <percent\_no\_limit>] - Percentage Space Provisioned inside Aggregate**

If this parameter is specified, the command displays information about the percentage of total provisioned space across all the volumes against aggr's size.

**[-object-store-physical-used {<integer>[KB|MB|GB|TB|PB]}] - Total Physical Used Size**

If this parameter is specified, the command displays information only about the aggregates whose physical space use in the attached object store matches the specified value.

**[-object-store-physical-used-percent <percent\_no\_limit>] - Physical Used Percentage**

If this parameter is specified, the command displays information only about aggregates whose physical space in use in the attached object store as a percentage of the license limit matches the specified value.

**[-object-store-referenced-capacity {<integer>[KB|MB|GB|TB|PB]}] - Total Object Store Logical Referenced Capacity**

If this parameter is specified, the command displays information only about the aggregates whose logical reference capacity space in use in the attached object store matches the specified value.

**[-object-store-referenced-capacity-percent <percent\_no\_limit>] - Object Store Logical Referenced Capacity Percentage**

If this parameter is specified, the command displays information only about aggregates whose logical reference capacity space in use in the attached object store as a percentage of the license limit matches the specified value.

**[-object-store-metadata {<integer>[KB|MB|GB|TB|PB]}] - (DEPRECATED)-Object Store Metadata**

This parameter is deprecated in Data ONTAP 9.10.1 and later. If this parameter is specified, the command displays information only about the aggregates whose metadata space in use in the attached object store matches the specified value.

**[-object-store-metadata-percent <percent\_no\_limit>] - (DEPRECATED)-Object Store Metadata Percent**

This parameter is deprecated in Data ONTAP 9.10.1 and later. If this parameter is specified, the command displays information only about aggregates whose metadata space in use in the attached object store as a percentage of the license limit matches the specified value.

**[-object-store-unreclaimed-space {<integer>[KB|MB|GB|TB|PB]}] - (DEPRECATED)-Total Unreclaimed Space**

This parameter is deprecated in Data ONTAP 9.10.1 and later. If this parameter is specified, the command displays information only about the aggregates whose unreclaimed space in use in the attached object store matches the specified value.

**[-object-store-unreclaimed-space-percent <percent\_no\_limit>] - (DEPRECATED)-Object Store Unreclaimed Space Percentage**

This parameter is deprecated in Data ONTAP 9.10.1 and later. If this parameter is specified, the command displays information only about aggregates whose unreclaimed space in use in the attached object store as a percentage of the license limit matches the specified value.

**[-object-store-size {<integer>[KB|MB|GB|TB|PB]}] - Object Store Size**

If this parameter is specified, the command displays information only about the aggregates whose attached object store size limit matches the specified value.

**[-object-store-sis-space-saved {<integer>[KB|MB|GB|TB|PB]}] - Object Store Space Saved by Storage Efficiency**

If this parameter is specified, the command displays information only about the aggregates whose amount of space saved by storage efficiency matches the specified value.

**[-object-store-sis-space-saved-percent <percent\_no\_limit>] - Object Store Space Saved by Storage Efficiency Percentage**

If this parameter is specified, the command displays information only about the aggregates whose percentage of space saved by storage efficiency matches the specified value.

**[-object-store-logical-used {<integer>[KB|MB|GB|TB|PB]}] - Total Logical Used Size**

If this parameter is specified, the command displays information only about the aggregates whose logical space use in the attached object store matches the specified value.

**[-object-store-logical-used-percent <percent\_no\_limit>] - Logical Used Percentage**

If this parameter is specified, the command displays information only about aggregates whose logical space in use in the attached object store as a percentage of the license limit matches the specified value.

**[-object-store-logical-unreferenced-capacity {<integer>[KB|MB|GB|TB|PB]}] - Logical Unreferenced Capacity**

If this parameter is specified, the command displays information only about the aggregates whose logical unreferenced capacity in use in the attached object store matches the specified value.

**[-object-store-logical-unreferenced-capacity-percent <percent\_no\_limit>] - Logical Unreferenced Percentage**

This parameter is deprecated in Data ONTAP 9.10.1 and later. If this parameter is specified, the command displays information only about aggregates whose logical unreferenced capacity in use in the attached object store as a percentage of the license limit matches the specified value.

## Examples

The following example displays information about all aggregates:

```

cluster1::> storage aggregate show-space
Aggregate : aggr0
Feature                                Used      Used%
-----                                -----
Volume Footprints                      5.75GB    91%
Aggregate Metadata                     380KB     0%
Snapshot Reserve                      325.3MB   5%
Total Used                            6.07GB    96%
Total Physical Used                   221.9MB   3%
Aggregate : aggr1
Feature                                Used      Used%
-----                                -----
Volume Footprints                      2.03GB    33%
Aggregate Metadata                     304KB     0%
Total Used                            2.03GB    33%
Total Physical Used                   2.23MB    0%

```

2 entries were displayed.

The following example displays information about all the aggregates in a system including the ones that have an object store attached to them.

```

cluster-1::> storage aggregate show-space
Aggregate : aggr0
Feature                                Used      Used%
-----                                -----      -----
Volume Footprints                      2.87GB    90%
Aggregate Metadata                     328KB     0%
Snapshot Reserve                      162.6MB   5%
Total Used                            3.03GB    95%
Total Physical Used                   2.08GB    65%
Aggregate : aggr1
Performance Tier
Feature                                Used      Used%
-----                                -----      -----
Volume Footprints                      1.25GB    13%
Aggregate Metadata                     540KB     0%
Snapshot Reserve                      0B        0%
Total Used                            1.25GB    13%
Total Physical Used                   1.23GB    13%
Aggregate : aggr1
Object Store: my-store
Feature                                Used      Used%
-----                                -----      -----
Referenced Capacity                    811.2MB   0%
Metadata                             0B        0%
Unreclaimed Space                    0B        0%
Space Saved by Storage Efficiency   0B        0%
Total Physical Used                  811.2MB   0%

```

## storage aggregate show-space-disks

### Display spare disks

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The command `storage aggregate show-space-disks` displays information about spare disks. The command output depends on the parameter or parameters specified with the command. If no parameters are specified, the command displays information about all spare disks in the cluster.

#### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

## **[-partition-info ] (privilege: advanced)**

Displays the following information about root-data and root-data1-data2 partitioned spares.

- Disk
- Type
- Class
- RPM
- Checksum
- Local Data Usable
- Local Data1 Usable
- Local Data2 Usable
- Local Root Usable
- Physical Size
- Status

## **[-instance ] }**

If this parameter is specified, the command displays detailed information about each spare disk.

### **[-original-owner <text>] - Original Owner**

Selects the spare disks that match this parameter value.

### **[-disk <disk path name>] - Disk Name**

Selects the spare disks that match this parameter value.

### **[-checksum-style {advanced\_zoned | block | none}] - Checksum Style**

Selects the spare disks that match this parameter value. Possible values are:

- block — Supports block checksum
- advanced\_zoned — Supports advanced zone checksum
- none — No checksum support

### **[-disk-type {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}] - Disk Type**

Selects the spare disks that match this parameter value.

### **[-effective-disk-type {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}] - Effective Disk Type**

Selects the spare disks that match this parameter value.

Hard disk drives with the same effective-disk-type value may be mixed together in the same aggregate depending upon the system's *raid.mix.hdd.disktype.capacity* and *raid.mix.hdd.disktype.performance* option settings. Solid state drives with the same effective-disk-type value may be mixed together in the same aggregate depending upon the system's *raid.mix.disktype.solid\_state* option setting.

**[-standard-disk-type {SATA | FC | NL-SAS | LUN | SAS | SCSI | SSD | VM-DISK | NVMe-SSD | SSD-CAP | SSD-ZNS | VM-LUN | VM-LUN-SSDS}]** - Standard Disk Type

Selects the spare disks that match this parameter value.

**[-disk-class {capacity | performance | archive | solid-state | array | virtual}]** - Disk Class

Selects the spare disks that match this parameter value. Possible values are:

- capacity — Capacity-oriented, near-line disk types. Includes disk types FSAS, BSAS and ATA.
- performance — Performance-oriented, enterprise class disk types. Includes disk types FCAL and SAS.
- archive — Archive class SATA disks in multi-disk carrier storage shelves. Includes disk type MSATA.
- solid-state — Solid-state drives. Includes disk type SSD, SSD-CAP and SSD-NVM.
- array — Logical storage devices backed by storage arrays and used by Data ONTAP as disks. Includes disk type LUN.
- virtual — Virtual disks that are formatted and managed by the hypervisor. Includes disk type VMDISK.

Disks with the same disk-class value are compatible for use in the same aggregate.

**[-disk-rpm <integer>]** - Disk RPM

Selects the spare disks that match this parameter value.

**[-effective-disk-rpm <integer>]** - Effective Disk RPM

Selects the spare disks that match this parameter value.

Hard disk drives with the same effective-disk-rpm value may be mixed together in the same aggregate depending upon the system's *raid.mix.hdd.rpm.capacity* and *raid.mix.hdd.rpm.performance* option settings.

**[-syncmirror-pool <text>]** - Pool Number

Selects the spare disks that match this parameter value.

**[-owner-name {<nodename>|local}]** - Current Owner

Selects the spare disks that match this parameter value.

**[-home-owner-name {<nodename>|local}]** - Home Owner

Selects the spare disks that match this parameter value.

**[-dr-owner-name {<nodename>|local}]** - DR Home Owner

Selects the spare disks that match this parameter value.

**[-usable-size-blks <integer>]** - Disk Usable Size in 4K blocks

Selects the spare disks that match this parameter value.

**[-local-usable-data-size-blks <integer>]** - Local Node Data Usable Size in 4K blocks

Selects the spare disks that match this parameter value.

Disks that have two partitions can be used for one root aggregate and one data aggregate.

Disks that have three partitions can be used for one root aggregate and one or two data aggregates.

This value describes the data partition size (of root-data partitioned disk) or the combined data1 + data2 partition size (of root-data1-data2 partitioned disk) in 4KB blocks.

**[-local-usable-root-size-blks <integer>] - Local Node Root Usable Size in 4K blocks**

Selects the spare disks that match this parameter value.

Disks that have two partitions can be used for one root aggregate and one data aggregate.

Disks that have three partitions can be used for one root aggregate and one or two data aggregates.

This value describes the root partition size in 4KB blocks.

**[-usable-size {<integer>[KB|MB|GB|TB|PB]}] - Disk Usable Size**

Selects the spare disks that match this parameter value.

**[-total-size {<integer>[KB|MB|GB|TB|PB]}] - Total Size**

Selects the spare disks that match this parameter value.

**[-local-usable-data-size {<integer>[KB|MB|GB|TB|PB]}] - Local Node Data Usable Size**

Selects the spare disks that match this parameter value.

Disks that have two partitions can be used for one root aggregate and one data aggregate.

Disks that have three partitions can be used for one root aggregate and one or two data aggregates.

This value describes the data partition size (of root-data partitioned disk) or the combined data1 + data2 partition size (of root-data1-data2 partitioned disk) in auto-scaled units.

**[-local-usable-root-size {<integer>[KB|MB|GB|TB|PB]}] - Local Node Root Usable Size**

Selects the spare disks that match this parameter value.

Disks that have two partitions can be used for one root aggregate and one data aggregate.

Disks that have three partitions can be used for one root aggregate and one or two data aggregates.

This value describes the root partition size in auto-scaled units.

**[-is-disk-zeroed {true|false}] - Is Disk Zeroed?**

Selects the spare disks that match this parameter value.

When disks are zeroed, they can be provisioned directly into aggregates which avoids a lengthy zeroing process.

**[-is-disk-zeroing {true|false}] - Is Disk Zeroing?**

Selects the spare disks that match this parameter value.

**[-zeroing-percent <percent>] - Zeroing Percentage Completed**

Selects the spare disks that match this parameter value.

**[-is-sparecore {true|false}] - Sparecore Disk?**

Selects the spare disks that match this parameter value.

**[-sparecore-status <Spare core status>] - Sparecore Status**

Selects the spare disks that match this parameter value.

**[-sparecore-percent <percent>] - Sparecore Percentage Completed**

Selects the spare disks that match this parameter value.

**[-is-disk-shared {true|false}] - Is Disk Shared?**

Selects the spare disks that match this parameter value.

Shared disks have partitions that allow them to be used in multiple aggregates and between nodes in an HA pair. When set to *true*, this parameter selects shared disks in which the root partition and/or the data partition is a spare. When set to *false* only spare disks without partitions are displayed. When this parameter is not used, all spare disks are displayed.

**[-is-disk-offline {true|false}] - Is Disk Offline?**

Selects the spare disks that match this parameter value.

Disk offline events are typically temporary events which allow Data ONTAP to perform background error recovery activity.

**[-is-disk-sick {true|false}] - Is Disk Sick?**

Selects the spare disks that match this parameter value.

A sick disk triggers Rapid RAID Recovery to copy data to a spare drive. At the end of the process the sick disk is marked as *broken*.

**[-is-disk-left-behind {true|false}] - Is Disk Left Behind Spare?**

Selects the spare disks that match this parameter value.

Disk are left behind if they are not responding during a giveback or switchback event.

**[-local-usable-data1-size-blks <integer>] - Local Node Data1 Usable Size in 4K blocks  
(privilege: advanced)**

Selects the spare disks that match this parameter value.

Disk that have two partitions can be used for one root aggregate and one data aggregate.

Disk that have three partitions can be used for one root aggregate and one or two data aggregates.

This value describes the data1 partition size of a root-data1-data2 partitioned disk in 4KB blocks.

**[-local-usable-data2-size-blks <integer>] - Local Node Data2 Usable Size in 4K blocks  
(privilege: advanced)**

Selects the spare disks that match this parameter value.

Disk that have two partitions can be used for one root aggregate and one data aggregate.

Disk that have three partitions can be used for one root aggregate and one or two data aggregates.

This value describes the data2 partition size of a root-data1-data2 partitioned disk in 4KB blocks.

**`[-local-usable-data1-size {<integer>[KB|MB|GB|TB|PB]} ] - Local Node Data1 Usable Size`  
(privilege: advanced)**

Selects the spare disks that match this parameter value.

Disks that have two partitions can be used for one root aggregate and one data aggregate.

Disks that have three partitions can be used for one root aggregate and one or two data aggregates.

This value describes the data1 partition size of a root-data1-data2 partitioned disk in auto-scaled units.

**`[-local-usable-data2-size {<integer>[KB|MB|GB|TB|PB]} ] - Local Node Data2 Usable Size`  
(privilege: advanced)**

Selects the spare disks that match this parameter value.

Disks that have two partitions can be used for one root aggregate and one data aggregate.

Disks that have three partitions can be used for one root aggregate and one or two data aggregates.

This value describes the data2 partition size of a root-data1-data2 partitioned disk in auto-scaled units.

## Examples

Display spare disks owned by node *node-b* .

```
cluster1::> storage aggregate show-spare-disks -owner-name node-b
```

Original Owner: node-b

Pool0

Spare Pool

Usable Physical

Disk	Type	Class	RPM	Checksum	Size
Size	Status				
1.1.13	BSAS	capacity	7200	block	827.7GB
828.0GB	zeroed				
1.1.15	BSAS	capacity	7200	block	413.2GB
414.0GB	zeroed				

Original Owner: node-b

Pool0

Partitioned Spares

Disk	Type	Class	RPM	Checksum	Usable
Usable	Size	Status			
1.0.8	SAS	performance	10000	block	472.9GB
73.89GB	547.1GB	zeroed			

Check on the progress of a previous disk zeroing command.

```

cluster1::> storage aggregate show-spare-disks -owner-name node-b -zeroing
-percentage >0

Original Owner: node-b
Pool0
  Spare Pool
Usable Physical
  Disk          Type  Class      RPM  Checksum      Size
Size Status
-----
-----
  1.1.13        BSAS  capacity    7200  block      827.7GB
828.0GB zeroing, 17% done
  1.1.15        BSAS  capacity    7200  block      413.2GB
414.0GB zeroing, 28% done
2 entries were displayed.

```

## storage aggregate show-status

Display aggregate configuration

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate show-status` command displays the RAID layout and disk configuration of aggregates. The command output depends on the parameter or parameters specified with the command. If no parameters are specified, the command displays information about all aggregates in the cluster.



This command does not use pagination. You can reduce the output by filtering with the parameters below.

### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

This parameter currently has no effect.

**[-aggregate <text>] - Aggregate Name**

Selects the aggregates that match this parameter value.

**[-node <nodename>] - Node**

Selects the aggregates that match this parameter value.

**[-aggregate-uuid <UUID>] - Aggregate UUID**

Selects the aggregates that match this parameter value.

**Examples**

Display the RAID layout of a Flash Pool aggregate.

```
cluster1::> storage aggregate show-status -aggregate nodeB_flashpool_1

Owner Node: node-b
Aggregate: nodeB_flashpool_1 (online, raid_dp, hybrid) (block checksums)
  Plex: /nodeB_flashpool_1/plex0 (online, normal, active, pool0)
    RAID Group /nodeB_flashpool_1/plex0/rg0 (normal, block checksums)
                                                Usable
Physical
  Position Disk                                Pool Type    RPM    Size
Size Status
  -----  -----  -----  -----  -----  -----
  -----  -----
  dparity 1.1.7                                0  BSAS    7200  827.7GB
828.0GB (normal)
  parity 1.1.8                                0  BSAS    7200  827.7GB
828.0GB (normal)
  data 1.1.10                                 0  BSAS    7200  827.7GB
828.0GB (normal)
  data 1.1.11                                 0  BSAS    7200  827.7GB
828.0GB (normal)
  data 1.1.12                                 0  BSAS    7200  827.7GB
828.0GB (normal)
RAID Group /nodeB_flashpool_1/plex0/rg1 (normal, block checksums) (Storage
Pool: SP2)
                                                Usable
Physical
  Position Disk                                Pool Type    RPM    Size
Size Status
  -----  -----  -----  -----  -----  -----
  -----  -----
  shared 1.0.22                                0  SSD     -  186.2GB
745.2GB (normal)
  shared 1.0.20                                0  SSD     -  186.2GB
745.2GB (normal)
  shared 1.0.18                                0  SSD     -  186.2GB
745.2GB (normal)
  shared 1.0.16                                0  SSD     -  186.2GB
745.2GB (normal)
```

## storage aggregate show

Display a list of aggregates

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate show` command displays information about aggregates. The command output depends on the parameter or parameters specified with the command. If no parameters are specified, the command displays the following information about all aggregates:

- Aggregate name
- Size
- Available size
- Percentage used
- State
- Number of volumes
- Node on which the aggregate is located
- RAID status

To display detailed information about a single aggregate, use the `-aggregate` parameter.

### Parameters

{ [-fields <fieldname>, ...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-checksum ]

If this parameter is specified, the command displays information about the checksum for all aggregates in the cluster:

- Aggregate name
- Checksum status (active, off, reverting, none, unknown, initializing, reinitializing, reinitialized, upgrading\_phase1, upgrading\_phase2)
- Checksum style (none, advanced\_zoned, block, mixed, WAFL, or unknown)

| [-disk ]

If this parameter is specified, the command displays disk names for all aggregates in the cluster:

- Aggregate name
- Number and names of disks in the aggregate

| [-raid-info ]

If this parameter is specified, the command displays information about RAID groups, RAID type, maximum RAID size, checksum state, checksum style and whether the RAID status is inconsistent.

**[ [-instance ] ]**

If this parameter is specified, the command displays detailed information about all aggregates in the cluster.

**[ -aggregate <aggregate name> ] - Aggregate**

If this parameter is specified, the command displays detailed information about the specified aggregate.

**[ -storage-type {hdd | hybrid | lun | ssd | vmdisk} ] - Storage Type**

If this parameter is specified, the command displays information only about the aggregates with the specified storage type. The possible values are hdd, hybrid, lun, ssd and vmdisk.

**[ -chksumstyle <aggrChecksumStyle> ] - Checksum Style**

If this parameter is specified, the command displays information only about the aggregates that use the specified checksum style.

**[ -diskcount <integer> ] - Number Of Disks**

If this parameter is specified, the command displays information only about the aggregates that have the specified number of disks.

**[ -m, -mirror <true> ] - Is Mirrored**

If this parameter is specified, the command displays information only about the aggregates that have the specified mirrored value.

**[ -d, -disklist <disk path name>, ... ] - Disks for First Plex**

If this parameter is specified, the command displays information only about the aggregates that have the specified disk or disks.

**[ -mirror-disklist <disk path name>, ... ] - Disks for Mirrored Plex**

If this parameter is specified, the command displays information only about the aggregates that have the specified disk or disks present in the mirrored plex.

**[ -node {<nodename>|local} ] - Node**

If this parameter is specified, the command displays information only about the aggregates that are located on the specified node.

**[ -free-space-realloc {on|off} ] - Free Space Reallocation**

If this parameter is specified, the command displays whether free space reallocation is enabled on the specified aggregate.

**[ -ha-policy {sfo|cfo} ] - HA Policy**

This optionally specifies the high-availability policy to be used in the context of a root recovery procedure. Do not modify this setting unless directed to do so by a customer support representative.

**[ -percent-snapshot-space <percent> ] - Space Reserved for Snapshot Copies**

If this parameter is specified, the command displays information only about the aggregates that have the specified space reserved for Snapshot copies.

**[ -space-nearly-full-threshold-percent <percent> ] - Aggregate Nearly Full Threshold Percent**

If this parameter is specified, the command displays information only about the aggregates that have the specified nearly full threshold percent.

**[-space-full-threshold-percent <percent>] - Aggregate Full Threshold Percent**

If this parameter is specified, the command displays information only about the aggregates that have the specified full threshold percent.

**[-hybrid-enabled {true|false}] - Hybrid Enabled**

If this parameter is specified, the command displays information only about the aggregates that are eligible to contain both SSD and non-SSD RAID groups.

**[-availsize {<integer>[KB|MB|GB|TB|PB]}] - Available Size**

If this parameter is specified, the command displays information only about the aggregates that have the specified available size.

**[-chksumenabled {true|false}] - Checksum Enabled**

If this parameter is specified, the command displays information only about the aggregates that have the specified checksum setting.

**[-chksumstatus <text>] - Checksum Status**

If this parameter is specified, the command displays information only about the aggregates that have the specified checksum status. The possible values for checksum status include the following: active, off, reverting, none, unknown, initializing, reinitializing, reinitialized, upgrading\_phase1, and upgrading\_phase2.

**[-cluster <text>] - Cluster**

If this parameter is specified, the command displays information only about the aggregates that are owned by nodes in the specified cluster. By default, only local cluster aggregates are displayed.

**[-cluster-id <UUID>] - Home Cluster ID**

If this parameter is specified, the command displays information only about the aggregates that are owned by nodes in the cluster specified by the cluster UUID. By default, only local cluster aggregates are displayed.

**[-dr-home-id <integer>] - DR Home ID**

If this parameter is specified, the command displays information only about the aggregates whose Disaster Recovery home node has the specified system ID.

**[-dr-home-name <text>] - DR Home Name**

If this parameter is specified, the command displays information only about the aggregates whose Disaster Recovery home is the specified node.

**[-inofile-version <integer>] - Inofile Version (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregates whose inode files are at the specified version.

**[-has-mroot {true|false}] - Has Mroot Volume**

If this parameter is specified, the command displays information about only the aggregates that contain their owning node's management root directory.

**[-has-partner-mroot {true|false}] - Has Partner Node Mroot Volume**

If this parameter is specified, the command displays information about only the aggregates that contain the management root directory of their owning node's failover partner.

**[-home-id <integer>] - Home ID**

If this parameter is specified, the command displays information only about the aggregates whose home node has the specified system ID.

**[-home-name <text>] - Home Name**

If this parameter is specified, the command displays information only about the aggregates whose home node is the specified node.

**[-hybrid-cache-size-total {<integer>[KB|MB|GB|TB|PB]}] - Total Hybrid Cache Size**

If this parameter is specified, the command displays information only about the aggregates that have the specified total cache size in a Flash Pool.

**[-hybrid {true|false}] - Hybrid**

If this parameter is specified, the command displays information only about the aggregates that currently contain both SSD and non-SSD RAID groups.

**[-inconsistent {true|false}] - Inconsistent**

If this parameter is specified, the command displays information only about the aggregates that have the specified consistency.

**[-is-home {true|false}] - Is Aggregate Home**

If this parameter is specified, the command displays information only about the aggregates whose home node and owner node have the same system ID.

**[-s, -maxraidsize <integer>] - Max RAID Size**

If this parameter is specified, the command displays information only about the aggregates that have the specified maximum number of disks for RAID groups.



For Flash Pools, this option controls the maximum size of the HDD RAID groups.

**[-cache-raid-group-size <integer>] - Flash Pool SSD Tier Maximum RAID Group Size**

If this parameter is specified, the command displays information about the maximum RAID group size for the SSD tier for Flash Pools.



This parameter is applicable only for Flash Pools.

**[-owner-id <integer>] - Owner ID**

If this parameter is specified, the command displays information only about the aggregates that are owned by the node with the specified system ID.

**[-owner-name <text>] - Owner Name**

If this parameter is specified, the command displays information only about the aggregates that are owned by the specified node.

**[-percent-used <percent>] - Used Percentage**

If this parameter is specified, the command displays information only about the aggregates that have the specified used size, as a percentage.

**[-plexes <text>, ...] - Plexes**

If this parameter is specified, the command displays information only about the aggregates that have the specified plex or plexes.

**[-raidgroups <text>, ...] - RAID Groups**

If this parameter is specified, the command displays information only about the aggregates that have the specified RAID group or groups.

**[-raidstatus <text>] - RAID Status**

If this parameter is specified, the command displays information only about the aggregates that have the specified RAID status. The possible values for RAID status are normal, copying, ironing, degraded, mirror degraded, growing, initializing, invalid, needs check, partial, reconstruct, raid4, raid\_ep, raid0, raid\_dp, raid\_tec, redirect, and wafl inconsistent. You can specify multiple values (for example, reconstruct and growing).

**[-t, -raidtype {raid\_tec|raid\_dp|raid4|raid\_ep}] - RAID Type**

If this parameter is specified, the command displays information only about the aggregates that use the specified RAID type. The possible values are *raid0* for RAID 0, *raid4* for RAID4 of disks other than *SSD-ZNS*, *raid\_ep* for RAID4 of *SSD-ZNS* disks with additional RAID4 protection inside each disk, *raid\_dp* for RAID-DP, *raid\_tec* for RAID-TEC, and *mixed\_raid\_type* for aggregates that include a mix of RAID types.

**[-resyncsnaptime <integer>] - SyncMirror Resync Snapshot Frequency in Minutes**

If this parameter is specified, the command displays information only about the aggregates whose SyncMirror Resynchronization Snapshot Frequency is the specified value.

**[-root {true|false}] - Is Root**

If this parameter is specified, the command displays information about only the root aggregates in the cluster.

**[-sis-metadata-space-used <integer>[KB|MB|GB|TB|PB]] - Space Used by Metadata for Volume Efficiency**

If this parameter is specified, the command displays information about only the aggregates with the specified space used by A-SIS metafiles for volume efficiency. This parameter is deprecated in Data ONTAP 8.2 and later. Use the volume-footprint-list-info API for details related to space usage by deduplication metadata

**[-size <integer>[KB|MB|GB|TB|PB]] - Size**

If this parameter is specified, the command displays information only about the aggregates that have the specified size. The size of the aggregate is reported as the size available for use by WAFL, excluding WAFL reserve and aggregate Snapshot reserve capacity. Use the [storage aggregate show-space](#) command to see the details of space utilization within an aggregate.

**[-state <aggregate state>] - State**

If this parameter is specified, the command displays information only about the aggregates that have the specified state.

**[-usedsize <integer>[KB|MB|GB|TB|PB]] - Used Size**

If this parameter is specified, the command displays information only about the aggregates that have the specified used size.

**[-uses-shared-disks {true|false}] - Uses Shared Disks**

Selects the aggregates that match this parameter value. This parameter is used to list all the aggregates that use shared HDDs or shared SSDs.

**[-uuid <text>] - UUID String (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregate that has the specified UUID. This parameter is available only at the advanced privilege level and higher.

**[-volcount <integer>] - Number Of Volumes**

If this parameter is specified, the command displays information only about the aggregates that have the specified number of volumes.

**[-is-autobalance-eligible {true|false}] - Is Eligible for Auto Balance Aggregate (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregates that are considered by the Auto Balance Aggregate feature.

**[-autobalance-state <Auto Balance Aggregate state>] - State of the aggregate being balanced (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregates that have the specified state.

**[-physical-used {<integer>[KB|MB|GB|TB|PB]}] - Total Physical Used Size**

If this parameter is specified, the command displays information only about the aggregates that have the specified physical used size. This differs from *total-used* space by the space that is guaranteed for future writes. The value includes blocks in use by Snapshot copies.

**[-physical-used-percent <percent\_no\_limit>] - Physical Used Percentage**

If this parameter is specified, the command displays information only about the aggregates that have the specified physical used percent.

**[-autobalance-state-change-counter <integer>] - State Change Counter for Auto Balancer (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregates that have the specified number of state change caused by the Auto Balance Aggregate feature.

**[-L, -snaplock-type {non-snaplock|compliance|enterprise}] - SnapLock Type**

If this parameter is specified, the command displays information only about the aggregates that have the specified snaplock-type.

**[-is-nve-capable {true|false}] - Is NVE Capable**

This parameter indicates whether or not the aggregate is capable of supporting NVE (NetApp volume encryption).

**[-is-cft-precommit {true|false}] - Is in the precommit phase of Copy-Free Transition (privilege: advanced)**

Selects the aggregates that are set with this parameter value. This parameter lists all the aggregates that are in the precommit phase of a Copy-Free Transition workflow.

**[-is-transition-out-of-space {true|false}]** - Is a 7-Mode transitioning aggregate that is not yet committed in clustered Data ONTAP and is currently out of space (privilege: advanced)

Selects the aggregates that match this parameter value. This parameter is used to list all the 7-mode transitioning aggregates that are not yet committed in clustered Data ONTAP, and are currently out of space.

**[-autobalance-unbalanced-threshold-percent <integer>]** - Threshold When Aggregate Is Considered Unbalanced (%) (privilege: advanced)

If this parameter is specified, the command displays information only about the aggregates that have the specified unbalanced threshold percentage.

**[-autobalance-available-threshold-percent <integer>]** - Threshold When Aggregate Is Considered Balanced (%) (privilege: advanced)

If this parameter is specified, the command displays information only about the aggregates that have the specified available threshold percentage.

**[-resync-priority {high(fixed)|high|medium|low}]** - Resynchronization Priority

This parameter indicates the relative priority that is used to decide whether a mirrored aggregate can start a resynchronization operation or not. This field is not set for unmirrored aggregates.

Use the [storage aggregate resynchronization modify](#) command to modify this field for mirrored aggregates.

The valid values for this field are:

- high(fixed): This value is reserved for Data ONTAP system aggregates, which cannot have any other value for this field. It cannot be explicitly set on a data aggregate. These aggregates always start their resynchronization operation at the first available opportunity.
- high: Mirrored data aggregates with this priority value start resynchronization first.
- medium: Mirrored data aggregates with this priority value start resynchronization after all the system aggregates and data aggregates with 'high' priority value have started resynchronization.
- low: Mirrored data aggregates with this priority value start resynchronization only after all the other aggregates have started resynchronization.

**[-data-compaction-space-saved {<integer>[KB|MB|GB|TB|PB]}]** - Space Saved by Data Compaction

This parameter indicates the amount of the space saved by Data Compaction in bytes.

**[-data-compaction-space-saved-percent <percent>]** - Percentage Saved by Data Compaction

This parameter indicates the percentage of space saved in the aggregate by Data Compaction.

**[-data-compacted-count {<integer>[KB|MB|GB|TB|PB]}]** - Amount of compacted data

This parameter indicates the number of bytes occupied by compacted data inside this aggregate.

**[-creation-timestamp <MM/DD/YYYY HH:MM:SS>]** - Timestamp of Aggregate Creation

This parameter indicates the date and time the aggregate was created.

**[-single-instance-data-logging {off|on}]** - Enable SIDL

If this parameter is specified, the command displays whether Single Instance Data Logging feature is enabled on the specified aggregate.

**[-composite {true|false}] - Composite**

If this parameter is specified, the command displays information only about aggregates whose classification as a FabricPool matches the specified value. A FabricPool has an external capacity tier attached to it.

**[-is-fabricpool-mirrored {true|false}] - Is FabricPool Mirrored**

If this parameter is specified, the command displays information only about FabricPools whose classification as mirrored matches the specified value. A mirrored FabricPool has a second external capacity tier attached to it.

**[-composite-capacity-tier-used {<integer>[KB|MB|GB|TB|PB]}] - Capacity Tier Used Size**

If this parameter is specified, the command displays the amount of space in use in the attached external capacity tier.

**[-sis-space-saved {<integer>[KB|MB|GB|TB|PB]}] - Space Saved by Storage Efficiency**

This parameter indicates the total amount of space saved by storage efficiency in bytes.

**[-sis-space-saved-percent <percent>] - Percentage of Space Saved by Storage Efficiency**

This parameter indicates the percentage of space saved by storage efficiency.

**[-sis-shared-count {<integer>[KB|MB|GB|TB|PB]}] - Amount of Shared bytes count by Storage Efficiency**

This parameter indicates the number of bytes shared by storage efficiency.

**[-is-inactive-data-reporting-enabled {true|false}] - Inactive Data Reporting Enabled**

If this parameter is specified, the command displays whether reporting of inactive user data is enabled. This parameter is not allowed on FabricPools

**[-inactive-data-reporting-start-timestamp <MM/DD/YYYY HH:MM:SS>] - Timestamp when Inactive Data Reporting was Enabled**

If this parameter is specified, the command displays the timestamp at which inactive data reporting was enabled on the aggregate. This parameter is not allowed on FabricPools.

**[-encrypt-with-aggr-key {true|false}] - Enable Aggregate level Encryption**

Selects the aggregates that are encrypted with aggregate keys.

**[-drive-protection-enabled {true|false}] - Aggregate uses data protected SEDs**

If this parameter is specified, the command displays whether this aggregate is entirely composed of self-encrypting drives that have data protection enabled.

**[-azcs-read-optimization {on|off}] - azcs read optimization**

If this parameter is specified, the command displays whether azcs-with-compression feature is enabled.

**[-space-required-for-revert {<integer>[KB|MB|GB|TB|PB]}] - Metadata Reserve Space Required For Revert (privilege: advanced)**

If this parameter is specified, the command displays the additional amount of free space needed for metadata reserve in the aggregate if the system is required to revert to an ONTAP release earlier than 9.11.1x.

## Examples

The following example displays information about all aggregates that are owned by nodes in the local cluster:

```
cluster1::> storage aggregate show
Aggregate      Size Available Used% State      #Vols Nodes      RAID
Status
-----
-----
aggr0          6.21TB    1.78TB    71% online      49 cluster1-01
raid_dp,
                                                 normal
aggr1          56.04MB   55.89MB   0% online      0 cluster1-02
raid_dp,
                                                 mirrored,
                                                 normal
aggr2          1.77TB    1.63TB    8% online      1 cluster1-01
raid_dp,
                                                 normal
aggr3          1.77TB    1.73TB    2% online      2 cluster1-02
raid_dp,
                                                 normal
4 entries were displayed.
```

The following example displays information about an aggregate name aggr1:

```
cluster1::> storage aggregate show -aggregate aggr1
                           Aggregate: aggr1
                           Checksum Style: block
                           Number Of Disks: 6
                           Mirror: true
                           Nodes: cluster1-02
                           Disks for First Plex: 1.1.2,
                                                 1.1.10,
                                                 1.1.11
                           Disks for Mirrored Plex: 1.1.6,
                                                 1.1.8,
                                                 1.1.9
                           Free Space Reallocation: off
                           HA Policy: sfo
                           Space Reserved for Snapshot Copies: 5%
                           Hybrid Enabled: false
                           Available Size: 53.10MB
                           Block Type: 64-bit
```

```

Checksum Enabled: true
Checksum Status: active
Cluster: cluster1
Home Cluster ID: 686964a0-2172-11e3-
837d-123478563412
DR Home ID: -
DR Home Name: -
Has Mroot Volume: false
Has Partner Node Mroot Volume: false
Home ID: 4050409551
Home Name: cluster1-02
Total Hybrid Cache Size: 0B
Hybrid: false
Inconsistent: false
Is Aggregate Home: true
Max RAID Size: 16
Hybrid Aggregate SSD Tier Maximum RAID Group Size: -
Owner ID: 4050409551
Owner Name: cluster1-02
Used Percentage: 0%
Plexes: /aggr1/plex0,
/aggr1/plex1
RAID Groups: /aggr1/plex0/rg0
(block)
/aggr1/plex1/rg0
(block)
RAID Status: raid_dp, mirrored,
normal
RAID Type: raid_dp
SyncMirror Resync Snapshot Frequency in Minutes: 60
Is Root: false
Space Used By metadata for Volume Efficiency: 0B
Size: 53.24MB
SnapLock Type of the Aggregate: -
State: online
Used Size: 144KB
Number Of Volumes: 0
Is Flash Pool Caching: -
Is Eligible for Auto Balance Aggregate: false
State of the aggregate being balanced: ineligible
State Change Counter for Auto Balancer: 0
Is Encrypted: true
Encryption Key ID:
40004FE3000000000303000000000000436F5DB53445FD603FB5A8A64937AA7B
Is in the precommit phase of Copy-Free Transition: false
Is a 7-Mode transitioning aggregate that is not yet committed in clustered

```

```

Data ONTAP and is currently out of space: false
Threshold When Aggregate Is Considered Unbalanced (%): 70
Threshold When Aggregate Is Considered Balanced (%): 40
    Resynchronization Priority: -
    Space Saved by Data Compaction: 99.24MB
        Percentage Saved by Data Compaction: 7%
        Amount of compacted data: 99.24MB
    Timestamp of Aggregate Creation: 1/3/2017 23:38:06
    Enable SIDL: off
    Composite: false
    Capacity Tier Used Size: 0B
    Space Saved by Storage Efficiency: 99.24MB
        Percentage of Space Saved by Storage Efficiency: 7%
    Amount of Shared bytes count by Storage Efficiency: 99.24MB

```

The following example displays information about aggregates that are owned by nodes in cluster1:

```

cluster1::> storage aggregate show -cluster cluster1

cluster1:
Aggregate      Size Available Used% State      #Vols  Nodes          RAID
Status
-----  -----
-----  -----
aggr0          6.04GB     3.13GB    48% online        2  cluster1-01
raid_dp,
mirrored,                                              normal
aggr1          53.24MB    12.59MB   76% online        2  cluster1-02
raid_dp,
mirrored,                                              normal
2 entries were displayed.

```

The following example displays information about aggregates that are owned by nodes in the remote cluster named cluster2:

```

cluster1::> storage aggregate show -cluster cluster2

cluster2:
Aggregate      Size Available Used% State      #Vols  Nodes      RAID
Status

-----
-----
aggr2          -          -      - remote_cluster
                           - - - - -
aggr3          -          -      - remote_cluster
                           - - - - -
2 entries were displayed.

```

The following example displays information about aggregates that are owned by nodes in all the clusters:

```

cluster1::> storage aggregate show -cluster *
cluster2:
Aggregate      Size Available Used% State      #Vols  Nodes      RAID
Status

-----
-----
aggr2          -          -      - remote_cluster
                           - - - - -
aggr3          -          -      - remote_cluster
                           - - - - -
cluster1:
Aggregate      Size Available Used% State      #Vols  Nodes      RAID
Status

-----
-----
aggr0          6.04GB    3.14GB    48% online      2 cluster1-01
raid_dp,
mirrored,                               normal
aggr1          53.24MB   12.59MB   76% online      2 cluster1-02
raid_dp,
mirrored,                               normal
4 entries were displayed.

```

## Related Links

- [storage aggregate show-space](#)
- [storage aggregate resynchronization modify](#)

## storage aggregate verify

Verify an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate verify` command verifies the two plexes of an aggregate. It compares the data in the two plexes to ensure that the plexes are identical. It can be used whenever the administrator needs to ensure that the two plexes are completely synchronized with each other. To view any discrepancies, use the following command:

```
event log show -message-name raid.mirror.verify.mismatch
```

### Parameters

#### **-aggregate <aggregate name> - Aggregate**

This parameter specifies the aggregate to be verified. If no aggregate is specified then the action specified by the parameter `-action` will be taken on all the aggregates.

#### **-action {start|stop|resume|suspend|status} - Action**

This parameter specifies the action to be taken. The possible actions are:

- start - Starts a verify.
- stop - Permanently stops a verify. A stopped verify cannot be resumed.
- resume - Resumes a suspended verify.
- suspend - Suspends a verify.
- status - Displays the current status of a verify.

#### **[-plex-to-fix <text>] - Plex to be Corrected in Case of Mismatches**

This parameter specifies the name of a plex to fix in case the two plexes of the aggregate do not match. The default behavior is to log any discrepancies instead of fixing them.



This parameter is only applicable when the command is used to start a verify.

### Examples

The following example starts a verify on an aggregate named aggr1.

```
cluster1::> storage aggregate verify -aggregate aggr1 -action start
```

The following example queries the status of a verify on an aggregate named aggr1.

```
cluster1::> storage aggregate verify -aggregate aggr1 -action status
Aggregate:aggr1, Is Suspended:false, Percentage Completed:19.03%
```

The following example starts a verify on all the aggregates.

```
cluster1::> storage aggregate verify -action start
```

## storage aggregate efficiency show

Display aggregate storage efficiency details

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate efficiency show` command displays information about the different storage efficiency of all the aggregates. If no parameters are specified, the command displays the following information for all aggregates:

- Aggregate
- Node
- Cross-vol-background-dedupe State (Enabled, Disabled)
- Cross-vol-inline-dedupe State (Enabled, Disabled)

### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-aggregate <aggregate name>] - Aggregate**

Displays the aggregate name. If this parameter is specified, the command displays detailed information about the storage efficiency of the specified aggregate.

**[-node {<nodename>|local}] - Node**

Displays the node which owns the aggregate. If this parameter is specified, the command displays storage efficiency information only about the aggregates that are located on the specified node.

**[-cross-volume-background-dedupe {true|false}] - Cross Volume Background Deduplication**

Displays whether the cross volume background deduplication is enabled/disabled in the aggregate.

**[-cross-volume-inline-dedupe {true|false}] - Cross Volume Inline Deduplication**

Displays whether the cross volume inline deduplication is enabled/disabled in the aggregate.

**[-cross-volume-dedupe-savings {true|false}] - Has Cross Volume Deduplication Savings**

Displays whether the aggregate may have savings from cross volume deduplication.

**[-auto-adaptive-compression-savings {true|false}] - Has Auto Adaptive Compression Savings**

Displays whether the aggregate may have auto adaptive compression savings.

## Examples

The following example displays information about all aggregates that are owned by nodes in the local cluster:

```
cluster:::> storage aggregate efficiency show

Aggregate: aggr0
  Node: vivek6-vsim2

  Has Cross Volume Deduplication Savings:           false
  Cross Volume Background Deduplication:           false
  Cross Volume Inline Deduplication:               false

Aggregate: aggr1
  Node: vivek6-vsim2

  Has Cross Volume Deduplication Savings:           true
  Cross Volume Background Deduplication:           true
  Cross Volume Inline Deduplication:               true

  2 entries were displayed.
```

## storage aggregate efficiency stat

Display aggregate storage efficiency statistics

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The *storage aggregate efficiency stat* command displays storage efficiency statistics.

### Parameters

{ [-fields <fieldname>,...]}

If you specify the *-fields <fieldname>,...* parameter, the command output also includes the specified field or fields. You can use *'-fields ?'* to display the fields to specify.

**[ [-instance ] ]**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[ -aggregate <aggregate name> ] - Aggregate**

If this parameter is specified, the command displays storage efficiency statistics for the specified aggregate.

**[ -node {<nodename> | local} ] - Node**

If this parameter is specified, the command displays storage efficiency statistics for the aggregates that are located on the specified node.

**[ -total-blocks-recompressed <integer> ] - Total Number of Blocks Recompressed**

This field represents the total number of blocks recompressed. If this parameter is specified, the command displays storage efficiency statistics that match the specified block count.

**[ -active-blocks-recompressed <integer> ] - Number of Active Blocks Recompressed**

This field represents the total number of hot blocks recompressed. If this parameter is specified, the command displays storage efficiency statistics that match the specified block count.

**[ -inactive-blocks-recompressed <integer> ] - Number of Inactive Blocks Recompressed**

This field represents the total number of cold blocks recompressed. If this parameter is specified, the command displays storage efficiency statistics that match the specified block count.

## Examples

The following example displays storage efficiency statistics for all the aggregates that are owned by nodes in the local cluster:

```
cluster1:::> storage aggregate efficiency stat
Aggregate: aggr1
                                Node: node1
    Total Number of Blocks Recompressed: 512
        Number of Active Blocks Recompressed: 120
        Number of Inactive Blocks Recompressed: 392
Aggregate: aggr2
                                Node: node1
    Total Number of Blocks Recompressed: 0
        Number of Active Blocks Recompressed: 0
        Number of Inactive Blocks Recompressed: 0

2 entries were displayed.
```

## storage aggregate efficiency cross-volume-dedupe revert-to

Reverts the cross volume deduplication savings on an aggregate

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The storage aggregate cross-volume-dedupe revert-to command is used to revert cross volume deduplication savings on an aggregate.

## Parameters

### **-aggregate <aggregate name> - Aggregate (privilege: advanced)**

This specifies the aggregate on which cross volume deduplication savings should be reverted. If no aggregate is specified then it will revert the savings on all aggregates

### **[-c, -clean-up {true|false}] - Delete Previously Downgraded Metafiles (privilege: advanced)**

This specifies whether downgrade metafile needs to be removed so that other efficiency operations can start on that aggregate.

## Examples

The following example displays information for reverting cross volume background deduplication on aggregate "aggr1":

```
cluster:::> storage aggregate efficiency cross-volume-dedupe revert-to
-aggregate aggr1
The revert operation started on aggregate "aggr1".

cluster:::> storage aggregate efficiency cross-volume-dedupe revert-to
-aggregate aggr1 -clean-up true
The revert operation started on aggregate "aggr1".
```

## storage aggregate efficiency cross-volume-dedupe show

Display aggregate cross volume deduplication efficiency details

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The storage aggregate efficiency cross-volume-dedupe show command displays information in detail about the different storage efficiency of all the aggregates. If no parameters are specified, the command displays the following information for all aggregates:

## Parameters

### **{ [-fields <fieldname>,...]**

If you specify the **-fields <fieldname>,...** parameter, the command output also includes the specified field or fields. You can use **'-fields ?'** to display the fields to specify.

### **| [-instance ] }**

If you specify the **-instance** parameter, the command displays detailed information about all fields.

**[-aggregate <aggregate name>] - Aggregate**

Displays the aggregate name. If this parameter is specified, the command displays detailed information about the storage efficiency of the specified aggregate.

**[-node {<nodename>|local}] - Node**

Displays the node which owns the aggregate. If this parameter is specified, the command displays storage efficiency information only about the aggregates that are located on the specified node.

**[-background-progress <text>] - Progress**

Displays the information for the aggregates that match the specified progress.

**[-background-op-status <text>] - Operation Status**

Displays the information for the aggregates that match the specified operation status.

**[-background-last-op-state <text>] - Last Operation State**

Displays the information for the aggregates that match the specified last operation state.

**[-background-last-success-op-begin <Date>] - Last Success Operation Begin Time**

Displays the information for the aggregates that match the specified last successful operation begin time.

**[-background-last-success-op-end <Date>] - Last Success Operation End Time**

Displays the information for the aggregates that match the specified last successful operation end time.

**[-background-last-op-begin <Date>] - Last Operation Begin Time**

Displays the information for the aggregates that match the specified last operation begin time.

**[-background-last-op-end <Date>] - Last Operation End Time**

Displays the information for the aggregates that match the specified last operation end time.

**[-background-last-op-error <text>] - Last Operation Error**

Displays the information for the aggregates that match the specified last operation error.

**[-background-stage <text>] - Stage**

Displays the information for the aggregates that match the specified stage.

**[-background-checkpoint-time <Date>] - Checkpoint Time**

Displays the information for the aggregates that match the specified checkpoint time.

**[-background-checkpoint-op-type <text>] - Checkpoint Operation Type**

Displays the information for the aggregates that match the specified checkpoint operation type.

**[-background-checkpoint-stage <text>] - Checkpoint Stage**

Displays the information for the aggregates that match the specified checkpoint stage.

**[-background-dedupe {true|false}] - Background State**

Displays the information for the aggregates that match the specified cross volume background dedupe state.

**[-inline-dedupe {true|false}] - Inline State**

Displays the information for the aggregates that match the specified cross volume inline dedupe state.

**[-dedupe-savings {true|false}] - Has Cross Volume Deduplication Savings**

Displays the information for the aggregates that has some savings from cross volume deduplication.

## Examples

The following example displays information about all aggregates that are owned by nodes in the local cluster:

```
cluster:::> storage aggregate efficiency cross-volume-dedupe show

Aggregate: aggr0
  Node: vivek6-vsim2

Has Cross Volume Deduplication Savings: false

-----:Cross Volume Background Deduplication Status:-----
State: false
Progress: -
Operation Status: Idle
Last Operation State: Success
Last Success Operation Begin Time: -
Last Success Operation End Time: -
Last Operation Begin Time: -
Last Operation End Time: -
Last Operation Error: Operation
succeeded
Stage: -
Checkpoint Time: -
Checkpoint Operation Type: -
Checkpoint Stage: -

-----:Cross Volume Inline Deduplication Status:-----
State: false
Aggregate: aggr1
  Node: vivek6-vsim2

Has Cross Volume Deduplication Savings: true

-----:Cross Volume Background Deduplication Status:-----
State: true
Progress: -
Operation Status: Idle
Last Operation State: Success
Last Success Operation Begin Time: Wed Aug 30
06:31:50 2017
```

```

Last Success Operation End Time:                               Wed Aug 30
06:31:50 2017
Last Operation Begin Time:                                Wed Aug 30
06:31:50 2017
Last Operation End Time:                                 Wed Aug 30
06:31:50 2017
Last Operation Error:                                    Operation
succeeded
Stage:                                                 Cross
volume sharing Done
Checkpoint Time:                                         -
Checkpoint Operation Type:                            -
Checkpoint Stage:                                     -
-----:Cross Volume Inline Deduplication Status:-----
State:                                                 true

2 entries were displayed.

```

## storage aggregate efficiency cross-volume-dedupe start

Starts the cross volume background deduplication on an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate cross-volume-dedupe start` command is used to start cross volume background deduplication on an aggregate.

### Parameters

#### **-aggregate <aggregate name> - Aggregate**

This specifies the aggregate on which cross volume background deduplication should be started. If no aggregate is specified then it will start on all aggregates

#### **[-s, -scan-old-data <true>] - Scan Old Data**

This option processes all the existing data on all volumes on the aggregate. It prompts for user confirmation before proceeding. Default value is `false` .

### Examples

The following example displays information for starting cross volume background deduplication on aggregate "aggr1":

```
cluster:::> storage aggregate efficiency cross-volume-dedupe start
-aggregate aggr1
The efficiency operation on aggregate "aggr1" has started.
```

```
cluster:::> storage aggregate efficiency cross-volume-dedupe start
-aggregate aggr1 -scan-old-data true
The efficiency operation on aggregate "aggr1" has started.
```

## storage aggregate efficiency cross-volume-dedupe stop

Stops the cross volume background deduplication on an aggregate

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The storage aggregate cross-volume-dedupe stop command is used to stop cross volume background deduplication on an aggregate.

### Parameters

**-aggregate <aggregate name>** - Aggregate (privilege: advanced)

This specifies the aggregate on which cross volume background deduplication should be stopped. If no aggregate is specified then it will stop on all aggregates

### Examples

The following example displays information for stopping cross volume background deduplication on aggregate "aggr1":

```
cluster:::> storage aggregate efficiency cross-volume-dedupe stop
-aggregate aggr1
The efficiency operation on aggregate "aggr1" is being stopped.
```

## storage aggregate encryption show-key-id

Display encrypted aggregate information

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The storage aggregate encryption show-key-id command displays the key IDs of all NAE (NetApp Aggregate Encryption) aggregates.

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-aggregate <text>] - Aggregate**

If this parameter is specified, the command displays information only about the specific NAE (NetApp Aggregate Encryption) aggregate.

**[-aggrID <UUID>] - Aggregate UUID**

If this parameter is specified, the command displays the key ID of the specified NAE (NetApp Aggregate Encryption) aggregate ID.

**[-keyid-index-zero <text>,...] - 0th Index Keyid**

If this parameter is specified, the command displays the 0th index key ID of NAE (NetApp Aggregate Encryption) aggregates.

## storage aggregate inode-upgrade resume

Resume suspended inode upgrade

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage aggregate inode-upgrade resume` command resumes a suspended inode upgrade process. The inode upgrade process might have been suspended earlier due to performance reasons.

## Parameters

**-node {<nodename>|local} - Node Name (privilege: advanced)**

If this parameter is specified, the command resumes the upgrade process of an aggregate that is located on the specified node.

**-aggregate <aggregate name> - Aggregate Name (privilege: advanced)**

This specifies the aggregate for which the inode upgrade process is to be resumed.

## Examples

The following example resumes an aggregate upgrade process:

```
cluster1::> storage aggregate inode-upgrade resume -aggregate aggr1
```

## storage aggregate inode-upgrade show

Display inode upgrade progress

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage aggregate inode-upgrade show` command displays information about aggregates undergoing the inode upgrade process. The command output depends on the parameter or parameters specified with the command. If no parameters are specified, the command displays the default fields about all aggregates undergoing the inode upgrade process. The default fields are:

- aggregate
- status
- scan-percent
- remaining-time
- space-needed
- scanner-progress

### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-aggregate <text>] - Aggregate Name (privilege: advanced)**

If this parameter is specified with the `-node` parameter, the command displays detailed information about the specified aggregate. If only this parameter is specified, the command displays information about all aggregates that match the specified name.

**[-node <nodename>] - Node Name (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregate or aggregates that are located on the specified node.

**[-status {pending|scanning|suspended-initializing|suspended|cleanup-pending|cleanup|cleanup-done|suspended-aborting|suspended-removing|suspended-while-removing|suspended-ironing}] - Upgrade Status (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregate or aggregates that match the specified inode upgrade status.

**[-scan-percent <percent>] - Upgrade Scan Percent Complete (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregate or aggregates that match the specified inode upgrade progress percentage.

## **[-space-needed {<integer>[KB|MB|GB|TB|PB]}] - Space Needed to Complete Upgrade (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregate or aggregates where the space needed to complete the upgrade process matches the specified size.

## **[-remaining-time <[<integer>h]<integer>m]<integer>s] - Remaining Upgrade Time (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregate or aggregates where the remaining time to complete the inode upgrade process matches the specified time.

## **[-scanner-progress <text>] - Scanner Progress (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregate or aggregates where the progress of the inode upgrade process matches the input.

## **Examples**

The following example displays information about all aggregates undergoing the inode upgrade process:

```
cluster1::> storage aggregate inode-upgrade show
Aggregate Status %Complete Time Remaining Space Needed Inode Progress
----- -----
aggr0 pending 0% - 20.36MB Public : Inode 0
out of 65562
aggr1 pending 0% - 19.84MB Public : Inode 0
out of 63714
```

## **storage aggregate object-store attach**

Attach an object store to an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The storage aggregate object-store attach command attaches an object store to an aggregate to create a FabricPool. This command requires two parameters to create a FabricPool - an aggregate and a configuration to attach an object-store to the aggregate. This command verifies whether the object store is accessible through the intercluster LIF both from the node on which the aggregate is present as well as its High Availability (HA) partner node. The command fails if the object store is not accessible. Once an object store is attached to an aggregate, it cannot be detached.

### **Parameters**

#### **-aggregate <text> - Name of the Aggregate**

This parameter specifies the aggregate to which the object store must be attached to create a FabricPool.

#### **-object-store-name <text> - Object Store Configuration Name**

This parameter specifies the object store configuration that describes the object store to be attached. The object store configuration has information about object store server name, port, access credentials, and

provider type.

#### **[-allow-flexgroup {true|false}] - Allow Existing FlexGroup Constituents in the Aggregate on Attach**

This optional parameter allows attaching object store to an aggregate already containing FlexGroup constituents. The default value is false. Mixing FabricPools and non-FabricPools within a FlexGroup is not recommended. All aggregates hosting constituents of a FlexGroup should be attached to the object store.

#### **Examples**

The following example attaches an object store to aggregate aggr1:

```
cluster1::>storage aggregate object-store attach -aggregate aggr1 -object  
-store-name my-store
```

### **storage aggregate object-store mirror**

Attaches a second object store to a FabricPool aggregate to create a mirror

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### **Description**

The `storage aggregate object-store mirror` command attaches a second object store to a FabricPool aggregate to create a mirror. This command verifies whether the object store is accessible through the intercluster LIF from both the node on which the aggregate is present and from its high-availability (HA) partner node. The command fails if the object store is not accessible.

#### **Parameters**

##### **-aggregate <text> - Name of the Aggregate**

This parameter specifies the aggregate to which the object store must be attached in order to create a mirror.

##### **-object-store-name <text> - Object Store Configuration Name**

This parameter specifies the name of the new object store configuration to be attached to the aggregate. The object store configuration has information about the object store server name, port, access credentials, and provider type.

#### **Examples**

The following example shows how to create a mirror to aggregate aggr1:

```
cluster1::>storage aggregate object-store mirror -aggregate aggr1 -object  
-store-name my-store-2
```

## storage aggregate object-store modify

Modify attributes of object stores attached to an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The storage aggregate object-store modify command is used to update one or more object store parameters.

### Parameters

#### **-aggregate <text> - Aggregate Name**

This parameter identifies the aggregate to which the object store to be modified is attached.

#### **-object-store-name <text> - ONTAP Name for this Object Store Config**

This parameter identifies the configuration name of the object store to be modified.

#### **[-unreclaimed-space-threshold <percent>] - Threshold for Reclaiming Unreferenced Space (privilege: advanced)**

This optional parameter specifies the usage threshold below which Data ONTAP reclaims unused space from objects in the object store. When Data ONTAP writes data to the object store, it packages multiple file system blocks into one object. Over time, blocks stored in an object can be freed, leaving part of the object unused. When the percentage of used blocks in an object falls below this threshold, a background task moves the blocks which are still used to a new object. Afterwards, Data ONTAP frees the original object to reclaim the unused space. Valid values are between 0% and 99%. The default value depends on the object store's provider type. It is 20% for *AWS\_S3* , 25% for *Azure\_Cloud* , 40% for *SGWS* , 20% for *IBM\_COS* , 20% for *AliCloud* , 20% for *GoogleCloud* and 40% for *ONTAP\_S3* . Consult the FabricPool best practices guidelines for more information.

#### **[-tiering-fullness-threshold <percent>] - Aggregate Fullness Threshold Required for Tiering (privilege: advanced)**

This optional parameter specifies the percentage of space in the performance tier which must be used before data is tiered out to the capacity tier.

#### **[-mirror-type {primary|mirror}] - Object Store Mirror Type**

This parameter specifies the object store mirror type. Valid mirror types are *primary* or *mirror* .

#### **[-force-tiering-on-metrocluster {true|false}] - Force Tiering with no Mirror in a MetroCluster Configuration**

This parameter specifies force tiering option enabled or not on primary object stores for aggregates in a MetroCluster configuration.

### Examples

The following example modifies the unreclaimed space threshold of an object store attached to an aggregate named aggr1:

```
cluster1::> storage aggregate object-store modify -aggregate aggr1 -object
-store-name my-store -unreclaimed-space-threshold 20%
```

## storage aggregate object-store show-freeing-status

Show status of background object freeing work after aggregate delete

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage aggregate object-store show-freeing-status` command displays status information about the background work that frees an aggregate's objects from an object store after a [storage aggregate delete](#).

### Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-bin-uuid <UUID>] - UUID of the Bin (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregate attached to the specified bin UUID.

**[-config-id <integer>] - Object Store Config ID (privilege: advanced)**

If this parameter is specified, the command displays information only about the aggregate attached to the object-store with specified config ID.

**[-object-store-name <text>] - Object Store Configuration Name (privilege: advanced)**

If this parameter is specified, the command displays information only about object stores whose configuration name matches the specified names.

**[-aggregate-name <aggregate name>] - Aggregate (privilege: advanced)**

If this parameter is specified, the command displays information only about the specified aggregates that were deleted.

**[-request-state {queued|running|cleaning-up|finishing}] - Request State (privilege: advanced)**

If this parameter is specified, the command displays information only about the object stores that have the specified object freeing request state.

**[-num-objects-freed <integer>] - Num Objects Freed (privilege: advanced)**

If this parameter is specified, the command displays information only about the object stores that have the specified number of objects that have been freed.

## **[-last-error <text>] - The Last Error Encountered (privilege: advanced)**

If this parameter is specified, the command displays information only about the object stores that have the specified last error encountered.

### **Related Links**

- [storage aggregate delete](#)

## **storage aggregate object-store show-resync-status**

Display object store mirror resync progress

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `storage aggregate object-store show-resync-status` command displays information about the progress of resync for mirror object stores attached to a FabricPool.

### **Parameters**

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

### **[-aggregate <aggregate name>] - Aggregate**

If this parameter is specified, the command displays information only about the specified aggregates.

### **[-primary-object-store-name <text>] - Primary Object Store Name**

If this parameter is specified, the command displays information only about aggregates whose primary object store configuration name matches the specified names.

### **[-mirror-object-store-name <text>] - Mirror Object Store Name**

If this parameter is specified, the command displays information only about aggregates whose mirror object store configuration name matches the specified names.

### **[-percent-complete <percent>] - Resync Complete Percentage**

If this parameter is specified, the command displays information only about aggregates whose mirror object store resync progress percentage matches the specified value.

### **Examples**

The following example displays resync progress for all aggregates with mirror object stores which are not in sync:

```
cluster1::>storage aggregate object-store show-resync-status
```

## storage aggregate object-store show-space

Display space utilization of object stores attached to an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate object-store show-space` command displays information about the amount of space used in the object store for each of the aggregates in FabricPool. The used space is displayed in both absolute size as well as a percentage of the FabricPool license limit.

### Parameters

{ [-fields <fieldname>, ...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-aggregate <text>] - Aggregate Name**

If this parameter is specified, the command displays space information only about object stores that are attached to the specified aggregates.

**[-object-store-name <text>] - ONTAP Name for this Object Store Config**

If this parameter is specified, the command displays space information only about object stores whose configuration name matches the specified names.

**[-object-store-availability <object Store Availability>] - Availability of the Object Store**

If this parameter is specified, the command displays space information about the object stores whose availability status matches the specified value. Supported values with this parameter are - available and unavailable.

**[-object-store-unavailable-reason <text>] - Reason why Object Store is Unavailable**

If this parameter is specified, the command displays information only about object stores whose unavailability reason matches the specified reason.

**[-provider-type <providerType>] - Type of the Object Store Provider**

If this parameter is specified, the command displays information only about object store configurations whose provider type matches the specified value.

**[-license-used-percent <percent\_no\_limit>] - License Space Used Percent**

If this parameter is specified, the command displays space information only about object stores whose space used by the associated aggregate as a percentage of the license limit matches the specified value. If the object store does not require a license, then this field is not set.

**[-unreclaimed-space-threshold <percent>] - Threshold for Reclaiming Unreferenced Space  
(privilege: advanced)**

If this parameter is specified, the command displays information only about object stores whose threshold for reclaiming unused space from objects in the object store matches the specified value.

## **[-tiering-fullness-threshold <percent>] - Aggregate Fullness Threshold Required for Tiering (privilege: advanced)**

If this parameter is specified, the command displays information only about object stores whose performance tier fullness threshold for tiering matches the specified value.

## **[-mirror-type {primary|mirror}] - Object Store Mirror Type**

If this parameter is specified, the command displays information about object stores with a mirror-type that matches the specified value.

## **[-is-mirror-degraded {true|false}] - This object store is in mirror degraded mode**

If this parameter is specified, the command displays information only about mirror object stores which have the specified mirror degraded state.

## **[-force-tiering-on-metrocluster {true|false}] - Force Tiering with no Mirror in a MetroCluster Configuration**

If this parameter is specified, the command displays information only about primary object stores for which force tiering is toggled on for aggregates in a MetroCluster configuration.

## **[-cluster <Cluster name>] - The name of the Cluster to which the bin belongs**

If this parameter is specified, the command displays information only about object stores for which cluster matches the specified value.

## **Examples**

The following example displays space information about all object stores:

```
cluster1::>storage aggregate object-store show-space
```

## **storage aggregate object-store show**

Display the details of object stores attached to an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `storage aggregate object-store show` command displays information about all the object stores in the system.

### **Parameters**

```
{ [-fields <fieldname>,...]
```

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `-fields ?` to display the fields to specify.

```
| [-instance ] }
```

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-aggregate <text>] - Aggregate Name**

If this parameter is specified, the command displays information only about the object stores that are attached to the specified aggregates.

**[-object-store-name <text>] - ONTAP Name for this Object Store Config**

If this parameter is specified, the command displays information only about object stores whose configuration name matches the specified names.

**[-object-store-availability <object Store Availability>] - Availability of the Object Store**

If this parameter is specified, the command displays information only about object stores whose availability status matches the specified value. Supported values with this parameter are - available and unavailable.

**[-object-store-unavailable-reason <text>] - Reason why Object Store is Unavailable**

If this parameter is specified, the command displays information only about object stores whose unavailability reason matches the specified reason.

**[-provider-type <providerType>] - Type of the Object Store Provider**

If this parameter is specified, the command displays information only about object store configurations whose provider type matches the specified value.

**[-license-used-percent <percent\_no\_limit>] - License Space Used Percent**

If this parameter is specified, the command displays information only about object stores whose space used by the aggregate as a percentage of the license limit matches the specified value.

**[-unreclaimed-space-threshold <percent>] - Threshold for Reclaiming Unreferenced Space  
(privilege: advanced)**

If this parameter is specified, the command displays information only about object stores whose threshold for reclaiming unused space from objects in the object store matches the specified value.

**[-tiering-fullness-threshold <percent>] - Aggregate Fullness Threshold Required for Tiering  
(privilege: advanced)**

If this parameter is specified, the command displays information only about object stores whose performance tier fullness threshold for tiering matches the specified value.

**[-mirror-type {primary|mirror}] - Object Store Mirror Type**

If this parameter is specified, the command displays information about object stores with a mirror-type that matches the specified value.

**[-is-mirror-degraded {true|false}] - This object store is in mirror degraded mode**

If this parameter is specified, the command displays information only about mirror object stores which have the specified mirror degraded state. When a mirror object store is attached to a FabricPool, it is initially degraded because it does not contain a copy of all the data in the primary object store. While the mirror is degraded, all reads are served from the primary object store, and the mirror cannot be promoted to become the primary. After the resync process copies all data from the primary object store to the mirror, the mirror is no longer degraded. From that point on the mirror is always kept in sync with the primary and never becomes degraded again.

**[-force-tiering-on-metrocluster {true|false}] - Force Tiering with no Mirror in a MetroCluster Configuration**

If this parameter is specified, the command displays information only about primary object stores for which force tiering is toggled on for aggregates in a MetroCluster configuration.

## **[-cluster <Cluster name>] - The name of the Cluster to which the bin belongs**

If this parameter is specified, the command displays information only about object stores for which cluster matches the specified value.

### **Examples**

The following example displays all information about all object stores:

```
cluster1::>storage aggregate object-store show
```

## **storage aggregate object-store unmirror**

Remove the second object store from a mirrored FabricPool

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `storage aggregate object-store unmirror` command detaches a second object store from a mirrored FabricPool. This command verifies whether the primary object store is accessible through the intercluster LIF from both the node on which the aggregate is present and from its high-availability (HA) partner node. The command fails if the primary object store is not available.

### **Parameters**

#### **-aggregate <text> - Name of the Aggregate**

This parameter specifies the aggregate from which the mirrored object store must be removed.

### **Examples**

The following example shows how to unmirror a mirrored FabricPool aggr1:

```
cluster1::>storage aggregate object-store unmirror -aggregate aggr1
```

## **storage aggregate object-store config create**

Define the configuration for an object store

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `storage aggregate object-store config create` command is used by a cluster administrator to tell Data ONTAP how to connect to an object store. Following pre-requisites must be met before creating an object store configuration in Data ONTAP.

- A valid data bucket or container must be created with the object store provider. This assumes that the user has valid account credentials with the object store provider to access the data bucket.

- The Data ONTAP node must be able to connect to the object store. This includes
- Fast, reliable connectivity to the object store.
- An inter-cluster LIF (Logical Interface) must be configured on the cluster. Data ONTAP will verify connectivity prior to saving this configuration information.
- If SSL/TLS authentication is required, then valid certificates must be installed.
- FabricPool license (required for Amazon S3 and Azure object stores).

An object-store configuration once created must not be reassigned with a different object-store or container. See [storage aggregate object-store config modify](#) command for more information. If neither the `access-key` nor the `secret-password` are provided while setting up a configuration for AWS\_S3 object store in Cloud Volumes ONTAP, then the access key (access key ID), the secret password (secret access key), and the session token will be retrieved from EC2 instance metadata for the AWS Identity and Access Management (IAM) role associated with the EC2 instance. If Data ONTAP is unable to create a object store configuration, then the command will fail explaining the reason for failure.

## Parameters

### **`-object-store-name <text>` - Object Store Configuration Name**

This parameter specifies the name that will be used to identify the object store configuration. The name can contain the following characters: "", "-", A-Z, a-z, and 0-9. *The first character must be one of the following: "", A-Z, or a-z.*

### **`-provider-type <providerType>` - Type of the Object Store Provider**

This parameter specifies the type of object store provider that will be attached to the aggregate. Valid options are: AWS\_S3 (Amazon S3 storage), Azure\_Cloud (Microsoft Azure Cloud), SGWS (StorageGrid WebScale), IBM\_COS (IBM Cloud Object Storage), AliCloud (Alibaba Cloud Object Storage Service), GoogleCloud (Google Cloud Storage) and ONTAP\_S3.

### **`[-auth-type <object_store_auth_type>]` - Authentication Used to Access the Object Store**

This parameter specifies where the system obtains credentials for authentication to an object store. The available choices depend on the platform (Cloud Volumes ONTAP or not) and provider-type (AWS\_S3 or not). The `keys` value is always applicable, and if selected means that the `access-key` and `secret-password` are provided by the system administrator. In Cloud Volumes ONTAP, the `EC2-IAM` value is also applicable. It means that the IAM role is associated with the EC2 instance, and that the `access-key`, `secret-password` and `session token` are retrieved from EC2 instance metadata for this IAM role. Note that `-use-iam-role` and `-auth-type` are mutually exclusive, `-auth-type EC2-IAM` is an equivalent of `-use-iam-role true`, and `-auth-type key` is an equivalent of `-use-iam-role false`. In Cloud Volumes ONTAP, the `GCP-SA` value may also be applicable. It means that a session token is retrieved from the GCP instance metadata for the Service Account associated with the GCP instance. Similarly, `Azure-MSI` means that a session token is retrieved from the Azure instance metadata for the Managed Service Identity (MSI) associated with the Azure instance. For the `AWS_S3` provider, the `CAP` (C2S Authentication Portal) value is also applicable. This should only be used when accessing C2S (Commercial Cloud Services). If the `CAP` value is specified, then the `-cap-url` must be specified. See `cap-url`.

### **`[-cap-url <text>]` - URL to Request Temporary Credentials for C2S Account**

This parameter is available only when `-auth-type` is `CAP`. It specifies a full URL of the request to a CAP server for retrieving temporary credentials (access-key, secret-password and session token) for accessing the object store server. The CAP URL may look like: <https://123.45.67.89:1234/CAP/api/v1/credentials?agency=myagency=mymission=myrole>

## **-server <Remote InetAddress> - Fully Qualified Domain Name of the Object Store Server**

This parameter specifies the Fully Qualified Domain Name (FQDN) of the remote object store server. For Amazon S3, server name must be an AWS regional endpoint in the format s3.amazonaws.com or s3-  
<region>.amazonaws.com, for example, s3-us-west-2.amazonaws.com. The region of the server and the bucket must match. For more information on AWS regions, refer to 'Amazon documentation on AWS regions and endpoints'. For Azure, if the -server is a "blob.core.windows.net" or a "blob.core.usgovcloudapi.net", then a value of -azure-account followed by a period will be added in front of the server.

## **[-is-ssl-enabled {true|false}] - Is SSL/TLS Enabled**

This parameter indicates whether a secured SSL/TLS connection will be used during data access to the object store. The default value is true .

## **[-port <integer>] - Port Number of the Object Store**

This parameter specifies the port number on the remote server that Data ONTAP will use while establishing connection to the object store.

## **-container-name <text> - Data Bucket/Container Name**

This parameter specifies the data bucket or container that will be used for read and write operations.



This name cannot be modified once a configuration is created.

## **{ [-access-key <text>] - Access Key ID for S3 Compatible Provider Types**

This parameter specifies the access key (access key ID) required to authorize requests to the AWS S3, SGWS, IBM COS object stores and ONTAP\_S3. For an Azure object store see -azure-account .

## **[-secret-password <text>] - Secret Access Key for S3 Compatible Provider Types**

This parameter specifies the password (secret access key) to authenticate requests to the AWS S3, SGWS, IBM COS object stores and ONTAP\_S3. If the -access-key is specified but the -secret-password is not, then one will be asked to enter the -secret-password without echoing the input. For an Azure object store see -azure-private-key .

## **| [-azure-account <text>] - Azure Account**

This parameter specifies the account required to authorize requests to the Azure object store. For other object store providers see access-key.



The value of this field cannot be modified once a configuration is created.

## **[-ask-azure-private-key {true|false}] - Ask to Enter the Azure Access Key without Echoing**

If this parameter is true then one will be asked to enter -azure-private-key without echoing the input. Default value: true .

## **[-azure-private-key <text>] - Azure Access Key }**

This parameter specifies the access key required to authenticate requests to the Azure object store. See also ask-azure-private-key . For other object store providers see -secret-password .

## **[-ipspace <IPspace>] - IPspace to Use in Order to Reach the Object Store**

This optional parameter specifies the IPspace to use to connect to the object store. Default value: Default

## **[-is-certificate-validation-enabled {true|false}] - Is SSL/TLS Certificate Validation Enabled**

This parameter indicates whether an SSL/TLS certificate of an object store server is validated whenever an SSL/TLS connection to an object store server is established. This parameter is only applicable when `is-ssl-enabled` is `true`. The default value is `true`. It is recommended to use the default value to make sure that Data ONTAP connects to a trusted object store server, otherwise identities of an object store server are not verified.

## **[-use-http-proxy {true|false}] - Use HTTP Proxy**

This optional parameter indicates whether an HTTP proxy will be used for connecting to an object store. Note that an HTTP proxy is configured using the `vserver http-proxy` commands at the `diagnostic` privilege level. Default value: `false`.

## **[-cluster <Cluster name>] - The Name of the Cluster to which the Configuration Belongs**

This optional parameter should only be specified in MetroCluster switched-over mode and specifies the name of the cluster for which the configuration must be created. By default the configuration is created for the local cluster.

## **[-server-side-encryption {none | SSE-S3}] - Encryption of Data at Rest by the Object Store Server (privilege: advanced)**

This parameter specifies if AWS or other S3 compatible object store server must encrypt data at rest. The available choices depend on provider-type. `none` encryption (no encryption required) is supported by all types of S3 (non-Azure) object store servers. `SSE-S3` encryption is supported by and is a default for all types of S3 (non-Azure) object store servers except ONTAP\_S3. This is an advanced property. In most cases it is best not to change default value of "sse\_s3" for object store servers which support SSE-S3 encryption. The encryption is in addition to any encryption done by ONTAP at a volume or at an aggregate level.

## **[-url-style {path-style | virtual-hosted-style}] - URL Style Used to Access S3 Bucket**

This parameter specifies the URL style used to access S3 bucket. This option is only available for non-Azure object store providers. The available choices and default value depend on provider-type.

## **Examples**

The following example creates an object store configuration in Data ONTAP:

```
cluster1::>storage aggregate object-store config create -object-store-name
               my_aws_store -provider-type AWS_S3 -server s3.amazonaws.com
               -container-name my-aws-bucket -access-key DXJRXHPXHYXA9X31X3JX
```

## **Related Links**

- [storage aggregate object-store config modify](#)

## **storage aggregate object-store config delete**

Delete the configuration of an object store

**Availability:** This command is available to *cluster* administrators at the `admin` privilege level.

## Description

The `storage aggregate object-store config delete` command removes an existing object store configuration in Data ONTAP. The configuration cannot be deleted if it is used by any aggregates or if the system is still freeing objects from the object store from a previously executed `storage aggregate delete` command. The command `storage aggregate object-store show` can be used to view the aggregates attached to the object store before issuing the delete command.



The `storage aggregate object-store show` command will not display aggregates that have been previously deleted but still has objects in the object store.

## Parameters

### **-object-store-name <text>** - Object Store Configuration Name

This parameter specifies the object store configuration to be deleted.

## Examples

The following example deletes an object store configuration named `my-store`:

```
cluster1::>storage aggregate object-store config delete -object-store-name  
my-store
```

## Related Links

- [storage aggregate delete](#)
- [storage aggregate object-store show](#)

## **storage aggregate object-store config modify**

### Modify object store configuration attributes

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage aggregate object-store config modify` command is used to update one or more of object store configuration parameters. This command must not be used to reassociate an existing valid object-store configuration to a new object-store or container. The modifiable parameters include object store name, server name, port, access\_key, secret-password, ipspace and is-ssl-enabled.

## Parameters

### **-object-store-name <text>** - Object Store Configuration Name

This parameter identifies the configuration to be modified.

### **[-new-object-store-name <text>]** - Object Store Configuration New Name

This optional parameter specifies the new name for the object store configuration.

## **[-auth-type <object\_store\_auth\_type>] - Authentication Used to Access the Object Store**

This optional parameter specifies where the system obtains credentials for authentication to an object store. The available choices depend on the platform (Cloud Volumes ONTAP or not) and provider-type (AWS\_S3 or not). The *keys* value is always applicable, and if selected means that the *access-key* and *secret-password* are provided by the system administrator. In Cloud Volumes ONTAP, the *EC2-IAM* value is also applicable. It means that the IAM role is associated with the EC2 instance, and that the *access-key*, *secret-password* and session token are retrieved from EC2 instance metadata for this IAM role. Note that *-use-iam-role* and *-auth-type* are mutually exclusive, *-auth-type EC2-IAM* is an equivalent of *-use-iam-role true*, and *-auth-type key* is an equivalent of *-use-iam-role false*. In Cloud Volumes ONTAP, the *GCP-SA* value may also be applicable. It means that a session token is retrieved from the GCP instance metadata for the Service Account associated with the GCP instance. Similarly, *Azure-MSI* means that a session token is retrieved from the Azure instance metadata for the Managed Service Identity (MSI) associated with the Azure instance. For the *AWS\_S3* provider, the *CAP* (C2S Authentication Portal) value is also applicable. This should only be used when accessing C2S (Commercial Cloud Services). If the *CAP* value is specified, then the '*-cap-url*' must be specified. See *cap-url*.

## **[-cap-url <text>] - URL to Request Temporary Credentials for C2S Account**

This parameter is available only when *-auth-type* is *CAP*. It specifies a full URL of the request to a CAP server for retrieving temporary credentials (access-key, secret-password and session token) for accessing the object store server. The CAP URL may look like: <https://123.45.67.89:1234/CAP/api/v1/credentials?agency=myagency=mymission=myrole>

## **[-server <Remote InetAddress>] - Fully Qualified Domain Name of the Object Store Server**

This optional parameter specifies the new Fully Qualified Domain Name (FQDN) of the same object store server. For Amazon S3, server name must be an AWS regional endpoint in the format s3.amazonaws.com or s3-<region>.amazonaws.com, for example, s3-us-west-2.amazonaws.com. The region of the server and the bucket must match. For more information on AWS regions, refer to 'Amazon documentation on AWS regions and endpoints'. For Azure, if the *-server* is a "blob.core.windows.net" or a "blob.core.usgovcloudapi.net", then the value of *azure-account* in the configuration followed by a period will be added in front of the server. Note that the value of *azure-account* cannot be modified.

## **[-is-ssl-enabled {true|false}] - Is SSL/TLS Enabled**

This optional parameter indicates whether a secured SSL/TLS connection will be used during data access to the object store.

## **[-port <integer>] - Port Number of the Object Store**

This optional parameter specifies a new port number to connect to the object store server indicated in the *-server* parameter.

## **[-access-key <text>] - Access Key ID for S3 Compatible Provider Types**

This optional parameter specifies a new access key (access key ID) for the AWS S3, SGWS, IBM COS object stores and ONTAP S3.

## **[-secret-password <text>] - Secret Access Key for S3 Compatible Provider Types**

This optional parameter specifies a new password (secret access key) for the AWS S3, SGWS, IBM COS object stores and ONTAP S3. For an Azure object store see *-azure-private-key*. If the *-access-key* is specified but the *-secret-password* is not then one will be asked to enter the *-secret-password* without echoing the input.

**[-ask-azure-private-key {true|false}] - Ask to Enter the Azure Access Key without Echoing**

If this optional parameter is true then one will be asked to enter the `-azure-private-key` without echoing the input.

**[-azure-private-key <text>] - Azure Access Key**

This optional parameter specifies a new access key for Azure object store. For other object store providers see `secret-password`. See also `ask-azure-private-key`.

**[-ipspace <IPspace>] - IPspace to Use in Order to Reach the Object Store**

This optional parameter specifies new ipspace values for the configuration.

**[-is-certificate-validation-enabled {true|false}] - Is SSL/TLS Certificate Validation Enabled**

This optional parameter indicates whether an SSL/TLS certificate of an object store server is validated whenever an SSL/TLS connection to an object store server is established. This parameter is only applicable when `is-ssl-enabled` is true. It is recommended to keep the default value which is true to make sure that Data ONTAP connects to a trusted object store server, otherwise identities of an object store server are not verified.

**[-use-http-proxy {true|false}] - Use HTTP Proxy**

This optional parameter indicates whether an HTTP proxy will be used for connecting to an object store.

Note that an HTTP proxy is configured using the `vserver http-proxy` commands at the diagnostic privilege level.

**[-server-side-encryption {none | SSE-S3}] - Encryption of Data at Rest by the Object Store Server (privilege: advanced)**

This parameter specifies if AWS or other S3 compatible object store server must encrypt data at rest. The available choices depend on provider-type. `none` encryption (no encryption required) is supported by all S3 (non-Azure) object store servers. `SSE-S3` encryption is supported by all S3 (non-Azure) object store servers except ONTAP\_S3. This is an advanced property. In most cases it is best not to change default value of "sse\_s3" for object store servers which support SSE-S3 encryption. The encryption is in addition to any encryption done by ONTAP at a volume or at an aggregate level. Note that changing this option does not change encryption of data which already exist in the object store.

**[-url-style {path-style | virtual-hosted-style}] - URL Style Used to Access S3 Bucket**

This parameter specifies the URL style used to access S3 bucket. This option is only available for non-Azure object store providers. The available choices and default value depend on provider-type.

## Examples

The following example modifies two parameters (port number and `is-ssl-enabled`) of an object store configuration named `my-store`:

```
cluster1::>storage aggregate object-store config modify -object-store-name my-store -port 1235 -is-ssl-enabled true
```

## storage aggregate object-store config rename

Rename an existing object store configuration

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage aggregate object-store config rename` command is used to rename an existing object store configuration.

## Parameters

### **-object-store-name <text>** - Object Store Configuration Name

This parameter identifies an existing object store configuration.

### **-new-object-store-name <text>** - Object Store Configuration New Name

This parameter specifies the new object store configuration name.

## Examples

The following example renames an object store configuration from my-store to ms1:

```
cluster1::>storage aggregate object-store config rename -object-store-name
my-store -new-object-store-name ms1
```

## storage aggregate object-store config show

Display a list of object store configurations

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The *storage aggregate object-store config show* command displays information about all existing object store configurations in the cluster.

## Parameters

### { [-fields <fieldname>,...]

If you specify the *-fields <fieldname>,...* parameter, the command output also includes the specified field or fields. You can use *'-fields ?'* to display the fields to specify.

### | [-instance ] }

If you specify the *-instance* parameter, the command displays detailed information about all fields.

### **[-object-store-name <text>]** - Object Store Configuration Name

If this parameter is specified, the command displays information only about object store configurations whose name matches the specified names.

**[-object-store-uuid <UUID>] - UUID of the Object Store Configuration**

If this parameter is specified, the command displays information only about object store configurations whose UUID matches the specified UUID values.

**[-provider-type <providerType>] - Type of the Object Store Provider**

If this parameter is specified, the command displays information only about object store configurations whose provider type matches the specified value.

**[-auth-type <object\_store\_auth\_type>] - Authentication Used to Access the Object Store**

If this parameter is specified, the command displays information only about object store configurations whose authentication type matches the specified value.

**[-cap-url <text>] - URL to Request Temporary Credentials for C2S Account**

If this parameter is specified, the command displays information only about object store configurations whose CAP URL matches the specified value.

**[-server <Remote InetAddress>] - Fully Qualified Domain Name of the Object Store Server**

If this parameter is specified, the command displays information only about object store configurations whose server name matches the specified value. The server name is specified as a Fully Qualified Domain Name (FQDN).

**[-is-ssl-enabled {true|false}] - Is SSL/TLS Enabled**

If this parameter is specified, the command displays information only about object store configurations whose status about the use of secured communication over the network matches the specified value.

**[-port <integer>] - Port Number of the Object Store**

If this parameter is specified, the command displays information only about object store configurations whose port numbers matches the specified value.

**[-container-name <text>] - Data Bucket/Container Name**

If this parameter is specified, the command displays information only about object store configurations whose container name matches the specified value. Data ONTAP uses this container name or object store data bucket while accessing data from the object store.

**[-access-key <text>] - Access Key ID for S3 Compatible Provider Types**

If this parameter is specified, the command displays information only about AWS S3, SGWS, IBM COS object store configurations and ONTAP S3 whose access key matches the specified value. Data ONTAP requires the access key for authorized access to the object store.

**[-azure-account <text>] - Azure Account**

If this parameter is specified, the command displays information only about Azure object store configurations whose account matches the specified value. Data ONTAP requires the Azure account for authorized access to the Azure object store.

**[-ipspace <IPspace>] - IPspace to Use in Order to Reach the Object Store**

If this parameter is specified, the command displays information only about object store configurations whose IPspace matches the specified value. Data ONTAP uses the IPspace value to connect to the object store.

**[-iam-role <text>] - IAM Role for AWS Cloud Volumes ONTAP**

If this parameter is specified, the command displays information only about object store configurations whose IAM (Identity and Access Management) role matches the specified value.

**[-is-certificate-validation-enabled {true|false}] - Is SSL/TLS Certificate Validation Enabled**

If this parameter is specified, the command displays information only about object store configurations whose status about the validation of SSL/TLS certificate matches the specified value.

**[-use-http-proxy {true|false}] - Use HTTP Proxy**

If this parameter is specified, the command displays information only about object store configurations for which usage of HTTP proxy matches the specified value.

**[-cluster <Cluster name>] - The Name of the Cluster to which the Configuration Belongs**

If this parameter is specified, the command displays information only about object store configurations for which cluster matches the specified value.

**[-server-side-encryption {none | SSE-S3}] - Encryption of Data at Rest by the Object Store Server (privilege: advanced)**

If this parameter is specified, the command displays information only about object store configurations whose server-side encryption matches the specified value.

**[-url-style {path-style | virtual-hosted-style}] - URL Style Used to Access S3 Bucket**

If this parameter is specified, the command displays information only about object store configurations whose URL style matches the specified value.

## Examples

The following example displays all available object store configuration in the cluster:

```
cluster1::>storage aggregate object-store config show
```

## storage aggregate object-store profiler abort

### Abort Object Store Profiler

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

#### Description

The storage aggregate object-store profiler abort command will abort an ongoing object store profiler run. This command requires two parameters - an object store configuration and a node on which the profiler is currently running.

#### Parameters

**-node {<nodename>|local} - Node on Which the Profiler Should Run (privilege: advanced)**

This parameter specifies the node on which the object store profiler is running.

## **-object-store-name <text> - Object Store Configuration Name (privilege: advanced)**

This parameter specifies the object store configuration that describes the object store. The object store configuration has information about the object store server name, port, access credentials, and provider type.

### **Examples**

The following example aborts the object store profiler :

```
cluster1::>storage aggregate object-store profiler abort -object-store
-name my-store -node my-node
```

## **storage aggregate object-store profiler show**

### **Show Object Store Profiler Status**

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### **Description**

The *storage aggregate object-store profiler show* command is used to monitor progress and results of the [storage aggregate object-store profiler start](#) command.

### **Parameters**

**{ [-fields <fieldname>,...]**

If you specify the *-fields <fieldname>,...* parameter, the command output also includes the specified field or fields. You can use *'-fields ?'* to display the fields to specify.

**| [-instance ] }**

If you specify the *-instance* parameter, the command displays detailed information about all fields.

### **[-node <nodename>] - Node Name (privilege: advanced)**

This parameter specifies the node on which the profiler was started.

### **[-object-store-name <text>] - ONTAP Name for this Object Store Configuration (privilege: advanced)**

This parameter specifies the object store configuration that describes the object store. The object store configuration has information about the object store server name, port, access credentials, and provider type.

### **[-object-name-prefix <UUID>] - Bin UUID (privilege: advanced)**

This parameter specifies the object name prefix.

### **[-profiler-status <text>] - Profiler Status (privilege: advanced)**

Current status of the profiler.

**[-start-time <MM/DD/YYYY HH:MM:SS>] - Profiler Start Time (privilege: advanced)**

Time at which profiler run started.

**[-op-name <text>] - Operation Name - PUT/GET (privilege: advanced)**

Name of the operation. Possible values are PUT or GET.

**[-op-size {<integer>[KB|MB|GB|TB|PB]}] - Size of Operation (privilege: advanced)**

Size of the PUT or GET operation.

**[-op-count <integer>] - Number of Operations Performed (privilege: advanced)**

Number of operations issued to the object store.

**[-op-failed <integer>] - Number of Operations Failed (privilege: advanced)**

Number of operations that failed.

**[-op-latency-minimum <integer>] - Minimum Latency for Operation in Milliseconds (privilege: advanced)**

Minimum latency of the operation in milliseconds, as measured from the filesystem layer.

**[-op-latency-maximum <integer>] - Maximum Latency for Operation in Milliseconds (privilege: advanced)**

Maximum latency of the operation in milliseconds, as measured from the filesystem layer.

**[-op-latency-average <integer>] - Average Latency for Operation in Milliseconds (privilege: advanced)**

Average latency of the operation in milliseconds, as measured from the filesystem layer.

**[-op-throughput {<integer>[KB|MB|GB|TB|PB]}] - Throughput per Second for the operation (privilege: advanced)**

Throughput per second for the operation.

**[-op-errors <text>,...] - Error Reasons and Count (privilege: advanced)**

Error reasons and count for failed operation.

**[-op-latency-histogram <text>,...] - Latency Histogram (privilege: advanced)**

Latency histogram for the operation.

## Examples

The following example displays the results of [storage aggregate object-store profiler start](#) :

```
cluster1::>storage aggregate object-store profiler show
```

## Related Links

- [storage aggregate object-store profiler start](#)

## storage aggregate object-store profiler start

Start the object store profiler to measure latency and throughput

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The storage aggregate object-store profiler start command writes objects to an object store and reads those objects to measure latency and throughput of an object store. This command requires two parameters - an object store configuration and node from which to send the PUT/GET/DELETE operations. This command verifies whether the object store is accessible through the intercluster LIF of the node on which it runs. The command fails if the object store is not accessible. The command will create a 10GB dataset by doing 2500 PUTs for a maximum time period of 60 seconds. Then it will issue GET operations of different sizes - 4KB, 8KB, 32KB, 256KB for a maximum time period of 180 seconds. Finally it will delete the objects it created. This command can result in additional charges to your object store account. This is a CPU intensive command. It is recommended to run this command when the system is under 50% CPU utilization.

### Parameters

#### **-node {<nodename>|local} - Node on Which the Profiler Should Run (privilege: advanced)**

This parameter specifies the node from which PUT/GET/DELETE operations are sent.

#### **-object-store-name <text> - Object Store Configuration Name (privilege: advanced)**

This parameter specifies the object store configuration that describes the object store. The object store configuration has information about the object store server name, port, access credentials, and provider type.

### Examples

The following example starts the object store profiler :

```
cluster1::>storage aggregate object-store profiler start -object-store
-name my-store -node my-node
```

## storage aggregate object-store put-rate-limit modify

Modify the maximum, per node, FabricPool put rate

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The storage aggregate object-store put-rate-limit modify command enables the modification of values that can be used to limit the FabricPool put rate or to allow it to run more aggressively. Use the [storage aggregate object-store put-rate-limit show](#) command to display the current maximum put rate, if any, in effect.

## Parameters

**-node {<nodename>|local} - Node Name (privilege: advanced)**

This parameter specifies the Node name.

**[-default {true|false}] - Set Default Values (privilege: advanced)**

Setting this field to true will reset the put-rate-limit to the system default.

**[-put-rate-bytes-limit {<integer>[KB|MB|GB|TB|PB]}] - Limit Max (B/s) Allowed (privilege: advanced)**

This field is the maximum put rate in bytes per second. The field can be used to reduce the put rate to an object store.

## Related Links

- [storage aggregate object-store put-rate-limit show](#)

## storage aggregate object-store put-rate-limit show

Display the per node FabricPool Put Rate Limit

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage aggregate object-store put-rate-limit show` command displays the maximum put rate for FabricPool.

## Parameters

{ [-fields <fieldname>, ...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node (privilege: advanced)**

This parameter specifies the Node name.

**[-put-rate-bytes-limit {<integer>[KB|MB|GB|TB|PB]}] - Put Rate Limit (B/s) (privilege: advanced)**

This field represents an upper boundary on the allowed put rate. The put rate will not be allowed to exceed this value but can be throttled to values less than it to accommodate client operations and a high average system CPU. Some platforms are intentionally configured with a lower maximum put rate in an effort to reduce the impact of the FabricPool put subsystem on the overall system health. A limit in effect, lower than the default, may keep cold data in the performance tier for a long period of time and may require an increase in space requirements. A value of -1 indicates no upper bound is in effect.

**[-put-rate {<integer>[KB|MB|GB|TB|PB]}] - Estimated Put Rate (B/s) (privilege: advanced)**

The put-rate displays the maximum computed bytes per second the put subsystem assumes is possible.

This put rate is measured in real-time and is in relation to the node for all attached object stores which have put traffic to them.

#### **[-max-put-rate-in-effect {<integer>[KB|MB|GB|TB|PB]}] - Current Maximum Put Rate In Effect (B/s) (privilege: advanced)**

This field displays the maximum allowed put rate. If it is less than the max-throughput then it indicates that throttling is in effect. The throttling is the outcome of either staying at put-rates-byte-limit or an effort to accomodate client operations on a system with high CPU.

#### **[-max-throughput {<integer>[KB|MB|GB|TB|PB]}] - Estimated Maximum Throughput (B/s) (privilege: advanced)**

This field displays the maximum put throughput rate in bytes per second that the put subsystem will throttle down from or up to. It's the greater of the put-rate and the node default value.

## **storage aggregate plex delete**

### Delete a plex

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### **Description**

The storage aggregate plex delete command deletes the specified plex. The aggregate specified with then -aggregate will be unmirrored and contain the remaining plex. The disks in the deleted plex become spare disks.

#### **Parameters**

##### **-aggregate <aggregate name> - Aggregate**

Name of an existing aggregate which contains the plex specified with the -plex parameter.

##### **-plex <text> - Plex**

Name of a plex which belongs to the aggregate specified with the -aggregate parameter.

#### **Examples**

The following example deletes plex0 of aggregate aggr1:

```
cluster1::> storage aggregate plex delete -aggregate aggr1 -plex plex0
```

## **storage aggregate plex offline**

### Offline a plex

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### **Description**

The storage aggregate plex offline command takes the specified plex offline. The aggregate specified with the -aggregate parameter must be a mirrored aggregate and both plexes must be online. Prior

to taking a plex offline, the system will flush all internally-buffered data associated with the plex and create a snapshot that is written out to both plexes. The snapshot allows for efficient resynchronization when the plex is subsequently brought back online.

## Parameters

### **-aggregate <aggregate name> - Aggregate**

Name of an existing aggregate which contains the plex specified with the **-plex** parameter.

### **-plex <text> - Plex**

Name of a plex which belongs to the aggregate specified with the **-aggregate** parameter.

## Examples

The following example takes plex0 of aggregate aggr1 offline:

```
cluster1::> storage aggregate plex offline -aggregate aggr1 -plex plex0
```

## storage aggregate plex online

### Online a plex

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The **storage aggregate plex online** command brings the specified plex online. The aggregate specified with the **-aggregate** parameter must be an online mirrored aggregate. The system will initiate resynchronization of the plex as part of online processing.

## Parameters

### **-aggregate <aggregate name> - Aggregate**

Name of an existing aggregate which contains the plex specified with the **-plex** parameter.

### **-plex <text> - Plex**

Name of a plex which belongs to the aggregate specified with the **-aggregate** parameter.

## Examples

The following example brings plex0 of aggregate aggr1 online:

```
cluster1::> storage aggregate plex online -aggregate aggr1 -plex plex0
```

## storage aggregate plex show

### Show plex details

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage aggregate plex show` command displays information for the specified plex. By default, the command displays the following information about all plexes:

- Aggregate Name
- Plex Name
- Is Online
- Is Resyncing
- Resyncing Percentage
- Plex Status

To display detailed information about a single plex, use the `-aggregate` and `-plex` parameter.

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-aggregate <aggregate name>] - Aggregate**

Name of an existing aggregate which contains the plex specified with the `-plex` parameter.

**[-plex <text>] - Plex Name**

Name of a plex which belongs to the aggregate specified with the `-aggregate` parameter.

**[-status <text>] - Status**

Displays plex status. Possible values are:

- *normal*
- *failed*
- *empty*
- *invalid*
- *uninitialized*
- *failed assimilation*
- *limbo*
- *active*
- *inactive*
- *resyncing*

These values may appear by themselves or in combination separated by commas, for example, "normal,active".

**[-is-online {true|false}] - Is Online**

Selects the plexes that match this parameter value.

**[-in-progress {true|false}] - Resync is in Progress**

Selects the plexes that match this parameter value.

**[-resyncing-percent <percent>] - Resyncing Percentage**

Selects the plexes that match this parameter value.

**[-resync-level <integer>] - Resync Level**

Selects the plexes that match this parameter value.

**[-pool <integer>] - Pool**

Selects the plexes that match this parameter value.

## Examples

The following example displays information about all the plexes for all the aggregates:

```
cluster1::> storage aggregate plex show
              Is      Is      Resyncing
Aggregate  Plex      Online  Resyncing  Percent  Status
-----  -----
aggr0      plex0    true    false      - normal,active
aggr1      plex0    true    false      - normal,active
aggr1      plex1    true    false      - normal,active
aggr2      plex0    true    false      - normal,active
aggr2      plex2    true    false      - normal,active
5 entries were displayed.
```

The following example displays information about plex1 of aggregate aggr1:

```
cluster1::> storage aggregate plex show -aggregate aggr1 -plex plex1
Aggregate: aggr1
          Plex Name: plex1
          Status: normal,active
          Is Online: true
Resync is in Progress: false
Resyncing Percentage: -
          Resync Level: -
          Pool: 1
```

## storage aggregate reallocation quiesce

Quiesce reallocate job on aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

Temporarily stops any reallocation jobs that are in progress. When you use this command, the persistent state is saved. You can use the [storage aggregate reallocation restart](#) command to restart a job that is quiesced.

There is no limit to how long a job can remain in the quiesced (paused) state.

### Parameters

#### **-aggregate <aggregate name> - Aggregate Name**

Specifies the aggregate on which you want to temporarily pause the job.

### Examples

```
cluster1::> storage aggregate reallocation quiesce
    -aggregate aggr0
```

Temporarily stops (pauses) any reallocation job running on aggregate aggr0.

### Related Links

- [storage aggregate reallocation restart](#)

## storage aggregate reallocation restart

Restart reallocate job on aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

Starts a reallocation job. Use this command to restart a quiesced (temporarily stopped) job or a scheduled scan that is idle for the aggregate.

### Parameters

#### **-aggregate <aggregate name> - Aggregate Name**

Specifies the aggregate on which you want to restart reallocation scans.

#### **[-i, -ignore-checkpoint <true>] - Ignore Checkpoint**

Restarts the job at the beginning when set to true. If you use this command without specifying this parameter, its effective value is false and the job starts the scan at the point where it was stopped. If you specify this parameter without a value, it is set to true and the scan restarts at the beginning.

## Examples

```
cluster1::> storage aggregate reallocation restart
    -aggregate aggr0 -ignore-checkpoint true
```

Restarts reallocation job on aggregate aggr0 from the beginning.

## storage aggregate reallocation schedule

Modify schedule of reallocate job on aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

Schedules a reallocation scan for an existing reallocation job. If the reallocation job does not exist, use the [storage aggregate reallocation start](#) command to define a reallocation job.

You can delete an existing reallocation scan schedule. However, if you do this, the job's scan interval reverts to the schedule that was defined for it when the job was created with the [storage aggregate reallocation start](#) command.

### Parameters

#### **-aggregate <aggregate name>** - Aggregate Name

Specifies the aggregate on which you want to schedule reallocation jobs.

#### **[-d, -del <true>]** - Delete

Deletes an existing reallocation schedule when set to true. If you use this command without specifying this parameter, its effective value is false and the reallocation schedule is not deleted. If you specify this parameter without a value, it is set to true and the reallocation schedule is deleted.

#### **[-s, -cron <text>]** - Cron Schedule

Specifies the schedule with the following four fields in sequence. Use a space between field values. Enclose the values in double quotes.

- minute is a value from 0 to 59.
- hour is a value from 0 (midnight) to 23 (11:00 p.m.).
- day of week is a value from 0 (Sunday) to 6 (Saturday).
- day of month is a value from 1 to 31.



If you specify 31 as the value for the day of month, reallocation scans will not run in any months with fewer than 31 days.

Use an asterisk "\*" as a wildcard to indicate every value for that field. For example, an \* in the day of month field means every day of the month. You cannot use the wildcard in the minute field.

You can enter a number, a range, or a comma-separated list of values for a field.

## Examples

```
cluster1::> storage aggregate reallocation schedule -aggregate aggr0 -cron  
"0 23 6 *"
```

Schedules a reallocation job to run at 11:00 p.m. every Saturday on aggr0.

## Related Links

- [storage aggregate reallocation start](#)

## storage aggregate reallocation show

Show reallocate job status for improving free space layout

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

Displays the status of a reallocation scan, including the state, schedule, aggregate and scan id. If you do not specify the `id` for a particular reallocation scan, the command displays information about all the existing reallocation scans.

## Parameters

{ [-fields <fieldname>,...]

Displays the value of relevant field that you specify for the reallocation scans that are present.

| [-v ]

Specify this parameter to display the output in a verbose format.

| [-instance ] }

Displays information about reallocation scans on aggregates in a list format.

**[-id <integer>] - Job ID**

Specify this parameter to display the reallocation scan that matches the reallocation job ID that you specify.

**[-aggregate <aggregate name>] - Aggregate Name**

Specify this parameter to display the reallocation scan that matches the aggregate that you specify.

**[-description <text>] - Job Description**

Specify this parameter to display reallocation scans that match the text description that you specify.

**[-state**

**{Initial|Queued|Running|Waiting|Pausing|Paused|Quitting|Success|Failure|Reschedule|Error|Quit|Dead|Unknown|Restart|Dormant} ] - Job State**

Specify this parameter to display reallocation jobs that match the state that you specify.

### **[-progress <text>] - Execution Progress**

Specify this parameter to list the running reallocation jobs whose progress indicator matches the text that you provide. For example, if you specify "Starting ..." as the text string for the progress option, then the system lists all the jobs that are starting.

### **[-schedule <job\_schedule>] - Schedule Name**

Specify this parameter to display reallocation scans that match the schedule name that you specify. If you want a list of all job schedules, use the [job schedule show](#) command.

### **[-global-status <text>] - Global State of Scans**

Specify this parameter to indicate if reallocation scans are on or off globally. You must type either of the following text strings:

- "Reallocation scans are on"
- "Reallocation scans are off"

## **Examples**

```
cluster1::> storage aggregate reallocation show
Job ID          Aggregate          Schedule          State
-----          -----          -----
23              aggr0            reallocate_0 23 * 6  Queued
```

Displays the job ID, aggregate, schedule, and state for the reallocation scans.

## **Related Links**

- [job schedule show](#)

## **storage aggregate reallocation start**

Start reallocate job on aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## **Description**

Begins a reallocation scan on a specified aggregate.

Before performing a reallocation scan, the reallocation job normally performs a check of the current layout optimization. If the current layout optimization is less than the threshold, then the system does not perform a reallocation on the aggregate.

You can define the reallocation scan job so that it runs at a specific interval, or you can use the [storage aggregate reallocation schedule](#) command to schedule reallocation jobs.

## **Parameters**

## **-aggregate <aggregate name> - Aggregate Name**

Specify this parameter to specify the target aggregate on which to start a reallocation scan.

## **{ [-i, -interval <text>] - Interval Schedule**

Specified the schedule in a single string with four fields:

- minute is a value from 0 to 59.
- hour is a value from 0 (midnight) to 23 (11:00 p.m.).
- day of month is a value from 1 to 31.



If you specify 31 as the value for the day of the month, reallocation scans will not run in any of the months with fewer than 31 days.

- day of the week is a value from 0 (Sunday) to 6 (Saturday).

Use an asterisk "\*" as a wildcard to indicate every value for that field. For example, an \* in the day of month field means every day of the month. You cannot use the wildcard in the minute field.

You can enter a number, a range, or a comma-separated list of values for a field.

## **| [-o, -once <true>] - Once }**

Specifies that the job runs once and then is automatically removed from the system when set to true. If you use this command without specifying this parameter, its effective value is false and the reallocation scan runs as scheduled. If you enter this parameter without a value, it is set to true and a reallocation scan runs once.

## **Examples**

```
cluster1::> storage aggregate reallocation start -aggregate aggr0
-interval "0 23 * 6"
```

Starts a reallocation job on aggregate aggr0 at 11:00 p.m. every Saturday.

## **Related Links**

- [storage aggregate reallocation schedule](#)

## **storage aggregate reallocation stop**

Stop reallocate job on aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## **Description**

Stops and deletes any reallocation scan running on the specified aggregate. This command stops and deletes in-progress, scheduled, and quiesced scans.

## Parameters

### **-aggregate <aggregate name> - Aggregate Name**

Specify this parameter to specify the target aggregate on which to stop and delete a reallocation scan.

## Examples

```
cluster1::> storage aggregate reallocation stop -aggregate aggr0
```

Stops and deletes the reallocation scan on aggregate aggr0.

## **storage aggregate relocation show**

Display relocation status of an aggregate

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The *storage aggregate relocation show* command displays status of aggregates which were relocated in the last instance of relocation operation.

## Parameters

### **{ [-fields <fieldname>,...]**

If you specify the *-fields <fieldname>,...* parameter, the command only displays the fields that you specify.

### **| [-instance ] }**

If you specify the *-instance* parameter, the command displays detailed information about all entries.

### **[-node {<nodename>|local}] - Node**

Selects aggregates from the specified source node.

### **[-aggregate <text>] - Aggregate Name**

Selects the aggregates that match this parameter value.

### **[-relocation-status <text>] - Aggregates Relocation Status**

Selects the aggregates whose relocation status matches this parameter value.

### **[-destination <text>] - Destination for Relocation**

Selects the aggregates that are designated for relocation on the specified destination node.

## Examples

The following example displays the relocation status of aggregates on all nodes in the cluster:

```

cluster1::> storage aggregate relocation show
Source          Aggregate  Destination  Relocation Status
-----  -----  -----  -----
node0
          -          -          Not attempted yet
node1
          aggr1      node0      Done
          aggr2      node0      In progress
          aggr3      node0      Not attempted yet
4 entries were displayed.

```

## storage aggregate relocation start

Relocate aggregates to the specified destination

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The storage aggregate relocation start command initiates the relocation of the aggregates from one node to the partner node in a high-availability (HA) pair.

### Parameters

**-node {<nodename>|local} - Name of the Node that currently owns the aggregate**

This specifies the source node where the aggregates to be relocated reside.

**-destination {<nodename>|local} - Destination node**

This specifies the destination node where aggregates are to be relocated.

**-aggregate-list <aggregate name>,... - List of Aggregates to be relocated**

This specifies the list of aggregate names to be relocated from source node to destination node.

**[-override-vetoes {true|false}] - Override Vetoes**

This specifies whether to override the veto checks for relocation operation. Initiating aggregate relocation with vetoes overridden will result in relocation proceeding even if the node detects outstanding issues that would make aggregate relocation dangerous or disruptive. The default value is false.

**[-relocate-to-higher-version {true|false}] - Relocate To Higher Version**

This specifies if the aggregates are to be relocated to a node which is running on a higher version of Data ONTAP than the source node. If an aggregate is relocated to this destination then that aggregate cannot be relocated back to the source node till the source is also upgraded to the same or higher Data ONTAP version. This option is not required if the destination node is running on higher minor version, but the same major version. The default value is false.

**[-override-destination-checks {true|false}] - Override Destination Checks**

This specifies if the relocation operation should override the check done on destination node. This option could be used to force a relocation of aggregates even if the destination has outstanding issues. Note that

this could make the relocation dangerous or disruptive. The default value is false.

#### **[-ndo-controller-upgrade {true|false}] - Relocate Aggregates for NDO Controller Upgrade (privilege: advanced)**

This specifies if the relocation operation is being done as a part of non-disruptive controller upgrade process. Aggregate relocation will not change the home ownerships of the aggregates while relocating as part of controller upgrade. The default value is false.

### **Examples**

The following example relocates aggregates name aggr1 and aggr2 from source node node0 to destination node node1:

```
cluster1::> storage aggregate relocation start -node node0 -destination
node1 -aggregate-list aggr1, aggr2
```

## **storage aggregate resynchronization modify**

### **Modify aggregate resynchronization priorities**

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The *storage aggregate resynchronization modify* command can be used to modify the resynchronization priority of an aggregate.

When the number of aggregates pending resynchronization is higher than the maximum number of concurrent resynchronization operations allowed on a node, the aggregates get resynchronized in the order of their "resync-priority" values.

For example, let the *max-concurrent-resync* under the *storage aggregate resynchronization* options directory for a node be set to two. If there are three aggregates waiting to be resynchronized, where their respective *resync-priority* values are *high*, *medium*, and *low*, then the third aggregate is not allowed to start resynchronization until one of the first two aggregates has completed resynchronizing.

### **Parameters**

#### **-aggregate <aggregate name> - Aggregate**

This parameter specifies the aggregate that is to be modified.

#### **[-resync-priority {high(fixed) | high|medium|low}] - Resynchronization Priority**

This parameter specifies the new resynchronization priority value for the specified aggregate. This field cannot be modified for unmirrored or Data ONTAP system aggregates.

Possible values for this parameter are:

- *high*: Mirrored data aggregates with this priority value start resynchronization first.
- *medium*: Mirrored data aggregates with this priority value start resynchronization after all the system aggregates and data aggregates with 'high' priority value have started resynchronization.

- low: Mirrored data aggregates with this priority value start resynchronization only after all the other aggregates have started resynchronization.

## Examples

The following example changes the `resync-priority` of a specified aggregate to `medium`:

```
cluster1::> storage aggregate resynchronization modify -aggregate aggr1
-resync-priority medium
```

## storage aggregate resynchronization show

Display aggregate resynchronization priorities

**Availability:** This command is available to *cluster* administrators at the `admin` privilege level.

### Description

The `storage aggregate resynchronization show` command displays the relative resynchronization priority for each aggregate in the cluster. When a particular node restricts how many resync operations can be active concurrently, these priorities are used to prioritize the operations. The maximum concurrent resync operations for a node is displayed in the [storage aggregate resynchronization options show](#) command. If no parameters are specified, the command displays the following information about all the aggregates in the cluster:

- Aggregate name
- Node that owns the aggregate
- Resync priority for the aggregate

### Parameters

{ [-fields <fieldname>, ...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-aggregate <aggregate name>] - Aggregate**

If this parameter is specified, the command displays the resynchronization priority only for the specified aggregate.

**[-node {<nodename>|local}] - Node**

If this parameter is specified, the command displays the resynchronization priority only for the aggregates owned by the specified node.

**[-resync-priority {high(fixed)|high|medium|low}] - Resynchronization Priority**

If this parameter is specified, the command displays only the resynchronization priority that matches the specified value. Possible values for this parameter are:

- **high(fixed)**: This value is reserved for Data ONTAP system aggregates, which cannot have any other value for this field. These aggregates always start their resynchronization operation at the first available opportunity. This value cannot be assigned to a data aggregate.
- **high**: Mirrored data aggregates with this priority value start resynchronization first.
- **medium**: Mirrored data aggregates with this priority value start resynchronization after all the system aggregates and data aggregates with 'high' priority value have started resynchronization.
- **low**: Mirrored data aggregates with this priority value start resynchronization only after all the other aggregates have started resynchronization.

When the number of aggregates waiting for resynchronization is higher than the maximum number of resynchronization operations allowed on a node, then the resync-priority field is used to determine which aggregate starts resynchronization first. This field is not set for unmirrored aggregates.

## Examples

The following command displays the resynchronization priorities for all the aggregates in the cluster:

```
cluster1::> storage aggregate resynchronization show
Aggregate Node          Resync Priority
-----
aggr0_n1    cluster1-01    high(fixed)
aggr0_n2    cluster1-02    high(fixed)
aggr1       cluster1-01    low
aggr2       cluster1-01    high
aggr3       cluster1-01    medium
4 entries were displayed.
```

## Related Links

- [storage aggregate resynchronization options show](#)

## storage aggregate resynchronization options modify

Modify node specific aggregate resynchronization options

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage aggregate resynchronization options modify` command can be used to modify the options that govern the resynchronization of aggregates on a given cluster node.

Modifying the `max-concurrent-resyncs` option changes the number of aggregates that are allowed to resynchronize concurrently. When the number of aggregates waiting for resynchronization is higher than this value, the aggregates are resynchronized in the order of their "resync-priority". This value can be modified using the [storage aggregate resynchronization modify](#) command while specifying the `-resync-priority` parameter.

## Parameters

### **-node {<nodename>|local} - Node**

This parameter specifies the node for which the option is to be modified.

### **[-max-concurrent-resync <integer>] - Maximum Concurrent Resynchronizing Aggregates**

This parameter specifies the new value for the maximum number of concurrent resync operations allowed on a node. This option must be specified along with the **-node** parameter. When a node has active resync operations, setting this parameter to a value that is lower than the number of currently resyncing aggregates will trigger a user confirmation.

## Examples

The following example changes the maximum concurrent resync operations for the specified node to ten :

```
cluster1::> storage aggregate resynchronization options modify -node node1  
-max-concurrent-resyncs 10
```

## Related Links

- [storage aggregate resynchronization modify](#)

## storage aggregate resynchronization options show

Display node specific aggregate resynchronization options

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The **storage aggregate resynchronization options show** command displays all the options that govern the resynchronization of aggregates on a given cluster node. If no parameters are specified, the command displays the following information about all nodes:

- Node for which the information is being displayed
- Maximum number of concurrent resynchronizing aggregates allowed

## Parameters

### { [-fields <fieldname>,...]

If you specify the **-fields <fieldname>,...** parameter, the command output also includes the specified field or fields. You can use **'-fields ?'** to display the fields to specify.

### | [-instance ] }

If you specify the **-instance** parameter, the command displays detailed information about all fields.

### **[-node {<nodename>|local}] - Node**

If this parameter is specified, the command displays resynchronization options only for the specified node.

## **[-max-concurrent-resync <integer>] - Maximum Concurrent Resynchronizing Aggregates**

If this parameter is specified, the command displays only the resynchronization option that matches the specified value.

### **Examples**

The following example displays the maximum number of concurrent resyncs allowed for each node in the cluster:

```
cluster1::> storage aggregate resynchronization options show
Node           Maximum Concurrent Resynchronizing Aggregates
-----
cluster1-01    15
cluster1-02    4
2 entries were displayed.
```

The following example displays the maximum number of concurrent resyncs allowed for a specified node:

```
cluster1::> storage aggregate resynchronization options show -node node1
Node           Maximum Concurrent Resynchronizing Aggregates
-----
cluster1-01    15
```

The following example displays all the nodes that allow more than five concurrent resync operations:

```
cluster1::> storage aggregate resynchronization options show -max
-concurrent-resyncs >5
Node           Maximum Concurrent Resynchronizing Aggregates
-----
cluster1-01    15
```

## **storage array commands**

### **storage array modify**

Make changes to an array's profile.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### **Description**

The `storage array modify` command lets the user change several array parameters.

## Parameters

### **-name <text>** - Name

Storage array name, either generated by Data ONTAP or assigned by the user.

### **[-prefix <text>]** - Prefix

Abbreviation for the named array.

### **[-vendor <text>]** - Vendor

Array manufacturer.

### **[-model <text>]** - Model

Array model number.

### **[-options <text>]** - options

Vendor specific array settings.

### **[-max-queue-depth <integer>]** - Target Port Queue Depth (privilege: advanced)

The target port queue depth for all target ports on this array.

### **[-lun-queue-depth <integer>]** - LUN Queue Depth (privilege: advanced)

The queue depth assigned to array LUNs from this array.

### **{ [-is-upgrade-pending {true|false}]}** - Upgrade Pending (privilege: advanced)

Set this parameter to *true* if the array requires additional Data ONTAP resilience for a pending firmware upgrade. Keep this parameter *false* during normal array operation. This value can not be set to *true* if -path-failover-time is greater than zero.

### **[-path-failover-time <integer>]** - Path Failover Time (sec)

The time delay (in secs) before switching the I/O path when the path is deleted. The maximum time delay is 30 sec. The default is 0. This value can not be greater than zero if -is-upgrade-pending is *true*.

### **[-all-path-fail-delay <integer>]** - Extend All Path Failure Event (secs)

Use this parameter to increase the delay before Data ONTAP declares an "all path failure" event for an array. Delaying the "all path failure" event allows Data ONTAP to suspend I/O operations for a longer period of time before declaring a data access disruption, allowing for I/O operations to resume if any path comes back online within the specified duration. A valid delay is any value between 30 and 90 seconds. A value of 0 will reset the delay, resulting in default actions being taken whenever an "all path failure" event is detected.

## Examples

This command changes the model to FastT.

```
cluster1::> storage array modify -name IBM_1722_1 -model FastT
```

## storage array remove

Remove a storage array record from the array profile database.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage array remove` command discards array profile records for a particular storage array from the cluster database. The command fails if a storage array is still connected to the cluster. Use the [storage array config show](#) command to view the array connectivity status. The array target port can be removed using the [storage array port remove](#) command.

## Parameters

### **-name <text>** - Name

Name of the storage array you want to remove from the database.

## Examples

```
cluster1::> storage array remove IBM_1722_1
```

## Related Links

- [storage array config show](#)
- [storage array port remove](#)

## storage array rename

Change the name of a storage array in the array profile database.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage array rename` command permits substitution of the array profile name which Data ONTAP assigned during device discovery. By default, the name that Data ONTAP assigned to the storage array during discovery is shown in Data ONTAP displays and command output.

## Parameters

### **-name <text>** - Name

Storage array name either generated by Data ONTAP or assigned by the user.

### **-new-name <text>** - The new name to assign to this array profile. (28 chars max)

New name to assign to the storage array.

## Examples

```
cluster1::> storage array rename -name HITACHI_DF600F_1 -new-name MyArray
```

## storage array show

Display information about SAN-attached storage arrays.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage array show` command displays information about arrays visible to the cluster. If no parameters are specified, the command displays the following information about all storage arrays:

- Prefix
- Name
- Vendor
- Model
- Options

To display detailed information about a single array, use the `'-name'` parameter. The detailed view adds the following information:

- Serial Number
- Optimization Policy
- Affinity
- Errors
- Path Failover Time
- Extend All Path Failure Event

### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-name <text>] - Name**

Selects the arrays that match this parameter value.

**[-prefix <text>] - Prefix**

Abbreviation for the named array.

**[-vendor <text>] - Vendor**

Array manufacturer.

**[-model <text>] - Model**

Array model number.

**[-options <text>] - options**

Vendor specific array settings.

**[-serial-number <text>] - Serial Number**

Array product identifier.

**[-max-queue-depth <integer>] - Target Port Queue Depth (privilege: advanced)**

Selects the arrays that match this parameter value.

**[-lun-queue-depth <integer>] - LUN Queue Depth (privilege: advanced)**

Selects the arrays that match this parameter value.

**[-optimization-policy {iALUA|eALUA|symmetric|proprietary|mixed|unknown}] - Optimization Policy**

Selects the arrays that match this parameter value.

**[-affinity {none|aaa|ap|mixed|unknown}] - Affinity**

Selects the arrays that match this parameter value.

**[-error-text <text>,...] - Error Text**

Selects the arrays that match this parameter value.

**[-is-upgrade-pending {true|false}] - Upgrade Pending (privilege: advanced)**

Selects the arrays that match this parameter value.

**[-path-failover-time <integer>] - Path Failover Time (sec)**

Use this parameter to list arrays that have path failover time set to the value you specify.

**[-all-path-fail-delay <integer>] - Extend All Path Failure Event (secs)**

Use this parameter to list arrays that have the all path failure event delay set to the value you specify.

## Examples

The following example displays information about all arrays.

```
cluster1::> storage array show
Prefix          Name      Vendor      Model Options
-----  -----
          HITACHI_DF600F_1  HITACHI      DF600F
          IBM_1722_1        IBM          1722
2 entries were displayed.
```

The following example displays detailed information about a specific array:

```
cluster1::> storage array show -name HITACHI_DF600F_1
Name: HITACHI_DF600F_1
                  Prefix: abc
                  Vendor: HITACHI
                  Model: DF600F
                  options:
                  Serial Number: 4291000000000000
Optimization Policy: iALUA
                  Affinity: aaa
                  Error Text:
Path Failover Timeout (sec): 30
Extend All Path Failure Event (secs): 50
```

## storage array config show

Display connectivity to back-end storage arrays.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage array config show` command displays information about how the storage arrays connect to the cluster, LUN groups, number of LUNS, and more. Use this command to validate the configuration and to assist in troubleshooting.

### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-switch ]

If you specify this parameter, switch port information is shown.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Controller Name**

Selects the arrays that match this parameter value.

**[-group <integer>] - LUN Group**

Selects the arrays that match this parameter value. A LUN group is a set of LUNs that shares the same path set.

**[-target-wwpn <text>] - Array Target Ports**

Selects the arrays that match this parameter value (the World Wide Port Name of a storage array port).

**[-initiator <text>] - Initiator**

Selects the arrays that match this parameter value (the host bus adapter that the clustered node uses to connect to storage arrays).

**[-array-name <array name>] - Array Name**

Selects the arrays that match this parameter value.

**[-target-side-switch-port <text>] - Target Side Switch Port**

Selects the arrays that match this parameter value.

**[-initiator-side-switch-port <text>] - Initiator Side Switch Port**

Selects the arrays that match this parameter value.

**[-lun-count <integer>] - Number of array LUNs**

Selects the arrays that match this parameter value.

**[-ownership {all|assigned|unassigned}] - Ownership**

Selects the arrays that match this parameter value.

## Examples

```
cluster1::> storage array config show
      LUN      LUN
      Node      Group Count      Array Name      Array Target
      Port Initiator
-----
-----
  vnv3070f19a      0      20      DGC_RAID5_1
  5006016030229f13      0d
  5006016130229f13      0c
  5006016830229f13      0b
  5006016930229f13      0a
      1      21      HITACHI_OPEN_1
  50060e80034fe704      0c
  0d
  50060e80034fe714      0a
  0b
  50060e80034fe715      0b
  50060e80034fe716      0c
```

0d  
2 8 EMC\_SYMMETRIX\_1  
50060482cb1bce1d 0a

0b  
5006048acb1bce0c 0c

0d  
3 10 IBM\_UniversalXport\_1  
202600a0b8322d10 0c

0d  
204700a0b8322d10 0a

0b  
vnv3070f19b 0 20 DGC\_RAID5\_1  
5006016030229f13 0d

5006016130229f13 0c

5006016830229f13 0b

5006016930229f13 0a  
1 21 HITACHI\_OPEN\_1  
50060e80034fe704 0c

0d  
50060e80034fe714 0a

0b  
50060e80034fe715 0b

50060e80034fe716 0c

0d  
2 8 EMC\_SYMMETRIX\_1  
50060482cb1bce1d 0a

0b  
5006048acb1bce0c 0c

```
0d
      3      10      IBM_UniversalXport_1
202600a0b8322d10      0c

0d
204700a0b8322d10      0a

0b
38 entries were displayed.

Warning: Configuration errors were detected.  Use 'storage errors show'
for detailed information.
```

## storage array disk paths show

Display a list of LUNs on the given array

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage array disk paths show` command displays information about disks and array LUNs. Where it appears in the remainder of this document, "disk" may refer to either a disk or an array LUN. By default, the command displays the following information about all disks:

- Disk Unique Identifier
- Controller name
- Initiator Port
- LUN ID
- Failover optimization type
- The Use State of the LUN on this path
- Target Port
- Target IQN
- TPGN
- Port speeds
- Kbytes/sec on Disk (Rolling Average)
- Number IOPS per second on disk (Rolling Average)

To display detailed information about a single disk, use the `-disk` parameter.

### Parameters

{ [-fields <fieldname>,...]

Displays the specified fields for all disks, in column style output.

| [-switch ]

Displays the switch port information for all disks, in column style output.

| [-instance ] }

Displays detailed disk information. If no disk path name is specified, this parameter displays the same detailed information for all disks as does the -disk parameter. If a disk path name is specified, then this parameter displays the same detailed information for the specified disks as does the -disk parameter.

#### **[-uid <text>] - Disk Unique Identifier**

Selects the disks whose unique id matches this parameter value. A disk unique identifier has the form:

`20000000:875D4C32:00000000:00000000:00000000:00000000:00000000:00000000:00000000

`

#### **[-disk <disk path name>] - Disk Name**

Displays detailed information about the specified disks.

#### **[-array-name <array name>] - Array Name**

Selects information about the LUNs presented by the specified storage array.

#### **[-diskpathnames <disk path name>,...] - Path-Based Disk Names**

Selects information about disks that have all of the specified path names.

#### **[-nodelist {<nodename>|local}] - Controller name**

Selects information about disks that are visible to all of the specified nodes .

#### **[-initiator <text>,...] - Initiator Port**

Selects information about disks that are visible to the initiator specified. Disks that are not currently in use by that initiator are included.

#### **[-lun <integer>,...] - LUN ID**

Selects information about the specified LUNs.

#### **[-target-wwpn <text>,...] - Target Port**

Selects information about disks that are visible on target ports identified by their World Wide Port Name.

#### **[-initiator-side-switch-port <text>,...] - Initiator Side Switch Port**

Selects information about disks visible to an initiator that is connected to the specified switch port.

#### **[-lun-path-use-state <text>,...] - The Use State of the LUN on this path**

Selects information about LUNs reporting the specified in-use state.

#### **[-tpgn <integer>,...] - Target Port Group Number**

Selects information about disks that belong to the specified Target Port Group Number.

#### **[-port-speed <text>,...] - Port Speed**

Selects information about disks served by a Host Bus Adapter that is running at the specified port speed.

**[-lun-io-kbps <integer>, ...] - Kbytes/sec on Disk (Rolling Average)**

Selects information about the LUNs that have reached the specified I/O throughput.

**[-lun-iops <integer>, ...] - Number IOPS per second on disk (Rolling Average)**

Selects information about the LUNs that have reached the specified number of IOPs.

**[-target-side-switch-port <text>, ...] - Target Side Switch Port**

Selects information about disks that are visible on target ports identified by the switch port to which they are connected.

**[-target-port-access-state <text>, ...] - Failover optimization type**

Selects information about disks visible on target ports that have the specified access state.

**[-initiator-io-kbps <integer>, ...] - Kbytes of I/O per second on Initiator (Rolling Average)**

Selects information about disks visible to an initiator that has executed I/O at the specified throughput.

**[-initiator-iops <integer>, ...] - Number of IOPS on Initiator (Rolling Average)**

Selects information about disks visible to an initiator that has executed the specified number of IOPs.

**[-target-io-kbps <integer>, ...] - Kbytes of I/O per second to Target (Rolling Average)**

Selects information about disks visible on target ports that have reached the specified I/O throughput.

**[-target-iops <integer>, ...] - Number of IOPS to Target (Rolling Average)**

Selects information about disks visible on target ports that have performed the specified number of IOPs.

**[-path-link-errors <integer>, ...] - Link Error count on path**

Selects information about disks with paths that have incurred the specified number of FC link errors.

**[-path-io-kbps <integer>, ...] - Kbytes of I/O per second on Path (Rolling Average)**

Selects information about disk with paths that have reached the specified I/O throughput.

**[-path-iops <integer>, ...] - Number of IOPS on Path (Rolling Average)**

Selects information about disks on those paths that have reached the specified number of IOPs.

**[-path-quality <integer>, ...] - Percentage of weighted error threshold**

Selects information about disks on paths that have incurred the specified number of errors. The value displayed is a measure of the health of a path expressed as a percentage of an error threshold. Once a path has reached or surpassed the error threshold, another path will be selected for I/O transfer, if there is one available.

**[-path-lun-in-use-count <integer>, ...] - Number of LUNs in the in-use state on this path**

Selects information about disks with paths that have the specified in-use-count.

**[-initiator-lun-in-use-count <integer>, ...] - Number of LUNs in the in-use state on this initiator**

Selects information about disks with a path through an initiator that has the specified in-use-count.

**[-target-lun-in-use-count <integer>, ...] - Number of LUNs in the in-use state on this target**

Selects information about disks with a path through a target port that has the specified in-use-count.

**[-preferred-target-port {true|false}] - Whether or not target port group is preferred**

Selects information about disks that match the specified parameter value indicating whether the backing storage is ALUA (Assymetric Logical Unit Access) capable and has specified the array target port on this path to be a preferred target port for I/O.

**[-vmdisk-device-id <integer>,...] - Virtual disk device ID**

Selects information about disks that have the specified virtual disk device ID.

**[-host-adapter <text>] - Primary Path Host Adapter**

Selects information about disks that are currently using the specified Host Bus Adapter.

**[-primary-port <text>] - Primary Path Disk Port**

Selects information about disks that use the specified primary port.

**[-secondary-name <disk path name>] - Secondary Path Name**

Selects information about disks that use the specified secondary path name, for multipath configuration.

**[-secondary-port <text>] - Secondary Path Disk Port**

Selects information about disks that use the specified secondary port.

## Examples

The following example displays information about all disks:

```
cluster1::> storage array disk paths show
Disk Name: 1.0.20
UID:
5000C500:0979E09F:00000000:00000000:00000000:00000000:00000000:00
00000:00000000
                                         LUN
Link      Disk I/O
Controller      Initiator      ID  Acc  Use  Target Port
TPGN      Speed          (KB/s)      IOPS
node2          3a            0   AO   INU  5000c5000979e09d
80      9 Gb/S          0
node2          3c            0   AO   RDY  5000c5000979e09e
12      9 Gb/S          0
node1          3a            0   AO   RDY  5000c5000979e09e
12      9 Gb/S          0
node1          3c            0   AO   INU  5000c5000979e09d
80      9 Gb/S          0
                                         LUN
Disk Name: 1.0.22
UID:
5000C500:0979E3C3:00000000:00000000:00000000:00000000:00000000:00
00000:00000000
Link      Disk I/O
```



## storage array port modify

Make changes to a target port record.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The storage array port modify command lets the user change array target port parameters.

### Parameters

#### **-name <text>** - Name

Selects the array ports that match this parameter value. The storage array name is either generated by Data ONTAP or assigned by the user.

#### **-wwnn <text>** - WWNN

Selects the array ports that match this parameter value.

#### **-wwpn <text>** - WWPN

Selects the array ports that match this parameter value.

#### **[-max-queue-depth <integer>]** - Target Port Queue Depth

The target port queue depth for this target port.

#### **[-utilization-policy {normal|defer}]** - Utilization Policy

The policy used in automatically adjusting the queue depth of the target port based on its utilization.

### Examples

This command changes the maximum queue depth for this target port to 32.

```
cluster1::> storage array port modify -name HITACHI_DF600F_1 -wwnn  
50060e80004291c0 -wwpn 50060e80004291c0 -max-queue-depth 32
```

## storage array port remove

Remove a port record from an array profile.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The storage array port remove command removes a port from the array database. You might want to remove ports that are no longer connected to the clustered node. Port information can change after hardware replacement, rezoning, or similar configuration activities. The database retains the records about previous ports unless you remove the information.

## Parameters

### **-name <text> - Name**

Selects the array ports that match this parameter value. The storage array name is either generated by Data ONTAP or assigned by the user.

### **{ [-wwnn <text>] - WWNN**

Selects the array ports that match this parameter value.

### **[-wwpn <text>] - WWPN**

Selects the array ports that match this parameter value.

### **| [-target-iqn <text>] - Target IQN**

Selects the array ports that match this parameter value.

### **[-tpgt <integer>] - TPGT }**

Selects the array ports that match this parameter value.

## Examples

This command removes a port record from the array profiles database.

```
cluster1::> storage array port remove -name HITACHI_DF600F_1 -wwnn  
50060e80004291c0 -wwpn 50060e80004291c0
```

## storage array port show

Display information about a storage array's target ports.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage array port show` command displays all the target ports known to the cluster for a given storage array (if an array name is specified) or for all storage arrays if no storage array name is specified. Target ports remain in the database as part of an array profile unless you explicitly remove them from the database.

## Parameters

### **{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

### **| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

### **[-name <text>] - Name**

Selects the array ports that match this parameter value. The storage array name is either generated by

Data ONTAP or assigned by the user.

**[-wwnn <text>] - WWNN**

Selects the array ports that match this parameter value.

**[-wwpn <text>] - WWPN**

Selects the array ports that match this parameter value.

**[-max-queue-depth <integer>] - Target Port Queue Depth**

Selects the array ports that match this parameter value.

**[-node {<nodename>|local}] - Controller Name**

Selects the array ports that match this parameter value.

**[-initiator-port <text>, ...] - Initiator Port**

Selects the array ports that match this parameter value.

**[-average-dynamic-queue-depth <integer>, ...] - Average Dynamic Queue Depth (privilege: advanced)**

The average value of the dynamic target port queue depth.

**[-average-latency-per-iop <integer>, ...] - Average Latency Per IOP**

Selects the array ports that match this parameter value (average latency per I/O performed in microseconds).

**[-average-pending <integer>, ...] - Average Pending (privilege: advanced)**

Selects the array ports that match this parameter value (average over time of how many commands are on the outstanding queue).

**[-average-waiting <integer>, ...] - Average Waiting (privilege: advanced)**

Selects the array ports that match this parameter value (average over time of how many commands are on the waiting queue).

**[-connection-type {direct|fabric|ISCSI}] - Connection Type**

Selects the array ports that match this parameter value (type of connection between the controller and the back end storage).

**[-dynamic-queue-depth <integer>, ...] - Dynamic Queue Depth (privilege: advanced)**

Current dynamic target port queue depth, the maximum number of commands allowed outstanding.

**[-max-pending <integer>, ...] - Max Pending (privilege: advanced)**

Selects the array ports that match this parameter value (largest number of commands observed on the outstanding queue).

**[-max-waiting <integer>, ...] - Max Waiting (privilege: advanced)**

Selects the array ports that match this parameter value (largest number of commands observed on the waiting queue).

**[-path-link-errors <integer>, ...] - Link Error count on path**

Selects the array ports that match this parameter value.

**[-percent-busy <integer>, ...] - Percent Busy**

Selects the array ports that match this parameter value (percentage of time I/Os are outstanding on the port).

**[-percent-waiting <integer>, ...] - Percent Waiting**

Selects the array ports that match this parameter value (percentage of time there are I/Os waiting on the throttle list on the target port).

**[-switch-port <text>] - Switch Port**

Selects the array ports that match this parameter value (for fabric attached connections, the switch port the array target port is connected to; N/A for direct attached).

**[-target-io-kbps <integer>, ...] - Kbytes of I/O per second to Target (Rolling Average)**

Selects the array ports that match this parameter value.

**[-target-iops <integer>, ...] - Number of IOPS to Target (Rolling Average)**

Selects the array ports that match this parameter value.

**[-target-lun-in-use-count <integer>, ...] - Target LUN In Use Count**

Selects the array ports that match this parameter value (number of IN-USE disks on this target port).

**[-target-port-speed <text>] - Target Port Speed**

Selects the array ports that match this parameter value (speed that the target port has negotiated with its connected switch port, or initiator port if direct attached).

**[-utilization-policy {normal|defer}] - Utilization Policy**

The policy used when sending I/O to an array target port when it reaches maximum queue depth. Possible values are:

- normal - This policy aggressively competes for target port resources, in effect competing with other hosts. (default)
- defer - This policy does not aggressively compete for target port resources, in effect deferring to other hosts.

## Examples

The example below displays the port information for a single port.

```

cluster1::> storage array port show -wwpn 50060e80004291c0
Array Name: HITACHI_DF600F_1
WWNN: 50060e80004291c0
WWPN: 50060e80004291c0
Connection Type: fabric
Switch Port: vgbr300s89:9
Link Speed: 4 GB/s
Max Queue Depth: 1024
Utilization Policy: normal

LUN

Link
Node          Initiator  Count   IOPS   KB/s   %busy   %waiting
Errs

-----
--v
0          vnv3070f20a    0b      2       0       0       0       0
0          vnv3070f20b    0b      2       0       0       0       0
0

```

## storage automated-working-set-analyzer commands

### storage automated-working-set-analyzer show

Display running instances

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

#### Description

The automated-working-set-analyzer show command displays the Automated Working-set Analyzer running instances.

#### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `-fields ?` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

#### [-node <nodename>] - Node Name (privilege: advanced)

This parameter indicates the node name that the AWA instance runs on.

**[-flash-cache {true|false}] - Flash Cache Node-wide Modeling (privilege: advanced)**

This parameter indicates whether the AWA is modeling flash-cache.

**[-aggregate-uuid <UUID>] - Uuid of the Aggregate (privilege: advanced)**

This parameter indicates the aggregate uuid that the AWA instance runs on.

**[-aggregate <aggregate name>] - Aggregate (privilege: advanced)**

This parameter indicates the aggregate name that the AWA instance runs on.

**[-working-set-size {true|false}] - Working Set Size (privilege: advanced)**

This parameter indicates whether the AWA instance is configured to find the working set size.

**[-start-time <Date>] - Starting Time (privilege: advanced)**

This parameter indicates the time when the AWA instance was started.

**[-total-intervals <integer>] - Total Interval Count (privilege: advanced)**

This parameter indicates the total number of intervals that the AWA instance has covered.

**[-read-throughput {<integer>[Bps|KBps|MBps|GBps]}] - Read Throughput (privilege: advanced)**

This parameter indicates the maximum read throughput over an interval that AWA has observed from the storage disks.

**[-write-throughput {<integer>[Bps|KBps|MBps|GBps]}] - Write Throughput (privilege: advanced)**

This parameter indicates the maximum write throughput over an interval that AWA has observed to the storage disks

**[-cacheable-read <percent>] - Cacheable Read (privilege: advanced)**

This parameter indicates the maximum percent of cacheable read over an interval that AWA has observed. Cacheable reads are non-sequential reads, i.e., the percentage of data reads that could have been cached.

**[-cacheable-write <percent>] - Cacheable Write (privilege: advanced)**

This parameter indicates the maximum percent of cacheable write over an interval that AWA has observed. Cacheable writes are random overwrites, percentage of disk writes that could have been cached.

**[-projected-cache-size {<integer>[KB|MB|GB|TB|PB]}] - Max Projected Cache Size (privilege: advanced)**

This parameter indicates the projected Flash Pool cache usage.

**[-projected-read-hit <percent>] - Projected Read Hit (privilege: advanced)**

This parameter indicates the percentage of blocks that could be read from the Flash Pool cache instead of HDDs.

**[-projected-write-hit <percent>] - Projected Write Hit (privilege: advanced)**

This parameter indicates the percentage of block overwrites that could go to the Flash Pool cache instead of HDDs.

**[-referenced-interval-id <integer>] - Referenced Interval ID (privilege: advanced)**

This parameter indicates the interval in which the cache size effect information is derived from.

**[-referenced-interval-time <Date>] - Referenced Interval Time (privilege: advanced)**

This parameter indicates the time when the referenced interval for the cache size effect information is derived from.

**[-referenced-interval-cache-size {<integer>[KB|MB|GB|TB|PB]}] - Referenced Interval Cache Size (privilege: advanced)**

This parameter indicates the cache size at the end of the referenced interval from which the cache size effect information is based on.

**[-read-hit-20 <percent>] - 20% Cache Read Hit (privilege: advanced)**

This parameter indicates the predicted read hit rate when the cache size is 20% of the referenced cache size.

**[-read-hit-40 <percent>] - 40% Cache Read Hit (privilege: advanced)**

This parameter indicates the predicted read hit rate when the cache size is 40% of the referenced cache size.

**[-read-hit-60 <percent>] - 60% Cache Read Hit (privilege: advanced)**

This parameter indicates the predicted read hit rate when the cache size is 60% of the referenced cache size.

**[-read-hit-80 <percent>] - 80% Cache Read Hit (privilege: advanced)**

This parameter indicates the predicted read hit rate when the cache size is 80% of the referenced cache size.

**[-read-hit-100 <percent>] - 100% Cache Read Hit (privilege: advanced)**

This parameter indicates the predicted read hit rate when the cache size is 100% of the referenced cache size.

**[-write-hit-20 <percent>] - 20% Cache Write Hit (privilege: advanced)**

This parameter indicates the predicted write hit rate when the cache size is 20% of the referenced cache size.

**[-write-hit-40 <percent>] - 40% Cache Write Hit (privilege: advanced)**

This parameter indicates the predicted writehit rate when the cache size is 40% of the referenced cache size.

**[-write-hit-60 <percent>] - 60% Cache Write Hit (privilege: advanced)**

This parameter indicates the predicted write hit rate when the cache size is 60% of the referenced cache size.

**[-write-hit-80 <percent>] - 80% Cache Write Hit (privilege: advanced)**

This parameter indicates the predicted write hit rate when the cache size is 80% of the referenced cache size.

**[-write-hit-100 <percent>] - 100% Cache Write Hit (privilege: advanced)**

This parameter indicates the predicted write hit rate when the cache size is 100% of the referenced cache

size.

#### **[-num-intervals-show <integer>] - Number of intervals to show (privilege: advanced)**

This parameter indicates the number of intervals to the past this command is showing.

### **Examples**

The following example shows a running instance of automated-working-set-analyzer on node *node1* for aggregate *aggr0*.

```
cluster1::> cluster-1::*> storage automated-working-set-analyzer show
Node          FC      Aggregate      wss      Intervals Start Time
-----  -----  -----  -----  -----
-----  -----
node1          false  aggr0          false      125  Wed Jul 22 13:58:17
2015
```

## **storage automated-working-set-analyzer start**

Command to start Automated Working Set Analyzer on node or aggregate

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### **Description**

The automated-working-set-analyzer start command enables the Automated Workload Analyzer that is capable of doing the following:

- Flash Pool modeling for an aggregate
- Flash Cache modeling for a node - can not specify an aggregate.
- Working set size estimation
- Workload monitoring

### **Parameters**

#### **-node <nodename> - Node Name (privilege: advanced)**

This parameter indicates the node name that the AWA instance runs on.

#### **[-flash-cache {true|false}] - Flash Cache Node-wide Modeling (privilege: advanced)**

This parameter indicates whether the AWA is modeling flash-cache.

#### **[-aggregate <aggregate name>] - Aggregate (privilege: advanced)**

This parameter indicates the aggregate name that the AWA instance runs on.

#### **[-working-set-size {true|false}] - Working Set Size (privilege: advanced)**

This parameter indicates whether the AWA instance is configured to find the working set size.

## Examples

```
cluster1::> storage automated-working-set-analyzer start -node vsim1  
-aggregate aggr0
```

## storage automated-working-set-analyzer stop

Command to stop Automated Working Set Analyzer on node or aggregate

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The storage automated-working-set-analyzer stop command terminates one or multiple Automated Workload Analyzer running instances.

### Parameters

#### **-node <nodename> - Node Name (privilege: advanced)**

This parameter indicates the node name that the AWA instance runs on.

#### **[-flash-cache {true|false}] - Flash cache node-wide modeling (privilege: advanced)**

This parameter indicates whether the AWA is modeling flash-cache.

#### **[-aggregate <aggregate name>] - Aggregate (privilege: advanced)**

This parameter indicates the aggregate name that the AWA instance runs on.

## Examples

```
cluster1::> storage automated-working-set-analyzer stop -node vsim1  
-aggregate aggr1
```

## storage automated-working-set-analyzer volume show

Displays the Automated Working Set Analyzer volume table

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The automated-working-set-analyzer volume show command displays the volume statistics reported by the corresponding Automated Working-set Analyzer running instances.

### Parameters

#### **{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**[ [-instance ] ]**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[ -node <nodename> ] - Node (privilege: advanced)**

This parameter indicates the node name that the AWA instance runs on.

**[ -flash-cache {true|false} ] - Flash Cache Node-wide Modeling (privilege: advanced)**

This parameter indicates whether the AWA is modeling flash-cache.

**[ -vol-uuid <UUID> ] - Uuid of the Volume (privilege: advanced)**

This parameter indicates the volume uuid that this command is issued on.

**[ -aggregate <aggregate name> ] - Aggregate (privilege: advanced)**

This parameter indicates the aggregate name that the AWA instance runs on.

**[ -volume <volume name> ] - Volume (privilege: advanced)**

This parameter indicates the volume name that this command is issued on.

**[ -rank <integer> ] - Cache Benefit Rank (privilege: advanced)**

This parameter indicates the rank of this volume among all volumes that would be most benefited by the modeled cache technology based on the AWA prediction.

**[ -read-throughput {<integer>[Bps|KBps|MBps|GBps]} ] - Read Throughput (privilege: advanced)**

This parameter indicates the maximum read throughput over an interval that AWA has observed from the storage disks for this volume.

**[ -write-throughput {<integer>[Bps|KBps|MBps|GBps]} ] - Write Throughput (privilege: advanced)**

This parameter indicates the maximum write throughput over an interval that AWA has observed to the storage disks for this volume.

**[ -cacheable-read <percent> ] - Cacheable Read (privilege: advanced)**

This parameter indicates the maximum percent of cacheable read over an interval that AWA has observed for this volume. Cacheable reads are non-sequential reads, i.e., the percentage of data reads that could have been cached.

**[ -cacheable-write <percent> ] - Cacheable Write (privilege: advanced)**

This parameter indicates the maximum percent of cacheable write over an interval that AWA has observed. Cacheable writes are random overwrites, percentage of disk writes that could have been cached.

**[ -projected-cache-size {<integer>[KB|MB|GB|TB|PB]} ] - Max Projected Cache Size (privilege: advanced)**

This parameter indicates the projected Flash Pool cache usage by this volume.

**[ -projected-read-hit <percent> ] - Projected Read Hit (privilege: advanced)**

This parameter indicates the percentage of blocks that could be read from the Flash Pool cache instead of HDDs for this volume.

**[-projected-write-hit <percent>] - Projected Write Hit (privilege: advanced)**

This parameter indicates the percentage of block overwrites that could go to the Flash Pool cache instead of HDDs for this volume.

**[-num-intervals-show <integer>] - Number of intervals to show (privilege: advanced)**

This parameter indicates the number of intervals to the past this command is showing.

**Examples**

```
cluster1::> cluster-1::*> storage automated-working-set-analyzer volume
show
Node          FC      Aggregate    Volume      Rank  Read Thrupt Write
Thrupt
-----
-----
vsim1        false aggr0        vol0          1    230.47KBps
580.09KBps
```

## storage disk commands

### storage disk assign

Assign ownership of a disk to a system

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The *storage disk assign* command is used to assign ownership of an unowned disk or array LUN to a specific node. You can also use this command to change the ownership of a disk or an array LUN to another node. You can designate disk ownership by specifying disk names, array LUN names, wildcards, or all (for all disks or array LUNs visible to the node). For disks, you can also set up disk ownership autoassignment. You can also assign disks to a particular pool. You can also assign disks by copying ownership from another disk.

#### Parameters

**{ [-disk <disk path name>] - Disk Path**

This specifies the disk or array LUN that is to be assigned. Disk names take one of the following forms:

- Disks are named in the form *<stack-id>.<shelf>.<bay>*
- Disks on multi-disk carriers are named in the form *<stack-id>.<shelf>.<bay>.<lun>*
- Virtual disks are named in the form *<prefix>.<number>*, where prefix is the storage array's prefix and number is a unique ascending number.

Disk names take one of the following forms on clusters that are not yet fully upgraded to Data ONTAP 8.3:

- Disks that are not attached to a switch are named in the form *<node>:<host\_adapter>.<loop\_ID>*. For disks with a LUN, the form is *<node>:<host\_adapter>.<loop\_ID>L<LUN>*. For instance,

disk number 16 on host adapter 1a on a node named node0a is named node0a:1a.16. The same disk on LUN lun0 is named node0a:1a.16Llun0.

- Disks that are attached to a switch are named in the form `<node>:<switch_name>:<switch_port>.<loop_ID>`. For disks with a LUN, the form is `<node>:<switch_name>:<switch_port>.<loop_ID>L<LUN>`. For instance, disk number 08 on port 11 of switch fc1 on a node named node0a is named node0a:fc1:11.08. The same disk on LUN lun1 is named node0a:fc1:11.08Llun1.

Before the cluster is upgraded to Data ONTAP 8.3, the same disk can have multiple disk names, depending on how the disk is connected. For example, a disk known to a node named alpha as alpha:1a.19 can be known to a node named beta as beta:0b.37. All names are listed in the output of queries and are equally valid. To determine a disk's unique identity, run a detailed query and look for the disk's universal unique identifier (UUID) or serial number.

A subset of disks or array LUNs can be assigned using the wildcard character (\*) in the `-disk` parameter. Either the `-owner`, the `-sysid`, or the `-copy-ownership-from` parameter must be specified with the `-disk` parameter. Do not use the `-node` parameter with the `-disk` parameter.

#### | **-disklist <disk path name>,...** - Disk list

This specifies the List of disks to be assigned.

#### | **-all <true>** - Assign All Disks

This optional parameter causes assignment of all visible unowned disks or array LUNs to the node specified in the `-node` parameter. The `-node` parameter must be specified with the `-all` parameter. When the `-copy-ownership-from` parameter is specified with the `-node` parameter, it assigns disk ownership based on the `-copy-ownership-from` parameter; otherwise it assigns ownership of the disks based on the `-node` parameter. Do not use the `-owner` or the `-sysid` parameter with the `-all` parameter.

#### | **[-T, -type {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}]** - Storage Type

This optional parameter assigns ownership of a specific type of disk or array LUN (or a set of disks/array LUNs) to a node. The `-count` parameter must be specified with the `-type` parameter.

#### **-n, -count <integer>** - Disk Count

This optional parameter assigns ownership of a number of disks or array LUNs specified in the `-count` parameter, to a node.

#### | **-auto <true>** - Auto Assign }

This optional parameter causes all visible disks eligible for autoassignment to be immediately assigned to the node specified in the `-node` parameter, regardless of the setting of the `disk.auto_assign` option. Only unowned disks on loops or stacks owned wholly by that system and which have the same pool information will be assigned. The `-node` parameter must be specified with the `-auto` parameter. Do not use the `-owner`, the `-sysid`, or the `-copy-ownership-from` parameter with the `-auto` parameter. When possible, use the `-auto` parameter rather than the `-all` parameter to conform to disk ownership best practices. The `-auto` parameter is ignored for array LUNs.

#### **[-p, -pool <integer>]** - Pool

This optional parameter specifies the pool to which a disk must be assigned. It can take values of "0" or "1".

#### { **[-o, -owner <nodename>]** - Owner Name

This optional parameter specifies the node to which the disk or array LUN has to be assigned.

**[-s, -sysid <nvramid>] - New Owner ID**

This optional parameter specifies the serial number (NVRAM ID) of the node to which the disk or array LUN has to be assigned.

**| [-copy-ownership-from <disk path name>] - Disk Name to Copy Ownership }**

This optional parameter specifies the disk name from where the node needs to copy disk ownership information. You can use this parameter for disks to have the same ownership as the provided input disk.

**[-c, -checksum {block|zoned|advanced\_zoned}] - Checksum Compatibility**

This optional parameter is used to set the checksum type for a disk or an array LUN. The possible values are *block*, *zoned*, and *advanced\_zoned*. This operation will fail if the specified disk is incompatible with the specified checksum type. A newly created aggregate with zoned checksum array LUNs is assigned advanced zoned checksum (AZCS) checksum type. AZCS checksum type provides more functionality than the "version 1" zoned checksum type which has been supported in previous Data ONTAP releases. Zoned checksum spare array LUNs added to an existing zoned checksum aggregate continue to be zoned checksum. Zoned checksum spare array LUNs added to an AZCS checksum type aggregate use the AZCS checksum scheme for managing checksums. For some disks (e.g. FCAL, SSD, SAS disks), the checksum type cannot be modified. For more information on modifying the checksum type, refer to the "Physical Storage Management Guide".

**[-f, -force <true>] - Force Flag**

This optional parameter forces the assignment of ownership of an already owned disk to a node. This parameter could also be used to assign an array LUN with a redundancy error, for example, if the array LUN is available on only one path. For a disk which is part of a live aggregate, even specification of the *-force* parameter would not force the assignment, since it would be catastrophic.

**[-N, -node <nodename>] - Node Name (For Auto Assign)**

This optional parameter is used with either the *-auto* or the *-all* parameter. If used with the *-auto* parameter, all disks which are visible to the node specified in the *-node* parameter and which are eligible for autoassignment would be assigned to it. If used with the *-all* parameter, all unowned disks or array LUNs visible to the node would be assigned to it.

**{ [-root <true>] - Root Partition of Root-Data or Root-Data1-Data2 Partitioned Disk (privilege: advanced)}**

This optional parameter assigns the root partition of a root-data/root-data1-data2 partitioned disk. You cannot use this parameter with disks that are part of a storage pool. The default value is *false*.

**| [-data <true>] - Data Partition of Root-Data Partitioned Disk (privilege: advanced)**

This optional parameter assigns the data partition of a root-data partitioned disk. You cannot use this parameter with disks that are part of a storage pool. The default value is *false*.

**| [-data1 <true>] - Data1 Partition of Root-Data1-Data2 Partitioned Disk (privilege: advanced)**

This optional parameter assigns the data1 partition of a root-data1-data2 partitioned disk. You cannot use this parameter with disks that are part of a storage pool. The default value is *false*.

**| [-data2 <true>] - Data2 Partition of Root-Data1-Data2 Partitioned Disk (privilege: advanced) }**

This optional parameter assigns the data2 partition of a root-data1-data2 partitioned disk. You cannot use this parameter with disks that are part of a storage pool. The default value is *false*.

## Examples

The following example assigns ownership of an unowned disk named ``\_1\_`` . ``\_1\_`` . ``\_16\_`` to a node named ``\_node1\_`` :

```
cluster1::> storage disk assign -disk 1.1.16 -owner node1
```

The following example assigns all unowned disks or array LUNs visible to a node named *node1* to itself:

```
cluster1::> storage disk assign -all -node node1
```

The following example autoassigns all unowned disks (eligible for autoassignment) visible to a node named *node1* to itself:

```
cluster1::> storage disk assign -auto -node node1
```

The following two examples show the working of the **-force** parameter with a spare disk that is already owned by another system:

```
cluster1::> storage disk assign -disk 1.1.16 -owner node1
Error: command failed: Failed to assign disks. Reason: Disk 1.1.16 is
already owned.
```

```
cluster1::> storage disk assign -disk 1.1.16 -owner node1 -force
Success.
```

The following example assigns ownership of the set of unowned disks on *<stack> 1* , to a node named *node1* :

```
cluster1::> storage disk assign -disk 1.* -owner node1
```

The following example assigns ownership of unowned disk *1.1.16* by copying ownership from disk *1.1.18* :

```
cluster1::> storage disk assign -disk 1.1.16
-copystatus-from 1.1.18
```

The following example assigns all unowned disks visible to a node named ``\_node1\_`` by copying ownership from disk ``\_1\_`` .``\_1\_`` .``\_18\_`` :

```
cluster1::> storage disk assign -all -node node1  
-copy-ownership-from 1.1.18
```

## storage disk fail

Fail the file system disk

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The *storage disk fail* command can be used to manually force a file system disk to fail. It is used to remove a file system disk that may be logging excessive errors and requires replacement. To unfail a disk, use the [storage disk unfail](#) command.

### Parameters

**-disk <disk path name> - Disk Name**

This parameter specifies the disk to be failed.

**[-i, -immediate <true>] - Fail immediately**

This parameter optionally specifies whether the disk is to be failed immediately. It is used to avoid Rapid RAID Recovery and remove the disk from the RAID configuration immediately. Note that when a file system disk has been removed in this manner, the RAID group to which the disk belongs enters degraded mode (meaning a disk is missing from the RAID group). If a suitable spare disk is available, the contents of the disk being removed are reconstructed onto that spare disk.

### Examples

The following example fails a disk named 1.1.16 immediately:

```
cluster1::> storage disk fail -disk 1.1.16 -i true  
WARNING: The system will not prefail the disk and its contents will not be  
copied to a replacement disk before being failed out. Do you want to  
fail out the disk immediately? {y|n}: y
```

### Related Links

- [storage disk unfail](#)

## storage disk reassign

(DEPRECATED)-Change the default owner of all disks from one node to another

**Availability:** This command is available to *cluster* administrators at the **advanced** privilege level.

## Description

The `storage disk reassign` is deprecated and may be removed in a future release of Data ONTAP. Disk reassignment is no longer required as part of a controller replacement procedure. For further information, see the latest controller or NVRAM FRU replacement flyer for your system. This command changes the ownership of all disks on a node to the ownership of another node. Use this command only when a node has a complete failure (for instance, a motherboard failure) and is replaced by another node. If the node's disks have already been taken over by its storage failover partner, use the `-force` parameter.

## Parameters

**`-s, -homeid <nvramid>` - Current Home ID (privilege: advanced)**

This specifies the serial number of the failed node.

**`-d, -newhomeid <nvramid>` - New Home ID (privilege: advanced)**

This specifies the serial number of the node that is to take ownership of the failed node's disks.

**`[-f, -force <true>]` - Force (privilege: advanced)**

This optionally specifies whether to force the reassignment operation. The default setting is `false`.

## Examples

In the following example, a node named `node0` and having serial number `12345678` has failed. Its disks have not been taken over by its storage failover partner. A replacement node with serial number `23456789` was installed and connected to `node0`'s disk shelves. To assign `node0`'s disks to the new node, start the new node and run the following command:

```
cluster::*> storage disk reassign -homeid 12345678 -newhomeid 23456789
node0's disks 1.1.11, 1.1.12, 1.1.13, 1.1.14, 1.1.15, 1.1.16, 1.1.23 and
1.1.24
were reassigned to new owner with serial number 23456789.
```

In the following example, a similar failure has occurred, except that `node0`'s disks have been taken over by its storage failover partner, `node1`. A new node with serial number `23456789` has been installed and configured. To assign the disks that previously belonged to `node0` to this new node, run the following command:

```
cluster::*> storage disk reassign -homeid 12345678 -newhomeid 23456789
-force true
node0's disks 1.1.11, 1.1.12, 1.1.13, 1.1.14, 1.1.15, 1.1.16, 1.1.23 and
1.1.24
were reassigned to new owner with serial number 23456789.
```

## storage disk refresh-ownership

Refresh the disk ownership information on a node

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

This command updates the disk ownership information for all the disks attached to a node to the latest view for all the nodes in the cluster. During normal operations, disk ownership is kept up to date automatically. In certain circumstances, however, disk ownership must be updated manually. If this is required, EMS messages will indicate that this command should be run. If the *-node* parameter is provided, the disk ownership information is updated only on the node specified.

## Parameters

**[-node {<nodename>|local}] - Node (privilege: advanced)**

If this parameter is provided, the disk ownership information is updated only on the node specified.

## Examples

The following example refreshes the disk ownership information for all the nodes in the cluster:

```
cluster1::> storage disk refresh-ownership
```

## storage disk remove-reservation

Removes reservation from an array LUN marked as foreign.

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The *storage disk remove-reservation* command removes persistent reservation from a specified foreign array LUN.

## Parameters

**-disk <disk path name> - Disk Name (privilege: advanced)**

This specifies the disk from which persistent reservation is to be removed.

## Examples

The following example removes the persistent reservation from a disk named *node1:switch01:port.126L1*.

```
cluster1::> storage disk remove-reservation -disk
node1:switch01:port.126L1
```

## storage disk remove

Remove a spare disk

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage disk remove` command removes the specified spare disk from the RAID configuration, spinning the disk down when removal is complete.

This command does not remove disk ownership information from the disk. Therefore, if you plan to reuse the disk in a different storage system, you should use the [storage disk removeowner](#) command instead. See the "Physical Storage Management Guide" for the complete procedure.



For systems with multi-disk carriers, it is important to ensure that none of the disks in the carrier are filesystem disks before attempting removal. To convert a filesystem disk to a spare disk, see [storage disk replace](#).

## Parameters

### **-disk <disk path name>** - Disk Name

This parameter specifies the disk to be removed.

## Examples

The following example removes a spare disk named 1.1.16:

```
cluster1::> storage disk remove -disk 1.1.16
```

## Related Links

- [storage disk removeowner](#)
- [storage disk replace](#)

## **storage disk removeowner**

### Remove disk ownership

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage disk removeowner` command removes ownership from a specified disk. Then disk can then be reassigned to a new owner.

## Parameters

### **-disk <disk path name>** - Disk Name

This specifies the disk whose ownership is to be removed.

## Examples

The following example removes the ownership from a disk named 1.1.27.

```
cluster1::> storage disk removeowner -disk 1.1.27
```

## storage disk replace

Initiate or stop replacing a file-system disk

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage disk replace` command starts or stops the replacement of a file system disk with spare disk. When you start a replacement, Rapid RAID Recovery begins copying data from the specified file system disk to a spare disk. When the process is complete, the spare disk becomes the active file system disk and the file system disk becomes a spare disk. If you stop a replacement, the data copy is halted, and the file system disk and spare disk retain their initial roles.

### Parameters

#### **-disk <disk path name>** - Disk Name

This specifies the file system disk that is to be replaced. Disk names take one of the following forms:

- Disks are named in the form `<stack-id>.<shelf>.<bay>`
- Disks on multi-disk carriers are named in the form `<stack-id>.<shelf>.<bay>.<lun>`
- Virtual disks are named in the form `<prefix>.<number>`, where prefix is the storage array's prefix and number is a unique ascending number.

Disk names take one of the following forms on clusters that are not yet fully upgraded to Data ONTAP 8.3:

- Disks that are not attached to a switch are named in the form `<node>:<host_adapter>.<loop_ID>`. For disks with a LUN, the form is `<node>:<host_adapter>.<loop_ID>L<LUN>`. For instance, disk number 16 on host adapter 1a on a node named node0a is named node0a:1a.16. The same disk on LUN lun0 is named node0a:1a.16Llun0.
- Disks that are attached to a switch are named in the form `<node>:<switch_name>:<switch_port>.<loop_ID>`. For disks with a LUN, the form is `<node>:<switch_name>:<switch_port>.<loop_ID>L<LUN>`. For instance, disk number 08 on port 11 of switch fc1 on a node named node0a is named node0a:fc1:11.08. The same disk on LUN lun1 is named node0a:fc1:11.08Llun1.

Before the cluster is upgraded to Data ONTAP 8.3, the same disk can have multiple disk names, depending on how the disk is connected. For example, a disk known to a node named alpha as alpha:1a.19 can be known to a node named beta as beta:0b.37. All names are listed in the output of queries and are equally valid. To determine a disk's unique identity, run a detailed query and look for the disk's universal unique identifier (UUID) or serial number.

#### **-action {start | stop}** - Action

This specifies whether to start or stop the replacement process.

#### **[-replacement <disk path name>]** - Replacement

This specifies the spare disk that is to replace the file system disk.

## **[-allow-same-carrier <true>] - Allow Same RAID Group Within Carrier**

This parameter can be used to allow two disks housed in the same carrier to be in the same RAID group when you replace a disk in an aggregate.

Having disks in the same carrier in the same RAID group is not desirable because a carrier failure can cause a simultaneous outage for two disks in the same RAID group. You can replace a disk in an aggregate with a disk that causes this situation, but when an alternate disk becomes available, Data ONTAP automatically initiates a series of disk copy operations to put the disks into different RAID groups. For this reason, you should use this parameter only when necessary. When possible, ensure that disks housed in the same carrier are in different RAID groups.

This parameter affects only the disk replace operation. It is not a persistent attribute of the aggregate.

## **[-m, -allow-mixing <true>] - Allow Mixing of Disks of Different RPM or Pool**

This optional parameter specifies whether the disk can be replaced with another disk of different RPM or from different Pool. This parameter affects only the current disk replacement operation.

### **Examples**

The following example begins replacing a file system disk named `1.0.16` with a spare disk named `1.1.14`.

```
cluster1::> storage disk replace -disk 1.0.16 -replacement 1.1.14 -action start
```

## **storage disk set-foreign-lun**

Sets or Unsets an array LUN as foreign

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `storage disk set-foreign-lun` command sets or unsets a specified array LUN as foreign. This command will enable/disable the feature of importing the data from foreign LUN.

### **Parameters**

#### **-disk <disk path name> - Disk Name**

This parameter specifies the array LUN which is to be set or unset as foreign.

#### **-is-foreign-lun <true> - Is Foreign LUN**

If the parameter value specified is `true` then array LUN is set as foreign. If the parameter value specified is `false` then array LUN foreignness is cleared.

### **Examples**

The following example shows how to set an array LUN as foreign:

```
cluster1::> storage disk set-foreign-lun -disk EMC-1.1 -is-foreign-lun
true
```

The following example shows how to mark an array LUN as not foreign:

```
cluster1::> storage disk set-foreign-lun -disk EMC-1.1 -is-foreign-lun
false
```

## storage disk set-led

Identify disks by turning on their LEDs

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage disk set-led` command controls the LED of a specified disk.

You can turn an LED on or off, cause it to blink or stop blinking, or test it.

This command is useful for locating a disk in its shelf.

### Parameters

**-action {on|off|blink|blinkoff|testall|resetall} -Action**

This parameter specifies the state to which the LED is to be set. Possible values include the following:

- on - The LED is lit steadily
- off - The LED is not lit
- blink - The LED blinks
- blinkoff - The LED stops blinking and is not lit
- testall - This tests the operation of every disk enclosure's hardware and drivers per node. Do not use this value in normal operation.
- resetall - This resets the LED of every disk on the node and lights up the LED of disks with faults.

**{ [-disk <disk path name>] - Disk Name**

This specifies the disk whose LED is to be set. Disk names take one of the following forms:

- Disks are named in the form `<stack-id>.<shelf>.<bay>`
- Disks on multi-disk carriers are named in the form `<stack-id>.<shelf>.<bay>.<lun>`
- Virtual disks are named in the form `<prefix>.<number>`, where prefix is the storage array's prefix and number is a unique ascending number.

Disk names take one of the following forms on clusters that are not yet fully upgraded to Data ONTAP 8.3:

- Disks that are not attached to a switch are named in the form `<node>:<host_adapter>.<loop_ID>`

. For disks with a LUN, the form is `<node>:<host_adapter>.<loop_ID>L<LUN>`. For instance, disk number 16 on host adapter 1a on a node named node0a is named node0a:1a.16. The same disk on LUN lun0 is named node0a:1a.16Llun0.

- Disks that are attached to a switch are named in the form `<node>:<switch_name>:<switch_port>.<loop_ID>`. For disks with a LUN, the form is `<node>:<switch_name>:<switch_port>.<loop_ID>L<LUN>`. For instance, disk number 08 on port 11 of switch fc1 on a node named node0a is named node0a:fc1:11.08. The same disk on LUN lun1 is named node0a:fc1:11.08Llun1.

Before the cluster is upgraded to Data ONTAP 8.3, the same disk can have multiple disk names, depending on how the disk is connected. For example, a disk known to a node named alpha as alpha:1a.19 can be known to a node named beta as beta:0b.37. All names are listed in the output of queries and are equally valid. To determine a disk's unique identity, run a detailed query and look for the disk's universal unique identifier (UUID) or serial number.

#### **`[-adapter <text>]` - Adapter Name**

The name of the adapter to which the shelves of disks of interest are attached to.

#### **`[-node {<nodename>|local}]` - Node Name }**

The node for which action is to be taken.

#### **`[-duration <integer>]` - Duration (minutes)**

This specifies the duration, in minutes, that the LED is to remain in the specified state. Only actions "on" and "blink" are supported.

#### **`[-iteration <integer>]` - Test iterations**

This specifies the number of iterations to run the action for. Only action "test-all" is supported.

## **Examples**

The following example causes the LEDs on all disks whose names match the pattern 1.0.\* to turn on for 5 minutes:

```
Cluster1::> storage disk set-led -disk 1.0.* -action on -duration 5
```

The following example causes the LEDs on disks 1.0.0 and 1.0.1 to turn on for 2 minutes:

```
Cluster1::> storage disk set-led -disk 1.0.0,1.0.1 -action on -duration 2
```

The following example causes the LEDs on all disks attached to adapter 0b on Node2 to turn on for 1 minute:

```
Cluster1::> storage disk set-led -node Node2 -adapter 0b -action on -duration 1
```

The following example resets the LEDs on all disks on the local node and causes the LEDs of disks with faults to turn on:

```
Cluster1::> storage disk set-led -action resetall
```

The following example tests the LEDs on all disks owned by the local node for 3 iterations:

```
Cluster1::> storage disk set-led -action testall -iteration 3
```

## storage disk show

Display a list of disk drives and array LUNs

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage disk show` command displays information about disks and array LUNs. Where it appears in the remainder of this document "disk" may refer to either a disk or an array LUN. By default, the command displays the following information about all disks in column style output:

- Disk name
- Usable space on the disk, in human readable units
- Shelf number
- Bay number
- Container type (aggregate, broken, foreign, labelmaint, maintenance, mediator, remote, shared, spare, unassigned, unknown, volume, or unsupported)
- Position (copy, data, dparity, orphan, parity, pending, present, shared or tparity)
- Container name
- Owning node name

To display detailed information about a single disk, use the `-disk` parameter.

### Parameters

{ [-fields <fieldname>,...]

Displays the specified fields for all disks, in column style output.

| [-broken ]

Displays the following RAID-related information about broken disks:

- Original owning node name
- Checksum compatibility
- Disk name
- Outage reason
- Host bus adapter
- Shelf number

- Bay number
- Primary port / Channel
- Pool
- Disk type
- RPM (Revolutions per minute)
- Usable size in human readable units
- Physical size in human readable units
- Current owner node

#### | [-errors ]

Displays the following disk information about the disks which have errors.

- Disk Name
- Error Type
- Error Description and corresponding corrective action

#### | [-longop ]

Displays the following information about long-running disk operations, in column style output:

- Disk name
- Whether the disk is marked as prefailed
- Whether the disk is being replaced
- Whether the disk is zeroed
- Copy destination
- Percentage of copy complete
- Percentage of zeroing complete
- Percentage of reconstruction complete

#### | [-maintenance ]

Displays the following RAID-related information about disks in the maintenance center:

- Original owning node name
- Checksum compatibility
- Disk name
- Outage Reason
- Host bus adapter
- Shelf number
- Bay number
- Primary port / Channel
- Pool
- Disk type

- RPM (Revolutions per minute)
- Usable size in human readable units
- Physical size in human readable units
- Current owner node

#### | [-ownership ]

Displays the following ownership-related information:

- Disk name
- Aggregate name
- Home node name
- Owning node name
- Disaster recovery home node name
- Home node system id
- Owning node system id
- Disaster recovery home node system id
- Reservation node system id
- SyncMirror pool

#### | [-partition-ownership ]

Displays the following ownership-related information for partitioned disks:

- Disk name
- Aggregate name
- Owner of root partition on a partitioned disk
- Owner system id of root partition on a partitioned disk
- Owner of data or data1 partition on a root-data or a root-data1-data2 partitioned disk respectively
- Owner system id of data or data1 partition on a root-data or a root-data1-data2 partitioned disk respectively
- Owner of data2 partition on a root-data1-data2 partitioned disk
- Owner system id of data2 partition on a root-data1-data2 partitioned disk
- Owner of the disk which is partitioned
- Owner system id of the disk which is partitioned

#### | [-physical ]

Displays the following information about the disk's physical attributes, in column style output:

- Disk name
- Disk type
- Disk vendor
- Disk model
- Firmware revision level

- RPM (Revolutions per minute)
- BPS (Bytes per sector)

#### **[ -port ]**

Displays the following path-related information:

- Disk name and disk port associated with disk primary path
- Disk name and disk port associated with the disk secondary path, for a multipath configuration
- Type, shelf, and bay information for the disks

#### **[ -raid ]**

Displays the following RAID-related information:

- Disk name
- Container type (aggregate, broken, labelmaint, maintenance, mediator, remote, shared, spare, unassigned, unknown, or volume)
- Outage reason
- Position (copy, data, dparity, orphan, parity, pending, present, shared or tparity)
- RAID group name
- Aggregate name

#### **[ -raid-info-for-aggregate ]**

Displays the following RAID-related information about the disks used in an aggregate:

- Owning node name
- Aggregate name
- Plex name
- RAID group name
- Position (copy, data, dparity, orphan, parity, pending, present, shared or tparity)
- Disk name
- Host bus adapter
- Shelf number
- Bay number
- Primary port / Channel
- Pool
- Disk type
- RPM (Revolutions per minute)
- Usable size in human readable units
- Physical size in human readable units

When this parameter is specified, RAID groups that use shared disks are not included. Use [storage aggregate show-status](#) to show information for all RAID groups and aggregates.

**| [-spare ]**

Displays the following RAID-related information about available spare disks:

- Original owning node name
- Checksum compatibility
- Disk name
- Host bus adapter
- Shelf number
- Bay number
- Primary port / Channel
- Pool
- Disk type
- Disk class
- RPM (Revolutions per minute)
- Usable size in human readable units
- Physical size in human readable units
- Current owner node

**| [-ssd-wear ]**

Displays the following wear life related information about solid state disks:

- Rated Life Used : An estimate of the percentage of device life that has been used, based on the actual device usage and the manufacturer's prediction of device life. A value greater than 99 indicates that the estimated endurance has been used, but this does not necessarily indicate a device failure. Omitted if value is unknown.
- Spare Blocks Consumed Limit : Spare blocks consumed percentage limit reported by the device. When the Spare Blocks Consumed percentage for the device reaches this read-only value, Data ONTAP initiates a disk copy operation to prepare to remove the device from service. Omitted if value is unknown.
- Spare Blocks Consumed : Percentage of device spare blocks that have been used. Each device has a number of spare blocks that will be used when a data block can no longer be used to store data. This value reports what percentage of the spares have already been consumed. Omitted if value is unknown.

**| [-virtual-machine-disk-info ]**

Displays information about Data ONTAP virtual disks, their mapped datastores and their specific backing device attributes, such as: disk or LUN, adapter and initiator details (if applicable).

- Disk name.
- Name of the node.
- Data ONTAP-supplied serial number of the system disk.
- Size of the system disk.
- Name of the disk backing store. A backing store represents a storage location for virtual machine files. It can be a VMFS volume, a directory on network-attached storage, or a local file system path.
- File name of the virtual disk used by the hypervisor. Each Data ONTAP disk is mapped to a unique VM

disk file.

- Type of the disk backing store. It can be a VMFS volume, a directory on network-attached storage, or a local file system path.
- Size of the disk backing store.
- Full path to the backing store for network-attached storage. This field is valid only for NAS connections.
- Backing adapter PCI device ID for the virtual disk, for example "50:00.0".
- Backing adapter device name, for example "vmhba32".
- Backing adapter model type, for example "LSI1064E".
- Backing adapter driver name of the initiator.
- The iSCSI name of the disk backing target. This field is valid only for iSCSI connections.
- The iSCSI IP address of the disk backing target. This field is valid only for iSCSI connections.
- SCSI device name for the backing disk. It takes the form target-id:lun-id, for example "2:1".
- Hypervisor-assigned unique ID of the backing device (disk or LUN).
- Backing disk partition number where the corresponding VM disk file resides.
- Size of the backing device (disk or LUN).
- Backing device manufacturer, for example "FUJITSU" or "IBM".
- Backing device model, for example "MBE2073RC" or "LUN".
- Storage account associated with the VM Disk.
- Container associated with the VM Disk.
- Page blob associated with the VM Disk.
- Error (if any) while retrieving virtual disk details.

#### | [-vmdisk-backing-info ]

Displays information about the backing disks on certain Data ONTAP-v models:

- Disk name
- Backing disk vendor
- Backing disk model
- Backing disk serial number
- Backing disk device id

#### | [-foreign ] (privilege: advanced)

Displays the following foreign LUN import related information about foreign disks:

- Disk name
- Array name
- Capacity in sectors
- Capacity in mb
- Serial Number

## | [-physical-location ] (privilege: advanced)

Displays the following information about disks:

- Disk name
- Container type
- Primary path
- Location
- Home node name
- Physical size in human readable units

## | [-primary-paths ] (privilege: advanced)

Displays the following information about disks:

- Disk Name
- Shelf
- Bay
- Container Type
- Primary Path

## | [-instance ] }

Displays detailed disk information. If no disk path name is specified, this parameter displays the same detailed information for all disks as does the -disk parameter. If a disk path name is specified, then this parameter displays the same detailed information for the specified disks as does the -disk parameter.

### **[-disk <disk path name>] - Disk Name**

Displays detailed information about the specified disks. Disk names take one of the following forms:

- Disks are named in the form *<stack-id>.<shelf>.<bay>*
- Disks on multi-disk carriers are named in the form *<stack-id>.<shelf>.<bay>.<lun>*
- Virtual disks are named in the form *<prefix>.<number>*, where prefix is the storage array's prefix and number is a unique ascending number.

Disk names take one of the following forms on clusters that are not yet fully upgraded to Data ONTAP 8.3:

- Disks that are not attached to a switch are named in the form *<node>:<host\_adapter>.<loop\_ID>*. For disks with a LUN, the form is *<node>:<host\_adapter>.<loop\_ID>L<LUN>*. For instance, disk number 16 on host adapter 1a on a node named node0a is named node0a:1a.16. The same disk on LUN lun0 is named node0a:1a.16Llun0.
- Disks that are attached to a switch are named in the form *<node>:<switch\_name>:<switch\_port>.<loop\_ID>*. For disks with a LUN, the form is *<node>:<switch\_name>:<switch\_port>.<loop\_ID>L<LUN>*. For instance, disk number 08 on port 11 of switch fc1 on a node named node0a is named node0a:fc1:11.08. The same disk on LUN lun1 is named node0a:fc1:11.08Llun1.

Before the cluster is upgraded to Data ONTAP 8.3, the same disk can have multiple disk names, depending on how the disk is connected. For example, a disk known to a node named alpha as alpha:1a.19 can be known to a node named beta as beta:0b.37. All names are listed in the output of queries and are equally valid. To determine a disk's unique identity, run a detailed query and look for the disk's universal unique

identifier (UUID) or serial number.

**[-owner {<nodename>|local}] - Owner**

Selects information about disks that are owned by the specified node.

**[-owner-id <nvrmaid>] - Owner System ID**

Selects the disks that are owned by the node with the specified system ID.

**[-is-foreign {true|false}] - Foreign LUN (privilege: advanced)**

Selects information about array LUNs that have been declared to be foreign LUNs.

**[-uid <text>] - Disk Unique ID**

Selects the disks whose unique id matches this parameter value. A disk unique identifier has the form:

`20000000:875D4C32:00000000:00000000:00000000:00000000:00000000:00000000:00000000`

**[-aggregate <aggregate name>] - Aggregate**

Selects information about disks that belong to the specified aggregate.

**[-array-name <array name>] - Array Name**

Selects information about the LUNs presented by the specified storage array.

**[-average-latency <integer>] - Average I/O Latency Across All Active Paths**

Selects information about disks that have the specified average latency.

**[-bay <integer>] - Bay**

Selects information about disks that are located in the carrier within the specified shelf bay.

**[-bps <integer>] - Bytes Per Sector**

Selects information about disks that have the specified number of bytes per sector. Possible settings are 512, 520, 4096, and 4160.

**[-carrier-id <text>] - Carrier ID**

Selects information about disks that are located within the specified multi-disk carrier.

**[-checksum-compatibility {advanced\_zoned | block | none}] - Checksum Compatibility**

Selects information about disks that have the specified checksum compatibility.

**[-class {capacity | performance | archive | solid-state | array | virtual}] - Disk Class**

Selects information about disks that have the specified disk class.

- capacity = Capacity-oriented, near-line disk types. Includes disk types FSAS, BSAS and ATA.
- performance = Performance-oriented, enterprise class disk types. Includes disk types FCAL and SAS.
- archive = Archive class SATA disks in multi-disk carrier storage shelves. Includes disk type MSATA.
- solid-state = Solid-state drives. Includes disk type SSD, SSD-CAP and SSD-NVM.
- array = Logical storage devices backed by storage arrays and used by Data ONTAP as disks. Includes disk type LUN.

- virtual = Virtual disks that are formatted and managed by the hypervisor. Includes disk type VMDISK.

**[-container-type {aggregate | broken | foreign | labelmaint | maintenance | mediator | remote | shared | spare | unassigned | unknown | unsupported}] - Container Type**

Selects information about disks that have the specified container type.

- Aggregate = Disk is used as a physical disk in an aggregate.
- Broken = Disk is in broken pool.
- Foreign = Array LUN has been marked foreign.
- Labelmaint = Disk is in online label maintenance list.
- Maintenance = Disk is in maintenance center.
- Mediator = A mediator disk is a disk used on non-shared HA systems hosted by an external node which is used to communicate the viability of the storage failover between non-shared HA nodes.
- Remote = Disk belongs to the remote cluster.
- Shared = Disk is partitioned or in a storage pool.
- Spare = Disk is a spare disk.
- Unassigned = Disk ownership has not been assigned.
- Unknown = Container is currently unknown. This is the default setting.
- Unsupported = Disk is not supported.

**[-container-name <text>] - Container Name**

Selects information about disks that have the specified container name. + If a disk is in an aggregate or storage pool, the container name is the name of the aggregate or storage pool. + Spare disks show the SyncMirror Pool to which they belong. + Partitioned disks could return multiple aggregate names.

**[-copy-destination <disk path name>] - Copy Destination Name**

Selects information about disks whose contents are being copied (due to either Rapid RAID Recovery or disk replacement) to the specified spare disk.

**[-copy-percent <integer>] - Percentage of Copy Complete**

Selects information about disks that are involved as either a source or destination of a copy operation, (due to either disk replacement or Rapid RAID Recovery) and that have the specified percentage of the copy operation completed.

**[-data-owner {<nodename>|local}] - Owner of Data Partition of Root-Data Partitioned Disk**

Selects information about disks that have the specified data partition owner name. Used with root-data partitioned disks.

**[-data1-owner {<nodename>|local}] - Owner of Data1 Partition of Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified data1 partition owner name. Used with root-data1-data2 partitioned disks.

**[-data2-owner {<nodename>|local}] - Owner of Data2 Partition of Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified data2 partition owner name. Used with root-data1-

data2 partitioned disks.

**[-data-home {<nodename>|local}] - Home Owner of Data Partition of Root-Data Partitioned Disk**

Selects information about disks that have the specified data partition home owner name. Used with root-data partitioned disks.

**[-data1-home {<nodename>|local}] - Home Owner of Data1 Partition of Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified data1 partition home owner name. Used with root-data1-data2 partitioned disks.

**[-data2-home {<nodename>|local}] - Home Owner of Data2 Partition of Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified data2 partition home owner name. Used with root-data1-data2 partitioned disks.

**[-data-owner-id <nvramid>] - Owner System ID of Data Partition of Root-Data Partitioned Disk**

Selects information about disks that have the specified data partition owner system ID. Used with root-data partitioned disks.

**[-data1-owner-id <nvramid>] - Owner System ID of Data1 Partition of Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified data1 partition owner system ID. Used with root-data1-data2 partitioned disks.

**[-data2-owner-id <nvramid>] - Owner System ID of Data2 Partition of Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified data2 partition owner system ID. Used with root-data1-data2 partitioned disks.

**[-data-home-id <nvramid>] - Home Owner System ID of Data Partition of Root-Data Partitioned Disk**

Selects information about disks that have the specified data partition home owner system ID. Used with root-data partitioned disks.

**[-data1-home-id <nvramid>] - Home Owner System ID of Data1 Partition of Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified data1 partition home owner system ID. Used with root-data1-data2 partitioned disks.

**[-data2-home-id <nvramid>] - Home Owner System ID of Data2 Partition of Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified data2 partition home owner system ID. Used with root-data1-data2 partitioned disks.

**[-disk-io-kbps-total <integer>] - Total Disk Throughput in KBPS Across All Active Paths**

Selects information about disks that have attained the specified I/O throughput on all connected paths.

**[-disk-iops-total <integer>] - Total Disk IOPs Across All Active Paths**

Selects information about disks that have achieved the specified number of IOPs per second on all connected paths.

**[-diskpathnames <disk path name>, ...] - List of Path-Based Disk Names**

Selects information about disks that have all of the specified path names.

**[-effective-rpm <integer>] - Effective RPM**

Selects information about disks with the specified effective rotational speed.

**[-dr-home {<nodename>|local}] - Disaster Recovery Home**

Selects information about disks that have the specified Disaster home node.

**[-dr-home-id <nvrmaid>] - Disaster Recovery Home System ID**

Selects information about disks whose Disaster home node has the specified system id.

**[-drawer <integer>] - Drawer**

Selects information about disks that are located in the specified drawer.

**[-error-type**

**{onepath|onedomain|control|foreign|toobig|toosmall|invalidblocksize|targetasymmap|deviceassymmap|failovermisconfig|unknown|netapp|fwdownrev|qualfail|diskfail|notallflashdisk}] - Error Type**

Selects information about disks that have the specified error types.

- onepath = The array LUN is accessible only via a single path.
- onedomain = The array LUN is accessible only via a single fault domain.
- control = The array LUN cannot be used because it is a control device.
- foreign = The array LUN is marked as foreign and has some external SCSI reservations other than those from Data ONTAP.
- toobig = The array LUN exceeds the maximum array LUN size that Data ONTAP supports.
- toosmall = The array LUN is less than the minimum array LUN size that Data ONTAP supports.
- invalidblocksize = The array LUN is not a valid block size.
- targetasymmap = The array LUN is presented more than once on a single target port.
- deviceassymmap = The array LUN is presented with multiple IDs.
- failovermisconfig = The array LUN is configured with inconsistent failover methods.
- unknown = The array LUN from a storage array that is not supported by this version of Data ONTAP.
- netapp = A SAN front-end LUN from one Data ONTAP system that is presented as external storage to another Data ONTAP system.
- fwdownrev = The disk firmware is a down version.
- qualfail = The disk is not supported.
- diskfail = The disk is in a failed state.
- notallflashdisk = The disk does not match the All-Flash Optimized personality of the system.

**[-firmware-revision <text>] - Firmware Revision**

Selects information about disks that have the specified firmware revision level.

**[-home {<nodename>|local}] - Home**

Selects information about disks that have the specified home node.

**[-home-id <nvramid>] - Home System ID**

Selects information about disks whose home node has the specified system ID.

**[-host-adapter <text>] - Primary Path Host Adapter**

Selects information about disks that are currently using the specified Host Bus Adapter.

**[-import-in-progress {true|false}] - Foreign LUN import in progress**

Selects information about the array LUNs that are currently being imported

**[-initiator <text>, ...] - Initiator Port**

Selects information about disks that are visible to the initiator specified. Disks that are not currently in use by that initiator are included.

**[-initiator-iops <integer>, ...] - Number of IOPS on Initiator (Rolling Average)**

Selects information about disks that are visible to an initiator that has executed the specified number of IOPs.

**[-initiator-io-kbps <integer>, ...] - Kbytes of I/O per second on Initiator (Rolling Average)**

Selects information about disks visible to an initiator that has executed I/O at the specified throughput.

**[-initiator-lun-in-use-count <integer>, ...] - Number of LUNs in the in-use state on this initiator**

Selects information about disks with a path through an initiator that has the specified in-use-count.

**[-initiator-side-switch-port <text>, ...] - Initiator Side Switch Port**

Selects information about disks that are visible to an initiator connected to the specified switch port.

**[-is-multidisk-carrier {true|false}] - Multi Disk Carrier?**

Selects information about disks that are located within a multi-disk carrier.

**[-is-local-attach {true|false}] - Indicates If the Disk Is Local to This Cluster**

Selects information about disks attached to the local(true) or remote(false) MetroCluster site.

**[-location {<nodename>|local}] - Physical Location**

Selects information about disks attached to the specified node.

**[-location-id <nvramid>] - The system ID of the node where the disk is attached**

Selects information about disks attached to the node with the specified system ID.

**[-lun <integer>, ...] - LUN ID**

Selects information about the specified LUNs.

**[-lun-iops <integer>, ...] - Number IOPS per second on disk (Rolling Average)**

Selects information about the LUNs that have reached the specified number of IOPs.

**[-lun-io-kbps <integer>, ...] - Kbytes/sec on Disk (Rolling Average)**

Selects information about the LUNs that have reached the specified I/O throughput.

**[-lun-path-use-state <text>, ...] - The Use State of the LUN on this path**

Selects information about LUNs reporting the specified in-use state.

**[-model <text>] - Model**

Selects information about disks of the specified model.

**[-nodelist {<nodename>|local}] - Controller name**

Selects information about disks that are visible to all of the specified nodes .

**[-outage-reason <text>] - Outage Reason**

Selects information about disks that are not in service for the specified reason. Possible values are: admin failed, admin removed, admin testing, evacuated, bad label, bypassed, failed, init failed, label version, labeled broken, labelmaint, LUN resized, missing, not responding, predict failure, rawsize shrank, recovering, sanitizing, sanitized, SnapLock Disk, testing, unassigned, unknown.

**[-path-error-count <integer>] - Path Error Count**

Selects information about disks that are visible on a path that has incurred the specified number of errors.

**[-path-iops <integer>, ...] - Number of IOPS on Path (Rolling Average)**

Selects information about disks on those paths that have reached the specified number of IOPs.

**[-path-io-kbps <integer>, ...] - Kbytes of I/O per second on Path (Rolling Average)**

Selects information about disk with paths that have reached the specified I/O throughput

**[-path-link-errors <integer>, ...] - Link Error count on path**

Selects information about disks with paths that have incurred the specified number of FC link errors.

**[-path-lun-in-use-count <integer>, ...] - Number of LUNs in the in-use state on this path**

Selects information about disks with paths that have the specified in-use-count.

**[-path-quality <integer>, ...] - Percentage of weighted error threshold**

Selects information about disks on paths that have incurred the specified number of errors. The value displayed is a measure of the health of a path expressed as a percentage of an error threshold. Once a path has reached or surpassed the error threshold, another path will be selected for I/O transfer, if there is one available.

**[-physical-size-mb <integer>] - Physical Size (MB)**

Selects information about disks that have the specified physical capacity, in megabytes.

**[-physical-size {<integer> [KB|MB|GB|TB|PB]}] - Physical Size**

Selects information about disks that have the specified physical capacity, in human readable units.

**[-physical-size-512b <integer>] - Physical Size in Units of 512 Bytes**

Selects information about disks that have the specified physical capacity, in 512-byte chunks. This parameter is present only for backwards compatibility with Data ONTAP 8.0.

**[-plex <text>] - Plex Name**

Selects information about disks that belong to the specified RAID plex.

**[-pool <text>] - Assigned Pool**

Selects information about disks that belong to the specified SyncMirror pool (pool0 or pool1).

**[-port-speed <text>, ...] - Port Speed**

Selects information about disks that are served by a Host Bus Adapter that is running at the specified port speed.

**[-position <diskPositionType>] - Disk Position**

Selects information about disks that have the specified position within their disk container.

**[-power-on-hours <integer>] - Hours Powered On**

Selects information about disks that have the specified number of hours being powered up.

**[-prefailed {true|false}] - Marked for Rapid RAID Recovery?**

Selects information about disks that match the specified parameter value indicating whether the disk is either awaiting or is in process of Rapid RAID Recovery.

**[-preferred-target-port {true|false}] - Whether or not target port group is preferred  
(privilege: advanced)**

Selects information about disks that match the specified parameter value indicating whether the backing storage is ALUA (Asymmetric Logical Unit Access) capable and has specified the array target port on this path to be a preferred target port for I/O.

**[-primary-port <text>] - Primary Path Disk Port**

Selects information about disks that use the specified primary port.

**[-raid-group <text>] - Raid Group Name**

Selects information about disks that belong to the specified RAID group.

**[-reconstruction-percent <integer>] - Percentage of Reconstruction Complete**

Selects information about disks that are being reconstructed and that have the specified percentage of the reconstruction operation completed.

**[-replacing {true|false}] - Being Replaced?**

Selects information about disks that match the specified boolean value indicating whether the disk is either awaiting or in process of disk replacement.

**[-reservation-key <text>] - Reservation Key**

If this parameter is specified, the command displays information only about the disk or disks that have the specified persistent reservation key.

**[-reservation-type {rs|we|re|ea|sa|wero|earo|wear|eaar|none}] - Reservation Type**

If this parameter is specified, the command displays information only about the disk or disks that have the specified persistent reservation type. Possible values are: rs, we, re, ea, sa, wero, earo, wear, eaar, or none.

**[-reserver-id <integer>] - Reservation System ID**

Selects information about disks that are reserved by the node with the specified system ID.

**[-root-owner {<nodename>|local}] - Owner of Root Partition of Root-Data/Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified root partition owner name. Used with root-data/root-data1-data2 partitioned disks.

**[-root-owner-id <nvramid>] - Owner System ID of Root Partition of Root-Data/Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified root partition owner system ID. Used with root-data/root-data1-data2 partitioned disks.

**[-root-home {<nodename>|local}] - Home Owner of Root Partition of Root-Data/Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified root partition home owner name. Used with root-data/root-data1-data2 partitioned disks.

**[-root-home-id <nvramid>] - Home Owner System ID of Root Partition of Root-Data/Root-Data1-Data2 Partitioned Disk**

Selects information about disks that have the specified root partition home owner system ID. Used with root-data/root-data1-data2 partitioned disks.

**[-rpm <integer>] - Revolutions Per Minute**

Selects information about disks that have the specified rotational speed.

**[-secondary-name <disk path name>] - Secondary Path Name**

Selects information about disks that use the specified secondary path name, for multipath configuration.

**[-secondary-port <text>] - Secondary Path Disk Port**

Selects information about disks that use the specified secondary port.

**[-serial-number <text>] - Serial Number**

Selects information about the disk that has the specified serial number.

**[-storage-pool <text>] - Storage Pool Name**

Selects information about disks that belong to the specified SSD storage pool.

**[-shelf <integer>] - Shelf**

Selects information about disks that are located within the specified shelf.

**[-shelf-uid <text>] - Shelf UID**

Selects information about disks that are located within a shelf with the specified Shelf UID.

**[-slot <integer>] - Slot**

Selects information about disks that are located in a drawer with the specified slot.

**[-stack-id <integer>] - Stack ID**

A cluster unique id for a collection of one or more interconnected shelves.

**[-target-iops <integer>, ...] - Number of IOPS to Target (Rolling Average)**

Selects information about disks that are visible on target ports that have performed the specified number of IOPs.

**[-target-io-kbps <integer>, ...] - Kbytes of I/O per second to Target (Rolling Average)**

Selects information about disks that are visible on target ports that have reached the specified I/O throughput.

**[-target-lun-in-use-count <integer>, ...] - Number of LUNs in the in-use state on this target**

Selects information about disks with a path through a target port that has the specified in-use-count.

**[-target-port-access-state <text>, ...] - Failover optimization type**

Selects information about disks that are visible on target ports that have the specified access state.

**[-target-side-switch-port <text>, ...] - Target Side Switch Port**

Selects information about disks that are visible on target ports identified by the switch port to which they are connected.

**[-target-wwpn <text>, ...] - Target Port**

Selects information about disks that are visible on target ports identified by their World Wide Port Name.

**[-tpgn <integer>, ...] - Target Port Group Number**

Selects information about disks that belong to the specified Target Port Group Number.

**[-type {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}] - Disk Type**

Selects information about disks that have the specified disk type.

**[-usable-size-mb <integer>] - Usable Size (MB)**

Selects information about disks that have the specified usable space, in megabytes.

**[-usable-size {<integer>[KB|MB|GB|TB|PB]}] - Usable Size**

Selects information about disks that have the specified usable space, in human readable units.

**[-vendor <text>] - Vendor Name**

Selects information about disks that have the specified vendor.

**[-vmdisk-device-id <integer>, ...] - Virtual Disk Device ID**

Selects information about disks that have the specified virtual disk device ID.

**[-zeroed {true|false}] - Zeroed?**

Selects information about disks that have (true) or have not (false) been fully pre-zeroed.

**[-zeroing-percent <integer>] - Percentage of Zeroing Complete**

Selects information about disks that are zeroing and have the specified percentage complete.

**[-carrier-serialno <text>] - Carrier Serial Number**

Selects information about disks that are located within the multi-disk carrier specified by the serial number.

**[-vmdisk-target-address <text>] - Target Address of the VM Disk**

Displays the VM Disk's target address either in the form of bus target lun or bus unit.

**[-path-count <integer>] - Number of Paths to Disk**

Selects information about disks that have the specified number of paths.

**[-hw-minimum-os <ClusterVersion>] - Hardware Minimum Supported ONTAP Version (x.y.z)**

Selects information about disks that have the specified hardware minimum supported ONTAP version in x.y.z format, for example "9.8.0" or "9.9.1".

## Examples

The following example displays information about all disks:

cluster1::> storage disk show						
Disk Owner	Usable Size	Container			Position	Aggregate
		Shelf	Bay	Type		
1.1.1 node1	10GB	1	1	spare	present	-
1.1.4 node1	78.59GB	1	4	spare	present	-
1.1.12 node1	10GB	1	12	spare	present	-
1.2.12 node1	10GB	2	12	broken	present	-
1.3.7 node1	78.59GB	3	7	aggregate	parity	aggr0_u23
1.1.6 node1	78.59GB	1	6	broken	present	-
1.2.10 node1	78.59GB	2	10	aggregate	dparity	aggr0_u23
1.4.9 node1	78.59GB	4	9	aggregate	data	aggr0_u23
1.1.0 node2	10GB	1	0	aggregate	dparity	aggr0_u22
1.4.1 node2	10GB	4	1	aggregate	data	dp_degraded
1.1.2 node2	10GB	1	2	spare	present	-
1.1.3 node2	20GB	1	3	spare	present	-
1.4.4 node2	20GB	4	4	spare	present	-
1.4.6 node2	10GB	4	6	aggregate	data	dp_sdc
1.1.5 node2	268.0GB	1	5	maintenance	present	-
1.3.0 node2	10GB	3	0	aggregate	parity	aggr0_u22
1.4.11 node2	10GB	4	11	spare	present	-
1.4.13 node2	20GB	4	13	broken	present	-
[...]						

The following example displays detailed information about a disk named 1.0.75

```

cluster1::> storage disk show -disk 1.0.75
          Disk: 1.0.75
          Container Type: spare
          Owner/Home: node2 / node2
          DR Home: -
          Stack ID/Shelf/Bay: 1 / 0 / 75
          LUN: 0
          Array: N/A
          Vendor: NETAPP
          Model: X267_HKURO500SSX
          Serial Number: ZAKAS0GH
          UID:
1FF17846:0A419201:9325845A:3ABD5075:00000000:00000000:00000000:00
000000:00000000
          BPS: 512
          Physical Size: 10.15GB
          Position: present
Checksum Compatibility: block
          Aggregate: -
          Plex: -
Paths:
          LUN  Initiator Side          Target Side
Link
Controller      Initiator      ID  Switch Port          Switch Port
Acc Use  Target Port          TPGN      Speed          I/O KB/s
IOPS
-----  -----  -----  -----  -----  -----
-----  -----  -----  -----  -----  -----
node1          0d          0  N/A          N/A
AO  INU  220a000a3384e4d2          21  2 Gb/S          0
0
node1          0c          0  N/A          N/A
AO  RDY  2209000a3384e4d2          62  2 Gb/S          0
0
node2          0d          0  N/A          N/A
AO  INU  2209000a3384e4d2          62  2 Gb/S          3
0
Errors:
-

```

The following example displays RAID-related information about disks used in an aggregate:

```
cluster1::> storage disk show -raid-info-for-aggregate
```

```

Owner Node: node1
  Aggregate: aggr0_node1_0
    Plex: plex0
      RAID Group: rg0

```

Usable Physical

RPM	Position Disk		HA	Shelf	Bay	Chan	Pool	Type
	Size	Size						
	data	2.11.2						
15000	9.77GB	9.93GB	2d	11	2 B		Pool0	SAS
	dparity	2.11.0						
15000	9.77GB	9.93GB	2d	11	0 B		Pool0	SAS
	parity	2.11.1						
15000	9.77GB	9.93GB	2d	11	1 B		Pool0	SAS

Owner Node: node2

```

  Aggregate: a1
    Plex: plex0
      RAID Group: rg0

```

Usable Physical

RPM	Position Disk		HA	Shelf	Bay	Chan	Pool	Type
	Size	Size						
	data	2.1.8						
7200	9.77GB	9.91GB	2a	1	8 B		Pool0	BSAS
	dparity	2.1.6						
7200	9.77GB	9.91GB	2a	1	6 B		Pool0	BSAS
	parity	2.1.7						
7200	9.77GB	9.91GB	2a	1	7 B		Pool0	BSAS

Owner Node: node2

```

  Aggregate: a1
    Plex: plex0
      RAID Group: rg1

```

Usable Physical

RPM	Position Disk		HA	Shelf	Bay	Chan	Pool	Type
	Size	Size						
	data	2.1.11						
7200	9.77GB	9.91GB	2a	1	11 B		Pool0	BSAS
	dparity	2.1.9						
7200	9.77GB	9.91GB	2a	1	9 B		Pool0	BSAS

```

        parity  2.1.10          2a    1 10 B    Pool0  BSAS
7200  9.77GB  9.91GB
Owner Node: node2
Aggregate: aggr0
Plex: plex0
RAID Group: rg0

Usable Physical
      Position Disk          HA Shelf Bay Chan Pool    Type
RPM     Size     Size
      ----- -----  -----
      ----- -----
      data    2.1.5          2a    1    5 B    Pool0  BSAS
7200  9.71GB 10.03GB
      dparity 2.1.2          2a    1    2 B    Pool0  BSAS
7200  9.71GB 10.03GB
      parity   2.1.4          2a    1    4 B    Pool0  BSAS
7200  9.71GB 10.03GB
12 entries were displayed.

```

The following example displays RAID-related information about spares:

```

cluster1::> storage disk show -spare
Original Owner: node1
  Checksum Compatibility: block
                                         Usable
Physical
  Disk          HA Shelf Bay Chan  Pool  Type    RPM    Size
Size Owner
  -----
  1.1.23        0b      1  23    A  Pool0  FCAL  10000  132.8GB
134.2GB node1
  1.1.25        0b      1  25    A  Pool0  FCAL  10000  132.8GB
133.9GB node1
  1.1.26        0b      1  26    A  Pool1  FCAL  10000  132.8GB
133.9GB node1
  1.1.27        0b      1  27    A  Pool1  FCAL  10000  132.8GB
134.2GB node1
Home Owner: node2
  Checksum Compatibility: block
                                         Usable
Physical
  Disk          HA Shelf Bay Chan  Pool  Type    RPM    Size
Size Owner
  -----
  1.1.19        0a      1  19    B  Pool1  FCAL  10000  132.8GB
133.9GB node2
  1.1.20        0a      1  20    B  Pool0  FCAL  10000  132.8GB
133.9GB node2
  1.1.21        0a      1  21    B  Pool0  FCAL  10000  132.8GB
133.9GB node2
[...]

```

The following example displays RAID-related information about broken disks:

```

cluster1::> storage disk show -broken
Original Owner: node1
  Checksum Compatibility: block

Usable Physical
  Disk          Outage Reason HA Shelf Bay Chan   Pool   Type     RPM
Size    Size
-----  -----
-----  -----
  1.1.0          admin failed 0b      1   0     A  Pool0  FCAL  10000
132.8GB  133.9GB
  1.2.6          admin removed 0b     2   6     A  Pool1  FCAL  10000
132.8GB  134.2GB
Original Owner: node2
  Checksum Compatibility: block

Usable Physical
  Disk          Outage Reason HA Shelf Bay Chan   Pool   Type     RPM
Size    Size
-----  -----
-----  -----
  1.1.0          admin failed 0a      1   0     B  Pool0  FCAL  10000
132.8GB  133.9GB
  1.1.13         admin removed 0a     1  13     B  Pool0  FCAL  10000
132.8GB  133.9GB
4 entries were displayed.

```

The following example displays RAID-related information about disks in maintenance center:

```

cluster1::> storage disk show -maintenance
Original Owner: node1
  Checksum Compatibility: block

Usable Physical
  Disk          Outage Reason HA Shelf Bay Chan   Pool   Type     RPM
Size    Size
----- ----- ----- ----- ----- ----- ----- ----- ----- ----- -----
----- -----
  1.1.8          admin testing 0b      1     8     A  Pool0  FCAL  10000
132.8GB  133.9GB
  1.2.11         admin testing 0b      2    11     A  Pool1  FCAL  10000
132.8GB  134.2GB
Original Owner: node2
  Checksum Compatibility: block

Usable Physical
  Disk          Outage Reason HA Shelf Bay Chan   Pool   Type     RPM
Size    Size
----- ----- ----- ----- ----- ----- ----- ----- ----- ----- -----
----- -----
  1.2.10         admin testing 0a      2    10     B  Pool1  FCAL  10000
132.8GB  133.9GB
  1.2.13         admin testing 0a      2    13     B  Pool1  FCAL  10000
132.8GB  134.2GB
4 entries were displayed.

```

The following example displays partition-related information about disks:

```

cluster1::> storage disk show -partition-ownership
Disk      Partition Home          Owner          Home ID      Owner
ID

-----
----- VMw-1.13 Container pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
VMw-1.14 Container pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
VMw-1.15 Container pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
      Root      pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
      Data      pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
VMw-1.16 Container pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
      Root      pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
      Data1     pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
      Data2     pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
VMw-1.17 Container pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
VMw-1.18 Container pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
      Root      -          -          -          -
      Data      pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
VMw-1.19 Container pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
      Root      pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786
      Data1     -          -          -          -
      Data2     pvaruncluster-2-01 pvaruncluster-2-01 4087518786
4087518786

```

## Related Links

- [storage aggregate show-status](#)

## storage disk unfail

Unfail a broken disk

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage disk unfail` command can be used to unfail a broken disk.

If the attempt to unfail the disk is unsuccessful, the disk remains in the broken state.

The `disk unfail` command prompts for confirmation unless you specify the `-quiet` parameter.

## Parameters

### **`-disk <disk path name>` - Disk Name (privilege: advanced)**

This parameter specifies the disk to be unfailed.

### **`[-s, -spare <true>]` - Make the Disk Spare (privilege: advanced)**

This parameter specifies whether the unfailed disk will be made a spare disk. The disk is forced to become a spare disk if this parameter is specified.

If this parameter is not specified, the disk is brought back into its parent aggregate. Setting this parameter might result in the aggregate coming back online if it is not complete or online. The default value is false.

### **`[-q, -quiet <true>]` - Confirmations off (privilege: advanced)**

You can set this parameter to true to suppress the confirmation messages. However, before proceeding with the command, you should be aware that the confirmation message contains important information about the effect of unfailing a disk. This command cannot be reversed once it is invoked. The default value is false.

## Examples

The following example unfails a disk named 1.1.16 to become a spare disk:

```
cluster1::>* storage disk unfail -disk 1.1.16 -spare
```

Warning: Failed disk "1.1.16" may have aggregate labels and file system data present. In that case use of this command to release this disk as a spare disk, will lead to permanent loss of any file system data that may be on this disk, and may prevent recovery of a failed aggregate. Are you sure you want to continue with disk unfail? {y|h}:

## **storage disk updatefirmware**

**(DEPRECATED)** - Update disk firmware

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description



This command is deprecated and may be removed in a future release of Data ONTAP. Use the ["storage disk firmware update"](#) command.

The `storage disk updatefirmware` command updates the firmware on one or more disks.

You can download the latest firmware by using the [storage firmware download](#) command.

You can specify a list of one or more disks whose firmware is to be updated by using the `-disk` parameter, or you can update the firmware on all local disks by omitting the `-disk` parameter.

## Parameters

### **[-disk <disk path name>, ...] - Disk**

This specifies the disk or disks whose firmware is to be updated.

If you do not specify this option, all local disks' firmware is updated.

## Examples

The following example updates the firmware on all disks:

```
cluster1::> storage disk updatefirmware
```

## Related Links

- [storage disk firmware update](#)
- [storage firmware download](#)

## storage disk zerospares

Zero non-zeroed spare disks

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage disk zerospares` command zeroes all non-zeroed spare disks in all nodes or a specified node in the cluster. A node must be online to zero disks. This operation must be done before a disk can be reused in another aggregate. This version of ONTAP uses fast zeroing, which converts a spare disk from non-zeroed to zeroed without the long wait times required when physically zeroing a disk.

## Parameters

### **[-owner {<nodename>|local}] - Owner**

If this parameter is specified, only non-zeroed spares assigned to the specified node will be zeroed. Otherwise, all non-zeroed spares in the cluster will be zeroed.

## Examples

The following example zeroes all non-zeroed spares owned by a node named node4, using fast zeroing:

```
cluster1::> storage disk zerospares -owner node4
```

## storage disk error show

Display disk component and array LUN configuration errors.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage disk error show` command displays disk component and array LUN configuration errors.

### Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-uid <text>] - UID**

Displays the error information of the disk whose unique ID matches the value you specify. A disk unique identifier has the form:

`'20000000:875D4C32:00000000:00000000:00000000:00000000:00000000:00000000:00000000'`

**[-array-name <array name>] - Array Name**

Displays the errors of the storage array whose name you specified.

**[-node {<nodename>|local}] - Controller Name**

Displays the error information for the disks on the clustered node whose name you specified.

**[-disk <disk path name>] - Disk**

Displays detailed error information about the disk you specified.

**[-serial-number <text>] - Serial Number**

Displays the error information for the disk whose serial number you specified.

**[-error-id <integer>,...] - Error ID**

Displays the error information for the disks whose Error IDs match IDs you specified.

**[-error-type**

`{onepath|onedomain|control|foreign|toobig|toosmall|invalidblocksize|targetasympmap|deviceasympmap|failovermisconfig|unknown|netapp|fwdownrev|qualfail|diskfail|notailflashdisk}] - Error Type`

Displays all disk errors of the error types you specified, grouped by type.

- `onepath` = The array LUN is accessible only via a single path.
- `onedomain` = The array LUN is accessible only via a single fault domain.
- `control` = The array LUN cannot be used because it is a control device.

- **foreign** = The array LUN is marked as foreign and has some external SCSI reservations other than those from Data ONTAP.
- **toobig** = The array LUN exceeds the maximum array LUN size that Data ONTAP supports.
- **toosmall** = The array LUN is less than the minimum array LUN size that Data ONTAP supports.
- **invalidblocksize** = The array LUN is not a valid block size.
- **targetasymmap** = The array LUN is presented more than once on a single target port.
- **deviceassymmap** = The array LUN is presented with multiple IDs.
- **failovermisconfig** = The array LUN is configured with inconsistent failover methods.
- **unknown** = The array LUN from a storage array that is not supported by this version of Data ONTAP.
- **netapp** = A SAN front-end LUN from one Data ONTAP system that is presented as external storage to another Data ONTAP system.
- **fwdownrev** = The disk firmware is a down version.
- **qualfail** = The disk is not supported.
- **diskfail** = The disk is in a failed state.
- **notallflashdisk** = The disk does not match the All-Flash Optimized personality of the system.

## Examples

The following example displays configuration errors seen in the system:

```
cluster1::> storage disk error show
Disk          Error Type      Error Text
-----  -----
-----  -----
1.02.0      qualfail      This disk failed dynamic disk
qualification. Update the Disk Qualification Package.
```

## storage disk firmware revert

### Revert disk firmware

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage disk firmware revert` command reverts firmware on all disks or a specified list of disks on a node.

You can specify a list of one or more disks whose firmware is to be reverted by using the `-disk` parameter.

You can revert the firmware on all the disks owned by a node by using the `-node` parameter.

This command can make the disks inaccessible for up to five minutes after the start of its execution. Therefore, the network sessions that use the concerned node must be terminated before running the `storage disk firmware revert` command. This is particularly true for CIFS sessions that might be terminated when this

command is executed.

If you need to view the current firmware versions, use the `storage disk show -fields firmware-revision` command. The following example displays partial output from the `storage disk show -fields firmware-revision` command, where the firmware version for the disks is NA02:

```
cluster1::> storage disk show -fields firmware-revision
  disk      firmware-revision
  -----
  1.0.0      NA02
  1.0.1      NA02
  1.0.2      NA02
  1.0.3      NA02
  1.0.4      NA02
  1.0.5      NA02
```

The firmware files are stored in the `/mroot/etc/disk_fw` directory on the node. The firmware file name is in the form of "product-ID.revision.LOD". For example, if the firmware file is for Seagate disks with product ID `X225_ST336704FC` and the firmware version is NA01, the file name is `X225_ST336704FC.NA01.LOD`. If the node in this example contains disks with firmware version NA02, the `/mroot/etc/disk_fw/X225_ST336704FC.NA01.LOD` file is downloaded to every disk when you execute this command.

#### How to Revert the Firmware for an HA Pair in a Cluster

Use the following procedure to perform a revert on the disks in an HA environment:

- Make sure that the nodes are not in takeover or giveback mode.
- Download the latest firmware on both nodes by using the `storage firmware download` command.
- Revert the disk firmware on Node A's disks by entering the `storage disk firmware revert-node node-A` command.
- Wait until the `storage disk firmware revert` command completes on Node A, and then revert the firmware on Node B's disks by entering the `storage disk firmware revert-node node-B` command.

#### Parameters

**{ -disk <disk path name>, ... - Disk Name (privilege: advanced)}**

Specifies the disk or disks whose firmware is to be reverted.

**| -node {<nodename>|local} - Node Name (privilege: advanced) }**

Specifies the node name. The disk firmware will be reverted on all the disks owned by the node specified by this parameter.

#### Examples

- The following example reverts the firmware on all disks owned by cluster-node-01:

```
cluster1::*> storage disk firmware revert -node cluster-node-01

Warning: Disk firmware revert can be disruptive to the system. Reverts
involve
    power cycling all of the affected disks, as well as suspending
    disk
    I/O to the disks being reverted. This delay can cause client
    disruption. Takeover/giveback operations on a high-availability
    (HA)
    group will be delayed until the firmware revert process is
    complete.

    Disk firmware revert should only be done one node at a time. Disk
    firmware revert can only be performed when the HA group is
    healthy;
    they cannot be performed if the group is in takeover mode.

Do you want to continue with disk firmware revert? {y|n}: y

Info: Reverting disk firmware for disks on cluster-node-01.
```

- The following example reverts the firmware on disk 1.5.0 which is owned by node cluster-node-04:

```
cluster1::*> storage disk firmware revert -disk 1.5.0

Warning: Disk firmware revert can be disruptive to the system. Reverts
involve
    power cycling all of the affected disks, as well as suspending
    disk
    I/O to the disks being reverted. This delay can cause client
    disruption. Takeover/giveback operations on a high-availability
    (HA)
    group will be delayed until the firmware revert process is
    complete.

    Disk firmware revert should only be done one node at a time. Disk
    firmware revert can only be performed when the HA group is
    healthy;
    they cannot be performed if the group is in takeover mode.

Do you want to continue with disk firmware revert? {y|n}: y

Info: Reverting disk firmware for disks on cluster-node-04.
```

## Related Links

- [storage disk show](#)
- [storage firmware download](#)

## storage disk firmware show-update-status

Display disk firmware update status.

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage disk firmware show-update-status` command displays the state of the background disk firmware update process.

### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node <nodename>] - Node (privilege: advanced)**

Selects the node that matches this parameter value.

**[-num-waiting-download <integer>] - The Number of Disks Waiting to Download (privilege: advanced)**

Selects the nodes whose number of disks waiting to download by the BDFU process matches this parameter value.

**[-total-completion-estimate <integer>] - Estimated Duration to Completion (mins) (privilege: advanced)**

Selects the nodes whose Background Disk Firmware Update (BDFU) completion time estimate matches this parameter value. This indicates the amount of estimated time required for BDFU to complete the firmware update cycle.

**[-average-duration-per-disk <integer>] - Average Firmware Update Duration per Disk (secs) (privilege: advanced)**

Selects the nodes whose BDFU reports the average time required to update a single disk matches this parameter value. This indicates the average amount of time required by each disk drive.

**[-unable-to-update <disk path name>,...] - List of Disks with a Failed Update (privilege: advanced)**

Selects the nodes whose unable to update disk list matches this parameter value. This is a list of disks that failed to update the firmware.

## **[-update-status {off|running|idle}] - Background Disk Firmware Update Status (privilege: advanced)**

Selects the nodes whose BDFU process status matches this parameter value. Possible values are:

- off - The BDFU process is off.
- running - The BDFU process is on and currently running.
- idle - The BDFU process is on and is currently idle.

### **Examples**

```
cluster1::>*> storage disk firmware show-update-status
                Number      Average      Total
                Update      Waiting      Duration Completion
                Node        State       Download /Disk (Sec) Est. (Min) Unable to
Update
-----
-----
node1          running      2           120          4 1.3.3
node2          idle        0           120          0 -
node3          off         0           120          0 -
```

## **storage disk firmware update**

### **Update disk firmware**

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### **Description**

Use the **storage disk firmware update** command to manually update firmware on all disks or a specified list of disks on a node. However, the recommended way to update disk firmware in a cluster is to enable automatic background firmware update by enabling the **-bkg-firmware-update** parameter for all of the nodes in the cluster. You can do this by entering the [storage disk option modify](#)-node \*-bkg-firmware-update *on* command.

You can download the latest firmware on the node by using the [storage firmware download](#) command.

You can specify a list of one or more disks whose firmware is to be updated by using the **-disk** parameter.

You can update the firmware on all the disks owned by a node by using the **-node** parameter.

This command can make the disks inaccessible for up to five minutes after the start of its execution. Therefore, the network sessions that use the concerned node must be terminated before running the **storage disk firmware update** command. This is particularly true for CIFS sessions that might be terminated when this command is executed.

The firmware is automatically downloaded to disks, which report previous versions of the firmware. For information on automatic firmware update downloads, see "Automatic versus Manual Firmware Download".

If you need to view the current firmware versions, use the `storage disk show -fields firmware-revision` command. The following example displays partial output from the `storage disk show -fields firmware-revision` command, where the firmware version for the disks is NA01:

```
cluster1::> storage disk show -fields firmware-revision
  disk      firmware-revision
  -----
1.0.0      NA01
1.0.1      NA01
1.0.2      NA01
1.0.3      NA01
1.0.4      NA01
1.0.5      NA01
```

The firmware files are stored in the `/mroot/etc/disk_fw` directory on the node. The firmware file name is in the form of "product-ID.revision.LOD". For example, if the firmware file is for Seagate disks with product ID `X225_ST336704FC` and the firmware version is `NA02`, the filename is `X225_ST336704FC.NA02.LOD`. The revision part of the file name is the number against which the node compares each disk's current firmware version. If the node in this example contains disks with firmware version `NA01`, the `/mroot/etc/disk_fw/X225_ST336704FC.NA02.LOD` file is used to update every eligible disk when you execute this command.

#### Automatic versus Manual Firmware Download

The firmware is automatically downloaded to those disks that report previous versions of firmware following a system boot or disk insertion. Note that:

- A manual download is a disruptive operation that makes disks inaccessible for up to five minutes after the download is started. Network sessions that use the node must be terminated before running the `storage disk firmware update` command.
- The firmware is not automatically downloaded to the node's partner node in an HA pair.
- The firmware is not automatically downloaded to unowned disks on nodes configured to use software-based disk ownership.
- The `bkg-firmware-update` parameter controls how the automatic firmware download feature works:
  - If the `bkg-firmware-update` parameter is set to `off`, then the `storage disk firmware update` will update the firmware on the drives in parallel.
  - If the `bkg-firmware-update` parameter is set to `on`, then the `storage disk firmware update` will update spares and filesystem disks in a nondisruptive manner in the background after boot. Firmware downloads for these disks will be done sequentially by temporarily taking them offline one at a time for the duration of the download. After the firmware is updated, the disk will be brought back online and restored to its normal operation.

During an automatic download to an HA environment, the firmware is not downloaded to the disks owned by the HA partner.

When you use the `storage disk firmware update` command, the firmware is:

- Updated on every disk regardless of whether it is on the A-loop, the B-loop, or in an HA environment.

- If the node is configured in a software-based disk ownership system, only disks owned by this node are updated.

During an automatic firmware download in a MetroCluster™ environment, the firmware is not downloaded to the disks owned by the partner cluster. During both manual and automatic firmware download in a MetroCluster-over-IP environment, the firmware is not downloaded to any remote disks located at the partner cluster while Disaster Recovery is in progress.

Follow the instructions in "How to Update the Firmware for an HA Pair in a Cluster" to ensure that the updating process is successful. Data ONTAP supports redundant path configurations for disks in a non-HA configuration. The firmware is automatically downloaded to disks on the A-loop or B-loop of redundant configurations that are not configured in an HA pair and are not configured to use software-based disk ownership.

#### Automatic Background Firmware Update

The firmware can be updated in the background so that the firmware update process does not impact the clients. This functionality is controlled with the `bkg-firmware-update` parameter. You can modify the parameter by using the CLI `storage disk option modify -node node_name -bkg-firmware-update on|off` command. The default value for this parameter is "on".

When disabled or set to "off", storage disk firmware update will update the firmware in automated mode. This means that all disks which had older firmware revision will be updated regardless of whether they are spare or filesystem disks.

When enabled or set to "on", the background storage disk firmware update will update firmware in automated mode only on disks that can be successfully taken offline from active filesystem RAID groups and from the spare pool. To ensure a faster boot process, the firmware is not downloaded to spares and filesystem disks at boot time.

This provides the highest degree of safety available, without the cost of copying data from each disk in the system twice. Disks are taken offline one at a time and then the firmware is updated on them. The disk is brought online after the firmware update and a mini/optimized reconstruct happens for any writes, which occurred while the disk was offline. Background disk firmware update will not occur for a disk if its containing RAID group or the volume is not in a normal state (for example, if the volume/plex is offline or the RAID group is degraded). However, due to the continuous polling nature of background disk firmware update, firmware updates will resume after the RAID group/plex/volume is restored to a normal mode. Similarly, background disk firmware updates are suspended for the duration of any reconstruction within the system.

#### How to Update the Firmware for an HA Pair in a Cluster

The best way to update the firmware in a cluster with HA pairs is to use automatic background firmware update by enabling the option `bkg-firmware-update` parameter for each node. Enable the `-bkg-firmware-update` parameter on all the nodes by entering the `storage disk option modify -node node_name -bkg-firmware-update on` command. Alternatively, use the following procedure to successfully perform a manual update on the disks in an HA environment:

- Make sure that the nodes are not in takeover or giveback mode.
- Download the latest firmware on both the nodes by using the `storage firmware download` command.
- Install the new disk firmware on Node A's disks by entering the `storage disk firmware update -node node-A` command.
- Wait until the `storage disk firmware update` command completes on Node A, and then install the new disk firmware on Node B's disks by entering the `storage disk firmware update -node node-B` command.

*B*`` command.

## Parameters

**{ -disk <disk path name>, ... - Disk (privilege: advanced)**

Specifies the disk or disks whose firmware is to be updated.

**| -node {<nodename>|local} - node (privilege: advanced) }**

Specifies the node name. The disk firmware will be updated on all the disks owned by the node specified by this parameter.

## Examples

- The following example updates the firmware on all disks owned by cluster-node-01:

```
cluster1::*> storage disk firmware update -node cluster-node-01

Warning: Disk firmware updates can be disruptive to the system. Updates
involve
      power cycling all of the affected disks, as well as suspending
disk
      I/O to the disks being updated. This delay can cause client
      disruption. Takeover/giveback operations on a high-availability
(HA)
      group will be delayed until the firmware update process is
complete.
      Disk firmware updates should only be done one node at a time.

Disk
      firmware updates can only be performed when the HA group is
healthy;
      they cannot be performed if the group is in takeover mode.

Do you want to continue with disk firmware updates? {y|n}: y

Info: Updating disk firmware for disks on cluster-node-01.
```

- The following example updates the firmware on disk 1.5.0 which is owned by node cluster-node-04:

```
cluster1::*> storage disk firmware update -disk 1.5.0

Warning: Disk firmware updates can be disruptive to the system. Updates
involve
          power cycling all of the affected disks, as well as suspending
disk
          I/O to the disks being updated. This delay can cause client
disruption. Takeover/giveback operations on a high-availability
(HA)
          group will be delayed until the firmware update process is
complete.
          Disk firmware updates should only be done one node at a time.

Disk
          firmware updates can only be performed when the HA group is
healthy;
          they cannot be performed if the group is in takeover mode.

Do you want to continue with disk firmware updates? {y|n}: y

Info: Updating disk firmware for disks on cluster-node-04.
```

## Related Links

- [storage disk option modify](#)
- [storage firmware download](#)
- [storage disk show](#)

## storage disk option modify

### Modify disk options

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage disk option modify` command modifies the background firmware update setting, automatic copy setting, controls automatic disk assignment of all disks assigned to a specified node, or modifies the policy of automatic disk assignment of unowned disks.

### Parameters

#### **-node {<nodename>|local} - Node**

This parameter specifies the node that owns the disks whose options are to be modified.

#### **[-bkg-firmware-update {on|off}] - Background Firmware Update**

This parameter specifies whether firmware updates run as a background process. The default setting is `on` , which specifies that firmware updates to spare disks and file system disks is performed nondisruptively via

a background process. If the option is turned off, automatic firmware updates occur at system startup or during disk insertion.

#### **[-autocopy {on|off}] - Auto Copy**

This parameter specifies whether data is to be automatically copied from a failing disk to a spare disk in the event of a predictive failure. The default setting is `on`. It is sometimes possible to predict a disk failure based on a pattern of recovered errors that have occurred. In such cases, the disk reports a predictive failure. If this option is set to `on`, the system initiates Rapid RAID Recovery to copy data from the failing disk to an available spare disk. When data is copied, the disk is marked as failed and placed in the pool of broken disks. If a spare is not available, the node continues to use the disk until it fails. If the option is set to `off`, the disk is immediately marked as failed and placed in the pool of broken disks. A spare is selected and data from the missing disk is reconstructed from other disks in the RAID group. The disk does not fail if the RAID group is already degraded or is being reconstructed. This ensures that a disk failure does not lead to the failure of the entire RAID group.

#### **[-autoassign {on|off}] - Auto Assign**

This parameter specifies whether automatic assignment of unowned disks is enabled or disabled. The default setting is `on`. This parameter is used to set both a node-specific and a cluster-wide disk option.

#### **[-autoassign-policy {default|bay|shelf|stack}] - Auto Assignment Policy**

This parameter defines the granularity at which auto assign should work. This option is ignored if the `-autoassign` option is `off`. Auto assignment can be done at the stack/loop, shelf, or bay level. The possible values for the option are `default`, `stack`, `shelf`, and `bay`. The default value is platform dependent. It is `stack` for all non-entry platforms and single-node systems, whereas it is `bay` for entry-level platforms.

### **Examples**

The following example sets the background firmware update setting to `on` for all disks belonging to a node named `node0`:

```
cluster1::> storage disk option modify -node node0 -bkg-firmware-update on
```

The following example shows how to enable auto assignment for the disks on `node1`:

```
cluster1::> storage disk option modify -node node1 -autoassign on
cluster1::> storage disk option show
Node          BKg. FW. Upd.  Auto Copy      Auto Assign      Auto Assign
Policy
-----
-----
node1        on            on            on            default
node2        on            on            off           default
2 entries were displayed.
```

The following example shows how to modify the auto assignment policy on `node1`:

```

cluster1::> storage disk option modify -node node1 -autoassign-policy bay
cluster1::> storage disk option show
Node          BKg. FW. Upd.  Auto Copy      Auto Assign      Auto Assign
Policy
-----
-----
node1          on            on            on            bay
node2          on            on            off           default
2 entries were displayed.

```

## storage disk option show

Display a list of disk options

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage disk option show` command displays the settings of the following disk options:

- Background firmware update
- Automatic copying of data to a spare disk in the event of a predictive failure
- Automatic assignment of disks
- Policy that governs automatic assignment of unowned disks

### Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `-fields ?` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the node that owns the disks. If this parameter is not specified, the command displays information about the disk options on all the nodes.

**[-bkg-firmware-update {on|off}] - Background Firmware Update**

Selects the disks that match this parameter value.

**[-autocopy {on|off}] - Auto Copy**

Selects the disks that match this parameter value.

**[-autoassign {on|off}] - Auto Assign**

Displays the auto assignment status of unowned disks. The default value is `on` .

## **[-autoassign-policy {default|bay|shelf|stack}] - Auto Assignment Policy**

Selects the disks that match the automatic assignment policy value:

- Default
- Stack/loop
- Shelf
- Bay

### **Examples**

The following example displays disk-option settings for disks owned by all nodes in the cluster:

```
cluster1::> storage disk option show
Node          BKg. FW. Upd.  Auto Copy      Auto Assign      Auto Assign
Policy
-----
-----
node0          on           on           on           default
node1          on           on           on           stack
node2          on           on           on           bay
node3          on           on           on           bay
4 entries were displayed.
```

## **storage dqp commands**

### **storage dqp show**

Display Disk Qualification Package details

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### **Description**

The `storage dqp show` command displays information about the Disk Qualification Package (DQP). The command displays the following information:

- Node Name
- Package Date
- File Version
- File Name
- Drive Record Count
- Drive Alias Record Count
- Device Class Record Count
- System Class Record Count

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Displays DQP information on the specified node.

**[-package-date <text>] - Package Date**

Selects DQP information with the specified package date.

**[-file-version <text>] - File Version**

Selects DQP information with the specified file version.

**[-filename <text>] - File Name**

Selects DQP information with the specified file name.

**[-drive-records <integer>] - Drive Record Count**

Selects DQP information with the specified drive record count.

**[-alias-records <integer>] - Alias Record Count**

Selects DQP information with the specified drive alias record count.

**[-device-records <integer>] - Device Record Count**

Selects DQP information with the specified device class record count.

**[-system-records <integer>] - System Record Count**

Selects DQP information with the specified system class record count.

## Examples

The following example displays the brief version of Disk Qualification Package details:

```
cluster1::> storage dqp show
      Node          Package Date      Version
      -----  -----
cluster1-01    20180907      3.17
cluster1-02    20180907      3.17
2 entries were displayed.
```

The following example displays the `-instance` version of Disk Qualification Package details:

```
cluster1::> storage dqp show -instance
Node: cluster1-01
    Package Date: 20180907
    Version: 3.17
    File Name: qual_devices_v3
    Drive Record Count: 626
    Alias Record Count: 196
    Device Record Count: 28
    System Record Count: 3
Node: cluster1-02
    Package Date: 20180907
    Version: 3.17
    File Name: qual_devices_v3
    Drive Record Count: 626
    Alias Record Count: 196
    Device Record Count: 28
    System Record Count: 3
2 entries were displayed.
```

## storage encryption commands

### storage encryption disk destroy

Cryptographically destroy a self-encrypting disk

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The *storage encryption disk destroy* command cryptographically destroys a self-encrypting disk (SED), making it incapable of performing I/O operations. This command performs the following operations:

- Employs the inherent erase capability of SEDs to cryptographically sanitize the disk
- Permanently locks the disk to prevent further data access
- Changes the data and FIPS authentication keys to random values that are not recorded except within the SED.

Use this command with extreme care. The only mechanism to restore the disk to usability (albeit without the data) is the [storage encryption disk revert-to-original-state](#) operation that is available only on disks that have the physical secure ID (PSID) printed on the disk label.

The destroy command requires you to enter a confirmation phrase before proceeding with the operation.

The command releases the cluster shell after launching the operation. Monitor the output of the [storage encryption disk show-status](#) command for command completion.

Upon command completion, remove the destroyed SED from the system.

## Parameters

### **-disk <disk path name> - Disk Name**

This parameter specifies the name of the disk you want to cryptographically destroy. See the man page for the `storage disk modify` command for information about disk-naming conventions.

### **[-force-all-states <true>] - Destroy All Matching Disks**

When this parameter is *false* or not specified, the operation defaults to spare and broken disks only, as reported in the output of the `storage disk show` command. When you specify this parameter as *true*, it allows you to cryptographically destroy all matching disk names regardless of their state, including those in active use in aggregates. This allows a quick destroy of all system disks if you use the `-disk` parameter with the asterisk wildcard (\*). If you destroy active disks, the nodes might not be able to continue operation, and might halt or panic.

## Examples

The following command cryptographically destroys the disk 1.10.20:

```
cluster1::> storage encryption disk destroy 1.10.20
```

```
Warning: This operation will cryptographically destroy 1 spare or broken
self-encrypting disks on 1 node.
```

```
You cannot reuse destroyed disks unless you revert
them to their original state using the PSID value.
```

```
To continue, enter
  destroy disk
:destroy disk
```

```
Info: Starting destroy on 1 disk.
```

```
View the status of the operation by using the
"storage encryption disk show-status" command.
```

```
cluster1::>
```

If you do not enter the correct confirmation phrase, the operation is aborted:

```
cluster1::> storage encryption disk destroy 1.10.2*
```

```
Warning: This operation will cryptographically destroy 5 spare or broken
self-encrypting disks on 1 node.
You cannot reuse destroyed disks unless you revert
them to their original state using the PSID value.
To continue, enter
    destroy disk
:yes
No disks destroyed.
```

```
cluster1::>
```

The following command quickly cryptographically destroys all system disks, including those in active use in aggregates and shared devices:

```
cluster1::> storage encryption disk destroy -force-all-states -disk *
```

```
Warning: This operation will cryptographically destroy 96
self-encrypting disks on 4 nodes.
To continue, enter
    destroy disk
:destroy disk
```

```
Info: Starting destroy on 96 disks.
```

```
View the status of the operation by using the
xref:{relative_path}storage-encryption-disk-show-status.html [storage
encryption disk show-status] command.
```

```
cluster1::>
```

## Related Links

- [storage encryption disk revert-to-original-state](#)
- [storage encryption disk show-status](#)
- [storage disk show](#)

## storage encryption disk modify

Modify self-encrypting disk parameters

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The storage encryption disk modify command changes the data protection parameters of self-encrypting disks (SEDs) and FIPS-certified SEDs (FIPS SEDs); it also modifies the FIPS-compliance AK (FIPS AK) of FIPS SEDs. The current data AK and FIPS AK of the device are required to effect changes to the respective AKs and FIPS compliance. The current and new AKs must be available from the key servers or onboard key management.

The command releases the cluster shell after launching the operation. Monitor the output of the [storage encryption disk show-status](#) command for command completion.

 To properly protect data at rest on a FIPS SED and place it into compliance with its FIPS certification requirements, set both the Data and FIPS AKs to a value other than the device's default key; depending on the device type, the default may be manufacture secure ID (MSID), indicated by a key ID with the special value `0x0`, or a null key represented by a blank key ID. Verify the key IDs by using the [storage encryption disk show](#) and [storage encryption disk show -fips](#) commands.

## Parameters

### **-disk <disk path name> - Disk Name**

This parameter specifies the name of the SED or FIPS SED that you want to modify.

### **{ [-data-key-id <text>] - Key ID of the New Data Authentication Key**

This parameter specifies the key ID associated with the data AK that you want the SED to use for future authentications. When the provided key ID is the MSID, data at rest on the SED is not protected from unauthorized access. Setting this parameter to a non-MSID value automatically engages the power-on-lock protections of the device, so that when the device is power-cycled, the system must authenticate with the device using the AK to reenable I/O operations. You cannot specify the null default key; use MSID instead.

### **| [-fips-key-id <text>] - Key ID of the New Authentication Key for FIPS Compliance }**

This parameter specifies the key ID associated with the FIPS AK that you want the FIPS SED to apply to SED credentials other than the one that protects the data. When the value is not the MSID, these credentials are changed to the indicated AK, and other security-related items are set to conform to the FIPS certification requirements ("FIPS compliance mode") of the device. You may set the `-fips-key-id` to any one of the key IDs known to the system. The FIPS key ID may, but does not have to, be the same as the data key ID parameter.

## Examples

The following command changes both the AK and the power-cycle protection to values that protect the data at rest on the disk. Note that the `-data-key-id` and `-fips-key-id` parameters require one of the key IDs that appear in the output of the [security key-manager query](#) command.

```
cluster1::> storage encryption disk modify -data-key-id  
6A1E21D80000000001000000000000000F5A1EB48EF26FD6A8E76549C019F2350 -disk  
2.10.*
```

Info: Starting modify on 14 disks.

View the status of the operation by using the  
storage encryption disk show-status command.

The following command changes the FIPS AK and sets the device into FIPS-compliance mode. Note that the `-fips-key-id` parameter requires one of the key IDs that appear in the output of the [security key-manager query](#) command.

```
cluster1::> storage encryption disk modify -fips-key-id  
6A1E21D80000000001000000000000005A1FB4EE8F62FD6D8AE6754C9019F35A 2.10.*
```

Info: Starting modify on 14 disks.

View the status of the operation by using the  
storage encryption disk show-status command.

## Related Links

- [storage encryption disk show-status](#)
- [storage encryption disk show](#)
- [security key-manager query](#)

## storage encryption disk revert-to-original-state

Revert a self-encrypting disk to its original, as-manufactured state

**Availability:** This command is available to *cluster* administrators at the `admin` privilege level.

### Description

Some self-encrypting disks (SEDs) are capable of an operation that restores them as much as possible to their as-manufactured state. The `storage encryption disk revert-to-original-state` command invokes this special operation that is available only in SEDs that have the physical secure ID (PSID) printed on their labels.

The PSID is unique to each SED, meaning the command can revert only one SED at a time. The disk must be in a "broken" or "spare" state as shown by the output of the `storage disk show` command.

The operation in the SED accomplishes the following changes:

- Sanitizes all data by changing the disk encryption key to a new random value
- Sets the data authentication key (AK) and FIPS AK to the default values
- Resets the data locking controls

- Resets the power-on lock state to *false*
- Initializes other vendor-unique encryption-related parameters

The command releases the cluster shell after launching the operation. Monitor the output of the [storage encryption disk show-status](#) command for command completion.

When the operation is complete, it is possible to return the SED to service using the [storage disk unfail](#) command in *advanced* privilege mode. To do so, you might also need to reestablish ownership of the SED using the [storage disk assign](#) command.

## Parameters

### **-disk <disk path name> - Disk Name**

The name of the SED to be reverted to its as-manufactured state. See the man page for the [storage disk modify](#) command for information about disk-naming conventions.

### **-psid <text> - Physical Secure ID**

The PSID printed on the SED label.

## Examples

The following command shows a SED being returned to its as-manufactured state:

```
cluster1::> storage encryption disk revert-to-original-state -disk 01.10.0
-psid AC65PYF8CG45YZABUQJKM98WV2VZGRLD
```

## Related Links

- [storage disk show](#)
- [storage encryption disk show-status](#)
- [storage disk unfail](#)
- [storage disk assign](#)

## storage encryption disk sanitize

Cryptographically sanitize a self-encrypting disk

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The [storage encryption disk sanitize](#) command cryptographically sanitizes one or more self-encrypting disks (SEDs), making the existing data on the SED impossible to retrieve. This operation employs the inherent erase capability of SEDs to perform all of the following changes:

- Sanitizes all data by changing the disk encryption key to a new random value
- Sets the data authentication key (AK) to the default AK (manufacture secure ID/MSID or null, depending on the device type)

- Unlocks the data band
- Resets the power-on lock state to *false*

There is no method to restore the disk encryption key to its previous value, meaning that you cannot recover the data on the SED. Use this command with extreme care.

The sanitize command requires you to enter a confirmation phrase before proceeding with the operation.

The command releases the cluster shell after launching the operation. Monitor the output of the [storage encryption disk show-status](#) command for command completion.

When the operation is complete, it is possible to return the SED to service using the [storage disk unfail](#) command in *advanced* privilege mode. To do so, you might also need to reestablish ownership of the SED using the [storage disk assign](#) command.

## Parameters

### **-disk <disk path name> - Disk Name**

This parameter specifies the name of the SEDs you want to cryptographically sanitize. See the man page for the [storage disk modify](#) command for information about disk-naming conventions.

### **[-force-all-states <true>] - Sanitize All Matching Disks**

When this parameter is *false* or not specified, the operation defaults to spare and broken disks only, as reported in the output of the [storage disk show](#) command. When you specify this parameter as *true*, it allows you to cryptographically sanitize all matching disk names regardless of their state, including those in active use in aggregates. This allows a quick erasure of all system data if you use the *-disk* parameter with the asterisk wildcard (\*). If you sanitize active disks, the nodes might not be able to continue operation, and might halt or panic.

## Examples

The following command sanitizes the disk 1.10.20:

```
cluster1::> storage encryption disk sanitize 1.10.20

Warning: This operation will cryptographically sanitize 1 spare or broken
self-encrypting disk on 1 node.
To continue, enter
    sanitize disk
: sanitize disk

Info: Starting sanitize on 1 disk.
      View the status of the operation using the
      xref:{relative_path}storage-encryption-disk-show-status.html [storage
      encryption disk show-status] command.

cluster1::>
```

If you do not enter the correct confirmation phrase, the operation is aborted:

```
cluster1::> storage encryption disk sanitize 1.10.2*
Warning: This operation will cryptographically sanitize 5 spare or broken
self-encrypting disks on 1 node.
To continue, enter
    sanitize disk
:yes
No disks sanitized.

cluster1::>
```

The following command quickly cryptographically sanitizes all system disks, including those in active use in aggregates and shared devices:

```
cluster1::> storage encryption disk sanitize -force-all-states -disk *
Warning: This operation will cryptographically sanitize 96
self-encrypting disks on 4 nodes.
To continue, enter
    sanitize disk
:sanitize disk

Info: Starting sanitize on 96 disks.
      View the status of the operation by using the
      xref:{relative\_path}storage-encryption-disk-show-status.html [storage
      encryption disk show-status] command.

cluster1::>
```

## Related Links

- [storage encryption disk show-status](#)
- [storage disk unfail](#)
- [storage disk assign](#)
- [storage disk show](#)

## storage encryption disk show-status

Display status of disk encryption operation

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage encryption disk show-status` command displays the results of the latest `destroy`,

modify, or sanitize operation of the storage encryption disk command family. Use this command to view the progress of these operations on self-encrypting disks (SEDs).

## Parameters

{ [-fields <fieldname>,...]

If you specify the -fields <fieldname>, ... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-node <nodename>] - Node Name**

If you specify this parameter, the command displays disk encryption status for the nodes that match this parameter.

**[-is-fips-support {true|false}] - Node Supports FIPS Disks**

If you specify this parameter, the command displays disk encryption status for the nodes that match this parameter (true means the node supports FIPS-certified self-encrypting drives).

**[-latest-op <Storage Disk Encryption Operation>] - Latest Operation Requested**

If you specify this parameter, the command displays disk encryption status for the nodes with a most recent storage encryption disk operation that matches this parameter (one of destroy, modify, revert-to-original-state, sanitize, or unknown).

**[-op-start-time <MM/DD/YYYY HH:MM:SS>] - Operation Start Time**

Selects the nodes with operation start times that match this parameter.

**[-op-execute-time <integer>] - Execution Time in Seconds**

If you specify this parameter, the command displays disk encryption status for the nodes with operation execution time that matches this parameter. The operation may be partial or completed.

**[-disk-start-count <integer>] - Number of Disks Started**

If you specify this parameter, the command displays disk encryption status for the nodes that started this number of SEDs in their latest operation.

**[-disk-done-count <integer>] - Number of Disks Done**

Selects the nodes that report this number of SEDs having completed the latest operation, successfully or not.

**[-disk-success-count <integer>] - Number of Disks Successful**

If you specify this parameter, the command displays disk encryption status for the nodes that report this number of SEDs that successfully completed the latest operation. When the operation is finished, if the success count is not the same as the started count, some additional detail is available using the -instance or -node parameters.

**[-disk-no-key-id-count <integer>] - Number of Disks with Key ID Not Found**

If you specify this parameter, the command displays disk encryption status for the nodes that report this number of SEDs that failed the latest operation because Data ONTAP could not find the Key IDs associated with the required authentication key of the SED.

**[-disk-no-authent-count <integer>] - Number of Disks Not Authenticated**

If you specify this parameter, the command displays disk encryption status for the nodes that report this number of SEDs that failed the latest operation because the identified Authentication Key could not authenticate with the SED.

**[-op-sequence-count <integer>] - Sequence Count of Latest Operation**

If you specify this parameter, the command displays disk encryption status for that nodes that match the value list.

## Examples

When no operation has been requested since node boot, the status for that node is empty. If you enter a node name, the output is in the same format as for the **-instance** parameter.

```
cluster1::> storage encryption disk show-status -node node
Node Name: node
  Node Supports FIPS-certified Self-Encrypting Disks: true
  Latest Operation Requested: unknown
  Operation Start Time: -
  Execution Time in Seconds: -
  Number of Disks Started: -
  Number of Disks Done: -
  Number of Disks Successful: -
  Number of Disks with Key ID Not Found: -
  Number of Disks Not Authenticated: -
```

Once an operation begins, the status is dynamic until all devices have completed. When disks are modified, sanitized, or destroyed, sequential executions of `storage encryption disk show-status` appear as in this example that shows the progress of a modify operation on three SEDs on each node of a two-node cluster:

```
cluster1::> storage encryption disk show-status
      SED      Latest      Start          Execution  Disks  Disks
Disk
Node   Support Request  Timestamp      Time (sec)  Begun  Done
Successful
-----
-----
node   true    modify   9/22/2014 13:58:53      4        3      0
0
node1  true    modify   9/22/2014 13:58:53      4        3      0
0
```

```
cluster1::> storage encryption disk show-status
      SED      Latest      Start          Execution  Disks  Disks
Disk
Node   Support Request  Timestamp      Time (sec)  Begun  Done
Successful
-----
-----
node   true    modify   9/22/2014 13:58:53      7        3      3
3
node1  true    modify   9/22/2014 13:58:53      7        3      3
3
```

## storage encryption disk show

Display self-encrypting disk attributes

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage encryption disk show` command displays information about encrypting drives. When no parameters are specified, the command displays the following information about all encrypting drives:

- Disk name
- The protection mode of the device
- The key ID associated with the data authentication key ("data AK")

In MetroCluster systems, the information is valid from the cluster that owns the drive, or from the DR cluster when in switchover mode. If information is not available, perform the `show` command from the cluster partner.

You can use the following parameters together with the `-disk` parameter to narrow the selection of displayed drives or the information displayed about them.

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-fips ]

If you specify this parameter, the command displays the key ID associated with the FIPS-compliance authentication key ("FIPS AK") instead of the data key ID.

| [-instance ] }

If you specify this parameter, the command displays detailed disk information about all disks, or only those specified by a `-disk` parameter.

**[-disk <disk path name>] - Disk Name**

If you specify this parameter, the command displays information about the specified disks. If you specify a single disk path name, the output is the same as when you use the `-instance` parameter. See the man page for the `storage disk modify` command for information about disk-naming conventions. Default is all self-encrypting disks.

**[-container-name <text>] - Container Name**

This parameter specifies the container name associated with an encrypting drive. If you specify an aggregate name or other container name, only the encrypting drives in that container are displayed. See the man page for the `storage disk show` command for a description of the container name. Use the `storage aggregate show-status` and `storage disk show` commands to determine which aggregates the drives are in.

**[-container-type {aggregate | broken | foreign | labelmaint | maintenance | mediator | remote | shared | spare | unassigned | unknown | unsupported}] - Container Type**

This parameter specifies the container type associated with an encrypting drive. If you specify a container type, only the drives with that container type are displayed. See the man page for the `storage disk show` command for a description of the container type.

**[-data-key-id <text>] - Key ID of the Current Data Authentication Key**

This parameter specifies the key ID associated with the data AK that the encrypting drive requires for authentication with its data-protection authorities. The special key ID `0x0` indicates that the current data AK of the drive is the default manufacture secure ID (MSID) that is not secret. Some devices employ an initial null default AK that appears as a blank data-key-id; you cannot specify a null data-key-id value. To properly protect data at rest on the device, modify the data AK using a key ID that is not a default value (MSID or null). When you modify the data AK with a non-MSID key ID, the system automatically sets the device's power-on lock enable control so that authentication with the data AK is required after a device power-cycle. Use `storage encryption disk modify`-`data-key-id key-id` to protect the data. Use `storage encryption disk modify`-`fips-key-id key-id` to place the drives into FIPS-compliance mode.

**[-fips-key-id <text>] - Key ID of the Current FIPS Authentication Key**

This parameter specifies the key ID associated with the FIPS authentication key ("FIPS AK") that the system must use to authenticate with FIPS-compliance authorities in FIPS-certified drives. This parameter may not be set to a non-MSID value in drives that are not FIPS-certified.

**[-is-power-on-lock-enabled {true|false}] - Is Power-On Lock Protection Enabled?**

This parameter specifies the state of the control that determines whether the encrypting drive requires

authentication with the data AK after a power-cycle. The system enables this control parameter automatically when you use the `storage encryption disk modify`-data-key-id command to set the data AK to a value other than the default AK. Data is protected only when this parameter is *true* and the data AK is not a default. Compare with the values of the -protection-mode parameter below.

#### **[-protection-mode <text>] - Mode of SED Data and FIPS-Compliance Protection**

The protection mode that the drive is in:

- open - data is unprotected; drive is not in FIPS-compliance mode
- data - data is protected; drive is not in FIPS-compliance mode
- part - data is unprotected; drive is otherwise in FIPS-compliance mode
- full - data is protected; drive is in FIPS-compliance mode
- miss - protection mode information is not available

#### **[-type {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}] - Disk Type**

This parameter selects the drive type to include in the output.

#### **[-control-standard <text>] - Control Standard**

This parameter specifies the industry standard for control of encrypting drives that the drive implements.

#### **[-compliance-standard <text>] - Compliance Standard**

This parameter specifies the industry compliance standard, if any, that the drive is certified as adhering to.

#### **[-overall-security <text>] - Overall Security**

This parameter specifies the drive's certified security level as defined in the compliance-standard, if the drive is certified to a compliance standard.

### **Examples**

The following command displays information about all encrypting drives:

```
cluster1::> storage encryption disk show
Disk      Mode Data Key ID
----- -----
0.0.0    open 0x0
0.0.1    part 0x0
0.0.2    data
0A9C9CFC0000000001000000000000345CFD1BAD310CA8EDB377D439FB5C9A
1.10.0   open
0A53ED2A0000000001000000000000BEDC1B27AD3F0DB8891375AED2F34D0B
1.10.1   part
0A9C9CFC0000000001000000000000345CFD1BAD310CA8EDB377D439FB5C9A
1.10.2   full
0A9C9CFC0000000001000000000000345CFD1BAD310CA8EDB377D439FB5C9A
[...]
```

Note in the example that only disk 1.10.2 is fully protected with FIPS mode, power-on-lock enable, and an AK that is not the default MSID or a null key.

The following command displays information about the protection mode and FIPS key ID for all encrypting drives:

```
cluster1::> storage encryption disk show -fips
Disk      Mode FIPS-Compliance Key ID
----- -----
0.0.0    open 0x0
0.0.1    part
0A53ED2A00000000010000000000000C1B27AD3F0DB8891375AED2F34D0BBED
0.0.2    data 0x0
1.10.0   open
0A53ED2A00000000010000000000000BEDC1B27AD3F0DB8891375AED2F34D0B
1.10.1   part
0A9C9CFC00000000010000000000000345CFD1BAD310CA8EDB377D439FB5C9A
1.10.2   full
0A9C9CFC00000000010000000000000BEDC1B27AD3F0DB8891375AED2F34D0B
[...]
```

Note again that only disk 1.10.2 is fully protected with FIPS-compliance mode set, power-on-lock enabled, and a data AK that is not the default MSID or a null key.

The following command displays the individual fields for disk 1.10.2:

```
cluster1::> storage encryption disk show -disk 1.10.2
Disk Name: 1.10.2
                                Container Name: aggr0
                                Container Type: shared
                                Is Drive FIPS-certified?: true
Key ID of the Current Data Authentication Key:
0A9C9CFC00000000010000000000000345CFD1BAD310CA8EDB377D439FB5C9A
Key ID of the Current FIPS Authentication Key:
0A9C9CFC00000000010000000000000BEDC1B27AD3F0DB8891375AED2F34D0B
                                Is Power-On Lock Protection Enabled?: true
Mode of Data and FIPS-Compliance Protection: full
                                Drive Type: SSD
                                Control Standard: TCG Enterprise
                                Compliance Standard: FIPS 140-2
                                Overall Security: Level 2
```

## Related Links

- [storage disk show](#)
- [storage aggregate show-status](#)
- [storage encryption disk modify](#)

# storage errors commands

## storage errors show

Display storage configuration errors.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage errors show` command displays configuration errors with back end storage arrays.

### Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-uid <text>] - UID**

Selects the disks that match this parameter value.

**[-array-name <array name>] - Array Name**

Selects the disks that have the specified name for the storage array that is connected to the cluster.

**[-node {<nodename>|local}] - Controller Name**

Selects the disks that match this parameter value.

**[-disk <disk path name>] - Disk**

Selects the disks that match this parameter value.

**[-serial-number <text>] - Serial Number**

Selects the disks that match this parameter value.

**[-error-id <integer>,...] - Error ID**

Selects the disks with error-id values that match this parameter value.

**[-error-type**

`{onepath|onedomain|control|foreign|toobig|toosmall|invalidblocksize|targetasympmap|deviceasympmap|failovermisconfig|unknown|netapp|fwdownrev|qualfail|diskfail|notallflashdisk}) - Error Type`

Selects the disks with error types values that match this parameter value.

## Examples

The following example displays configuration errors seen in the system:

```
cluster1::> storage errors show
Disk: vnv3070f20b:vnci9124s54:1-24.126L23
-----
vnci9124s54:1-24.126L23 (600a0b800019e999000036b24bac3983): This array LUN
reports an invalid block size and is not usable. Only a block size of 512
is supported.
```

# storage failover commands

## storage failover giveback

Return failed-over storage to its home node

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The *storage failover giveback* command returns storage that has failed over to a node's partner back to the home node. This operation fails if other resource-intensive operations (for instance, system dumps) are running and make the giveback operation potentially dangerous or disruptive. Some options are available only at the advanced privilege level and higher. Run the [storage failover show-giveback](#) command to check the status of giveback operations.

**NOTE:**

- If the system ID of the partner has changed while the node is in takeover mode, the *storage failover giveback* command updates the ownership of the partner's disks to the new system ID while giving back.
- If the giveback operation fails due to the operation being vetoed by a subsystem, check the syslog or EMS output for a subsystem-specific reason for the abort. The corrective action is subsystem-specific and is detailed in the corrective action portion of the message. Follow the corrective action specified by the subsystem and then reissue the *storage failover giveback* command. If you cannot perform the corrective action, then use the *override-vetoes* option in the *storage failover giveback* command to force the giveback.
- If the giveback operation fails because the node cannot communicate with its partner, check the EMS output for the corrective action. Follow the corrective action and then reissue the *storage failover giveback* command. If you cannot perform the corrective action, then use the *-require-partner* *-waiting* *false* option in the *storage failover giveback* command to force the giveback. This parameter is available only at the advanced privilege level and higher.
- If the node does not receive notification that the partner has brought online the given-back aggregate and its volumes, the [storage failover show-giveback](#) command displays the giveback status for the aggregate as failed. A possible reason for this failure is that the partner is overloaded and slow in bringing the aggregate online. Run the [storage aggregate show](#) command to verify that the aggregate and its volumes are online on the partner node. The node will not attempt the giveback operation for remaining aggregates.

To force the giveback, use the `-require-partner-waiting false` option in the `storage failover giveback` command. This parameter is available only at the advanced privilege level and higher.

## Parameters

### **{ -ofnode {<nodename>|local} - Node to which Control is Givenback**

Specifies the node whose storage is currently taken over by its partner and will be given back by the giveback operation.

### **| -fromnode {<nodename>|local} - Node Initiating Giveback }**

Specifies the node that currently holds the storage that is to be returned to the partner node.

### **[-require-partner-waiting {true|false}] - Require Partner in Waiting (privilege: advanced)**

If this optional parameter is used and set to false, the storage is given back regardless of whether the partner node is available to take back the storage or not. If this parameter is used and set to true, the storage will not be given back if the partner node is not available to take back the storage. If this parameter is not used, the behavior defaults to the setting of the `-check-partner` option set with the [storage failover modify](#) command.

### **[-override-vetoes <true>] - Override All Veto**

If this optional parameter is used, the system overrides veto votes during a giveback operation. If this parameter is not used, the system does not proceed with a giveback if it is vetoed. This parameter, if used, can only be set to true.

### **[-only-cfo-aggregates <true>] - Giveback Only CFO Aggregates**

If this optional parameter is used, giveback of only the CFO aggregates (root aggregate and CFO style data aggregates) will be attempted. If this parameter is not used, giveback of all the aggregates (CFO and SFO aggregates) will be attempted. This parameter, if used, can only be set to true.

## Examples

The following example gives back storage that is currently held by a node named node1. The partner must be available for the giveback operation to occur.

```
node::> storage failover giveback -fromnode node1
```

The following example gives back only the CFO aggregates to a node named node2 (the aggregates are currently held by a node named node1). The partner must be available for the giveback operation to occur, and the veto-giveback process can be overridden.

```
node::> storage failover giveback -ofnode node2  
-override-vetoes true -only-cfo-aggregates true
```

## Related Links

- [storage failover show-giveback](#)
- [storage aggregate show](#)
- [storage failover modify](#)

## storage failover modify

Modify storage failover attributes

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage failover modify` command changes the storage-failover options for a node. Some options are available only at the advanced privilege level and higher.

### Parameters

#### **-node {<nodename>|local} - Node**

This specifies the node whose storage-failover options are to be modified.

#### **{ [-enabled {true|false}] - Takeover Enabled**

This optionally specifies whether storage failover is enabled. The default setting is `true`.

#### **| [-mode {ha|non\_ha}] - HA Mode }**

This specifies whether the node is set up in high-availability mode or stand-alone mode. If the node is a member of a high-availability configuration, set the value to `ha`. If the node is stand-alone, set the value to `non_ha`. Before setting the HA mode, you must complete the platform dependent steps to set up the system in a stand-alone or HA configuration as shown in the documentation for your platform.

#### **[-auto-giveback {true|false}] - Auto Giveback Enabled**

This optionally specifies whether automatic giveback operations are enabled. An automatic giveback operation is invoked when one node of a failover pair is in takeover mode and the failed node is repaired and restarts. When the repaired node boots, the node in takeover mode detects this and initiates a giveback operation. The default setting is `true`. This parameter is not applicable if takeover was because of a disruption in the partner's operation. For those cases, use the `-auto-giveback-after-panic` parameter, instead.

#### **[-detection-time <integer>] - Takeover Detection Time (secs)**

This optionally specifies the amount of time, in seconds, that a node remains unresponsive before its partner initiates a takeover operation. Possible values range from 10 to 180 seconds. The default setting is 15 seconds.

#### **[-onfailure {true|false}] - Takeover on Failure Enabled (privilege: advanced)**

This optionally specifies whether the node automatically takes over for its partner node if the partner node fails. The default setting is `true`. This parameter is available only at the advanced privilege level and higher.

#### **[-onpanic {true|false}] - Takeover on Panic Enabled**

This optionally specifies whether the node automatically takes over for its partner node if the partner node panics. The default setting is `true`. Changing this parameter on one node automatically makes the same change on its partner node.

#### **[-onshort-uptime {true|false}] - Takeover on Short Uptime Enabled (privilege: advanced)**

This optionally specifies whether the node takes over for its partner node if the partner node fails within 60 seconds of starting up; the time period is modifiable by using the `-short-uptime` parameter. The default

setting is `true`. This parameter is available only at the advanced privilege level and higher.

#### **`[-short-uptime <integer>]` - Short Uptime (secs) (privilege: advanced)**

This optionally specifies the time period used by the `-onshort-uptime` parameter. The default setting is 60 seconds. This parameter is available only at the advanced privilege level and higher.

#### **`[-attempts <integer>]` - Number of Giveback Attempts (privilege: advanced)**

This optionally specifies the number of times the node attempts an automatic giveback operation within 60 minutes; the time period is modifiable by using the `-attempts-time` parameter. The default setting is 2 attempts. This parameter is available only at the advanced privilege level and higher.

#### **`[-attempts-time <integer>]` - Giveback Attempts Period (minutes) (privilege: advanced)**

This optionally specifies the time period used by the `-attempts` parameter. The default setting is 60 minutes. This parameter is available only at the advanced privilege level and higher.

#### **`[-propagate {true|false}]` - Propagate Status via Mailbox (privilege: advanced)**

This optionally specifies whether storage-failover status is communicated via mailbox disks. The default setting is `true`. This parameter is available only at the advanced privilege level and higher.

#### **`[-read-interval <integer>]` - Node Status Read Interval (secs) (privilege: advanced)**

This optionally specifies, in seconds, how frequently the node reads its partner node's status from the mailbox disks. The default setting is 5 seconds. This parameter is available only at the advanced privilege level and higher.

#### **`[-write-interval <integer>]` - Node Status Write Interval (secs) (privilege: advanced)**

This optionally specifies, in seconds, how frequently the node writes its status to the mailbox disks. The default setting is 5 seconds. This parameter is available only at the advanced privilege level and higher.

#### **`[-onreboot {true|false}]` - Takeover on Reboot Enabled**

This optionally specifies whether the node automatically takes over for its partner if the partner reboots. The default setting is `true`. Takeover can occur if the partner exceeds the expected time to reboot even when this option is set to `false`. The expected time to reboot is different for different platforms. The minimum expected time to reboot is 180 seconds. The `-inhibit-takeover` option of the [system node reboot](#) command overrides this option: if a node is rebooted with `-inhibit-takeover` set to `true` then takeover does not occur, even if the `takeover on reboot` option is `true`. If a node does takeover due to the partner rebooting, then it will automatically giveback after the reboot, even if the `-auto-giveback` option is set to `false`. This is non-persistent behavior: if the node does takeover due to partner reboot and then itself reboots (prior to giveback) then it will not automatically giveback if the `-auto-giveback` option is set to `false`.

#### **`[-delay-seconds <integer>]` - Delay Before Auto Giveback (secs)**

This optionally specifies the minimum time that a node will stay in takeover state prior to performing an automatic giveback. If the taken over node recovers quickly (for example, if the takeover was due to a reboot), by delaying the giveback for a few minutes the outage during the takeover and giveback can be reduced to two short outages instead of one longer one. The allowed range is 0 to 600, inclusive. The default setting is 600 seconds. This option affects all types of auto-giveback. This parameter is available only at the advanced privilege level and higher.



This delay does not affect manual giveback.

#### **[-hwassist {true|false}] - Hardware Assist Enabled**

This optionally specifies whether the hardware assist feature is enabled. If set to `true` this feature helps in fast takeover detection times in certain cases.

#### **[-hwassist-partner-ip <IP Address>] - Partner's Hwassist IP**

This optionally specifies the IP address on which the partner node receives hardware assist alerts. For the hardware assist feature to be active, the value of this option should be equal to partner's node management IP address.

#### **[-hwassist-partner-port <integer>] - Partner's Hwassist Port**

This optionally specifies the port number on which partner node listens to hardware assist alerts. It is recommended to have this value to be between 4000-4500. The default value is 4444.

#### **[-hwassist-health-check-interval <integer>] - Hwassist Health Check Interval (secs)**

This optionally specifies, in seconds, how frequently the hardware assist hardware on a node sends a heartbeat to its partner. The default value is 180.

#### **[-hwassist-retry-count <integer>] - Hwassist Retry Count**

This optionally specifies the number of times we repeat sending an hardware assist alert. The default value is 2.

#### **[-auto-giveback-after-panic {true|false}] - Auto Giveback After Takeover On Panic**

This optionally specifies whether a node should attempt automatic giveback operations if takeover was because of a disruption in the partner's operation. An automatic giveback operation is invoked when one node of a failover pair is in takeover mode and the failed node is repaired and restarts. When the repaired node boots, the node in takeover mode detects this and initiates a giveback operation automatically. The default setting is `true`.



This parameter is independent of the `-auto-giveback` parameter. If this parameter is enabled and the takeover is due to disruption in the partner's operation, giveback will be initiated even if `-auto-giveback` parameter is `false`.

#### **[-aggregate-migration-timeout <integer>] - Aggregate Migration Timeout (secs) (privilege: advanced)**

This optionally specifies the amount of time, in seconds, the source node has to wait for the destination node to complete the aggregate migration before declaring the migration as failed. The default setting is 120 seconds.

### **Examples**

The following example enables the storage-failover service on a node named node0:

```
node::> storage failover modify -node node0 -enabled true
```

The following examples enable storage-failover takeover on a short uptime of 30 seconds on a node named node0:

```
node::*> storage failover modify -node node0 -onshort-uptime true -short  
-uptime 30
```

## Related Links

- [system node reboot](#)

## storage failover show-giveback

Display giveback status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage failover show-giveback` command displays information about the giveback status of high-availability (HA) partner aggregates. The command displays the following information when no parameters are specified:

- Node name
- Partner aggregate name
- Giveback Status

You can specify additional parameters to display only the information that matches those parameters. For example, to display information only about a particular aggregate, run the command with the `'-aggregate aggregate_name'` parameter.

### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

[-node {<nodename>|local}] - Node

If this parameter is used, the command displays information about the giveback status of the aggregates belonging to the HA partner of the specified node.

[-aggregate <text>] - Aggregate

If this parameter is used, the command displays information about the giveback status of the specified aggregate.

### **[-giveback-status <text>, ...] - Aggregates Giveback State**

If this parameter is used, the command displays information about the aggregates with the specified giveback status.

### **[-destination <text>] - Destination for Giveback**

If this parameter is used, the command displays information about the giveback status of the aggregates whose destination after the giveback is the specified node.

## **Examples**

The following example displays information about giveback status on all nodes:

```
node::> storage failover show-giveback
          Partner
  Node      Aggregate      Giveback Status
  -----  -----
  -----
  node0          -          No aggregates to give back
  node1          -          No aggregates to give back
  node2          -          No aggregates to give back
  node3          -          No aggregates to give back
  4 entries were displayed.
```

## **storage failover show-takeover**

### **Display takeover status**

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The *storage failover show-takeover* command displays information about the takeover status of nodes in a cluster. The command also displays the takeover status of aggregates being taken over. During each phase of takeover, the takeover node and the node being taken over display their takeover status and the status of the aggregates being taken over. The command displays the following information when no parameters are specified:

- Node name
- Node takeover status - This contains a descriptive information about the phase of takeover.
- Aggregate
- Aggregate takeover status - This contains the following information:
- Takeover status of the aggregate, such as "Done", "Failed", "In progress" and "Not attempted yet".

- Reason for an aggregate takeover failure.
- Corrective action, in case of an aggregate takeover failure.

You can specify additional parameters to display only the information that matches those parameters. For example, to display information only about a particular node, run the command with the `-node` ```_node_name_``` parameter.

## Parameters

**{ [-fields <fieldname>, ...]**

If this parameter is specified, the command displays the specified fields for all nodes, in column style output.

**| [-instance ] }**

If this parameter is specified, the command displays the same detailed information as for the `-node` parameter, but for all nodes.

**[-node {<nodename>|local}] - Node Name**

If this parameter is specified, the command displays information about the takeover status of the specified node, and the takeover status of the aggregates being taken over.

**[-node-takeover-status <text>] - Node's Takeover Status**

If this parameter is specified, the command displays information about the takeover status of the nodes with the specified node-takeover-status. The command also displays the takeover status of the aggregates belonging to the node being taken over.

**[-aggregate <text>] - Aggregate Being Taken Over**

If this parameter is specified, the command displays information about the takeover status of the specified aggregate, and the takeover status of the nodes containing the specified aggregate.

**[-aggregate-takeover-status <text>] - Aggregate's Takeover Status**

If this parameter is specified, the command displays information about the takeover status of the aggregates with the specified aggregate takeover status, and the takeover status of the nodes containing those aggregates.

## Examples

The following example shows the takeover status of two nodes, nodeA and nodeB, in an High Availability (HA) pair, when both are in normal mode; neither node has taken over its HA partner. In this case, there is no takeover status for the aggregates.

```
cluster1::> storage failover show-takeover
Node          Node Status          Aggregate      Takeover Status
-----  -----  -----  -----
-----  -----
nodeA        Takeover not
            attempted.
            -          -
nodeB        Takeover not
            attempted.
            -          -
```

The following example shows the takeover status of two nodes, nodeA and nodeB, in an HA pair, when nodeA is in the SFO phase of an optimized takeover of nodeB. In this case, nodeA does not have information about the takeover status of nodeB's aggregates.

```
cluster1::> storage failover show-takeover
Node          Node Status          Aggregate      Takeover Status
-----  -----  -----  -----
-----  -----
nodeA        Optimized takeover
            of partner in
            progress. Partner,
            ("nodeB"), is
            relocating its SFO
            aggregates. Run the
            command "storage
            failover
            show-takeover -node
            nodeB" to display the
            relocation status of
            the partner.
            -          -
nodeB        Being taken over.
            aggr1      In progress, Module: backup.
            aggr2      Not attempted yet
            CFO aggregates Not attempted yet.
```

The following example shows the takeover status of two nodes, nodeA and nodeB, in an HA pair, when nodeA has completed the SFO phase of an optimized takeover of nodeB (but has not completed the CFO phase of the optimized takeover). In this case, nodeA has information about the takeover status of nodeB's aggregates.

```

cluster1::> storage failover show-takeover
ode      Node Status          Aggregate      Takeover Status
-----  -----  -----  -----
odeA      Partner has
          relocated its
          aggregates. Takeover
          in progress.
          aggr1      Done
          aggr2      Done
          CFO aggregates In progress.
odeB      Relocated aggregates
          to partner. Waiting
          for partner to
          takeover.
          aggr1      Done
          aggr2      Done
          CFO aggregates Not attempted yet.

```

The following example shows the takeover status of two nodes, nodeA and nodeB, in an HA pair, when nodeA has completed the SFO and CFO phases of an optimized takeover of nodeB. In this case, nodeA has information about the takeover status of nodeB's aggregates. Since nodeB is not operational, an Remote Procedure Call(RPC) error is indicated in the command output.

```

cluster1::> storage failover show-takeover
ode      Node Status          Aggregate      Takeover Status
-----  -----  -----  -----
odeA      Partner has
          relocated its
          aggregates. In
          takeover.
          aggr1      Done
          aggr2      Done
          CFO aggregates Done.
arning: Unable to list entries on node nodeB. RPC: Port mapper failure -
RPC:
          Timed out

```

The following example shows the takeover status of two nodes, nodeA and nodeB, in an HA pair, when nodeA has aborted the SFO phase of an optimized takeover of nodeB. In this case, nodeA does not have information about the takeover status of nodeB's aggregates.

```

cluster1::> storage failover show-takeover
ode      Node Status          Aggregate      Takeover Status
-----  -----  -----  -----
odeA      Optimized takeover
          of partner aborted.
          Run the command
          "storage failover
          show-takeover -node
          nodeB" to display the
          relocation status of
          the partner.
          -
odeB      Optimized takeover
          by partner aborted.
          aggr1      Failed: Destination node did
                      not online the aggregate on
                      time. To takeover the
                      remaining aggregates, run the
                      "storage failover takeover
                      -ofnode nodeB
                      -bypass-optimization true"
                      command. To giveback the
                      relocated aggregates, run the
                      "storage failover giveback
                      -ofnode nodeB" command.
          aggr2      Not attempted yet
          CFO aggregates Not attempted yet.

```

## storage failover show

Display storage failover status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage failover show` command displays information about storage-failover configurations. By default, the command displays the following information:

- Node name.
- Partner node name.
- Whether storage failover is possible.
- The current state of storage failover. If the takeover is disabled the appropriate reason would be displayed.

To display detailed information about storage failover on a specific node, run the command with the `-node`

parameter. The detailed view adds the following information:

- Node NVRAM ID.
- Partner NVRAM ID.
- Whether storage failover is enabled.
- Whether the storage-failover interconnect is available.
- Status of individual storage-failover interconnect links.
- Type and vendor of the storage-failover interconnect.
- Partner State
- Status codes from the takeover-by-partner process. Possible values include:
  - NVRAM\_DOWN
  - OPERATOR\_DISABLE\_NVRAM
  - PARTNER\_RESET
  - FM\_TAKEOVER
  - NVRAM\_MISMATCH
  - OPERATOR\_DENY
  - CLUSTER\_DISABLE
  - VERSION
  - SHELF\_HOT
  - REVERT\_IN\_PROGRESS
  - HALT\_NOTKOVER
  - TAKEOVER\_ON\_PANIC
- Reasons why takeover is not possible, if applicable. Possible values include:
  - NOT\_INIT
  - DISABLED
  - DEGRADED
  - MBX\_UNKNOWN
  - FM\_VERSION
  - PARTNER\_DISABLED
  - OPERATOR\_DENY
  - NVRAM\_MISMATCH
  - VERSION
  - IC\_ERROR
  - BOOTING
  - SHELF\_HOT
  - PARTNER\_REVERT\_IN\_PROGRESS
  - LOCAL\_REVERT\_IN\_PROGRESS
  - PARTNER\_TAKEOVER

- LOCAL\_TAKEOVER
- HALT\_NOTKOVER
- LOG\_UNSYNC
- UNKNOWN
- WAITING\_FOR\_PARTNER
- LOW\_MEMORY
- HALTING
- MBX\_UNCERTAIN
- NO\_AUTO\_TKOVER
- Time until takeover, in seconds.
- Time until auto giveback, in seconds.
- Delay for auto giveback, in seconds.
- List of local mailbox disks.
- List of partner mailbox disks.
- Whether operator-initiated planned takeover will be optimized for performance by relocating SFO (non-root) aggregates serially to the partner prior to takeover.

You can specify additional parameters to select the displayed information. For example, to display information only about storage-failover configurations whose interconnect is down, run the command with` -interconnect-up false` .

## Parameters

{ [-fields <fieldname>,...]

If you specify the -fields <fieldname>, ... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-options ]

Displays the following information:

- Node name
- Whether automatic giveback operations are enabled
- Whether long-running operations are terminated when an automatic giveback operation is initiated
- Whether the node checks its partner's readiness before initiating a giveback operation
- The time, in seconds, that the node remains unresponsive before its partner initiates a takeover operation
- Whether the node automatically takes over for its partner if the partner fails
- Whether the node automatically takes over for its partner if the partner panics
- Whether the node automatically takes over for its partner if the partner reboots
- whether Hardware Assisted Takeover is enabled
- Ip address on which the partner node listens to the Hardware Assist alerts
- Port number on which the partner node listens to the Hardware Assist alerts

- Whether operator-initiated planned takeover will be optimized for performance by relocating SFO (non-root) aggregates serially to the partner prior to takeover

If this parameter is specified when the privilege level is set to advanced or higher, the command displays the information in the previous list and the following additional information:

- Whether the node takes over for its partner if its partner fails after a period of time, which is listed in the following field
- The number of seconds before the node takes over for its partner
- The number of times the node attempts an automatic giveback operation within a period of time
- The number of minutes in which the automatic giveback attempts can occur
- Whether storage-failover status is communicated via mailbox disks
- The interval at which the node reads its partner node's status from the mailbox disks
- The interval at which the node writes its status to the mailbox disks
- '
- The interval at which Hardware assist h/w sends a heartbeat
- The number of times the Hardware assist alert is sent

#### | [-takeover-status ]

Displays the following information:

- Node name
- Partner name
- Takeover enabled
- Takeover possible
- Interconnect up
- State
- Node NVRAM ID
- Partner NVRAM ID
- Reason Takeover Not Possible By Partner
- Reason Takeover Not Possible
- Time Until Takeover

#### | [-advanced ] (privilege: advanced)

Displays the following information:

- Node name
- Whether kill messages are issued during a takeover operation
- Whether the node controls its partner's storage aggregates
- The time when firmware notification was received
- The time when booting notification was received
- The time at which the last takeover or giveback operation occurred, in microseconds

- The number of times the failover log was unsynchronized

#### **| [-iotime ] (privilege: advanced)**

Displays the following information:

- Node name
- Primary normal I/O time
- Primary transition I/O time
- Backup normal I/O time
- Backup transition I/O time

#### **| [-mailbox-status ] (privilege: advanced)**

Displays the following information:

- Node name
- Primary mailbox status
- Backup mailbox status

#### **| [-more-options ] (privilege: advanced)**

Displays the following information:

- Node name
- Whether takeover on short uptime is enabled
- Short uptime, in seconds
- Number of giveback attempts
- Interval of giveback attempts, in minutes
- Whether the primary mailbox is online
- Mailbox status read interval, in seconds
- Mailbox status write interval, in seconds

#### **| [-progress ] (privilege: advanced)**

Displays the following information:

- Node name
- Maximum resource-table index number
- Current resource-table index number
- Current resource-table entry

#### **| [-timeout ] (privilege: advanced)**

Displays the following information:

- Node name
- Fast timeout
- Slow timeout

- Mailbox timeout
- Connection timeout
- Operator timeout
- Firmware timeout
- Dump-core timeout
- Booting timeout
- Reboot timeout

**| [-transit ] (privilege: advanced)**

Displays the following information:

- Node name
- Transit Timer Enabled
- Transit Timeout

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the nodes whose name matches this parameter value.

**[-partner-name <text>] - Partner Name**

Selects the nodes that have the specified partner-name setting.

**[-nvramid <integer>] - Node NVRAM ID**

Selects the nodes that have the specified NVRAM ID setting.

**[-partner-nvramid <integer>] - Partner NVRAM ID**

Selects the nodes that have the specified partner NVRAM ID setting.

**[-enabled {true|false}] - Takeover Enabled**

Selects the nodes that have the specified takeover-enabled setting.

**[-mode {ha|non\_ha}] - HA Mode**

Selects the nodes that have the specified HA-mode setting. If the value is set to `ha` then the node is a member of a storage-failover configuration. If it is set to `non-ha` then it is in a stand alone configuration.

**[-possible {true|false}] - Takeover Possible**

Selects the nodes that have the specified failover-possible setting.

**[-reason <text>, ...] - Reason Takeover not Possible**

Selects the nodes that have the specified reason-not-possible setting. Possible values include:

- NOT\_INIT
- DISABLED
- DEGRADED

- MBX\_UNKNOWN
- FM\_VERSION
- PARTNER\_DISABLED
- OPERATOR\_DENY
- NVRAM\_MISMATCH
- VERSION
- IC\_ERROR
- BOOTING
- SHELF\_HOT
- PARTNER\_REVERT\_IN\_PROGRESS
- LOCAL\_REVERT\_IN\_PROGRESS
- PARTNER\_TAKEOVER
- LOCAL\_TAKEOVER
- HALT\_NOTKOVER
- LOG\_UNSYNC
- UNKNOWN
- WAITING\_FOR\_PARTNER
- LOW\_MEMORY
- HALTING
- MBX\_UNCERTAIN
- NO\_AUTO\_TKOVER

**`[-interconnect-up {true|false}]` - Interconnect Up**

Selects the nodes that have the specified interconnect-up setting.

**`[-interconnect-links <text>]` - Interconnect Links**

Selects the nodes that have the specified interconnect-links setting.

**`[-interconnect-type <text>]` - Interconnect Type**

Selects the nodes that have the specified interconnect-type setting.

**`[-state-description <text>]` - State Description**

Selects the nodes that have the specified state-description setting.

**`[-partner-state <text>]` - Partner State**

Selects the nodes that have the specified partner-state setting. Possible values include:

- OPERATOR COMPLETED
- DEBUGGUER COMPLETED
- PROGRESS COUNTER
- I/O ERROR

- BAD CHECKSUM
- RESERVED
- UNKNOWN
- INITIALIZING
- IN POWER-ON SELF TEST
- BOOTING
- BOOT FAILED
- WAITING
- KERNEL LOADED
- UP
- IN DEBUGGER
- WAITING FOR OPERATOR INPUT
- DUMPING CORE
- HALTED
- REBOOTING
- WAITING FOR GIVEBACK (DISK RESERVATIONS)
- WAITING FOR GIVEBACK (HA MAILBOXES)
- DUMPING SPARECORE
- MULTI-DISK PANIC
- IN TAKEOVER

**`[-time-until-takeover <integer>]` - Time Until Takeover**

Selects the nodes that have the specified time-until-takeover setting.

**`[-partner-reason <text>,...]` - Reason Takeover not Possible by Partner**

Selects the nodes that have the specified partner-reason text setting.

**`[-killpackets {true|false}]` - Issue Kill Packets (privilege: advanced)**

Selects the nodes that have the specified kill packets setting.

**`[-partner-aggregates {true|false}]` - Control Partner Aggregates (privilege: advanced)**

Selects the nodes that have the specified partner aggregates setting.

**`[-current-index <integer>]` - Current Progress Index (privilege: advanced)**

Selects the nodes that have the specified current-progress index setting.

**`[-current-entry <text>]` - Current Progress Entry (privilege: advanced)**

Selects the nodes that have the specified current-progress entry setting.

**`[-maximum-index <integer>]` - Maximum Progress Index (privilege: advanced)**

Selects the nodes that have the specified maximum-progress index setting.

**[-pmbox-status <text>, ...] - Primary Mailbox Status (privilege: advanced)**

Selects the nodes that have the specified primary mailbox status setting. Possible values include:

- MBX\_STATUS\_NODISKS
- MBX\_STATUS\_UNCERTAIN
- MBX\_STATUS\_STALE
- MBX\_STATUS\_CONFLICTED
- MBX\_STATUS\_OLD\_VERSION
- MBX\_STATUS\_NOT\_FOUND
- MBX\_STATUS\_WRONG\_STATE
- MBX\_STATUS\_BACKUP

**[-bmbox-status <text>, ...] - Backup Mailbox Status (privilege: advanced)**

Selects the nodes that have the specified backup-mailbox status setting. See the description of the `-pmbox-status` parameter for a list of possible values.

**[-major-seq-num-local <integer>] - Local Major Sequence Number (privilege: advanced)**

Selects the nodes that have the specified mailbox heartbeat major sequence number on the local node.

**[-minor-seq-num-local <integer>] - Local Minor Sequence Number (privilege: advanced)**

Selects the nodes that have the specified mailbox heartbeat minor sequence number on the local node.

**[-major-seq-num-partner <integer>] - Partner Major Sequence Number (privilege: advanced)**

Selects the nodes that have the specified mailbox heartbeat major sequence number on the partner node.

**[-minor-seq-num-partner <integer>] - Partner Minor Sequence Number (privilege: advanced)**

Selects the nodes that have the specified mailbox heartbeat minor sequence number on the partner node.

**[-local-mbx-node-status <Mailbox Status>] - Local Mailbox Node Status (privilege: advanced)**

Selects the nodes that have the specified local mailbox node status. Possible values include:

- MBX\_UNKNOWN - Local node is up, mailbox uninitialized
- MBX\_TAKEOVER\_DISABLED - Local node is up but takeover is disallowed
- MBX\_TAKEOVER\_ENABLED - Local node is up and takeover is allowed
- MBX\_TAKEOVER\_ACTIVE - Partner node has taken over
- MBX\_GIVEBACK\_DONE - Giveback completed, but local node has not yet restarted

**[-mbx-abs-time-local <integer>] - Local Mailbox Absolute Time (privilege: advanced)**

Selects the nodes that have the specified local mailbox channel absolute time. This time is measured in msec since 1/1/1970 (epoch).

**[-mbx-sk-time-local <integer>] - Local Mailbox Kernel Time (privilege: advanced)**

Selects the nodes that have the specified local mailbox channel Kernel Time.

**[-mbx-sk-cycles-local <integer>] - Local Mailbox CPU Cycles (privilege: advanced)**

Selects the nodes that have the specified local mailbox channel CPU Cycle count.

**[-ic-abs-time-local <integer>] - Local IC Absolute Time (privilege: advanced)**

Selects the nodes that have the specified local Interconnect channel absolute time. This time is measured in msecs since 1/1/1970 (epoch).

**[-ic-sk-time-local <integer>] - Local IC Kernel Time (privilege: advanced)**

Selects the nodes that have the specified local Interconnect channel Kernel Time.

**[-ic-sk-cycles-local <integer>] - Local IC CPU Cycles (privilege: advanced)**

Selects the nodes that have the specified local Interconnect channel CPU Cycle count.

**[-partner-mbx-node-status <Mailbox Status>] - Partner Mailbox Node Status (privilege: advanced)**

Selects the nodes that have the specified partner mailbox node status. Possible values include:

- MBX\_UNKNOWN
- MBX\_TAKEOVER\_DISABLED
- MBX\_TAKEOVER\_ENABLED
- MBX\_TAKEOVER\_ACTIVE
- MBX\_GIVEBACK\_DONE

**[-mbx-abs-time-partner <integer>] - Partner Mailbox Absolute Time (privilege: advanced)**

Selects the nodes that have the specified partner mailbox channel absolute time. This time is measured in msecs since 1/1/1970 (epoch).

**[-mbx-sk-time-partner <integer>] - Partner Mailbox Kernel Time (privilege: advanced)**

Selects the nodes that have the specified partner mailbox channel Kernel Time.

**[-mbx-sk-cycles-partner <integer>] - Partner Mailbox CPU Cycles (privilege: advanced)**

Selects the nodes that have the specified partner mailbox channel CPU Cycle count.

**[-mbx-major-seq-num-partner <integer>] - Partner Mailbox Major Sequence Number (privilege: advanced)**

Selects the nodes that have the specified partner mailbox channel major sequence number.

**[-mbx-minor-seq-num-partner <integer>] - Partner Mailbox Minor Sequence Number (privilege: advanced)**

Selects the nodes that have the specified partner mailbox channel minor sequence number.

**[-ic-abs-time-partner <integer>] - Partner IC Absolute Time (privilege: advanced)**

Selects the nodes that have the specified partner Interconnect channel absolute time. This time is measured in msecs since 1/1/1970 (epoch).

**[-ic-sk-time-partner <integer>] - Partner IC Kernel Time (privilege: advanced)**

Selects the nodes that have the specified partner Interconnect channel Kernel Time.

**[-ic-sk-cycles-partner <integer>] - Partner IC CPU Cycles (privilege: advanced)**

Selects the nodes that have the specified partner Interconnect channel CPU Cycle count.

**[-ic-major-seq-num-partner <integer>] - Partner IC Major Sequence Number (privilege: advanced)**

Selects the nodes that have the specified partner Interconnect channel major sequence number.

**[-ic-minor-seq-num-partner <integer>] - Partner IC Minor Sequence Number (privilege: advanced)**

Selects the nodes that have the specified partner Interconnect channel minor sequence number.

**[-local-takeover-info <text>] - Local Takeover Info (privilege: advanced)**

Selects the nodes that have the specified local node takeover information. This includes the type of negotiated failover request, or if takeover is not possible, the reason why takeover is disabled. Possible values include:

- NOTKOVER\_NVRAM\_DOWN - NVRAM mirror is down
- NOTKOVER\_OPERATOR\_DISABLE\_NVRAM - Operator disabled
- NOTKOVER\_PARTNER\_RESET - A link reset is in progress
- NOTKOVER\_FM\_TAKEOVER - The failover monitor has declared takeover
- NOTKOVER\_NVRAM\_MISMATCH - NVRAM sizes mismatch
- NOTKOVER\_OPERATOR\_DENY - Operator denies takeover
- NOTKOVER\_CLUSTER\_DISABLE - Cluster is disabled
- NOTKOVER\_VERSION - Version mismatch
- NOTKOVER\_SHELF\_HOT - Disk shelf is too hot
- NOTKOVER\_REVERT\_IN\_PROGRESS - Revert is in progress
- NOTKOVER\_HALT\_NOTKOVER - Node halted in no-takeover mode
- TKOVER\_ON\_REBOOT - Enable takeover on reboot
- TKOVER\_ON\_PANIC - Enabled takeover on panic
- TKOVER\_ON\_STUTTER\_DISABLED - Disable takeover on short uptime
- NFO\_DISK\_SHELF\_ENABLED - Negotiated failover for disk shelf module is enabled
- NFO\_ISCSI\_ENABLED - Negotiated failover for network interfaces module is enabled
- NFO\_FCP\_TARGET\_ENABLED - Negotiated failover for fcp target module is enabled

**[-partner-takeover-info <text>] - Partner Takeover Info (privilege: advanced)**

Selects the nodes that have the specified partner node takeover information. This includes the type of negotiated failover request, or if takeover is not possible, the reason why takeover is disabled. Possible values include:

- NOTKOVER\_NVRAM\_DOWN - NVRAM mirror is down
- NOTKOVER\_OPERATOR\_DISABLE\_NVRAM - Operator disabled
- NOTKOVER\_PARTNER\_RESET - A link reset is in progress
- NOTKOVER\_FM\_TAKEOVER - The failover monitor has declared takeover

- NOTKOVER\_NVRAM\_MISMATCH - NVRAM sizes mismatch
- NOTKOVER\_OPERATOR\_DENY - Operator denies takeover
- NOTKOVER\_CLUSTER\_DISABLE - Cluster is disabled
- NOTKOVER\_VERSION - Version mismatch
- NOTKOVER\_SHELF\_HOT - Disk shelf is too hot
- NOTKOVER\_REVERT\_IN\_PROGRESS - Revert is in progress
- NOTKOVER\_HALT\_NOTKOVER - Node halted in no-takeover mode
- TKOVER\_ON\_REBOOT - Takeover on reboot is enabled
- TKOVER\_ON\_PANIC - Takeover on panic is enabled
- TKOVER\_ON\_STUTTER\_DISABLED - Disable takeover on short uptime
- NFO\_DISK\_SHELF\_ENABLED - Negotiated failover for disk shelf module is enabled
- NFO\_ISCSI\_ENABLED - Negotiated failover for network interfaces module is enabled
- NFO\_FCP\_TARGET\_ENABLED - Negotiated failover for fcp target module is enabled

**`[-local-headswap-state <Headswap State>]` - Local Head Swap State (privilege: advanced)**

Selects the nodes that have the specified local node headswap state. Possible values are:

- HEADSWAP\_NONE - head swap not in progress
- HEADSWAP\_START - head swap started
- HEADSWAP\_CFO\_START - CFO phase of head swap started
- HEADSWAP\_CFO\_END - CFO phase of head swap completed
- HEADSWAP\_SFO\_START - SFO phase of head swap started

**`[-partner-headswap-state <Headswap State>]` - Partner Head Swap State (privilege: advanced)**

Selects the nodes that have the specified partner node headswap state. Possible values are:

- HEADSWAP\_NONE - head swap not in progress
- HEADSWAP\_START - head swap started
- HEADSWAP\_CFO\_START - CFO phase of head swap started
- HEADSWAP\_CFO\_END - CFO phase of head swap completed
- HEADSWAP\_SFO\_START - SFO phase of head swap started

**`[-fast-timeout <integer>]` - Fast Timeout (privilege: advanced)**

Selects the nodes that have the specified fast-timeout configuration setting.

**`[-slow-timeout <integer>]` - Slow Timeout (privilege: advanced)**

Selects the nodes that have the specified slow-timeout setting.

**`[-mailbox-timeout <integer>]` - Mailbox Timeout (privilege: advanced)**

Selects the nodes that have the specified mailbox-timeout setting.

**`[-connect-timeout <integer>]` - Connect Timeout (privilege: advanced)**

Selects the nodes that have the specified connect-timeout setting.

**[-operator-timeout <integer>] - Operator Timeout (privilege: advanced)**

Selects the nodes that have the specified operator-timeout setting.

**[-firmware-timeout <integer>] - Firmware Timeout (privilege: advanced)**

Selects the nodes that have the specified firmware-timeout setting.

**[-dumpcore-timeout <integer>] - Dumpcore Timeout (privilege: advanced)**

Selects the nodes that have the specified dump-core timeout setting.

**[-booting-timeout <integer>] - Booting Timeout (privilege: advanced)**

Selects the nodes that have the specified booting-timeout setting.

**[-transit-timer {true|false}] - Transit Timer Enabled (privilege: advanced)**

Selects the nodes that have the specified transit-timer setting.

**[-transit-timeout <integer>] - Transit Timeout (privilege: advanced)**

Selects the nodes that have the specified transit timeout.

**[-firmware-received <integer>] - Firmware Received (privilege: advanced)**

Selects the nodes that have the specified firmware-reception time.

**[-firmware-received-cycles <integer>] - Firmware Received in CPU Cycles (privilege: advanced)**

Selects the nodes that have the specified firmware-reception time in CPU Cycles.

**[-booting-received <integer>] - Booting Received (privilege: advanced)**

Selects the nodes that have the specified booting-reception time.

**[-transit-time <integer>] - Transit Event Time (privilege: advanced)**

Selects the nodes whose last failover event occurred at the specified time.

**[-pnormal <integer>] - Primary Normal IO Time (privilege: advanced)**

Selects the nodes that have the specified normal primary-mailbox I/O time.

**[-ptransition <integer>] - Primary Transition IO Time (privilege: advanced)**

Selects the nodes that have the specified transitional primary-mailbox I/O time.

**[-bnormal <integer>] - Backup Normal IO Time (privilege: advanced)**

Selects the nodes that have the specified normal backup-mailbox I/O time.

**[-btransition <integer>] - Backup Transition IO Time (privilege: advanced)**

Selects the nodes that have the specified transitional backup-mailbox I/O time.

**[-logs-unsynced <integer>] - Logs Unsynchronized Count (privilege: advanced)**

Selects the nodes that have the specified count of unsynchronized logs.

**[-auto-giveback {true|false}] - Auto Giveback Enabled**

Selects the nodes that have the specified auto-giveback setting.

**[-detection-time <integer>] - Takeover Detection Time (secs)**

Selects the nodes that have the specified detection-time setting.

**[-onfailure {true|false}] - Takeover on Failure Enabled (privilege: advanced)**

Selects the nodes that have the specified takeover-on-failure setting.

**[-onpanic {true|false}] - Takeover on Panic Enabled**

Selects the nodes that have the specified takeover-on-panic setting.

**[-onshort-uptime {true|false}] - Takeover on Short Uptime Enabled (privilege: advanced)**

Selects the storage-failover configurations that match this parameter value.

**[-short-uptime <integer>] - Short Uptime (secs) (privilege: advanced)**

Selects the nodes that have the specified short-uptime value.

**[-attempts <integer>] - Number of Giveback Attempts (privilege: advanced)**

Selects the nodes that have the specified number of giveback attempts.

**[-attempts-time <integer>] - Giveback Attempts Period (minutes) (privilege: advanced)**

Selects the nodes that have the specified time setting for giveback attempts.

**[-propagate {true|false}] - Propagate Status via Mailbox (privilege: advanced)**

Selects the nodes that have the specified propagate-status-via-mailbox setting.

**[-read-interval <integer>] - Node Status Read Interval (secs) (privilege: advanced)**

Selects the nodes that have the specified read interval.

**[-write-interval <integer>] - Node Status Write Interval (secs) (privilege: advanced)**

Selects the nodes that have the specified write interval.

**[-onreboot {true|false}] - Takeover on Reboot Enabled**

Selects the nodes that have the specified takeover-on-reboot setting.

**[-delay-seconds <integer>] - Delay Before Auto Giveback (secs)**

Selects the nodes that have the specified delay (in seconds) for the auto giveback.

**[-hwassist {true|false}] - Hardware Assist Enabled**

Selects the nodes that have the specified hwassist setting.

**[-hwassist-partner-ip <IP Address>] - Partner's Hwassist IP**

Selects the nodes that have the specified hwassist-partner-ip setting.

**[-hwassist-partner-port <integer>] - Partner's Hwassist Port**

Selects the nodes that have the specified hwassist-partner-port setting.

**[-hwassist-health-check-interval <integer>] - Hwassist Health Check Interval (secs)**

Selects the nodes that have the specified hwassist health check interval, in seconds.

**[-hwassist-retry-count <integer>] - Hwassist Retry Count**

Selects the nodes that have the specified hwassist retry count, in seconds.

**[-hwassist-status <text>] - Hwassist Status**

Selects the nodes that have the specified hwassist-status setting.

**[-time-until-autogiveback <integer>] - Time Until Auto Giveback (secs)**

Selects the nodes that have the specified time(in seconds) until auto giveback.

**[-local-mailbox-disks <text>] - Local Mailbox Disks**

Selects the nodes that have the specified mailbox disks on the local node.

**[-partner-mailbox-disks <text>] - Partner Mailbox Disks**

Selects the nodes that have the specified mailbox disks on the partner node.

**[-local-firmware-state <text>] - Local Firmware State (privilege: advanced)**

Selects the nodes that have the specified firmware state on the local node.

**[-local-firmware-progress <integer>] - Local Firmware Progress Counter (privilege: advanced)**

Selects the nodes that have the specified firmware progress counter for the local node.

**[-partner-firmware-state <text>] - Partner Firmware State (privilege: advanced)**

Selects the nodes that have the specified firmware state of the partner node.

**[-partner-firmware-progress <integer>] - Partner Firmware Progress Counter (privilege: advanced)**

Selects the nodes that have the specified firmware progress counter for the partner node.

**[-local-missing-disks <text>] - Missing Disks on Local Node**

Selects the nodes that have the specified missing disks on the local node.

**[-partner-missing-disks <text>] - Missing Disks on Partner Node**

Selects the nodes that have the specified missing disks on the partner node.

**[-reboot-timeout <integer>] - Reboot Timeout (privilege: advanced)**

Selects the nodes that have the specified reboot timeout.

**[-time-since-takeover <text>] - Time Since Takeover**

Selects the nodes that have been in takeover mode for the specified amount of time.

**[-auto-giveback-after-panic {true|false}] - Auto Giveback After Takeover On Panic**

Selects the nodes that have the specified auto-giveback-after-panic setting. If *true* then an automatic giveback operation is invoked when the failover node of an HA pair is repaired and rebooted. The takeover node of the HA pair detects this and initiates a giveback operation automatically.

**[-is-giveback-requested {true|false}] - Giveback Requested (privilege: advanced)**

Selects the nodes that have the specified is-giveback-requested setting. If *true* , a deferred giveback request has been made by the local node.

**[-auto-giveback-last-veto-check <integer>] - Auto Giveback Last Veto Check (privilege: advanced)**

Selects the nodes that have the specified auto-giveback-last-veto-check time. This setting indicates the time, in milliseconds, when the local node made the most recent giveback veto check.

**[-is-auto-giveback-attempts-exceeded {true|false}] - Auto Giveback Attempts Exceeded (privilege: advanced)**

Selects the nodes that have the specified is-auto-giveback-attempts-exceeded setting. If *true*, the local node has exceeded the maximum number of allowed auto giveback attempts.

**[-was-auto-giveback-done {true|false}] - Was Auto Giveback Done (privilege: advanced)**

Selects the nodes that have the specified was-auto-giveback-done setting. If *true*, the last giveback was automatic (as opposed to a manual giveback).

**[-is-cifs-auto-giveback-stopping {true|false}] - Is CIFS Auto Giveback Stopping (privilege: advanced)**

Selects the nodes that have the specified is-cifs-auto-giveback-stopping setting. If *true*, the local node has initiated CIFS termination as part of an automatic giveback.

**[-aggregate-migration-timeout <integer>] - Aggregate Migration Timeout (secs) (privilege: advanced)**

Selects the nodes that have the specified aggregate migration timeout.

**[-is-mirror-enabled {true|false}] - Is NVRAM Mirroring Enabled (privilege: advanced)**

Selects the nodes that have the specified is-mirror-enabled setting. If *true*, then NVRAM mirroring is enabled.

**[-is-mirror-consistency-required {true|false}] - Is Mirror Consistency Required (privilege: advanced)**

Selects the nodes that have the specified is-mirror-consistency-required setting. If *true*, then NVRAM mirror consistency is required.

**[-is-memory-insufficient {true|false}] - Is Memory Insufficient To Takeover (privilege: advanced)**

Selects the nodes that have the specified is-memory-insufficient setting. If *true*, the local node does not have enough memory to perform a takeover.

**[-memio-state <memio status>] - Current State of Memio Link (privilege: advanced)**

Selects the nodes that have the specified memio layer link current state. Possible values are:

- UNINIT - Uninitialized
- CLOSED - Closed
- HB\_LISTEN - Listening for connect
- SYN\_SENT - Sent generation information
- ESTABLISHED - Connection established

**[-is-degraded {true|false}] - Are Partner Mailbox Disks Not Known (privilege: advanced)**

Selects the nodes that have the specified is-degraded setting. If *true*, takeovers are deferred because partner mailbox disks are not known.

**[-reserve-policy <reserve policy>] - FM Reservation Policy (privilege: advanced)**

Selects the nodes that have the specified disk reservation policy. Possible values are:

- RESERVE\_NO\_DISKS - no disk reservations made during takeover, nor are disk reservations released during giveback
- RESERVE\_LOCK\_DISKS\_ONLY - only mailbox disks are released during takeover and released during giveback
- RESERVE\_ONLY\_AT\_TAKEOVER - reservations are issued only at takeover time. All disks are reserved. All reservations are released at giveback
- RESERVE\_ALWAYS\_AFTER\_TAKEOVER - reservations are issued at takeover. When disks are subsequently added, they are also reserved. All disks are released at giveback

**[-reset-disks {true|false}] - Issue Disk Resets during Failover (privilege: advanced)**

Selects the nodes that have the specified reset-disks setting. If *true*, disks are reset during takeover/giveback.

**[-total-system-uptime <integer>] - Total System Uptime (privilege: advanced)**

Selects the nodes that have the specified total system uptime, in milliseconds.

**[-current-time <integer>] - Current System Time (privilege: advanced)**

Selects the nodes that have the specified current time on the node.

**[-fm-takeover-state <FM Takeover/Giveback Transition>] - FM Takeover State (privilege: advanced)**

Selects the nodes that have the specified takeover state. Possible values are:

- FT\_NONE - Not in takeover
- FT\_TAKEOVER\_STARTED - Local node has initiated takeover
- FT\_TAKEOVER\_COMMITTED - Takeover has been committed
- FT\_TAKEOVER\_DONE\_OK - Local node successfully completed takeover
- FT\_TAKEOVER\_DONE\_FAILED - Takeover failed

**[-fm-giveback-state <FM Takeover/Giveback Transition>] - FM Giveback State (privilege: advanced)**

Selects the nodes that have the specified giveback state. Possible values are:

- FT\_NONE - Not in giveback
- FT\_GIVEBACK\_READY - Partner node is ready for giveback
- FT\_GIVEBACK\_STARTED - Local node has initiated giveback
- FT\_GIVEBACK\_COMMITTED - Giveback has been committed
- FT\_GIVEBACK\_DONE\_OK - Giveback completed successfully

**[-takeover-reason <FM Takeover Reason>] - Reason why takeover triggered (privilege: advanced)**

Selects the nodes that have the specified takeover reason. Possible values are:

- TAKEOVER\_NONE - Not in takeover

- TAKEOVER\_IMMEDIATE - Operator initiated forced takeover
- TAKEOVER\_NDU - Takeover initiated as part of NDU
- TAKEOVER\_FORCED - Operator initiated forced takeover, possible data loss
- TAKEOVER\_EARLY - Takeover occurred during the boot process
- TAKEOVER\_OPERATOR\_EXP - Takeover occurred after the operator timeout expired
- TAKEOVER\_POST\_FAILED - Takeover occurred on POST failure
- TAKEOVER\_PANIC - Takeover on panic
- TAKEOVER\_SHORTUPTIME - Takeover after rapid toggling between up and down states
- TAKEOVER\_SPARECORE\_EXP - Takeover on panic timeout expiration
- TAKEOVER\_REBOOT\_EXP - Takeover on reboot timer expiration
- TAKEOVER\_BOOTING\_EXP - Takeover on booting timer expiration
- TAKEOVER\_FIRMWARE\_EXP - Takeover on firmware timer expiration
- TAKEOVER\_NFO\_SHUTDOWN - Takeover on negotiated failover shutdown
- TAKEOVER\_NFO\_TIMER - Takeover on negotiated failover timer expiration
- TAKEOVER\_MDP - Takeover on multi-disk panic
- TAKEOVER\_REBOOT - Takeover on reboot
- TAKEOVER\_HALT - Takeover on halt
- TAKEOVER\_CLAM - CLAM-triggered takeover
- TAKEOVER\_HWASSIST - Hardware-assisted takeover
- TAKEOVER\_NORMAL - Operator initiated takeover

**`[-ha-type {none|shared_storage|non_shared_storage}] - HA Type`**

If this parameter is specified, the command selects the nodes that have the specified HA-type setting. If the value is set to `shared_storage`, then the node is in a storage-failover configuration using the shared storage. If it is set to `non_shared_storage`, then the node is in a storage-failover configuration using the unshared storage. If it is set to `none`, then the node is not part of a storage-failover configuration.

## Examples

The following example displays information about all storage-failover configurations:

```
cluster1::> storage failover show
                  Takeover
  Node      Partner  Possible State
  -----  -----
node0      node1      true    Connected to node1
node2      node3      true    Connected to node3
node1      node0      true    Connected to node0
node3      node2      true    Connected to node2
4 entries were displayed.
```

## storage failover takeover

Take over the storage of a node's partner

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The storage failover takeover command initiates a takeover of the partner node's storage.

### Parameters

**{ -ofnode {<nodename>|local} - Node to Takeover**

This specifies the node that is taken over. It is shut down and its partner takes over its storage.

**| -bynode {<nodename>|local} - Node Initiating Takeover }**

This specifies the node that is to take over its partner's storage.

**[ -option <takeover option>] - Takeover Option**

This optionally specifies the style of takeover operation. Possible values include the following:

- **normal** - Specifies a normal takeover operation; that is, the partner is given the time to close its storage resources gracefully before the takeover operation proceeds. This is the default value.
- **immediate** - Specifies an immediate takeover. In an immediate takeover, the takeover operation is initiated before the partner is given the time to close its storage resources gracefully. The use of this option results in an immediate takeover which does not do a clean shutdown. In case of NDU this can result in a NDU failure.



If this option is specified, negotiated takeover optimization is bypassed even if the `-bypass-optimization` option is set to false.



If this option is specified, migration of data LIFs from the partner will be delayed even if the `-skip-lif-migration-before-takeover` option is not specified. If possible, migrate the data LIFs to another node prior to specifying this option.

- **allow-version-mismatch** - If this value is specified, the takeover operation is initiated even if the partner is running a version of software that is incompatible with the version running on the node. In this case, the partner is given the time to close its storage resources gracefully before the takeover operation proceeds. However, the takeover operation will not be allowed if the partner has higher WAFL or RAID label versions. Use this value as part of a nondisruptive upgrade or downgrade procedure.
- **force** - If this value is specified, the takeover operation is initiated even if the node detects an error that normally prevents a takeover operation from occurring. This value is available only at the advanced privilege level and higher.



If this option is specified, negotiated takeover optimization is bypassed even if the `-bypass-optimization` option is set to false.



The use of this option can potentially result in data loss. If the HA interconnect is detached or inactive, or the contents of the failover partner's NVRAM cards are unsynchronized, takeover is normally disabled. Using the `-force` option enables a node to take over its partner's storage despite the unsynchronized NVRAM, which can contain client data that can be lost upon storage takeover.

#### **`[-bypass-optimization {true|false}]` - Bypass Takeover Optimization (privilege: advanced)**

If this is an operator-initiated planned takeover, this parameter specifies whether the takeover optimization is bypassed. This parameter defaults to false.



This parameter is ignored and negotiated takeover optimization automatically bypassed if the `-immediate` option, the `-force` option, or the `-allow-disk-inventory-mismatch` parameter is specified as part of the same storage failover takeover command.

#### **`[-allow-disk-inventory-mismatch {true|false}]` - Disk inventory**

If this parameter is specified, the takeover operation is initiated even if the local node cannot see the partner's filesystem disks.



If this parameter is specified, negotiated takeover optimization is bypassed even if the `-bypass-optimization` parameter is set to false.



The use of this parameter can potentially result in client outage.

#### **`[-skip-lif-migration-before-takeover <true>]` - Skip Migrating LIFs Away from Node Prior to Takeover**

This parameter specifies that LIF migration prior to takeover is skipped. However if LIFs on this node are configured for failover, those LIFs may still failover after the takeover has occurred. Without this parameter, the command attempts to synchronously migrate data and cluster management LIFs away from the node prior to its takeover. If the migration fails or times out, the takeover is aborted.

#### **`[-ignore-quorum-warnings <true>]` - Skip Quorum Check Before Takeover**

If this parameter is specified, quorum checks will be skipped prior to the takeover. The operation will continue even if there is a possible data outage due to a quorum issue.

#### **`[-override-vetoes <true>]` - Override Vetoes**

If this is an operator-initiated planned takeover, this parameter specifies whether the veto should be overridden. If this parameter is not specified, its value is set to false .



If this parameter is specified, negotiated takeover will override any vetoes to continue with takeover.



The use of this parameter might result in the takeover proceeding even if the node detects issues that can potentially make the takeover dangerous or disruptive.

#### **`[-halt <true>]` - Halt the Node That Is Taken Over**

This parameter specifies whether the node being taken over should be halted. If the value is true, then the node being taken over is halted. If the value is false, then the node being taken over is shutdown and might be rebooted if AUTOBOOT is set to true. This parameter defaults to false.

## Examples

The following example causes a node named node0 to initiate a negotiated optimized takeover of its partner's storage:

```
cluster1::> storage failover takeover -bynode node0
```

The following example causes a node named node0 to initiate an immediate takeover of its partner's storage:

```
cluster1::> storage failover takeover -bynode node0 -option immediate
```

## storage failover hwassist show

Display hardware-assisted storage failover status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage failover hwassist show` command displays information about the hardware-assisted storage failover status on each node. By default, the command displays the following information:

- Node name.
- Partner node name.
- Whether hardware-assisted failover is enabled.
- IP address on which the local node receives hardware-assisted failover alerts.
- Port on which the local node receives hardware-assisted failover alerts.
- Hardware-assisted failover status.
- If the monitor is inactive, the reason it is inactive.
- If the monitor is inactive, the corrective action to make it active.
- Status of keep-alive alerts on the local node.

Hardware-assisted failover establishes a notification channel from each respective node's service processor to the other (HA partner) node. If a node becomes unresponsive, its service processor notifies the HA partner of this condition, accelerating storage failover. By default, hwassist is enabled and configured automatically to use each node's node-mgmt LIF. To modify or show the hardware-assisted storage failover configuration, use the [storage failover modify](#) and [storage failover show](#) commands.

### Parameters

```
{ [-fields <fieldname>,...]
```

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

```
| [-instance ] }
```

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

If you specify this parameter, the command displays information only about hwassist on the specified nodes.

**[-partner-name {<nodename>|local}] - Name of the Partner Node**

If you specify this parameter, the command displays information only about hwassist on nodes with the specified partner node.

**[-enabled {true|false}] - Local Hardware Assist Enabled**

If you specify this parameter, the command displays information only about hwassist on nodes with the specified enabled state.

**[-local-status <text>] - Local Node's Hwassist Status**

If you specify this parameter, the command displays information only about hwassist on nodes with the specified local status (*active* or *inactive*).

**[-local-ip <text>] - IP Address on Which Local Node is Listening**

If you specify this parameter, the command displays information only about hwassist on nodes with the specified local IP address.

**[-local-port <integer>] - Port on Which Local Node is Listening**

If you specify this parameter, the command displays information only about hwassist on nodes with the specified local UDP port.

**[-local-inactive <text>] - Local Node's Hwassist Inactive Status Reason**

If you specify this parameter, the command displays information only about hwassist on nodes with the specified inactive reason.

**[-local-action <text>] - Corrective Action on Local Node**

If you specify this parameter, the command displays information only about hwassist on nodes with the specified corrective action.

## Examples

The following example displays the hardware-assisted failover information for node cluster1-01 and its HA partner node cluster1-02:

```

cluster1::> storage failover hwassist show
  Node
  -----
  cluster1-01
    Partner: cluster1-02
    Hwassist Enabled: true
    Hwassist IP: 10.225.248.19
    Hwassist Port: 4444
    Monitor Status: active
    Inactive Reason: -
    Corrective Action: -
    Keep-Alive Status: healthy
  cluster1-02
    Partner: cluster1-01
    Hwassist Enabled: true
    Hwassist IP: 10.225.248.21
    Hwassist Port: 4444
    Monitor Status: active
    Inactive Reason: -
    Corrective Action: -
    Keep-Alive Status: healthy

```

## Related Links

- [storage failover modify](#)
- [storage failover show](#)

## storage failover hwassist test

Test the hwassist functionality

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage failover hwassist test` command tests the Hardware Assist h/w connectivity between the two nodes in a HA pair. The test result can be one of the following.

- Hardware Assist is not initialized.
- HW assist is not supported.
- Partner is throttling alerts.
- Resource is busy.
- Hardware Assist h/w returned an error.
- No response from partner.Timed out.
- Unexpected abort.

- Partner has taken over.
- Interconnect is down between nodes.
- Partner is not booted up yet.

## Parameters

### **-node {<nodename>|local} - Node**

This specifies the node from which a test alert is initiated.

## Examples

The following command issues a test alert from the node cluster1-01:

```
cluster1::> storage failover hwassist test -node cluster1-01
Info: Operation successful.
```

## **storage failover hwassist stats clear**

Clear the hwassist statistics

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage failover hwassist stats clear` command clears the statistics information maintained by Hardware Assist functionality.

## Parameters

### **-node {<nodename>|local} - Node**

This specifies the node on which the statistics are to be cleared.

## Examples

The following example clears the hwassist statistics on the node cluster1-01:

```
cluster1::> storage failover hwassist stats clear -node cluster1-01
```

## **storage failover hwassist stats show**

Display hwassist statistics

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage failover hwassist stats show` command displays statistics about the hardware assist alerts processed by a node. The command displays the following information for each alert:

- Locally enabled.
- Partner Inactive Reason.
- Alert type.
- Event that triggered the alert.
- The number of times the alert has been received.
- Whether takeover was possible on receiving the alert.
- The last time at which the alert was received.

## Parameters

**{ [-fields <fieldname>, ...]**

If you specify the **-fields <fieldname>, ...** parameter, the command output also includes the specified field or fields. You can use **'-fields ?'** to display the fields to specify.

**| [-instance ] }**

If you specify the **-instance** parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the hwassist statistics for the specified node.

## Examples

The following example displays the hwassist statistics for the node ha1:

```

cluster1::> storage failover hwassist stats show -node ha1
Node: ha1
          Local Enabled: true
  Partner Inactive Reason: -
Alert Type  Alert Event          Count Takeover  Last Received
-----  -----
-----  -----
system_down power_loss           0 Yes      --- 
system_down 12_watchdog_reset   0 Yes      --- 
system_down power_off_via_rlm   0 Yes      --- 
system_down power_cycle_via_rlm 0 Yes      --- 
system_down reset_via_rlm       0 Yes      --- 
system_down power_off_via_sp    0 Yes      --- 
system_down power_cycle_via_sp  0 Yes      --- 
system_down reset_via_sp        0 Yes      --- 
system_down dimm_uecc_error    0 Yes      --- 
system_down post_error          0 No       --- 
system_down abnormal_reboot    0 No       --- 
system_down loss_of_heartbeat   0 No       --- 
keep_alive   periodic_message   10 No      Wed Mar  9 13:41:28
EST 2016
      test          test          0 No      --- 
      ID_mismatch   ---          0 ---      --- 
      Key_mismatch   ---          0 ---      --- 
      Unknown        ---          0 ---      --- 
      alerts_throttled 0 ---      --- 

```

The following example displays the hwassist statistics for the node ha1 where hardware assist hardware is not supported.

```

cluster1::> storage failover hwassist stats show -node ha1
Node: ha1
          Local Enabled: false
  Partner Inactive Reason: HW assist is not supported on partner.
Alert Type  Alert Event          Count Takeover  Last Received
-----  -----
-----  -----
-
```

## storage failover internal-options show

Display the internal options for storage failover

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage failover internal-options show` command displays the following information about the storage failover configuration:

- Node name
- Whether automatic giveback is enabled
- Whether partner checking is enabled
- Takeover detection time, in seconds
- Whether takeover on failover is enabled
- Whether takeover on panic is enabled
- Whether takeover on reboot is enabled
- Whether hardware-assisted takeover is enabled
- IP address on which the partner node listens to the hardware-assisted takeover alerts
- Port on which the partner node listens to the hardware-assisted takeover alerts
- Whether takeover on short uptime is enabled (detailed view only)
- Short uptime interval, in seconds (detailed view only)
- Number of giveback attempts (detailed view only)
- Giveback attempt interval, in minutes (detailed view only)
- Whether status is propagated through SFO mailboxes (detailed view only)
- Status read interval, in seconds (detailed view only)
- Status write interval, in seconds (detailed view only)
- Hardware-assisted takeover retry count (detailed view only)
- Hardware-assisted takeover heartbeat period (detailed view only)
- Whether operator-initiated planned takeover is optimized

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>`, ... parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-more ] (privilege: advanced)

This parameter displays the following additional information: :

- Node name
- Whether takeover on short uptime is enabled
- Short uptime interval, in seconds
- Number of giveback attempts
- Giveback attempt interval, in minutes
- Whether status is propagated through SFO mailboxes
- Status read interval, in seconds

- Status write interval, in seconds
- Hardware-assisted takeover retry count
- Hardware-assisted takeover heartbeat period

**[ [-instance ] ]**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[ -node {<nodename>|local} ] - Node (privilege: advanced)**

Selects configuration information for the specified node.

**[ -auto-giveback {true|false} ] - Auto Giveback Enabled (privilege: advanced)**

Selects configuration information for nodes that have the specified automatic giveback setting.

**[ -check-partner {true|false} ] - Check Partner Enabled (privilege: advanced)**

Selects configuration information for nodes that have the specified partner-checking setting.

**[ -detection-time <integer> ] - Takeover Detection Time (secs) (privilege: advanced)**

Selects configuration information for nodes that have the specified takeover detection time setting.

**[ -onfailure {true|false} ] - Takeover on Failure Enabled (privilege: advanced)**

Selects configuration information for nodes that have the specified takeover-on-failure setting.

**[ -onpanic {true|false} ] - Takeover on Panic Enabled (privilege: advanced)**

Selects configuration information for nodes that have the specified takeover-on-panic setting.

**[ -onshort-uptime {true|false} ] - Takeover on Short Uptime Enabled (privilege: advanced)**

Selects configuration information for nodes that have the specified takeover-on-short-uptime setting.

**[ -short-uptime <integer> ] - Short Uptime (secs) (privilege: advanced)**

Selects configuration information for nodes that have the specified takeover-on-short-uptime time setting.

**[ -attempts <integer> ] - Number of Giveback Attempts (privilege: advanced)**

Selects configuration information for nodes that have the specified number of giveback attempts setting.

**[ -attempts-time <integer> ] - Giveback Attempts Minutes (privilege: advanced)**

Selects configuration information for nodes that have the specified giveback attempt time setting.

**[ -propagate {true|false} ] - Propagate Status via Mailbox (privilege: advanced)**

Selects configuration information for nodes that have the specified setting for propagation of status through Storage Failover mailboxes.

**[ -read-interval <integer> ] - Node Status Read Interval (secs) (privilege: advanced)**

Selects configuration information for nodes that have the specified status read interval setting.

**[ -write-interval <integer> ] - Node Status Write Interval (secs) (privilege: advanced)**

Selects configuration information for nodes that have the specified status write interval setting.

**[-onreboot {true|false}] - Takeover on Reboot Enabled (privilege: advanced)**

Selects configuration information for nodes that have the specified takeover-on-reboot setting.

**[-delay-seconds <integer>] - Delay Before Auto Giveback (secs) (privilege: advanced)**

If this parameter is specified, the command displays information only about the node or nodes that have the specified delay for auto giveback.

**[-hwassist {true|false}] - Hwassist Enabled (privilege: advanced)**

Selects configuration information for nodes that have the specified hardware-assisted takeover setting.

**[-hwassist-partner-ip <text>] - Partner's Hwassist IP (privilege: advanced)**

Selects configuration information for nodes that have the specified partner IP setting for hardware-assisted takeovers.

**[-hwassist-partner-port <integer>] - Partner's Hwassist Port (privilege: advanced)**

Selects configuration information for nodes that have the specified partner port setting for hardware-assisted takeovers.

**[-hwassist-health-check-interval <integer>] - Hwassist Health Check Interval (secs) (privilege: advanced)**

Selects configuration information for nodes that have the specified health check interval setting for hardware-assisted takeovers

**[-hwassist-retry-count <integer>] - Hwassist Retry Count (privilege: advanced)**

Selects configuration information for nodes that have the specified retry count (in seconds) for hardware-assisted takeovers.

**[-mode {ha|non\_ha}] - HA Mode (privilege: advanced)**

If this parameter is specified, the command displays information only about the node or nodes that have the specified HA mode.

**[-bypass-takeover-optimization {true|false}] - Bypass Takeover Optimization Enabled (privilege: advanced)**

Selects configuration information for nodes that have the specified setting for bypass takeover optimization ( `true` means that optimized operator-initiated planned takeover is bypassed, `false` means that it is enabled). Operator-initiated planned takeover is optimized when SFO aggregates are relocated serially to the partner prior to takeover. This reduces client outage.

## Examples

The following example displays detailed information about the internal options for storage failover on a node named node2:

```
cluster1::*> storage failover internal-options show -node node2
Node: node2
                                Auto Giveback Enabled: false
                                Check Partner Enabled: true
                                Takeover Detection Time (secs): 15
                                Takeover On Failure Enabled: true
                                Takeover On Panic Enabled: false
                                Takeover On Short Uptime Enabled: true
                                Short Uptime (secs): -
                                Number of Giveback Attempts: 3
                                Giveback Attempts Minutes: 10
                                Propagate Status Via Mailbox: true
                                Node Status Read Interval (secs): 5
                                Node Status Write Interval (secs): 5
                                Failover the Storage when Cluster Ports Are Down: -
                                Failover Interval when Cluster Ports Are Down (secs): -
                                Takeover on Reboot Enabled: true
                                Delay Before Auto Giveback (secs): 300
                                Hardware Assist Enabled: true
                                Partner's Hw-assist IP:
                                Partner's Hw-assist Port: 4444
                                Hw-assist Health Check Interval (secs): 180
                                Hw-assist Retry count: 2
                                HA mode: ha
                                Bypass Takeover Optimization Enabled: true
```

## storage failover mailbox-disk show

Display information about storage failover mailbox disks

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage failover mailbox-disk show` command lists the mailbox disks that are used by storage failover. The command displays the following information:

- Node name
- Whether the mailbox disk is owned by the local node or by its partner
- Disk name
- Disk universal unique identifier (UUID)

This command is available only at the advanced privilege level and higher.

## Parameters

{ [-fields <fieldname>,...]

If -fields <fieldname>,... is used, the command displays only the specified fields.

| [-instance ] }

If this parameter is used, the command displays detailed information about all entries.

**[-node {<nodename>|local}] - Node (privilege: advanced)**

Selects the mailbox disks that are associated with the specified node.

**[-location {local|partner|tertiary}] - Mailbox Owner (privilege: advanced)**

Selects the mailbox disks that have the specified relationship to the node.

**[-diskindex <integer>] - Mailbox Disk Index (privilege: advanced)**

Selects the mailbox disk that has the specified index number.

**[-diskname <text>] - Mailbox Disk Name (privilege: advanced)**

Selects the mailbox disks that match the specified disk name.

**[-diskuuid <text>] - Mailbox Disk UUID (privilege: advanced)**

Selects the mailbox disks that match the specified UUID.

**[-physical-location {local|partner|mediator}] - Mailbox Disk Physical Location (privilege: advanced)**

Selects the mailbox disks that match the specified physical location.

**[-location-id <nvrmaid>] - System ID of the Node where the Disk is Attached (privilege: advanced)**

Selects the mailbox disks that match the specified location-id.

**[-location-name <text>] - Mailbox Disk Location (privilege: advanced)**

Selects the mailbox disks that match the specified location-name.

## Examples

The following example displays information about the mailbox disks on a node named node1:

```
cluster1::> storage failover mailbox-disk show -node node1
Node      Location  Index Disk Name      Physical Location  Disk UUID
-----  -----
-----  -----
node1
    local      0 1.0.4      local      20000000:8777E9D6:[...]
    local      1 1.0.6      partner    20000000:8777E9DE:[...]
    partner    0 1.0.1      local      20000000:877BA634:[...]
    partner    1 1.0.2      partner    20000000:8777C1F2:[...]
```

## storage failover progress-table show

Display status information about storage failover operations

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage failover progress-table show` displays status information about storage-failover operations. This information is organized in a resource table. The command displays the following information:

- Node name
- Resource-entry index number
- Resource-entry name
- Resource-entry state
- Resource-entry failure code
- Resource-entry time delta

This command is available only at the advanced privilege level and higher.

### Parameters

{ [-fields <fieldname>, ...]

If `-fields <fieldname>, ...` is used, the command will only displays only the specified fields.

| [-instance ] }

If this parameter is used, the command displays detailed information about all entries.

**[-node {<nodename>|local}] - Node (privilege: advanced)**

Selects the status information for the specified node.

**[-index <integer>] - Resource Table Index (privilege: advanced)**

Selects the status information for the specified index number.

**[-entryname <text>] - Resource Table Entry Name (privilege: advanced)**

Selects the status information for the specified entry name.

**[-state <text>] - Resource Table Entry State (privilege: advanced)**

Selects the status information for the specified state. Possible values include UP, START\_RUNNING, START\_DONE, START\_FAILED, STOP\_RUNNING, STOP\_FAILED, TAKEOVER\_BARRIER, and ONLY\_WHEN\_INITD.

**[-failurecode <text>] - Entry Failure Code (privilege: advanced)**

Selects the status information for the specified failure code. Possible values include OK, FAIL, FAIL\_ALWAYS, HANG, PANIC, and VETO.

**[-timedelta <integer>] - Entry Time Delta (privilege: advanced)**

Selects the status information for the specified time delta.

## Examples

The following example displays the entire storage-failover resource table:

```
cluster1::*> storage failover progress-table show
Node   Entry Name          State    Time Delta
-----  -----
node0
  Pre-rsrctbl: fmdisk_resumePartnerDi  start_done      6
  Pre-rsrctbl: coredump_get_busy_spar  start_done    107
  Pre-rsrctbl: raid_preread_labels_be start_done      1
  Pre-rsrctbl: fmdisk_reserve_all    start_done    84
  rsrctbl: fmrsrc_giveback_done    start_done      0
  rsrctbl: fmic                  start_done      0
  rsrctbl: fmdisk_reserve        start_done    171
  rsrctbl: fm_partnerSlowTimeout start_done      1
  rsrctbl: fmdisk_inventory      start_done      0
  rsrctbl: fmfsm_reserve        start_done      0
Press <space> to page down, <return> for next line, or 'q' to quit...
Node   Entry Name          State    Time Delta
-----  -----
node0
  rsrctbl: rdb-ha          start_done    36
  rsrctbl: giveback_cleanup_wait start_done      0
  rsrctbl: priority_ha      start_done      0
  rsrctbl: raid              start_done    113
  rsrctbl: raid_disaster_early start_done      0
  rsrctbl: wafl_nvram_replay start_done      0
  rsrctbl: takeover_test_1   start_done      0
```

# storage firmware commands

## storage firmware download

Download disk, ACP processor and shelf firmware

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The **storage firmware download** command downloads the ACP processor, disk, and shelf module firmware to a specified node. This command can also be used to download the disk qualification package (DQP).

Use the [storage disk firmware update](#) command to install downloaded disk firmware.

Use the [storage shelf firmware update](#) command to install downloaded shelf module firmware.

Use the `system node run` local storage download acp`` command to install downloaded ACP processor firmware.

## Parameters

### **-node {<nodename>|local} - Node (privilege: advanced)**

This specifies the node to which the firmware is to be downloaded.

### **-package-url <text> - Package URL (privilege: advanced)**

This specifies the path to the firmware package.

The packaged ACP processor, disk, and shelf firmware files need to have ".AFW", ".LOD", and ".SFW" file extensions, respectively.

The following URL protocols are supported: ftp, http, tftp and file. The file URL scheme can be used to specify the location of the package to be fetched from an external device connected to the storage controller. Currently, only USB mass storage devices are supported. The USB device is specified as `file://usb0/<filename>`. The package must be present in the root directory of the USB mass storage device.

## Examples

The following example downloads a disk firmware package with the path `ftp://example.com/fw/disk-fw-1.2.LOD.zip` to a node named `node1`:

```
cluster1::> storage firmware download -node node1 -package-url  
ftp://example.com/fw/disk-fw-1.2.LOD.zip
```

## Related Links

- [storage disk firmware update](#)
- [storage shelf firmware update](#)
- [system node run](#)

## storage firmware acp delete

### Delete an ACP firmware file

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage firmware acp delete` command deletes the specified ACP processor firmware file from all nodes that are currently part of the cluster.

## Parameters

### **-filename <text> - Firmware Filename (privilege: advanced)**

Specifies the firmware file to delete.

## Examples

The following example deletes the ACP processor firmware file with the name ACP-IOM3.0150.AFW.FVF on each node:

```
cluster1::*> storage firmware acp delete -filename ACP-IOM3.0150.AFW.FVF
```

## storage firmware acp rename

Rename an ACP firmware file

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage firmware acp rename` command renames the specified ACP processor firmware file on each node.

### Parameters

**-oldname <text> - Old Filename (privilege: advanced)**

This parameter specifies the firmware file to rename.

**-newname <text> - New Filename (privilege: advanced)**

This parameter specifies the new name of the firmware file.

## Examples

The following example renames the ACP processor firmware file with the name ACP-IOM3.0150.AFW.FVF to ACP-IOM3.AFW.FVF on each node:

```
cluster1::*> storage firmware acp rename -oldname ACP-IOM3.0150.AFW.FVF  
-newname ACP-IOM3.AFW.FVF
```

## storage firmware acp show

Display the list of ACP firmware files on the given node

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage firmware acp show` command displays the ACP processor firmware files present on each node.

### Parameters

{ [-fields <fieldname>,...]

If you specify the -fields <fieldname>, ... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the files that match the specified node name.

**[-filename <text>] - Storage Firmware File**

Selects the files that match the specified filename.

## Examples

The following example displays the ACP processor firmware files on each node:

```
cluster1::> storage firmware acp show
Node: Node1
ACP Firmware Files
-----
ACP-IOM3.0150.AFW.FVF
ACP-IOM3.AFW
ACP-IOM6.0210.AFW
ACP-IOM6.0210.AFW.FVF

Node: Node2
ACP Firmware Files
-----
ACP-IOM3.0150.AFW.FVF
ACP-IOM3.AFW
ACP-IOM6.0210.AFW
ACP-IOM6.0210.AFW.FVF
8 entries were displayed.
```

## storage firmware disk delete

Delete a disk firmware file

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The *storage firmware disk delete* command deletes the specified disk firmware file on each node.

### Parameters

## **-filename <text> - Storage Firmware Filename (privilege: advanced)**

Specifies the firmware file to delete.

### **Examples**

The following example deletes the disk firmware file with the name X262\_SMOOST25SSX.NA06.LOD on each node:

```
cluster1::*> storage firmware disk delete -filename  
X262_SMOOST25SSX.NA06.LOD
```

## **storage firmware disk rename**

Rename a disk firmware file

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### **Description**

The `storage firmware disk rename` command renames the specified disk firmware file on each node.

### **Parameters**

#### **-oldname <text> - Old Filename (privilege: advanced)**

This parameter specifies the firmware file to rename.

#### **-newname <text> - New Filename (privilege: advanced)**

This parameter specifies the new name of the firmware file.

### **Examples**

The following example renames the disk firmware file with the name X262\_SMOOST25SSX.NA06.LOD to X262\_SMOOST25SSX.LOD on each node:

```
cluster1::*> storage firmware disk rename -oldname  
X262_SMOOST25SSX.NA06.LOD -newname X262_SMOOST25SSX.LOD
```

## **storage firmware disk show**

Display the list of disk firmware files on the given node

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `storage firmware disk show` command displays the disk firmware files present on each node.

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

[-node {<nodename>|local}] - Node

Selects the files that match the specified node name.

[-filename <text>] - Storage Firmware File

Selects the files that match the specified filename.

## Examples

The following example displays the disk firmware files on each node:

```
cluster1::> storage firmware disk show
Node: Node1
Disk Firmware Files
-----
X262_SMOOST25SSX.NA06.LOD
X262_SMOOST25SSX.NA06.LOD.FVF
X267_SMOOST50SSX.NA06.LOD
X267_SMOOST50SSX.NA06.LOD.FVF

Node: Node2
Disk Firmware Files
-----
X262_SMOOST25SSX.NA06.LOD
X262_SMOOST25SSX.NA06.LOD.FVF
X267_SMOOST50SSX.NA06.LOD
X267_SMOOST50SSX.NA06.LOD.FVF
8 entries were displayed.
```

## storage firmware hba show

Display the list of HBA firmware files on the given node

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage firmware hba show` command displays the HBA firmware files present on each node. For MCC configs, run the command on each DR group.

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the files that match the specified node name.

**[-filename <text>] - Storage Firmware File**

Selects the files that match the specified filename.

## Examples

The following example displays the HBA firmware files on each node:

```
cluster1::> storage firmware hba show
Node: Node1
HBA Firmware Files
-----
PM8072.03080900.HFW
SAS3008.13000000.HFW
SAS3616W.12030003.HFW
PM8072.03080900.HFW

Node: Node2
HBA Firmware Files
-----
PM8072.03080900.HFW
SAS3008.13000000.HFW
SAS3616W.12030003.HFW
PM8072.03080900.HFW
8 entries were displayed.
```

## storage firmware shelf delete

Delete a shelf firmware file

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage firmware shelf delete` command deletes the specified shelf firmware file from all nodes that are currently part of the cluster.

## Parameters

### **-filename <text> - Storage Firmware Filename (privilege: advanced)**

Specifies the firmware file to delete.

## Examples

The following example deletes the shelf firmware file with the name IOM12.0210.SFW on each node:

```
cluster1::*> storage firmware shelf delete -filename IOM12.0210.SFW
```

## storage firmware shelf rename

Rename a shelf firmware file

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage firmware shelf rename` command renames the specified shelf firmware file on each node.

## Parameters

### **-oldname <text> - Old Filename (privilege: advanced)**

This parameter specifies the firmware file to rename.

### **-newname <text> - New Filename (privilege: advanced)**

This parameter specifies the new name of the firmware file.

## Examples

The following example renames the shelf firmware file with the name IOM12.0210.SFW to IOM12.000.SFW on each node:

```
cluster1::*> storage firmware shelf rename -oldname IOM12.0210.SFW  
-newname IOM12.000.SFW
```

## storage firmware shelf show

Display the list of shelf firmware files on the given node

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage firmware shelf show` command displays the shelf firmware files present on each node.

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the files that match the specified node name.

**[-filename <text>] - Storage Firmware File**

Selects the files that match the specified filename.

## Examples

The following example displays the shelf firmware files on each node:

```
cluster1::> storage firmware shelf show
Node: Node1
Shelf Firmware Files
-----
AT-FCX.3800.SFW
AT-FCX.3800.SFW.FVF
ESH4.1400.SFW
ESH4.1400.SFW.FVF

Node: Node2
Shelf Firmware Files
-----
AT-FCX.3800.SFW
AT-FCX.3800.SFW.FVF
ESH4.1400.SFW
ESH4.1400.SFW.FVF
8 entries were displayed.
```

# storage iscsi-initiator commands

## storage iscsi-initiator add-target

Add an iSCSI target

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage iscsi-initiator add-target` command adds an iSCSI target to a node's list of targets.

This command is only supported on high-availability shared-nothing virtualized platforms.

## Parameters

### **-node {<nodename>|local} - Node (privilege: advanced)**

Specifies the name of the Data ONTAP node to which the iSCSI target will be added.

### **-label <text> - User Defined Identifier (privilege: advanced)**

Specifies a label for the target to be added.

### **-target-type {external|mailbox|partner|partner2|dr\_auxiliary|dr\_partner} - Target Type (privilege: advanced)**

Specifies the type of the target. It is used by the node to determine how to use the LUNs. There are five target types:

- partner - The partner target should belong to the node's HA partner. This allows the node to access its partner's disks.
- mailbox - A mailbox target's LUNs are used exclusively as HA mailboxes.
- external - External targets' LUNs can be used by the node but do not play a role in HA.
- dr\_auxiliary - The DR auxiliary target for MetroCluster over IP. Not a valid target type for the add-target command.
- dr\_partner - The DR partner target for MetroCluster over IP. Not a valid target type for the add-target command.

### **-target-portal <text> - Target Portal (privilege: advanced)**

Specifies the target's IP address and listening TCP port. The port is not required if it is the default iSCSI port (3260). Examples of correct target portals are *10.0.0.2* and *10.0.0.2:860*.

### **-target-name <text> - iSCSI Name (privilege: advanced)**

Specifies the iSCSI target name such as an IQN (iSCSI qualified name).

### **[-status-admin {down|up}] - Administrative Status (default: up) (privilege: advanced)**

Use to specify whether the initial administrative status of the connection is up or down. The default setting is *up*.

## Examples

The following example adds and connects to an iSCSI target from the specified node.

```
cluster1::> storage iscsi-initiator add-target -node node1
              -label target1 -target-type external
              -target-portal 10.0.0.2:860
              -target-name iqn.2012-06.com.bsdctl:target0
```

## storage iscsi-initiator connect

Connect to an iSCSI target

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage iscsi-initiator connect` command connects a node to the specified target. This command is only supported on high-availability shared-nothing virtualized platforms.

## Parameters

**-node {<nodename>|local} - Node (privilege: advanced)**

Specifies the name of the Data ONTAP node to which the iSCSI target will be connected.

**[-target-type {external|mailbox|partner|partner2|dr\_auxiliary|dr\_partner}] - Target Type (privilege: advanced)**

Selects targets with the specified target type.

**-label <text> - User Defined Identifier (privilege: advanced)**

Specifies the label of the target to connect to.

## Examples

The following example adds and connects to an iSCSI target from the specified node.

```
cluster1::*> storage iscsi-initiator connect -node node1
                  -label target1
```

## storage iscsi-initiator disconnect

Disconnect from an iSCSI target

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage iscsi-initiator disconnect` command disconnects a node from the specified target. This command is only supported on high-availability shared-nothing virtualized platforms.

## Parameters

**-node {<nodename>|local} - Node (privilege: advanced)**

Specifies the name of the Data ONTAP node from which the iSCSI target will be disconnected.

**[-target-type {external|mailbox|partner|partner2|dr\_auxiliary|dr\_partner}] - Target Type (privilege: advanced)**

Selects targets with the specified target type.

**-label <text> - User Defined Identifier (privilege: advanced)**

Specifies the label of the target to disconnect from.

## Examples

The following example adds and connects to an iSCSI target from the specified node.

```
cluster1::*> storage iscsi-initiator disconnect -node node1
                  -label target1
```

## storage iscsi-initiator remove-target

Remove an iSCSI target

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage iscsi-initiator remove-target` command removes an iSCSI target from a node's list of targets. This command is only supported on high-availability shared-nothing virtualized platforms.

### Parameters

**-node {<nodename>|local} - Node (privilege: advanced)**

Specifies the name of the Data ONTAP node from which the iSCSI target will be removed.

**[-target-type {external|mailbox|partner|partner2|dr\_auxiliary|dr\_partner}] - Target Type (privilege: advanced)**

Selects targets with the specified target type.

**-label <text> - User Defined Identifier (privilege: advanced)**

Specifies the label of the target to be removed.

## Examples

The following example adds and connects to an iSCSI target from the specified *node*.

```
cluster1::*> storage iscsi-initiator remove-target -node node1
                  -label target1
```

## storage iscsi-initiator show

Display the iSCSI targets

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage iscsi-initiator show` displays the list of iSCSI targets configured for each Data ONTAP node in the cluster. This command is only supported on high-availability shared-nothing virtualized platforms.

## Parameters

{ [-fields <fieldname>, ...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node (privilege: advanced)**

Represents the name of the Data ONTAP node for which information is to be displayed. If this parameter is not specified, the command displays information about all nodes in the cluster.

**[-target-type {external|mailbox|partner|partner2|dr\_auxiliary|dr\_partner}] - Target Type (privilege: advanced)**

Selects targets with the specified target type.

**[-label <text>] - User Defined Identifier (privilege: advanced)**

Selects targets with the specified label.

**[-target-portal <text>] - Target Portal (privilege: advanced)**

Selects targets with the specified portal.

**[-target-name <text>] - iSCSI Name (privilege: advanced)**

Selects targets with the specified target name.

**[-status-admin {down|up}] - Administrative Status (privilege: advanced)**

Selects targets with the specified administrative status.

**[-status-oper {down|up}] - Operational Status (privilege: advanced)**

Selects targets with the specified operational status.

**[-failure-reason <text>] - Failure Reason (privilege: advanced)**

Selects targets with the specified failure reason.

## Examples

The following example displays the list of iSCSI targets for each node in the cluster.

```

cluster1::*> storage iscsi-initiator show

Status
Node Type Label      Target Portal      Target Name
Admin/Op

-----
-----
node1
  mailbox
    mediator 10.235.14.141      iqn.2012-05.local:mailbox.group.1
up/up
  partner
    partner 10.63.7.205:65200  iqn.2012-06.com.bsdctl:target0
up/up
node2
  mailbox
    mediator 10.235.14.141      iqn.2012-05.local:mailbox.group.1
up/up
  partner
    partner 10.63.7.201:65200  iqn.2012-06.com.bsdctl:target0
up/up
4 entries were displayed.

```

## storage path commands

### storage path quiesce

Quiesce I/O on a path to array

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The *storage path quiesce* command quiesces I/O on one path to a LUN. It also quiesces the given entire path immediately or can monitor the given path for error threshold before quiesce. After the I/O has been quiesced, no new I/O is sent on the path unless the [storage path resume](#) command is issued to continue I/O.

#### Parameters

**-node {<nodename>|local} - Node name**

The name of the clustered node for which information is being displayed.

**-initiator <initiator name> - Initiator Port**

Initiator port that the clustered node uses.

**-target-wwpn <wwpn name> - Target Port**

Target World Wide Port Name. Port on the storage array that is being used.

**{ [-lun-number <integer>] - LUN Number**

Logical Unit number. The range is: [0...65535]. If this parameter is not specified, Data ONTAP resumes the entire path to an array.

**| [-path-failure-threshold <integer>] - Max Number of Path Failures Acceptable During wait-duration**

The path failure count, exceeding this value within wait duration will quiesce the path.

**[-wait-duration <integer>] - Wait Duration in minutes }**

The time duration(minutes) in which path is monitored for path failures.

## Examples

The following example suspends I/O between node vbv3170f1b, port 0a and the array port 50001fe1500a8669, LUN 1.

```
node::> storage path quiesce -node vbv3170f1b -initiator 0a -target-wwpn  
50001fe1500a8669 -lun-number 1
```

The following example suspends I/O immediately between node vbv3170f1b, port 0a and the array port 50001fe1500a8669.

```
node::> storage path quiesce -node vbv3170f1b -initiator 0a -target-wwpn  
50001fe1500a8669
```

The following example suspends I/O between node vbv3170f1b, port 0a and the array port 50001fe1500a8669 after reaching 10 or more errors in duration of 5 mins.

```
node::> storage path quiesce -node vbv3170f1b -initiator 0a -target-wwpn  
50001fe1500a8669 -path-failure-threshold 10 -wait-duration 5
```

## Related Links

- [storage path resume](#)

## storage path resume

Resume I/O on a path to array

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage path resume` command continues I/O flow to an array LUN on a path or the entire path that was previously quiesced. It also disables the path failures monitoring feature, if it was enabled using the [storage path quiesce-path-failure-threshold count](#) command.

## Parameters

### **-node {<nodename>|local} - Node name**

The name of the clustered node for which information is being displayed.

### **-initiator <initiator name> - Initiator Port**

Initiator port that the clustered node uses.

### **-target-wwpn <wwpn name> - Target Port**

Target World Wide Port Name. Port on the storage array that is being used.

### **[-lun-number <integer>] - LUN Number**

Logical Unit number. The range is: [0...65535]. If this parameter is not specified, Data ONTAP resumes the entire path to an array.

## Examples

The following example resumes I/O between node vbv3170f1b, port 0a and the array port 50001fe1500a8669, LUN 1

```
node::> storage path resume -node vbv3170f1b -initiator 0a -target-wwpn  
50001fe1500a8669 -lun-number 1
```

The following example resumes I/O between node vbv3170f1b, port 0a and the array port 50001fe1500a8669

```
node::> storage path resume -node vbv3170f1b -initiator 0a -target-wwpn  
50001fe1500a8669
```

## Related Links

- [storage path quiesce](#)

## **storage path show-by-initiator**

Display a list of paths to attached arrays from the initiator's perspective

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage path show-by-initiator` command displays path based statistics. The output is similar to the [storage path show](#) command but the output is listed by initiator.

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Controller name**

The name of the clustered node for which information is being displayed.

**[-initiator <text>] - Initiator Port**

Initiator port that the clustered node uses.

**[-target-wwpn <text>] - Target Port**

Target World Wide Port Name. Port on the storage array that is being used.

**[-initiator-side-switch-port <text>] - Initiator Side Switch Port**

Switch port connected to the clustered node.

**[-target-side-switch-port <text>] - Target Side Switch Port**

Switch port connected to the array.

**[-array-name <array name>] - Array Name**

Name of the storage array that is connected to the cluster.

**[-tpgn <integer>] - Target Port Group Number**

TPGN refers to the target port group to which the target port belongs. A target port group is a set of target ports which share the same LUN access characteristics and failover behaviors.

**[-port-speed <text>] - Port Speed**

Port Speed of the specified port.

**[-path-io-kbps <integer>] - Kbytes of I/O per second on Path (Rolling Average)**

Rolling average of I/O per second on the path.

**[-path-iops <integer>] - Number of IOPS on Path (Rolling Average)**

Rolling average of Kbytes of I/O per second on the path

**[-initiator-io-kbps <integer>] - Kbytes of I/O per second on Initiator (Rolling Average)**

Rolling average of I/O per second on the initiator port.

**[-initiator-iops <integer>] - Number of IOPS on Initiator (Rolling Average)**

Rolling average of Kbytes of I/O per second on the initiator port.

**[-target-io-kbps <integer>] - Kbytes of I/O per second to Target (Rolling Average)**

Rolling average of I/O per second on the target port.

## **[-target-iops <integer>] - Number of IOPS to Target (Rolling Average)**

Rolling average of Kbytes of I/O per second on the target port.

### **Examples**

```
vnv3070f20b::> storage path show-by-initiator
Node: vnv3070f20b
      Initiator I/O      Initiator Side      Path I/O      Target
Side  Target I/O
Initiator      (KB/s)      Switch Port      (KB/s)      Switch
Port      (KB/s)      Target Port Array Name
-----
-----
0a          3  vnbr3850s4:4          3
vnbr3850s5:15          3  200600a0b819e16f  IBM_1722_1
                           0
vnbr3850s5:12          0  50060e80004291c0  HITACHI_DF600F_1
0c          35  vnci9124s54:1-6          35
vnci9124s54:1-24          35  200700a0b819e16f  IBM_1722_1
                           0
vnci9124s54:1-22          0  50060e80004291c2  HITACHI_DF600F_1
4 entries were displayed.
```

### **Related Links**

- [storage path show](#)

## **storage path show**

Display a list of paths to attached arrays.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `storage path show` command displays path based statistics. The default command shows:

- Node name
- Initiator port
- Target port
- Target IQN
- TPGN
- Port speeds
- Path I/O in Kbytes/sec
- IOPs

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-array ]

Using this option displays:

- Array name
- Target port
- Target IQN
- Target I/O in Kbytes/sec
- Target side switch port
- Path I/O in Kbytes/sec
- Initiator side switch port
- Initiator I/O in Kbytes/sec
- Initiator port

| [-by-target ]

Using this option displays the same information as the array option, but grouped by target port.

| [-detail ]

Using this option displays the same information as the array and by-target options, but adds the following:

- Target IOPs
- Target LUNs
- Path IOPs
- Path errors
- Path quality
- Path LUNs
- Initiator IOPs
- Initiator LUNs

| [-switch ]

Using this option adds switch port information to the default display.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Controller name**

The name of the clustered node for which information is being displayed.

**[-array-name <array name>] - Array Name**

Name of the storage array that is connected to the cluster.

**[-target-wwpn <text>] - Target Port**

Target World Wide Port Name. Port on the storage array that is being used.

**[-initiator <text>] - Initiator Port**

Initiator port that the clustered node uses.

**[-initiator-side-switch-port <text>] - Initiator Side Switch Port**

Switch port connected to the clustered node.

**[-tpgn <integer>] - Target Port Group Number**

TPGN refers to the target port group to which the target port belongs. A target port group is a set of target ports which share the same LUN access characteristics and failover behaviors.

**[-port-speed <text>] - Port Speed**

Port Speed of the specified port.

**[-path-io-kbps <integer>] - Kbytes of I/O per second on Path (Rolling Average)**

Rolling average of I/O per second on the path.

**[-path-iops <integer>] - Number of IOPS on Path (Rolling Average)**

Rolling average of Kbytes of I/O per second on the path

**[-initiator-io-kbps <integer>] - Kbytes of I/O per second on Initiator (Rolling Average)**

Rolling average of I/O per second on the initiator port.

**[-initiator-iops <integer>] - Number of IOPS on Initiator (Rolling Average)**

Rolling average of Kbytes of I/O per second on the initiator port.

**[-target-io-kbps <integer>] - Kbytes of I/O per second to Target (Rolling Average)**

Rolling average of I/O per second on the target port.

**[-target-iops <integer>] - Number of IOPS to Target (Rolling Average)**

Rolling average of Kbytes of I/O per second on the target port.

**[-target-side-switch-port <text>] - Target Side Switch Port**

Switch port connected to the array.

**[-path-link-errors <integer>] - Link Error count on path**

Fibre Channel link error count.

**[-path-quality <integer>] - Percentage of weighted error threshold**

A number representing the threshold of errors that is allowed on the path. Path quality is a weighted error value. When the error weight of a path exceeds the threshold, I/O is routed to a different path.

**[-path-lun-in-use-count <integer>] - Number of LUNs in the in-use state on this path**

Number of LUNs on this path.

**[-initiator-lun-in-use-count <integer>]** - Number of LUNs in the in-use state on this initiator

Number of LUNs on this initiator.

**[-target-lun-in-use-count <integer>]** - Number of LUNs in the in-use state on this target

Number of LUNs on this target.

**[-vmdisk-device-id <integer>]** - Virtual disk device ID

Common device identifier, shared by a VM and its hypervisor, of a virtual disk. On ESX servers, this is the Disk ID component of a virtual device node, with a value of 0 to 15.

**[-path-failure-threshold <integer>]** - Max number of path failures acceptable in wait-duration

The path failure count, exceeding this value within wait duration will quiesce the path.

**[-wait-duration <integer>]** - Wait Duration in minutes

The time duration(minutes) in which path is monitored for path failures.

## Examples

The following example shows the default display.

```
vbv3170f2a::> storage path show
```

Path I/O		Initiator	Array	Target	Port	TPGN	Speed
Node (KB/s)	IOPS						
vbv3170f2a-01 6	0b 2		50001fe1500a866c			2	2 Gb/S
vbv3170f2a-01 0	0b 0		50001fe1500a866d			2	2 Gb/S
vbv3170f2a-01 0	0c 0		50001fe1500a866e			4	4 Gb/S
vbv3170f2b-03 3	0a 1		50001fe1500a866d			1	2 Gb/S
vbv3170f2b-03 3	0c 1		50001fe1500a866f			4	4 Gb/S
5 entries were displayed.							

The following example shows how the information is displayed with the array option.

```
vnv3070f20b::> storage path show -array
Node: vnv3070f20b
                                         Target I/O          Target Side
                                         Initiator Side Initiator I/O Initiator
                                         Target Port          (KB/s)          Switch Port
                                         (KB/s)          Switch Port          (KB/s)          Port
                                         -----
                                         -----
HITACHI_DF600F_1 50060e80004291c0          0          vnbr3850s5:12
0          vnbr3850s4:4          3          0a
          50060e80004291c2          0          vnci9124s54:1-22
0          vnci9124s54:1-6          26          0c
IBM_1722_1 200600a0b819e16f          3          vnbr3850s5:15
3          vnbr3850s4:4          3          0a
          200700a0b819e16f          26          vnci9124s54:1-24
26          vnci9124s54:1-6          26          0c
4 entries were displayed.
```

The following example shows how the information is displayed when grouped by target.

```

vnv3070f20b::> storage path show -by-target
Node: vnv3070f20b
Array Name: HITACHI_DF600F_1
          Target I/O          Target Side      Path I/O
Initiator Side Initiator I/O Initiator
Target Port          (KB/s)          Switch Port      (KB/s)
Switch Port          (KB/s)          Port
-----
-----
50060e80004291c0      0          vnbr3850s5:12      0
vnbr3850s4:4          3          0a
50060e80004291c2      0          vnci9124s54:1-22      0
vnci9124s54:1-6      26          0c
Node: vnv3070f20b
Array Name: IBM_1722_1
          Target I/O          Target Side      Path I/O
Initiator Side Initiator I/O Initiator
Target Port          (KB/s)          Switch Port      (KB/s)
Switch Port          (KB/s)          Port
-----
-----
200600a0b819e16f      3          vnbr3850s5:15      3
vnbr3850s4:4          3          0a
200700a0b819e16f      26         vnci9124s54:1-24      26
vnci9124s54:1-6      26          0c
4 entries were displayed.

```

The following example shows how the information is displayed with the switch option.

```
vbv3170f2b::> storage path show -switch
```

Initiator Side				Target Side	
Node	Initiator	Array	Target	Port	Switch Port
Switch Port	TPGN	Speed	(KB/s)		IOPS
vbv3170f2a-01	0b	50001fe1500a866c			vbbr300s1:6
vbbr300s1:2	2	2 Gb/S	9		3
vbv3170f2a-01	0b	50001fe1500a866d			vbbr300s1:7
vbbr300s1:2	2	2 Gb/S	0		0
vbv3170f2a-01	0c	50001fe1500a866e			vbc19124s2:1-7
vbc19124s2:1-3	4	4 Gb/S	0		0
vbv3170f2b-03	0a	50001fe1500a866d			vbbr300s1:7
vbbr300s1:3	1	2 Gb/S	4		1
vbv3170f2b-03	0c	50001fe1500a866f			vbc19124s2:1-8
vbc19124s2:1-4	4	4 Gb/S	4		1

5 entries were displayed.

## storage pool commands

### storage pool add

Add disks to a storage pool

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The *storage pool add* command increases the total capacity of an existing storage pool by adding the specified SSDs to the storage pool. The disks are split into four equal partitions and added to each of the allocation units of the storage pool. If any allocation units from the storage pool have already been allocated to an aggregate, the cache capacity of that aggregate is increased automatically.

For example, if an SSD with a usable size of 745 GB is added to a storage pool that is part of four aggregates, each aggregate will grow its cache capacity by 186.2 GB. If a different allocation is desired, create a new storage pool using the [storage pool create](#) command.



Storage pools are not supported in all-flash aggregates.

#### Parameters

**-storage-pool <storage pool name>** - Storage Pool Name

This parameter specifies the storage pool to which disks are to be added.

## { [-disk-count <integer>] - Number of Disks to Add in Storage Pool}

This parameter specifies the number of disks that are to be added to the storage pool. The disks to be added come from the pool of spare disks.

## [-nodes {<nodename>|local}] - Nodes From Which Spares Should be Selected

This parameter specifies a list of nodes from which SSD disks are selected for addition to the storage pool. If this parameter is not specified, disks to be added to the storage pool can be selected from both the nodes sharing the storage pool. Use this parameter to restrict the selection of spare disks to one particular node.

## | [-disk-list <disk path name>,...] - List of Spare Disks }

This parameter specifies a list of disks to be added to the storage pool. In an HA configuration, SSDs being added to a storage pool can be owned by either node in the HA pair.

## { [-quiet <true>] - Confirmations off (privilege: advanced)}

When set to *true*, this parameter specifies the operation should be executed without pausing for confirmation.

## [-simulate <true>] - Simulate Storage Pool Addition

When set to *true*, this parameter specifies the operation should be performed as a simulation. The command reports which aggregates would grow automatically as a result of adding the disks to the storage pool. The disks are not added to the storage pool.

## Examples

In this example, the user requests a report detailing the changes that would occur if a new disk is added to the storage pool *SP1*. In this case, 186.2 GB of cache is added to the Flash Pool aggregates *nodeA\_flashpool\_1* and *nodeB\_flashpool\_1*. There are two unprovisioned allocation units in the storage pool and therefore the storage pool available capacity also grows by 372.5 GB.

```
cluster1::> storage pool add -storage-pool SP1 -disk-list 1.0.23 -simulate
```

This operation will result in capacity being allocated in the following way:

Container	Capacity	Current	New
Name	To Be Added	Size	Size
-----	-----	-----	-----
nodeA_flashpool_1	186.2GB	558.7GB	744.9GB
nodeB_flashpool_1	186.2GB	558.7GB	744.9GB
(Available Capacity)	372.5GB	1.09TB	1.45TB

The following example adds one disk to a storage pool named *SP1*. The spare disks are selected from either local node or its partner or both based on spare availability.

```

cluster-1::> storage pool add -storage-pool SP1 -disk-count 1

Info: The following disks will be added to storage pool "SP1":
Disk           Size  Type  Owner
-----
1.0.12         744.9GB SSD   cluster-1-01

New Allocation Unit Size: 744.8GB
Capacity will be allocated in the following way:
Container      Capacity  Current  New
Name           To Be Added  Size     Size
-----
nodeA_flashpool_1  186.2GB  558.7GB  744.9GB
nodeB_flashpool_1  186.2GB  558.7GB  744.9GB
(Available Capacity) 372.5GB  1.09TB   1.45TB

Are you sure you want to continue with this operation?
{y|n}: y
[Job 48] Job succeeded: storage pool add job for "SP1" completed
successfully

```

## Related Links

- [storage pool create](#)

## storage pool create

### Create a new storage pool

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage pool create` command creates an SSD storage pool using a given list of spare SSDs.

When a storage pool is created, Data ONTAP splits the capacity provided by the SSDs into four equally-sized allocation units. In an HA configuration, two allocation units (containing 50% of the total capacity) are assigned to each node in the HA pair. This assignment can be modified using the [storage pool reassign](#) command.

After the storage pool is created, its allocation units can be provisioned into Flash Pool aggregates using the [storage aggregate add-disks](#) command and the `-storage-pool` parameter.



Storage pools are not supported in All-Flash aggregates.

### Parameters

#### **-storage-pool <storage pool name> - Storage Pool Name**

This parameter specifies the name of the storage pool that is to be created. The SSDs are partitioned and placed into the new storage pool.

## { [-nodes {<nodename>|local}] - Nodes Sharing the Storage Pool

This parameter specifies a list of nodes from which SSD disks are selected to create the storage pool. If two nodes are specified then they need to be in HA configuration. Spare disks are selected from either node or its partner or both. If this parameter is not specified, storage pool will be created by selecting disks from either the node or its partner or both from where command is run.

## -disk-count <integer> - Number of Disks in Storage Pool

This parameter specifies the number of disks that are to be included in the storage pool. The disks in this newly created storage pool come from the pool of spare disks. The smallest disks in this pool are added to the storage pool first, unless you specify the -disk-size parameter.

## [-disk-size {<integer>[KB|MB|GB|TB|PB]} - Disk Size

This parameter specifies the size of the disks on which the storage pool is to be created. Disks with a usable size between 95% and 105% of the specified size are selected.

## { -disk-list <disk path name>, ... - Disk List for Storage Pool Creation }

This parameter specifies a list of SSDs to be included in the new storage pool. The SSDs must be spare disks and can be owned by either node in an HA pair.

## [-simulate <true>] - Simulate Storage Pool Creation

This option simulates the storage pool creation and prints the allocation unit size that would be used for the storage pool.

## Examples

The following example creates a storage pool named SP1. The storage pool contains 3 SSD disks, the spare disks selected are from either local node, or its partner or both based on spare availability.

```
cluster1::> storage pool create -storage-pool SP1 -disk-count 3
```

The following example creates a storage pool named SP2. The storage pool contains 3 SSD disks, the spare disks selected are from either node0, or its partner node1 or both based on spare availability.

```
cluster1::> storage pool create -storage-pool SP2 -disk-count 3 -nodes node0,node1
```

The following example creates a storage pool named SP3 from four SSDs using disk list.

```
cluster1::> storage pool create -storage-pool SP3 -disk-list 1.0.13,  
1.0.15, 1.0.17, 1.0.19
```

## Related Links

- [storage pool reassign](#)
- [storage aggregate add-disks](#)

## storage pool delete

Delete an existing storage pool

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage pool delete` command deletes an existing SSD storage pool. At the end of the operation, the SSDs are converted back to spare disks.

### Parameters

#### **-storage-pool <storage pool name> - Storage Pool Name**

This parameter specifies the storage pool that you want to delete. You can delete the storage pool only if all of the allocation units in the storage pool are available.

### Examples

Verify that storage pool *SP3* is ready for deletion by confirming it has four available allocation units and then delete it.

```
cluster1::> storage pool show-available-capacity -storage-pool SP3
                                         Storage SyncMirror Allocation Unit  Total
                                         Node      Storage Pool   Type     Pool      Unit size  Count Usable Size
-----  -----
node-a      SP3           SSD     Pool0      372.5GB   2      744.9GB
node-b      SP3           SSD     Pool0      372.5GB   2      744.9GB
2 entries were displayed.
```

```
cluster1::> storage pool delete -storage-pool SP3
```

```
Warning: Are you sure you want to delete storage pool "SP3"? {y|n}: y
[Job 313] Job succeeded: storage pool delete job for "SP3" completed
successfully
```

## storage pool reassign

Reassign capacity from one node to another node in storage pool

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage pool reassign` command changes the ownership of unprovisioned (available) storage pool allocation units from one HA partner to the other for an existing storage pool.

## Parameters

### **-storage-pool <storage pool name> - Storage Pool Name**

This parameter specifies the storage pool within which available capacity is reassigned from one node to another.

### **-from-node {<nodename>|local} - Reassign Available Capacity from This Node**

This parameter specifies the name of the node that currently owns the allocation units.

### **-to-node {<nodename>|local} - Reassign Available Capacity to This Node**

This parameter specifies the name of the node that will now own the allocation units.

### **-allocation-units <integer> - Allocation Units**

This parameter specifies the number of allocation units to be reassigned.

## Examples

Move an available allocation unit from node-b to node-a in preparation for provisioning the allocation units on node-a.

```
cluster1::*> storage pool show-available-capacity -storage-pool SP2
                                         Storage SyncMirror Allocation Unit  Total
                                         Node      Storage Pool      Type      Pool      Unit size  Count Usable Size
-----  -----
node-a      SP2                  SSD      Pool0      744.9GB   2      1.45TB
node-b      SP2                  SSD      Pool0      744.9GB   1      744.9GB
2 entries were displayed.
```

```
cluster1::*> storage pool reassign -storage-pool SP2 -from-node node-b -to
               -node node-a -allocation-units 1
[Job 310] Job succeeded: storage pool reassign job for "SP2" completed
successfully
```

```
cluster1::*> storage pool show-available-capacity -storage-pool SP2
                                         Storage SyncMirror Allocation Unit  Total
                                         Node      Storage Pool      Type      Pool      Unit size  Count Usable Size
-----  -----
node-a      SP2                  SSD      Pool0      744.9GB   3      2.18TB
node-b      SP2                  SSD      Pool0      744.9GB   0      0B
2 entries were displayed.
```

## storage pool rename

### Rename storage pool

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage pool rename` command changes the name of the storage pool.

## Parameters

### **-storage-pool <storage pool name> - Storage Pool Name**

This parameter specifies the storage pool name.

### **-new-name <storage pool name> - New Name of the Storage Pool**

This parameter specifies the new name of the storage pool.

## Examples

Renaming storage pool "sp1" to "sp2"

```
cluster-1::> storage pool show
      Storage
Storage Pool      Type    #Disks Nodes      Total Size
-----
sp1              SSD        4 node-a,
                           node-b
                           10.44GB
```

```
cluster-1::> storage pool rename -storage-pool sp1 -new-name sp2
```

```
cluster-1::> storage pool show
      Storage
Storage Pool      Type    #Disks Nodes      Total Size
-----
sp2              SSD        4 node-a,
                           node-b
                           10.44GB
```

## **storage pool show-aggregate**

Display aggregates provisioned from storage pools

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage pool show-aggregate` command displays allocation information for SSD storage pools in the cluster. The command output depends upon the parameter or parameters specified with the command. If no parameters are specified, the command displays information about allocations of all storage pools in the cluster.

## Parameters

{ [-fields <fieldname>,...]

If you specify the -fields <fieldname>, ... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-storage-pool <storage pool name>] - Name of Storage Pool**

Selects the storage pools that match this parameter value.

**[-aggregate <aggregate name>] - Aggregate**

Selects the storage pools that match this parameter value.

**[-capacity {<integer>[KB|MB|GB|TB|PB]}] - Capacity**

Selects the storage pools that match this parameter value.

Capacity includes space provided by data and parity portions of each allocation unit. Only the data portions of each allocation unit contribute to the cache capacity of Flash Pool.

**[-allocated-unit-count <integer>] - Number of AU's Assigned to This Aggregate**

Selects the storage pools that match this parameter value.

**[-original-owner <text>] - Original Owner Name**

Selects the storage pools that match this parameter value.

**[-node {<nodename>|local}] - Node**

Selects the storage pools that match this parameter value.

## Examples

Display information about the aggregate or aggregates using a storage pool called *SP2*:

```
cluster1::> storage pool show-aggregate -storage-pool SP2 -instance
Name of Storage Pool: SP2
                                Aggregate: node2_flashpool_1
                                Capacity: 744.9GB
Number of AU's Assigned to This Aggregate: 1
                                Original Owner Name: node2
                                Node: node2
```

## storage pool show-available-capacity

Display available capacity of storage pools

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The storage pool show-available-capacity command displays information about available capacity in SSD storage pools on each node in the cluster. The command output depends upon the parameter or parameters specified with the command. If no parameters are specified, the command displays information about available capacities in all shared pools in the cluster.

Storage pool available capacity is data storage space that has not yet been provisioned into Flash Pool. Allocation units might be provisioned into aggregates using the [storage aggregate add-disks](#) command and the `-storage-pool` parameter.

 All storage pool available capacity can be provisioned into aggregates. Available capacity within a storage pool is not used to protect against a disk failure. In the case of an SSD failure or predicted failure, Data ONTAP moves a suitable whole SSD spare disk from outside the storage pool into the storage pool and begins the recovery process (using either reconstruction or Rapid RAID Recovery, whichever is appropriate).

## Parameters

`{ [-fields <fieldname>, ...]`

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

`| [-instance ] }`

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**`[-storage-pool <storage pool name>]` - Name of Storage Pool**

Selects the available capacities that match this parameter value.

**`[-node {<nodename>|local}]` - Node**

Selects the available capacities that match this parameter value.

**`[-allocation-unit-size {<integer>[KB|MB|GB|TB|PB]}]` - Allocation Unit Size**

Selects the available capacities that match this parameter value.

Allocation units are the units of storage capacity that are available to be provisioned into aggregates.

**`[-storage-type <SSD>]` - Type of Storage Pool**

Selects the available capacities that match this parameter value. Only the `SSD` type is supported for this version of Data ONTAP.

**`[-allocation-unit-count <integer>]` - Number of Allocation Units Available**

Selects the available capacities that match this parameter value.

Allocation units are the units of storage capacity that are available to be provisioned into aggregates. Each allocation unit is one minimum unit of allocation (MUA) and its capacity is given as `allocation-unit-size`.

**`[-syncmirror-pool <text>]` - SyncMirror Pool**

Selects the available capacities that match this parameter value.

The SyncMirror pool of an allocation unit must match the SyncMirror pool of the disks of the aggregate when adding allocation units into an aggregate.

Mirroring of aggregates that are provisioned from SSD storage pools is not supported.

#### **[-available-size {<integer>[KB|MB|GB|TB|PB]}] - Total Usable Available Size**

Selects the available capacities that match this parameter value.

The available-size is the sum of the capacities of the allocation units that are assigned but not yet provisioned. The amount of available-size that is contributed to the cache capacity of an aggregate depends upon the RAID type used when provisioning the allocation units.

## Examples

In this example, two nodes of an HA pair share available capacity from two storage pools, *SP1* and *SP2*. There are a total of 5 allocation units that have not yet been provisioned.

```
cluster1::> storage pool show-available-capacity
          Storage SyncMirror Allocation Unit  Total
Node      Storage Pool    Type     Pool      Unit size  Count  Usable Size
-----  -----
node-a    SP1           SSD      Pool0    558.7GB   1      558.7GB
node-b    SP1           SSD      Pool0    558.7GB   1      558.7GB
node-a    SP2           SSD      Pool0    744.9GB   2      1.45TB
node-b    SP2           SSD      Pool0    744.9GB   1      744.9GB
```

## Related Links

- [storage aggregate add-disks](#)

## storage pool show-disks

Display disks in storage pools

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The *storage pool show-disks* command displays information about disks in storage pools in the cluster. The command output depends on the parameter or parameters specified with the command. If no parameters are specified, the command displays information about all disks in all storage pools in the cluster.

## Parameters

```
{ [-fields <fieldname>,...]
```

If you specify the *-fields <fieldname>,...* parameter, the command output also includes the specified field or fields. You can use *'-fields ?'* to display the fields to specify.

**[ [-instance ] ]**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-storage-pool <storage pool name>] - Name of Storage Pool**

Selects the storage pools that match this parameter value.

**[-disk <disk path name>] - Name of the disk**

Selects the storage pools with the disks that match this parameter value.

**[-disk-type {ATA | BSAS | FCAL | FSAS | LUN | MSATA | SAS | SSD | VMDISK | SSD-NVM | SSD-CAP | SSD-ZNS | VMLUN | VMLUN-SSD}] - Disk Type**

Selects the storage pools with the disks that match this parameter value. Only the `SSD` type is supported for this version of Data ONTAP.

**[-usable-size {<integer>[KB|MB|GB|TB|PB]}] - Disk Usable Size**

Selects the storage pools with the disks that match this parameter value.

In this command, `usable-size` refers to the sum of the capacities of all of the partitions on the disk.

**[-total-size {<integer>[KB|MB|GB|TB|PB]}] - Total Size**

Selects the storage pools with the disks that match this parameter value.

**[-node-list <nodename>,...] - List of Nodes**

Selects the storage pools with the disks that are visible to all of the specified nodes.

## Examples

Show information about SSDs in a storage pool called `SP2`.

```
cluster1::> storage pool show-disks -storage-pool SP2

Storage Pool Name: SP2
Storage
  Disk      Type      Usable Size  Total Size
  -----  -----  -----
  1.0.16    SSD      745.0GB    745.2GB
  1.0.18    SSD      745.0GB    745.2GB
  1.0.20    SSD      745.0GB    745.2GB
  1.0.22    SSD      745.0GB    745.2GB
```

## storage pool show

Display details of storage pools

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage pool show` command displays information about SSD storage pools in the cluster. By default, the command displays information about all storage pools in the cluster. You can specify parameters to limit the output to a specific set of storage pools.

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `-fields ?` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-storage-pool <storage pool name>] - Storage Pool Name**

Selects the storage pools that match this parameter value.

**[-storage-pool-uuid <UUID>] - UUID of Storage Pool**

Selects the storage pools that match this parameter value.

**[-nodes {<nodename>|local}] - Nodes Sharing the Storage Pool**

Selects the storage pools that match this parameter value.

In an HA pair, either node name may be specified.

**[-disk-count <integer>] - Number of Disks in Storage Pool**

Selects the storage pools that match this parameter value.

**[-allocation-unit-size {<integer>[KB|MB|GB|TB|PB]}] - Allocation Unit Size**

Selects the storage pools that match this parameter value.

Allocation units represent the unit of storage allocated to aggregates from this storage pool.

**[-allocation-unit-data-size-raid4 {<integer>[KB|MB|GB|TB|PB]}] - Allocation Unit Data Size for RAID4 and RAID-EP**

This parameter shows the amount of additional data capacity provided if an allocation unit from this storage pool was added to an aggregate with `-raidtype` as `raid4` or `raid_ep`.

**[-allocation-unit-data-size-raid-dp {<integer>[KB|MB|GB|TB|PB]}] - Allocation Unit Data Size for RAID-DP**

This parameter shows the amount of additional data capacity provided if an allocation unit from this storage pool was added to an aggregate with `-raidtype` as `raid_dp`.

**[-allocation-unit-data-size-raid-tec {<integer>[KB|MB|GB|TB|PB]}] - Allocation Unit Data Size for RAID-TEC**

This parameter shows the amount of additional data capacity provided if an allocation unit from this storage pool was added to an aggregate with `-raidtype` as `raid_tec`.

**[-storage-type <SSD>] - Storage Type**

Selects the storage pools that match this parameter value.

Only the SSD type is supported for this version of Data ONTAP.

**[-pool-usable-size {<integer>[KB|MB|GB|TB|PB]}] - Storage Pool Usable Size**

Selects the storage pools that match this parameter value.

The pool-usable-size is the sum of the capacities of the allocation units that are assigned to nodes but not yet provisioned. The amount of pool-usable-size that is contributed to the cache capacity of an aggregate depends upon the RAID type used when provisioning the allocation units.

**[-pool-total-size {<integer>[KB|MB|GB|TB|PB]}] - Storage Pool Total Size**

Selects the storage pools that match this parameter value.

The pool-total-size is the sum of the capacities of allocation units belonging to this storage pool.

**[-is-healthy {true|false}] - Is Pool Healthy?**

Selects the storage pools that match this parameter value.

For storage pools with is-healthy *false*, the unhealthy-reason parameter provides more information.

is-healthy must be *true* to provision allocation units from a storage pool into an aggregate.

**[-pool-state <State of the Storage Pool>] - State of the Storage Pool**

Selects the storage pools that match this parameter value. Possible states are:

- normal - the storage pool is operating normally.
- degraded - the storage pool has one or more failed disks.
- creating - the storage pool is being created.
- deleting - the storage pool is being deleted.
- reassigning - allocation units are being reassigned from one node to another.
- growing - allocation units in the storage pool are expanding due to the addition of new capacity into the storage pool.

**[-unhealthy-reason <text>] - Reason for Storage Pool Being Unhealthy**

Selects the storage pools that match this parameter value.

The message provided gives additional details about why the storage pool is unhealthy.

**[-current-operation-job-id <integer>] - Job ID of the Currently Running Operation**

Selects the storage pools that match this parameter value.

Long-running operations associated with storage pools will be managed via jobs. For example, if you provision allocation units from a storage pool into an aggregate and the disks associated with the storage pool need to be zeroed, the operation will be completed via a job.

## Examples

Display the storage pools in the cluster.

```
cluster1::> storage pool show
Storage Pool          Type  #Disks Nodes          Total Size
-----
LargeSP              SSD    10  noda-a, node-b    7.27TB
SmallSP              SSD    2   noda-a, node-b    1.45TB
2 entries were displayed.
```

The following example displays the details of a storage pool named SmallSP. Only one of its four allocation unit has been provisioned, so 75% of its size is available (usable).

```
cluster1::> storage pool show -storage-pool SmallSP
Storage Pool Name: SmallSP
                      UUID of Storage Pool: 60f2f1b9-e60f-11e3-a5e7-
00a0981899a2
                      Nodes Sharing the Storage Pool: node-a, node-b
                      Number of Disks in Storage Pool: 2
                      Allocation Unit Size: 372.5GB
                      Storage Type: SSD
                      Storage Pool Usable Size: 1.09TB
                      Storage Pool Total Size: 1.45TB
                      Is Pool Healthy?: true
                      State of the Storage Pool: normal
Reason for storage pool being unhealthy: -
Job ID of the Currently Running Operation: -
```

## storage port commands

### storage port disable

Disable a storage port

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The `storage port disable` command disables a specified storage port.

#### Parameters

**-node {<nodename>|local} -Node**

Use this parameter to specify the node on which the port resides.

#### **-port <text> - Port**

Use this parameter to specify the port that needs to be disabled.

#### **[-force <true>] - Force (privilege: advanced)**

Use this optional parameter to force the disabling of the storage port. The parameter can be used to disable the specified port even if some devices can only be accessed using this port. Note that doing so might cause multiple device failures.

### **Examples**

The following example disables port 0a on node node1:

```
cluster1::> storage port disable -node node1 -port 0a
```

## **storage port enable**

Enable a storage port

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The *storage port enable* command enables a specified storage port.

### **Parameters**

#### **-node {<nodename>|local} - Node**

Use this parameter to specify the node on which the port resides.

#### **-port <text> - Port**

Use this parameter to specify the port that needs to be enabled.

### **Examples**

The following example enables port 0a on node node1:

```
cluster1::> storage port enable -node node1 -port 0a
```

## **storage port modify**

Modify a storage port

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The *storage port modify* command modifies the attributes of a storage port.

## Parameters

### **-node {<nodename>|local} - Node**

This parameter specifies the name of the node.

### **-port <text> - Port**

This parameter specifies the name of the port.

### **[-mode {storage|network}] - Mode**

This parameter specifies the usage mode for an Ethernet port - storage or network use. The mode parameter only applies to Ethernet ports that are not dedicated to storage connectivity.

### **[-force <true>] - Force (privilege: advanced)**

This parameter allows the operation to override warnings.

## Examples

The following example places a nondedicated Ethernet port in storage mode:

```
cluster1::> storage port show
Speed                               VLAN
Node      Port  Type   Mode    (Gb/s)  State   Status      ID
-----  -----  -----  -----  -----  -----  -----
cluster1-01
        e0b  ENET  network      --      -      -
        e0c  ENET  -           100  enabled  online   30
        e0e  ENET  storage      0  enabled  offline  30
        e0f  ENET  -           100  enabled  online   30
cluster1-02
        e0b  ENET  storage      0  enabled  offline  30
        e0c  ENET  -           100  enabled  online   30
        e0e  ENET  storage      0  enabled  offline  30
        e0f  ENET  -           100  enabled  online   30
8 entries were displayed.
```

```
cluster1::> storage port modify -node cluster1-01 -port e0b -mode storage
```

```
cluster1::> storage port show
Speed                               VLAN
Node      Port  Type   Mode    (Gb/s)  State   Status      ID
-----  -----  -----  -----  -----  -----  -----
cluster1-01
        e0b  ENET  storage      0  enabled  offline  30
        e0c  ENET  -           100  enabled  online   30
        e0e  ENET  storage      0  enabled  offline  30
        e0f  ENET  -           100  enabled  online   30
cluster1-02
        e0b  ENET  storage      0  enabled  offline  30
        e0c  ENET  -           100  enabled  online   30
        e0e  ENET  storage      0  enabled  offline  30
        e0f  ENET  -           100  enabled  online   30
8 entries were displayed.
```

## storage port rescan

Rescan a storage port

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage port rescan` command rescans a specified storage port. This command is not supported on Ethernet storage ports (type = ENET).

## Parameters

### **-node {<nodename>|local} - Node (privilege: advanced)**

Use this parameter to specify the node on which the port resides.

### **-port <text> - Port (privilege: advanced)**

Use this parameter to specify the port that needs to be rescanned.

## Examples

The following example rescans port 0a on node node1:

```
cluster1::> storage port rescan -node node1 -port 0a
```

## storage port reset-device

Reset a device behind a storage port

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `storage port reset-device` command resets a device behind a port. If the device is behind a SAS port, you need to specify the shelf name and bay ID where the device resides. If the device is behind a FC port, you need to specify the loop ID of the device. This command is not supported on Ethernet storage ports (type = ENET).

## Parameters

### **-node {<nodename>|local} - Node (privilege: advanced)**

Use this parameter to specify the node on which the port resides.

### **-port <text> - Port (privilege: advanced)**

Use this parameter to specify the port used to reset the device.

### **{ -shelf-name <text> - Shelf Name (privilege: advanced)}**

Use this parameter to specify the shelf where the device resides.

### **-bay-id <integer> - Bay ID (privilege: advanced)**

Use this parameter to specify the bay where the device resides.

### **| -loop-id <integer> - Loop ID (privilege: advanced) }**

Use this parameter to specify the loop ID of the device.

## Examples

The following example resets a device behind SAS port 0a on node node1:

```
cluster1::> storage port reset-device -node node1 -port 0a -shelf-name 1.0  
-bay-id 10
```

The following example resets a device behind FC port 1b on node node1:

```
cluster1::> storage port reset-device -node node1 -port 1b -loop-id 20
```

## storage port reset

Reset a storage port

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage port reset` command resets a specified storage port. This command is not supported on Ethernet storage ports (type = ENET).

### Parameters

**-node {<nodename>|local} - Node (privilege: advanced)**

Use this parameter to specify the node on which the port resides.

**-port <text> - Port (privilege: advanced)**

Use this parameter to specify the port that needs to be reset.

## Examples

The following example resets port 0a on node node1:

```
cluster1::> storage port reset -node node1 -port 0a
```

## storage port show

Show storage port information

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage port show` command displays information about the storage ports in the cluster. If no parameters are specified, the default command displays the following information about the storage ports:

- Node
- Port
- Type
- Speed
- State
- Status

To display detailed profile information about a single storage port, use the **-node** and **-port** parameters.

## Parameters

**{ [-fields <fieldname>,...]**

Displays the specified fields for all the storage ports, in column style output.

**| [-errors ]**

Displays the following error status information about the storage ports which have errors:

- Error type
- Error severity
- Error description

**| [-instance ] }**

Displays expanded information about all the storage ports in the system. If a storage port is specified, then this parameter displays detailed information for that port only.

**[-node {<nodename>|local}] - Node**

Displays detailed information about the storage ports on the specified node.

**[-port <text>] - Port**

Selects the ports with the specified port name.

**[-port-type {Unknown|SAS|FC|ENET}] - Port Type**

Selects the ports of the specified type.

**[-port-speed {0|1|1.5|2|2.5|3|4|5|6|8|10|12|14|16|25|32|40|100}] - Port Speed**

Selects the ports with the specified speed.

**[-state {enabled|disabled|enable-pending|disable-pending}] - Port State**

Selects the ports with the specified state.

**[-status {unknown|online|online-degraded|offline|link-down}] - Port Status**

Selects the ports with the specified operational status.

**[-description <text>] - Description**

Selects the ports with the specified description.

**[-firmware-rev <text>] - Firmware Revision**

Selects the ports with the specified firmware revision.

**[-serial-number <text>] - Serial Number**

Selects the ports with the specified serial number.

**[-is-dedicated {true|false}] - Is Dedicated Storage Port?**

Selects the ports that match the specified value for storage-only ports. This value is always true for FC and SAS ports, as well as for ENET ports that are dedicated to storage.

**[-connection-mode {Unknown|Loop|Point-to-point}] - Connection Mode**

Selects the ports with the specified connection mode.

**[-wwnn <FC WNN>] - World Wide Node Name**

Selects the ports with the specified World Wide Node Name.

**[-wwpn <FC WNN>] - World Wide Port Name**

Selects the ports with the specified World Wide Port Name.

**[-board-name <text>] - Board Name**

Selects the ports with the specified board name.

**[-connector-capabilities <integer>,...] - Connector Capabilities**

Selects the ports with the specified list of connector capabilities.

**[-wwn <FC WNN>] - Base World Wide Name**

Selects the ports with the specified World Wide Name.

**[-mfg-part-number <text>] - MFG Part Number**

Selects the ports with the specified manufacturer part number.

**[-nvdata-rev <text>] - NVDATA Revision**

Selects the ports with the specified NVDATA revision.

**[-part-number <text>] - Part Number**

Selects the ports with the specified part number.

**[-date-code <text>] - Date Code**

Selects the ports with the specified date code.

**[-connector-technology {active-copper|passive-copper|optical}] - Connector Technology**

Selects the ports with the specified connector technology.

**[-phy-id <integer>,...] - Phy ID**

Selects the ports that have phys with the specified phy ID.

**[-phy-state {enabled|disabled}] - Phy State**

Selects the ports that have phys with the specified state.

**[-phy-status {unknown|online|offline|speed-negotiation-failed|sata-oob-failed}] - Phy Status**  
Selects the ports that have phys with the specified status.

**[-phy-speed {0|1|1.5|2|2.5|3|4|5|6|8|10|12|14|16|25|32|40|100}] - Phy Speed**  
Selects the ports that have phys with the specified speed.

**[-mac-address <text>] - MAC Address**  
Selects ports that match the specified MAC address.

**[-vlan-id <integer>] - VLAN ID**  
Selects the ports with the specified VLAN ID.

**[-vendor-id <text>] - Vendor ID**  
Selects the ports with the specified vendor ID.

**[-vendor-part-id <text>] - Vendor part ID**  
Selects the ports with the specified vendor part ID.

**[-device-type <text>] - Device type**  
Selects ports that match the specified device type.

**[-error-type {unknown|online|online-degraded|offline|link-down}] - Error Type**  
Selects the ports with the specified error type.

**[-error-severity {unknown|notice|warning|error|critical}] - Error Severity**  
Selects the ports with the specified error severity.

**[-error-text <text>] - Error Text**  
Selects the ports with the specified error text.

**[-corrective-action <text>] - Corrective Action**  
Selects the ports with the specified corrective action.

**[-cable-length <text>] - Cable Length**  
Selects the ports with the specified cable length.

**[-cable-identifier <text>] - Cable Identifier**  
Selects the ports with the specified cable identifier.

**[-cable-end-id {end\_0|end\_1}] - Cable End Identifier**  
Selects the ports with the specified cable end identifier.

**[-connector-type {QSFP|QSFP+|QSFP28|Mini-SAS HD|SFP}] - Connector Type**  
Selects the ports with the specified connector type.

**[-connector-vendor <text>] - Connector Vendor**  
Selects the ports with the specified connector vendor.

**[-connector-part-number <text>] - Connector Part Number**

Selects the ports with the specified connector part number.

**[-connector-serial-number <text>] - Connector Serial Number**

Selects the ports with the specified connector serial number.

**[-mode {storage|network}] - Mode**

Selects the ports with the specified mode.

**[-is-redundant {true|false}] - Is Redundant?**

Selects the ports that are redundant (true) or not redundant (false). A port is redundant if all attached devices have a second path through another port.

**[-in-use {true|false}] - In Use?**

Selects the ports that are in use (true) or not in use (false). A port is in use if any devices are connected using this port.

## Examples

The following example displays information about all storage ports in the cluster:

```
cluster1::> storage port show
Speed          VLAN
Node          Port Type Mode   (Gb/s) State   Status   ID
-----  -----  -----  -----  -----  -----  -----  -----
cluster1-01
        4a  SAS   -      0  enabled  offline  -
        4b  SAS   -      0  enabled  offline  -
        4c  SAS   -      0  enabled  offline  -
        4d  SAS   -      0  enabled  offline  -
        e3a ENET  network  --  -      -      -
        e3b ENET  storage  100 enabled  online  30
        e5a ENET  storage  100 enabled  online  30
        e5b ENET  network  --  -      -      -
cluster1-02
        4a  SAS   -      0  enabled  offline  -
        4b  SAS   -      0  enabled  offline  -
        4c  SAS   -      0  enabled  offline  -
        4d  SAS   -      0  enabled  offline  -
        e3a ENET  network  --  -      -      -
        e3b ENET  storage  100 enabled  online  30
        e5a ENET  storage  100 enabled  online  30
        e5b ENET  network  --  -      -      -
16 entries were displayed.
```

The following example displays detailed information about port e5a on node node1:

```
cluster1::> storage port show -node cluster1-01 -port e5a
Node: cluster1-01
          Port: e5a
          Port Type: ENET
          Mode: storage
          Description: 40G/100G Ethernet Controller CX5
Firmware Revision: 16.23.1020
          MAC Address: ec:0d:9a:65:e4:44
          Is Dedicated: false
          Serial Number: MT1730X00227
          Connector Vendor: Molex Inc.
          Connector Part Number: 112-00322
          Connector Serial Number: 532120266
          Port Speed: 100 Gb/s
          Port State: enabled
          Port Status: online
```

## storage raid-options commands

### storage raid-options modify

Modify a RAID option

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The `storage raid-options modify` command is used to modify the available RAID options for each node in a cluster. The options are described in the `storage raid-options` manual page.

#### Parameters

##### **-node {<nodename>|local} - Node**

This parameter specifies the node on which the RAID option is to be modified.

##### **-name <text> - Option Name**

This parameter specifies the RAID option to be modified. To see the list of RAID options that can be modified, use the [storage raid-options show](#) command.

##### **[-value <text>] - Option Value**

This parameter specifies the value of the selected RAID option.

#### Related Links

- [storage raid-options show](#)

## storage raid-options show

Display RAID options

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage raid-options show` command displays information about all the RAID options in a cluster. The options are described in the `storage raid-options` manual page.

### Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects information about all the RAID options on the specified node.

**[-name <text>] - Option Name**

Selects information about the RAID options that have the specified name.

**[-value <text>] - Option Value**

Selects information about all the RAID options that have the specified value.

**[-recommended-value <text>] - Recommended Value**

Selects information about all the RAID options that have the specified recommended value.

**[-constraint <text>] - Option Constraint**

Selects information about all the RAID options that have the specified constraint. The 'constraint' field indicates the expected setting for a RAID option across both nodes of an HA pair. The possible values are:

- *none* - no constraint on the value of this RAID option; nodes can have different values
- *same\_preferred* - the same value should be used on both nodes of an HA pair, otherwise the next takeover may not function correctly
- *same\_required* - the same value must be used on both nodes of an HA pair, otherwise the next takeover will not function correctly
- *only\_one* - the same value should be used on both nodes of an HA pair. If the values are different and a takeover is in progress, the value of the RAID option on the node that is taking over will be used
- *unknown* - no information about constraints for this RAID option

### Examples

The following example shows the RAID scrub settings for a node named `node1`:

```
cluster1::> storage raid-options show -node node1 -name raid.scrub*
                                         Current      Recommended
Node      Option                         Value       Value
Constraint
-----
-----
node1    raid.scrub.perf_impact          low        low
only_one
node1    raid.scrub.enable               on         off
none
2 entries were displayed.
```

## storage shelf commands

### storage shelf show

Display a list of storage shelves

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

The *storage shelf show* command displays information about all the storage shelves in the storage system. If no parameters are specified, the default command displays the following information about the storage shelves:

- Shelf Name
- Shelf ID
- Serial Number
- Model
- Module Type
- Status

To display detailed profile information about a single storage shelf, use the *-shelf* parameter.

#### Parameters

{ [-fields <fieldname>, ...]

Displays the specified fields for all the storage shelves, in column style output.

| [-bay ]

Displays the following details about the disk bays in the storage shelf:

- The unique positional identifier of the disk bay
- Whether a disk drive is installed in the bay

- Bay type
- Operational status of the disk bay

#### | [-connectivity ]

Displays the following details about the connectivity from the node to the storage shelf:

- Node name
- Initiator side switch port
- Target side switch port
- World-wide port name
- Target Port Group Number (TPGN)

#### | [-cooling ]

Displays the following details about the cooling elements and temperature sensors of the storage shelf:

- Element ID of the cooling fan
- The current speed of the cooling fan in revolutions per minute (rpm)
- Operational status of the cooling fan
- Sensor ID of the temperature sensor element
- Temperature at the sensor in degrees Celsius
- Whether the current temperature at the sensor is the ambient temperature
- Low critical threshold value for the temperature sensor
- Low warning threshold value for the temperature sensor
- High critical threshold value for the temperature sensor
- High warning threshold value for the temperature sensor
- Operational status for the temperature sensor

#### | [-errors ]

Displays the following error status information about the storage shelves that have errors:

- Error type
- Error description

#### | [-module ]

Displays the following details about the I/O modules attached to the storage shelf:

- Module ID
- Module part number
- Serial number of the Enclosure Services Controller Electronics element
- Whether monitoring is enabled on this module
- Whether this module is the SAS expander master module
- Whether this module is the element reporting
- Version of the firmware installed on the module

- Latest firmware revision
- Number of times, since the last boot, that this module has been swapped
- Operational status of the module

#### | [-port ]

Displays the following details about the storage shelf ports:

- Expander phy element identifier
- SAS shelf port type
- World-wide Port Name of the SAS port
- Operational physical link rate of the SAS port in Gb/s
- Negotiated physical link rate of the SAS port in Gb/s
- Power status of the SAS port
- Status of the SAS port
- Fibre Channel shelf port ID
- Fibre Channel shelf port type
- Fibre Channel shelf port status

#### | [-power ]

Displays the following details about the power supplies, voltage sensors, and current sensors of the storage shelf:

- Power Supply Unit (PSU) number
- PSU type
- PSU part number
- PSU serial number
- PSU power rating in watts
- PSU crest factor
- Power drawn from the PSU in watts
- Whether the PSU can be reset via software control
- Whether the auto power reset of the PSU is enabled
- PSU firmware revision
- Operational status of the PSU
- Voltage sensor number
- Voltage detected by the voltage sensor, in volts (V)
- Operational status of the voltage sensor
- Current sensor number
- Current detected by the current sensor, in millamps (mA)
- Operational status of the current sensor

**[ -instance ]**

Displays expanded information about all the storage shelves in the system.

**[ -shelf <text> ] - Shelf Name**

Displays information only about the storage shelves that match the names you specify.

**[ -node {<nodename>|local} ] - Node**

Displays information only about the storage shelves that are attached to the node you specify.

**[ -shelf-uid <text> ] - Shelf UID**

Displays information only about the storage shelf that matches the shelf UID you specify. Example:  
'50:05:0c:c0:02:10:64:26'

**[ -stack-id {<integer>|-} ] - Stack ID**

Displays information only about the storage shelves that are attached to the stack that matches the stack ID you specify

**[ -shelf-id <text> ] - Shelf ID**

Displays information only about the storage shelves that match the shelf ID you specify.

**[ -module-type**

**{unknown|atfcx|esh4|iom3|iom6|iom6e|iom12|iom12e|iom12f|nsm100|nsm8e|psm3e|iom12b|iom12g} ] - Shelf Module Type**

Displays information only about the storage shelves that match the module-type you specify.

**[ -connection-type {unknown|fc|sas|nvme} ] - Shelf Connection Type**

Displays information only about the storage shelves that match the connection type you specify. Example: FC or SAS.

**[ -is-local-attach {true|false} ] - Is the Shelf Local to This Cluster?**

Displays information only about the storage shelves that are local (TRUE) or remote (FALSE) to this cluster.

**[ -vendor <text> ] - Shelf Vendor**

Displays information only about the storage shelves that match the vendor you specify.

**[ -product-id <text> ] - Shelf Product Identification**

Displays information only about the storage shelves that match the product ID you specify.

**[ -serial-number <text> ] - Shelf Serial Number**

Displays information only about the storage shelf that matches the serial number you specify.

**[ -disk-count {<integer>|-} ] - Disk Count**

Displays information only about the storage shelves that have the disk count you specify.

**[ -state {unknown|no-status|init-required|online|offline|missing} ] - Shelf State**

Displays information only about the storage shelves that are in the state you specify.

**[ -op-status {unknown|normal|warning|error|critical|standby-power} ] - Shelf Operational Status**

Displays information only about the storage shelves that are currently operating under the status condition

you specify.

**[-bay-id {<integer>|-}] - Bay ID**

Displays information only about the storage shelves that have bays that match the bay ID you specify.

**[-bay-type {unknown|single-disk|multi-lun}] - Bay Type**

Displays information only about the storage shelves that have bays that match the type of bay you specify.

**[-bay-has-disk {true|false}] - Bay Has Disk**

Displays information only about the storage shelves that have bays with disk drives inserted in them (true) or empty bays (false).

**[-bay-op-status {unknown|normal|error}] - Bay Operational Status**

Displays information only about the storage shelves that have bays that match the operational state you specify.

**[-controller {<nodename>|local}] - Controller Name**

Displays information only about the storage shelves that are connected to the node you specify.

**[-controller-uuid <text>,...] - Controller UUID**

Displays information only about the storage shelves that are connected to the node UUID you specify.

**[-initiator <text>,...] - Initiator**

Displays information only about the storage shelves that are visible to the initiator you specify.

**[-initiator-wwpn <text>,...] - Initiator WWPN**

Displays information only about the storage shelves that are visible to the initiator WWPN you specify.

**[-initiator-side-switch-port <text>,...] - Initiator Side Switch Port**

Displays information only about the storage shelves that are visible to an initiator connected to the switch port you specify.

**[-target-side-switch-port <text>,...] - Target Side Switch Port**

Displays information only about the storage shelves visible on target ports identified by the switch port to which they are connected.

**[-target-port <text>,...] - Target Port**

Displays information only about the storage shelves visible on the specified target ports identified by their World-Wide Port Name (WWPN).

**[-tpgn {<integer>|-}] - Target Port Group Number**

Displays information only about the storage shelves that belong to the Target Port Group Name (TPGN) you specify.

**[-port-speed {<integer>|-}] - Port Speed**

Displays information only about the storage shelves with ports that match the port speed you specify.

**[-io-kbps {<integer>|-}] - Kbytes/sec on Storage Shelf**

Displays information only about the storage shelves visible to an initiator that has executed I/O at the throughput you specify.

**[-iops {<integer>}|-] - Number IOPS per Second on Storage Shelf**

Displays information only about the storage shelves visible to an initiator that has executed the number of IOPs you specify.

**[-current-sensor-id {<integer>}|-] - Current Sensor ID**

Displays information only about the storage shelves with current sensor that matches the current sensor ID you specify.

**[-current-sensor-location <text>, ...] - Current Sensor Location**

Displays information only about the storage shelves with current sensors installed at the location you specify.

**[-current-sensor-reading {<integer>}|-] - Current Sensor Reading**

Displays information only about the storage shelves with current sensors that match the current reading you specify.

**[-current-op-status {unknown|normal|over-current-critical|under-current-critical|not-supported|not-installed}] - Operational Status**

Displays information only about the storage shelves with current sensors that match the operational status you specify.

**[-fan-id {<integer>}|-] - Fan ID**

Displays information only about the storage shelves with cooling fans that match the fan IDs you specify.

**[-fan-location <text>, ...] - Fan Location**

Displays information only about the storage shelves with cooling fans installed.

**[-fan-rpm {<integer>}|-] - Fan Rotation Per Minute**

Displays information only about the storage shelves with cooling fans that match the rpm rate you specify.

**[-fan-op-status {unknown|normal|off|error|not-supported|not-installed}] - Fan Operational Status**

Displays information only about the storage shelves with cooling fans that match the operational status you specify.

**[-module-id <text>, ...] - Module ID**

Displays information only about the storage shelves with an I/O module that matches the module ID you specify.

**[-module-location <text>, ...] - Module Location**

Displays information only about the storage shelves with I/O modules in the specified shelf module slots.

**[-module-part-number <text>, ...] - Module Part Number**

Displays information only about the storage shelves with I/O modules that match the module part numbers you specify.

**[-is-sas-master-module {true|false}] - Is SAS Expander Master Module?**

Displays information only about the storage shelves with a SAS master I/O module (true) or an I/O module that is not a SAS master (false). This parameter applies only to SAS shelves.

**[-is-monitor-active {true|false}] - Is Monitor Active?**

Displays information only about the storage shelves whose monitoring is enabled (true) or disabled (false).

**[-enclosure-type <text>, ...] - Module Enclosure Type**

Displays information only about the storage shelves that match the enclosure types you specify.

**[-es-serial-number <text>, ...] - ES Electronics Element Serial Number**

Displays information only about the storage shelves with I/O modules that match the electronics serial numbers you specify.

**[-module-fru-id <text>, ...] - Field Replaceable Unit ID**

Displays information only about the storage shelves with I/O modules that match the field replaceable unit (FRU) IDs you specify.

**[-module-is-reporting-element {true|false}] - Is Reporting Element?**

Displays information only about the storage shelves with element reporting I/O modules (true) or not (false).

**[-module-fw-revision <text>, ...] - Firmware Revision**

Displays information only about the storage shelves with I/O modules that match the firmware revision you specify.

**[-module-latest-fw-revision <text>, ...] - Latest Firmware Revision**

Displays information only about the storage shelves with I/O modules that match the latest firmware revision you specify.

**[-module-fw-progress {not-available|ready|in-progress|failed}] - Module Firmware Progress**

Displays information only about the storage shelves with I/O modules that match the specified firmware update progress.

**[-module-swap-count {<integer>|-}] - Module Swap Count**

Displays information only about the storage shelves whose I/O modules have been swapped the specified number of times.

**[-module-op-status {unknown|normal|warning|error|not-installed}] - Module Operational Status**

Displays information only about the storage shelves with I/O modules that match the operational status you specify.

**[-sas-port-id <text>, ...] - Port ID**

Displays information only about the storage shelves with SAS Ports that match the port IDs you specify.

**[-sas-port-type**

**{unknown|circle|square|sil|disk|in|out|unused|host|dcm|aux1|aux2|hi\_ho|a\_to\_b|b\_to\_a}] - Port Type**

Displays information only about the storage shelves with SAS Ports that match the SAS port type you specify.

**[-sas-port-wwpn <text>, ...] - Port World Wide Port Name**

Displays information only about the storage shelves with SAS Ports that match the World-Wide Port Names

you specify.

#### **[-sas-port-speed <text>, ...] - Port Speed**

Displays information only about the storage shelves with SAS Ports that match the port speed you specify.

#### **[-sas-negotiated-port-speed <text>, ...] - Negotiated Port Speed**

Displays information only about the storage shelves with SAS Ports that match the negotiated port speed you specify.

#### **[-sas-port-power-status <text>, ...] - Port Power Status**

Displays information only about the storage shelves with SAS Ports that match the power status you specify.

**[-sas-port-op-status {error|normal|off|unknown|byp-bad-term|bad-zone-recovery|byp\_clk\_thr|byp\_comma\_los|byp\_crc\_brst\_thr|byp\_data\_timeout|byp\_drv\_fault|byp\_drv\_pcycle|byp\_drv\_pwr|byp\_drv\_self|byp\_gen|byp\_init|byp\_lip\_brst\_thr|byp\_lip\_f8|byp\_lip\_rate\_thr|byp\_lipf7|byp\_ltbi|byp\_man|byp\_no\_drive|byp\_osc|byp\_other\_thr|byp\_rec\_los|byp\_rport|byp\_stall\_thr|byp\_wrd\_brst\_thr|byp\_wrd\_rate\_thr|byp\_xmit\_fault|diag\_transmit|inserted|loopback|status\_unknown|warn\_high\_clk\_delta|warn\_high\_crc\_rate|warn\_high\_lip|warn\_high\_wrd\_rate|term|phy\_dis\_clk\_fault|phy\_dis\_crc\_err|phy\_dis\_crc\_err\_burst|phy\_dis\_disparity|phy\_dis\_disparity\_burst|phy\_dis\_emulate\_reserve|phy\_dis\_inval\_dword|phy\_dis\_inval\_dword\_burst|phy\_dis\_loss\_dword|phy\_dis\_loss\_dword\_burst|phy\_dis\_man\_smp|phy\_dis\_manual|phy\_dis\_mirrored|empty|phy\_dis\_phy\_change|phy\_dis\_phy\_change\_burst|phy\_dis\_phy\_reset|phy\_dis\_phy\_reset\_burst|phy\_dis\_phy\_unused|phy\_ena|phy\_ena\_not\_attach|phy\_ena\_unknown|phy\_unknown|phy\_dis\_illegal}] - Port Operational Status**

Displays information only about the storage shelves with SAS Ports that match the operational status you specify.

#### **[-sas-port-module-id {A|B}] - Port Module ID**

Displays information only about the storage shelves with SAS Ports that match the module ID you specify.

#### **[-fc-port-id <text>, ...] - Fibre Channel Port ID**

Displays information only about the storage shelves with FC Ports that match the port IDs you specify.

**[-fc-port-mode {unknown|circle|square|sil|disk|in|out|unused|host|dcm|aux1|aux2|hi\_ho|a\_to\_b|b\_to\_a}] - Fibre Channel Port Mode**

Displays information only about the storage shelves with FC Ports that match the port modes you specify.

**[-fc-port-op-status {error|normal|off|unknown|byp-bad-term|bad-zone-recovery|byp\_clk\_thr|byp\_comma\_los|byp\_crc\_brst\_thr|byp\_data\_timeout|byp\_drv\_fault|byp\_drv\_pcycle|byp\_drv\_pwr|byp\_drv\_self|byp\_gen|byp\_init|byp\_lip\_brst\_thr|byp\_lip\_f8|byp\_lip\_rate\_thr|byp\_lipf7|byp\_ltbi|byp\_man|byp\_no\_drive|byp\_osc|byp\_other\_thr|byp\_rec\_los|byp\_rport|byp\_stall\_thr|byp\_wrd\_brst\_thr|byp\_wrd\_rate\_thr|byp\_xmit\_fault|diag\_transmit|inserted|loopback|status\_unknown|warn\_high\_clk\_delta|warn\_high\_crc\_rate|warn\_high\_lip|warn\_high\_wrd\_rate|term|phy\_dis\_clk\_fault|phy\_dis\_crc\_err|phy\_dis\_crc\_err\_burst|phy\_dis\_disparity|phy\_dis\_disparity\_burst|phy\_dis\_emulate\_reserve|phy\_dis\_inval\_dword|phy\_dis\_inval\_dword\_burst|phy\_dis\_loss\_dword|phy\_dis\_loss\_dword\_burst|phy\_dis\_man\_smp|phy\_dis\_manual|phy\_dis\_mirrored|empty|phy\_dis\_phy\_change|phy\_dis\_phy\_change\_burst|phy\_dis\_phy\_reset|phy\_dis\_phy\_reset\_burst|phy\_dis\_phy\_unused|phy\_ena|phy\_ena\_not\_attach|phy\_ena\_unknown|phy\_unknown|phy\_dis\_illegal}] - Fibre Channel Port Operational Status**

**y\_dis\_phy\_unused|phy\_ena|phy\_ena\_not\_attach|phy\_ena\_unknown|phy\_unknown|phy\_dis\_i1legal}] - Fibre Channel Port Operational Status**

Displays information only about the storage shelves with FC Ports that match the operational status you specify.

**[-psu-id {<integer>}|-}] - Power Supply Unit ID**

Displays information only about the storage shelves with power supply units (PSU) that match the unit IDs you specify.

**[-psu-location <text>, ...] - Power Supply Unit Location**

Displays information only about the storage shelves with PSUs that are located at the specified location inside the shelf.

**[-psu-type <text>, ...] - Power Supply Unit Type**

Displays information only about the storage shelves with PSUs that match the PSU types you specify.

**[-psu-part-number <text>, ...] - Power Supply Unit Part Number**

Displays information only about the storage shelves with PSUs that match the PSU part number you specify.

**[-psu-serial-number <text>, ...] - Power Supply Unit Serial Number**

Displays information only about the storage shelves with PSUs that match the PSU serial numbers you specify.

**[-psu-reset-capable {true|false}] - Power Supply Unit Reset Capability**

Displays information only about the storage shelves with reset capable PSUs (true) or reset incapable PSUs (false).

**[-psu-is-enabled {true|false}] - Power Supply Unit Enable/Disable Status**

Displays information only about the storage shelves with PSUs that are enabled (true) or disabled (false).

**[-psu-fw-version <text>, ...] - Power Supply Unit Firmware Version**

Displays information only about the storage shelves with PSUs that have the firmware version you specify.

**[-psu-op-status {unknown|normal|error|dc-over-voltage|dc-under-voltage|dc-over-current|over-temperature-error|failed|off|not-supported|not-installed}] - Operational Status**

Displays information only about the storage shelves with PSUs that match the operational status you specify.

**[-psu-power-rating {<integer>}|-}] - Power Supply Power Ratings In Watts**

Displays information only about the storage shelves with PSUs that match the power rating you specify.

**[-psu-crest-factor {<integer>}|-}] - Power Supply Crest Factor**

Displays information only about the storage shelves with PSUs that match the crest factor value you specify.

**[-psu-power-drawn {<integer>}|-}] - Power Drawn From PSU In Watts**

Displays information only about the storage shelves with PSUs that match the drawn power you specify.

**[-temp-sensor-id {<integer>|-}] - Sensor Name**

Displays information only about the storage shelves with temperature sensors that match the sensor IDs you specify.

**[-temp-sensor-location <text>, ...] - Sensor Location**

Displays information only about the storage shelves with temperature sensors that match the specified sensor locations inside the shelf.

**[-temp-sensor-reading {<integer>|-}] - Temperature Reading**

Displays information only about the storage shelves with temperature sensors that match the temperature reading you specify.

**[-temp-is-ambient {true|false}] - Temperature Reading at Ambient Value**

Displays information only about the storage shelves with temperature sensors whose current temperature reading is ambient (true) or not (false).

**[-temp-high-critical-threshold {<integer>|-}] - High Critical Threshold**

Displays information only about the storage shelves with temperature sensors that match the high critical threshold you specify.

**[-temp-high-warning-threshold {<integer>|-}] - High Warning Threshold**

Displays information only about the storage shelves with temperature sensors that match the high warning threshold you specify.

**[-temp-low-warning-threshold {<integer>|-}] - Low Warning Threshold**

Displays information only about the storage shelves with temperature sensors that match the low warning threshold you specify.

**[-temp-low-critical-threshold {<integer>|-}] - Low Critical Threshold**

Displays information only about the storage shelves with temperature sensors that match the low critical threshold you specify.

**[-temp-op-status {unknown|normal|under-temperature|over-temperature|error|not-supported|not-installed}] - Operational Status**

Displays information only about the storage shelves with temperature sensors that match the operational status you specify.

**[-voltage-sensor-id {<integer>|-}] - Voltage Sensor ID**

Displays information only about the storage shelves with voltage sensors that match the sensor IDs you specify.

**[-voltage-sensor-location <text>, ...] - Voltage Sensor Location**

Displays information only about the storage shelves with voltage sensors that match the specified sensor locations inside the shelf.

**[-voltage-sensor-reading <text>, ...] - Voltage Current Reading**

Displays information only about the storage shelves with voltage sensors that match the voltage reading you specify.

**[-voltage-op-status {unknown|normal|over-voltage-critical|under-voltage-critical|not-supported|not-installed|not-recoverable}]** - Operational Status

Displays information only about the storage shelves with voltage sensors that match the operational status you specify.

**[-nsm-port-module-id {A|B}]** - Port Module ID

Displays information only about the storage shelves with PCIe Ports from the specified module.

**[-nsm-port-id <integer>,...]** - Port ID

Displays information only about the storage shelves with PCIe Ports that match the specified ID.

**[-nsm-port-type {cpu|disk|cx5|ethernet}]** - Port Type

Displays information only about the storage shelves with PCIe Ports that match the specified type.

**[-nsm-port-state {ok|off-link-disabled|off-dll-link|link-down|no-drive}]** - Port State

Displays information only about the storage shelves with PCIe Ports that match the specified state.

**[-nsm-port-bay <integer>,...]** - Port Bay

Displays information only about the storage shelves with PCIe Ports that match the specified bay.

**[-nsm-port-disk-id <integer>,...]** - Port Disk ID

Displays information only about the storage shelves with PCIe Ports that match the specified disk ID.

**[-nsm-port-is-installed {true|false}]** - Port Is Disk Installed

Displays information only about the storage shelves with PCIe Ports that have a disk installed.

**[-nsm-port-is-error {true|false}]** - Port Has Error

Displays information only about the storage shelves with PCIe Ports that have errors.

**[-nsm-port-speed {2.5|5.0|8.0}]** - Port Speed

Displays information only about the storage shelves with PCIe Ports that match the specified speed.

**[-nsm-port-speed-max {2.5|5.0|8.0}]** - Max Port Speed

Displays information only about the storage shelves with PCIe Ports that match the specified maximum speed.

**[-nsm-port-lane-width <integer>,...]** - Port Lane Width

Displays information only about the storage shelves with PCIe Ports that match the specified lane width.

**[-nsm-port-lane-width-max <integer>,...]** - Max Port Lane Width

Displays information only about the storage shelves with PCIe Ports that match the specified maximum lane width.

**[-dimm-module-id {A|B}]** - DIMM Module ID

Displays information only about the storage shelves with DIMMs from the specified module.

**[-dimm-id <integer>,...]** - DIMM ID

Displays information only about the storage shelves with DIMMs that match the specified ID.

**[-dimm-serial-number <text>, ...] - DIMM Serial Number**

Displays information only about the storage shelves with DIMMs that match the specified serial number.

**[-dimm-part-number <text>, ...] - DIMM Part Number**

Displays information only about the storage shelves with DIMMs that match the specified part number.

**[-dimm-vendor <text>, ...] - DIMM Vendor**

Displays information only about the storage shelves with DIMMs that match the specified vendor.

**[-dimm-type <text>, ...] - DIMM Type**

Displays information only about the storage shelves with DIMMs that match the specified type.

**[-dimm-size <text>, ...] - DIMM Size**

Displays information only about the storage shelves with DIMMs that match the specified size.

**[-dimm-speed <text>, ...] - DIMM Speed**

Displays information only about the storage shelves with DIMMs that match the specified speed.

**[-dimm-location <text>, ...] - DIMM Location**

Displays information only about the storage shelves with DIMMs that match the specified location.

**[-dimm-op-status {unknown|normal|error|not-supported|not-installed}] - DIMM Operational Status**

Displays information only about the storage shelves with DIMMs that match the specified operational status.

**[-boot-device-module-id {A|B}] - Boot Device Module ID**

Displays information only about the storage shelves with boot devices from the specified module.

**[-boot-device-id <integer>, ...] - Boot Device ID**

Displays information only about the storage shelves with boot devices that match the specified ID.

**[-boot-device-serial-number <text>, ...] - Boot Device Serial Number**

Displays information only about the storage shelves with boot devices that match the specified serial number.

**[-boot-device-part-number <text>, ...] - Boot Device Part Number**

Displays information only about the storage shelves with boot devices that match the specified part number.

**[-boot-device-vendor <text>, ...] - Boot Device Vendor**

Displays information only about the storage shelves with boot devices that match the specified vendor.

**[-boot-device-type <text>, ...] - Boot Device Type**

Displays information only about the storage shelves with boot devices that match the specified type.

**[-boot-device-size <text>, ...] - Boot Device Size**

Displays information only about the storage shelves with boot devices that match the specified size.

**[-boot-device-op-status {unknown|normal|error|not-supported|not-installed}] - Boot Device Operational Status**

Displays information only about the storage shelves with boot devices that match the specified operational status.

**[-coin-battery-module-id {A|B}] - Coin Battery Module ID**

Displays information only about the storage shelves with coin batteries from the specified module.

**[-coin-battery-id <integer>, ...] - Coin Battery ID**

Displays information only about the storage shelves with coin batteries that match the specified ID.

**[-coin-battery-voltage <integer>, ...] - Coin Battery Voltage (mV)**

Displays information only about the storage shelves with coin batteries that match the specified voltage.

**[-coin-battery-op-status {unknown|normal|error|low|high|not-supported|not-installed}] - Coin Battery Operational Status**

Displays information only about the storage shelves with coin batteries that match the specified operational status.

**[-error-type  
{Unknown|ACPP|Bootdevice|Coinbattery|Configuration|Current|Dimm|Expander|Fan|Module|PCM|Power|Temperature|Voltage}] - Error Type**

Displays information only about the storage shelves with errors that match the error type you specify.

**[-error-severity {unknown|notice|warning|error|critical}] - Error Severity**

Displays information only about the storage shelves with errors that match the error severity you specify.

## Examples

The following example displays information about all storage shelves:

```

cluster1::> storage shelf show
Module  Operational
          Shelf Name  Shelf ID  Serial Number  Model      Type
Status
-----
----- 1.1      1  6000832415  DS2246    IOM6
Critical
          1.2      2  6000647652  DS2246    IOM6
Normal
          1.3      3  6000003844  DS2246    IOM6
Normal
          1.4      4  SHJ000000013A9E  DS4246    IOM6
Normal
          1.5      5  SHJ000000013A84  DS4246    IOM6
Normal
          1.6      6  6000005555  DS2246    IOM6
Normal
          6 entries were displayed.
cluster1::>

```

The following example displays expanded information about a storage shelf named 1.2:

```

cluster1::> storage shelf show -shelf 1.2 -instance
Shelf Name: 1.2
          Stack ID: 1
          Shelf ID: 2
          Shelf UID: 50:0a:09:80:01:b9:75:41
          Serial Number: 6000647652
          Module Type: IOM6
          Model: DS2246
          Shelf Vendor: NETAPP
          Disk Count: 12
          Connection Type: SAS
          Shelf State: Online
          Status: Normal
Modules:                                     Module is
          Monitor  Is      Reporting FW Update
Latest  Swap  Operational  Module
          ID Part No.  ES Serial No.  is Active Master Element  Progress
FW Rev. FW Rev. Count Status      Location
-----
-----
          a 111-00190+A0  8006437891  true      false  false  not-
available 0191      -          0 normal      rear of the shelf at the top

```

left

b 111-00190+A0 8006435180 true true true not-  
available 0191 - 0 normal rear of the shelf at the top

right

Paths:

Speed

Controller Switch Port	Initiator Target Port	Initiator Side TP/GN	Switch Port Gb/s	Target Side I/O KB/s	IOPS
stsw-8020-01	0a	-	-	-	-
-	-	-	-	-	-
stsw-8020-01	2b	-	-	-	-
-	-	-	-	-	-
stsw-8020-02	0a	-	-	-	-
-	-	-	-	-	-
stsw-8020-02	2b	-	-	-	-
-	-	-	-	-	-

Power Supply Units:

Reset Capable	PSU Type	Part#	Operational Serial#	Crest Power Rating	Power Factor Drawn
	Enabled	Firmware	Status	PSU	Location
1	9C	114-00065+A1	XXT131052637	-	- -
false	true	020F	normal	rear of the shelf at the bottom	
left					
2	9C	114-00065+A1	XXT131052551	-	- -
false	true	020F	normal	rear of the shelf at the bottom	
right					

Voltage Sensors:

Voltage ID	Operational (V)	Status	Sensor Location
1	5.70	normal	rear of the shelf on the lower left
power supply			
2	12.300	normal	rear of the shelf on the lower left
power supply			
3	5.70	normal	rear of the shelf on the lower
right power supply			
4	12.180	normal	rear of the shelf on the lower
right power supply			

Current Sensors:

Current Operational						
ID	(mA)	Status	Sensor Location			
1	0	normal	rear of the shelf on the lower left			
power supply						
2	0	normal	rear of the shelf on the lower left			
power supply						
3	0	normal	rear of the shelf on the lower			
right power supply						
4	0	normal	rear of the shelf on the lower			
right power supply						
Fans:						
Speed Operational						
ID	(RPM)	Status	Fan Location			
1	3000	normal	rear of the shelf on the lower left			
power supply						
2	2970	normal	rear of the shelf on the lower left			
power supply						
3	3000	normal	rear of the shelf on the lower			
right power supply						
4	2970	normal	rear of the shelf on the lower			
right power supply						
Temperature:						
			-- Thresholds °C --			
			Temp	Is	Low	Low
					High	High
					Operational	
ID	°C	Ambient	Crit	Warn	Crit	Warn
Location						Sensor
1	23	true	0	5	42	40
shelf on the left, on the OPS panel						normal
2	26	false	5	10	55	50
shelf on the midplane						normal
3	24	false	5	10	55	50
shelf on the lower left power supply						normal
4	39	false	5	10	70	65
shelf on the lower left power supply						normal
5	25	false	5	10	55	50
shelf on the lower right power supply						normal
6	36	false	5	10	70	65
shelf on the lower right power supply						normal
7	25	false	5	10	60	55
shelf at the top left, on shelf module A						normal
8	26	false	5	10	60	55
shelf at the top right, on shelf module B						normal

## SAS Ports:

Port	Phy #	IOM	Port Type	WWPN	-- Port Speeds Gb/s -- Power		
					Operational	Negotiated	Status
<hr/>							
Enabled	0	A	Square	500a098004b063b0	6.0	- -	
Enabled	1	A	Square	500a098004b063b0	6.0	- -	
Enabled	2	A	Square	500a098004b063b0	6.0	- -	
Enabled	3	A	Square	500a098004b063b0	6.0	- -	
Enabled	4	A	Circle	500a09800569f03f	6.0	- -	
Enabled	5	A	Circle	500a09800569f03f	6.0	- -	
Enabled	6	A	Circle	500a09800569f03f	6.0	- -	
Enabled	7	A	Circle	500a09800569f03f	6.0	- -	
Enabled	8	A	Disk	500605ba00c1cb8d	6.0	6.0 on	
Enabled	9	A	Disk	500605ba00c1ea8d	6.0	6.0 on	
Enabled	10	A	Disk	500605ba00c1d111	6.0	6.0 on	
Enabled	11	A	Disk	500605ba00c1bc49	6.0	6.0 on	
Enabled	12	A	Disk	500605ba00c1cdfd	6.0	6.0 on	
Enabled	13	A	Disk	500605ba00c1c531	6.0	6.0 on	
Enabled	14	A	Disk	500605ba00c1eb05	6.0	6.0 on	
Enabled	15	A	Disk	500605ba00c1ec29	6.0	6.0 on	
Enabled	16	A	Disk	500605ba00c1bc29	6.0	6.0 on	
Enabled	17	A	Disk	500605ba00c1c471	6.0	6.0 on	
Enabled	18	A	Disk	500605ba00c039a9	6.0	6.0 on	
Enabled	19	A	Disk	500605ba00c1c4dd	6.0	6.0 on	

Enabled	20	A	Disk	-	-	- -
Empty	21	A	Disk	-	-	- -
Empty	22	A	Disk	-	-	- -
Empty	23	A	Disk	-	-	- -
Empty	24	A	Disk	-	-	- -
Empty	25	A	Disk	-	-	- -
Empty	26	A	Disk	-	-	- -
Empty	27	A	Disk	-	-	- -
Empty	28	A	Disk	-	-	- -
Empty	29	A	Disk	-	-	- -
Empty	30	A	Disk	-	-	- -
Empty	31	A	Disk	-	-	- -
Empty	32	A	SIL	-	-	- -
Disabled	33	A	SIL	-	-	- -
Disabled	34	A	SIL	-	-	- -
Disabled	35	A	SIL	-	-	- -
Disabled	0	B	Square	500a098004af9e30	6.0	- -
Enabled	1	B	Square	500a098004af9e30	6.0	- -
Enabled	2	B	Square	500a098004af9e30	6.0	- -
Enabled	3	B	Square	500a098004af9e30	6.0	- -
Enabled	4	B	Circle	500a098005688dbf	6.0	- -
Enabled	5	B	Circle	500a098005688dbf	6.0	- -
Enabled	6	B	Circle	500a098005688dbf	6.0	- -

Enabled	7	B	Circle	500a098005688dbf	6.0	- -
Enabled	8	B	Disk	500605ba00c1cb8e	6.0	6.0 on
Enabled	9	B	Disk	500605ba00c1ea8e	6.0	6.0 on
Enabled	10	B	Disk	500605ba00c1d112	6.0	6.0 on
Enabled	11	B	Disk	500605ba00c1bc4a	6.0	6.0 on
Enabled	12	B	Disk	500605ba00c1cdfc	6.0	6.0 on
Enabled	13	B	Disk	500605ba00c1c532	6.0	6.0 on
Enabled	14	B	Disk	500605ba00c1eb06	6.0	6.0 on
Enabled	15	B	Disk	500605ba00c1ec2a	6.0	6.0 on
Enabled	16	B	Disk	500605ba00c1bc2a	6.0	6.0 on
Enabled	17	B	Disk	500605ba00c1c472	6.0	6.0 on
Enabled	18	B	Disk	500605ba00c039aa	6.0	6.0 on
Enabled	19	B	Disk	500605ba00c1c4de	6.0	6.0 on
Enabled	20	B	Disk	-	-	- -
Empty	21	B	Disk	-	-	- -
Empty	22	B	Disk	-	-	- -
Empty	23	B	Disk	-	-	- -
Empty	24	B	Disk	-	-	- -
Empty	25	B	Disk	-	-	- -
Empty	26	B	Disk	-	-	- -
Empty	27	B	Disk	-	-	- -
Empty	28	B	Disk	-	-	- -
Empty	29	B	Disk	-	-	- -

Empty	30	B	Disk	-	-	- - -
Empty	31	B	Disk	-	-	- - -
Empty	32	B	SIL	-	-	- - -
Disabled	33	B	SIL	-	-	- - -
Disabled	34	B	SIL	-	-	- - -
Disabled	35	B	SIL	-	-	- - -
Disabled						
FC Ports:						
			Port			
	ID	Port	Type	Status		
	-----	-----	-----	-----	-----	-----
	- -	- -	- -	- -	- -	- -
Bays:						
Has				Operational		
	ID	Disk	Bay	Type	Status	
	-----	-----	-----	-----	-----	-----
	0	true	single-disk	normal		
	1	true	single-disk	normal		
	2	true	single-disk	normal		
	3	true	single-disk	normal		
	4	true	single-disk	normal		
	5	true	single-disk	normal		
	6	true	single-disk	normal		
	7	true	single-disk	normal		
	8	true	single-disk	normal		
	9	true	single-disk	normal		
	10	true	single-disk	normal		
	11	true	single-disk	normal		
	12	false	single-disk	normal		
	13	false	single-disk	normal		
	14	false	single-disk	normal		
	15	false	single-disk	normal		
	16	false	single-disk	normal		
	17	false	single-disk	normal		
	18	false	single-disk	normal		
	19	false	single-disk	normal		
	20	false	single-disk	normal		
	21	false	single-disk	normal		
	22	false	single-disk	normal		
	23	false	single-disk	normal		

```
cluster1::>
```

The following example displays information about the power supplies, voltage sensors and current sensors of the storage shelf 1.1:

```
cluster1::> storage shelf show -shelf 1.1 -power
Shelf Name: 1.1
          Stack ID: 1
          Shelf ID: 1
          Shelf UID: 50:0a:09:80:01:cb:d6:84
          Serial Number: 6000832415
          Module Type: IOM6
          Model: DS2246
          Shelf Vendor: NETAPP
          Disk Count: 12
          Connection Type: SAS
          Shelf State: Online
          Status: Normal

Power Supply Units:
          Reset   PSU          Operational
          ID      Type  Part#      Serial#      Power Rating      Crest  Power
          Capable Enabled Firmware Status
          ----- -----
          -----
          1  9C    114-00065+A1  XXT132835072  -          -          -
false    true    020F      normal
          2  9C    114-00065+A1  XXT132835073  -          -          -
false    true    020F      normal

Voltage Sensors:
          Voltage Operational
          ID      (V)  Status
          ----- -----
          1      5.70 normal
          2     12.180 normal
          3      5.70 normal
          4     12.300 normal

Current Sensors:
          Current Operational
          ID      (mA) Status
          ----- -----
          1        0 normal
          2        0 normal
          3     3900 normal
          4        0 normal
```

Errors:

-----

Critical condition is detected in storage shelf power supply unit "1".  
The unit might fail.

Critical over temperature failure for temperature sensor "1". Current  
temperature: "75" C ("167" F).

cluster1::>

The following example displays information about the cooling elements and temperature sensors inside the storage shelf 1.2:

```

cluster1::> storage shelf show -shelf 1.2 -cooling
Shelf Name: 1.2
      Stack ID: 1
      Shelf ID: 2
      Shelf UID: 50:0a:09:80:01:b9:75:41
      Serial Number: 6000647652
      Module Type: IOM6
      Model: DS2246
      Shelf Vendor: NETAPP
      Disk Count: 12
      Connection Type: SAS
      Shelf State: Online
      Status: Normal

Fans:
      Speed Operational
      ID (RPM) Status
      -- -----
      1 3000 normal
      2 3000 normal
      3 3000 normal
      4 2970 normal

Temperature:
      -- Thresholds °C --
      Temp Is      Low  Low  High  High  Operational
      ID  °C Ambient Crit Warn Crit Warn Status
      -- -----
      1  23 true      0    5    42    40  normal
      2  26 false     5   10    55    50  normal
      3  24 false     5   10    55    50  normal
      4  39 false     5   10    70    65  normal
      5  25 false     5   10    55    50  normal
      6  36 false     5   10    70    65  normal
      7  25 false     5   10    60    55  normal
      8  27 false     5   10    60    55  normal

Errors:
      -----
      -
cluster1::>

```

The following example displays information about the connectivity from the node to the storage shelf 1.2:

```

cluster1::> storage shelf show -shelf 1.2 -connectivity
      Shelf Name: 1.2
      Stack ID: 1
      Shelf ID: 2
      Shelf UID: 50:0a:09:80:01:b9:75:41
      Serial Number: 6000647652
      Module Type: IOM6
      Model: DS2246
      Shelf Vendor: NETAPP
      Disk Count: 12
      Connection Type: SAS
      Shelf State: Online
      Status: Normal

Paths:
Controller      Initiator Initiator Side Switch Port Target Side Switch
Port    Target Port      TPGN
-----  -----  -----  -----  -----  -----  -----  -----
-----  -----  -----  -----  -----  -----  -----  -----
  stsw-8020-01      0a      -      -      -      -
  -      -      -      -      -      -      -      -
  stsw-8020-01      2b      -      -      -      -
  -      -      -      -      -      -      -      -
  stsw-8020-02      0a      -      -      -      -
  -      -      -      -      -      -      -      -
  stsw-8020-02      2b      -      -      -      -
  -      -      -      -      -      -      -      -
Errors:
-----
  -
cluster1::>

```

The following example displays information about the disk bays of the storage shelf 1.2:

```

cluster1::> storage shelf show -shelf 1.2 -bay
Shelf Name: 1.2
          Stack ID: 1
          Shelf ID: 2
          Shelf UID: 50:0a:09:80:01:b9:75:41
          Serial Number: 6000647652
          Module Type: IOM6
          Model: DS2246
          Shelf Vendor: NETAPP
          Disk Count: 12
          Connection Type: SAS
          Shelf State: Online
          Status: Normal

Bays:
Has          Operational
  ID Disk  Bay Type      Status
  ---  ---  -----  -----
  0  true   0    single-disk  normal
  1  true   1    single-disk  normal
  2  true   2    single-disk  normal
  3  true   3    single-disk  normal
  4  true   4    single-disk  normal
  5  true   5    single-disk  normal
  6  true   6    single-disk  normal
  7  true   7    single-disk  normal
  8  true   8    single-disk  normal
  9  true   9    single-disk  normal
 10  true  10    single-disk  normal
 11  true  11    single-disk  normal
 12  false  12    single-disk  normal
 13  false  13    single-disk  normal
 14  false  14    single-disk  normal
 15  false  15    single-disk  normal
 16  false  16    single-disk  normal
 17  false  17    single-disk  normal
 18  false  18    single-disk  normal
 19  false  19    single-disk  normal
 20  false  20    single-disk  normal
 21  false  21    single-disk  normal
 22  false  22    single-disk  normal
 23  false  23    single-disk  normal

Errors:
  -----
  -
cluster1::>

```

The following example displays information about the ports of the storage shelf 1.2:

```
cluster1::> storage shelf show -shelf 1.2 -port
Shelf Name: 1.2
          Stack ID: 1
          Shelf ID: 2
          Shelf UID: 50:0a:09:80:01:b9:75:41
          Serial Number: 6000647652
          Module Type: IOM6
          Model: DS2246
          Shelf Vendor: NETAPP
          Disk Count: 12
          Connection Type: SAS
          Shelf State: Online
          Status: Normal

SAS Ports:
          -- Port Speeds Gb/s -- Power
Port
          Phy # IOM Port Type WWPN          Operational Negotiated Status
Status
          ----- ----- ----- ----- ----- ----- -----
          -----
          0  A  Square  500a098004b063b0  6.0      - - 
Enabled
          1  A  Square  500a098004b063b0  6.0      - - 
Enabled
          2  A  Square  500a098004b063b0  6.0      - - 
Enabled
          3  A  Square  500a098004b063b0  6.0      - - 
Enabled
          4  A  Circle  500a09800569f03f  6.0      - - 
Enabled
          5  A  Circle  500a09800569f03f  6.0      - - 
Enabled
          6  A  Circle  500a09800569f03f  6.0      - - 
Enabled
          7  A  Circle  500a09800569f03f  6.0      - - 
Enabled
          8  A  Disk    500605ba00c1cb8d  6.0      6.0 on
Enabled
          9  A  Disk    500605ba00c1ea8d  6.0      6.0 on
Enabled
         10 A  Disk    500605ba00c1d111  6.0      6.0 on
Enabled
         11 A  Disk    500605ba00c1bc49  6.0      6.0 on
Enabled
```

12	A	Disk	500605ba00c1cdfd	6.0	6.0	on
Enabled						
13	A	Disk	500605ba00c1c531	6.0	6.0	on
Enabled						
14	A	Disk	500605ba00c1eb05	6.0	6.0	on
Enabled						
15	A	Disk	500605ba00c1ec29	6.0	6.0	on
Enabled						
16	A	Disk	500605ba00c1bc29	6.0	6.0	on
Enabled						
17	A	Disk	500605ba00c1c471	6.0	6.0	on
Enabled						
18	A	Disk	500605ba00c039a9	6.0	6.0	on
Enabled						
19	A	Disk	500605ba00c1c4dd	6.0	6.0	on
Enabled						
20	A	Disk	-	-	-	-
Empty						
21	A	Disk	-	-	-	-
Empty						
22	A	Disk	-	-	-	-
Empty						
23	A	Disk	-	-	-	-
Empty						
24	A	Disk	-	-	-	-
Empty						
25	A	Disk	-	-	-	-
Empty						
26	A	Disk	-	-	-	-
Empty						
27	A	Disk	-	-	-	-
Empty						
28	A	Disk	-	-	-	-
Empty						
29	A	Disk	-	-	-	-
Empty						
30	A	Disk	-	-	-	-
Empty						
31	A	Disk	-	-	-	-
Empty						
32	A	SIL	-	-	-	-
Disabled						
33	A	SIL	-	-	-	-
Disabled						
34	A	SIL	-	-	-	-
Disabled						

35	A	SIL	-	-	-	-
Disabled						
0	B	Square	500a098004af9e30	6.0	-	-
Enabled						
1	B	Square	500a098004af9e30	6.0	-	-
Enabled						
2	B	Square	500a098004af9e30	6.0	-	-
Enabled						
3	B	Square	500a098004af9e30	6.0	-	-
Enabled						
4	B	Circle	500a098005688dbf	6.0	-	-
Enabled						
5	B	Circle	500a098005688dbf	6.0	-	-
Enabled						
6	B	Circle	500a098005688dbf	6.0	-	-
Enabled						
7	B	Circle	500a098005688dbf	6.0	-	-
Enabled						
8	B	Disk	500605ba00c1cb8e	6.0	6.0	on
Enabled						
9	B	Disk	500605ba00c1ea8e	6.0	6.0	on
Enabled						
10	B	Disk	500605ba00c1d112	6.0	6.0	on
Enabled						
11	B	Disk	500605ba00c1bc4a	6.0	6.0	on
Enabled						
12	B	Disk	500605ba00c1cdfe	6.0	6.0	on
Enabled						
13	B	Disk	500605ba00c1c532	6.0	6.0	on
Enabled						
14	B	Disk	500605ba00c1eb06	6.0	6.0	on
Enabled						
15	B	Disk	500605ba00c1ec2a	6.0	6.0	on
Enabled						
16	B	Disk	500605ba00c1bc2a	6.0	6.0	on
Enabled						
17	B	Disk	500605ba00c1c472	6.0	6.0	on
Enabled						
18	B	Disk	500605ba00c039aa	6.0	6.0	on
Enabled						
19	B	Disk	500605ba00c1c4de	6.0	6.0	on
Enabled						
20	B	Disk	-	-	-	-
Empty						
21	B	Disk	-	-	-	-
Empty						

```

22 B Disk -
Empty
23 B Disk -
Empty
24 B Disk -
Empty
25 B Disk -
Empty
26 B Disk -
Empty
27 B Disk -
Empty
28 B Disk -
Empty
29 B Disk -
Empty
30 B Disk -
Empty
31 B Disk -
Empty
32 B SIL -
Disabled
33 B SIL -
Disabled
34 B SIL -
Disabled
35 B SIL -
Disabled
FC Ports:
      Port
      ID Port Type Status
      --- -----
      - - - -
Errors:
      -----
      -
cluster1:>

```

The following example displays error information about the storage shelves that have errors:

```

cluster1::> storage shelf show -errors
Shelf Name: 1.1
    Shelf UID: 50:0a:09:80:01:cb:d6:84
    Serial Number: 6000832415
Error Type          Description
-----
Power              Critical condition is detected in storage shelf
power supply unit "1". The unit might fail.
Temperature        Critical over temperature failure for temperature
sensor "1". Current temperature: "75" C ("167" F).

```

## storage shelf acp configure

Configure alternate control path (ACP)

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

Configure the ACP connectivity on the cluster.

### Parameters

**-is-enabled {true|false} - Is Enabled?**

Configures the connectivity to the specified state.

**[-subnet <IP Address>] - Subnet**

Configures the connectivity to the specified subnet.

**[-netmask <IP Address>] - Netmask**

Configures the connectivity to the specified netmask.

**[-channel {out-of-band|in-band}] - Channel**

Configures the connectivity to the specified channel.

### Examples

The following example configures out-of-band ACP connectivity on each node:

```

cluster1::> storage shelf acp configure -is-enabled true -channel out-of-
band -subnet 192.168.0.1 -netmask 255.255.255.0

```

The following example configures in-band ACP connectivity on each node:

```

cluster1::> storage shelf acp configure -is-enabled true -channel in-band

```

The following example disables ACP connectivity on each node:

```
cluster1::> storage shelf acp configure -is-enabled false
```

## storage shelf acp show

Show connectivity information

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

Displays information about the ACP connectivity on each node

### Parameters

{ [-fields <fieldname>,...]

If you specify the -fields <field-name>,... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-errors ]

If you specify the -errors parameter, the command displays detailed information about all modules with errors.

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the nodes that match this parameter value.

**[-is-enabled {true|false}] - Is Enabled?**

Selects the nodes that are enabled or disabled.

**[-port <text>] - Port**

Selects the nodes that match the specified port on which ACP is configured.

**[-address <IP Address>] - IP Address**

Selects the nodes with the specified IP address.

**[-subnet <IP Address>] - Subnet**

Selects the nodes with the specified subnet.

**[-netmask <IP Address>] - Netmask**

Selects the nodes with the specified netmask.

**[-connection-status {no-connectivity|partial-connectivity|full-connectivity|additional-connectivity|unknown-connectivity|not-available|connection-disabled}] - Connection Status**

Selects the nodes with the specified connection status.

**[-error-id <integer>] - Error ID**

Selects the node with the specified error ID.

**[-error-type {No-Error|Connection-Issue|Connection-Activity|Module-Error|Shelf-Error}] - Error Type**

The error type, in case of a connection error.

**[-error-severity {unknown|notice|warning|error|critical}] - Error Severity**

The error severity, in case of a connection error.

**[-error-text <text>] - Error Text**

Selects the node with the specified error text.

**[-corrective-action <text>] - Corrective Action**

Selects the node with the specified corrective action.

**[-channel {unknown|out-of-band|in-band}] - Channel**

Selects the nodes that has channel configured out-of-band or in-band.

## Examples

The following example displays ACP connectivity on each node (in-band):

```
fas2750-2n-rtp-1::> storage shelf acp show
  Node          Channel          Connectivity
  -----  -----  -----
  fas2750-rtp-1a    in-band      active
  fas2750-rtp-1b    in-band      active
  2 entries were displayed.
```

The following example displays ACP connectivity on each node (out of band):

```
fas2750-2n-rtp-1::> storage shelf acp show
  Node          Channel          Connectivity
  -----  -----  -----
  fas2750-rtp-1a    out-of-band  full-connectivity
  fas2750-rtp-1b    out-of-band  full-connectivity
  2 entries were displayed.
```

The following example displays the -instance output of the storage acp show (in-band) command. Use this command to display details on connectivity and configuration.

```
fas2750-2n-rtp-1::> storage shelf acp show -instance
    Node: fas2750-rtp-1a
        Channel: in-band
        Enable Status: true
    Connection Status: active
Node: fas2750-rtp-1b
    Channel: in-band
    Enable Status: true
    Connection Status: active
2 entries were displayed.
```

The following example displays the -instance output of the storage acp show (out-of-band) command. Use this command to display details on connectivity and configuration.

```
fas2750-2n-rtp-1::> storage shelf acp show -instance
    Node: fas2750-rtp-1a
        Channel: out-of-band
    Enable Status: true
        Port: e0P
        IP Address: 192.168.1.74
        Subnet: 192.168.0.1
        Netmask: 255.255.252.0
    Connection Status: full-connectivity
Node: fas2750-rtp-1b
    Channel: out-of-band
    Enable Status: true
        Port: e0P
        IP Address: 192.168.1.75
        Subnet: 192.168.0.1
        Netmask: 255.255.252.0
    Connection Status: full-connectivity
2 entries were displayed.
```

## storage shelf acp module show

Show modules connected to the cluster

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

Displays information about the modules connected to each node

## Parameters

{ [-fields <fieldname>,...]

If you specify the -fields <field-name>", ... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify

| [-errors ]

If you specify the -errors parameter, the command displays detailed information about all modules with errors.

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the modules that match this parameter value.

**[-mac-address <text>] - MAC Address**

Selects the module that match the specified MAC address.

**[-module-name <text>] - Module name**

Selects the module that match the specified module name.

**[-module-address <IP Address>] - IP Address**

Selects the module that match the specified IP address.

**[-protocol-version <text>] - Protocol Version**

Selects the modules that match the specified protocol version.

**[-firmware-version <text>] - Firmware Version**

Selects the modules that match the specified firmware version.

**[-acpa-id <integer>] - ACPA assigner ID**

Selects the modules that match the specified ACPA ID.

**[-shelf-serial-number <text>] - Shelf Serial Number**

Selects the modules that match the specified shelf serial number.

**[-iom-type {Unknown|iom3|iom6|iom6e|iom12|iom12e|iom12f|iom12b}] - IOM Type**

Selects the modules that match the specified IOM type (IOM3/IOM6/IOM6E).

**[-last-contact <integer>] - Last Contact (secs)**

Selects the modules that match the specified last contact.

**[-state {unknown|initializing|discovery-complete|awaiting-inband|no-inband|active|awaiting-bootp|updating-firmware|connection-error|firmware-update-required|rebooting|fail|unsupported|degraded|shelf-off}] - Local Node State**

Selects the modules that match the specified state.

**[-stack-id {<integer>|-}] - Stack ID**

Selects the modules that match the specified stack ID.

**[-shelf-id <text>] - Shelf ID**

Selects the modules that match the specified shelf ID.

**[-adapter-name <text>] - Adapter Name**

Selects the modules that match the specified adapter name.

**[-error-id <integer>,...] - Error ID**

Selects the modules that match the specified error ID.

**[-error-text <text>,...] - Error Text**

The error text, in case of a module error.

**[-corrective-action <text>,...] - Corrective Action**

The corrective action, in case of a module error.

**[-error-type {No-Error|Connection-Issue|Connection-Activity|Module-Error|Shelf-Error}] - Error Type**

Selects the modules that match the specified error type.

**[-error-severity {unknown|notice|warning|error|critical}] - Error Severity**

Selects the modules that match the specified error severity.

**[-power-cycle-count <integer>] - Power Cycle count**

Number of times a shelf power cycle has been performed on a shelf

**[-power-off-count <integer>] - Power Off count**

Number of times a shelf power off has been performed on a shelf

**[-power-on-count <integer>] - Power On count**

Number of times a shelf power on has been performed on a shelf

**[-expander-reset-count <integer>] - Expander reset count**

Number of times an expander reset has been performed on a module

**[-expander-power-cycle-count <integer>] - Expander power cycle count**

Number of times an expander power cycle has been performed on a module

## Examples

The following example displays the ACP modules connected to each node:

```
cluster1::> storage shelf acp module show
Node           Module Name      State
-----
stor-v4-1a-1b-01  1.10.A        Active
                  1.10.B        Active
                  1.254.B       Active
                  1.254.A       Active

stor-v4-1a-1b-02  1.10.A        Active
                  1.10.B        Active
                  1.254.B       Active
                  1.254.A       Active

8 entries were displayed.
```

The following example displays the -instance output of the storage shelf acp module show. More details on each module can be seen here.

```
cluster1::> storage shelf acp module show -instance
Node: stor-v4-1a-1b-01
      Module Name: 1.10.A
      Mac Address: 00:a0:98:19:53:ee
      IOM Type: IOM6E
      Shelf Serial Number: SHJMS000000001A
      IP Address: 192.168.3.239
      Protocol Version: 2.1.1.21
      Assigner ID: 2.1.1.21
      State: Active
      Last Contact: 203
      Power Cycle Count: 0
      Power Off Count: 0
      Power On Count: 0
      Expander Reset Count: 0
Expander Power Cycle Count: 0
Node: stor-v4-1a-1b-01
      Module Name: 1.10.B
      Mac Address: 00:a0:98:19:55:16
      IOM Type: IOM6E
      Shelf Serial Number: SHJMS000000001A
      IP Address: 192.168.1.23
      Protocol Version: 2.1.1.21
      Assigner ID: 2.1.1.21
      State: Active
      Last Contact: 206
      Power Cycle Count: 0
      Power Off Count: 0
```

```
Power On Count: 0
Expander Reset Count: 0
Expander Power Cycle Count: 0
Node: stor-v4-1a-1b-01
    Module Name: 1.254.B
    Mac Address: 00:a0:98:32:d6:ac
    IOM Type: IOM6
    Shelf Serial Number: 6000368103
    IP Address: 192.168.2.173
    Protocol Version: 1.2.2. 8
    Assigner ID: 1.2.2. 8
    State: Active
    Last Contact: 215
    Power Cycle Count: 0
    Power Off Count: 0
    Power On Count: 0
    Expander Reset Count: 0
Expander Power Cycle Count: 0
Node: stor-v4-1a-1b-01
    Module Name: 1.254.A
    Mac Address: 00:a0:98:32:d6:dc
    IOM Type: IOM6
    Shelf Serial Number: 6000368103
    IP Address: 192.168.2.221
    Protocol Version: 1.2.2. 8
    Assigner ID: 1.2.2. 8
    State: Active
    Last Contact: 218
    Power Cycle Count: 0
    Power Off Count: 0
    Power On Count: 0
    Expander Reset Count: 0
Expander Power Cycle Count: 0
Node: stor-v4-1a-1b-02
    Module Name: 1.106.A
    Mac Address: 00:a0:98:19:53:ee
    IOM Type: IOM6E
    Shelf Serial Number: SHJMS000000001A
    IP Address: 192.168.3.239
    Protocol Version: 2.1.1.21
    Assigner ID: 2.1.1.21
    State: Initializing
    Last Contact: 206
    Power Cycle Count: 0
    Power Off Count: 0
    Power On Count: 0
```

```
    Expander Reset Count: 0
    Expander Power Cycle Count: 0
    Node: stor-v4-1a-1b-02
        Module Name: 1.106.B
        Mac Address: 00:a0:98:19:55:16
        IOM Type: IOM6E
        Shelf Serial Number: SHJMS000000001A
        IP Address: 192.168.1.23
        Protocol Version: 2.1.1.21
        Assigner ID: 2.1.1.21
        State: Initializing
        Last Contact: 209
        Power Cycle Count: 0
        Power Off Count: 0
        Power On Count: 0
        Expander Reset Count: 0
    Expander Power Cycle Count: 0
    Node: stor-v4-1a-1b-02
        Module Name: 1.10.B
        Mac Address: 00:a0:98:32:d6:ac
        IOM Type: IOM6
        Shelf Serial Number: 6000368103
        IP Address: 192.168.2.173
        Protocol Version: 1.2.2.8
        Assigner ID: 1.2.2.8
        State: Initializing
        Last Contact: 217
        Power Cycle Count: 0
        Power Off Count: 0
        Power On Count: 0
        Expander Reset Count: 0
    Expander Power Cycle Count: 0
    Node: stor-v4-1a-1b-02
        Module Name: 1.10.A
        Mac Address: 00:a0:98:32:d6:dc
        IOM Type: IOM6
        Shelf Serial Number: 6000368103
        IP Address: 192.168.2.221
        Protocol Version: 1.2.2.8
        Assigner ID: 1.2.2.8
        State: Initializing
        Last Contact: 220
        Power Cycle Count: 0
        Power Off Count: 0
        Power On Count: 0
        Expander Reset Count: 0
```

```
Expander Power Cycle Count: 0
```

```
8 entries were displayed.
```

## storage shelf drawer show-phy

Display a list of PHYs per drawer

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage shelf drawer show-phy` command displays information for drawer PHYs in the storage system. If no parameters are specified, the default command displays the following information about PHYs:

- Shelf Name
- Drawer Number
- PHY Number
- Type
- SAS Address
- State

To display detailed information about a single PHY, use the `-shelf`, `-drawer`, and `-phy` parameters.

### Parameters

{ [-fields <fieldname>,...]

Displays the specified fields for all drawer PHYs, in column style output.

| [-instance ]

Displays expanded information for all drawer PHYs in the system. If a shelf, drawer, and PHY are specified, then this parameter displays the same detailed information for the PHY you specify as does the `-shelf`, `-drawer`, and `-phy` parameters.

**[-shelf <text>] - Shelf Name**

Displays the PHYs in the storage shelf that matches the specified shelf name.

**[-drawer <integer>] - Drawer Number**

Displays the PHYs in the drawers that match the specified drawer number.

**[-phy <integer>] - PHY Number**

Displays the PHYs that match the specified PHY number.

**[-node {<nodename>|local}] - Node Name**

Displays the PHYs that are present for the specified node.

**[-type {unknown|disk|virtual|input}] - Type**

Displays the PHYs with the specified type.

**[-physical-id <integer>] - Physical ID**

Displays the PHYs that match the specified physical-id.

**[-sas-address <text>] - Attached SAS Address**

Displays the PHYs with the specified attached sas address.

**[-state-a {unknown|enabled|disabled}] - State Module A**

Displays the PHYs for which module A has the specified state.

**[-state-b {unknown|enabled|disabled}] - State Module B**

Displays the PHYs for which module B has the specified state.

**[-status-a <Drawer PHY Status>] - Status Module A**

Displays the PHYs with module A currently operating under the specified status.

**[-status-b <Drawer PHY Status>] - Status Module B**

Displays the PHYs with module B currently operating under the specified status.

## Examples

The following example displays information about all drawer PHYs:

```
cluster1::> storage shelf drawer show-phy
Shelf Drawer PHY #  Type      SAS Address          PHY State A/B
-----  -----
2.5
1
0  disk    00c5005079183f85  enabled/enabled
1  disk    -                  enabled/enabled
2  disk    -                  enabled/enabled
3  disk    00c50050e1183f85  enabled/enabled
4  disk    -                  enabled/enabled
5  disk    -                  enabled/enabled
6  disk    00c50050dd183f85  enabled/enabled
7  disk    -                  enabled/enabled
8  disk    -                  enabled/enabled
9  disk    00c500502d163f85  enabled/enabled
10 disk   -                  enabled/enabled
11 disk   -                  enabled/enabled
12 input   80090a5045e46f06  enabled/enabled
13 input   80090a5045e46f06  enabled/enabled
14 input   80090a5045e46f06  enabled/enabled
15 input   80090a5045e46f06  enabled/enabled
16 virtual 8a090a503dd01b17  enabled/enabled
```

2

0	disk	00c500503d0e3d85	enabled/enabled
1	disk	-	enabled/enabled
2	disk	-	enabled/enabled
3	disk	00c50050e9173f85	enabled/enabled
4	disk	-	enabled/enabled
5	disk	-	enabled/enabled
6	disk	00c50050a9163f85	enabled/enabled
7	disk	-	enabled/enabled
8	disk	-	enabled/enabled
9	disk	00c5005021173f85	enabled/enabled
10	disk	-	enabled/enabled
11	disk	-	enabled/enabled
12	input	80090a5045e46f06	enabled/enabled
13	input	80090a5045e46f06	enabled/enabled
14	input	80090a5045e46f06	enabled/enabled
15	input	80090a5045e46f06	enabled/enabled
16	virtual	8a090a503d90fd16	enabled/enabled

3

0	disk	00c500503d163f85	enabled/enabled
1	disk	-	enabled/enabled
2	disk	-	enabled/enabled
3	disk	00c50050bd163f85	enabled/enabled
4	disk	-	enabled/enabled
5	disk	-	enabled/enabled
6	disk	00c50050c1d44085	enabled/enabled
7	disk	-	enabled/enabled
8	disk	-	enabled/enabled
9	disk	00c50050f1d54085	enabled/enabled
10	disk	-	enabled/enabled
11	disk	-	enabled/enabled
12	input	80090a5045e46f06	enabled/enabled
13	input	80090a5045e46f06	enabled/enabled
14	input	80090a5045e46f06	enabled/enabled
15	input	80090a5045e46f06	enabled/enabled
16	virtual	8a090a503d202a17	enabled/enabled

4

0	disk	00c50050fdd54085	enabled/enabled
1	disk	-	enabled/enabled
2	disk	-	enabled/enabled
3	disk	00c50050d9d44085	enabled/enabled
4	disk	a0cc0050e5973712	enabled/enabled
5	disk	-	enabled/enabled
6	disk	00c500506dd34085	enabled/enabled
7	disk	-	enabled/enabled
8	disk	-	enabled/enabled

9	disk	00c5005045d64085	enabled/enabled
10	disk	-	enabled/enabled
11	disk	-	enabled/enabled
12	input	80090a5045e46f06	enabled/enabled
13	input	80090a5045e46f06	enabled/enabled
14	input	80090a5045e46f06	enabled/enabled
15	input	80090a5045e46f06	enabled/enabled
16	virtual	8a090a503d100b17	enabled/enabled
5			
0	disk	00c50050c9d54085	enabled/enabled
1	disk	-	enabled/enabled
2	disk	-	enabled/enabled
3	disk	00c50050f9d44085	enabled/enabled
4	disk	-	enabled/enabled
5	disk	-	enabled/enabled
6	disk	00c5005081d34085	enabled/enabled
7	disk	-	enabled/enabled
8	disk	-	enabled/enabled
9	disk	00c500505dd64085	enabled/enabled
10	disk	-	enabled/enabled
11	disk	-	enabled/enabled
12	input	80090a5045e46f06	enabled/enabled
13	input	80090a5045e46f06	enabled/enabled
14	input	80090a5045e46f06	enabled/enabled
15	input	80090a5045e46f06	enabled/enabled
16	virtual	8a090a503df00a17	enabled/enabled

85 entries were displayed.

cluster1::>

The following example displays expanded information for PHY 0 of drawer 1 in shelf 2.5:

```
cluster1::> storage shelf drawer show-phy -shelf 2.5 -drawer 1 -phy 0
Shelf: 2.5
      Drawer ID: 1
      PHY Number: 0
      Type: disk
      Physical ID: 1
      SAS Address: 00c5005079183f85
      State A: enabled
      State B: enabled
      Status A: enabled-12gbs
      Status B: enabled-12gbs
cluster1::>
```

## storage shelf drawer show-slot

Display a map between bay number and drawer/slot number

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage shelf drawer show-slot` command maps each drawer and slot number to the corresponding bay number.

### Parameters

{ [-fields <fieldname>,...]

Displays the specified fields in column style output.

| [-instance ]

Displays all slot information.

**[-shelf <text>] - Shelf Name**

Displays the slots in the shelf that matches the specified shelf name.

**[-bay <integer>] - Bay Number**

Displays the slots that have the specified bay number.

**[-node {<nodename>|local}] - Node Name**

Displays the slots that are present for the specified node.

**[-drawer <integer>] - Drawer Number**

Displays the slots in the drawers that match the specified drawer number.

**[-slot <integer>] - Slot Number**

Displays the slots that match the specified slot number.

**[-is-installed {yes|no}] - Is Disk Installed**

Displays the slots that have a disk installed.

### Examples

The following example displays the mapping from drawer and slot number to bay number:

```
cluster1::> storage shelf drawer show-slot
Shelf  Drawer  Slot  Bay  Installed?
-----  -----  ----  ---  -----
2.5          1
              0      0  yes
              1      1  no
              2      2  no
```

3	3	yes
4	4	no
5	5	no
6	6	yes
7	7	no
8	8	no
9	9	yes
10	10	no
11	11	no
2		
0	12	yes
1	13	no
2	14	no
3	15	yes
4	16	no
5	17	no
6	18	yes
7	19	no
8	20	no
9	21	yes
10	22	no
11	23	no
3		
0	24	yes
1	25	no
2	26	no
3	27	yes
4	28	no
5	29	no
6	30	yes
7	31	no
8	32	no
9	33	yes
10	34	no
11	35	no
4		
0	36	yes
1	37	no
2	38	no
3	39	yes
4	40	yes
5	41	no
6	42	yes
7	43	no
8	44	no
9	45	yes

```
      10  46  no
      11  47  no
      5
      0   48  yes
      1   49  no
      2   50  no
      3   51  yes
      4   52  no
      5   53  no
      6   54  yes
      7   55  no
      8   56  no
      9   57  yes
     10  58  no
     11  59  no

60 entries were displayed.
cluster1::>
```

## storage shelf drawer show

Display a list of drawers

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage shelf drawer show` command displays information for storage shelf drawers in the storage system. If no parameters are specified, the default command displays the following information for the drawers:

- Shelf Name
- Drawer Number
- Status
- Closed/Open
- Disk Count
- Firmware

To display detailed information for a single drawer, use the `-shelf` and `-drawer` parameters.

### Parameters

`{ [-fields <fieldname>,...]`

Displays the specified fields for all drawers, in column style output.

`| [-errors ]`

Displays the following error status information about the drawers that have errors:

- Status

- Error Description

**[**-instance** ]**

Displays expanded information for all drawers in the system. If a shelf and drawer are specified, then this parameter displays the same detailed information for the specified drawer as does the -shelf and -drawer parameters.

**[**-shelf** <text>] - Shelf Name**

Displays the drawers in the storage shelf that matches the specified shelf name.

**[**-drawer** <integer>] - Drawer Number**

Displays the drawers that match the specified drawer number.

**[**-node** {<nodename>|local}] - Node Name**

Displays the drawers that are present for the specified node.

**[**-disk-count** <integer>] - Drawer Disk Count**

Displays the drawers that have the specified disk count.

**[**-part-number** <text>] - Part Number**

Displays the drawers that have the specified part number.

**[**-serial-number** <text>] - Serial Number**

Displays the drawer that matches the specified serial number.

**[**-is-closed** {open|closed}] - Drawer is Closed?**

Displays the drawers that are closed or open.

**[**-firmware-a** <text>] - Firmware A**

Displays the the drawers for which module A has the specified firmware version.

**[**-firmware-b** <text>] - Firmware B**

Displays the drawers for which module B has the specified firmware version.

**[**-path-a** {unknown|ok|degraded|none}] - Path A**

Displays the drawers for which module A has the specified path status.

**[**-path-b** {unknown|ok|degraded|none}] - Path B**

Displays about drawers for which module B has the specified path status.

**[**-is-supported** {yes|no}] - Drawer is Supported?**

Displays the drawers that are supported (TRUE) or not supported (FALSE).

**[**-vendor** <text>] - Vendor Name**

Displays the drawers that match the specified vendor.

**[**-mfg-date** <text>] - Mfg. Date**

Displays the drawers that match the specified manufactured date.

**[-fru-type <text>] - FRU Type**

Displays the drawers that match the specified FRU type.

**[-status-a {unknown|normal|warning|error|critical}] - Status A**

Displays the drawers with module A currently operating under the specified status.

**[-status-b {unknown|normal|warning|error|critical}] - Status B**

Displays the drawers with module B currently operating under the specified status.

**[-error <text>] - Error**

Displays the drawers that match the specified error description.

## Examples

The following example displays information about all drawers:

```
cluster1::> storage shelf drawer show
Drawer    Disk
Shelf  Drawer   Status A/B   Closed?  Count   Firmware A/B
-----  -----
2.5
      1  normal/normal   closed      4  00000634/00000634
      2  normal/normal   closed      4  00000634/00000634
      3  normal/normal   closed      4  00000634/00000634
      4  normal/normal   closed      5  00000634/00000634
      5  normal/normal   closed      4  00000634/00000634
5 entries were displayed.
cluster1::>
```

The following example displays expanded information about drawer 1 in shelf 2.5:

```

cluster1::> storage shelf drawer show -shelf 2.5 -drawer 1
Shelf: 2.5
          Drawer ID: 1
          Part Numer: 111-03071
          Serial Number: 021604008153
          Drawer is Closed?: closed
          Disk Count: 4
          Firmware A: 00000634
          Firmware B: 00000634
          Path A: ok
          Path B: ok
          Status A: normal
          Status B: normal
          Drawer is Supported?: yes
          Vendor Name: NETAPP
          Mfg. Date: 02/2016
          FRU Type: SASDRWR
          Error Description: -
cluster1::>

```

The following example displays error information about the drawers that have errors:

```

cluster1::> storage shelf drawer show -errors
Shelf Drawer      Status A/B      Error Description
-----  -----
-----  -----
2.5          2  warning/warning  Drawer open.
cluster1::>

```

## storage shelf firmware show-update-status

Display the Shelf Firmware Update (SFU) Status.

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage shelf firmware show-update-status` command displays the state of the Shelf Firmware Update process.

### Parameters

{ [-fields <fieldname>, ...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified

field or fields. You can use '-fields ?' to display the fields to specify.

**[-instance ] }**

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-node <nodename>] - Node (privilege: advanced)**

Selects the node that matches this parameter value.

**[-update-status {running|idle}] - Disk Shelf Firmware Update Status (privilege: advanced)**

Selects the nodes whose SFU process status matches this parameter value. Possible values are:

- running - Disk shelf firmware update is in progress.
- idle - Disk shelf firmware update is not in progress.

**[-in-progress-count <integer>] - Number of Shelves with Earlier Revisions Being Updated (privilege: advanced)**

Selects the nodes that matches the number of shelves the SFU process is updating to this parameter value. This specifies the number of shelves with earlier revisions that are being updated.

## Examples

```
cluster1::*> storage shelf firmware show-update-status
              Update  In-Progress
Node          Status      Count
-----
cluster-n1    running     10
cluster-n2    idle        -
cluster-n3    running     7
```

## storage shelf firmware update

### Update Shelf Firmware

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The storage shelf firmware update command updates the firmware on one or more shelves. You can download the latest firmware by using the [storage firmware download](#) command. You can specify a shelf whose firmware is to be updated by using the -shelf parameter. You can update the firmware on all the shelves by not providing the -shelf parameter. All the shelves of a specific module type can be updated by providing a value to the -module-type parameter.

### Parameters

**{ [-shelf <text>] - Shelf Name (privilege: advanced)}**

This specifies the name of the shelf whose firmware is to be updated.

```
| [-module-type  
{atfcx|esh4|iom3|iom6|iom6e|iom12|iom12e|iom12b|nsm100|nsm8e|iom12g}] - Shelf Module  
Type (privilege: advanced) }
```

Update the firmware on the shelves that match the module-type you specify.

**[-refresh <true>] - Refresh (privilege: advanced)**

Forces an update on the shelf with the highest revision of the applicable firmware, resulting in a refresh of the firmware image already present on the shelf.

## Examples

The following example updates the firmware on all the shelves in the cluster:

```
cluster1::*> storage shelf firmware update
```

The following example updates the firmware on all shelves with the IOM6 module type:

```
cluster1::*> storage shelf firmware update -module-type IOM6
```

The following example updates the firmware on shelf 1.2:

```
cluster1::*> storage shelf firmware update -shelf 1.2
```

The following example refreshes the firmware on all shelves with the IOM6 module type:

```
cluster1::*> storage shelf firmware update -refresh -module-type IOM6
```

The following example refreshes the firmware on shelf 1.2:

```
cluster1::*> storage shelf firmware update -refresh -shelf 1.2
```

## Related Links

- [storage firmware download](#)

## storage shelf location-led modify

Modify the state of the shelf Location LED

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The *storage shelf location-led modify* command modifies the on/off state of the shelf location LED.

## Parameters

### **-shelf-name <text>** - Shelf Name

This parameter specifies the shelf whose LED is to be turned on or turned off.

### **[-led-status {on|off}]** - Location LED

This parameter specifies whether the shelf location LED needs to be turned on or turned off.

## Examples

The following example turns on the shelf location LED of the specified shelf.

```
cluster1::> storage shelf location-led modify -shelf-name 1.0 -led-status
on

Info: Shelf locate request successful for shelf "1.0".
```

The following example turns off the shelf location LED of the specified shelf.

```
cluster1::> storage shelf location-led modify -shelf-name 1.0 -led-status
off

Info: Shelf locate request successful for shelf "1.0".
```

## **storage shelf location-led show**

Display the Location LED status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `storage shelf location-led show` command displays the state of shelf location LED.

## Parameters

### **{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

### **| [-instance ]**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

### **[-shelf-name <text>]** - Shelf Name

Selects the shelves whose shelf-name matches this parameter value.

**[-node {<nodename>|local}] - Node Name**

Selects the nodes that match this parameter value.

**[-stack-id <integer>] - Stack ID**

Selects the shelves whose stack-id matches this parameter value.

**[-shelf-id <integer>] - Shelf ID**

Selects the shelves whose shelf-id matches this parameter value.

**[-led-status {on|off}] - Location LED**

Shows the state of the shelf location LED.

## Examples

The following example shows the state of the shelf location LED for each shelf.

```
cluster1::> storage shelf location-led show
Shelf Name Stack ID Shelf ID LED Status
----- -----
 8.2          8        2  off
 8.3          8        3  off
 6.0          6        0  unsupported
 8.1          8        1  off
4 entries were displayed.
```

## storage shelf port show

Display storage shelf ports

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The *storage shelf port show* command displays information for storage shelf ports in the storage system. If no parameters are specified, the default command displays the following information for the ports:

- Shelf Name
- ID
- Module
- State
- Internal?

To display detailed information for a single port, use the *-shelf* and *-id* parameters.

### Parameters

{ [-fields <fieldname>,...]

Displays output in column style about the specified fields for all shelf ports.

| [-cables ]

Displays information about all cables connected to the shelf ports.

| [-instance ]

Displays expanded information for all shelf ports in the system. If a shelf and ID are specified, then this parameter displays the same detailed information for the specified port as does the -shelf and -id parameters.

**[-shelf <text>] - Shelf Name**

Displays the ports in the storage shelf that matches the specified shelf name.

**[-id <integer>] - Port ID**

Displays the ports that match the specified ID.

**[-node {<nodename>|local}] - Node Name**

Displays the ports that are present for the specified node.

**[-module-id {A|B}] - Module ID**

Displays the ports from the specified shelf module ID.

**[-is-internal {true|false}] - Is Port Internal?**

Displays the ports that are internal.

**[-location <text>] - Location**

Displays the ports with the specified location.

**[-is-cable-connected {true|false}] - Is Cable Connected?**

Displays the ports that have cables connected to them.

**[-is-error {true|false}] - Any Errors?**

Displays the ports for which errors have been logged.

**[-connector-state {connected|disconnected|error}] - Connector State**

Displays the ports with the specified connector state.

**[-connector-serial-number <text>] - Connector Serial Number**

Displays the ports with the specified connector serial number.

**[-connector-type {QSFP|QSFP+|QSFP28|Mini-SAS-HD}] - Connector Type**

Displays the ports with the specified connector type.

**[-cable-vendor <text>] - Cable Vendor**

Displays the ports that are connected to a cable from the specified vendor.

**[-cable-part-number <text>] - Cable Part Number**

Displays the ports that are connected to a cable with the specified part number.

**[-cable-technology {active-copper|passive-copper|optical}] - Cable Technology**

Displays the ports that are connected to a cable with the specified technology.

**[-cable-length <text>] - Cable Length**

Displays the ports that are connected to a cable with the specified length.

**[-cable-id <text>] - Cable ID**

Displays the ports that are connected to a cable with the specified ID.

**[-cable-end {end\_0|end\_1}] - Cable End**

Displays the ports that are connected to a cable with the specified cable end.

**[-designator <text>] - Designator**

Displays the ports with the specified designator.

**[-wwn <text>] - Local Device WWN**

Displays the ports with the specified WWN.

**[-remote-wwn <text>] - Remote Device WWN**

Displays the ports connected to the specified remote WWN.

**[-remote-phy <text>] - Remote Phy**

Displays the ports connected to the specified remote PHY.

**[-swap-count <integer>] - Swap Count**

Displays the ports with the specified swap count.

**[-mac <MAC Address>] - Local MAC Address**

Displays the ports with the specified MAC address.

**[-remote-mac <MAC Address>] - Remote MAC Address**

Displays the ports connected to the specified MAC address.

**[-remote-port <text>] - Remote Port**

Displays the ports connected to the specified port.

**[-remote-chassis <text>] - Remote Chassis**

Displays the ports connected to the specified chassis.

**[-remote-device <text>] - Remote Device**

Displays the ports connected to the specified device.

**[-vlan-id <integer>] - VLAN ID**

Displays the ports with the specified VLAN ID.

## Examples

The following example displays information about all shelf ports:

```
cluster1::> storage shelf port show

Shelf ID Module State      Internal?
----- -----
1.4
  0 A      connected    false
  1 A      connected    false
  2 B      connected    false
  3 B      connected    false
4 entries were displayed.
```

The following example displays expanded information about port 0 in shelf 1.4:

```
cluster1::> storage shelf port show -shelf 1.4 -id 0
Shelf Name: 1.4
          Port ID: 0
          Module ID: A
          Is Port Internal?: false
          Location: rear of the shelf at the top left, on shelf
module A
          Is Cable Connected?: true
          Any Errors?: false
          Connector State: connected
Connector Serial Number: 616930439
          Connector Type: qsfp+
          Cable Vendor: Molex Inc.
          Cable Part Number: 112-00431+A0
          Cable Technology: passive-copper
          Cable Length: 5m
          Cable ID: 500a0980000b6c3f-50000d1703544b80
          Cable End: end_1
          Designator: sqr
          Local Device WWN: 500A0980000B6C3F
          Remote Device WWN: 50000D1703544B80
          Remote Phy: 12
          Swap Count: 0
```

The following example displays information about the cables:

```
cluster1::> storage shelf port show -cables
```

```
Shelf: 1.4
```

ID	Vendor	Part Number	Technology	Length	Type	Serial
Number						
0	Molex Inc.	112-00431+A0	passive-copper	5m	qsfp+	616930439
1	Molex Inc.	112-00431+A0	passive-copper	5m	qsfp+	616930364
2	Molex Inc.	112-00431+A0	passive-copper	5m	qsfp+	616930452
3	Molex Inc.	112-00431+A0	passive-copper	5m	qsfp+	616930474
4	entries were displayed.					

## storage tape commands

### storage tape offline

Take a tape drive offline

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

#### Description

This command takes the specified tape drive offline.

#### Parameters

**-node {<nodename>|local} - Node**

Use this parameter to specify the node to which the tape drive is attached.

**{ -name <text> - Tape Drive Device Name**

Use this parameter to specify the device name of the tape drive that needs to be taken offline. The format of the device -name name includes a prefix to specify how the tape cartridge is handled and a suffix to describe the density of the tape. The prefix suggests 'r', 'nr' or 'ur' for rewind, no rewind, or unload/reload and a suffix shows density of 'l', 'm', 'h' or 'a'. For example, a tape device name for this operation might have the form "nrst8m" were 'nr' is the 'no rewind' prefix, 'st8' is the alias-name and 'm' is the tape density. You can use the 'storage tape show -device-names' command to find more information about device names of tape drives attached to a node.

**| -device-id <text> - Tape Drive Device ID }**

Use this parameter to specify the device ID of the tape drive that needs to be taken offline.

#### Examples

The following example takes the tape drive with device name 'nrst8m' offline. This tape drive is attached to cluster1-01.

```
cluster1::> storage tape offline -node cluster1-01 -name nrst8m
```

## storage tape online

Bring a tape drive online

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

This command brings a specified tape drive online.

### Parameters

**-node {<nodename>|local} - Node**

Use this parameter to specify the node to which the tape drive is attached.

**{ -device-id <text> - Tape Drive Device ID**

Use this parameter to specify the device ID of the tape drive that needs to be brought online.

**| -name <text> - Tape Drive Device Name }**

Use this parameter to specify the device name of the tape drive that needs to be brought online. The format of the device -name name includes a prefix to specify how the tape cartridge is handled and a suffix to describe the density of the tape. The prefix suggests 'r', 'nr' or 'ur' for rewind, no rewind, or unload/reload and a suffix shows density of 'l', 'm', 'h' or 'a'. For example, a tape device name for this operation might have the form "nrst8m" were 'nr' is the 'no rewind' prefix, 'st8' is the alias-name and 'm' is the tape density. You can use the 'storage tape show -device-names' command to find more information about device names of tape drives attached to a node.

### Examples

The following example brings the tape drive with device id sw4:2.126L4 attached to the node, cluster1-01, online.

```
cluster1::> storage tape online -node cluster1-01 -device-id sw4:2.126L4
```

## storage tape position

Modify a tape drive cartridge position

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

This command changes the tape drive cartridge position.

## Parameters

### **-node {<nodename>|local} - Node**

Use this parameter to specify the node to which the tape drive is attached.

### **-name <text> - Tape Drive Device Name**

Use this parameter to specify the device name of the tape drive whose cartridge position needs to be changed. The format of the device -name includes a prefix to specify how the tape cartridge is handled and a suffix to describe the density of the tape. The prefix suggests 'r', 'nr' or 'ur' for rewind, no rewind, or unload/reload and a suffix shows density of 'l', 'm', 'h' or 'a'. For example, a tape device name for this operation might have the form "nrst8m" were 'nr' is the 'no rewind' prefix, 'st8' is the alias-name and 'm' is the tape density. You can use the 'storage tape show -device-names' command to find more information about device names of tape drives attached to a node.

### **-operation {weof|fsf|bsf|fsr|bsr|rewind|erase|eom} - Tape Position Operation**

Use this parameter to specify the tape positioning operation. The possible values for -operation are:

- weof - Write end-of-file marks
- fsf - Forward space end-of-file marks
- bsf - Backward space end-of-file marks
- fsr - Forward space records
- bsr - Backward space records
- rewind - Rewind the tape
- erase - Erase then entire tape media from current position
- eom - Position the tape at end of data (end of media if full)

### **[-count <integer>] - Count for Positioning**

Use this parameter to specify the count for a tape positioning operation. You can specify this parameter only with the following operations: weof, fsf, bsf, fsr, and bsr. The default value of this parameter is one.

## Examples

The following example specifies a rewind operation on a tape device. Note the -count parameter does not need to be specified for this type of operation.

```
cluster1::> storage tape position -node cluster1-01 -name nrst8m
-operation rewind
```

The following example specifies an fsf (forward space filemark) operation on a tape device. Note the -count parameter specifies 5 forward space filemarks for this operation.

```
cluster1::> storage tape position -node cluster1-01 -name nrst1a
-operation fsf -count 5
```

The following example specifies an eom (end-of-media) operation on a tape device. The 'eom' positions a tape at end of data (end of media if full). Note the -count parameter does not need to be specified for this type of

operation.

```
cluster1::> storage tape position -node cluster1-01 -name rst0h -operation
eom
```

## storage tape reset

Reset a tape drive

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

This command resets a specified tape drive.

### Parameters

**-node {<nodename>|local} - Node (privilege: advanced)**

Use this parameter to specify the node to which the tape drive is attached.

**-device-id <text> - Tape Drive Device ID (privilege: advanced)**

Use this parameter to specify the device ID of the tape drive is to be reset.

### Examples

The following example resets the tape drive with device ID sw4:2.126L3 attached to the node, cluster1-01.

```
cluster1::> storage tape reset -node cluster1-01 -device-id sw4:2.126L3
```

## storage tape show-errors

Display tape drive errors

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage tape show-errors` command displays error information about tape drives attached to the cluster. By default, this command displays the following information about all tape drives:

- Node to which the tape drive is attached
- Device ID of the tape drive
- Type of device(tape drive)
- Description of the tape drive
- Alias name of the tape drive
- Tape drive errors

## Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Displays detailed information about tape drives on the specified node.

**[-device-id <text>] - Device ID**

Selects the tape drive with the specified device ID.

**[-device-type <text>] - Device Type**

Selects the devices with the specified type of tape drive.

**[-description <text>] - Description**

Selects the tape drives with the specified description.

**[-alias-name <text>] - Alias Name**

Selects the tape drive with the specified alias name.

**[-wwnn <text>] - World Wide Node Name**

Selects the tape drives with the specified World Wide Node Name.

**[-wwpn <text>] - World Wide Port Name**

Selects the tape drive with the specified World Wide Port Name.

**[-serial-number <text>] - Serial Number**

Selects the tape drive with the specified serial number.

**[-error <text>] - Tape Drive Error Description**

Selects the tape drives with the specified error string.

**[-initiator <text>] - Initiator Port**

Selects the tape drives with the specified initiator port.

## Examples

The following example shows error information for all tape drives attached to cluster1.

```
cluster1::> storage tape show-errors
    Node: node1
    Device ID: 0d.125
    Device Type: tape drive
    Description: Hewlett-Packard LTO-5
    Alias: st0
    Errors: hardware error; repair or replace tape drive
    Node: node1
    Device ID: 2d.0
    Device Type: tape drive
    Description: IBM LTO-6 ULT3580
    Alias: st2
    Errors: -
```

The following example shows error information for tape drive sw4:2.126L1 attached to the node, node1.

```
cluster1::> storage tape show-errors -device-id sw4:2.126L1 -node node1
    Node: node1
    Device ID: sw4:2.126L1
    Device Type: tape drive
    Description: Hewlett-Packard LTO-3
    Alias: st3
    Errors: -
```

## storage tape show-media-changer

Display information about media changers

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

This *storage tape show-media-changer* command displays information about media changers attached to the cluster. By default, this command displays the following information about all media changers:

- Device ID of media changer
- Description of media changer
- World Wide Node Name of media changer
- World Wide Port Name of media changer
- Serial number of media changer
- Media changer errors
- Node to which the media changer is attached
- Initiator port which hosts the media changer

- Alias name of media changer
- Operational state of media changer
- Functional status of media changer

## Parameters

**{ [-fields <fieldname>,...]**

If you specify the **-fields <fieldname>,...** parameter, the command output also includes the specified field or fields. You can use **'-fields ?'** to display the fields to specify.

**| [-instance ] }**

If you specify the **-instance** parameter, the command displays detailed information about all fields.

**[-device-id <text>] - Device ID**

Selects the media changer with the specified device ID.

**[-node {<nodename>|local}] - Node**

Displays detailed information about media changers on the specified node.

**[-description <text>] - Description**

Selects the media changers with the specified description.

**[-alias-name <text>] - Alias Name**

Selects the media changer with the specified alias name.

**[-wwnn <text>] - World Wide Node Name**

Selects the media changers with the specified World Wide Node Name.

**[-wwpn <text>] - World Wide Port Name**

>Selects the media changer with the specified World Wide Port Name.

**[-serial-number <text>] - Serial Number**

Selects the media changer with the specified serial number.

**[-device-if-type {unknown|fibre-channel|SAS|pSCSI}] - Device If Type**

Selects the media changers with the specified interface type.

**[-device-state {unknown|available|ready-write-enabled|ready-write-protected|offline|in-use|error|reserved-by-another-host|normal}] - Operational State of Device**

Selects the media changers with the specified operational state.

**[-error <text>] - Media Changer Error Description**

Selects the media changers with the specified error string.

**[-initiator <text>] - Initiator Port**

Selects the media changers with the specified initiator port.

## Examples

The following example displays information about all media changers attached to the cluster:

```
cluster1::> storage tape show-media-changer

Media Changer: sw4:10.11L1
  Description: PX70-TL
    WWNN: 2:00a:000e11:10b919
    WWPN: 2:00b:000e11:10b919
  Serial Number: 00FRU7800000_LL1
  Errors: -

  Paths:
  Node           Initiator  Alias  Device  State
  Status
  -----
  -----
  cluster1-01      2b        mc0    in-use
  normal

Media Changer: sw4:12.4L1
  Description: NEO-TL
    WWNN: 2:001:000e11:10b919
    WWPN: 2:002:000e11:10b919
  Serial Number: 00FRU7800000_LL0
  Errors: -

  Paths:
  Node           Initiator  Alias  Device  State
  Status
  -----
  -----
  cluster1-01      5a        mc1    available
  normal
```

## storage tape show-supported-status

Displays the qualification and supported status of tape drives

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

This command displays the supported and qualification status of all tape drives recognized by Data ONTAP attached to a node in the cluster. This includes nonqualified tape drives. Such tape drives do not have a Tape Configuration File (TCF) on the storage system. A nonqualified tape drive can be used if the tape drive emulates a qualified tape drive or if the appropriate TCF for the nonqualified tape drive is downloaded from the

## Parameters

{ [-fields <fieldname>, ...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the tape drives that match this parameter value.

**[-tape-drive <text>] - Tape Drive Name**

Selects the tape drives that match this parameter value.

**[-is-supported {true|false}] - Tape Drive Supported**

Selects the tape drives that match this parameter value.

**[-status <text>] - Supported Status**

Selects the tape drives that match this parameter value.

## Examples

The following example displays support and qualification status of tape drives recognized by Data ONTAP. The command also identifies tape drives attached to the node that are nonqualified (not supported).

```
cluster1::> storage tape show-supported-status
Node: Node1
          Is
Tape Drive      Supported  Support Status
-----
-----
sw4:2.126L6          false    Nonqualified tape drive
Hewlett-Packard C1533A    true     Qualified
Hewlett-Packard C1553A    true     Qualified
Hewlett-Packard Ultrium 1  true     Qualified
Sony SDX-300C          true     Qualified
Sony SDX-500C          true     Qualified
StorageTek T9840C        true    Dynamically Qualified
StorageTek T9840D        true    Dynamically Qualified
Tandberg LTO-2 HH         true    Dynamically Qualified
```

The following example displays support and qualification status of tape drives selected by `ltape-drive`. The command identifies the supported status of the selected tape drive.

```
cluster1::> storage tape show-supported-status -tape-drive "Sony SDX-300C"  
Node: Node1
```

Tape Drives	Is Supported	Support Status
Sony SDX-300C	true	Qualified

## storage tape show-tape-drive

## Display information about tape drives

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

This `storage tape show-tape-drive` command displays information about tape drives attached to the cluster. By default, this command displays the following information about all tape drives:

- Device ID of tape drive
- Description of tape drive
- World Wide Node Name of tape drive
- World Wide Port Name of tape drive
- Serial Number of tape drive
- Tape drive errors
- Node to which the tape drive is attached

- Initiator port which hosts the tape drive
- Alias name of tape drive
- Operational state of tape drive
- Functional status of tape drive

## Parameters

{ [-fields <fieldname>, ...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-device-id <text>] - Device ID**

Selects the tape drive with the specified device ID.

**[-node {<nodename>|local}] - Node**

Displays detailed information about tape drives on the specified node.

**[-description <text>] - Description**

Selects the tape drives with the specified description.

**[-alias-name <text>] - Alias Name**

Selects the tape drive with the specified alias name.

**[-wwnn <text>] - World Wide Node Name**

Selects the tape drives with the specified World Wide Node Name.

**[-wwpn <text>] - World Wide Port Name**

Selects the tape drive with the specified World Wide Port Name.

**[-serial-number <text>] - Serial Number**

Selects the tape drive with the specified serial number.

**[-device-if-type {unknown|fibre-channel|SAS|pSCSI}] - Device If Type**

Selects the tape drives with the specified interface type.

**[-device-state {unknown|available|ready-write-enabled|ready-write-protected|offline|in-use|error|reserved-by-another-host|normal}] - Operational State of Device**

Selects the tape drives with the specified operational state.

**[-error <text>] - Tape Drive Error Description**

Selects the tape drives with the specified error string.

**[-initiator <text>] - Initiator Port**

Selects the tape drives with the specified initiator port.

**[-resv-type {off|persistent|scsi}] - Reservation type for device**

Selects the tape drives with the specified type.

**Examples**

The following example displays information about all tape drives attached to the cluster:

```
cluster1::> storage tape show-tape-drive
Tape Drive: sw4:11.126
  Description: StorageTek T10000C
    WWNN: 5:001:04f000:b39ec8
    WWPN: 5:001:04f000:b39ec9
  Serial Number: 576004000041
  Errors: -

  Paths:
  Node           Initiator  Alias  Device  State
  Status
  -----
  -----
cluster1-01           2a        st0    ready-write-enabled
normal

Tape Drive: sw4:12.4
  Description: HP LTO-3
    WWNN: 2:001:000e11:10b919
    WWPN: 2:002:000e11:10b919
  Serial Number: 1068000371
  Errors: -

  Paths:
  Node           Initiator  Alias  Device  State
  Status
  -----
  -----
cluster1-01           0b        st1    ready-write-enabled
normal
```

**storage tape show**

Display information about tape drives and media changers

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

**Description**

The *storage tape show* command displays information about tape drives and media changers attached to the cluster. Where it appears in the remainder of this document "device" may refer to either a tape drive or a

media changer. By default, this command displays the following information about all tape drives and media changers:

- Node to which the tape drive/media changer is attached
- Device ID of the tape drive/media changer
- Description of the tape drive/media changer
- Type of device: tape drive or media changer
- Functional status of the tape drive/media changer

## Parameters

{ [-fields <fieldname>, ...]

If you specify the -fields <fieldname>, ... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-alias ]

Displays the tape drive/media changer alias with the following details:

- Node to which tape drive/media changer is attached
- Device ID of the tape drive/media changer
- Alias name of the tape drive/media changer
- Alias mapping for tape drive/media changer

| [-connectivity ]

Displays the connectivity from the node to the tape drive/media changer with the following details:

- Node to which tape drive/media changer is attached
- Device ID of the tape drive/media changer
- Tape drive/media changer description
- Type of device: tape drive or media changer
- Interface type for the tape drive/media changer
- World Wide Node Name of tape drive/media changer
- World Wide Port Name of tape drive/media changer
- Serial Number of tape drive/media changer
- Tape drive/media changer errors
- Initiator port which hosts the tape drive/media changer
- Alias name of the tape drive/media changer
- Operational state of tape drive/media changer
- Functional status of tape drive/media changer

| [-device-names ]

Displays the tape drive names for used tape positioning using the following details: rewind, no rewind, unload/reload and density

- Node to which tape drive/media changer is attached
- Device ID of the tape drive/media changer
- Tape drive/media changer description
- Device Names that include Rewind, no Rewind, Unload/Reload

**| [-status ]**

Displays the status of tape drive/media changer with the following details:

- Device ID of the tape drive/media changer
- Tape drive/media changer description
- World Wide Node Name of tape drive/media changer
- World Wide Port Name of tape drive/media changer
- Serial Number of tape drive/media changer
- Alias name of the tape drive/media changer
- Format used for tape cartridge mounted by tape drive
- Tape drive/media changer errors
- Node to which tape drive/media changer is attached
- Operational state of tape drive/media changer
- File number following last tape drive I/O operation
- Block number following last tape drive I/O operation
- Residual count following last tape drive I/O operation

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-device-id <text>] - Device ID**

Selects the tape drive/media changer with the specified device ID.

**[-node {<nodename>|local}] - Node**

Displays detailed information about tape drives or media changers on the specified node.

**[-device-type <text>] - Device Type**

Selects the devices with the specified type of tape drive or media changer.

**[-description <text>] - Description**

Selects the tape drives/media changers with the specified description.

**[-alias-name <text>] - Alias Name**

Selects the tape drive/media changer with the specified alias name.

**[-alias-mapping <text>] - Alias Mapping**

Selects the tape drive/media changer with the specified alias mapping.

**[-wwnn <text>] - World Wide Node Name**

Selects the tape drives/media changers with the specified World Wide Node Name.

**[-wwpn <text>] - World Wide Port Name**

Selects the tape drive/media changer with the specified World Wide Port Name.

**[-serial-number <text>] - Serial Number**

Selects the tape drive/media changer with the specified serial number.

**[-functional-status {unknown|normal|error}] - Functional Status**

Selects the tape drives/media changers with the specified functional status of the device.

**[-device-if-type {unknown|fibre-channel|SAS|pSCSI}] - Device Interface Type**

Selects the tape drives/media changers with the specified interface type.

**[-device-state {unknown|available|ready-write-enabled|ready-write-protected|offline|in-use|error|reserved-by-another-host|normal}] - Operational State of Device**

Selects the tape drives/media changers with the specified operational state.

**[-format <text>, ...] - Tape Cartridge Format**

Selects the tape drives with the specified tape format.

**[-error <text>] - Tape Error**

Selects the tape drives/media changers with the specified error string.

**[-initiator <text>] - Initiator Port**

Selects the tape drives/media changers with the specified initiator port.

**[-file-number <integer>] - File Number**

Selects the tape drives/media changers with the specified file number. The file number is the number of file marks between the beginning of media and current logical position. File number gets modified on write file mark, and forward or backward space file operations. A value of -1 indicates unknown position on the tape media or tape not loaded in the tape drive.

**[-block-number <integer>] - Block Number**

Selects the tape drives/media changers with the specified block number. The block number is the number of logical blocks between the beginning of tape media or the prior file mark and the current logical position on the tape media. Block number gets modified on writes, reads, and forward or backward space over records (blocks). The block number also gets reset to zero when a file mark is crossed or another file mark is written that designates a new file. If the tape is back spaced to a prior file mark, the block number might be zeroed. A value of -1 indicates unknown position on the tape media or that a tape not loaded in the tape drive.

**[-residual-count <integer>] - Residual Count of Last I/O Operation**

Selects the tape drives with the specified residual count.

**[-device-name-r <text>, ...] - Device Name for Rewind**

Selects the tape drives with the specified device name for rewind.

**[-device-name-nr <text>, ...] - Device Name for No Rewind**

Selects the tape drives with the specified device name for no rewind.

**[-device-name-ur <text>, ...] - Device Name for Unload Reload**

Selects the tape drives with the specified device name for unload/reload.

**[-resv-type {off|persistent|scsi}] - Reservation Type for device**

Selects the tape drives with the specified type.

**[-aliases-name <text>, ...] - Alias Names**

Selects the tape drive/media changer with the specified alias name.

**[-aliases-mapping <text>, ...] - Alias Mappings**

Selects the tape drive/media changer with the specified alias mapping.

## Examples

The following example displays information about all tape drives and media changers attached to the cluster:

```
cluster1::> storage tape show

Node: cluster1-01
Device ID          Device Type      Description
Status
-----
-----
sw4:10.11          tape drive      HP LTO-3
error

Node: cluster1-01
Device ID          Device Type      Description
Status
-----
-----
sw4:10.11L1        media changer   PX70-TL
normal
```

The following example displays detailed information about a tape drive named sw4:10.11

```
cluster1::> storage tape show -device-id sw4:10.11

Node: cluster1-01
Device ID          Device Type      Description
Status

-----
-----
sw4:10.11          tape drive      HP LTO-3
error
```

## storage tape trace

Enable/disable tape trace operations

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

This command enables or disables diagnostic tape trace operations for all tape drives attached to the node you have specified.

### Parameters

#### **-node {<nodename>|local} - Node**

Use this parameter to specify the node on which the tape trace feature is enabled or disabled.

#### **[-is-trace-enabled {true|false}] - Tape Trace Enabled or Disabled**

Use this parameter to enable or disable the tape trace feature. By default, the tape trace feature is enabled.

### Examples

The following example enables tape trace operation on the node, cluster1-01.

```
cluster1::> storage tape trace -node cluster1-01 -is-trace-enabled true
```

## storage tape alias clear

Clear alias names

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

This command clears alias names for a tape drive or media changer.

## Parameters

### **-node {<nodename>|local} - Node**

Use this parameter to specify the node to which the tape drive is attached.

### **{ -name <text> - Alias Name That Is to Be Cleared**

Use this parameter to specify the alias name that is to be cleared. You can use the 'storage tape show -alias' command to find more information about alias names of tape drives and media changers attached to a node. The -clear-scope and -name parameters are mutually exclusive. If you specify the -name parameter, a single alias name is cleared.

### **| -clear-scope {tape|media-changer|all} - Scope of Alias Clear Operation }**

Use this parameter to specify the scope of the alias clear operation. The -clear-scope and -name parameters are mutually exclusive. If you specify the -clear-scope parameter, multiple aliases are cleared depending upon the value of the parameter.

The possible values for -clear-scope are as follows:

- tape - Clear all tape drive aliases
- media-changer - Clear all media-changer aliases
- all - Clear both tape drive and media-changer aliases

## Examples

The following example clears an alias name 'st3' attached to the node, cluster1-01.

```
cluster1::> storage tape alias clear -node cluster1-01 -name st3
```

The following example clears all tape drive alias names attached to the node, cluster1-01.

```
cluster1::> storage tape alias clear -node cluster1-01 -clear-scope tape
```

The following example clears all media changer alias names attached to the node, cluster1-01.

```
cluster1::> storage tape alias clear -node cluster1-01 -clear-scope media-changer
```

The following example clears both tape and media changer alias names attached to the node, cluster1-01.

```
cluster1::> storage tape alias clear -node cluster1-01 -clear-scope all
```

## **storage tape alias set**

Set an alias name for tape drive or media changer

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

This command sets an alias name for a tape drive or media changer.

## Parameters

### **-node {<nodename>|local} - Node**

Use this parameter to specify the node to which the tape drive is attached.

### **-name <text> - Alias Name for Tape Drive or Media Changer**

Use this parameter to specify the alias name for tape drive or media changer. For a tape drive alias name, the format is 'st' followed by one or more digits. For a media changer alias name, the format is 'mc' followed by one or more digits.

### **-mapping <text> - Mapping for Alias Name**

Use this parameter to specify the mapping for an alias name. Use the format 'SN[<serial-number>]'. Valid mapping for serial numbers are in the format 'SN[<serial-number>]' where the <serial-number> is from 2 to 90 characters long and includes the following characters: 0-9, a-z, and A-Z.

## Examples

The following example sets an alias name 'st3' for a tape drive with serial number SN[123456]L4 attached to the node, node1.

```
cluster1::storage tape alias> set -node node1 -name st3 -mapping
SN[123456]L4.
```

The following example sets an alias name 'mc1' for a media changer with serial number SN[65432] attached to the node, node1.

```
cluster1::storage tape alias> set -node node1 -name mc1 -mapping
SN[65432].
```

## **storage tape alias show**

Displays aliases of all tape drives and media changers

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

This command displays aliases of all tape drives and media changers attached to every node in the cluster.

## Parameters

{ [-fields <fieldname>,...]

If you specify the -fields <fieldname>, ... parameter, the command output also includes the specified field or fields. You can use '-fields ?' to display the fields to specify.

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Displays the tape drive and media changer aliases on the specified node.

**[-alias-list <text>,...] - List of Aliases**

Displays the node with the specified list of tape drive and media changer aliases.

## Examples

The following example shows the aliases of all tape drives and media changers attached to every node in the cluster:

```
cluster1::> storage tape alias show

Node: node1

Alias                                Mapping
-----
-----
mc0                                  SN[00FRU7800000_LL0]L1
mc1                                  SN[00FRU7800000_LL1]L1
mc2                                  SN[aa6a64c69360a0980248c8]
mc3                                  SN[c940abe8b0c3a0980248c8]
mc4                                  SN[fb082e6b335a0980248c8]L5
st0                                  SN[HU19487T7N]
st1                                  SN[1068000230]
st10                                 SN[fb0c508b335a0980248c8]L7

Node: node2

Alias                                Mapping
-----
-----
mc1                                  SN[c940982fc48c8]
st3                                  SN[ST456HT8N]L3
st2                                  SN[HG68000230]L2
st11                                 SN[aba673980248c8]L7
```

## storage tape config-file delete

Delete a tape config file

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `storage tape config-file delete` command deletes the specified tape drive configuration file from all nodes that are currently part of the cluster.

### Parameters

#### **-filename <text> - Config File Filename (privilege: advanced)**

This parameter specifies the name of the tape configuration file that will be deleted from all nodes that are currently part of the cluster.

### Examples

The following example deletes the specified tape drive configuration files on every node that is currently part of the cluster:

```
cluster1::> storage tape config-file delete -filename XYZ_LTO-6.TCF
```

## storage tape config-file get

Get a tape drive configuration file

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage tape config-file get` command uploads a specified tape drive configuration file to each node that is currently part of the cluster.

### Parameters

#### **-url <text> - Config File URL**

This parameter specifies the URL that provides the location of the package to be fetched. Standard URL schemes, including HTTP and TFTP, are accepted.

### Examples

The following example uploads the specified tape drive configuration file to each node that is currently part of the cluster:

```
cluster1::> storage tape config-file get -url  
http://example.com/~tapeconfigfile/XYZ_LTO-6.TCF
```

## **storage tape config-file show**

Display the list of tape drive configuration files on the given node

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `storage tape config-file show` command lists the tape drive configuration files loaded onto each node in the cluster.

### **Parameters**

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'?` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects information about tape drive configuration files for the specified node.

**[-config-file <text>] - Tape Config File**

Selects information about the tape drive configuration file specified.

### **Examples**

The following example lists the tape drive config files loaded onto each node in the cluster:

```
cluster1::> storage tape config-file show

Node: node1

Tape Config Files
-----
CERTANCE_LTO2_ULTRIUM.TCF
CERTANCE_LTO3_ULTRIUM.TCF
HP_LT09.TCF
HP_LTO2.TCF
HP_LTO3_ULTRIUM.TCF
HP_LTO4_ULTRIUM.TCF
HP_LTO5_ULTRIUM.TCF
HP_LTO6_ULTRIUM.TCF
IBM_3592.TCF
IBM_3592E05.TCF
IBM_5038_sdfkjl.TCF
IBM_LTO2_ULT3580.TCF
IBM_LTO2_ULTRIUM.TCF
```

## storage tape library config show

Display connectivity to back-end storage tape libraries.

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

This command displays information such as how the storage tape libraries connect to the cluster, LUN groups, number of LUNs, WWPN, and switch port information. Use this command to verify the cluster's storage tape library configuration or to assist in troubleshooting.

### Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-switch ]

If you specify this parameter, switch port information is shown.

| [-instance ] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Controller Name**

The name of the clustered node for which information is being displayed.

**[-group <integer>] - LUN Group**

A LUN group is a set of LUNs that shares the same path set.

**[-target-wwpn <text>] - Library Target Ports**

The World Wide Port Name of a storage tape library port.

**[-initiator <text>] - Initiator**

The host bus adapter that the clustered node uses to connect to storage tape libraries.

**[-array-name <array name>] - Library Name**

Name of the storage tape library that is connected to the clustered node.

**[-target-side-switch-port <text>] - Target Side Switch Port**

This identifies the switch port that connects to the tape library's target port.

**[-initiator-side-switch-port <text>] - Initiator Side Switch Port**

This identifies the switch port that connects to the node's initiator port.

**[-lun-count <integer>] - Number of LUNS**

This is a command-line switch (-lun-count) used to restrict what LUN groups are displayed in the output.

## Examples

The following example displays the storage tape library configuration information.

```
cluster1::> storage tape library config show
      LUN      LUN
      Node      Group Count      Library Name      Library Target
      Port Initiator
-----
-----
cluster1-01
      0      2      TAPE_LIB_1
50050763124b4d6f      3d

cluster1::>
```

## storage tape library path show-by-initiator

Display a list of LUNs on the given tape library

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

This command displays path information for every initiator port connected to a tape library. The output is similar to the storage library path show command but the output is listed by initiator.

## Parameters

{ [-fields <fieldname>,...]

fields used to be used in this display

| [-instance ] }

If you specify the -instance parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Controller name**

The name of the clustered node for which information is being displayed.

**[-initiator <text>] - Initiator Port**

Initiator port that the clustered node uses.

**[-target-wwpn <text>] - Target Port**

Target World Wide Port Name. Port on the storage tape library that is being used.

**[-initiator-side-switch-port <text>] - Initiator Side Switch Port**

Switch port connected to the clustered node.

**[-target-side-switch-port <text>] - Target Side Switch Port**

Switch port connected to the tape library.

**[-array-name <array name>] - Library Name**

Name of the storage tape library that is connected to the cluster.

**[-tpgn <integer>] - Target Port Group Number**

TPGN refers to the target port group to which the target port belongs. A target port group is a set of target ports which share the same LUN access characteristics and failover behaviors.

**[-port-speed <text>] - Port Speed**

Port Speed of the specified port.

**[-path-io-kbps <integer>] - Kbytes of I/O per second on Path (Rolling Average)**

Rolling average of Kbytes of I/O per second on the library path.

**[-path-iops <integer>] - Number of I/O per second on Path (Rolling Average)**

Rolling average of I/O per second on the library path.

**[-initiator-io-kbps <integer>] - Kbytes of I/O per second on Initiator (Rolling Average)**

Rolling average of Kbytes of I/O per second on the initiator port.

**[-initiator-iops <integer>] - Number of I/O per second on Initiator (Rolling Average)**

>Rolling average of I/O per second on the initiator port.

**[-target-io-kbps <integer>] - Kbytes of I/O per second to Target (Rolling Average)**

Rolling average of Kbytes of I/O per second on the target port.

## **[-target-iops <integer>] - Number of I/O per second to Target (Rolling Average)**

Rolling average of I/O per second on the target port.

### **Examples**

The following example displays the path information by initiator for a storage tape library.

```
cluster1::> storage tape library path show-by-initiator
Node: cluster1-01
      Initiator I/O      Initiator Side      Path I/O      Target
Side  Target I/O
Initiator      (KB/s)      Switch Port      (KB/s)      Switch
Port      (KB/s)      Target Port Library Name
-----
-----
0b          0 sw_tape:6          0          0
sw_tape:0      0 510a09800000412d TAPE_LIB_1

sw_tape:1      0 510a09820000412d TAPE_LIB_1
3d          0 N/A          0
N/A          0 50050763124b4d6f TAPE_LIB_2
3 entries were displayed.
```

## **storage tape library path show**

Display a list of Tape Libraries on the given path

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

This command displays path information for a tape library and has the following parameters by default:

- Node name
- Initiator port
- Target port
- TPGN (Target Port Group Number)
- Port speeds
- Path I/O in Kbytes/sec
- IOPs

### **Parameters**

{ [-fields <fieldname>, ...]

fields used to be used in this display

**[ -detail ]**

Using this option displays the following:

- Target IOPs
- Target LUNs
- Path IOPs
- Path errors
- Path quality
- Path LUNs
- Initiator IOPs
- Initiator LUNs

**[ -instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[ -node {<nodename>|local} ] - Controller name**

The name of the clustered node for which information is being displayed.

**[ -array-name <array name> ] - Library Name**

Name of the storage tape library that is connected to the cluster.

**[ -target-wwpn <text> ] - Target Port**

Target World Wide Port Name. Port on the storage tape library that is being used.

**[ -initiator <text> ] - Initiator Port**

Initiator port that the clustered node uses.

**[ -initiator-side-switch-port <text> ] - Initiator Side Switch Port**

Switch port connected to the clustered node.

**[ -tpgn <integer> ] - Target Port Group Number**

TPGN refers to the target port group to which the target port belongs. A target port group is a set of target ports which share the same LUN access characteristics and failover behaviors.

**[ -port-speed <text> ] - Port Speed**

Port Speed of the specified port.

**[ -path-io-kbps <integer> ] - Kbytes of I/O per second on Path(Rolling Average)**

Rolling average of Kbytes of I/O per second on the library path.

**[ -path-iops <integer> ] - Number of I/O per second on Path(Rolling Average)**

Rolling average of I/O per second on the library path.

**[ -initiator-io-kbps <integer> ] - Kbytes of I/O per second on Initiator(Rolling Average)**

Rolling average of Kbytes of I/O per second on the initiator port.

**[-initiator-iops <integer>] - Number of I/O per second on Initiator(Rolling Average)**

>Rolling average of I/O per second on the initiator port.

**[-target-io-kbps <integer>] - Kbytes of I/O per second to Target(Rolling Average)**

Rolling average of Kbytes of I/O per second on the target port.

**[-target-iops <integer>] - Number of I/O per second to Target(Rolling Average)**

Rolling average of I/O per second on the target port.

**[-target-side-switch-port <text>] - Target Side Switch Port**

Switch port connected to the tape library.

**[-path-link-errors <integer>] - Link Error count on path**

Fibre Channel link error count.

**[-path-quality <integer>] - Percentage of weighted error threshold**

A number representing the threshold of errors that is allowed on the path. Path quality is a weighted error value. When the error weight of a path exceeds the threshold, I/O is routed to a different path.

**[-path-lun-in-use-count <integer>] - Number of LUNs in the in-use state on this path**

Number of LUNs on this path.

**[-initiator-lun-in-use-count <integer>] - Number of LUNs in the in-use state on this initiator**

Number of LUNs on this initiator.

**[-target-lun-in-use-count <integer>] - Number of LUNs in the in-use state on this target**

Number of LUNs on this target.

## Examples

The following example displays the path information for a storage tape library

```
cluster1::> storage tape library path show
Node           Initiator  Target Port          TPGN      Speed
(KB/s)        IOPs
-----  -----  -----  -----  -----
-----  -----
cluster1-01
                3d      50050763124b4d6f      61      4 Gb/S
0            0
cluster1-01
                0b      510a09800000412d      35      4 Gb/S
0            0
cluster1-01
                0b      510a09820000412d      1      4 Gb/S
0            0
3 entries were displayed.
```

## storage tape load-balance modify

Modify the tape load balance configuration

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage tape load-balance modify` command modifies the tape load balance setting for a specified node in the cluster.

### Parameters

#### **-node {<nodename>|local} - Node**

This parameter specifies the node on which the tape load balance setting is to be modified.

#### **[-is-enabled {true|false}] - Is Tape Load Balance Enabled**

This parameter specifies whether tape load balancing is enabled on the node. The default setting is false.

### Examples

The following example modifies the tape load balance setting on node1 in the cluster:

```
cluster1::> storage tape load-balance modify -node node1 -is-enabled true
```

## storage tape load-balance show

Displays the tape load balance configuration

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `storage tape load-balance show` command displays tape load balance settings for each node in the cluster.

### Parameters

#### **{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>,...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

#### **| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

#### **[-node {<nodename>|local}] - Node**

Selects information about tape load balancing for the specified node.

**[-is-enabled {true|false}] - Is Tape Load Balance Enabled**

Selects information about load balance configuration as specified by enabled or disabled setting.

**Examples**

The following example shows the load balance setting for each node in the cluster:

```
cluster1::> storage tape load-balance show

Node           Enabled
-----
node1          false
node2          false
2 entries were displayed.
```

## Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

**LIMITED RIGHTS LEGEND:** Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.