



# **system controller commands**

## **ONTAP 9.3 commands**

NetApp  
February 12, 2024

# Table of Contents

system controller commands	1
system controller show	1
system controller bootmedia show-serial-number	2
system controller bootmedia show	5
system controller clus-flap-threshold show	7
system controller config show-errors	7
system controller config show	8
system controller config pci show-add-on-devices	10
system controller config pci show-hierarchy	13
system controller environment show	16
system controller flash-cache show	18
system controller flash-cache secure-erase run	20
system controller flash-cache secure-erase show	21
system controller fru show-manufacturing-info	22
system controller fru show	25
system controller fru led disable-all	28
system controller fru led enable-all	28
system controller fru led modify	29
system controller fru led show	31
system controller ioxm show	32
system controller location-led modify	34
system controller location-led show	35
system controller memory dimm show	36
system controller nvram-bb-threshold show	38
system controller pci show	39
system controller pcicerr threshold modify	41
system controller pcicerr threshold show	42
system controller platform-capability show	42
system controller service-event delete	43
system controller service-event show	44
system controller sp config show	46
system controller sp upgrade show	48

# system controller commands

## system controller show

Display the controller information

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `system controller show` command displays information about all the controllers in the cluster. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported. By default, the command displays the following information about all the controllers in the cluster:

- Controller name
- System ID
- System serial number
- Controller model name
- Health monitor status

To display more details, use the `-instance` parameter.

### Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed information about all the controllers in the cluster.

**[-node {<nodename>|local}] - Node**

Selects information about the specified controller.

**[-system-id <text>] - System ID**

Selects information about the controller with the specified System ID.

**[-model <text>] - Model Name**

Selects information about the controllers with the specified model name.

**[-part-number <text>] - Part Number**

Selects information about the controllers with the specified part number.

**[-revision <text>] - Revision**

Selects information about the controllers with the specified revision.

**[-serial-number <text>] - Serial Number**

Selects information about the controller with the specified system serial number.

### **[-controller-type <text>] - Controller Type**

Selects information about the controllers with the specified controller type.

### **[-status {ok|ok-with-suppressed|degraded|unreachable|unknown}] - Status**

Selects information about the controllers with the specified health monitor status.

### **[-chassis-id <text>] - Chassis ID**

Selects information about the controllers with the specified chassis ID.

## **Examples**

The below example displays information about all controllers in the cluster.

```
cluster1::> system controller show
      Controller Name      System ID      Serial Number      Model
Status
-----
ok      node1              140733730268652  700001456939      FAS2520
ok      node2              140733730268667  700001456941      FAS2520
2 entries were displayed.
```

The example below displays detailed information about specified controller in the cluster.

```
cluster1::> system controller show -instance -node node1
      Node: node1
      System ID: 140733730268652
      Model Name: FAS2520
      Part Number: 111-01316
      Revision: 21
      Serial Number: 700001456939
      Controller Type: none
      Status: ok
      Chassis ID: 4591227214
```

## **system controller bootmedia show-serial-number**

Display the Boot Media Device serial number

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The system controller bootmedia show-serial-number command displays the Boot Media Device serial number. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported. By default, the command displays the following information about the bootmedia:

- Node name
- Display name
- Serial Number
- Size
- Bootmedia state
- Status

To display more details, use the `-instance` parameter.

## Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed information for all the bootmedia devices.

**[-node {<nodename>|local}] - Node**

Selects the bootmedia device that is present on the specified node.

**[-serial-num <text>] - Serial Number**

Selects the bootmedia devices with the specified serial number.

**[-vendor-id <Hex Integer>] - Vendor ID**

Selects the bootmedia devices with the specified vendor ID.

**[-device-id <Hex Integer>] - Device ID**

Selects the bootmedia devices with the specified device ID.

**[-display-name <text>] - Display Name**

Selects the bootmedia devices with the specified display name.

**[-unique-name <text>] - Unique Name**

Selects the bootmedia device with the specified unique name.

**[-monitor {node-connect|system-connect|system|controller|chassis|cluster-switch|example}] - Health Monitor Name**

Selects the bootmedia devices with the specified health monitor.

**[-usbmon-status {present|not-present}] - Bootmedia Health Monitor**

Selects the bootmedia devices with the specified USBMON status.

### **[-device-state {good|warn|bad}] - Bootmedia State**

Selects the bootmedia devices with the specified device state.

### **[-size <integer>] - Max Memory Size (MB)**

Selects the bootmedia devices with the specified memory size.

### **[-health {ok|ok-with-suppressed|degraded|unreachable|unknown}] - Status**

Selects the bootmedia devices with the specified health monitor status.

## **Examples**

The following example displays the information of the bootmedia devices present in all the nodes in a cluster:

```
cluster1::> system controller bootmedia show-serial-number
```

Node Status	Display Name	Serial Number	(MB)	State
----------------	--------------	---------------	------	-------

-----	-----	-----	-----	-----
-----				

or-12-01	BootMedia/SAMSUNG	S2J4NXAGA08186	122104	good
----------	-------------------	----------------	--------	------

ok

MZVLV128HCGR-00000

BootMedia-2/SAMSUNG	S2J4NXAGA08198	122104	good
---------------------	----------------	--------	------

ok

MZVLV128HCGR-00000

2 entries were displayed.

The following example displays the detailed information about the bootmedia present in a node:

```
cluster1::> system controller bootmedia show-serial-number -instance -node  
node1
```

Node: node1

Vendor ID: 8086

Device ID: 8d02

Display Name: TOSHIBA THNSNJ060GMCU

Unique Name: /dev/ad4s1 (TOSHIBA THNSNJ060GMCU)

Health Monitor Name: controller

Bootmedia Health Monitor: present

Bootmedia State: good

Max memory size(in MB): 16367

Status: ok

Serial number: Y4IS104FTNEW

# system controller bootmedia show

Display the Boot Media Device Health Status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller bootmedia show` command displays details of the bootmedia devices present in all the nodes in a cluster. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported. By default, the command displays the following information about the bootmedia:

- Node name
- Display name
- Vendor ID
- Device ID
- Memory size
- Bootmedia state
- Health monitor status

To display more details, use the `-instance` parameter.

## Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed information for all the bootmedia devices.

**[-node {<nodename>|local}] - Node**

Selects the bootmedia device that is present on the specified node.

**[-serial-num <text>] - Serial Number**

Selects the bootmedia devices with the specified serial number.

**[-vendor-id <Hex Integer>] - Vendor ID**

Selects the bootmedia devices with the specified vendor ID.

**[-device-id <Hex Integer>] - Device ID**

Selects the bootmedia devices with the specified device ID.

**[-display-name <text>] - Display Name**

Selects the bootmedia devices with the specified display name.

**[-unique-name <text>] - Unique Name**

Selects the bootmedia device with the specified unique name.

**[*-monitor {node-connect|system-connect|system|controller|chassis|cluster-switch|example}*]] - Health Monitor Name**

Selects the bootmedia devices with the specified health monitor.

**[*-usbmon-status {present|not-present}*]] - Bootmedia Health Monitor**

Selects the bootmedia devices with the specified USBMON status.

**[*-device-state {good|warn|bad}*]] - Bootmedia State**

Selects the bootmedia devices with the specified device state.

**[*-size <integer>*]] - Max Memory Size (MB)**

Selects the bootmedia devices with the specified memory size.

**[*-health {ok|ok-with-suppressed|degraded|unreachable|unknown}*]] - Status**

Selects the bootmedia devices with the specified health monitor status.

## Examples

The following example displays the information of the bootmedia devices present in all the nodes in a cluster:

```
cluster1::> system controller bootmedia show
Size Bootmedia
Node          Display Name          Vendor ID Device ID      (MB) State
Status
-----
node1         Micron Technology        634        655        1929 good
ok
              0x655
node2         Micron Technology        634        655        1929 good
ok
              0x655
```

The example below displays the detailed information about the bootmedia present in a node.



```
cluster1::> system controller bootmedia show -instance -node node1
Node: node1
    Vendor ID: 634
    Device ID: 655
    Display Name: Micron Technology 0x655
    Unique Name: Micron Technology 0x655 (ad.0)
    Health Monitor Name: controller
    USBMON Health Monitor: present
    Bootmedia State: good
    Max memory size(in MB): 1929
    Status: ok
```

## system controller clus-flap-threshold show

Display the controller cluster port flap threshold

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `system controller clus-flap-threshold show` command allows the display of the threshold for link flapping counts for all nodes. This threshold would be the number of times the cluster port links for a given node can flap (go down) within a polling period before triggering an alert.

## system controller config show-errors

Display configuration errors

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `system controller config show-errors` displays configuration errors.

- node
- description

To display more details, use the `-instance` parameter.

### Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed information for all the PCI devices.

### **[`-node` {<nodename>|local}] - Node**

Displays configuration errors on the specified node.

### **[`-verbose` <true>] - Verbose Output?**

The `-verbose` parameter enables verbose mode, resulting in the display of more detailed output.

### **[`-description` <text>] - Error Description**

Displays the node with the specified configuration error.

## **Examples**

The example below displays configuration errors on all the nodes in the cluster.

```
cluster1::> system controller config show-errors

Configuration Info and Errors for Node: cluster1-01
-----
----
Chelsio T320E 2x10G NIC card (PN X1008A) in slot 1 is not supported on
model FAS3210

Configuration Info and Errors for Node: cluster1-02
-----
----
PCI-E Dual 10/100/1000 Ethernet G20 card (PN X1039A) in slot 2 is not
supported on model FAS3210

cluster1::>

cluster1::> system controller config show-errors -verbose

Configuration Info and Errors for Node: cluster1-01
-----
----
sysconfig: Card in slot 2 (7-1275-0008-46848) is not supported.
sysconfig: slot 12 OK: X2067: Proprietary embedded SAS HBA

cluster1::>
```

## **system controller config show**

Display System Configuration Information

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller config show` command displays system configuration information for the devices present in the controller. To display more details, use the `-instance` parameter.

## Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects the nodes that match this parameter value.

**[-device <text>] - Device**

Selects the configuration information that matches the specified device.

**[-slot <integer>] - Slot Number**

Selects the configuration information that matches the specified slot.

**[-subslot <integer>] - Subslot Number**

Selects the configuration information that matches the specified subslot.

**[-info <text>] - Device Info**

Selects the configuration information that matches the specified device information.

## Examples

The following example displays configuration information for slot 1 of the controller:

```

cluster1::> system controller config show -slot 1

Node: node1
Sub- Device/
Slot slot Information
---- ----
-----
1      - NVRAM10 HSL
        Device Name:      Interconnect HBA: Generic OFED Provider
        Port Name:        ib1a
        Default GID:      fe80:0000:0000:0000:0000:0000:0000:0104
        Base LID:         0x104
        Active MTU:       8192
        Data Rate:        0 Gb/s (8X)
        Link State:       DOWN
        QSFP Vendor:      Amphenol
        QSFP Part Number: 112-00436+A0
        QSFP Type:        Passive Copper 1m ID:00
        QSFP Serial Number: APF16130066875
        QSFP Vendor:      Amphenol
        QSFP Part Number: 112-00436+A0
        QSFP Type:        Passive Copper 1m ID:00
        QSFP Serial Number: APF16130066857

cluster1::>

```

## system controller config pci show-add-on-devices

Display PCI devices in expansion slots

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `system controller config pci show-add-on-devices` command displays information about the PCIe devices in I/O expansion slots. The command displays the following information about the PCIe devices:

- Node
- Model
- Type
- Slot
- Device
- Vendor
- Sub-device ID

To display more details, use the `-instance` parameter.

## Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**[-instance ] }**

Displays detailed information about PCI devices.

**[-node {<nodename>|local}] - Node**

Selects the PCI devices that are present in the specified node.

**[-model <text>] - Model String**

Selects the PCI devices that are present on the system with the specified model name.

**[-type <integer>] - Device Type**

Selects the PCI devices with the specified device type.

**[-slot-and-sub <text>] - PCI Slot Number**

Selects the PCI devices present in the specified slot or slot-subslot combination.

**[-device <text>] - Device**

Selects the PCI devices with the specified device ID.

**[-vendor <text>] - Vendor Number**

Selects the PCI devices with the specified vendor ID.

**[-sub-device-id <integer>] - Sub Device ID**

Selects the PCI devices with the specified sub-device ID.

## Examples

The example below displays information about PCI devices found in I/O expansion slots of all the nodes in the cluster.

```
cluster1::> system controller config pci show-add-on-devices
```

Node ID	Model	Slot	Type	Device	Vendor	Sub-Device
---------	-------	------	------	--------	--------	------------

-----						
-----						

cluster1-01	FAS6240					
		6	7	0x2532	0x1077	
10						
		5	1	0x1527	0x8086	
0						
		2	7	0x6732	0x15B3	
0						
		3	1	0x8030	0x1077	
0						
		1	2	0x8001	0x11F8	
0						
		15	1	0x10FB	0x8086	
0						
		13	1	0x150E	0x8086	
1						
		7	1	0x1528	0x8086	
0						

cluster1-02	FAS6240					
		6	7	0x2532	0x1077	
10						
		5	1	0x1527	0x8086	
0						
		2	7	0x6732	0x15B3	
0						
		3	1	0x8030	0x1077	
0						
		1	2	0x8001	0x11F8	
0						
		15	1	0x10FB	0x8086	
0						
		13	1	0x150E	0x8086	
1						
		7	1	0x1528	0x8086	
0						

16 entries were displayed.

```
cluster1::>
```

# system controller config pci show-hierarchy

Display PCI hierarchy

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller config pci show-hierarchy` command displays the PCI Hierarchy of all PCI devices found in a controller. The command displays the following information about the PCI devices:

- Node
- Level
- Device
- Link Capability
- Link Status

To display more details, use the `-instance` parameter.

## Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed information for PCI devices.

**[-node {<nodename>|local}] - Node**

Displays the PCI hierarchy of the specified node.

**[-level <integer>] - PCI Device Level**

Displays the PCI devices that match the specified level within the PCI hierarchy.

**[-pci-device <text>] - PCI Device**

Displays the PCI devices that match the specified device description.

**[-link-cap <text>] - Link Capability**

Displays the PCI devices that match the specified link capability.

**[-link-status <text>] - Link Status**

Displays the PCI devices that match the specified link status.

## Examples

The example below displays the PCI hierarchy for all of the nodes in the cluster.

```
cluster1:> system controller config pci show-hierarchy
PCI Hierarchy
```

Node: cluster1-01

Level	Device	Link
-----	-----	-----
1	Br[3721](0,3,0): PCI Device 8086:3721 on Controller	
	LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(3),L1(6),Port(68))	
	LinkStatus(LkSp(2),LkWd(4),DLAct),	
2	Dv[8001](1,0,0): PMC SAS adapter on Controller	
	LinkCap(MaxLkSp(2),MaxLkWd(8),ASPM(3),L0(3),L1(6),Port(68))	
	LinkStatus(LkSp(2),LkWd(4),SClk),	
1	Br[3722](0,4,0): PCI Device 8086:3722 on Controller	
	LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(3),L1(6),Port(68))	
	LinkStatus(LkSp(1),LkWd(4),DLAct),	
2	Dv[6274](2,0,0): PCI Device 15b3:6274 on Controller	
	LinkCap(MaxLkSp(1),MaxLkWd(8),ASPM(1),L0(7),L1(7),Port(68))	
	LinkStatus(LkSp(1),LkWd(4)),	
1	Br[3723](0,5,0): PCI Device 8086:3723 on Controller	
	LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(3),L1(6),Port(68))	
	LinkStatus(LkSp(1),LkWd(0)),	
1	Br[3b42](0,28,0): PCI Device 8086:3b42 on Controller	
	LinkCap(MaxLkSp(1),MaxLkWd(4),ASPM(3),L0(4),L1(6),Port(68))	
	LinkStatus(LkSp(1),LkWd(4),SClk,DLAct),	
2	Dv[150e](4,0,0): Intel 1G NIC on Controller	
	LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(6),L1(6),Port(68))	
	LinkStatus(LkSp(1),LkWd(4),SClk),	
2	Dv[150e](4,0,1): Intel 1G NIC on Controller	
	LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(6),L1(6),Port(68))	
	LinkStatus(LkSp(1),LkWd(4),SClk),	
2	Dv[150e](4,0,2): Intel 1G NIC on Controller	
	LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(6),L1(6),Port(68))	
	LinkStatus(LkSp(1),LkWd(4),SClk),	
2	Dv[150e](4,0,3): Intel 1G NIC on Controller	
	LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(6),L1(6),Port(68))	
	LinkStatus(LkSp(1),LkWd(4),SClk),	
1	Br[3b4a](0,28,4): PCI Device 8086:3b4a on Controller	



```

LinkCap(MaxLkSp(1),MaxLkWd(1),ASPM(3),L0(4),L1(6),Port(68))
    LinkStatus(LkSp(1),LkWd(1),SClk,DlAct),
2    Dv[10d3](5,0,0): Intel 1G NIC on Controller

LinkCap(MaxLkSp(1),MaxLkWd(1),ASPM(3),L0(1),L1(6),Port(68))
    LinkStatus(LkSp(1),LkWd(1),SClk),
1    Br[3b4e](0,28,6): PCI Device 8086:3b4e on Controller

LinkCap(MaxLkSp(1),MaxLkWd(1),ASPM(3),L0(4),L1(6),Port(68))
    LinkStatus(LkSp(1),LkWd(1),SClk,DlAct),
2    Dv[10d3](7,0,0): Intel 1G NIC on Controller

LinkCap(MaxLkSp(1),MaxLkWd(1),ASPM(3),L0(1),L1(6),Port(68))
    LinkStatus(LkSp(1),LkWd(1),SClk),

Node: cluster1-02

Level Device      Link
-----
1    Br[3721](0,3,0): PCI Device 8086:3721 on Controller

LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(3),L1(6),Port(68))
    LinkStatus(LkSp(2),LkWd(4),DlAct),
2    Dv[8001](1,0,0): PMC SAS adapter on Controller

LinkCap(MaxLkSp(2),MaxLkWd(8),ASPM(3),L0(3),L1(6),Port(68))
    LinkStatus(LkSp(2),LkWd(4),SClk),
1    Br[3722](0,4,0): PCI Device 8086:3722 on Controller

LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(3),L1(6),Port(68))
    LinkStatus(LkSp(1),LkWd(4),DlAct),
2    Dv[6274](2,0,0): PCI Device 15b3:6274 on Controller

LinkCap(MaxLkSp(1),MaxLkWd(8),ASPM(1),L0(7),L1(7),Port(68))
    LinkStatus(LkSp(1),LkWd(4)),
1    Br[3723](0,5,0): PCI Device 8086:3723 on Controller

LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(3),L1(6),Port(68))
    LinkStatus(LkSp(1),LkWd(0)),
1    Br[3b42](0,28,0): PCI Device 8086:3b42 on Controller

LinkCap(MaxLkSp(1),MaxLkWd(4),ASPM(3),L0(4),L1(6),Port(68))
    LinkStatus(LkSp(1),LkWd(4),SClk,DlAct),
2    Dv[150e](4,0,0): Intel 1G NIC on Controller

```

```

LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(6),L1(6),Port(68))
      LinkStatus(LkSp(1),LkWd(4),SClk),
2      Dv[150e](4,0,1): Intel 1G NIC on Controller

LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(6),L1(6),Port(68))
      LinkStatus(LkSp(1),LkWd(4),SClk),
2      Dv[150e](4,0,2): Intel 1G NIC on Controller

LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(6),L1(6),Port(68))
      LinkStatus(LkSp(1),LkWd(4),SClk),
2      Dv[150e](4,0,3): Intel 1G NIC on Controller

LinkCap(MaxLkSp(2),MaxLkWd(4),ASPM(3),L0(6),L1(6),Port(68))
      LinkStatus(LkSp(1),LkWd(4),SClk),
1      Br[3b4a](0,28,4): PCI Device 8086:3b4a on Controller

LinkCap(MaxLkSp(1),MaxLkWd(1),ASPM(3),L0(4),L1(6),Port(68))
      LinkStatus(LkSp(1),LkWd(1),SClk,DlAct),
2      Dv[10d3](5,0,0): Intel 1G NIC on Controller

LinkCap(MaxLkSp(1),MaxLkWd(1),ASPM(3),L0(1),L1(6),Port(68))
      LinkStatus(LkSp(1),LkWd(1),SClk),
1      Br[3b4e](0,28,6): PCI Device 8086:3b4e on Controller

LinkCap(MaxLkSp(1),MaxLkWd(1),ASPM(3),L0(4),L1(6),Port(68))
      LinkStatus(LkSp(1),LkWd(1),SClk,DlAct),
2      Dv[10d3](7,0,0): Intel 1G NIC on Controller

LinkCap(MaxLkSp(1),MaxLkWd(1),ASPM(3),L0(1),L1(6),Port(68))
      LinkStatus(LkSp(1),LkWd(1),SClk),
28 entries were displayed.
cluster::>

```

## system controller environment show

Display the FRUs in the controller

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `system controller environment show` displays information about all environment FRUs in the cluster. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported. By default, the command displays the following information about the environment FRUs in the cluster:

- Node

- FRU name
- FRU state

To display more details, use the `-instance` parameter.

## Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**[-instance ] }**

Displays detailed information about the environment FRUs.

**[-node {<nodename>|local}] - Node**

Selects information about all the environment FRUs that the specified node owns.

**[-serial-number <text>] - FRU Serial Number**

Selects information about all the environment FRUs with the specified serial number.

**[-fru-name <text>] - FRU Name**

Selects information about the environment FRU with the specified FRU name.

**[-type {controller|psu|fan|dimm|bootmedia|ioxm|nvram|nvdim}] - FRU Type**

Selects information about all the environment FRUs with the specified FRU type.

**[-name <text>] - Name**

Selects information about all the environment FRUs with the specified unique name.

**[-state <text>] - FRU State**

Selects information about all the environment FRUs with the specified FRU state.

**[-status {ok|ok-with-suppressed|degraded|unreachable|unknown}] - Status**

Selects information about all the environment FRUs with the specified health monitor status.

**[-display-name <text>] - Display Name for the FRU**

Selects information about all the environment FRUs with the specified display name.

**[-monitor {node-connect|system-connect|system|controller|chassis|cluster-switch|example}] - Monitor Name**

Selects information about all the environment FRUs with the specified monitor.

**[-model <text>] - Model Type**

Selects information about all the environment FRUs with the specified FRU model.

**[-shared {shared|not\_shared}] - Shared Resource**

Selects information about all the environment FRUs with the specified sharing type.

**[-chassis-id <text>] - Chassis ID**

Selects information about all the environment FRUs in the specified chassis.

### **[-additional-info <text>] - Additional Information About the FRU**

Selects information about all the environment FRU with specified additional information.

### **[-seq-state-cnt <integer>] - Count of Same State**

Selects information about all the environment FRU with specified sequential state count.

## **Examples**

The following example displays information about all major environment FRUs in the cluster:

```
cluster1::> system controller environment show
```

Node	FRU Name	State
-----	-----	-----
node1	PSU1 FRU	GOOD
node1	PSU2 FRU	GOOD
node2	PSU1 FRU	GOOD
node2	PSU2 FRU	GOOD

The following example displays detailed information about a specific environment FRU:

```
cluster1::> system controller environment show -node node1 -fru-name "PSU1
FRU" -instance
Node: node1
```

```
FRU Serial Number: XXT122737891
```

```
FRU Name: PSU1 FRU
```

```
FRU Type: psu
```

```
Name: XXT122737891
```

```
FRU State: GOOD
```

```
Status: ok
```

```
Display Name for the FRU: PSU1 FRU
```

```
Monitor Name: controller
```

```
Model Type: none
```

```
Shared Resource: shared
```

```
Chassis ID: 4591227214
```

```
Additional Information About the FRU: Part Number: 114-00065+A0
```

```
Revision: 020F
```

```
Manufacturer: NetApp
```

```
FRU Name: PSU
```

## **system controller flash-cache show**

Display the Flash Cache device status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller flash-cache show` command displays the current Flash Cache device information.

## Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

If this parameter is specified, only status information for the matching node is displayed.

**[-slot <integer>] - Slot**

If this parameter is specified, only status information for the matching slot is displayed.

**[-subslot <integer>] - Subslot**

If this parameter is specified, only status information for the matching subslot is displayed.

**[-slot-string <text>] - Slot String**

If this parameter is specified, only status information for the matching slot is displayed. Format can be slot or slot-subslot.

**[-device-state**

**{ok|erasing|erased|failed|removed|online|offline\_failed|degraded|offline\_threshold}] - Device State**

If this parameter is specified, only status information for the matching device-state is displayed.

**[-model-number <text>] - Model Number**

If this parameter is specified, only status information for the matching model-number is displayed.

**[-part-number <text>] - Part Number**

If this parameter is specified, only status information for the matching part-number is displayed.

**[-serial-number <text>] - Serial Number**

If this parameter is specified, only status information for the matching serial-number is displayed.

**[-firmware-version <text>] - Firmware Version**

If this parameter is specified, only status information for the matching firmware-version is displayed.

**[-firmware-file <text>] - Firmware Filename**

If this parameter is specified, firmware-file is the base name of the firmware file located in `disk_fw` to update the device firmware.

**[-hardware-revision <text>] - Hardware Revision**

If this parameter is specified, only status information for the matching hardware-revision is displayed.

**[-capacity <integer>] - Capacity**

If this parameter is specified, only status information for the matching capacity is displayed.

**[-last-change-time <integer>] - Time Last State Change**

If this parameter is specified, only status information for the matching last-change-time is displayed.

**[-service-time <integer>] - Service Time**

If this parameter is specified, only status information for the matching service-time is displayed.

**[-percent-online <integer>] - Percent Online**

If this parameter is specified, only status information for the matching percent-online is displayed.

**[-average-erase-cycle-count <integer>] - Avg Erase Cycle Count**

If this parameter is specified, only status information for the matching average-erase-cycle-count is displayed.

**[-threshold-profile <text>] - Threshold Profile**

If this parameter is specified, only status information for the matching threshold-profile is displayed.

## Examples

The following example displays the current state of all Flash Cache devices:

```
cluster1::> system controller flash-cache show
```

Device	Model	Part	Serial	Firmware	Capacity
Node	Slot	Number	Number	Version	(GB)
State					
-----					
node1					
	6-1	X9172A	119-00209	A22P7061550000004	NA00 4096 ok
	6-2	X9170A	119-00207	A22P5061550000135	NA00 1024 ok
node2					
	6-1	X9172A	119-00209	A22P7061550000007	NA00 4096 ok
	6-2	X9170A	119-00207	A22P5061550000091	NA00 1024 ok

4 entries were displayed.

## system controller flash-cache secure-erase run

Perform a secure-erase operation on the targeted devices

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller flash-cache secure-erase run` command securely erases the given Flash Cache device.

## Parameters

**-node {<nodename>|local} - Node**

Selects the node of the specified Flash Cache devices.

**-slot <text> - Slot**

Selects the slot or slot-subslot of the specified Flash Cache devices.

## Examples

The following example securely erases the selected Flash Cache device:

```
cluster1::> system controller flash-cache secure-erase -node node1 -slot 0-1
```

## system controller flash-cache secure-erase show

Display the Flash Cache card status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller flash-cache secure-erase show` command displays the current Flash Cache device secure-erase status.

## Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

If this parameter is specified, only status information for the matching node is displayed.

**[-slot <text>] - Slot**

If this parameter is specified, only status information for the matching slot is displayed. Slot can have a format of slot or slot-subslot.

### **[*-device-state* {*ok|erasing|erased|failed|removed*}] - Device State**

If this parameter is specified, only status information for the matching device-state is displayed.

## **Examples**

The following example displays the current state of all the Flash Cache devices:

```
cluster1::> system controller flash-cache secure-erase show
Node          Slot Device State
-----
node1
        6-1  ok
        6-2  erasing
node2
        6-1  erased
        6-2  ok
4 entries were displayed.
```

## **system controller fru show-manufacturing-info**

Display manufacturing information of FRUs

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `system controller fru show-manufacturing-info` command displays manufacturing information for field replaceable units (FRUs) installed in the system. The information includes FRU-description, serial number, part number, and revision number. To display more details, use the `-instance` parameter.

### **Parameters**

**{ [*-fields* <fieldname>,...]**

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use '`-fields ?`' to display the fields to specify.

**| [*-instance* ] }**

Displays detailed information about the installed FRUs in the system.

**[*-node* {<nodename>|local}] - Node**

Selects a specific node's installed FRUs.

**[*-system-sn* <text>] - System Serial Number**

Selects information about installed FRUs with the specified system serial number.



**[-model-name <text>] - Model Name**

Selects information about installed FRUs with the specified model name.

**[-system-id <text>] - System ID**

Selects information about installed FRUs with the specified system ID.

**[-kernel-version <text>] - Kernel Version**

Selects information about installed FRUs with the specified kernel version.

**[-firmware-release <text>] - Firmware Release**

Selects information about installed FRUs with the specified firmware release.

**[-description <text>] - FRU Description**

Selects information about installed FRUs with the specified FRU description.

**[-fru-subtype <text>] - FRU Sub-type**

Selects information about the FRU with the specified FRU subtype.

**[-serial-number <text>] - FRU Serial Number**

Selects information about the FRU with the specified serial number.

**[-part-number <text>] - FRU Part Number**

Selects information about the FRU with the specified part number.

**[-revision <text>] - FRU Revision of Part Number**

Selects information about the FRU with the specified revision.

**[-manufacturer <text>] - FRU Manufacturer**

Selects information about the FRU with the specified manufacturer.

**[-manufacture-date <text>] - FRU Manufacturing Date**

Selects information about the FRU with the specified manufacture date.

**[-product-id <text>] - FRU Product Identifier**

Selects information about the FRU with the specified product ID.

**[-firmware-version <text>] - FRU Firmware Version**

Selects information about the FRU with the specified firmware version.

## Examples

The following example displays all installed FRUs in the system:

```
cluster1::> system controller fru show-manufacturing-info
Node: platsw-lodi-1-01
System Serial Number: 791541000047
      Model Name: FAS9040
      System ID: 0537024373
```

Firmware release: 10.0X18

Kernel Version: NetApp Release sysMman\_3887886\_1608151712: Mon Aug

15

15:54:00 PDT 2016

FRU Description Rev.	FRU Serial Number	FRU Part Number	FRU
-----	-----	-----	
Mother Board	031537000390	111-02419	40
Chassis	031536000252	111-02392	40
DIMM-1	CE-01-1510-02A8DC73	SHB722G4LML23P2-SB	-
DIMM-3	CE-01-1510-02A8DCCC	SHB722G4LML23P2-SB	-
DIMM-8	CE-01-1510-02A8DE54	SHB722G4LML23P2-SB	-
DIMM-9	CE-01-1510-02A8DE1C	SHB722G4LML23P2-SB	-
DIMM-11	CE-01-1510-02A8DF42	SHB722G4LML23P2-SB	-
DIMM-16	CE-01-1510-02A8DD9B	SHB722G4LML23P2-SB	-
FAN1	031534001263	441-00058	40
FAN2	031534001292	441-00058	40
FAN3	031534001213	441-00058	40
PSU1	PSD092153200591	114-00146	40
PSU3	PSD092153200700	114-00146	40
mSATA boot0	1439100B02C3	-	MU03
1/10 Gigabit Ethernet Controller IX4-T	031538000121	111-02399	40
QLogic 8324 10-Gigabit Ethernet Controller	031535000664	111-02397	40
NVRAM10	031537000846	111-02394	40
NVRAM10 BATT	31534000932	NetApp, Inc.	111-
02591			
NVRAM10 DIMM	CE-01-1510-02A8DC03	SHB722G4LML23P2-SB	-
PMC-Sierra PM8072 (111-02396)	031537000246	111-02396	41
PMC-Sierra PM8072 (111-02396)	031537000246	111-02396	41
PMC-Sierra PM8072 (111-02396)	031537000246	111-02396	41
PMC-Sierra PM8072 (111-02396)	031537000246	111-02396	41
PMC-Sierra PM8072 (111-02396)	031537000179	111-02396	41
Disk Serial Number	PNHH1J0B	X421_HCOBD450A10	-
Disk Serial Number	PNHH2BKB	X421_HCOBD450A10	-
Disk Serial Number	PNHJPZ8B	X421_HCOBD450A10	-
Disk Serial Number	PNHG6SKB	X421_HCOBD450A10	-
Disk Serial Number	PNHKJYTB	X421_HCOBD450A10	-
Disk Serial Number	PNHSVMEY	X421_HCOBD450A10	-
Disk Serial Number	PNHT8KWY	X421_HCOBD450A10	-
Disk Serial Number	PNHSVL0Y	X421_HCOBD450A10	-
Disk Serial Number	PNHG5RHB	X421_HCOBD450A10	-
Disk Serial Number	PNHEXLWB	X421_HCOBD450A10	-
Disk Serial Number	PNHT8LJY	X421_HCOBD450A10	-
Disk Serial Number	PNHSVKZY	X421_HCOBD450A10	-
PMC-Sierra PM8072 (111-02396)	031537000179	111-02396	41

PMC-Sierra PM8072 (111-02396) 031537000179	111-02396	41
PMC-Sierra PM8072 (111-02396) 031537000179	111-02396	41
DS2246 6000113106	0190	-
DS2246-Pwr-Supply XXT111825308	114-00065+A0	9C
DS2246-Pwr-Supply XXT111825314	114-00065+A0	9C
DS2246-MODULE 8000675532	111-00690+A3	23
DS2246-MODULE 8000751790	111-00690+A3	23
DS2246-CABLE 512130075	112-00430+A0	-
DS2246-CABLE -	-	-
DS2246-CABLE 512130118	112-00430+A0	-
DS2246-CABLE -	-	-

49 entries were displayed.

## system controller fru show

### Display Information About the FRUs in the Controller

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `system controller fru show` command displays information about all the controller specific Field Replaceable Units (FRUs) in the cluster. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported. By default, the command displays the following information about all the FRUs in the cluster:

- Node
- FRU name
- Health monitor subsystem
- Health monitor status

To display more details, use the `-instance` parameter.

### Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed information about the controller specific FRUs in the cluster.

**[-node {<nodename>|local}] - Node**

Selects information about the FRUs in the specified node.

**[-subsystem <Subsystem>] - Subsystem**

Selects information about the FRUs of the specified subsystem.

**`[-serial-number <text>] - FRU Serial Number`**

Selects information about the FRU with the specified serial number.

**`[-fru-name <text>] - Name of the FRU`**

Selects information about the FRU with the specified FRU name.

**`[-type {controller|psu|fan|dimm|bootmedia|ioxm|nvram|nvdim}] - FRU Type`**

Selects information about the FRU with the specified FRU type.

**`[-name <text>] - FRU Name`**

Selects information about the FRU with the specified unique name.

**`[-state <text>] - FRU State`**

Selects information about the FRU with the specified state.

**`[-status {ok|ok-with-suppressed|degraded|unreachable|unknown}] - Status`**

Selects information about the FRU with the specified health monitor status.

**`[-display-name <text>] - Display Name for the Fru`**

Selects information about the FRU with the specified display name.

**`[-monitor {node-connect|system-connect|system|controller|chassis|cluster-switch|example}] - Monitor Name`**

Selects information about the FRU with the specified health monitor type.

**`[-model <text>] - Model Type`**

Selects information about the FRU with the specified model.

**`[-chassis-id <text>] - Chassis ID`**

Selects information about the FRU with the specified chassis ID.

**`[-location <text>] - Location of the FRU`**

Selects information about the FRU with the specified FRU location.

**`[-additional-info <text>] - Additional Information About the FRU`**

Selects information about the FRU with the specified additional information.

## Examples

The example below displays information about all controller specific FRUs in the cluster.

```

cluster1::> system controller fru show
      Node          FRU Name          Subsystem
Status -----
-----
ok      node1          PSU1 FRU          Environment
ok      node1          PSU2 FRU          Environment
ok      node1          DIMM-NV1          Memory
ok      node1          DIMM-1          Memory
ok      node1          Micron Technology 0x655 (ad.0) Motherboard
ok
node2      PSU1 FRU          Environment      ok
      node2          PSU2 FRU          Environment
ok      node2          DIMM-NV1          Memory
ok      node2          DIMM-1          Memory
ok      node2          Micron Technology 0x655 (ad.0) Motherboard
ok
      10 entries were displayed.

```

The example below displays information about the specific FRU.

```

cluster1::> system controller fru show -instance -serial-number AD-01-1306-2EA01E9A
      Node: node1
      Subsystem: Memory
      FRU Serial Number: AD-01-1306-2EA01E9A
      Name of the FRU: DIMM-1
      FRU Type: dimm
      FRU Name: DIMM-1
      FRU State: ok
      Status: ok
      Display Name for the Fru: DIMM-1
      Monitor Name: controller
      Model Type: none
      Chassis ID: 4591227214
      Location of the FRU: Memory Slot: 1
      Additional Information About the FRU: Part No: HMT82GV7MMR4A-H9

```

# system controller fru led disable-all

Turn off all the LEDs Data Ontap has lit

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `system controller fru led disable-all` command turns off all the controller and IOXM FRU fault LEDs.

A FRU (Field Replaceable Unit) is any piece of the system that is designed to be easily and safely replaced by a field technician.

Both the controller and IOXM FRUs have a number of internal FRUs for which there are corresponding fault LEDs. In addition, there is a summary FRU fault LED on the external face-plate of both the controller and IOXM; labeled with a "!". A summary fault LED will be on when any of the internal FRU fault LEDs are on. Only the controller and IOXM internal FRU fault LEDs can be controlled by the end-user. The summary fault LEDs are turned on and off based on the simple policy described above. If you want to turn off the summary fault LED, you must turn off all internal FRU fault LEDs.

All FRU fault LEDs are amber in color. However, not all amber LEDs in the system are FRU fault LEDs. Externally visible fault LEDs are labeled with a "!" and internal FRU fault LEDs remain on, even when the controller or IOXM is removed from the chassis. In addition, internal FRU fault LEDs will remain on until explicitly turned off by the end-user, even after a FRU has been replaced.

FRUs are identified by a FRU ID and slot tuple. FRU IDs include: DIMMs, cards in PCI slots, boot media devices, NV batteries and coin cell batteries. For each FRU ID, the FRUs are numbered 1 through N, where N is the number of FRUs of that particular type that exist in the controller or IOXM. Both controller and IOXM have a FRU map label for use in physically locating internal FRUs. The FRU ID/slot tuple used by the [system controller fru led show](#) command matches that specified on the FRU map label.

## Examples

Turn off all FRU fault LEDs.

```
cluster1::*> system controller fru led disable-all
14 entries were modified.
```

## Related Links

- [system controller fru led show](#)

# system controller fru led enable-all

Light all the LEDs

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `system controller fru led enable-all` command turns on all the controller and IOXM FRU fault LEDs.

A FRU (Field Replaceable Unit) is any piece of the system that is designed to be easily and safely replaced by a field technician.

Both the controller and IOXM FRUs have a number of internal FRUs for which there are corresponding fault LEDs. In addition, there is a summary FRU fault LED on the external face-plate of both the controller and IOXM; labeled with a "!". A summary fault LED will be on when any of the internal FRU fault LEDs are on. Only the controller and IOXM internal FRU fault LEDs can be controlled by the end-user. The summary fault LEDs are turned on and off based on the simple policy described above. If you want to turn off the summary fault LED, you must turn off all internal FRU fault LEDs.

All FRU fault LEDs are amber in color. However, not all amber LEDs in the system are FRU fault LEDs. Externally visible fault LEDs are labeled with a "!" and internal FRU fault LEDs remain on, even when the controller or IOXM is removed from the chassis. In addition, internal FRU fault LEDs will remain on until explicitly turned off by the end-user, even after a FRU has been replaced.

FRUs are identified by a FRU ID and slot tuple. FRU IDs include: DIMMs, cards in PCI slots, boot media devices, NV batteries and coin cell batteries. For each FRU ID, the FRUs are numbered 1 through N, where N is the number of FRUs of that particular type that exist in the controller or IOXM. Both controller and IOXM have a FRU map label for use in physically locating internal FRUs. The FRU ID/slot tuple used by the [system controller fru led show](#) command matches that specified on the FRU map label.

## Examples

Turn on all FRU fault LEDs.

```
cluster1::*> system controller fru led enable-all
14 entries were modified.
```

## Related Links

- [system controller fru led show](#)

## system controller fru led modify

Modify the status of FRU LEDs

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `system controller fru led modify` command modifies the current state of the controller and IOXM FRU fault LEDs.

A FRU (Field Replaceable Unit) is any piece of the system that is designed to be easily and safely replaced by a field technician.

Both the controller and IOXM FRUs have a number of internal FRUs for which there are corresponding fault LEDs. In addition, there is a summary FRU fault LED on the external face-plate of both the controller and IOXM; labeled with a "!". A summary fault LED will be on when any of the internal FRU fault LEDs are on. Only the controller and IOXM internal FRU fault LEDs can be controlled by the end-user. The summary fault LEDs are turned on and off based on the simple policy described above. If you want to turn off the summary fault LED, you must turn off all internal FRU fault LEDs.

All FRU fault LEDs are amber in color. However, not all amber LEDs in the system are FRU fault LEDs. Externally visible fault LEDs are labeled with a "!" and internal FRU fault LEDs remain on, even when the controller or IOXM is removed from the chassis. In addition, internal FRU fault LEDs will remain on until explicitly turned off by the end-user, even after a FRU has been replaced.

FRUs are identified by a FRU ID and slot tuple. FRU IDs include: DIMMs, cards in PCI slots, boot media devices, NV batteries and coin cell batteries. For each FRU ID, the FRUs are numbered 1 through N, where N is the number of FRUs of that particular type that exist in the controller or IOXM. Both controller and IOXM have a FRU map label for use in physically locating internal FRUs. The FRU ID/slot tuple used by the [system controller fru led show](#) command matches that specified on the FRU map label.

## Parameters

**-node {<nodename>|local} - Node (privilege: advanced)**

Selects FRU fault LEDs on the specified nodes.

**-fru-id <FRU LED key> - FRU ID (privilege: advanced)**

Selects the FRU fault LEDs that match the specified FRU type.

**-fru-slot <integer> - FRU Slot (privilege: advanced)**

Selects the FRU fault LEDs that match the specified slot.

**[-fru-state {on|off|unknown}] - FRU State (privilege: advanced)**

Specifies the target state for the FRU fault LED.

## Examples

Turn off DIMM 3's FRU fault LED.

```
cluster1::*> system controller fru led modify -node node1 -fru-id dimm
-fru-slot 3 -fru-state on
```

The example below turns on all PCI FRU fault LEDs.

```
cluster1::*> system controller led modify -node node1 -fru-id pci -fru
-slot * -fru-state on
```

## Related Links

- [system controller fru led show](#)



# system controller fru led show

Display the status of FRU LEDs

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

## Description

The `system controller fru led show` command displays information about the current state of the controller and IOXM FRU fault LEDs.

A FRU (Field Replaceable Unit) is any piece of the system that is designed to be easily and safely replaced by a field technician.

Both the controller and IOXM FRUs have a number of internal FRUs for which there are corresponding fault LEDs. In addition, there is a summary FRU fault LED on the external face-plate of both the controller and IOXM; labeled with a "!". A summary fault LED will be on when any of the internal FRU fault LEDs are on.

All FRU fault LEDs are amber in color. However, not all amber LEDs in the system are FRU fault LEDs. Externally visible fault LEDs are labeled with a "!" and internal FRU fault LEDs remain on, even when the controller or IOXM is removed from the chassis.

FRUs are identified by a FRU ID and slot tuple. FRU IDs include: DIMMs, cards in PCI slots, boot media devices, NV batteries and coin cell batteries. For each FRU ID, the FRUs are numbered 1 through N, where N is the number of FRUs of that particular type that exist in the controller or IOXM. Both controller and IOXM have a FRU map label for use in physically locating internal FRUs. The FRU ID/slot tuple used by the `system controller fru led show` command matches that specified on the FRU map label.

## Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `-fields ?` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node (privilege: advanced)**

Selects FRU fault LEDs on the specified nodes.

**[-fru-id <FRU LED key>] - FRU ID (privilege: advanced)**

Selects the FRU fault LEDs that match the specified FRU type.

**[-fru-slot <integer>] - FRU Slot (privilege: advanced)**

Selects the FRU fault LEDs that match the specified slot.

**[-fru-bay <text>] - FRU Bay (privilege: advanced)**

Selects the FRU fault LEDs that match the specified bay.

### **[-fru-state {on|off|unknown}] - FRU State (privilege: advanced)**

Selects the FRU fault LEDs that match the specified status.

### **[-lit-by <text>] - Lit By (privilege: advanced)**

Selects the FRU fault LEDs that were lit by the specified source.

## **Examples**

List the current state of all FRU fault LEDs.

```
cluster1::*> system controller fru led show
```

Node	FRU Type	Bay	Slot	State	Lit By
host1	controller	A	1	on	SP
	ioxm	B	1	off	-
	pci	-	1	off	-
	pci	-	2	off	-
	pci	-	3	off	-
	pci	-	4	off	-
	pci	-	5	off	-
	pci	-	6	off	-
	dimmm-nv	-	1	off	-
	dimmm-nv	-	2	off	-
	dimmm	-	1	off	-
	dimmm	-	2	off	-
	dimmm	-	3	off	-
	dimmm	-	4	off	-
	identify	-	1	off	-

5 entries were displayed.

The example below displays the status of only a specific FRU.

```
cluster1::*> system controller fru led show -node host1 -fru-id controller -fru-slot 1
```

Node	FRU Type	Bay	Slot	State	Lit By
host1	controller	A	1	off	-

## **system controller ioxm show**

Displays IOXM Device Health Status

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller ioxm show` command displays the details of the IO expansion modules (IOXMs) that are connected to the nodes in a cluster. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported. By default, the command displays the following information about the IOXMs:

- Node name
- Display name
- Is IOXM present?
- Power status
- Health monitor status

To display more details, use the `-instance` parameter.

## Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed information for all the IOXMs.

**[-node {<nodename>|local}] - Node**

Selects the IOXM that is connected to the specified node.

**[-chassis-config {c-i|c-c|c-b}] - Controller-IOXM or Controller-Controller or Controller-Blank**

Selects the IOXMs with the specified chassis configuration.

**[-is-present {present|not-present}] - IOXM Presence**

Selects the IOXMs that are connected and detected (`present`) or connected but not detected (`not-present`).

**[-power {good|bad}] - Power to IOXM**

Selects the IOXMs with the specified power state.

**[-display-name <text>] - Display Name**

Selects the IOXMs with the specified display name.

**[-unique-name <text>] - Unique Name**

Selects the IOXM with the specified unique name.

**[-monitor {node-connect|system-connect|system|controller|chassis|cluster-switch|example}] - Health Monitor Name**

Selects the IOXMs with the specified health monitor.

**[-status {ok|ok-with-suppressed|degraded|unreachable|unknown}] - IOXM Health**

Selects the IOXMs with the specified health monitor status.

## Examples

The example below displays the information of all the IOXMs that are connected to the nodes in a cluster.

```
cluster1::> system controller ioxm show
```

Node	Display Name	Is-Present?	Power	Status
node1	IOXM	present	good	ok
node2	IOXM	present	good	ok

The example below displays detailed information of an IOXM that is connected to a node.

```
cluster1::> system controller ioxm show -instance -node node1
Node: node1
Controller-IOXM or Controller-Controller or Controller-Blank: c-i
  IOXM Presence: present
  Power to IOXM: good
  Display Name: node1/IOXM
  Unique Name: 8006459930
Health Monitor Name: controller
  IOXM Health: ok
```

## system controller location-led modify

Modify the location LED state of a controller

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `system controller location-led modify` command modifies the current state of the location LED. When lit, the location LED can help you find the controller in the data center.

There is a blue location LED on every controller and on the front of the chassis. When you turn on the location LED for either controller, the chassis location LED automatically turns on. When both controller location LEDs are off, the chassis location LED automatically turns off.

After the location LED is turned on, it stays illuminated for 30 minutes and then automatically shuts off.

### Parameters

**-node {<nodename>|local} - Node**

Selects the location LED on the specified filers.

### **`[-state {on|off}] - LED State`**

Modifies the state of the location LED on the filer.

## **Examples**

The following example turns on the location LED:

```
cluster1::*> system controller location-led modify -node node1 -state on
```

Turn off Location LED.

```
cluster1::*> system controller location-led modify -node node1 -state off
```

## **system controller location-led show**

Display the location LED state on controllers

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### **Description**

The `system controller location-led show` command shows the current state of the location LED. When lit, the location LED can help you find the controller in the data center.

There is a blue location LED on every controller and on the front of the chassis. When you turn on the location LED for either controller, the chassis location LED automatically turns on. When both controller location LEDs are off, the chassis location LED automatically turns off.

After the location LED is turned on, it stays illuminated for 30 minutes and then automatically shuts off.

### **Parameters**

**`{ [-fields <fieldname>, ...]`**

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**`| [-instance ] }`**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**`[-node {<nodename>|local}] - Node`**

Selects the location LED on the specified filers.

**`[-state {on|off}] - LED State`**

Displays the location LED's status.

## Examples

The following example lists the current state of the location LED:

```
cluster1::*> system controller location-led show
Node                Location LED State
-----
node1               Off
node2               Off
```

## system controller memory dimm show

Display the Memory DIMM Table

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `system controller memory dimm show` command displays information about the DIMMs in all the nodes in the cluster. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported. By default, the command displays the following information about all the DIMMs in the cluster:

- Node
- DIMM name
- Uncorrectable ECC error count
- Correctable ECC error count
- CECC Alert Method
- CPU socket
- Channel
- Slot number
- Health monitor status

To display more details, use the `-instance` parameter.

### Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed information about the DIMMs in all the controllers in the cluster.

**[-node {<nodename>|local}] - Node**

Selects information about the DIMMs in the specified node.

**[-pds-id <integer>] - DIMM ID**

Selects information about the DIMMs with the specified DIMM ID.

**[-slotname <text>] - Slot Name**

Selects information about the DIMMs with the specified slot name.

**[-socket <integer>] - CPU Socket**

Selects information about the DIMMs with the specified socket ID.

**[-channel <integer>] - Channel**

Selects information about the DIMMs with the specified channel number.

**[-slot-no <integer>] - Slot Number on a Channel**

Selects information about the DIMMs with the specified slot number.

**[-serial <text>] - Serial Number**

Selects information about the DIMMs with the specified serial number.

**[-part-no <text>] - Part Number**

Selects information about the DIMMs with the specified part number.

**[-cecc-count <integer>] - Correctable ECC Error Count**

Selects information about the DIMMs with the specified correctable ECC error count.

**[-uecc-count <integer>] - Uncorrectable ECC Error Count**

Selects information about the DIMMs with the specified uncorrectable ECC error count.

**[-monitor {node-connect|system-connect|system|controller|chassis|cluster-switch|example}] - Health Monitor Name**

Selects information about the DIMMs with the specified health monitor.

**[-status {ok|ok-with-suppressed|degraded|unreachable|unknown}] - Status**

Selects information about the DIMMs with the specified health monitor status.

**[-name <text>] - Unique Name of DIMM**

Selects information about the DIMMs with the specified unique name.

**[-display-name <text>] - Display Name for the DIMM**

Selects information about the DIMMs with the specified display name.

**[-alt-cecc-method <text>] - CECC Alert Method**

Selects information about the DIMMs with the specified CECC error alert method.

**[-alt-cecc-dimm {true|false}] - Replace DIMM**

Selects information about the DIMMs with the specified replace DIMM value.

## Examples

The example below displays information about the DIMMs in all the nodes in the cluster.

```
cluster1::> system controller memory dimm show
```

Slot		DIMM	UECC	CECC	Alert	CPU
Number	Status	Name	Count	Count	Method	Socket Channel
0	ok	DIMM-1	0	0 bucket	0	0
1	ok	DIMM-NV1	0	0 bucket	0	1
0	ok	DIMM-1	1	0 bucket	0	0
1	ok	DIMM-NV1	0	0 bucket	0	1

4 entries were displayed.

The example below displays detailed information about a specific DIMM in a specific controller.

```
cluster1::> system controller memory dimm show -instance -node node1 -pds
-id 1
```

```

Node: node1
DIMM ID: 1
Slot Name: DIMM-1
CPU Socket: 0
Channel: 0
Slot Number on a Channel: 0
Serial Number: AD-01-1306-2EA01E9A
Part Number: HMT82GV7MMR4A-H9
Correctable ECC Error Count: 0
Uncorrectable ECC Error Count: 0
Health Monitor Name: controller
Status: ok
Unique Name of DIMM: DIMM-1
Display Name for the DIMM: DIMM-1
CECC Alert Method: bucket
Replace DIMM: false

```

## system controller nvram-bb-threshold show

Display the controller NVRAM bad block threshold

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.



## Description

The `system controller nvram-bb-threshold show` command displays the threshold for the NVRAM bad block counts for a node.

## system controller pci show

Display the PCI Device Table

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller pci show` command displays details of the PCI devices present in all of the nodes in a cluster. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported. By default, the command displays the following information about the PCI devices:

- Node name
- Display name
- Correctable error count
- Functional link width
- Functional link speed
- Health monitor status

To display more details, use the `-instance` parameter.

## Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed information for all of the PCI devices.

**[-node {<nodename>|local}] - Node**

Selects the PCI devices that are present in the specified node.

**[-bus-number <integer>] - Bus Number**

Selects the PCI devices with the specified bus number.

**[-device-number <integer>] - Device Number**

Selects the PCI devices with the specified device number.

**[-function-number <integer>] - Function Number**

Selects the PCI devices with the specified function number.

**[-slot-number <integer>] - Slot Info**

Selects the PCI devices with the specified slot number.

**[-monitor {node-connect|system-connect|system|controller|chassis|cluster-switch|example}] - Health Monitor Name**

Selects the PCI devices monitored by the specified health monitor.

**[-vendor-id <Hex Integer>] - Vendor ID**

Selects the PCI devices with the specified vendor ID.

**[-device-id <Hex Integer>] - Device ID**

Selects the PCI devices with the specified device ID.

**[-physical-link-width <integer>] - Physical Link Width**

Selects the PCI devices with the specified physical link width.

**[-functional-link-width <integer>] - Functional Link Width**

Selects the PCI devices with the specified functional link width.

**[-physical-link-speed <text>] - Physical Link Speed(GT/s)**

Selects the PCI devices with the specified physical link speed.

**[-functional-link-speed <text>] - Functional Link Speed(GT/s)**

Selects the PCI devices with the specified functional link speed.

**[-unique-name <text>] - Unique Name**

Selects the PCI devices with the specified unique name.

**[-corr-err-count <integer>] - Correctable Error Count**

Selects the PCI devices with the specified correctable error count.

**[-health {ok|ok-with-suppressed|degraded|unreachable|unknown}] - Status**

Selects the PCI devices with the specified health monitor status.

**[-display-name <text>] - Display Name**

Selects the PCI devices with the specified display name.

**[-cerr-diff <integer>] - Correctable Error Difference**

Selects the PCI devices with the specified difference in correctable error count.

## Examples

The example below displays the information about the PCIe devices present in all of the nodes in the cluster.

```
cluster1::> system controller pci show
```

Node	Display Name	Correctable Error Count	Functional Link Width	Functional Link Speed
cluster1-01	Ontap PCI Device 0	0	4	5GT/s
cluster1-02	Ontap PCI Device 4	0	4	5GT/s

```
ok
```

The example below displays detailed information about a PCIe device in a node.

```
cluster1::> system controller pcie show -instance -node cluster1-01 -bus
-number 1
Node: cluster1-01
    Bus Number: 1
    Device Number: 0
    Function Number: 0
    Slot Info: 0
    Health Monitor Name: controller
    Vendor ID: 11f8
    Device ID: 8001
    Physical Link Width: 4
    Functional Link Width: 4
    Physical Link Speed(GT/s): 5GT/s
    Functional Link Speed(GT/s): 5GT/s
    Unique Name: ontap0@pci0:1:0:0
    Correctable Error Count: 0
    Status: ok
    Display Name: Ontap PCI Device 0
    Correctable Error Difference: 0
```

## system controller pcicerr threshold modify

Modify the Node PCIe error alert threshold

**Availability:** This command is available to *cluster* administrators at the *advanced* privilege level.

### Description

The `system controller pcicerr threshold modify` command modifies node-wide PCIe correctable error threshold counts in the cluster.

## Parameters

### **`[-pcie-cerr-threshold <integer>]` - Corr. Error Limit**

The PCIe error threshold count that would trigger an alert if exceeded.

### **`[-nvram-bb-threshold <integer>]` - NVRAM Bad Block limit**

The NVRAM bad block threshold count that would trigger an alert if exceeded.

## Examples

The example below displays the information about setting node-wide PCIe error threshold count in the cluster:

```
cluster1::> system controller threshold modify -pcie-cerr-threshold 100
```

## system controller pcicerr threshold show

Display the Node PCIe error alert threshold

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller pcicerr threshold show` command displays information about node-wide PCIe correctable error threshold counts in the cluster.

## Examples

The example below displays the information about node-wide PCIe error threshold count in the cluster:

```
cluster1::> system controller pcicerr threshold show

PCIe Error Threshold
-----
                        200
```

## system controller platform-capability show

Display platform capabilities

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller platform-capability show` command displays information about all platform capabilities for each controller in the cluster. By default, the command displays the following information about all controllers in the cluster:

- Controller Name
- Capability ID
- Capability Supported?
- Capability Name

## Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>`, ... parameter, the command output also includes the specified field or fields. You can use `-fields ?` to display the fields to specify.

**| [-instance ] }**

Displays detailed information about all controllers in the cluster.

**[-node {<nodename>|local}] - Node**

Selects information about the specified controller.

**[-capability-id <integer>] - Capability ID**

Selects the desired capability ID.

**[-supported <text>] - Supported?**

Selects the desired capability support state (true or false).

**[-name <text>] - Capability Name**

Selects the desired capability name.

## Examples

The following example displays platform capability information for the controller:

```
cluster1::> system controller platform-capability show
Node          Capability ID Supported? Capability Name
-----
or-099-diag-01
                0          false    CAP_CMCI_ENABLED
                1          false    CAP_HA_CONFIG_ONLY
                2           true    CAP_SUPPORT_CARD_FRU
                3           true    CAP_SCORPIO_EN
                4          false    CAP_NVD_EN
                5          false    CAP_ENABLE_HPET
                6          false    CAP_VERIFY_ACPI_TABLE
7 entries were displayed.
```

## system controller service-event delete

Manually clear a selected service event

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller service-event delete` command removes the service event from the list and extinguishes all related FRU attention LEDs.

In some cases, where the underlying fault condition remains, the service event might be reported again, causing it to reappear in the list. In such cases, it is necessary to remedy the underlying fault condition in order to clear the service event.

## Parameters

**-node {<nodename>|local} - Node**

Selects service events on the specified nodes.

**-event-id <integer> - Service Event ID**

Selects the service events that match the specified event identifier. Together with the node, this field uniquely identifies the row to delete. Use the [system controller service-event show](#) command to find the event identifier for the service event to delete.

## Examples

The following example lists the currently active service events. Then, using the listed Service Event ID, the service event is deleted:

```
cluster1::> system controller service-event show
```

Node	ID	Event Location	Event Description
plata4-1a	1	DIMM in slot 1 on Controller A	Uncorrectable ECC

```
cluster1::> system controller service-event delete -event-id 1
```

## Related Links

- [system controller service-event show](#)

## system controller service-event show

Display the active service events causing attention LEDs to be lit

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller service-event show` command displays one or more events that have been detected by the system for which a physical service action might be required. Physical service actions

sometimes involve replacing or re-seating misbehaving FRUs. In such cases FRU attention LEDs will be illuminated to assist in physically locating the FRU in need of attention. When the FRU in question is contained within another FRU, both the inner and outer FRU attention LEDs will be lit. It creates a path of LEDs that starts at the chassis level and leads to the FRU in question. For example, if a DIMM is missing from the controller motherboard, the storage OS will detect this and log a service event whose location is the DIMM slot on the controller. The DIMM slot LED, controller LED and chassis LED will all be lit to create a path of LEDs to follow.

FRU Attention LEDs that are not visible from outside of the system (e.g. those on the controller motherboard such as DIMMs, boot device etc.) will remain on for a few minutes, even after power is removed from the containing FRU. As such, when the controller is removed from the chassis, a DIMM slot FRU attention LED will remain on, helping to locate the FRU in need of attention.

Generally, service events are cleared automatically when the issue is resolved. The corresponding FRU attention LEDs are extinguished accordingly. In cases where the service event request is caused by an environmental issue, it might be necessary to manually remove the service event from the list. This can be done using the [system controller service-event delete](#) command.

## Parameters

**{ [-fields <fieldname>,...]**

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

**| [-instance ] }**

If you specify the `-instance` parameter, the command displays detailed information about all fields.

**[-node {<nodename>|local}] - Node**

Selects service events on the specified nodes.

**[-event-id <integer>] - Service Event ID**

Selects the service events that match the specified event identifier. Together with the node, this field uniquely identifies the row for use with the [system controller service-event delete](#) command

**[-event-loc <text>] - Location**

Selects the service events that match the specified event location.

**[-event-desc <text>] - Description**

Selects the service events that match the specified event description.

**[-event-timestamp <text>] - Timestamp**

The time that the event occurred, recorded by the Service Processor

## Examples

The following example lists the currently active service events.

```
cluster1::> system controller service-event show
```

Node	ID	Event Location	Event Description
-----	---	-----	
plata4-1a	1	DIMM in slot 1 on Controller A	Uncorrectable ECC

## Related Links

- [system controller service-event delete](#)

## system controller sp config show

Display the Service Processor Config Table

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

## Description

The `system controller sp config show` command displays the following configuration information of the service processor for all nodes in the cluster:

- Node name
- Service processor status
- Service processor firmware version
- Booted firmware version
- Service processor configuration status
- Physical Ethernet link status of service processor
- Health monitor status

To display more details, use the `-instance` parameter. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported.

## Parameters

**{ [-fields <fieldname>,...]**

Selects the field that you specify.

**| [-instance ] }**

Displays detailed configuration information of the service processor.

**[-node {<nodename>|local}] - Node**

Use this parameter to list the service processor configuration of the specific node.



### **[-version <text>] - Firmware Version**

Selects the service processor configuration with the specified firmware version.

### **[-boot-version {primary|backup}] - Booted Version**

Selects the service processor configuration with the specified version of the currently booted partition.

### **[-monitor {node-connect|system-connect|system|controller|chassis|cluster-switch|example}] - Health Monitor Name**

Selects the service processor configuration with the specified monitor name.

### **[-sp-status {online|offline|sp-daemon-offline|node-offline|degraded|rebooting|unknown|updating}] - SP Status**

Selects the service processor configuration with the specified status of service processor.

### **[-sp-config {true|false}] - Auto Update Configured**

Selects information about the service processor with the specified configuration status of the service processor.

### **[-status {ok|ok-with-suppressed|degraded|unreachable|unknown}] - Status**

Selects the service processor configuration information with the specified service processor status.

### **[-link-status {up|down|disabled|unknown}] - Public Link Status**

Selects the service processor configuration with the specified physical ethernet link status.

### **[-name <text>] - Display Name**

Selects the service processor configuration with the specified unique name.

## **Examples**

The example below displays configuration of the service processor in all the nodes in the cluster:

```
cluster1::> system controller sp config show
```

	Firmware	Booted	Auto Update	SP	Link	
Node	Version	Version	Configured	Status	Status	Status
----	-----	-----	-----	-----	-----	-----
node1	2.2.2	primary	true	online	up	ok
node2	2.2.2	primary	true	online	up	ok

The example below displays configuration of the service processor of a particular node in detail:

```
cluster1::> system controller sp config show -instance -node node1
      Node: node1
      Firmware Version: 2.2.2
      Booted Version: primary
      Health Monitor Name: controller
      SP Status: online
      Auto Update Configured: true
      Status: ok
      Public Link Status: up
      Display Name: SP Config
```

## system controller sp upgrade show

Display the Service Processor Upgrade Table

**Availability:** This command is available to *cluster* administrators at the *admin* privilege level.

### Description

The `system controller sp upgrade show` command displays the following information about the service processor firmware of all the nodes in the cluster:

- Node name
- Is new firmware available?
- Is autoupdate enabled?
- Status of autoupdate
- Health monitor status

To display more details, use the `-instance` parameter. These commands are available for 80xx, 25xx and later systems. Earlier models are not supported.

### Parameters

**{ [-fields <fieldname>,...]**

Selects the fields that you specify.

**| [-instance ] }**

Displays detailed upgrade information of the service processor.

**[-node {<nodename>|local}] - Node**

Use this parameter to list the upgrade information of the service processor on the specified node.

**[-new-fw-avail {true|false}] - New Firmware Available**

Selects the information of the service processors which have new firmware available.

**[-new-fw-version <text>] - New Firmware Version**

Selects the information about service processors with the specified firmware version.

**[-auto-update {true|false}] - Auto Update**

Selects the information about service processors with the specified state.

**[-auto-update-stat {installed|corrupt|updating|auto-updating|none}] - Auto Update Status**

Selects the information about service processors with the specified auto update status.

**[-auto-update-sttime <MM/DD/YYYY HH:MM:SS>] - Auto Update Start Time**

Selects the information about service processors with the specified start time.

**[-auto-update-entime <MM/DD/YYYY HH:MM:SS>] - Auto Update End Time**

Selects the information about service processors with the specified end time.

**[-auto-update-per <integer>] - Auto Update Percent Done**

Selects the information about service processors with the specified auto update percentage completed.

**[-auto-update-maxret <integer>] - Auto Update Maximum Retries**

Selects the information about service processors with the specified maximum number of retries.

**[-auto-update-curret <integer>] - Auto Update Current Retries**

Selects the information about service processors with the specified number of current retries.

**[-auto-update-prevstat {failed|passed}] - Previous AutoUpdate Status**

Selects the information about service processors with the specified automatic update status.

**[-monitor {node-connect|system-connect|system|controller|chassis|cluster-switch|example}] - Health Monitor Name**

Selects the information about service processors with the specified monitor name.

**[-status {ok|ok-with-suppressed|degraded|unreachable|unknown}] - Status**

Selects the information about service processors with the specified health monitor status.

**[-name <text>] - Display Name**

Selects the information about service processors with the specified display name.

## Examples

The example below displays service processor upgrade information for all nodes in the cluster:

```
cluster1::> system controller sp upgrade show
```

New Node	Firmware Available	Auto Update Feature	Auto Update Status	Status
node1	false	true	installed	ok
node2	false	true	installed	ok

2 entries were displayed.

The example below displays the detailed service processor upgrade information for a specific node:

```
cluster1::> system controller sp upgrade show -instance -node node1
```

Node: node1

```

  New Firmware Available: false
    New Firmware Version: Not Applicable
      Auto Update: true
        Auto Update Status: installed
          Auto Update Start Time: Thu Oct 20 20:06:03 2012 Etc/UTC
            Auto Update End Time: Thu Oct 20 20:09:19 2012 Etc/UTC
              Auto Update Percent Done: 0
                Auto Update Maximum Retries: 5
                  Auto Update Current Retries: 0
                    Previous AutoUpdate Status: passed
                      Health Monitor Name: controller
                        Status: ok
                          Display Name: SP Upgrade

```

## Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.