



network subnet commands

ONTAP 9.8 commands

NetApp
September 27, 2022

Table of Contents

- network subnet commands 1
 - network subnet add-ranges 1
 - network subnet create 1
 - network subnet delete 2
 - network subnet modify 3
 - network subnet remove-ranges 4
 - network subnet rename 5
 - network subnet show 5

network subnet commands

network subnet add-ranges

Add new address ranges to a subnet

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

Add new address ranges to a subnet.



All addresses in a range must be the same address family (IPv4 or IPv6) and must have the same subnet mask. Ranges that overlap or are next to existing ranges will be merged with the existing ranges.

Parameters

-ip-space <IPspace> - IPspace Name

The IPspace in which the range resides.

-subnet-name <subnet name> - Subnet Name

The name of the subnet.

-ip-ranges {<ipaddr>|<ipaddr>-<ipaddr>} - IP Ranges

The list of ranges to add to the subnet.

[-force-update-lif-associations <true>] - Force Update LIF Associations

This command will fail if any service processor interfaces or network interfaces are using the IP addresses in the ranges provided. Using this parameter will associate any manually addressed interfaces with the subnet and will allow the command to succeed.

Examples

The following example allocates addresses for subnet *s1* in IPspace *Default*.

```
cluster1::> network subnet add-ranges -ip-space Default -subnet-name s1
-ip-ranges "10.98.1.20-10.98.1.30, 10.98.1.35, 10.98.1.40-10.98.1.49"
```

network subnet create

Create a new layer 3 subnet

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

Create a new subnet.

Parameters

[-ip-space <IPspace>] - IPspace Name

The IPspace to which the new subnet belongs.

-subnet-name <subnet name> - Subnet Name

The name of the subnet to be created. The name of the subnet needs to be unique within the IPspace.

-broadcast-domain <Broadcast Domain> - Broadcast Domain

The broadcast domain to which the new subnet belongs.

-subnet <IP Address/Mask> - Layer 3 Subnet

The address and mask of the subnet.

[-gateway <IP Address>] - Gateway

The gateway of the subnet.

[-ip-ranges {<ipaddr>|<ipaddr>-<ipaddr>}] - IP Addresses or IP Address Ranges

The IP ranges associated with this subnet.

[-force-update-lif-associations <true>] - Change the subnet association

This command will fail if any service processor interfaces or network interfaces are using the IP addresses in the ranges provided. Using this parameter will associate any manually addressed interfaces with the subnet and will allow the command to succeed.

Examples

The following examples create subnets named *s1* and *s6* in IPspace *Default*.

```
cluster1::> network subnet create -ip-space Default -broadcast-domain bd1
-subnet-name s1
      -subnet 192.168.1.0/24 -gateway 192.168.1.1 -ip-ranges "192.168.1.1-
192.168.1.100, 192.168.1.112, 192.168.1.145"
```

```
cluster1::> network subnet create -ip-space Default -broadcast-domain bd1
-subnet-name s6
      -subnet 3FFE::/64 -gateway 3FFE::1 -ip-ranges "3FFE::10-3FFE::20"
```

network subnet delete

Delete an existing subnet object

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

Delete a subnet that contains no ports.

Parameters

-ipSPACE <IPspace> - IPspace Name

The IPspace to which the subnet belongs.

-subnet-name <subnet name> - Subnet Name

The name of the subnet to be deleted.

[-force-update-lif-associations <true>] - Change the subnet association

This command will fail if the subnet has ranges containing any existing service processor interface or network interface IP addresses. Setting this value to true will remove the network interface associations with the subnet and allow the command to succeed. However, it will not affect service processor interfaces.

Examples

The following example deletes subnet *s1* in IPspace *Default*.

```
cluster1::> network subnet delete -ipSPACE Default -subnet-name s1
```

network subnet modify

Modify a layer 3 subnet

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

Modify a subnet.

Parameters

-ipSPACE <IPspace> - IPspace Name

The IPspace to which the subnet belongs.

-subnet-name <subnet name> - Subnet Name

The name of the subnet to modify.

[-subnet <IP Address/Mask>] - Layer 3 Subnet

The new address and mask of the subnet.

[-gateway <IP Address>] - Gateway

The new gateway address.

[-ip-ranges {<ipaddr>|<ipaddr>-<ipaddr>}] - IP Addresses or IP Address Ranges

The new IP ranges for this subnet.

[-force-update-lif-associations <true>] - Change the subnet association

This command will fail if any existing service processor interfaces or network interfaces are using IP addresses in the IP ranges being added. It will also fail if any existing service processor interfaces or network interfaces are using IP addresses in the IP ranges being removed. Using this parameter will associate the interfaces with the IP addresses in the ranges being added to the subnet. It will also remove the subnet's association with the interfaces with IP addresses in the IP ranges being removed and will allow the command to succeed.

Examples

The following example modifies the subnet address and gateway.

```
cluster1::> network subnet modify -ip-space Default -subnet-name s1 -subnet
192.168.2.0/24 -gateway 192.168.2.1
```

network subnet remove-ranges

Remove address ranges from a subnet

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

Remove address ranges from a subnet.

Parameters

-ip-space <IPspace> - IPspace Name

The IPspace in which the range resides.

-subnet-name <subnet name> - Subnet Name

The name of the subnet.

-ip-ranges {<ipaddr>|<ipaddr>-<ipaddr>} - IP Ranges

IP ranges to remove.

[-force-update-lif-associations <true>] - Force Update LIF Associations

This command will fail if any existing service processor interfaces or network interfaces are using IP addresses in the ranges provided. Using this parameter will remove the subnet's association with those interfaces and allow the command to succeed.

Examples

The following example removes an address range with starting address of *10.98.1.1* from subnet *s1* in IPspace *Default*.

```
cluster1::> network subnet remove-ranges -ip-space Default -subnet-name s1
-ip-ranges "10.98.1.1-10.98.1.30"
```

network subnet rename

Rename a layer 3 subnet

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

Rename a Subnet.

Parameters

-ip-space <IPspace> - IPspace Name

The IPspace to which the subnet belongs.

-subnet-name <subnet name> - Subnet Name

The name of the subnet to rename.

-new-name <text> - New Name

The new name for the subnet.

Examples

The following example renames subnet *s1* to *s3*.

```
cluster1::> network subnet rename -ip-space Default -subnet s1 -new-name s3
```

network subnet show

Display subnet information

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

Display subnet information.

Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

[`-instance`] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

[`-ip-space <IPspace>`] - IPspace Name

Selects the subnets that match the given IPspace name.

[`-subnet-name <subnet name>`] - Subnet Name

Selects the subnets that match the given subnet name.

[`-broadcast-domain <Broadcast Domain>`] - Broadcast Domain

Selects the subnets that match the given broadcast domain name.

[`-subnet <IP Address/Mask>`] - Layer 3 Subnet

Selects the subnets that match the given address and mask.

[`-gateway <IP Address>`] - Gateway

Selects the subnets that match the given gateway address.

[`-ip-ranges {<ipaddr>|<ipaddr>-<ipaddr>}`] - IP Addresses or IP Address Ranges

Selects the subnets that match the given IP range.

[`-total-count <integer>`] - Total Address Count

Selects the subnets that match the given total address count.

[`-used-count <integer>`] - Used Address Count

Selects the subnets that match the given number of addresses allocated.

[`-available-count <integer>`] - Available Address Count

Selects the subnets that match the given number of addresses available.

Examples

The following example displays general information about the subnets.


```
cluster1::> network subnet show
```

```
IPspace: Default
```

Subnet Name	Subnet	Broadcast Domain	Gateway	Avail/ Total	Ranges
s4	192.168.4.0/24	bd4	192.168.4.1	5/5	
	192.168.5.6-192.168.5.10				
s6	192.168.6.0/24	bd4	192.168.6.1	5/5	
	192.168.6.6-192.168.6.10				

```
IPspace: ips1
```

Subnet Name	Subnet	Broadcast Domain	Gateway	Avail/ Total	Ranges
s10	192.168.6.0/24	bd10	192.168.6.1	0/0	-

```
3 entries were displayed.
```

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.