



## **Manage local users**

ONTAP 9.14.1 REST API reference

NetApp  
May 23, 2024

# Table of Contents

- Manage local users ..... 1
  - Protocols CIFS local-users endpoint overview ..... 1
  - Retrieve local users for all SVMs ..... 7
  - Create the local user configuration for an SVM ..... 14
  - Delete the local user configuration for an SVM ..... 22
  - Retrieve the local user information for a user and SVM ..... 24
  - Update the local user information for a user and SVM ..... 29

# Manage local users

## Protocols CIFS local-users endpoint overview

### Overview

The CIFS server can use local users for CIFS authentication. The local users can also be used for authorization when determining both share and file/directory access rights to data residing on the storage virtual machine (SVM). You can use this API to display local user information and to control local user configurations.

### Retrieving local user information

You can use the local user GET endpoint to retrieve all of the local user configurations for data SVMs.

### Examples

#### Retrieving all of the fields for local user configurations for all SVMs

```
# The API:
/api/protocols/cifs/local-users

# The call:
curl -X GET "https://<mgmt-ip>/api/protocols/cifs/local-users?fields=*"
-H "accept: application/json"

# The response:
{
  "records": [
    {
      "svm": {
        "uuid": "25b363a6-2971-11eb-88e1-0050568eefd4",
        "name": "vs1"
      },
      "sid": "S-1-5-21-256008430-3394229847-3930036330-500",
      "name": "CIFS_SERVER1\\Administrator",
      "full_name": "",
      "description": "Built-in administrator account",
      "account_disabled": false,
      "membership": [
        {
          "name": "BUILTIN\\Administrators",
          "sid": "S-1-5-32-544"
        }
      ]
    }
  ]
}
```

```

},
{
  "svm": {
    "uuid": "25b363a6-2971-11eb-88e1-0050568eefd4",
    "name": "vs1"
  },
  "sid": "S-1-5-21-256008430-3394229847-3930036330-1001",
  "name": "CIFS_SERVER1\\user1",
  "full_name": "local user1",
  "description": "This is CIFS local user",
  "account_disabled": false
},
{
  "svm": {
    "uuid": "25b363a6-2971-11eb-88e1-0050568eefd4",
    "name": "vs1"
  },
  "sid": "S-1-5-21-256008430-3394229847-3930036330-1002",
  "name": "CIFS_SERVER1\\user2",
  "full_name": "local user2",
  "description": "This is CIFS local user",
  "account_disabled": false,
  "membership": [
    {
      "name": "CIFS_SERVER1\\grp1",
      "sid": "S-1-5-21-256008430-3394229847-3930036330-1001"
    },
    {
      "name": "CIFS_SERVER1\\grp2",
      "sid": "S-1-5-21-256008430-3394229847-3930036330-1002"
    }
  ]
},
{
  "svm": {
    "uuid": "3f479a01-2971-11eb-88e1-0050568eefd4",
    "name": "vs2"
  },
  "sid": "S-1-5-21-1625922807-3304708894-3529444428-500",
  "name": "CIFS_SERVER2\\Administrator",
  "full_name": "",
  "description": "Built-in administrator account",
  "account_disabled": false,
  "membership": [
    {
      "name": "BUILTIN\\Administrators",

```

```

        "sid": "S-1-5-32-544"
    }
]
},
{
    "svm": {
        "uuid": "3f479a01-2971-11eb-88e1-0050568eefd4",
        "name": "vs2"
    },
    "sid": "S-1-5-21-1625922807-3304708894-3529444428-1001",
    "name": "CIFS_SERVER2\\user1",
    "full_name": "local user1",
    "description": "This is CIFS local user",
    "account_disabled": false
}
],
"num_records": 5
}

```

## Retrieving the local user configuration of a specific SVM

```

# The API:
/api/protocols/cifs/local-users

# The call:
curl -X GET "https://<mgmt-ip>/api/protocols/cifs/local-
users?svm.uuid=25b363a6-2971-11eb-88e1-0050568eefd4&fields=*" -H "accept:
application/json"

# The response:
{
  "records": [
    {
      "svm": {
        "uuid": "25b363a6-2971-11eb-88e1-0050568eefd4",
        "name": "vs1"
      },
      "sid": "S-1-5-21-256008430-3394229847-3930036330-500",
      "name": "CIFS_SERVER1\\Administrator",
      "full_name": "",
      "description": "Built-in administrator account",
      "account_disabled": false,

```

```

"membership": [
  {
    "name": "BUILTIN\\Administrators",
    "sid": "S-1-5-32-544"
  }
]
},
{
  "svm": {
    "uuid": "25b363a6-2971-11eb-88e1-0050568eefd4",
    "name": "vs1"
  },
  "sid": "S-1-5-21-256008430-3394229847-3930036330-1001",
  "name": "CIFS_SERVER1\\user1",
  "full_name": "local user1",
  "description": "This is CIFS local user",
  "account_disabled": false
},
{
  "svm": {
    "uuid": "25b363a6-2971-11eb-88e1-0050568eefd4",
    "name": "vs1"
  },
  "sid": "S-1-5-21-256008430-3394229847-3930036330-1002",
  "name": "CIFS_SERVER1\\user2",
  "full_name": "local user2",
  "description": "This is CIFS local user",
  "account_disabled": false,
  "membership": [
    {
      "name": "CIFS_SERVER1\\grp1",
      "sid": "S-1-5-21-256008430-3394229847-3930036330-1001"
    },
    {
      "name": "CIFS_SERVER1\\grp2",
      "sid": "S-1-5-21-256008430-3394229847-3930036330-1002"
    }
  ]
},
],
"num_records": 3
}

```

## Retrieving a local user configuration of a specific SVM and user

```
# The API:
/api/protocols/cifs/local-users/{svm.uuid}/{sid}

# The call:
curl -X GET "https://<mgmt-ip>/api/protocols/cifs/local-users/25b363a6-2971-11eb-88e1-0050568eefd4/S-1-5-21-1625922807-3304708894-3529444428-1001" -H "accept: application/json"

# The response:
{
  "svm": {
    "uuid": "25b363a6-2971-11eb-88e1-0050568eefd4",
    "name": "vs1"
  },
  "sid": "S-1-5-21-256008430-3394229847-3930036330-1001",
  "name": "CIFS_SERVER1\\user1",
  "full_name": "local user1",
  "description": "This is CIFS local user",
  "account_disabled": false
}
```

## Creating a local user configuration

The local user POST endpoint creates a local user configuration for the specified SVM.

### Examples

#### Creating a local user configuration with all fields specified

```
# The API:
/api/protocols/cifs/local-users

# The call:
curl -X POST "https://<mgmt-ip>/api/protocols/cifs/local-users" -H
"accept: application/json" -H "Content-Type: application/json" -d "{
 \"account_disabled\": false, \"description\": \"This is local user.\",
 \"full_name\": \"user name\", \"name\": \"SMB_SERVER01\\\\\\\\user\",
 \"password\": \"netapp1N\", \"svm\": { \"name\": \"vs1\", \"uuid\":
 \"25b363a6-2971-11eb-88e1-0050568eefd4\" }}"
```

---

### Creating a local user configuration with only mandatory fields specified

```
# The API:
/api/protocols/cifs/local-users

# The call:
curl -X POST "https://<mgmt-ip>/api/protocols/cifs/local-users" -H
"accept: application/json" -d "{ \"name\": \"user1\", \"password\":
 \"netapp1N\", \"svm\": { \"uuid\": \"25b363a6-2971-11eb-88e1-
0050568eefd4\" }}"
```

---

### Updating a local user configuration

The local user PATCH endpoint updates the local user configuration for the specified user and SVM.

#### Updating a local user name and password

```
# The API:
/api/protocols/cifs/local-users/{svm.uuid}/{sid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/protocols/cifs/local-users/25b363a6-
2971-11eb-88e1-0050568eefd4/S-1-5-21-1625922807-3304708894-3529444428-
1001" -H "accept: application/json" -d "{ \"name\": \"new_user1\",
 \"password\": \"netapp1Net\" }"
```



## Deleting a local user configuration

The local user DELETE endpoint deletes the specified local user for the specified SVM. The following example shows a DELETE operation:

```
# The API:
/api/protocols/cifs/local-users/{svm.uuid}/{sid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/protocols/cifs/local-users/25b363a6-2971-11eb-88e1-0050568eefd4/s-1-5-21-1625922807-3304708894-3529444428-1001" -H "accept: application/json"
```

## Retrieve local users for all SVMs

GET /protocols/cifs/local-users

**Introduced In:** 9.9

Retrieves local users for all of the SVMs. Local groups to which this user belongs to are also displayed.

### Advanced properties

- membership

### Related ONTAP commands

- `vserver cifs users-and-groups local-user show`
- `vserver cifs users-and-groups local-user show-membership`

### Learn more

- [DOC /protocols/cifs/local-users](#)

### Parameters

Name	Type	In	Required	Description
name	string	query	False	Filter by name <ul style="list-style-type: none"><li>• minLength: 1</li></ul>
description	string	query	False	Filter by description <ul style="list-style-type: none"><li>• maxLength: 256</li></ul>

Name	Type	In	Required	Description
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
account_disabled	boolean	query	False	Filter by account_disabled
sid	string	query	False	Filter by sid <ul style="list-style-type: none"> <li>Introduced in: 9.10</li> </ul>
full_name	string	query	False	Filter by full_name <ul style="list-style-type: none"> <li>maxLength: 256</li> </ul>
membership.sid	string	query	False	Filter by membership.sid <ul style="list-style-type: none"> <li>Introduced in: 9.10</li> </ul>
membership.name	string	query	False	Filter by membership.name <ul style="list-style-type: none"> <li>minLength: 1</li> </ul>
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>Default value: 1</li> </ul>

Name	Type	In	Required	Description
return_timeout	integer	query	False	<p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul>
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">_links</a>	
num_records	integer	Number of local user records.
records	array[ <a href="#">local_cifs_user</a> ]	

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "description": "This is local user.",
    "full_name": "user name",
    "membership": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "SMB_SERVER01\\group",
      "sid": "S-1-5-21-256008430-3394229847-3930036330-1001"
    },
    "name": "SMB_SERVER01\\user",
    "sid": "S-1-5-21-256008430-3394229847-3930036330-1001",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    }
  }
}
```

## Error

Status: Default, Error

Name	Type	Description
error	<a href="#">returned_error</a>	

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

\_links

Name	Type	Description
self	<a href="#">href</a>	

membership

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	Local group name. The maximum supported length of a group name is 256 characters.
sid	string	The security ID of the local group which uniquely identifies the group. The group SID is automatically generated in POST and it is retrieved using the GET method.

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.

Name	Type	Description
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

#### local\_cifs\_user

Name	Type	Description
_links	<a href="#">_links</a>	
account_disabled	boolean	Indicates whether the user account is enabled or disabled.
description	string	Description for the local user.
full_name	string	User's full name.
membership	array[ <a href="#">membership</a> ]	Specifies local groups of which this local user is a member.
name	string	Local user name. The maximum supported length of an user name is 20 characters.
password	string	Password for the local user.
sid	string	The security ID of the local user which uniquely identifies the user. The user SID is automatically generated in POST and it is retrieved using the GET method.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.

#### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

#### returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Create the local user configuration for an SVM

POST /protocols/cifs/local-users

**Introduced In:** 9.9

Creates the local user configuration for an SVM.

### Important notes

- The user name can contain up to 20 characters.
- The user name cannot be terminated by a period.
- The user name does not support any of the following characters: " / ? [ ] , : \ | < > + = ; ? \* @ or ASCII characters in the range 1-31.
- The password must be at least six characters in length and must not contain the user account name.
- The password must contain characters from three of the following four categories:
  - English uppercase characters (A through Z)
  - English lowercase characters (a through z)
  - Base 10 digits (0 through 9)
  - Special characters: ~ ! @ # 0 ^ & \* \_ - + = ` ? \ | ( ) [ ] ; ; " ' < > , . ? /

### Required properties

- `svm.uuid` or `svm.name` - Existing SVM in which to create the local user.
- `name` - Name of the local user.
- `password` - Password for the local user.

### Default property values

If not specified in POST, the following default property value is assigned:

- `account_disabled` - false



## Related ONTAP commands

- `vserver cifs users-and-groups local-user create`

## Learn more

- [DOC /protocols/cifs/local-users](#)

## Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned.  • Default value:

## Request Body

Name	Type	Description
_links	<a href="#">_links</a>	
account_disabled	boolean	Indicates whether the user account is enabled or disabled.
description	string	Description for the local user.
full_name	string	User's full name.
membership	array[ <a href="#">membership</a> ]	Specifies local groups of which this local user is a member.
name	string	Local user name. The maximum supported length of an user name is 20 characters.
password	string	Password for the local user.
sid	string	The security ID of the local user which uniquely identifies the user. The user SID is automatically generated in POST and it is retrieved using the GET method.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "description": "This is local user.",
  "full_name": "user name",
  "membership": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "SMB_SERVER01\\group",
    "sid": "S-1-5-21-256008430-3394229847-3930036330-1001"
  },
  "name": "SMB_SERVER01\\user",
  "sid": "S-1-5-21-256008430-3394229847-3930036330-1001",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

## Response

Status: 201, Created

Name	Type	Description
<a href="#">_links</a>	<a href="#">_links</a>	
num_records	integer	Number of local user records.
records	array[ <a href="#">local_cifs_user</a> ]	

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "description": "This is local user.",
    "full_name": "user name",
    "membership": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "SMB_SERVER01\\group",
      "sid": "S-1-5-21-256008430-3394229847-3930036330-1001"
    },
    "name": "SMB_SERVER01\\user",
    "sid": "S-1-5-21-256008430-3394229847-3930036330-1001",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    }
  }
}
```

## Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

## Error

Status: Default

### ONTAP Error Response Codes

Error Code	Description
262278	Name and password are required fields.
655399	CIFS server must exist to create a local user.
655660	The operation is allowed only on data SVMs.
655661	The user name should not exceed 20 characters. Also full_name and description should not exceed 256 characters.
655665	The user name must not match the CIFS server name of the specified SVM.
655668	The specified user name contains illegal characters.
655675	The local domain name specified in user name doesn't exist.
655682	The user name cannot be blank.
655733	The password does not meet the password complexity requirements.
655736	The specified user name already exists.
2621706	The specified SVM UUID is incorrect for the specified SVM name.

Name	Type	Description
error	<a href="#">returned_error</a>	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

membership

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	Local group name. The maximum supported length of a group name is 256 characters.
sid	string	The security ID of the local group which uniquely identifies the group. The group SID is automatically generated in POST and it is retrieved using the GET method.

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

local\_cifs\_user

Name	Type	Description
_links	<a href="#">_links</a>	

Name	Type	Description
account_disabled	boolean	Indicates whether the user account is enabled or disabled.
description	string	Description for the local user.
full_name	string	User's full name.
membership	array[ <a href="#">membership</a> ]	Specifies local groups of which this local user is a member.
name	string	Local user name. The maximum supported length of an user name is 20 characters.
password	string	Password for the local user.
sid	string	The security ID of the local user which uniquely identifies the user. The user SID is automatically generated in POST and it is retrieved using the GET method.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.

#### \_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

#### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

#### returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments

Name	Type	Description
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Delete the local user configuration for an SVM

```
DELETE /protocols/cifs/local-users/{svm.uuid}/{sid}
```

**Introduced In:** 9.10

Deletes a local user configuration for the specified SVM.

### Related ONTAP commands

- `vserver cifs users-and-groups local-user delete`

### Learn more

- [DOC /protocols/cifs/local-users](#)

### Parameters

Name	Type	In	Required	Description
sid	string	path	True	Local user SID
svm.uuid	string	path	True	UUID of the SVM to which this object belongs.

### Response

```
Status: 200, Ok
```

### Error

```
Status: Default
```

ONTAP Error Response Codes



Error Code	Description
655735	The local Administrator account cannot be deleted.

Name	Type	Description
error	<a href="#">returned_error</a>	

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Retrieve the local user information for a user and SVM

```
GET /protocols/cifs/local-users/{svm.uuid}/{sid}
```

**Introduced In:** 9.10

Retrieves local user information for the specified user and SVM.

### Advanced properties

- membership

### Related ONTAP commands

- `vserver cifs users-and-groups local-user show`
- `vserver cifs users-and-groups local-user show-membership`

### Learn more

- [DOC /protocols/cifs/local-users](#)

### Parameters

Name	Type	In	Required	Description
sid	string	path	True	Local user SID
svm.uuid	string	path	True	UUID of the SVM to which this object belongs.
fields	array[string]	query	False	Specify the fields to return.

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">_links</a>	
account_disabled	boolean	Indicates whether the user account is enabled or disabled.
description	string	Description for the local user.
full_name	string	User's full name.
membership	array[ <a href="#">membership</a> ]	Specifies local groups of which this local user is a member.
name	string	Local user name. The maximum supported length of an user name is 20 characters.
password	string	Password for the local user.
sid	string	The security ID of the local user which uniquely identifies the user. The user SID is automatically generated in POST and it is retrieved using the GET method.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "description": "This is local user.",
  "full_name": "user name",
  "membership": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "SMB_SERVER01\\group",
    "sid": "S-1-5-21-256008430-3394229847-3930036330-1001"
  },
  "name": "SMB_SERVER01\\user",
  "sid": "S-1-5-21-256008430-3394229847-3930036330-1001",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

## Error

Status: Default, Error

Name	Type	Description
error	<a href="#">returned_error</a>	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

membership

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	Local group name. The maximum supported length of a group name is 256 characters.
sid	string	The security ID of the local group which uniquely identifies the group. The group SID is automatically generated in POST and it is retrieved using the GET method.

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

error\_arguments

Name	Type	Description
code	string	Argument code

Name	Type	Description
message	string	Message argument

returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Update the local user information for a user and SVM

PATCH /protocols/cifs/local-users/{svm.uuid}/{sid}

**Introduced In:** 9.10

Updates local user information for the specified user and SVM. The PATCH endpoint is also used to rename a user and to set the password for the user.

### Related ONTAP commands

- `vserver cifs users-and-groups local-user modify`
- `vserver cifs users-and-groups local-user rename`
- `vserver cifs users-and-groups local-user set-password`

### Learn more

- [DOC /protocols/cifs/local-users](#)

### Parameters

Name	Type	In	Required	Description
sid	string	path	True	Local user SID
svm.uuid	string	path	True	UUID of the SVM to which this object belongs.

## Request Body

Name	Type	Description
_links	<a href="#">_links</a>	
account_disabled	boolean	Indicates whether the user account is enabled or disabled.
description	string	Description for the local user.
full_name	string	User's full name.
membership	array[ <a href="#">membership</a> ]	Specifies local groups of which this local user is a member.
name	string	Local user name. The maximum supported length of an user name is 20 characters.
password	string	Password for the local user.
sid	string	The security ID of the local user which uniquely identifies the user. The user SID is automatically generated in POST and it is retrieved using the GET method.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.



## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "description": "This is local user.",
  "full_name": "user name",
  "membership": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "SMB_SERVER01\\group",
    "sid": "S-1-5-21-256008430-3394229847-3930036330-1001"
  },
  "name": "SMB_SERVER01\\user",
  "sid": "S-1-5-21-256008430-3394229847-3930036330-1001",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

## Response

Status: 200, Ok

## Error

Status: Default

## ONTAP Error Response Codes

Error Code	Description
655661	The user name should not exceed 20 characters. Also full_name and description should not exceed 256 characters.
655668	The specified user name contains illegal characters.
655675	The local domain name specified in the user name does not exist.
655682	The user name cannot be blank.
655732	Failed to rename a user. The error code returned details the failure along with the reason for the failure. Take corrective actions as per the specified reason.
655733	The specified password does not meet the password complexity requirements.
655737	To rename an existing user, the local domain specified in name must match the local domain of the user to be renamed.

Name	Type	Description
error	<a href="#">returned_error</a>	

### Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```

### Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

membership

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	Local group name. The maximum supported length of a group name is 256 characters.
sid	string	The security ID of the local group which uniquely identifies the group. The group SID is automatically generated in POST and it is retrieved using the GET method.

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

local\_cifs\_user

Name	Type	Description
_links	<a href="#">_links</a>	

Name	Type	Description
account_disabled	boolean	Indicates whether the user account is enabled or disabled.
description	string	Description for the local user.
full_name	string	User's full name.
membership	array[ <a href="#">membership</a> ]	Specifies local groups of which this local user is a member.
name	string	Local user name. The maximum supported length of an user name is 20 characters.
password	string	Password for the local user.
sid	string	The security ID of the local user which uniquely identifies the user. The user SID is automatically generated in POST and it is retrieved using the GET method.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.

#### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

#### returned\_error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.