■ NetApp

Manage storage pools

ONTAP 9.14.1 REST API reference

NetApp May 23, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-9141/ontap/storage_pools_endpoint_overview.html on May 23, 2024. Always check docs.netapp.com for the latest.

Table of Contents

M	anage storage pools	. 1	ĺ
	Storage pools endpoint overview	. 1	l
	Retrieve storage pools for the entire cluster	. 7	7
	Create a new storage pool	21	ı

Manage storage pools

Storage pools endpoint overview

Retrieving storage pool information

The Storage Pools GET API retrieves all shared storage pools in the cluster.

The collection GET returns the storage pool identifiers, UUID and name. The instance GET, by default, returns all of the properties defined in the storage_pool object. The "show_spares" query returns a response outside of the records body, which includes the groups of usable spares in the cluster. The usable count for each class of spares does not include reserved spare capacity recommended by ONTAP best practices.

Creating storage pools

Creating a shared storage pool is recommended when distributing flash capacity across the cache tiers of HDD aggregates across an HA pair. POST can be used with specific properties to create a storage pool as requested. At a minimum, the storage pool name, disk count, and the nodes where it should reside, are required to create a new instance.

When using POST with input properties, three properties are required. These are:

- name Name of the storage pool.
- node.name or node.uuid Node that can use capacity from the storage pool in their cache tiers.
- capacity.disk count Number of disks to be used to create the storage pool.

Examples

Retrieving a list of storage pools from the cluster

The following example shows the response with a list of storage pools in the cluster:

```
"records": [
  "uuid": "8255fef7-4737-11ec-bd1b-005056bbb879",
  "nodes": [
      "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
      "name": "node-1",
    },
      "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
     "name": "node-2",
  ],
  " links": {
   "self": {
      "href": "/api/storage/pools/8255fef7-4737-11ec-bd1b-005056bbb879"
   }
 }
}
],
"num records": 1,
" links": {
 "self": {
    "href": "/api/storage/pools"
 }
}
}
```

```
"uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
    "name": "node-1",
 },
   "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
   "name": "node-2",
 }
],
"storage type": "ssd",
"capacity": {
    "remaining": 1846542336,
   "total": 7386169344,
    "spare allocation units": [
      "node": {
        "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
        "name": "node-1",
      },
      "count": 1,
      "syncmirror pool": "pool0",
      "size": 1846542336,
      "available size": 1846542336
    },
      "node": {
        "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
        "name": "node-2",
      },
      "count": 0,
      "syncmirror pool": "pool0",
      "size": 1846542336,
     "available size": 0
    }
    "used allocation units": [
      "aggregate": {
        "uuid": "19425837-f2fa-4a9f-8f01-712f626c983c",
        "name": "test a"
      },
      "allocated unit count": 2,
        "uuid": "caf95bec-f801-11e8-8af9-005056bbe5c1",
       "name": "node-1",
      "capacity": 2769813504
```

```
},
    "aggregate": {
      "uuid": "f4cc30d5-b052-493a-a49f-19781425f987",
      "name": "test b"
    },
    "allocated unit count": 1,
    "node": {
      "uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
     "name": "node-2",
    "capacity": 1384906752
 ],
  "disk count": 4,
  "disks": [
   {
      "disk": {
       "name": "VMw-1.11"
      "usable size": 1902379008,
      "total size": 1908871168,
    },
      "disk": {
       "name": "VMw-1.12"
      "usable size": 1902379008,
      "total size": 1908871168,
    },
      "disk": {
       "name": "VMw-1.23"
      "usable_size": 1902379008,
      "total size": 1908871168,
    },
      "disk": {
       "name": "VMw-1.24"
      "usable size": 1902379008,
      "total size": 1908871168,
   }
},
```

```
"health": {
    "state": "normal",
    "is_healthy": true
    },
}

!
"num_records": 1,
}
```

Retrieving the usable spare information for the cluster

The following example shows the response from retrieving usable spare information according to ONTAP best practices.

```
# The API:
/api/storage/pools?show spares=true
# The call:
curl -X GET "https://<mgmt-ip>/api/storage/pools?show spares=true" -H
"accept: application/json"
# The response:
"records": [],
"num records": 0,
"spares": [
    "disk class": "solid state",
    "disk type": "ssd",
    "size": 3720609792,
    "checksum style": "block",
    "syncmirror pool": "pool0",
    "usable": 12,
    "nodes": [
        "uuid": "54af4069-c1f7-11ec-884e-005056bb6e0b",
        "name": "node-1",
        " links": {
          "self": {
            "href": "/api/cluster/nodes/54af4069-c1f7-11ec-884e-
005056bb6e0b"
      },
        "uuid": "d50flacb-c1f6-11ec-9dfd-005056bb8d04",
```

Simulating the creation of a storage pool

The following example shows the response containing the simulated layout details of a new storage pool in the cluster.



Each storage pool UUID provided in this response is not guaranteed to be the same UUID for the storage pool if it is created.

```
"uuid": "cf9ab500-ff3e-4bce-bfd7-d679e6078f47",
      "name": "node-2",
    }
  ],
  "capacity": {
    "total": 7386169344,
    "disk count": 4,
    "disks": [
        "disk": {
         "name": "VMw-1.11"
        },
      },
        "disk": {
         "name": "VMw-1.12"
        },
      } ,
        "disk": {
         "name": "VMw-1.23"
        },
      },
        "disk": {
         "name": "VMw-1.24"
        },
      }
  }
}
]
```

Retrieve storage pools for the entire cluster

GET /storage/pools

Introduced In: 9.11

Retrieves the collection of storage pools for the entire cluster.

Related ONTAP commands

storage pool show

Parameters

Name	Туре	In	Required	Description
capacity.used_alloca tion_units.node.nam e	string	query	False	Filter by capacity.used_alloc ation_units.node.na me
capacity.used_alloca tion_units.node.uuid	string	query	False	Filter by capacity.used_alloc ation_units.node.uui d
capacity.used_alloca tion_units.count	integer	query	False	Filter by capacity.used_alloc ation_units.count
capacity.used_alloca tion_units.current_us age	integer	query	False	Filter by capacity.used_alloc ation_units.current_usage
capacity.used_alloca tion_units.aggregate. uuid	string	query	False	Filter by capacity.used_alloc ation_units.aggregat e.uuid
capacity.used_alloca tion_units.aggregate. name	string	query	False	Filter by capacity.used_alloc ation_units.aggregat e.name
capacity.disk_count	integer	query	False	Filter by capacity.disk_count
capacity.remaining	integer	query	False	Filter by capacity.remaining
capacity.disks.usabl e_size	integer	query	False	Filter by capacity.disks.usabl e_size
capacity.disks.disk.n ame	string	query	False	Filter by capacity.disks.disk.n ame

Name	Туре	In	Required	Description
capacity.disks.total_ size	integer	query	False	Filter by capacity.disks.total_ size
capacity.total	integer	query	False	Filter by capacity.total
capacity.spare_alloc ation_units.node.na me	string	query	False	Filter by capacity.spare_alloc ation_units.node.na me
capacity.spare_alloc ation_units.node.uui d	string	query	False	Filter by capacity.spare_alloc ation_units.node.uui d
capacity.spare_alloc ation_units.available _size	integer	query	False	Filter by capacity.spare_alloc ation_units.available _size
capacity.spare_alloc ation_units.count	integer	query	False	Filter by capacity.spare_alloc ation_units.count
capacity.spare_alloc ation_units.size	integer	query	False	Filter by capacity.spare_alloc ation_units.size
capacity.spare_alloc ation_units.syncmirr or_pool	string	query	False	Filter by capacity.spare_alloc ation_units.syncmirr or_pool
uuid	string	query	False	Filter by uuid
health.unhealthy_rea son.code	string	query	False	Filter by health.unhealthy_re ason.code
health.unhealthy_rea son.arguments.code	string	query	False	Filter by health.unhealthy_re ason.arguments.cod e

Name	Туре	In	Required	Description
health.unhealthy_rea son.arguments.mess age	string	query	False	Filter by health.unhealthy_re ason.arguments.me ssage
health.unhealthy_rea son.message	string	query	False	Filter by health.unhealthy_re ason.message
health.is_healthy	boolean	query	False	Filter by health.is_healthy
health.state	string	query	False	Filter by health.state
nodes.name	string	query	False	Filter by nodes.name
nodes.uuid	string	query	False	Filter by nodes.uuid
name	string	query	False	Filter by name
storage_type	string	query	False	Filter by storage_type
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 1 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
error	error	
num_records	integer	Number of shared storage pools in the cluster.
records	array[storage_pool]	
spares	array[storage_pool_show_spares]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
  },
  "self": {
   "href": "/api/resourcelink"
  }
},
"error": {
  "arguments": {
   "code": "string",
   "message": "string"
  },
  "code": "4",
  "message": "entry doesn't exist"
},
"num records": 1,
"records": {
  " links": {
    "self": {
     "href": "/api/resourcelink"
  },
  "capacity": {
   "disks": {
      "disk": {
        " links": {
          "self": {
            "href": "/api/resourcelink"
        },
        "name": "1.0.1"
      "total size": 0,
      "usable size": 0
    },
    "remaining": 0,
    "spare allocation units": {
      "available size": 0,
      "node": {
        " links": {
          "self": {
            "href": "/api/resourcelink"
```

```
},
      "name": "node1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    } ,
    "size": 0,
    "syncmirror pool": "pool0"
  },
  "total": 0,
  "used allocation units": {
    "aggregate": {
      " links": {
       "self": {
          "href": "/api/resourcelink"
       }
      },
      "name": "aggr1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    "current usage": 0,
    "node": {
      " links": {
        "self": {
          "href": "/api/resourcelink"
       }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
},
"health": {
  "state": "normal",
  "unhealthy reason": {
   "arguments": {
      "code": "string",
     "message": "string"
   },
    "code": "4",
   "message": "entry doesn't exist"
  }
},
"nodes": {
 " links": {
   "self": {
      "href": "/api/resourcelink"
```

```
}
    },
   "name": "node1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  "storage type": "SSD",
  "uuid": "string"
} ,
"spares": {
 "checksum_style": "block",
 "disk class": "solid state",
  "disk type": "fc",
  "nodes": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
   "name": "node1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 },
  "size": 10156769280,
  "syncmirror pool": "pool0",
 "usable": 9
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
10944513	Unable to retrieve shared disk capability information.
10944514	Unable to enable shared disk capability.
10944527	Storage pools are not supported in MetroCluster configurations.
10944528	Unable to retrieve MetroCluster configuration information.
11206662	There is no storage pool matching the specified UUID or name.

Error Code	Description
11206667	Storage pool feature is not enabled.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Туре	Description
error	returned_error	

Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

_links

Name	Туре	Description
next	href	
self	href	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message

_links

Name	Туре	Description
self	href	

disk

Reference to the constituent disk object.

Name	Туре	Description
_links	_links	
name	string	

storage_pool_disk

Name	Туре	Description
disk	disk	Reference to the constituent disk object.
total_size	integer	Raw capacity of the disk, in bytes.
usable_size	integer	Usable capacity of this disk, in bytes.

node

Specifies what node can use this set of allocation units.

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

storage_pool_spare_allocation_unit

Name	Туре	Description
available_size	integer	The usable capacity of this set of allocation units.
count	integer	The number of spare allocation units on this node.
node	node	Specifies what node can use this set of allocation units.
size	integer	Size of each allocation unit.
syncmirror_pool	string	The RAID SyncMirror Pool to which this allocation unit is assigned.

aggregate

The aggregate that is using this cache capacity.

Name	Туре	Description
_links	_links	
name	string	

Name	Туре	Description
uuid	string	

node

The node hosting the aggregate using this set of allocation units.

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

storage_pool_used_allocation_unit

Name	Туре	Description
aggregate	aggregate	The aggregate that is using this cache capacity.
count	integer	The number of allocation units used by this aggregate.
current_usage	integer	The amount of cache space used by this aggregate.
node	node	The node hosting the aggregate using this set of allocation units.

capacity

Name	Туре	Description
disk_count	integer	The number of disks in the storage pool.
disks	array[storage_pool_disk]	Properties of each disk used in the shared storage pool.
remaining	integer	Remaining usable capacity in the flash pool, in bytes.
spare_allocation_units	<pre>array[storage_pool_spare_allocati on_unit]</pre>	Properties of spare allocation units.
total	integer	Total size of the flash pool, in bytes.

Name	Туре	Description
used_allocation_units	array[storage_pool_used_allocation_unit]	Information about the storage pool allocation units participating in the cache tier of an aggregate.

error

Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools.

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message

health

Properties that outline shared storage pool health.

Name	Туре	Description
is_healthy	boolean	Indicates whether the storage pool is able to participate in provisioning operations.
state	string	The state of the shared storage pool.
unhealthy_reason	error	Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools.

node_reference

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

storage_pool

Name	Туре	Description
_links	_links	

Name	Туре	Description
capacity	capacity	
health	health	Properties that outline shared storage pool health.
name	string	Storage pool name.
nodes	array[node_reference]	Nodes that can use this storage pool for their aggregates.
storage_type	string	Storage type for the disks used to create the storage pool.
uuid	string	Storage pool UUID.

storage_pool_show_spares

Available spares for stoarge pool.

Name	Туре	Description
checksum_style	string	The checksum type that has been assigned to the spares.
disk_class	string	Disk class of spares.
disk_type	string	Type of disk.
nodes	array[node_reference]	Nodes that can use the usable spares for storage pool.
size	integer	Usable size of each spare, in bytes.
syncmirror_pool	string	SyncMirror spare pool.

Name	Туре	Description
usable	integer	Total number of usable spares in the bucket. The usable count for each class of spares does not include reserved spare capacity recommended by ONTAP best practices. • example: 9 • readOnly: 1 • Introduced in: 9.12 • x-nullable: true

returned error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create a new storage pool

POST /storage/pools

Introduced In: 9.11

Creates a new storage pool using available solid state capacity attached to the nodes specified.

Required properties

The following properties are required in the POST body:

- name Name of the new storage pool.
- nodes[].name or nodes[].uuid Nodes that can use cache capacity from the new storage pool. Only nodes in the same HA pair can be specified for a given storage pool. Spare cache capacity will be distributed evenly among the specified nodes.
- capacity.disk count Number of SSDs to be used to create the storage pool.

Related ONTAP commands

• storage pool create

Example:

```
POST /api/storage/pools {"nodes": [{"name": "node1"}, {"name": "node2"}],
"name": "storage_pool_1", "capacity": {"disk_count": "4"}}
```

Parameters

Name	Туре	In	Required	Description
disk_size	integer	query	False	If set, POST only selects SSDs within five percent of the specified size.
simulate	boolean	query	False	When set to "true", the end point returns a simulated layout of the proposed new storage pool, without changing system state. • Introduced in: 9.12

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 1 • Max value: 120 • Min value: 0
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Туре	Description
_links	_links	
capacity	capacity	
health	health	Properties that outline shared storage pool health.

Name	Туре	Description
name	string	Storage pool name.
nodes	array[node_reference]	Nodes that can use this storage pool for their aggregates.
storage_type	string	Storage type for the disks used to create the storage pool.
uuid	string	Storage pool UUID.

```
" links": {
  "self": {
    "href": "/api/resourcelink"
 }
},
"capacity": {
  "disks": {
   "disk": {
      " links": {
        "self": {
          "href": "/api/resourcelink"
       }
      },
      "name": "1.0.1"
    "total size": 0,
    "usable size": 0
  },
  "remaining": 0,
  "spare allocation units": {
    "available size": 0,
    "node": {
      " links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "size": 0,
    "syncmirror pool": "pool0"
  },
  "total": 0,
  "used allocation units": {
    "aggregate": {
      " links": {
        "self": {
         "href": "/api/resourcelink"
        }
      },
      "name": "aggr1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
```

```
},
      "current usage": 0,
      "node": {
        " links": {
         "self": {
           "href": "/api/resourcelink"
         }
       } ,
       "name": "node1",
       "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
 },
 "health": {
   "state": "normal",
    "unhealthy reason": {
     "arguments": {
       "code": "string",
       "message": "string"
     },
     "code": "4",
     "message": "entry doesn't exist"
   }
 },
  "nodes": {
   " links": {
    "self": {
      "href": "/api/resourcelink"
    }
    },
   "name": "node1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 },
 "storage_type": "SSD",
 "uuid": "string"
}
```

Response

```
Status: 202, Accepted
```

Name	Туре	Description
job	job_link	

Example response

Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

Response

```
Status: 201, Created
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
11206666	Storage pool is unhealthy.
11208658	A storage pool already uses the specified name.
11208660	Disk does not exist.
11208661	Disk is not a spare disk.
11208662	Disk is not an SSD.
11208663	Disk is reserved for core dump.
11208664	Could not determine checksum type of disk.
11208666	Could not determine usable size of disk.

Error Code	Description
11208668	Could not determine connectivity between controller and disk.
11208670	Could not determine original owner of disk.
11208671	Could not determine SyncMirror pool of disk.
11208673	Could not determine HA mode of node.
11208674	Could not determine HA partner of node.
11208675	Disks specified in the disk list are not visible to node.
11208678	The disk list contains disks from nodes which are not in HA pair.
11208679	Storage pools are not supported on nodes.
11208680	Internal error. Cannot determine configuration for node.
11208681	Node is not online.
11208682	Internal error. Sharing configuration mismatch.
11208684	Unable to share disk.
11208686	Disk cannot be shared.
11208687	Unable to retrieve expected sharing configuration.
11208688	Storage pool create job failed.
11208690	Not all nodes sharing the storage pool view disk as a shared disk.
11208691	Not enough matching spares available.
11208692	A disk list or count is a required parameter for storage pool creation.
11208693	Invalid number of disks specified.
11208698	Internal error. Missing node name.
11208699	Internal error. Missing partner name for node configured for HA.
11208701	Node is a standalone node. Do not specify other nodes with a standalone node.
11208703	Incorrect number of nodes specified. Specify one node or both nodes in an HA pair.
11208704	Specified nodes are not part of HA relationship. Specify one node or both nodes in an HA pair.
11208705	Disk is a data center SSD, which cannot be used in storage pools.
11208706	Disk is a SSD-ZNS, which cannot be used in storage pools.

Error Code	Description
11215756	Missing a required field for POST request.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Туре	Description
error	returned_error	

Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

_links

Name	Туре	Description
self	href	

disk

Reference to the constituent disk object.

Name	Туре	Description
_links	_links	
name	string	

storage_pool_disk

Name	Туре	Description
disk	disk	Reference to the constituent disk object.
total_size	integer	Raw capacity of the disk, in bytes.
usable_size	integer	Usable capacity of this disk, in bytes.

node

Specifies what node can use this set of allocation units.

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

storage_pool_spare_allocation_unit

Name	Туре	Description
available_size	integer	The usable capacity of this set of allocation units.
count	integer	The number of spare allocation units on this node.
node	node	Specifies what node can use this set of allocation units.
size	integer	Size of each allocation unit.
syncmirror_pool	string	The RAID SyncMirror Pool to which this allocation unit is assigned.

aggregate

The aggregate that is using this cache capacity.

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

node

The node hosting the aggregate using this set of allocation units.

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

storage_pool_used_allocation_unit

Name	Туре	Description
aggregate	aggregate	The aggregate that is using this cache capacity.
count	integer	The number of allocation units used by this aggregate.

Name	Туре	Description
current_usage	integer	The amount of cache space used by this aggregate.
node	node	The node hosting the aggregate using this set of allocation units.

capacity

Name	Туре	Description
disk_count	integer	The number of disks in the storage pool.
disks	array[storage_pool_disk]	Properties of each disk used in the shared storage pool.
remaining	integer	Remaining usable capacity in the flash pool, in bytes.
spare_allocation_units	array[storage_pool_spare_allocation_unit]	Properties of spare allocation units.
total	integer	Total size of the flash pool, in bytes.
used_allocation_units	array[storage_pool_used_allocation_unit]	Information about the storage pool allocation units participating in the cache tier of an aggregate.

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools.

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code

Name	Туре	Description
message	string	Error message

health

Properties that outline shared storage pool health.

Name	Туре	Description
is_healthy	boolean	Indicates whether the storage pool is able to participate in provisioning operations.
state	string	The state of the shared storage pool.
unhealthy_reason	error	Indicates why the storage pool is unhealthy. This property is not returned for healthy storage pools.

node_reference

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

storage_pool

Name	Туре	Description
_links	_links	
capacity	capacity	
health	health	Properties that outline shared storage pool health.
name	string	Storage pool name.
nodes	array[node_reference]	Nodes that can use this storage pool for their aggregates.
storage_type	string	Storage type for the disks used to create the storage pool.

Name	Туре	Description
uuid	string	Storage pool UUID.

job_link

Name	Туре	Description
_links	_links	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

returned_error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.