



Manage NVMe services

ONTAP 9.6 REST API reference

NetApp
May 08, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-96/ontap/protocols_nvme_services_endpoint_overview.html on May 08, 2024. Always check docs.netapp.com for the latest.

Table of Contents

- Manage NVMe services 1
 - Protocols NVMe services endpoint overview 1
 - Retrieve NVMe services 6
 - Create an NVMe service 11
 - Delete an NVMe service 16
 - Retrieve an NVMe service 18
 - Update an NVMe service 22

Manage NVMe services

Protocols NVMe services endpoint overview

Overview

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

The Non-Volatile Memory Express (NVMe) service REST API allows you to create, update, delete, and discover NVMe services for SVMs.

Examples

Creating an NVMe service for an SVM

The simplest way to create an NVMe service is to specify only the SVM, either by name or UUID. By default, the new NVMe service is enabled.

In this example, the `return_records` query parameter is used to retrieve the new NVMe service object in the REST response.

```

# The API:
POST /api/protocols/nvme/services

# The call:
curl -X POST 'https://<mgmt-
ip>/api/protocols/nvme/services?return_records=true' -H 'accept:
application/hal+json' -d '{ "svm": { "name": "svm1" } }'

# The response:
{
  "num_records": 1,
  "records": [
    {
      "svm": {
        "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
        "name": "svm1",
        "_links": {
          "self": {
            "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
          }
        }
      },
      "enabled": true,
      "_links": {
        "self": {
          "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-
005056bb7341"
        }
      }
    }
  ]
}

```

Retrieving the NVMe services for all SVMs in the cluster

```

# The API:
GET /api/protocols/nvme/services

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/services' -H 'accept:
application/hal+json'

# The response:

```

```

{
  "records": [
    {
      "svm": {
        "uuid": "ab60c350-dc68-11e8-9711-005056bbe408",
        "name": "svm0",
        "_links": {
          "self": {
            "href": "/api/svm/svms/ab60c350-dc68-11e8-9711-005056bbe408"
          }
        }
      },
      "_links": {
        "self": {
          "href": "/api/protocols/nvme/services/ab60c350-dc68-11e8-9711-005056bbe408"
        }
      }
    },
    {
      "svm": {
        "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
        "name": "svm1",
        "_links": {
          "self": {
            "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
          }
        }
      },
      "_links": {
        "self": {
          "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-005056bb7341"
        }
      }
    }
  ],
  "num_records": 2,
  "_links": {
    "self": {
      "href": "/api/protocols/nvme/services"
    }
  }
}

```

Retrieving details for a specific NVMe service

The NVMe service is identified by the UUID of its SVM.

```
# The API:
GET /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-005056bb7341' -H 'accept: application/hal+json'

# The response:
{
  "svm": {
    "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
      }
    }
  },
  "enabled": true,
  "_links": {
    "self": {
      "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-005056bb7341"
    }
  }
}
```

Disabling an NVMe service

Disabling an NVMe service shuts down all active NVMe connections for the SVM and prevents the creation of new NVMe connections.

The NVMe service to update is identified by the UUID of its SVM.

```
# The API:
PATCH /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-005056bb7341' -H 'accept: application/hal+json' -d '{"enabled": "false" }'
```

You can retrieve the NVMe service to confirm the change.

```
# The API:
GET /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-005056bb7341' -H 'accept: application/hal+json'

# The response:
{
  "svm": {
    "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
      }
    }
  },
  "enabled": false,
  "_links": {
    "self": {
      "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-005056bb7341"
    }
  }
}
```

Deleting an NVMe service

The NVMe service must be disabled before it can be deleted. In addition, all NVMe interfaces, subsystems, and subsystem maps associated with the SVM must first be deleted.

The NVMe service to delete is identified by the UUID of its SVM.

```
# The API:
DELETE /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-
dc69-11e8-b29f-005056bb7341' -H 'accept: application/hal+json'
```

Retrieve NVMe services

GET /protocols/nvme/services

Retrieves NVMe services.

Related ONTAP commands

- `vserver nvme show`

Learn more

- [DOC /protocols/nvme/services](#)

Parameters

| Name | Type | In | Required | Description |
|----------------|---------------|-------|----------|---|
| svm.uuid | string | query | False | Filter by svm.uuid |
| svm.name | string | query | False | Filter by svm.name |
| enabled | boolean | query | False | Filter by enabled |
| fields | array[string] | query | False | Specify the fields to return. |
| max_records | integer | query | False | Limit the number of records returned. |
| return_records | boolean | query | False | The default is true for GET calls. When set to false, only the number of records is returned. |

| Name | Type | In | Required | Description |
|----------------|---------------|-------|----------|--|
| return_timeout | integer | query | False | The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. |
| order_by | array[string] | query | False | Order results by specified fields and optional [asc |

Response

Status: 200, Ok

| Name | Type | Description |
|-------------|---------------------------------------|--------------------|
| _links | _links | |
| num_records | integer | Number of records. |
| records | array[nvme_service] | |

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    }
  }
}
```

Error

Status: Default, Error

| Name | Type | Description |
|-------|-----------------------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| next | href | |
| self | href | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

svm

SVM, applies only to SVM-scoped objects.

| Name | Type | Description |
|--------|------------------------|-----------------------------------|
| _links | _links | |
| name | string | The name of the SVM. |
| uuid | string | The unique identifier of the SVM. |

nvme_service

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

An NVMe service is identified by the UUID of its SVM.

| Name | Type | Description |
|--------|------------------------|-------------|
| _links | _links | |

| Name | Type | Description |
|---------|---------------------|--|
| enabled | boolean | The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM. This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST. |
| svm | svm | SVM, applies only to SVM-scoped objects. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Create an NVMe service

POST /protocols/nvme/services

Creates an NVMe service.

Required properties

- `svm.uuid` or `svm.name` - The existing SVM in which to create the NVMe service.

Related ONTAP commands

- `vserver nvme create`

Learn more

- [DOC /protocols/nvme/services](#)

Request Body

| Name | Type | Description |
|----------------------|------------------------|---|
| <code>_links</code> | _links | |
| <code>enabled</code> | boolean | <p>The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.</p> <p>This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p> |
| <code>svm</code> | svm | SVM, applies only to SVM-scoped objects. |

Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

Response

Status: 201, Created

| Name | Type | Description |
|-------------|---------------------------------------|--------------------|
| _links | _links | |
| num_records | integer | Number of records. |
| records | array[nvme_service] | |

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    }
  }
}
```

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|---|
| 1115127 | The cluster lacks a valid NVMe license. |
| 2621462 | The supplied SVM does not exist. |
| 2621507 | NVMe is not allowed for the specified SVM. |
| 2621706 | The specified <code>svm.uuid</code> and <code>svm.name</code> do not refer to the same SVM. |
| 2621707 | No SVM was specified. Either <code>svm.name</code> or <code>svm.uuid</code> must be supplied. |
| 72089650 | An NVMe service already exists for the specified SVM. |
| 5374893 | The SVM is stopped. The SVM must be running to create an NVMe service. |
| 72089900 | An NVMe service cannot be creating in an SVM that is configured for a SAN protocol. |

| Name | Type | Description |
|-------|-------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

svm

SVM, applies only to SVM-scoped objects.

| Name | Type | Description |
|--------|------------------------|-----------------------------------|
| _links | _links | |
| name | string | The name of the SVM. |
| uuid | string | The unique identifier of the SVM. |

nvme_service

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

An NVMe service is identified by the UUID of its SVM.

| Name | Type | Description |
|---------|------------------------|---|
| _links | _links | |
| enabled | boolean | <p>The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.</p> <p>This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p> |
| svm | svm | SVM, applies only to SVM-scoped objects. |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| next | href | |
| self | href | |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Delete an NVMe service

```
DELETE /protocols/nvme/services/{svm.uuid}
```

Deletes an NVMe service. An NVMe service must be disabled before it can be deleted. In addition, all NVMe interfaces, subsystems, and subsystem maps associated with the SVM must first be deleted.

Related ONTAP commands

- `vserver nvme delete`

Learn more

- [DOC /protocols/nvme/services](#)

Parameters

| Name | Type | In | Required | Description |
|----------|--------|------|----------|-------------|
| svm.uuid | string | path | True | |

Response

Status: 200, Ok

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|---|
| 2621462 | The supplied SVM does not exist. |
| 72089651 | The supplied SVM does not have an NVMe service. |
| 72089653 | There are subsystems associated with the NVMe service SVM. The subsystems must be removed before deleting the NVMe service. |
| 72089654 | There are NVMe-oF LIFs associated with the NVMe service SVM. The LIFs must be removed before deleting the NVMe service. |
| 72090028 | The NVMe service is enabled. The NVMe service must be disabled before it can be deleted. |

| Name | Type | Description |
|-------|-------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Retrieve an NVMe service

GET /protocols/nvme/services/{svm.uuid}

Retrieves an NVMe service.

Related ONTAP commands

- `vserver nvme show`

Learn more

- [DOC /protocols/nvme/services](#)

Parameters

| Name | Type | In | Required | Description |
|----------|--------|------|----------|---|
| svm.uuid | string | path | True | The unique identifier of the SVM whose NVMe service is to be retrieved. |

| Name | Type | In | Required | Description |
|--------|---------------|-------|----------|-------------------------------|
| fields | array[string] | query | False | Specify the fields to return. |

Response

Status: 200, Ok

| Name | Type | Description |
|---------|------------------------|---|
| _links | _links | |
| enabled | boolean | <p>The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.</p> <p>This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p> |
| svm | svm | SVM, applies only to SVM-scoped objects. |

Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|---|
| 2621462 | The supplied SVM does not exist. |
| 72089651 | The supplied SVM does not have an NVMe service. |

| Name | Type | Description |
|-------|-----------------------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

svm

SVM, applies only to SVM-scoped objects.

| Name | Type | Description |
|--------|------------------------|-----------------------------------|
| _links | _links | |
| name | string | The name of the SVM. |
| uuid | string | The unique identifier of the SVM. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Update an NVMe service

PATCH /protocols/nvme/services/{svm.uuid}

Updates an NVMe service.

Related ONTAP commands

- `vserver nvme modify`

Learn more

- [DOC /protocols/nvme/services](#)

Parameters

| Name | Type | In | Required | Description |
|----------|--------|------|----------|---|
| svm.uuid | string | path | True | The unique identifier of the SVM whose NVMe service is to be updated. |

Request Body

| Name | Type | Description |
|---------|------------------------|---|
| _links | _links | |
| enabled | boolean | <p>The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.</p> <p>This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p> |
| svm | svm | SVM, applies only to SVM-scoped objects. |

Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

Response

Status: 200, Ok

Error

Status: Default

ONTAP Error Response Codes

| Error Code | Description |
|------------|--|
| 1115127 | The cluster lacks a valid NVMe license. |
| 2621462 | The supplied SVM does not exist. |
| 72089651 | The supplied SVM does not have an NVMe service. |
| 5374893 | The SVM is stopped. The SVM must be running to create an NVMe service. |

| Name | Type | Description |
|-------|-------|-------------|
| error | error | |

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

| Name | Type | Description |
|------|--------|-------------|
| href | string | |

_links

| Name | Type | Description |
|------|----------------------|-------------|
| self | href | |

svm

SVM, applies only to SVM-scoped objects.

| Name | Type | Description |
|--------|------------------------|-----------------------------------|
| _links | _links | |
| name | string | The name of the SVM. |
| uuid | string | The unique identifier of the SVM. |

nvme_service

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

An NVMe service is identified by the UUID of its SVM.

| Name | Type | Description |
|---------|------------------------|---|
| _links | _links | |
| enabled | boolean | <p>The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.</p> <p>This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p> |
| svm | svm | SVM, applies only to SVM-scoped objects. |

error_arguments

| Name | Type | Description |
|---------|--------|------------------|
| code | string | Argument code |
| message | string | Message argument |

error

| Name | Type | Description |
|-----------|--|---|
| arguments | array[error_arguments] | Message arguments |
| code | string | Error code |
| message | string | Error message |
| target | string | The target parameter that caused the error. |

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.