



# **Manage NVMe services**

## **ONTAP 9.6 REST API reference**

NetApp  
April 02, 2024

This PDF was generated from [https://docs.netapp.com/us-en/ontap-restapi-96/ontap/protocols\\_nvme\\_services\\_endpoint\\_overview.html](https://docs.netapp.com/us-en/ontap-restapi-96/ontap/protocols_nvme_services_endpoint_overview.html) on April 02, 2024. Always check docs.netapp.com for the latest.

# Table of Contents

- Manage NVMe services . . . . . 1
  - Protocols NVMe services endpoint overview . . . . . 1
  - Retrieve NVMe services . . . . . 6
  - Create an NVMe service . . . . . 11
  - Delete an NVMe service . . . . . 16
  - Retrieve an NVMe service . . . . . 18
  - Update an NVMe service . . . . . 22

# Manage NVMe services

## Protocols NVMe services endpoint overview

### Overview

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

The Non-Volatile Memory Express (NVMe) service REST API allows you to create, update, delete, and discover NVMe services for SVMs.

### Examples

#### Creating an NVMe service for an SVM

The simplest way to create an NVMe service is to specify only the SVM, either by name or UUID. By default, the new NVMe service is enabled.

In this example, the `return_records` query parameter is used to retrieve the new NVMe service object in the REST response.

```
# The API:
POST /api/protocols/nvme/services

# The call:
curl -X POST 'https://<mgmt-
ip>/api/protocols/nvme/services?return_records=true' -H 'accept:
application/hal+json' -d '{ "svm": { "name": "svm1" } }'

# The response:
{
  "num_records": 1,
  "records": [
    {
      "svm": {
        "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
        "name": "svm1",
        "_links": {
          "self": {
            "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
          }
        }
      },
      "enabled": true,
      "_links": {
        "self": {
          "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-
005056bb7341"
        }
      }
    }
  ]
}
```

## Retrieving the NVMe services for all SVMs in the cluster

```
# The API:
GET /api/protocols/nvme/services

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/services' -H 'accept:
application/hal+json'

# The response:
```

```

{
  "records": [
    {
      "svm": {
        "uuid": "ab60c350-dc68-11e8-9711-005056bbe408",
        "name": "svm0",
        "_links": {
          "self": {
            "href": "/api/svm/svms/ab60c350-dc68-11e8-9711-005056bbe408"
          }
        }
      },
      "_links": {
        "self": {
          "href": "/api/protocols/nvme/services/ab60c350-dc68-11e8-9711-005056bbe408"
        }
      }
    },
    {
      "svm": {
        "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
        "name": "svm1",
        "_links": {
          "self": {
            "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
          }
        }
      },
      "_links": {
        "self": {
          "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-005056bb7341"
        }
      }
    }
  ],
  "num_records": 2,
  "_links": {
    "self": {
      "href": "/api/protocols/nvme/services"
    }
  }
}

```

## Retrieving details for a specific NVMe service

The NVMe service is identified by the UUID of its SVM.

```
# The API:
GET /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-005056bb7341' -H 'accept: application/hal+json'

# The response:
{
  "svm": {
    "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
      }
    }
  },
  "enabled": true,
  "_links": {
    "self": {
      "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-005056bb7341"
    }
  }
}
```

## Disabling an NVMe service

Disabling an NVMe service shuts down all active NVMe connections for the SVM and prevents the creation of new NVMe connections.

The NVMe service to update is identified by the UUID of its SVM.

```
# The API:
PATCH /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-
dc69-11e8-b29f-005056bb7341' -H 'accept: application/hal+json' -d '{
"enabled": "false" }'
```

You can retrieve the NVMe service to confirm the change.

```
# The API:
GET /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-dc69-
11e8-b29f-005056bb7341' -H 'accept: application/hal+json'

# The response:
{
"svm": {
  "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
  "name": "svm1",
  "_links": {
    "self": {
      "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
    }
  }
},
"enabled": false,
"_links": {
  "self": {
    "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-
005056bb7341"
  }
}
}
```

## Deleting an NVMe service

The NVMe service must be disabled before it can be deleted. In addition, all NVMe interfaces, subsystems, and subsystem maps associated with the SVM must first be deleted.

The NVMe service to delete is identified by the UUID of its SVM.

```
# The API:
DELETE /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/protocols/nvme/services/bfblbeb0-
dc69-11e8-b29f-005056bb7341' -H 'accept: application/hal+json'
```

## Retrieve NVMe services

GET /protocols/nvme/services

Retrieves NVMe services.

### Related ONTAP commands

- `vserver nvme show`

### Learn more

- [DOC /protocols/nvme/services](#)

### Parameters

Name	Type	In	Required	Description
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
enabled	boolean	query	False	Filter by enabled
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.



Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">_links</a>	
num_records	integer	Number of records.
records	array[ <a href="#">nvme_service</a> ]	

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    }
  }
}
```

## Error

Status: Default, Error

Name	Type	Description
error	error	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

\_links

Name	Type	Description
self	<a href="#">href</a>	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
<a href="#">_links</a>	<a href="#">_links</a>	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

nvme\_service

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

An NVMe service is identified by the UUID of its SVM.

Name	Type	Description
<a href="#">_links</a>	<a href="#">_links</a>	

Name	Type	Description
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.

#### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Create an NVMe service

POST `/protocols/nvme/services`

Creates an NVMe service.

### Required properties

- `svm.uuid` or `svm.name` - The existing SVM in which to create the NVMe service.

## Related ONTAP commands

- `vserver nvme create`

## Learn more

- [DOC /protocols/nvme/services](#)

## Request Body

Name	Type	Description
<code>_links</code>	<code>_links</code>	
<code>enabled</code>	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
<code>svm</code>	<code>svm</code>	SVM, applies only to SVM-scoped objects.

## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

## Response

Status: 201, Created

Name	Type	Description
_links	<a href="#">_links</a>	
num_records	integer	Number of records.
records	array[nvme_service]	

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    }
  }
}
```

## Error

Status: Default

## ONTAP Error Response Codes

Error Code	Description
1115127	The cluster lacks a valid NVMe license.
2621462	The supplied SVM does not exist.
2621507	NVMe is not allowed for the specified SVM.
2621706	The specified <code>svm.uuid</code> and <code>svm.name</code> do not refer to the same SVM.
2621707	No SVM was specified. Either <code>svm.name</code> or <code>svm.uuid</code> must be supplied.
72089650	An NVMe service already exists for the specified SVM.
5374893	The SVM is stopped. The SVM must be running to create an NVMe service.
72089900	An NVMe service cannot be creating in an SVM that is configured for a SAN protocol.

Name	Type	Description
error	error	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions



## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

nvme\_service

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

An NVMe service is identified by the UUID of its SVM.

Name	Type	Description
_links	<a href="#">_links</a>	
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.

\_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Delete an NVMe service

DELETE /protocols/nvme/services/{svm.uuid}

Deletes an NVMe service. An NVMe service must be disabled before it can be deleted. In addition, all NVMe interfaces, subsystems, and subsystem maps associated with the SVM must first be deleted.

### Related ONTAP commands

- `vserver nvme delete`

### Learn more

- [DOC /protocols/nvme/services](#)

### Parameters

Name	Type	In	Required	Description
svm.uuid	string	path	True	

## Response

Status: 200, Ok

## Error

Status: Default

### ONTAP Error Response Codes

Error Code	Description
2621462	The supplied SVM does not exist.
72089651	The supplied SVM does not have an NVMe service.
72089653	There are subsystems associated with the NVMe service SVM. The subsystems must be removed before deleting the NVMe service.
72089654	There are NVMe-oF LIFs associated with the NVMe service SVM. The LIFs must be removed before deleting the NVMe service.
72090028	The NVMe service is enabled. The NVMe service must be disabled before it can be deleted.

Name	Type	Description
error	error	

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

### See Definitions

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Retrieve an NVMe service

```
GET /protocols/nvme/services/{svm.uuid}
```

Retrieves an NVMe service.

### Related ONTAP commands

- `vserver nvme show`

### Learn more

- [DOC /protocols/nvme/services](#)

### Parameters

Name	Type	In	Required	Description
svm.uuid	string	path	True	The unique identifier of the SVM whose NVMe service is to be retrieved.

Name	Type	In	Required	Description
fields	array[string]	query	False	Specify the fields to return.

## Response

Status: 200, Ok

Name	Type	Description
<a href="#">_links</a>	<a href="#">_links</a>	
enabled	boolean	<p>The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.</p> <p>This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p>
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

## Error

Status: Default

### ONTAP Error Response Codes

Error Code	Description
2621462	The supplied SVM does not exist.
72089651	The supplied SVM does not have an NVMe service.

Name	Type	Description
error	<a href="#">error</a>	

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Update an NVMe service

PATCH /protocols/nvme/services/{svm.uuid}

Updates an NVMe service.

## Related ONTAP commands

- `vserver nvme modify`

## Learn more

- [DOC /protocols/nvme/services](#)

## Parameters

Name	Type	In	Required	Description
svm.uuid	string	path	True	The unique identifier of the SVM whose NVMe service is to be updated.

## Request Body

Name	Type	Description
<a href="#">_links</a>	<a href="#">_links</a>	
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.



## Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

## Response

Status: 200, Ok

## Error

Status: Default

### ONTAP Error Response Codes

Error Code	Description
1115127	The cluster lacks a valid NVMe license.
2621462	The supplied SVM does not exist.
72089651	The supplied SVM does not have an NVMe service.
5374893	The SVM is stopped. The SVM must be running to create an NVMe service.

Name	Type	Description
error	error	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

nvme\_service

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

An NVMe service is identified by the UUID of its SVM.

Name	Type	Description
_links	<a href="#">_links</a>	
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
svm	<a href="#">svm</a>	SVM, applies only to SVM-scoped objects.

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.