



Manage storage ports

ONTAP 9.9.1 REST API reference

NetApp
April 02, 2024

Table of Contents

- Manage storage ports 1
 - Storage ports endpoint overview 1
 - Retrieve storage ports 6
 - Retrieve a storage port 14

Manage storage ports

Storage ports endpoint overview

Retrieving storage port information

The storage port GET API retrieves all of the storage ports in the cluster.

Examples

1) Retrieve a list of storage ports from the cluster

The following example shows the response with a list of storage ports in the cluster:

```
# The API:
/api/storage/ports

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/ports" -H "accept:
application/hal+json"

# The response:
{
  "records": [
    {
      "node": {
        "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
        "name": "node-1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-
00a0985a72ee"
          }
        }
      },
      "name": "0a",
      "_links": {
        "self": {
          "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-
00a0985a72ee/0a"
        }
      }
    },
  ]
}
```

```

{
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
      }
    }
  },
  "name": "0b",
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0b"
    }
  }
},
{
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
      }
    }
  },
  "name": "0c",
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0c"
    }
  }
},
{
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
      }
    }
  }
}

```

```

    }
  },
  "name": "0d",
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0d"
    }
  }
},
{
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
      }
    }
  },
  "name": "0e",
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0e"
    }
  }
},
{
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
      }
    }
  },
  "name": "0f",
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0f"
    }
  }
}

```

```

    }
  },
  {
    "node": {
      "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
      "name": "node-1",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
        }
      }
    },
    "name": "0g",
    "_links": {
      "self": {
        "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0g"
      }
    }
  },
],
"num_records": 7,
"_links": {
  "self": {
    "href": "/api/storage/ports"
  }
}
}

```

2) Retrieve a specific storage port from the cluster

The following example shows the response of the requested storage port. If there is no storage port with the requested node uuid and name, an error is returned.

```
# The API:
/api/storage/ports/{node.uuid}/{name}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0a" -H "accept: application/hal+json"

# The response:
{
  "node": {
    "uuid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
    "name": "node-1",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
      }
    }
  },
  "name": "0a",
  "description": "SAS Host Adapter 0a (PMC-Sierra PM8001 rev. C)",
  "wwn": "500a098003633df0",
  "speed": 6,
  "cable": {
    "part_number": "112-00429+A0",
    "serial_number": "629230774",
    "identifier": "500a0980066e2c01-500a098003633df0",
    "length": "0.5m"
  },
  "state": "online",
  "enabled": true,
  "firmware_version": "01.12.09.00",
  "type": "sas",
  "redundant": true,
  "in_use": true,
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0a"
    }
  }
}
```

Retrieve storage ports

GET /storage/ports

Introduced In: 9.6

Retrieves a collection of storage ports.

Related ONTAP commands

- `storage port show`

Learn more

- [DOC /storage/ports](#)

Parameters

Name	Type	In	Required	Description
firmware_version	string	query	False	Filter by firmware_version <ul style="list-style-type: none">• Introduced in: 9.9
name	string	query	False	Filter by name
speed	number	query	False	Filter by speed
cable.identifier	string	query	False	Filter by cable.identifier
cable.serial_number	string	query	False	Filter by cable.serial_number
cable.part_number	string	query	False	Filter by cable.part_number
cable.length	string	query	False	Filter by cable.length
redundant	boolean	query	False	Filter by redundant <ul style="list-style-type: none">• Introduced in: 9.9

Name	Type	In	Required	Description
type	string	query	False	Filter by type • Introduced in: 9.9
wwpn	string	query	False	Filter by wwpn • Introduced in: 9.9
node.name	string	query	False	Filter by node.name
node.uuid	string	query	False	Filter by node.uuid
mac_address	string	query	False	Filter by mac_address
board_name	string	query	False	Filter by board_name
error.corrective_action	string	query	False	Filter by error.corrective_action
error.message	string	query	False	Filter by error.message
serial_number	string	query	False	Filter by serial_number
state	string	query	False	Filter by state
wwn	string	query	False	Filter by wwn
part_number	string	query	False	Filter by part_number
in_use	boolean	query	False	Filter by in_use • Introduced in: 9.9
mode	string	query	False	Filter by mode • Introduced in: 9.8

Name	Type	In	Required	Description
enabled	boolean	query	False	Filter by enabled <ul style="list-style-type: none"> • Introduced in: 9.9
description	string	query	False	Filter by description
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> • Default value: 1 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

Status: 200, Ok

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[storage_port]	

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "cable": {
      "identifier": "500a0980000b6c3f-50000d1703544b80",
      "length": "2m",
      "part_number": "112-00431+A0",
      "serial_number": "616930439"
    },
    "description": "SAS Host Adapter 2a (PMC-Sierra PM8072 rev. C)",
    "firmware_version": "03.08.09.00",
    "mode": "storage",
    "name": "2a",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "part_number": "111-03801",
    "serial_number": "7A2463CC45B",
    "speed": "6",
    "state": "online",
    "type": "sas",
    "wwn": "50000d1703544b80"
  }
}
```

Error

Status: Default, Error

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

cable

Name	Type	Description
identifier	string	
length	string	
part_number	string	
serial_number	string	

error

Name	Type	Description
corrective_action	string	Error corrective action
message	string	Error message

_links

Name	Type	Description
self	href	

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

storage_port

Name	Type	Description
board_name	string	
cable	cable	
description	string	
enabled	boolean	
error	error	
firmware_version	string	
in_use	boolean	Specifies whether any devices are connected through this port
mac_address	string	
mode	string	Operational mode of a non-dedicated Ethernet port
name	string	
node	node	
part_number	string	
redundant	boolean	Specifies whether all devices connected through this port have a redundant path from another port
serial_number	string	
speed	number	Operational port speed in Gbps
state	string	
type	string	
wwn	string	World Wide Name
wwpn	string	World Wide Port Name

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve a storage port

GET /storage/ports/{node.uuid}/{name}

Introduced In: 9.6

Retrieves a specific storage port.

Related ONTAP commands

- `storage port show`

Learn more

- [DOC /storage/ports](#)

Parameters

Name	Type	In	Required	Description
node.uuid	string	path	True	Node UUID
name	string	path	True	Port name
fields	array[string]	query	False	Specify the fields to return.

Response

Status: 200, Ok

Name	Type	Description
board_name	string	

Name	Type	Description
cable	cable	
description	string	
enabled	boolean	
error	error	
firmware_version	string	
in_use	boolean	Specifies whether any devices are connected through this port
mac_address	string	
mode	string	Operational mode of a non-dedicated Ethernet port
name	string	
node	node	
part_number	string	
redundant	boolean	Specifies whether all devices connected through this port have a redundant path from another port
serial_number	string	
speed	number	Operational port speed in Gbps
state	string	
type	string	
wwn	string	World Wide Name
wwpn	string	World Wide Port Name

Example response

```
{
  "cable": {
    "identifier": "500a0980000b6c3f-50000d1703544b80",
    "length": "2m",
    "part_number": "112-00431+A0",
    "serial_number": "616930439"
  },
  "description": "SAS Host Adapter 2a (PMC-Sierra PM8072 rev. C)",
  "firmware_version": "03.08.09.00",
  "mode": "storage",
  "name": "2a",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "part_number": "111-03801",
  "serial_number": "7A2463CC45B",
  "speed": "6",
  "state": "online",
  "type": "sas",
  "wwn": "50000d1703544b80"
}
```

Error

Status: Default, Error

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

cable

Name	Type	Description
identifier	string	
length	string	
part_number	string	
serial_number	string	

error

Name	Type	Description
corrective_action	string	Error corrective action
message	string	Error message

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.