



Install the hardware

Install and maintain

NetApp
February 13, 2026

This PDF was generated from <https://docs.netapp.com/us-en/ontap-systems-switches/switch-cisco-9336c-fx2/install-hardware-workflow.html> on February 13, 2026. Always check docs.netapp.com for the latest.

Table of Contents

Install the hardware	1
Hardware install workflow for Cisco Nexus 9336C-FX2 and 9336C-FX2-T switches	1
Complete the Cisco Nexus 9336C-FX2 or 9336C-FX2-T cabling worksheet	1
9336C-FX2 sample cabling worksheet	1
9336C-FX2 blank cabling worksheet	3
9336C-FX2-T sample cabling worksheet (12-port)	4
9336C-FX2-T blank cabling worksheet (12-port)	5
Install 9336C-FX2 and 9336C-FX2-T cluster switches	6
Install Cisco Nexus 9336C-FX2 and 9336C-FX2-T switches in a NetApp cabinet	7
Review cabling and configuration considerations	11
Support for NVIDIA CX6, CX6-DX, and CX7 Ethernet ports	11
25GbE FEC requirements	12
Ports do not link up due to TCAM resources	12

Install the hardware

Hardware install workflow for Cisco Nexus 9336C-FX2 and 9336C-FX2-T switches

To install and configure the hardware for 9336C-FX2 and 9336C-FX2-T cluster switches, follow these steps:

1

[Complete the cabling worksheet](#)

The sample cabling worksheet provides examples of recommended port assignments from the switches to the controllers. The blank worksheet provides a template that you can use in setting up your cluster.

2

[Install the switch](#)

Install the 9336C-FX2 and 9336C-FX2-T switches.

3

[Install the switch in a NetApp cabinet](#)

Install the 9336C-FX2 and 9336C-FX2-T switches and pass-through panel in a NetApp cabinet as required.

4

[Review cabling and configuration](#)

Review support for NVIDIA Ethernet ports, 25GbE FEC requirements, and information on TCAM resources.

Complete the Cisco Nexus 9336C-FX2 or 9336C-FX2-T cabling worksheet

If you want to document the supported platforms, download a PDF of this page and complete the cabling worksheet.

The sample cabling worksheet provides examples of recommended port assignments from the switches to the controllers. The blank worksheet provides a template that you can use in setting up your cluster.

- [9336C-FX2 sample cabling worksheet](#)
- [9336C-FX2 blank cabling worksheet](#)
- [9336C-FX2-T sample cabling worksheet \(12-port\)](#)
- [9336C-FX2-T blank cabling worksheet \(12-port\)](#)

9336C-FX2 sample cabling worksheet

The sample port definition on each pair of switches is as follows:

Cluster switch A		Cluster switch B	
Switch port	Node and port usage	Switch port	Node and port usage
1	4x10GbE node 1	1	4x10GbE node 1
2	4x10GbE node 2	2	4x10GbE node 2
3	4x10GbE node 3	3	4x10GbE node 3
4	4x25GbE node 4	4	4x25GbE node 4
5	4x25GbE node 5	5	4x25GbE node 5
6	4x25GbE node 6	6	4x25GbE node 6
7	40/100GbE node 7	7	40/100GbE node 7
8	40/100GbE node 8	8	40/100GbE node 8
9	40/100GbE node 9	9	40/100GbE node 9
10	40/100GbE node 10	10	40/100GbE node 10
11	40/100GbE node 11	11	40/100GbE node 11
12	40/100GbE node 12	12	40/100GbE node 12
13	40/100GbE node 13	13	40/100GbE node 13
14	40/100GbE node 14	14	40/100GbE node 14
15	40/100GbE node 15	15	40/100GbE node 15
16	40/100GbE node 16	16	40/100GbE node 16
17	40/100GbE node 17	17	40/100GbE node 17
18	40/100GbE node 18	18	40/100GbE node 18
19	40/100GbE node 19	19	40/100GbE node 19
20	40/100GbE node 20	20	40/100GbE node 20
21	40/100GbE node 21	21	40/100GbE node 21

Cluster switch A		Cluster switch B	
22	40/100GbE node 22	22	40/100GbE node 22
23	40/100GbE node 23	23	40/100GbE node 23
24	40/100GbE node 24	24	40/100GbE node 24
25 through 34	Reserved	25 through 34	Reserved
35	100GbE ISL to switch B port 35	35	100GbE ISL to switch A port 35
36	100GbE ISL to switch B port 36	36	100GbE ISL to switch A port 36

9336C-FX2 blank cabling worksheet

You can use the blank cabling worksheet to document the platforms that are supported as nodes in a cluster. The *Supported Cluster Connections* section of the [Hardware Universe](#) defines the cluster ports used by the platform.

Cluster switch A		Cluster switch B	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
10		10	
11		11	

Cluster switch A		Cluster switch B	
12		12	
13		13	
14		14	
15		15	
16		16	
17		17	
18		18	
19		19	
20		20	
21		21	
22		22	
23		23	
24		24	
25 through 34	Reserved	25 through 34	Reserved
35	100GbE ISL to switch B port 35	35	100GbE ISL to switch A port 35
36	100GbE ISL to switch B port 36	36	100GbE ISL to switch A port 36

9336C-FX2-T sample cabling worksheet (12-port)

The sample port definition on each pair of switches is as follows:

Cluster switch A		Cluster switch B	
Switch port	Node and port usage	Switch port	Node and port usage
1	4x10GbE node 1	1	4x10GbE node 1

Cluster switch A		Cluster switch B	
2	4x10GbE node 2	2	4x10GbE node 2
3	4x10GbE node 3	3	4x10GbE node 3
4	4x25GbE node 4	4	4x25GbE node 4
5	4x25GbE node 5	5	4x25GbE node 5
6	4x25GbE node 6	6	4x25GbE node 6
7	40/100GbE node 7	7	40/100GbE node 7
8	40/100GbE node 8	8	40/100GbE node 8
9	40/100GbE node 9	9	40/100GbE node 9
10	40/100GbE node 10	10	40/100GbE node 10
11 through 34	Requires license	11 through 34	Requires license
35	100GbE ISL to switch B port 35	35	100GbE ISL to switch A port 35
36	100GbE ISL to switch B port 36	36	100GbE ISL to switch A port 36

9336C-FX2-T blank cabling worksheet (12-port)

You can use the blank cabling worksheet to document the platforms that are supported as nodes in a cluster. The *Supported Cluster Connections* section of the [Hardware Universe](#) defines the cluster ports used by the platform.

Cluster switch A		Cluster switch B	
1		1	
2		2	
3		3	
4		4	
5		5	

Cluster switch A		Cluster switch B	
6		6	
7		7	
8		8	
9		9	
10		10	
11 through 34	Requires license	11 through 34	Requires license
35	100GbE ISL to switch B port 35	35	100GbE ISL to switch A port 35
36	100GbE ISL to switch B port 36	36	100GbE ISL to switch A port 36

See the [Hardware Universe](#) for more information on switch ports.

What's next

After you've completed your cabling worksheets, you can [install the switch](#).

Install 9336C-FX2 and 9336C-FX2-T cluster switches

Follow this procedure to set up and configure the Cisco Nexus 9336C-FX2 and 9336C-FX2-T switches.

Before you begin

Make sure you have the following:

- Access to an HTTP, FTP, or TFTP server at the installation site to download the applicable NX-OS and Reference Configuration File (RCF) releases.
- Applicable NX-OS version, downloaded from the [Cisco Software Download](#) page.
- Applicable licenses, network and configuration information, and cables.
- Completed [cabling worksheets](#).
- Applicable NetApp cluster network and management network RCFs downloaded from the NetApp Support Site at mysupport.netapp.com. All Cisco cluster network and management network switches arrive with the standard Cisco factory-default configuration. These switches also have the current version of the NX-OS software but do not have the RCFs loaded.
- [Required switch and ONTAP documentation](#).

Steps

1. Rack the cluster network and management network switches and controllers.

If you are installing the...	Then...
Cisco Nexus 9336C-FX2 in a NetApp system cabinet	See the <i>Installing a Cisco Nexus 9336C-FX2 cluster switch and pass-through panel in a NetApp cabinet</i> guide for instructions to install the switch in a NetApp cabinet.
Equipment in a Telco rack	See the procedures provided in the switch hardware installation guides and the NetApp installation and setup instructions.

2. Cable the cluster network and management network switches to the controllers using the completed cabling worksheets.
3. Power on the cluster network and management network switches and controllers.

What's next?

Optionally, you can [install a Cisco Nexus 9336C-FX2 switch in a NetApp cabinet](#). Otherwise, go to [review cabling and configuration](#).

Install Cisco Nexus 9336C-FX2 and 9336C-FX2-T switches in a NetApp cabinet

Depending on your configuration, you might need to install the Cisco Nexus 9336C-FX2 and 9336C-FX2-T switch and pass-through panel in a NetApp cabinet. Standard brackets are included with the switch.

Before you begin

Make sure you have the following:

- The pass-through panel kit, which is available from NetApp (part number X8784-R6).

The NetApp pass-through panel kit contains the following hardware:

- One pass-through blanking panel
- Four 10-32 x .75 screws
- Four 10-32 clip nuts

- For each switch, eight 10-32 or 12-24 screws and clip nuts to mount the brackets and slider rails to the front and rear cabinet posts.
- The Cisco standard rail kit to install the switch in a NetApp cabinet.



The jumper cords are not included with the pass-through kit and should be included with your switches. If they were not shipped with the switches, you can order them from NetApp (part number X1558A-R6).

- For initial preparation requirements, kit contents, and safety precautions, see [Cisco Nexus 9000 Series Hardware Installation Guide](#).


Steps

1. Install the pass-through blanking panel in the NetApp cabinet.

- a. Determine the vertical location of the switches and blanking panel in the cabinet.

In this procedure, the blanking panel is installed in U40.


- b. Install two clip nuts on each side in the appropriate square holes for front cabinet rails.
- c. Center the panel vertically to prevent intrusion into adjacent rack space, and then tighten the screws.
- d. Insert the female connectors of both 48-inch jumper cords from the rear of the panel and through the brush assembly.



(1) Female connector of the jumper cord.

2. Install the rack-mount brackets on the Nexus 9336C-FX2 switch chassis.

- a. Position a front rack-mount bracket on one side of the switch chassis so that the mounting ear is aligned with the chassis faceplate (on the PSU or fan side), and then use four M4 screws to attach the bracket to the chassis.




- b. Repeat step 2a with the other front rack-mount bracket on the other side of the switch.

- c. Install the rear rack-mount bracket on the switch chassis.

- d. Repeat step 2c with the other rear rack-mount bracket on the other side of the switch.


3. Install the clip nuts in the square hole locations for all four IEA posts.



The two 9336C-FX2 and 9336C-FX2-T switches are always mounted in the top 2U of the cabinet RU41 and 42.

4. Install the slider rails in the cabinet.

- Position the first slider rail at the RU42 mark on the back side of the rear left post, insert screws with the matching thread type, and then tighten the screws with your fingers.



(1) As you gently slide the slider rail, align it to the screw holes in the rack.

(2) Tighten the screws of the slider rails to the cabinet posts.


- b. Repeat step 4a for the right-side rear post.
- c. Repeat steps 4a and 4b at the RU41 locations on the cabinet.

5. Install the switch in the cabinet.



This step requires two people: one person to support the switch from the front and another to guide the switch into the rear slider rails.


- a. Position the back of the switch at RU41.



(1) As the chassis is pushed toward the rear posts, align the two rear rack-mount guides with the slider rails.

(2) Gently slide the switch until the front rack-mount brackets are flush with the front posts.

- b. Attach the switch to the cabinet.



(1) With one person holding the front of the chassis level, the other person should fully tighten the four rear screws to the cabinet posts.

- c. With the chassis now supported without assistance, fully tighten the front screws to the posts.
- d. Repeat steps 5a through 5c for the second switch at the RU42 location.



By using the fully installed switch as a support, it is not necessary to hold the front of the second switch during the installation process.

6. When the switches are installed, connect the jumper cords to the switch power inlets.
7. Connect the male plugs of both jumper cords to the closest available PDU outlets.



To maintain redundancy, the two cords must be connected to different PDUs.

8. Connect the management port on each 9336C-FX2 and 9336C-FX2-T switches to either of the management switches (if ordered) or connect them directly to your management network.

The management port is the upper-right port located on the PSU side of the switch. The CAT6 cable for each switch needs to be routed through the pass-through panel after the switches are installed to connect to the management switches or management network.

What's next?

After you've installed the switches in the NetApp cabinet, you can [configure the Cisco Nexus 9336C-FX2 and 9336C-FX2-T switches](#).

Review cabling and configuration considerations

Before configuring your 9336C-FX2 and 9336C-FX2-T switches, review the following considerations.

Support for NVIDIA CX6, CX6-DX, and CX7 Ethernet ports

If connecting a switch port to an ONTAP controller using NVIDIA ConnectX-6 (CX6), ConnectX-6 Dx (CX6-DX), or ConnectX-7 (CX7) NIC ports, you must hard-code the switch port speed.

```
(cs1) (config)# interface Ethernet1/19
For 100GbE speed:
(cs1) (config-if)# speed 100000
For 40GbE speed:
(cs1) (config-if)# speed 40000
(cs1) (config-if)# no negotiate auto
(cs1) (config-if)# exit
(cs1) (config)# exit
Save the changes:
(cs1) # copy running-config startup-config
```

See the [Hardware Universe](#) for more information on switch ports. See [What additional information do I need to install my equipment that is not in HWU?](#) for more information about switch installation requirements.

25GbE FEC requirements

FAS2820 e0a/e0b ports

FAS2820 e0a and e0b ports require FEC configuration changes to link up with 9336C-FX2 and 9336C-FX2-T switch ports. For switch ports e0a and e0b, the fec setting is set to `rs-cons16`.

```
(cs1) (config)# interface Ethernet1/8-9
(cs1) (config-if-range)# fec rs-cons16
(cs1) (config-if-range)# exit
(cs1) (config)# exit
Save the changes:
(cs1) # copy running-config startup-config
```

Ports do not link up due to TCAM resources

On the 9336C-FX2 and 9336C-FX2-T switches, the Ternary Content Addressable Memory (TCAM) resources configured in the configuration utilized by the switch are exhausted.

See the Knowledge Base article [Ports do not link up on Cisco Nexus 9336C-FX2 due to TCAM resources](#) for details on how to resolve this issue.

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.