



Chassis

Install and maintain

NetApp
February 01, 2026

Table of Contents

- Chassis..... 1
 - Chassis replacement workflow - ASAA1K..... 1
 - Requirements to replace the chassis - ASAA1K..... 1
 - Prepare to replace the chassis - ASAA1K..... 2
 - Step 1: Locate and monitor your system..... 2
 - Step 2: Verify replacement components..... 2
 - Step 3: Label the cables..... 2
 - Shut down the controller to replace the chassis - ASAA1K..... 3
 - Replace the chassis - ASAA1K..... 4
 - Step 1: Remove the PSUs and cables..... 4
 - Step 2: Remove the I/O cards, NVRAM12, and system management module..... 5
 - Step 3: Remove the controller module..... 7
 - Step 4: Replace the impaired chassis..... 7
 - Step 5: Install the chassis components..... 7
 - Complete the chassis replacement - ASAA1K..... 8
 - Step 1: Boot the controllers and verify system health..... 9
 - Step 2: Return the failed part to NetApp..... 9

Chassis

Chassis replacement workflow - ASA A1K

Get started with replacing the chassis of your ASA A1K storage system by reviewing the replacement requirements, shutting down the controller, replacing the chassis, and verifying system operations.

1

Review the chassis replace requirements

Review the chassis replacement requirements.

2

Prepare for chassis replace

Prepare to replace the chassis by locating the system, gathering system credentials and necessary tools, verifying the replacement chassis was received, and labeling the system cables.

3

Shut down the controller

Shut down the controller so you can perform maintenance on the chassis.

4

Replace the chassis

Replace the chassis by moving the components from the impaired chassis to the replacement chassis.

5

Complete the chassis replacement

Complete the chassis replacement by bringing the controller up, giving back the controller, and returning the failed chassis to NetApp.

Requirements to replace the chassis - ASA A1K

Before replacing the chassis in your ASA A1K system, ensure you meet the necessary requirements for a successful replacement. This includes verifying all other components in the system are functioning properly, verifying that you have local administrator credentials for ONTAP, the correct replacement chassis, and the necessary tools.

The chassis is the physical chassis housing all the system components such as the fans, controller/CPU unit, NVRAM12, system management module, I/O cards and blanking modules, and PSUs.

Review the following requirements.

- Make sure all other components in the system are functioning properly; if not, contact [NetApp support](#) for assistance.
- Obtain local administrator credentials for ONTAP if you don't have them.

- Make sure that you have the necessary tools and equipment for the replacement.
- You can use the chassis replacement procedure with all versions of ONTAP supported by your system.
- The chassis replacement procedure is written with the assumption that you are moving the bezel, fans, controller module, NVRAM12, system management module, I/O cards and blanking modules, and PSUs to the new chassis, and that the replacement chassis is a new component from NetApp.

What's next?

After you've reviewed the requirements to replace the chassis, you need to [prepare to replace the chassis](#).

Prepare to replace the chassis - ASA A1K

Prepare to replace the impaired chassis in your ASA A1K system by identifying the impaired chassis, verifying the replacement components, and labeling the cables and controller module.

Step 1: Locate and monitor your system

You should open a console session and save sessions logs for future reference, and also turn on the system location LED to find the impaired chassis.

Steps

1. Connect to the serial console port to interface with and monitor the system.
2. Locate and turn on the controller's Location LED:
 - a. Use the `system controller location-led show` command to show the current state of the location LED.
 - b. Change the state of the location LED to "on":

```
system controller location-led modify -node node1 -state on
```

The Location LED remains lit for 30 minutes.

Step 2: Verify replacement components

You should verify that you received the necessary components, remove them from packaging, and save the packaging.

Steps

1. Before opening the packaging, you should look at the packaging label and verify:
 - Component part number.
 - Part description.
 - Quantity in the box.
2. Remove the contents from the packaging and use the packaging to returning the failed component to NetApp.

Step 3: Label the cables

You should label the cables before removing them from the I/O modules on the back of the system.

Steps

1. Label all the cables associated with the storage system. This aids recabling later in this procedure.
2. If you are not already properly grounded, ground yourself.

What's next?

After you've prepared to replace your ASA A1K chassis hardware, you need to [shut down the controller](#).

Shut down the controller to replace the chassis - ASA A1K

Shut down the controller in your ASA A1K storage system to prevent data loss and ensure system stability when replacing the chassis.

To shut down the impaired controller, you must determine the status of the controller and, if necessary, take over the controller so that the healthy controller continues to serve data from the impaired controller storage.

About this task

- If you have a SAN system, you must have checked event messages (`cluster kernel-service show`) for the impaired controller SCSI blade. The `cluster kernel-service show` command (from `priv advanced` mode) displays the node name, [quorum status](#) of that node, availability status of that node, and operational status of that node.

Each SCSI-blade process should be in quorum with the other nodes in the cluster. Any issues must be resolved before you proceed with the replacement.

- If you have a cluster with more than two nodes, it must be in quorum. If the cluster is not in quorum or a healthy controller shows false for eligibility and health, you must correct the issue before shutting down the impaired controller; see [Synchronize a node with the cluster](#).

Steps

1. If AutoSupport is enabled, suppress automatic case creation by invoking an AutoSupport message:

```
system node autosupport invoke -node * -type all -message MAINT=<# of hours>h
```

The following AutoSupport message suppresses automatic case creation for two hours:

```
cluster1:> system node autosupport invoke -node * -type all -message MAINT=2h
```

2. Disable automatic giveback:

- a. Enter the following command from the console of the healthy controller:

```
storage failover modify -node impaired_node_name -auto-giveback false
```

- b. Enter `y` when you see the prompt *Do you want to disable auto-giveback?*

3. Take the impaired controller to the LOADER prompt:

If the impaired controller is displaying...	Then...
The LOADER prompt	Go to the next step.

If the impaired controller is displaying...	Then...
Waiting for giveback...	Press Ctrl-C, and then respond <code>y</code> when prompted.
System prompt or password prompt	Take over or halt the impaired controller from the healthy controller: <pre>storage failover takeover -ofnode impaired_node_name -halt true</pre> The <code>-halt true</code> parameter brings you to the LOADER prompt.

What's next?

After you've shut down the controller, you need to [replace the chassis](#).

Replace the chassis - ASA A1K

Replace the chassis of your ASA A1K system when a hardware failure requires it. The replacement process involves removing the controller, I/O cards, NVRAM12 module, system management module, and power supply units (PSUs), installing the replacement chassis, and reinstalling the chassis components.

Step 1: Remove the PSUs and cables

You need to remove the two power supply units (PSUs) before removing the controller.

Steps

1. Remove the PSUs:


- If you are not already grounded, properly ground yourself.
- Unplug power cords from the PSUs.

If your system has DC power, disconnect the power block from the PSUs.

- Remove the two PSUs from the rear of the chassis by rotating the PSU handle up so that you can pull the PSU out, press the PSU locking tab, and then pull PSU out of the chassis.



The PSU is short. Always use two hands to support it when removing it from the controller module so that it does not suddenly swing free from the controller module and injure you.



1	Terracotta PSU locking tab
---	----------------------------

d. Repeat these steps for the second PSU.

2. Remove the cables:

- a. Unplug the system cables and any SFP and QSFP modules (if needed) from the controller module, but leave them in the cable management device to keep them organized.




Cables should have been labeled at the beginning of this procedure.

- b. Remove the cable management device from the chassis and set it aside.

Step 2: Remove the I/O cards, NVRAM12, and system management module

1. Remove the target I/O module from the chassis:



1	I/O cam latch
---	---------------

- a. Depress the cam button on the target module.
- b. Rotate the cam latch away from the module as far as it will go.
- c. Remove the module from the chassis by hooking your finger into the cam lever opening and pulling the module out of the chassis.

Make sure that you keep track of which slot the I/O module was in.

d. Set the I/O module aside and repeat these steps for any other I/O modules.


2. Remove the NVRAM12 module:

a. Depress the locking cam button.

The cam button moves away from the chassis.

b. Rotate the cam latch down as far as it will go.

c. Remove the NVRAM module from the chassis by hooking your finger into the cam lever opening and pulling the module out of the chassis.



1	NVRAM12 cam latch
---	-------------------


d. Set the NVRAM module on a stable surface.

3. Remove the system management module:

a. Depress the cam button on the System Management module.

b. Rotate the cam lever down as far as it will go.

c. Loop your finger into the hole on the cam lever and pull the module straight out of the system.




1	System Management module cam latch
---	------------------------------------

Step 3: Remove the controller module

1. On the front of the unit, hook your fingers into the holes in the locking cams, squeeze the tabs on the cam levers, and gently, but firmly rotate both latches toward you at the same time.

The controller module moves slightly out of the chassis.



1

Locking cam latches

2. Slide the controller module out of the chassis and place it on a flat, stable surface.

Make sure that you support the bottom of the controller module as you slide it out of the chassis.

Step 4: Replace the impaired chassis

Remove the impaired chassis and install the replacement chassis.

Steps

1. Remove the impaired chassis:
 - a. Remove the screws from the chassis mount points.
 - b. Slide the impaired chassis off the rack rails in a system cabinet or equipment rack, and then set it aside.
2. Install the replacement chassis:
 - a. Install the replacement chassis into the equipment rack or system cabinet by guiding the chassis onto the rack rails in a system cabinet or equipment rack.
 - b. Slide the chassis all the way into the equipment rack or system cabinet.
 - c. Secure the front of the chassis to the equipment rack or system cabinet, using the screws you removed from the impaired chassis.

Step 5: Install the chassis components

After the replacement chassis is installed, you need to install the controller module, recable the I/O modules and system management module, and then reinstall and plug in the PSUs.

Steps

1. Install the controller module:
 - a. Align the end of the controller module with the opening in the front of the chassis, and then gently push

the controller all the way into the chassis.

- b. Rotate the locking latches into the locked position.
2. Install the I/O cards at the rear of the chassis:
 - a. Align the end of the I/O module with the same slot in the replacement chassis as in the impaired chassis, and then gently push the module all the way into the chassis.
 - b. Rotate the cam latch upward into the locked position.
 - c. Repeat these steps for any other I/O modules.
3. Install the system management module at the rear of the chassis:
 - a. Align the end of the system management module with the opening in the chassis, and then gently push the module all the way into the chassis.
 - b. Rotate the cam latch upward into the locked position.
 - c. If you have not already done so, reinstall the cable management device and reconnect the cables to the I/O cards and system management module.



If you removed the media converters (QSFPs or SFPs), remember to reinstall them.

Make sure that the cables are connected according to the cable labels.

4. Install the NVRAM12 module in the back of the chassis at the rear of the chassis:
 - a. Align the end of the NVRAM12 module with the opening in the chassis, and then gently push the module all the way into the chassis.
 - b. Rotate the cam latch upward into the locked position.
5. Install the PSUs:
 - a. Using both hands, support and align the edges of the PSU with the opening in the chassis.
 - b. Gently push the PSU into the chassis until the locking tab clicks into place.

The power supplies will only properly engage with the internal connector and lock in place one way.



To avoid damaging the internal connector, do not use excessive force when sliding the PSU into the system.

6. Reconnect the PSU power cables to both of the PSUs and secure each power cable to the PSU using the power cable retainer.

If you have DC power supplies, reconnect the power block to the power supplies after the controller module is fully seated in the chassis and secure the power cable to the PSU with the thumbscrews.

The controller modules begin to boot as soon as PSUs are installed and power is restored.

What's next?

After you've replaced the impaired ASAA1K chassis and reinstalled the components into it, you need to [complete the chassis replacement](#).

Complete the chassis replacement - ASA A1K

Reboot the controller, verify system health, and return the failed part to NetApp to

complete the final step in the ASA A1K chassis replacement procedure.

Step 1: Boot the controllers and verify system health

After the controllers reboot, boot ONTAP, give back the controllers, and verify the storage system health.

Steps

1. Check the console output:
 - a. If the controller boots to the LOADER prompt, reboot the controller with the `boot_ontap` command.
 - b. If the console displays `waiting for giveback` after the reboot, log into the partner controller and check that the replaced controller is ready for giveback with the `storage failover show` command.
2. Perform the giveback:
 - a. Connect the console cable to the partner controller.
 - b. Return the impaired controller to normal operation by giving back its storage: `storage failover giveback -ofnode impaired_node_name`
 - c. If automatic giveback was disabled, reenable it: `storage failover modify -node impaired_node_name -auto-giveback true`
 - d. If AutoSupport is enabled, restore/unsuppress automatic case creation: `system node autosupport invoke -node * -type all -message MAINT=END`
3. After the giveback is complete, run [Active IQ Config Advisor](#) to verify the health of the storage system and correct any issues you encounter.

Step 2: Return the failed part to NetApp

Return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return and Replacements](#) page for further information.

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.