



## **Drive shelf**

### **Install and maintain**

NetApp  
November 08, 2024

# Table of Contents

- Drive shelf ..... 1
  - Overview of shelf maintenance - NS224 shelves ..... 1
  - Cold-replace a shelf - NS224 shelves ..... 1
  - Hot-add a drive - NS224 shelves ..... 1
  - Hot-remove a shelf - NS224 shelves ..... 1
  - Monitor drive shelf LEDs - NS224 shelves ..... 5

# Drive shelf

## Overview of shelf maintenance - NS224 shelves

You can take the following actions to maintain your NS224 shelf:

- [Hot-add a drive](#)
- [Cold-replace a shelf](#)
- [Hot-remove a shelf](#)
- [Monitor shelf LEDs](#)

## Cold-replace a shelf - NS224 shelves

When replacing a drive shelf in a production system that has disks in use, you need to perform a cold shelf replacement. This is a disruptive procedure. It requires you to halt the controllers in your HA pair.

Use the NetApp Knowledge Base article [How to replace a shelf chassis using a cold shelf removal procedure](#).

## Hot-add a drive - NS224 shelves

You can add new drives to a powered-on shelf non-disruptively, even during I/O operations.

Use the NetApp Knowledge Base article [Best practices for adding disks to an existing shelf or cluster](#).

## Hot-remove a shelf - NS224 shelves

You can hot-remove an NS224 drive shelf that has had the aggregates removed from the drives, in an HA pair that is up and serving data (I/O is in progress).

### Before you begin

- Your HA pair cannot be in a takeover state.
- You must have removed all aggregates from the drives (the drives must be spares) in the shelf you are removing.



If you attempt this procedure with aggregates on the shelf you are removing, you could fail the system with a multidisk panic.

You can use the `storage aggregate offline -aggregate aggregate_name` command and then the `storage aggregate delete -aggregate aggregate_name` command.

- If your system shipped in a system cabinet, you need a Phillips screwdriver to remove the screws securing the shelf to the cabinet rear uprights.

### About this task

- If you are hot-removing more than one shelf, you remove one shelf at a time.
- **Best practice:** The best practice is to remove drive ownership after you remove the aggregates from the drives in the shelf you are removing.

Removing ownership information from a spare drive allows the drive to be properly integrated into another node (as needed).

The procedure for removing ownership from drives can be found in the disks and aggregates content:

### [Disks and aggregates overview](#)



The procedure requires you to disable automatic drive assignment. You reenable automatic drive assignment at the end of this procedure (after you have hot-removed the shelf).

- If needed, you can turn on the shelf's location (blue) LEDs to aid in physically locating the affected shelf:  
`storage shelf location-led modify -shelf-name shelf_name -led-status on`

If you do not know the *shelf\_name* of the affected shelf, run the `storage shelf show` command.

A shelf has three location LEDs: one on the operator display panel and one on each NSM module. Location LEDs remain illuminated for 30 minutes. You can turn them off by entering the same command, but using the `off` option.

- After disconnecting a shelf from non-dedicated RoCE capable ports (on board the controllers, on RoCE capable PCIe cards, a combination of both, or on I/O modules), you have the option of reconfiguring these ports for networking use.



If your HA pair is running a version of ONTAP 9.6, you need to reboot the controllers one at a time. If your HA pair is running ONTAP 9.7 or later, you do not need to reboot the controllers, unless one or both controllers are in maintenance mode. This procedure assumes that neither controller is in maintenance mode.

## Steps

1. Properly ground yourself.
2. Verify that the drives in the shelf you are removing have no aggregates (are spares) and that ownership is removed:
  - a. Enter the following command to list all of the drives in the shelf that you are removing: `storage disk show -shelf shelf_number`  
  
You can enter the command on either controller module.
  - b. Check the output to verify that there are no aggregates on the drives.  
  
Drives with no aggregates have a dash in the `Container Name` column.
  - c. Check the output to verify that ownership is removed from the drives.  
  
Drives with no ownership have a dash in the `Owner` column.



If you have failed drives, they display broken in the `Container Type` column. (Failed drives do not have ownership.)

The following output shows drives on the shelf being removed (shelf 2) are in a correct state for removing the shelf. The aggregates are removed on all of the drives; therefore, a dash appears in the `Container Name` column for each drive. Ownership is also removed on all of the drives; therefore, a dash appears in the `Owner` column for each drive.

```
cluster1::> storage disk show -shelf 2
```

Disk	Usable Size	Shelf	Bay	Disk Type	Container Type	Container Name	Owner
...							
2.2.4	-	2	4	SSD-NVM	spare	-	-
2.2.5	-	2	5	SSD-NVM	spare	-	-
2.2.6	-	2	6	SSD-NVM	broken	-	-
2.2.7	-	2	7	SSD-NVM	spare	-	-
...							

3. Physically locate the shelf you are removing.
4. Disconnect the cabling from the shelf you are removing:
  - a. Disconnect the power cords from the power supplies by opening the power cord retainer if they are AC power supplies, or unscrewing the two thumb screws if they are DC power supplies, and then unplug the power cords from the power supplies.

Power supplies do not have a power switch.

- b. Disconnect the storage cabling (from the shelf to the controllers).
5. Physically remove the shelf from the rack or cabinet.



A fully loaded NS224 shelf can weigh up to 66.78 lbs (30.29 kg) and requires two people to lift or use of a hydraulic lift. Avoid removing shelf components (from the front or rear of the shelf) to reduce the shelf weight, because shelf weight will become unbalanced.



If your system was shipped in a cabinet, you must first unscrew the two Phillips screws securing the shelf to the rear uprights. The screws are located on the inside shelf walls of the bottom NSM module. You should remove both NSM modules to access the screws.

6. If you are removing more than one shelf, repeat steps 2 through 5.

Otherwise, go to the next step.

7. If you disabled automatic drive assignment when you removed ownership from the drives, reenable it:
 

```
storage disk option modify -autoassign on
```

You run the command on both controller modules.

8. You have the option of reconfiguring the non-dedicated RoCE capable ports for networking use, by completing the following substeps.

Otherwise, you are done with this procedure.

- a. Verify the names of the non-dedicated ports, currently configured for storage use: `storage port show`


You can enter the command on either controller module.



The non-dedicated ports configured for storage use are displayed in the output as follows: If your HA pair is running ONTAP 9.8 or later, the non-dedicated ports display `storage` in the `Mode` column. If your HA pair is running ONTAP 9.7 or 9.6, the non-dedicated ports, which display `false` in the `Is Dedicated?` column, also display `enabled` in the `State` column.

- b. Complete the set of steps applicable to the version of ONTAP your HA pair is running:

If your HA pair is running...	Then...
ONTAP 9.8 or later	<ol style="list-style-type: none"> <li>a. Reconfigure the non-dedicated ports for networking use, on the first controller module: <code>storage port modify -node <i>node name</i> -port <i>port name</i> -mode network</code>  You must run this command for each port you are reconfiguring.</li> <li>b. Repeat the above step to reconfigure the ports on the second controller module.</li> <li>c. Go to substep 8c to verify all port changes.</li> </ol>
ONTAP 9.7	<ol style="list-style-type: none"> <li>a. Reconfigure the non-dedicated ports for networking use, on the first controller module: <code>storage port disable -node <i>node name</i> -port <i>port name</i></code>  You must run this command for each port you are reconfiguring.</li> <li>b. Repeat the above step to reconfigure the ports on the second controller module.</li> <li>c. Go to substep 8c to verify all port changes.</li> </ol>

If your HA pair is running...	Then...
A version of ONTAP 9.6	<p>a. Reconfigure the RoCE capable ports for networking use, on the first controller module: <code>storage port disable -node <i>node name</i> -port <i>port name</i></code></p> <p>You must run this command for each port you are reconfiguring.</p> <p>b. Reboot the controller module to make the port changes take effect:</p> <pre>system node reboot -node <i>node name</i> -reason <i>reason for the reboot</i></pre> <div style="border: 1px solid gray; padding: 5px; margin: 10px 0;">  The reboot must complete before you proceed to the next step. The reboot can take up to 15 minutes. </div> <p>c. Reconfigure the ports on the second controller module, by repeating the first step (a).</p> <p>d. Reboot the second controller to make the port changes take effect, by repeating the second step (b).</p> <p>e. Go to substep 8c to verify all port changes.</p>

- c. Verify that the non-dedicated ports of both controller modules are reconfigured for networking use:
- ```
storage port show
```

You can enter the command on either controller module.

If your HA pair is running ONTAP 9.8 or later, the non-dedicated ports display `network` in the `Mode` column.

If your HA pair is running ONTAP 9.7 or 9.6, the non-dedicated ports, which display `false` in the `Is Dedicated?` column, also display `disabled` in the `State` column.

## Monitor drive shelf LEDs - NS224 shelves

You can monitor the health of your drive shelf by understanding the location and status conditions of the LEDs on your drive shelf components.

- The location (blue) LEDs, on a shelf's operator display panel (ODP) and both NSM modules, can be activated to aid in physically locating the shelf that needs servicing: `storage shelf location-led modify -shelf-name shelf_name -led-status on`

If you do not know the `shelf_name` of the affected shelf, run the `storage shelf show` command.

Location LEDs remain illuminated for 30 minutes. You can turn them off by entering the same command, but using the `off` option.

- An LED state can be:
  - "On": The LED illumination is solid/steady
  - "Off": The LED is not illuminated
  - "Blink": The LED turns on and off at varying intervals depending on the FRU status
  - "Any state": The LED can be "On", "Off", or "Blink"

## Operator display panel LEDs

The LEDs on the drive shelf front operator display panel (ODP) indicate whether your drive shelf is functioning normally or there are problems with the hardware.

The following illustration and table describes the three LEDs on the ODP:




| LED icon | LED name & color  | State | Description                                                                                                                                                                                                                                                                                                                                                                                    |
|----------|-------------------|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ⏻        | Power (Green)     | On    | One or more power supplies are supplying power to the drive shelf.                                                                                                                                                                                                                                                                                                                             |
| !        | Attention (Amber) | On    | <ul style="list-style-type: none"> <li>• An error occurred with the function of one of more shelf FRUs.</li> </ul> <p>Check event messages to determine corrective action to take.</p> <ul style="list-style-type: none"> <li>• If the two-digit shelf ID is also blinking, the shelf ID is in a pending state.</li> </ul> <p>Power cycle the drive shelf for the shelf ID to take affect.</p> |
| 📍        | Location (Blue)   | On    | The system administrator activated this LED function.                                                                                                                                                                                                                                                                                                                                          |



## NSM module LEDs

The LEDs on an NSM module indicate whether the module is functioning normally, whether it is ready for I/O traffic, and whether there are any problems with the hardware.

The following illustration and tables describe NSM module LEDs associated with the function of a module and the function of each NVMe port on a module.



| Call out | LED icon | Color | Description               |
|----------|----------|-------|---------------------------|
| 1        | 📍        | Blue  | NSM module: Location      |
| 2        | !        | Amber | NSM module: Attention     |
| 3        | LNK      | Green | NVMe port/link: status    |
| 4        | !        | Amber | NVMe port/link: attention |


| Status                           | NSM Attention (Amber) | Port LNK (Green)                | Port Attention (Amber) |
|----------------------------------|-----------------------|---------------------------------|------------------------|
| NSM normal                       | Off                   | Any state                       | Off                    |
| NSM fault                        | On                    | Any state                       | Any state              |
| NSM VPD Error                    | On                    | Any state                       | Any state              |
| No host port connection          | Any state             | Off                             | Off                    |
| Host port connection link active | Any state             | On/Blinks with activity         | Any state              |
| Host port connection w/ fault    | On                    | On/Off if all lanes are faulted | On                     |

| Status                                   | NSM Attention (Amber) | Port LNK (Green) | Port Attention (Amber) |
|------------------------------------------|-----------------------|------------------|------------------------|
| BIOS boot from BIOS image after power up | Blink                 | Any state        | Any state              |

## Power supply LEDs

The LEDs on an AC or DC power supply (PSU) indicate whether the PSU is functioning normally or there are hardware problems.

The following illustration and tables describe the LED on a PSU. (The illustration is an AC PSU; however, the LED location is the same on the DC PSU):




| Call out | Description                                                                |
|----------|----------------------------------------------------------------------------|
| 1        | The bi-color LED indicates power/activity when green and a fault when red. |

| Status                                   | Power/activity (Green) | Attention (Red) |
|------------------------------------------|------------------------|-----------------|
| No AC/DC power to the enclosure          | Off                    | Off             |
| No AC/DC power to the PSU                | Off                    | On              |
| AC/DC power on, but PSU not in enclosure | Blink                  | Off             |
| PSU operating correctly                  | On                     | Off             |
| PSU failure                              | Off                    | On              |
| Fan failure                              | Off                    | On              |
| Firmware update mode                     | Blink                  | Off             |

## Drive LEDs

The LEDs on an NVMe drive indicates whether it is functioning normally or there are problems with the hardware.

The following illustration and tables describe the two LEDs on an NVMe drive:



| Call out | LED name       | Color |
|----------|----------------|-------|
| 1        | Attention      | Amber |
| 2        | Power/activity | Green |

| Status                          | Power/Activity (Green)  | Attention (Amber) | Associated ODP LED       |
|---------------------------------|-------------------------|-------------------|--------------------------|
| Drive installed and operational | On/Blinks with activity | Any state         | N/A                      |
| Drive failure                   | On/Blinks with activity | On                | Attention (Amber)        |
| SES device identify set         | On/Blinks with activity | Blinks            | Attention (Amber) is off |
| SES device fault bit set        | On/Blinks with activity | On                | Attention (Amber)        |
| Power control circuit failure   | Off                     | Any state         | Attention (Amber)        |

## Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.