



Stage 2 Relocate and retiring node1

ONTAP Systems

NetApp
June 15, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-systems/upgrade-arl-auto-app/stage_2_relocating_and_retiring_node1_overview.html on June 15, 2021. Always check docs.netapp.com for the latest.

Table of Contents

- Stage 2 Relocate and retiring node1 1
- Stage 2. Relocate and retire node1 1
- Relocate non-root aggregates and NAS data LIFs owned by node1 to node2 1
- Relocate failed or vetoed aggregates 2
- Retire node1..... 3
- Prepare for netboot 3

Stage 2 Relocate and retiring node1

Stage 2. Relocate and retire node1

During Stage 2, you relocate the node1 aggregates and LIFs to node2, record node1 information, and then retire node1. This process is largely automated; the operation pauses to allow you to check its status. You must manually resume the operation.

Steps

1. [Relocate non-root aggregates and NAS data LIFs owned by node1 to node2](#)
2. [Retire node1](#)
3. [Prepare for netboot](#)

Relocate non-root aggregates and NAS data LIFs owned by node1 to node2

Before you can replace node1 with node3, you must move the non-root aggregates and NAS data LIFs from node1 to node2 before eventually moving node1's resources to node3.

Before you begin

The operation should already be paused when you begin the task; you must manually resume the operation.

About this task

After the aggregates and LIFs are migrated, the operation is paused for verification purposes. At this stage, you must verify whether or not all the non-root aggregates and non-SAN data LIFs are migrated to node3.



The home owner for the aggregates and LIFs are not modified; only the current -owner is modified.

Steps

1. Resume the aggregate relocation and NAS data LIF move operations by using the following command:

```
system controller replace resume
```

All the non-root aggregates and NAS data LIFs are migrated from node1 to node2.

The operation pauses to allow you to verify whether all node1 non-root aggregates and non-SAN data LIFs have been migrated to node2.

2. Check the status of the aggregate relocation and NAS data LIF move operations by using the following command:

```
system controller replace show-details
```

3. With the operation still paused, verify that all the non-root aggregates are online for their state on node2 by using the following command:

```
storage aggregate show -node <node2> -state online -root false
```

The following example shows that the non-root aggregates on node2 are online:

```
cluster::> storage aggregate show -node node2 state online -root false

Aggregate Size      Available Used% State #Vols Nodes RAID Status
aggr_1 744.9GB 744.8GB 0% online 5 node2 raid_dp,normal
aggr_2 825.0GB 825.0GB 0% online 1 node2 raid_dp,normal
2 entries were displayed.
```

If the aggregates have gone offline or become foreign on node2, bring them online by using the following command on node2, once for each aggregate:

```
storage aggregate online -aggregate <aggr_name>
```

4. Verify that all the volumes are online on node2 by using the following command on node2 and examining its output:

```
volume show -node <node2> -state offline
```

If any volumes are offline on node2, bring them online by using the following command on node2, once for each volume:

```
volume online -vserver <vserver-name> -volume <volume-name>
```

The <vserver-name> to use with this command is found in the output of the previous volume show command.

5. If any LIFs are down, set the administrative status of the LIFs to **up** by using the following command, once for each LIF:

```
network interface modify -vserver <vserver_name> - lif <LIF_name> -home-node <nodename> - status-admin up
```

Relocate failed or vetoed aggregates

If any aggregates fail to relocate or are vetoed, you must manually relocate the aggregates, or if necessary, override either the vetoes or destination checks.

About this task

The relocation operation will have paused due to the error.

Steps

1. Check the event management system (EMS) logs to determine why the aggregate failed to relocate or was vetoed.
2. Relocate any failed or vetoed aggregates by using the following command:

```
storage aggregate relocation start -node <node1> -destination <node2>
```

```
aggregate-list <aggr_name> -ndo-controller-upgrade true
```

3. When prompted, enter `y`.
4. You can force relocation by using one of the following methods:

Option	Description
Overriding veto checks	Use the following command: <pre>storage aggregate relocation start -node node1 -destination node2 -aggregate-list <aggr_list> -ndo -controller-upgrade true -override-vetoes true</pre>
Overriding destination checks	Use the following command: <pre>storage aggregate relocation start -node node1 -destination node2 -aggregate-list <aggr_list> -ndo -controller-upgrade true -override-vetoes true -override-destination-checks true</pre>

Retire node1

To retire node1, you resume the automated operation to disable the HA pair with node2 and shut node1 down properly. You must later remove node1 from the rack or chassis.

Steps

1. Resume the operation by using the following command:

```
system controller replace resume
```

2. Verify that node1 has been halted by using the following command:

```
system controller replace show-details
```

After you finish

You can decommission node1 after the upgrade is completed. See [Decommission the old system](#).

Prepare for netboot

After you physically rack node3 and node4 later in the procedure, you might need to netboot them. The term `netboot` means you are booting from an ONTAP image stored on a remote server. When preparing for netboot, you must put a copy of the ONTAP 9 boot image onto a web server that the system can access.

Before you begin

- Verify that you can access a HTTP server with the system.
- You need to download the necessary system files for your platform and the correct version of ONTAP from the NetApp Support Site at mysupport.netapp.com.

About this task

You must netboot the new controllers if they do not have the same version of ONTAP 9 installed on them that is

installed on the original controllers. After you install each new controller, you boot the system from the ONTAP 9 image stored on the web server. You can then download the correct files to the boot media device for subsequent system boots.

Steps

1. Access the NetApp Support Site to download the files used for performing the netboot of the system.
2. Download the appropriate ONTAP software from the software download section of the NetApp Support Site and store the `<ontap_version>_image.tgz` file on a web-accessible directory.
3. Change to the web-accessible directory and verify that the files you need are available.

For...	Then...
FAS/AFF8000 series systems	Extract the contents of the <code><ontap_version>_image.tgz</code> file to the target directory by using the following command: <code>tar -zxvf <ontap_version>_image.tgz</code> Note: If you are extracting the contents on Windows, use 7-Zip or WinRAR to extract the netboot image. Your directory listing should contain a netboot folder with a kernel file: <code>netboot/kernel</code>
All other systems	Your directory listing should contain the following file: <code><ontap_version>_image.tgz</code> Note: You do not need to extract the contents of the <code><ontap_version>_image.tgz</code> file.

You will use the information in the directories in [Stage 3](#).

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.