

Preparation ONTAP 9

NetApp April 24, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap/smb-config/assess-physical-storage-requirements-task.html on April 24, 2024. Always check docs.netapp.com for the latest.

Table of Contents

Preparation	. 1
Assess physical storage requirements	. 1
Assess networking requirements	. 1
Decide where to provision new SMB storage capacity	. 2
Worksheet for gathering SMB configuration information	. 3

Preparation

Assess physical storage requirements

Before provisioning SMB storage for clients, you must ensure that there is sufficient space in an existing aggregate for the new volume. If there is not, you can add disks to an existing aggregate or create a new aggregate of the desired type.

Steps

1. Display available space in existing aggregates: storage aggregate show

If there is an aggregate with sufficient space, record its name in the worksheet.

cluster::> Aggregate	storage Size	aggregate Available	show Used%	State	#Vols Nodes	RAID Status
aggr_0	239.0GB	11.13GB	95%	online	1 nodel	raid_dp, normal
aggr_1	239.0GB	11.13GB	95%	online	1 nodel	raid_dp, normal
aggr_2	239.0GB	11.13GB	95%	online	1 node2	raid_dp, normal
aggr_3	239.0GB	11.13GB	95%	online	1 node2	raid_dp, normal
aggr_4	239.0GB	238.9GB	95%	online	5 node3	raid_dp, normal
aggr_5	239.0GB	239.0GB	95%	online	4 node4	raid_dp, normal
6 entries	were disp	played.				

2. If there are no aggregates with sufficient space, add disks to an existing aggregate by using the storage aggregate add-disks command, or create a new aggregate by using the storage aggregate create command.

Assess networking requirements

Before providing SMB storage to clients, you must verify that networking is correctly configured to meet the SMB provisioning requirements.

Before you begin

The following cluster networking objects must be configured:

- · Physical and logical ports
- Broadcast domains
- Subnets (if required)

- IPspaces (as required, in addition to the default IPspace)
- Failover groups (as required, in addition to the default failover group for each broadcast domain)
- External firewalls

Steps

- 1. Display the available physical and virtual ports: network port show
 - When possible, you should use the port with the highest speed for the data network.
 - All components in the data network must have the same MTU setting for best performance.
- 2. If you are planning to use a subnet name to allocate the IP address and network mask value for a LIF, verify that the subnet exists and has sufficient addresses available: network subnet show

Subnets contain a pool of IP addresses that belong to the same layer 3 subnet. Subnets are created by using the network subnet create command.

3. Display available IPspaces: network ipspace show

You can use the default IPspace or a custom IPspace.

4. If you want to use IPv6 addresses, verify that IPv6 is enabled on the cluster: network options ipv6 show

If required, you can enable IPv6 by using the network options ipv6 modify command.

Decide where to provision new SMB storage capacity

Before you create a new SMB volume or qtree, you must decide whether to place it in a new or existing SVM, and how much configuration the SVM requires. This decision determines your workflow.

Choices

• If you want to provision a volume or qtree on a new SVM, or on an existing SVM that has SMB enabled but not configured, complete the steps in both "Configuring SMB access to an SVM" and "Adding storage capacity to an SMB-enabled SVM".

Configuring SMB access to an SVM

Configuring SMB client access to shared storage

You might choose to create a new SVM if one of the following is true:

- You are enabling SMB on a cluster for the first time.
- You have existing SVMs in a cluster in which you do not want to enable SMB support.
- You have one or more SMB-enabled SVMs in a cluster, and you want one of the following connections:
 - To a different Active Directory forest or workgroup.
 - To an SMB server in an isolated namespace (multi-tenancy scenario). You should also choose this
 option to provision storage on an existing SVM that has SMB enabled but not configured. This
 might be the case if you created the SVM for SAN access or if no protocols were enabled when the
 SVM was created.

After enabling SMB on the SVM, proceed to provision a volume or qtree.

• If you want to provision a volume or qtree on an existing SVM that is fully configured for SMB access, complete the steps in "Adding storage capacity to an SMB-enabled SVM".

Configuring SMB client access to shared storage

Worksheet for gathering SMB configuration information

The SMB configuration worksheet enables you to collect the required information to set up SMB access for clients.

You should complete one or both sections of the worksheet, depending on the decision you made about where to provision storage:

• If you are configuring SMB access to an SVM, you should complete both sections.

Configuring SMB access to an SVM

Configuring SMB client access to shared storage

• If you are adding storage capacity to an SMB-enabled SVM, you should complete only the second section.

Configuring SMB client access to shared storage

The command man pages contain details about the parameters.

Configuring SMB access to an SVM

Parameters for creating an SVM

You supply these values with the vserver create command if you are creating a new SVM.

Field	Description	Your value
-vserver	A name you supply for the new SVM that is either a fully qualified domain name (FQDN) or follows another convention that enforces unique SVM names across a cluster.	
-aggregate	The name of an aggregate in the cluster with sufficient space for new SMB storage capacity.	
-rootvolume	A unique name you supply for the SVM root volume.	

Field	Description	Your value
-rootvolume-security-style	Use the NTFS security style for the SVM.	ntfs
-language	Use the default language setting in this workflow.	C.UTF-8
ipspace	Optional: IPspaces are distinct IP address spaces in which SVMs reside.	

Parameters for creating a LIF

You supply these values with the <code>network interface create</code> command when you are creating LIFs.

Field	Description	Your value
-lif	A name you supply for the new LIF.	
-role	Use the data LIF role in this workflow.	data
-data-protocol	Use only the SMB protocol in this workflow.	cifs
-home-node	The node to which the LIF returns when the network interface revert command is run on the LIF.	
-home-port	The port or interface group to which the LIF returns when the network interface revert command is run on the LIF.	
-address	The IPv4 or IPv6 address on the cluster that will be used for data access by the new LIF.	
-netmask	The network mask and gateway for the LIF.	
-subnet	A pool of IP addresses. Used instead of -address and -netmask to assign addresses and netmasks automatically.	

Field	Description	Your value
-firewall-policy	Use the default data firewall policy in this workflow.	data
-auto-revert	Optional: Specifies whether a data LIF is automatically reverted to its home node on startup or under other circumstances. The default setting is false.	

Parameters for DNS host name resolution

You supply these values with the vserver services name-service dns create command when you are configuring DNS.

Field	Description	Your value
-domains	Up to five DNS domain names.	
-name-servers	Up to three IP addresses for each DNS name server.	

Setting up an SMB server in an Active Directory domain

Parameters for time service configuration

You supply these values with the cluster time-service ntp server create command when you are configuring time services.

Field	Description	Your value
-server	The host name or IP address of the NTP server for the Active Directory domain.	

Parameters for creating an SMB server in an Active Directory domain

You supply these values with the <code>vserver cifs create</code> command when you create a new SMB server and specify domain information.

Field	Description	Your value
-vserver	The name of the SVM on which to create the SMB server.	
-cifs-server	The name of the SMB server (up to 15 characters).	

Field	Description	Your value
-domain	The fully qualified domain name (FQDN) of the Active Directory domain to associate with the SMB server.	
-ou	Optional: The organizational unit within the Active Directory domain to associate with the SMB server. By default, this parameter is set to CN=Computers.	
-netbios-aliases	Optional: A list of NetBIOS aliases, which are alternate names to the SMB server name.	
-comment	Optional: A text comment for the server. Windows clients can see this SMB server description when browsing servers on the network.	

Setting up an SMB server in a workgroup

Parameters for creating an SMB server in a workgroup

You supply these values with the <code>vserver cifs create</code> command when you create a new SMB server and specify supported SMB versions.

Field	Description	Your value
-vserver	The name of the SVM on which to create the SMB server.	
-cifs-server	The name of the SMB server (up to 15 characters).	
-workgroup	The name of the workgroup (up to 15 characters).	
-comment	Optional: A text comment for the server. Windows clients can see this SMB server description when browsing servers on the network.	

Parameters for creating local users

You supply these values when you create local users by using the <code>vserver cifs users-and-groups local-user create command</code>. They are required for SMB servers in workgroups and optional in AD domains.

Field	Description	Your value
-vserver	The name of the SVM on which to create the local user.	
-user-name	The name of the local user (up to 20 characters).	
-full-name	Optional: The user's full name. If the full name contains a space, enclose the full name within double quotation marks.	
-description	Optional: A description for the local user. If the description contains a space, enclose the parameter in quotation marks.	
-is-account-disabled	Optional: Specifies whether the user account is enabled or disabled. If this parameter is not specified, the default is to enable the user account.	

Parameters for creating local groups

You supply these values when you create local groups by using the vserver cifs users-and-groups local-group create command. They are optional for SMB servers in AD domains and workgroups.

Field	Description	Your value
-vserver	The name of the SVM on which to create the local group.	
-group-name	The name of the local group (up to 256 characters).	
-description	Optional: A description for the local group. If the description contains a space, enclose the parameter in quotation marks.	

Adding storage capacity to an SMB-enabled SVM

Parameters for creating a volume

You supply these values with the volume create command if you are creating a volume instead of a qtree.

Field	Description	Your value
-vserver	The name of a new or existing SVM that will host the new volume.	
-volume	A unique descriptive name you supply for the new volume.	
-aggregate	The name of an aggregate in the cluster with sufficient space for the new SMB volume.	
-size	An integer you supply for the size of the new volume.	
-security-style	Use the NTFS security style for this workflow.	ntfs
-junction-path	Location under root (/) where the new volume is to be mounted.	

Parameters for creating a qtree

You supply these values with the volume dtree create command if you are creating a dtree instead of a volume.

Field	Description	Your value
-vserver	The name of the SVM on which the volume containing the qtree resides.	
-volume	The name of the volume that will contain the new qtree.	
-qtree	A unique descriptive name you supply for the new qtree, 64 characters or less.	
-qtree-path	The qtree path argument in the format /vol/volume_name/qtree_nam e\> can be specified instead of specifying volume and qtree as separate arguments.	

Parameters for creating SMB shares

You supply these values with the vserver cifs share create command.

Field	Description	Your value
-vserver	The name of the SVM on which to create the SMB share.	
-share-name	The name of the SMB share that you want to create (up to 256 characters).	
-path	The name of the path to the SMB share (up to 256 characters). This path must exist in a volume before creating the share.	
-share-properties	Optional: A list of share properties. The default settings are oplocks, browsable, changenotify, and show-previous-versions.	
-comment	Optional: A text comment for the server (up to 256 characters). Windows clients can see this SMB share description when browsing on the network.	

Parameters for creating SMB share access control lists (ACLs)

You supply these values with the ${\tt vserver}$ cifs share access-control create command.

Field	Description	Your value
-vserver	The name of the SVM on which to create the SMB ACL.	
-share	The name of the SMB share on which to create.	
-user-group-type	The type of the user or group to add to the share's ACL. The default type is windows	windows
-user-or-group	The user or group to add to the share's ACL. If you specify the user name, you must include the user's domain using the "domain\username" format.	
-permission	Specifies the permissions for the user or group.	[No_access Read Change Full_Control]

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.