



SnapCenter Windows disk management cmdlets

SnapCenter cmdlets

NetApp
November 04, 2025

Table of Contents

SnapCenter Windows disk management cmdlets	1
Add-SdIgroupInitiator	1
Syntax	1
Detailed Description	1
Parameters	1
Examples	2
Add-SdLunMap	2
Syntax	2
Detailed Description	2
Parameters	2
Examples	3
Add-SdPortSetPort	3
Syntax	3
Detailed Description	3
Parameters	3
Examples	4
Connect-SdIscsiTarget	4
Syntax	4
Detailed Description	4
Parameters	4
Examples	5
Connect-SdStorage	5
Syntax	5
Detailed Description	6
Parameters	6
Examples	7
Debug-SdHost	8
Syntax	8
Detailed Description	8
Parameters	8
Examples	8
Delete-SdLUNS	10
Syntax	10
Detailed Description	10
Parameters	10
Examples	10
Disconnect-SdIscsiTarget	10
Syntax	10
Detailed Description	10
Parameters	10
Examples	11
Disconnect-SdStorage	11
Syntax	11

Detailed Description	11
Parameters	11
Examples	12
Dismount-SdClone	12
Syntax	12
Detailed Description	12
Parameters	13
Examples	13
Dismount-SdSnapshot	15
Syntax	15
Detailed Description	15
Parameters	15
Examples	16
Get-SdAluaPaths	17
Syntax	17
Detailed Description	17
Parameters	17
Examples	17
Get-SdDataStores	17
Syntax	17
Detailed Description	17
Parameters	18
Examples	18
Get-SdFCPInitiator	18
Syntax	18
Detailed Description	18
Parameters	18
Examples	18
Get-Sdlgroup	19
Syntax	19
Detailed Description	19
Parameters	19
Examples	19
Get-SdlgroupWithUuid	20
Syntax	20
Detailed Description	20
Parameters	20
Examples	20
Get-SdlInfo	20
Syntax	20
Detailed Description	21
Parameters	21
Examples	21
Get-SdlscsilInitiator	22
Syntax	23

Detailed Description	23
Parameters	23
Examples	23
Get-SdIsCsiTarget	23
Syntax	23
Detailed Description	23
Parameters	24
Examples	24
Get-SdLun	24
Syntax	24
Detailed Description	24
Parameters	25
Examples	25
Get-SdLunMap	25
Syntax	25
Detailed Description	25
Parameters	25
Examples	26
Get-SdLunMapWithUuid	26
Syntax	26
Detailed Description	26
Parameters	26
Examples	26
Get-SdLunWithUuid	26
Syntax	26
Detailed Description	27
Parameters	27
Examples	27
Get-SdNfsExport	27
Syntax	27
Detailed Description	27
Parameters	27
Examples	28
Get-SdPlugIn	28
Syntax	28
Detailed Description	28
Parameters	28
Examples	28
Get-SdPlugInResource	28
Syntax	28
Detailed Description	28
Parameters	28
Examples	29
Get-SdPortSet	29
Syntax	29

Detailed Description	29
Parameters	29
Examples	30
Get-SdSMBShadowCopyEmsMessage	30
Syntax	30
Detailed Description	30
Parameters	30
Examples	30
Get-SdSnapMirror	31
Syntax	31
Detailed Description	31
Parameters	31
Examples	32
Get-SdSnapMirrorPolicyRule	33
Syntax	33
Detailed Description	33
Parameters	33
Examples	34
Get-SdSnapshot	35
Syntax	35
Detailed Description	35
Parameters	35
Examples	36
Get-SdStorage	40
Syntax	40
Detailed Description	41
Parameters	41
Examples	42
Get-SdStorageConnectionSetting	43
Syntax	43
Detailed Description	44
Parameters	44
Examples	44
Get-SdVM	45
Syntax	45
Detailed Description	45
Parameters	45
Examples	46
Get-SdVolumeCloneSplit	48
Syntax	48
Detailed Description	48
Parameters	48
Examples	49
Get-SdVolumeCloneSplitEstimate	49
Syntax	49

Detailed Description	49
Parameters	49
Examples	50
Get-SdVsphereSetting	50
Syntax	50
Detailed Description	50
Parameters	50
Examples	50
Invoke-SdEmsAutosupportLog	50
Syntax	50
Detailed Description	50
Parameters	51
Examples	52
Invoke-SdHostVolumeSpaceReclaim	53
Syntax	53
Detailed Description	53
Parameters	53
Examples	54
Invoke-SdSnapMirrorUpdate	54
Syntax	54
Detailed Description	54
Parameters	54
Examples	56
Map-SdLUNS	59
Syntax	59
Detailed Description	59
Parameters	59
Examples	60
Mount-SdClone	60
Syntax	60
Detailed Description	60
Parameters	60
Examples	61
Mount-SdSnapshot	62
Syntax	62
Detailed Description	62
Parameters	62
Examples	64
New-SdBackup	67
Syntax	67
Detailed Description	67
Parameters	67
Examples	68
New-SdIgroup	68
Syntax	68

Detailed Description	68
Parameters	68
Examples	69
New-SdLun	69
Syntax	69
Detailed Description	69
Parameters	69
Examples	70
New-SdPortSet	70
Syntax	70
Detailed Description	70
Parameters	70
Examples	71
New-SdSMBShare	71
Syntax	71
Detailed Description	71
Parameters	71
Examples	74
New-SdSnapshot	74
Syntax	74
Detailed Description	74
Parameters	74
Examples	75
New-SdStorage	76
Syntax	76
Detailed Description	76
Parameters	76
Examples	78
New-SdVolume	81
Syntax	81
Detailed Description	82
Parameters	82
Examples	95
Remove-SdBackup	96
Syntax	96
Detailed Description	96
Parameters	96
Examples	97
Remove-SdIgroup	97
Syntax	97
Detailed Description	97
Parameters	97
Examples	98
Remove-SdLun	98
Syntax	98

Detailed Description	98
Parameters	98
Examples	98
Remove-SdLunMap	99
Syntax	99
Detailed Description	99
Parameters	99
Examples	99
Remove-SdPortSet	99
Syntax	99
Detailed Description	100
Parameters	100
Examples	100
Remove-SdPortSetPort	100
Syntax	100
Detailed Description	100
Parameters	101
Examples	101
Remove-SdSMBShare	101
Syntax	101
Detailed Description	101
Parameters	101
Examples	102
Remove-SdSnapMirrorPolicyRule	102
Syntax	102
Detailed Description	102
Parameters	102
Examples	103
Remove-SdSnapshot	103
Syntax	104
Detailed Description	104
Parameters	104
Examples	104
Remove-SdStorage	105
Syntax	105
Detailed Description	105
Parameters	105
Examples	106
Remove-SdStorageConnectionSetting	106
Syntax	106
Detailed Description	106
Parameters	106
Examples	107
Remove-SdVolume	108
Syntax	108

Detailed Description	108
Parameters	108
Examples	109
Remove-SdVsphereSetting	109
Syntax	109
Detailed Description	109
Parameters	109
Examples	109
Rename-SdIgroup	110
Syntax	110
Detailed Description	110
Parameters	110
Examples	110
Rename-SdSnapshot	111
Syntax	111
Detailed Description	111
Parameters	111
Examples	112
Repair-SdAluaPaths	113
Syntax	113
Detailed Description	113
Parameters	113
Examples	113
Restore-SdPlugInResource	113
Syntax	113
Detailed Description	113
Parameters	114
Examples	114
Restore-SdSnapshot	114
Syntax	114
Detailed Description	114
Parameters	114
Examples	115
Set-SdAluaStateMonitor	116
Syntax	116
Detailed Description	117
Parameters	117
Examples	117
Set-SdDiskDriveLetter	117
Syntax	117
Detailed Description	117
Parameters	118
Examples	118
Set-SdSettings	118
Syntax	118

Detailed Description	118
Parameters	118
Examples	119
Set-SdSnapMirrorPolicyRule	119
Syntax	119
Detailed Description	119
Parameters	119
Examples	120
Set-SdSnapshot	121
Syntax	121
Detailed Description	121
Parameters	122
Examples	122
Set-SdStorageConnectionSetting	123
Syntax	123
Detailed Description	123
Parameters	124
Examples	126
Set-SdStorageSize	128
Syntax	128
Detailed Description	128
Parameters	128
Examples	128
Set-SdVsphereSetting	129
Syntax	129
Detailed Description	129
Parameters	129
Examples	129
Start-SdVolumeCloneSplit	129
Syntax	130
Detailed Description	130
Parameters	130
Examples	130
Stop-SdVolumeCloneSplit	130
Syntax	130
Detailed Description	130
Parameters	130
Examples	131
UnMap-SdLUNS	131
Syntax	131
Detailed Description	131
Parameters	131
Examples	131

SnapCenter Windows disk management cmdlets

Add-SdIgroupInitiator

Adds one or more FCP and/or iSCSI initiators to an existing igroup on your storage system.

Syntax

```
Add-SdIgroupInitiator [-Name] <String> [-Initiators] <String[]> [-StorageSystem] <String> [-Validate] <> [-Session] <String> [-Host] <String>
```

Detailed Description

Adds one or more FCP and/or iSCSI initiators to an existing igroup on your storage system. You should not mix FCP and iSCSI initiators on a specified Windows node. You can mix FCP and iSCSI initiators in a clustered scenario on a Windows node.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Name	Specifies the name of the igroup to which you want to add an array of FCP or iSCSI initiators.	true	true (ByPropertyName)	
Initiators	Provides a comma-separated list of the FCP or iSCSI initiators you want to add to your igroup.	true	true (ByPropertyName)	
StorageSystem	Specifies the storage system on which your igroup is defined.	true	true (ByPropertyName)	
Validate		false	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Adding an FCP initiator to an igroup

```
PS C:\> Add-SdIgroupInitiator -Name IGroupFCPDemo -Initiators  
"20:00:00:0e:13:75:90:02" -StorageSystem 172.17.168.13
```

This example syntax adds an FCP initiator to the specified igroup.

Example 2: Adding an iSCSI initiator to an igroup

```
PS C:\> Add-SdIgroupInitiator -Name IgroupDemo -Initiators iqn.1991-  
05.com.microsoft:mva-s24-rx200.sddev.mycompany.com -StorageSystem  
172.17.168.13
```

This example syntax adds an iSCSI initiator to the specified igroup.

Example 3: Adding an array of initiators to your igroup

```
PS C:\> Add-SdIgroupInitiator -Name IgroupDemo -Initiators iqn.1991-  
05.com.microsoft:mva-s24-rx200.sddev.mycompany.com, iqn.1991-  
05.com.microsoft:mva-rx200-s4.sddev.mycompany.com -StorageSystem  
172.17.168.13
```

This example syntax adds an array of initiators to the specified igroup.

Add-SdLunMap

Maps your LUN to an igroup.

Syntax

```
Add-SdLunMap [-StorageSystem] <String> [-LunPath] <String> [-Igroup]  
<String> [-Session] <String> [-Host] <String>
```

Detailed Description

Maps your LUN to an igroup. You can use this on the storage system level, for Data ONTAP storage systems. If you are performing provisioning operations, use `New-SdStorage`.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the storage system on which the igroup to which you want to map your LUN is located.	true	true (ByPropertyName)	
LunPath	Specifies the LUN on your storage system.	true	true (ByPropertyName)	
Igroup	Specifies the igroup to which you want to map your LUN.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection. For internal use only.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Mapping a LUN to an igroup on an ONTAP storage system

```
Add-SdLunMap -StorageSystem svm1 -LunPath /vol/vol1/lun1 -Igroup "myTestIgroup"
```

This example syntax maps the LUN called lun1 to the igroup "myTestIgroup" on svm1.

Add-SdPortSetPort

Adds a port to an existing portset.

Syntax

```
Add-SdPortSetPort [-PortSetName] <String> [-Port] <String> [-StorageSystem] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Adds a port to an existing portset.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
PortSetName	Specifies the name of the portset to which you want to add a new port.	true	true (ByPropertyName)	
Port	Specifies the name of the port you want to add to your portset.	true	true (ByPropertyName)	
StorageSystem	Specifies the storage system on which your portset resides.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection. For internal use only.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Connect-SdIscsiTarget

Establishes a session with your specified iSCSI target.

Syntax

```
Connect-SdIscsiTarget [-TargetNodeAddress] <String> [-TargetPortalAddress] <String> [-TargetPortalPortNumber] <UInt16> [-InitiatorPortalAddress] <String> [-CHAPUserName] <String> [-CHAPPassword] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Establishes a session with your specified iSCSI target.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
TargetNodeAddress	Specifies the target node address.	true	true (ByPropertyName)	
TargetPortalAddress	Specifies the target portal address.	true	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
TargetPortalPortNumber	Specifies the target portal port number.	false	true (ByPropertyName)	
InitiatorPortalAddresses	Specifies the initiator portal address.	false	true (ByPropertyName)	
CHAPUserName	Specifies your CHAP user name.	false	true (ByPropertyName)	
CHAPPassword	Specifies your CHAP password.	false	true (ByPropertyName)	
Session	Specifies the session ID from OpenSmConnection. For internal use only.	false	true (ByPropertyName)	
Host	Specifies the name of the computer or host on which the SnapCenter Plug-in for Microsoft Windows service you want to perform the operation runs. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Connecting to an iSCSI target

```
PS C:\> Connect-SdIscsiTarget -TargetNodeAddress iqn.1992-08.com.netapp:sn.54053432d1f311e19455123478563412:vs.5
-TargetPortalAddress 172.17.175.84 -TargetPortalPortNumber 3260
```

This example syntax connects you to an iSCSI target.

Connect-SdStorage

Connects a Windows disk to a LUN.

Syntax

```
Connect-SdStorage [-Path] <String> [-LunPath] <String> [-StorageSystem] <String> [-SharedDisk] <> [-ClusteredSharedVolume] <> [-Igroup] <String> [-InitiatorInfo] <HostInitiatorInfo> [-PortSet] <String> [-AutoPickPortSet] <> [-AutopickMountPoint] <> [-ResourceGroup] <String> [-RawDeviceMapping] <> [-Datastore] <String> [-FileSystemLabel] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Connects a dedicated disk, shared disk, or a clustered shared volume based on a LUN.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies the drive letter or mount point: D:, D:\	false	true (ByPropertyName)	
LunPath	Specifies your LUN path using this format: /vol/volx/lunx	true	true (ByPropertyName)	
StorageSystem	Specifies the target virtual storage machine that you are going to use for provisioning.	true	true (ByPropertyName)	
SharedDisk	Indicates whether you need to provision your Windows disk as a shared disk.	false	true (ByPropertyName)	
ClusteredSharedVolume	Indicates whether you will provision your Windows disk as a Clustered Shared Volume.	false	true (ByPropertyName)	
Igroup	Specifies the igroup you want to use for mapping the LUN. If not specified, SnapCenter Plug-in for Microsoft Windows automatically manages the igroup for mapping the LUN.	false	true (ByPropertyName)	
InitiatorInfo	Specifies the initiators you want to add to your Igroup.	false	true (ByPropertyName)	
PortSet	Specifies the portset you want to use for binding your igroup. If your igroup is already bound to a different portset, specifying this parameter unbinds your igroup and then binds it to the portset specified here.	false	true (ByPropertyName)	
AutoPickPortSet	Indicates whether you want SnapCenter Plug-in for Microsoft Windows to handle the portset binding automatically.	false	true (ByPropertyName)	
AutopickMountPoint	Specifies whether SnapCenter Plug-in for Windows automatically picks the drive letter/volume mount point for the connected disk.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
ResourceGroup	Specifies the Cluster Resource Group you want to use for a shared disk.	false	true (ByPropertyName)	
RawDeviceMapping	Specifies whether the disk is provisioned as RAW device Mapping.	false	true (ByPropertyName)	
Datastore	Specifies whether the datastore is to be used for RDM.	false	true (ByPropertyName)	
FileSystemLabel	Specifies the label you want to attach to your new Windows volume.	false	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies your target host.	false	true (ByPropertyName)	

Examples

Example 1: Connecting to a dedicated Windows disk

```
PS C:\> connect-sdstorage -StorageSystem 172.17.165.31 -path V: -LunPath /vol/santest/b09
```

In this example syntax, you connect to a dedicated disk.

Example 2: Connecting to a shared Windows disk

```
PS C:\> connect-sdstorage -StorageSystem 172.17.165.31 -path V: -LunPath /vol/santest/b09 -SharedDisk -ResourceGroup prod
```

In this example syntax, you connect to a shared disk.

Example 3: Connecting to a Clustered Shared Volume

```
PS C:\> connect-sdstorage -StorageSystem 172.17.165.31 -LunPath /vol/santest/b09 -ClusteredSharedVolume
```

In this example syntax, you connect to a Clustered Shared Volume.

Debug-SdHost

Troubleshoots your system setup.

Syntax

```
Debug-SdHost [-Session] <String> [-Host] <String> [-RuleCategory]
<Category> [-Session] <String> [-Host] <String>
```

Detailed Description

Troubleshoots your system setup. You can use this cmdlet to identify problems with the following rules:a) Validate storage connection settings.b) Export-policy rule.c) SMB share "continuously-available" property.d) SMB share ACL setup.When you are troubleshooting a clustered Data ONTAP environment, run Debug-SdHost on each node of the Windows cluster.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
RuleCategory	Indicates that you want to troubleshoot the specified category only.	false	true (ByPropertyName)	

Examples

Example 1: Debugging your host

```
PS C:\> Debug-SdHost
```

In this example syntax, you have checked your host for the various system setup problems and found errors with the export-policy rule, the SMB share ACL setup rule, and the SMB share "continuously-available" property rule.

```
Rule: Storage connections.
Description : The storage connection rule verifies that the storage
connection settings on your host system are valid and active.
Category: General
Source : NEXTGEN-BOX59
```

Severity: Info
Problem : N/A
Impact : N/A
Resolution : N/A
Message : Success. All your storage connection settings are valid and active.
Rule: Export-Policy Rule
Description : The export-policy rule verifies that the client trying to access the data objects is doing so using the SMB protocol.
Category: SMB
Source : NEXTGEN-BOX59
Severity: Info
Problem : N/A
Impact : N/A
Resolution : N/A
Message : Success. The SMB protocol is set in the export-policy rule of all the virtual storage servers.
Rule: SMB share ACL setup.
Description : This rule verifies that the share ACL has host permissions, and if your host is a part of a cluster it verifies that the share has cluster permissions.
Category: Hyper_V
Source : NEXTGEN-BOX59
Severity: Error
Problem : Your shares do not have access control set for the host or the cluster.
Impact : You cannot access these shares from your host.
Resolution : Add the host or the cluster to your share's ACL.
Message : Error. The following shares do not have host or clusters set in the ACLs: \\CIFS_SERV\admin\$,\\CIFS_SERV\ipc\$.
Rule: SMB share "continuously-available" property.
Description : This rule verifies that your SMB share contains the continuously-available property. The continuously-available property is mandatory for installing a VM.
Category: Hyper_V
Source : NEXTGEN-BOX59
Severity: Error
Problem : Some of the shares do not contain the continuously-available property.
Impact : You cannot install a VM on the share.
Resolution : Set the share property to continuously-available.
Message : Error. The following shares do not have continuously-available property set:
\\CIFS_SERV\admin\$,\\CIFS_SERV\sales_dbshare,\\CIFS_SERV\ACL,\\CIFS_SERV\

```
qtree,\\CIFS_SERV\ipc$.
```

Delete-SdLUNS

Syntax

```
Delete-SdLUNS [-LunPath] <String[]> [-RestApiURL] <String> [-Session]  
<String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
LunPath		true	true (ByValue, ByPropertyName)	
RestApiURL		true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Disconnect-SdIscsiTarget

Terminates your session with the iSCSI target.

Syntax

```
Disconnect-SdIscsiTarget [-SessionIdentifier] <String> [-  
TargetNodeAddress] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Terminates your session with the iSCSI target.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
SessionIdentifier	Specifies the session identifier.	true	true (ByPropertyName)	
TargetNodeAddress	Specifies the target node address.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name of the computer or host on which the SnapCenter Plug-in for Microsoft Windows service you want to perform the operation runs. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Disconnecting from your iSCSI target session

```
PS C:\> Disconnect-SdIscsiTarget -SessionIdentifier fffffa800762f020-4000013700000001 -TargetNodeAddress iqn.1992-08.com.netapp:sn.54053432d1f311e19455123478563412:vs.5
```

This example syntax disconnects you from your iSCSI target session.

Disconnect-SdStorage

Disconnects your storage system from your Windows disk or SMB share.

Syntax

```
Disconnect-SdStorage [-Path] <String> [-IgnoreVolumeMountPoint] <> [-Session] <String> [-Host] <String>
```

Detailed Description

Disconnects your Windows disk or SMB share from your storage system.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies your LUN path or mount point using the format: D:, D:\Mount	true	true (ByPropertyName)	
IgnoreVolumeMount Point		false	true (ByPropertyName)	
Session	Specifies the Session ID from Open-SmConnection	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Disconnecting a storage system from a Windows drive

```
PS C:\> Disconnect-SDStorage -Path K:
```

This example syntax disconnect the specified drive from a storage system.

Example 2: Disconnecting a storage system from a Windows mount point

```
PS C:\> Disconnect-SDStorage -Path K:\Mount
```

This example syntax disconnect the specified Mount Point from a storage system.

Dismount-SdClone

Enables dismounting a cloned storage resource.

Syntax

```
Dismount-SdClone [-ClonePath] <String[]> [-ResourceType] <ResourceType>
[-Session] <String> [-Host] <String>
```

Detailed Description

Enables dismounting a cloned storage resource. This can be a single clone or a comma-separated list of clones of the same resource type. Related cmdlets: Mount-SdClone, Get-SmClone, Remove-SmClone, New-SmClone

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
ClonePath	Specifies the path to the clone that you want to dismount. This can be a single clone or a comma-separated list of clones of the same resource type.	true	true (ByValue, ByPropertyName)	
ResourceType	Specifies the type of the resource in the ClonePath parameter. The possible options are: "SDStorageVolume", "SDStorageLunPath", "SDStorageDir".	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the FQDN or IP address of the host on which you want to execute the operation.	false	true (ByPropertyName)	

Examples

Example 1: Dismount a clone from a given cloned path

```
PS C:\> Dismount-SdClone -ClonePath Primary_SVM:/vol/Vol11201210041488133  
-ResourceType SDStorageVolume
```

This example syntax specifies the cloned volume path and the resource type, and dismounts the clone.

```
Vserver : Primary_SVM  
FullPath: Primary_SVM:/vol/Vol11201210041488133  
JunctionPath:  
JunctionParentName :  
SizeTotal : 70931603456  
SizeUsed: 62187937792  
SnapMirrorSource:  
SnapMirrorDest :  
SnapVaultPrimary:  
SnapVaultSecondary :  
FlexCloneEnabled:  
IsFlexClone :  
VolumeSecurityStyle :  
AggregateName : Aggr4  
AggregateUuid : b3525de1-9aa0-46d2-9259-eeaef94d34b0  
FlexCloneLevel :
```

IsLeaf :
VolumeState : online
AggregateAvailableSpace :
ExportPolicy: default
VolumeUuid : fd1bb1d5-528a-11ec-a2a8-00a0986d2568
OwningVserverName : Primary_SVM
VolumeType :
IsProtected : False
StorageVmKey:
VolumeKey :
VolumeInstanceUuid :
Size:
IsRootVolume:
IsSelectable:
StorageKey :
ProtectionStatus:
ComplianceStatus:
StatusMessage :
SVMSloKey :
VolumeSloKey:
SpaceGuarantee :
PhysicalUsed: 7004160
IsFlexGroup :
ResourceType: SDStorageVolume
ResourceName: Primary_SVM:/vol/Vol11201210041488133
Ranges :
Name: Vol11201210041488133
Type:
Id :
Host:
UserName:
Passphrase :
Deleted : False
Auth: SMCoreContracts.SmAuth
IsClone : False
CloneLevel : 0
Hosts :
StorageName :
ResourceGroupNames :
PolicyNames :
Key : 0
NsmObjectID : 0
SizeOfSmObject :

Example 2: Dismount a set of clones from the given list of cloned paths

```
PS C:\> Dismount-SdClone -ClonePath
Primary_SVM:/vol/Vol11201212311309514,Primary_SVM:/vol/Vol1120121231535451
5 -ResourceType SDStorageVolume -Verbose
```

This example syntax specifies the list of cloned volume paths and their resource type, and dismounts the clones. The output is shortened for readability.

```
Vserver : Primary_SVM
FullPath: Primary_SVM:/vol/Vol11201212311309514
.....
Vserver : Primary_SVM
FullPath: Primary_SVM:/vol/Vol11201212315354515
.....
VERBOSE: Operation successful.
```

Dismount-SdSnapshot

Facilitates dismounting the list of SMB shares that are mounted from the specified Snapshot copy as a different set of shares. Facilitates dismounting the list of LUNs mounted from the specified Snapshot copies as a different set of LUNs.

Syntax

```
Dismount-SdSnapshot [-Path] <Object[]> [-DeleteParentClones] <> [-
IgnoreVolumeMountPoint] <> [-Session] <String> [-Host] <String>
```

Detailed Description

Facilitates dismounting the list of SMB shares that are mounted from the specified Snapshot copy as a different set of shares. Facilitates dismounting the list of LUNs mounted from the specified Snapshot copies as a different set of LUNs. You can use this cmdlet during backup verification operations. First, you can use Mount-SdSnapshot to mount database and log shares or LUNs from the Snapshot copy. Next, you perform verification operations. After the backup verification is completed, use this cmdlet to dismount the shares/LUNs. If multiple paths contain one or more invalid paths specified in the cmdlet, the command fails for all the paths in the input. Related cmdlets: Mount-SdSnapshot

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies a comma-separated list of SMB shares, disks, or LUN mount points you want to dismount. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByValue, ByPropertyName)	
DeleteParentClones		false	true (ByPropertyName)	
IgnoreVolumeMount Point		false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. For SMB shares, the default is your local machine. For LUNs, you must provide this parameter.	false	true (ByPropertyName)	

Examples

Example 1: Dismounting multiple shares that were mounted from a Snapshot copy

```
PS C:\> Dismount-SdSnapshot -Path
"\SQLFileserver\DBShareSdClone607fb343_2b3c_41f6_8912_8762a1800290","\SQLFileserver\DBShareSdClone6bcf3df5_3384_4ba4_9b33_25bb9636a486"
```

This example syntax specifies how to dismount your Snapshot copies mounted on the specified shares.

Example 2: Dismounting a Snapshot of a LUN

```
PS C:\> Dismount-SdSnapshot -Path I: -Host Host1.DMN.COM
```

This example syntax specifies how to dismount your Snapshot copy mounted on the specified drive.

Example 3: Dismounting multiple mount points

```
PS C:\> Dismount-SdSnapshot -Path
"C:\scmnpt\mpdisk0005\","C:\scmnpt\mpdisk0006\" -Host Host1.DMN.COM
```

This example syntax specifies how to dismount your Snapshot copies mounted on the specified mount points.

Get-SdAluaPaths

Lists all available ALUA-enabled disks and their state.

Syntax

```
Get-SdAluaPaths [-Paths] <String[]> [-Session] <String> [-Host]
<String>
```

Detailed Description

Lists all available ALUA-enabled disks and their state.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Paths	Specifies the drive letter or mount point of the file system.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name of the host.	false	true (ByPropertyName)	

Examples

Example 1: Listing all ALUA enabled disks

```
PS C:\> Get-SdAluaPaths
```

This example syntax lists information about all ALUA enabled disks.

Get-SdDataStores

Syntax

```
Get-SdDataStores [-Shared] <> [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Shared		false	false	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Get-SdFCPInitiator

Lists FCP initiators.

Syntax

```
Get-SdFCPInitiator [-Session] <String> [-Host] <String>
```

Detailed Description

Lists FCP initiators.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name of the computer or host on which the SnapCenter Plug-in for Microsoft Windows service you want to perform the operation runs. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Listing all FCP initiators

```
PS C:\> Get-SdFCPInitiator
```

This example syntax displays all your FCP initiators.

Get-SdIgroup

Gets information about available igroups.

Syntax

```
Get-SdIgroup [-Name] <String[]> [-Initiators] <String[]> [-LunPath]
<String> [-StorageSystem] <String> [-Session] <String> [-Host]
<String>
```

Detailed Description

Gets information about available igroups.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Name	Specifies the name of the igroups about which you want to retrieve information.	false	true (ByPropertyName)	
Initiators	Specifies any initiators included in the igroup.	false	true (ByPropertyName)	
LunPath	Specifies the LUN on your storage system.	false	true (ByPropertyName)	
StorageSystem	Specifies the storage system on which the igroup resides.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Retrieving igroup information

```
PS C:\> Get-SdIgroup -StorageSystem 172.17.168.13
```

This example syntax retrieves the igroup information for the specified storage system.

Get-SdIgroupWithUuid

Syntax

```
Get-SdIgroupWithUuid [-Name] <String[]> [-Initiators] <String[]> [-LunPath] <String> [-LunUuid] <String> [-StorageSystem] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Name		false	true (ByPropertyName)	
Initiators		false	true (ByPropertyName)	
LunPath		false	true (ByPropertyName)	
LunUuid		false	true (ByPropertyName)	
StorageSystem		true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Get-SdInfo

Gets information about the SnapCenter Plug-in for Microsoft Windows instance that you are running.

Syntax

```
Get-SdInfo [-Session] <String> [-Host] <String> [-Details] <> [-Session] <String> [-Host] <String>
```

Detailed Description

You can use this cmdlet to retrieve the version number of the SnapCenter Plug-in for Microsoft Windows instance you are currently running. You can use the Details parameter to get additional information about Snapshot, discovery, virtualization, configuration, storage resolution, SMB shadow copy, SnapRemote, administration, and provisioning services, along with the interface name.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Session	Specifies the session ID from Open-SmConnection..	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
Details	Gets additional information about Snapshot copy, discovery, virtualization, configuration, storage resolution, SMB shadow copy, SnapRemote, administration, and provisioning services, along with the interface name.	false	true (ByPropertyName)	

Examples

Example 1: Getting the details about the SnapCenter Plug-in for Microsoft Windows instance

```
PS C:\> Get-SdInfo -Details
```

This example gets detailed information about the version and services of the SnapCenter Plug-in for Microsoft Windows instance you are running.

```
Get-SdInfo -Details
Version: 7.0.0.5779
Snapshot Service
InterfaceName: SDSnapshot_v1_1
Version: 7.0.0.5779
URLForInterface: net.tcp://localhost:808/SnapDrive/Snapshot
URLForWSDL:
Discovery Service
InterfaceName: SDDiscovery_v10
Version: 7.0.0.5779
URLForInterface: net.tcp://localhost:808/SnapDrive/Discovery
URLForWSDL:
```

```

Virtualization Service
InterfaceName:
SnapDrive.Nsf.Interfaces.Virtualization.IVirtualMachineManagement
Version: 7.0.0.5779
URLForInterface: net.tcp://localhost:808/SnapDrive/Virtualization
URLForWSDL:
Configuration Service
InterfaceName: SnapDrive.Nsf.Interfaces.SDConfiguraiton
Version: 7.0.0.5779
URLForInterface: net.tcp://localhost:808/SnapDrive/Configuration
URLForWSDL:
StorageResolution Service
InterfaceName: SnapDrive.Nsf.Interfaces.SDStorageResolution
Version: 7.0.0.5779
URLForInterface: net.tcp://localhost:808/SnapDrive/StorageResolution
URLForWSDL:
CIFS ShadowCopy Service
InterfaceName: SnapDrive.Nsf.Interfaces.SDCIFSShadowCopyManagement
Version: 7.0.0.5779
URLForInterface:
net.tcp://localhost:808/SnapDrive/CIFSShadowCopyManagement
URLForWSDL:
SnapRemote Service
InterfaceName: SDSnapRemote_v1_3
Version: 7.0.0.5779
URLForInterface: net.tcp://localhost:808/SnapDrive/SnapshotRemote
URLForWSDL:
Administration Service
InterfaceName: SDAdmin_v10
Version: 7.0.0.5779
URLForInterface: net.tcp://localhost:808/SnapDrive/SDAdminNext
URLForWSDL:
InterfaceName: SDAdmin
Version: 7.0.0.5779
URLForInterface: net.tcp://localhost:808/SnapDrive/SDAdminInfo
URLForWSDL:
Provisioning Service
InterfaceName: SnapDrive.Nsf.Interfaces.SDProvisioningManagement
Version: 7.0.0.5779
URLForInterface: net.tcp://localhost:808/SnapDrive/ProvisioningManagement
URLForWSDL:

```

Get-Sdlscsilnitiator

Enumerates information about iSCSI sessions and initiators.

Syntax

```
Get-SdIscsiInitiator [-Session] <String> [-Host] <String>
```

Detailed Description

Enumerates information about iSCSI sessions and initiators.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name of the computer or host on which the SnapDrive service you want to perform the operation runs. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Listing all iSCSI sessions and initiators

```
PS C:\> Get-SdIscsiInitiator
```

In this example syntax, you list all iSCSI sessions and associated initiators.

Get-SdIscsiTarget

Enumerates iSCSI targets on a storage system.

Syntax

```
Get-SdIscsiTarget [-StorageSystemName] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Enumerates iSCSI targets on a storage system.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystemName	Specifies the name of the storage system for which you want to list iSCSI targets.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name of the computer or host on which the SanpCenter Plug-in for Microsoft Windows service you want to perform the operation runs. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Listing all iSCSI targets on a storage system

```
PS C:\> Get-SdIscsiTarget -StorageSystemName vs0
```

In this sample syntax, you get information about iSCSI targets on a specified storage system.

Example 2: Listing all iSCSI targets on a storage system

```
PS C:\> Get-SdIscsiTarget -StorageSystem 172.17.11.122
```

In this sample syntax, you get information about iSCSI targets on a specified storage system.

Get-SdLun

Gets information about the LUNs created on your storage system.

Syntax

```
Get-SdLun [-StorageSystem] <String> [-LunPath] <String> [-Session] <String> [-Host] <String> [-SerialNumber] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Gets information about the LUNs created on your storage system.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the name of the storage system on which your LUN is located.	true	true (ByPropertyName)	
LunPath	Specifies the path of the LUN on your storage system.	false	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
SerialNumber		true	true (ByPropertyName)	

Examples

Get-SdLunMap

Gets information about all the mapped LUNs and the igroups to which they are mapped.

Syntax

```
Get-SdLunMap [-StorageSystem] <String> [-LunPath] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Gets information about all the mapped LUNs and the igroups to which they are mapped.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the storage system on which the igroup, to which you mapped your LUNs, is located.	true	true (ByPropertyName)	
LunPath	Specifies the path of the LUN on your storage system.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Get-SdLunMapWithUuid

Syntax

```
Get-SdLunMapWithUuid [-StorageSystem] <String> [-LunPath] <String> [-LunUuid] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem		true	true (ByPropertyName)	
LunPath		false	true (ByPropertyName)	
LunUuid		false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Get-SdLunWithUuid

Syntax

```
Get-SdLunWithUuid [-StorageSystem] <String> [-LunPath] <String> [-LunUuid] <String> [-Session] <String> [-Host] <String> [-SerialNumber] <String> [-LunUuid] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem		true	true (ByPropertyName)	
LunPath		false	true (ByPropertyName)	
LunUuid		false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	
SerialNumber		true	true (ByPropertyName)	

Examples

Get-SdNfsExport

Syntax

```
Get-SdNfsExport [-DataPaths] <String[]> [-ExportPath] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
DataPaths		true	true (ByValue, ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
ExportPath		true	true (ByValue, ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Get-SdPlugIn

Syntax

```
Get-SdPlugIn [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Get-SdPlugInResource

Syntax

```
Get-SdPlugInResource [-Files] <String[]> [-ComputerName] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Files		true	true (ByPropertyName)	
ComputerName		false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Get-SdPortSet

Gets information about available portsets.

Syntax

```
Get-SdPortSet [-PortSetName] <String> [-StorageSystem] <String> [-
GetLunMappings] <> [-Session] <String> [-Host] <String>
```

Detailed Description

Gets information about available portsets.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
PortSetName	Specifies the name of the portset about which you want to get information.	false	true (ByPropertyName)	
StorageSystem	Specifies the name of the storage system on which your portset resides.	true	true (ByPropertyName)	
GetLunMappings	Indicates that you want to get information about the number of LUN mappings.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Get-SdSMBShadowCopyEmsMessage

Gets SMB shadow copy EMS messages from the event log, so that you can find backup failure details.

Syntax

```
Get-SdSMBShadowCopyEmsMessage [-Path] <Object> [-SearchPattern]  
<String> [-Session] <String> [-Host] <String>
```

Detailed Description

Gets shadow copy EMS messages that contain specified SMB shadow copy ID search criteria from the virtual storage server, so that you can view the SMB shadow copy failure details.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies the SMB share path for shadow copy EMS messages. Enter one path only. If you enter more than one path value, the search is performed only on the first path. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByValue, ByPropertyName)	
SearchPattern	Specifies a regular expression search criteria, so that you can search for EMS messages pertaining to a specific backup failure event.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Getting shadow copy EMS messages for a specified ID

```
PS C:\> Get-SdSMBShadowCopyEmsMessage -Path \\10.53.41.218\root
-SearchPattern *9831ed56-ee2e-11e1-994b*
```

Gets shadow copy EMS messages that contains specified SMB shadow copy ID search criteria from the virtual storage server for the SMB shadow copy.

Gets shadow copy EMS messages that contains specified SMB shadow copy ID search criteria from the virtual storage server for the SMB shadow copy.

Example 2: Getting all SMB shadow copy EMS message on a virtual storage server

```
PS C:\> Get-SdSMBShadowCopyEmsMessage -Path \\172.17.165.40\root
-SearchPattern *
```

Gets all shadow copy EMS messages from the virtual storage server for the SMB shadow copy. The message you retrieve looks similar to example 1.

Get-SdSnapMirror

Gets the SnapMirror relationship status for storage system volumes you specify.

Syntax

```
Get-SdSnapMirror [-StorageSystem] <String> [-Volume] <String[]> [-Session] <String> [-Host] <String>
```

Detailed Description

Gets the SnapMirror relationship status for storage system volumes you specify. If you do not specify any volumes, you retrieve SnapMirror relationships for all registered virtual storage servers. This cmdlet is supported in clustered Data ONTAP 8.2 and later. Related cmdlets: Invoke-SdSnapMirrorUpdate

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the primary storage system name or IP address containing the volumes for which you want to retrieve the SnapMirror relationship status.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Volume	Indicates a comma-separated list of storage system volumes for which you want to retrieve the SnapMirror relationship status.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Getting SnapMirror information for a storage system volume

```
PS C:\> Get-SdSnapMirror -StorageSystem 172.17.162.61 -Volume test_vol1 -Verbose
```

In this example syntax, you retrieve SnapMirror relationship status information for the volume test_vol1.

```
Get-SdSnapMirror -StorageSystem 172.17.162.61 -Volume test_vol1 -Verbose
SnapMirrorRelationshipType : data_protection
SnapMirrorPolicyName      : DPDefault
SnapMirrorRelationship    : vserver : test_vol1 ==> vserver : test_vol2
SnapMirrorState: snapmirrored
SnapMirrorStatus         : Idle
Lag: 0
LagSpecified            : False
BaseSnapshotName         : snapmirror.9a000021-fb71-11e1-8315-123478563412_2147484917.2013-07-19_124400
Message: Success.
```

Example 2: Getting SnapVault information for a storage system volume

```
PS C:\> Get-SdSnapMirror -StorageSystem 172.17.162.61 -Volume snapvault_source -Verbose
```

In this example syntax, you retrieve SnapVault relationship status information for the volume snapvault_source.

```
PS C:\Users\administrator.NEXTGEN> Get-SdSnapMirror -StorageSystem
172.17.162.61 -Volume snapvault_source -Verbose
SnapMirrorRelationshipType : vault
SnapMirrorPolicyName      : XDPDefault
SnapMirrorRelationship    : vserver : snapvault_source ==> vserver :
snapvault_dest
SnapMirrorState: snapmirrored
SnapMirrorStatus        : Idle
Lag: 0
LagSpecified           : False
BaseSnapshotName       : DATA
Message: Success.
```

Get-SdSnapMirrorPolicyRule

Gets the rules for managing Snapshot retention on the SnapVault secondary storage system.

Syntax

```
Get-SdSnapMirrorPolicyRule [-SourceStorageSystem] <String> [-
SourceStorageSystemVolume] <String> [-DestinationStorageSystem]
<String> [-DestinationStorageSystemVolume] <String> [-Session]
<String> [-Host] <String>
```

Detailed Description

Gets the rules for managing Snapshot retention on the SnapVault secondary storage system. Related cmdlets: Set-SdSnapMirrorPolicyRule, Remove-SdSnapMirrorPolicyRule

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
SourceStorageSystem	Specifies the primary storage system name containing the source volumes of the SnapMirror relationship for which you want to retrieve the SnapMirror policy rules. IP addresses are not supported.	true	true (ByValue, ByPropertyName)	
SourceStorageSystemVolume	Specifies the source volume of the SnapMirror relationship for which you want to retrieve the SnapMirror policy rules.	true	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
DestinationStorageSystem	Specifies the secondary storage system name containing the destination volumes of the SnapMirror relationship for which you want to retrieve the SnapMirror policy rules. IP addresses are not supported.	true	true (ByValue, ByPropertyName)	
DestinationStorageSystemVolume	Specifies the destination volume of the SnapMirror relationship for which you want to retrieve the SnapMirror policy rules.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Getting SnapMirror policy rule information from the policy for a SnapMirror relationship

```
PS C:\> Get-SdSnapMirrorPolicyRule -SourceStorageSystem vs1
-SourceStorageSystemVolume src_vol -DestinationStorageSystem vs2
-DestinationStorageSystemVolume dest_vol01 -verbose
```

Get the SnapMirror policy rules from the policy on the specified relationship.

```

SnapLabel    : daily
NumberOfSnapsToKeep: 10
PreserveSnaps :
PreserveSnapsSpecified : False
WarnThreshold : 0
SnapMirrorPolicy : snapvault_policy
SnapLabel    : weekly
NumberOfSnapsToKeep: 3
PreserveSnaps :
PreserveSnapsSpecified : False
WarnThreshold : 2
SnapMirrorPolicy : snapvault_policy
SnapLabel    : mothly
NumberOfSnapsToKeep: 4
PreserveSnaps :
PreserveSnapsSpecified : False
WarnThreshold : 3
SnapMirrorPolicy : snapvault_policy
The getting SnapMirror policy rules operation is successful.

```

Get-SdSnapshot

Lists the Snapshot copies for a specified set of volumes, logical disks, or SMB shares.

Syntax

```

Get-SdSnapshot [-Path] <Object[]> [-Snapshot] <String> [-VersionUuid]
<String> [-GetAllSnapshots] <> [-GetSecondarySnapshots] <> [-Session]
<String> [-Host] <String> [-StorageSystem] <String> [-VolumeName]
<String> [-Snapshot] <String> [-VersionUuid] <String> [-
GetAllSnapshots] <> [-GetSecondarySnapshots] <> [-Session] <String>
[-Host] <String>

```

Detailed Description

Lists the Snapshot copies for a specified set of volumes, logical disks, or SMB shares. You can also use this cmdlet to get information about a specific Snapshot copy. Related cmdlets: New-SdSnapshot Remove-SdSnapshot, Rename-SdSnapshot and Restore-SdSnapshot

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies avolumes, logical disks, or a comma-separated list of SMB shares. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByValue, ByPropertyName)	
Snapshot	Names the Snapshot copy about which you want information. If you do not use this parameter, all the Snapshot copies for the specified list of SMB shares, Windows volume, or Windows logical disk is returned.	false	true (ByPropertyName)	
VersionUuid	Indicates the version of the Snapshot copy about which you want information.	false	true (ByPropertyName)	
GetAllSnapshots	Indicates that you want to get information about both primary and secondary Snapshot copies. The default behavior is to enumerate only the primary Snapshot copies.	false	false	
GetSecondarySnapshots	Indicates that you want to retrieve information about secondary Snapshot copies only.	false	false	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
StorageSystem	Specifies the name of the storage system on which the Snapshot copies are located.	true	true (ByValue, ByPropertyName)	
VolumeName	Specifies the name of the volume you are querying.	true	true (ByValue, ByPropertyName)	

Examples

Example 1: Getting Snapshot copies for the specified list of SMB shares

```
PS C:\> Get-SdSnapshot -path "\\CifsServer\sqlshare",
 "\\CifsServer\sqlshare2"
```

This example syntax gets a list of Snapshot copies for the list of SMB shares you provide.

```
PS C:\Users\administrator.NEXTGEN> Get-SdSnapshot -Path
"\CIFS_SERV\snapvault_source", "\CIFS_SERV\test_voll" -Verbose
VERBOSE: Validating input paths.
AccessTime: 1373664154
AccessTimeDT : 7/12/2013 9:22:34 PM
Busy : False
ContainsLunClones :
CumulativePercentageOfTotalBlocks : 0
CumulativePercentageOfUsedBlocks : 1
CumulativeTotalBlocks : 1052076
CumulativeTotalKb : 1077325824
Dependency:
Is7ModeSnapshot : False
PercentageOfTotalBlocks : 0
PercentageOfUsedBlocks: 0
SnapshotInstanceUuid : eb674595-5901-453e-9e83-93322e1f6547
SnapshotOwnersList: {}
TotalBlocks : 296
TotalKb : 303104
SnapshotName : KII
AccessPoint : \CIFS_SERV\snapvault_source
StorageSystemName : vserver1
StorageVolumeName : snapvault_source
VersionUuid : eb674595-5901-453e-9e83-93322e1f6547
AccessTime: 1373664320
AccessTimeDT : 7/12/2013 9:25:20 PM
Busy : False
ContainsLunClones :
CumulativePercentageOfTotalBlocks : 0
CumulativePercentageOfUsedBlocks : 1
CumulativeTotalBlocks : 1051780
CumulativeTotalKb : 1077022720
Dependency:
Is7ModeSnapshot : False
PercentageOfTotalBlocks : 0
PercentageOfUsedBlocks: 0
SnapshotInstanceUuid : 12e542fe-f771-41ed-8ffe-f4a922337c3f
SnapshotOwnersList: {}
TotalBlocks : 116200
TotalKb : 118988800
SnapshotName : Koo
AccessPoint : \CIFS_SERV\snapvault_source
StorageSystemName : vserver1
StorageVolumeName : snapvault_source
```

```
VersionUuid      : 12e542fe-f771-41ed-8ffe-f4a922337c3f
AccessTime: 1373678045
AccessTimeDT    : 7/13/2013 1:14:05 AM
Busy           : False
ContainsLunClones :
CumulativePercentageOfTotalBlocks : 0
CumulativePercentageOfUsedBlocks  : 1
CumulativeTotalBlocks : 935580
CumulativeTotalKb    : 958033920
Dependency:
Is7ModeSnapshot    : False
PercentageOfTotalBlocks : 0
PercentageOfUsedBlocks: 1
SnapshotInstanceUuid : fca29895-f5cf-4737-a1df-e3915ff3e551
SnapshotOwnersList: {}
TotalBlocks       : 935580
TotalKb           : 958033920
SnapshotName      : JI
AccessPoint       : \\CIFS_SERV\snapvault_source
StorageSystemName : vserver1
StorageVolumeName : snapvault_source
VersionUuid      : fca29895-f5cf-4737-a1df-e3915ff3e551
AccessTime: 1374096530
AccessTimeDT    : 7/17/2013 9:28:50 PM
Busy           : False
ContainsLunClones :
CumulativePercentageOfTotalBlocks : 0
CumulativePercentageOfUsedBlocks  : 0
CumulativeTotalBlocks : 9196
CumulativeTotalKb    : 9416704
Dependency:
Is7ModeSnapshot    : False
PercentageOfTotalBlocks : 0
PercentageOfUsedBlocks: 0
SnapshotInstanceUuid : 22e13abf-89bf-442e-9a0a-832dc1d0a534
SnapshotOwnersList: {}
TotalBlocks       : 4180
TotalKb           : 4280320
SnapshotName      : new_SP1
AccessPoint       : \\CIFS_SERV\test_vol1
StorageSystemName : vserver1
StorageVolumeName : test_vol1
VersionUuid      : 22e13abf-89bf-442e-9a0a-832dc1d0a534
AccessTime: 1374263040
AccessTimeDT    : 7/19/2013 7:44:00 PM
Busy           : False
```

```

ContainsLunClones :
CumulativePercentageOfTotalBlocks : 0
CumulativePercentageOfUsedBlocks : 0
CumulativeTotalBlocks : 5016
CumulativeTotalKb : 5136384
Dependency: snapmirror
Is7ModeSnapshot : False
PercentageOfTotalBlocks : 0
PercentageOfUsedBlocks: 0
SnapshotInstanceUuid : 49b7b1cf-9fa2-4737-b3b8-df294bb570ea
SnapshotOwnersList: {}
TotalBlocks : 4168
TotalKb : 4268032
SnapshotName : snapmirror.9a000021-fb71-11e1-8315-
123478563412_2147484917.2013-07-19_124400
AccessPoint : \\CIFS_SERV\test_vol1
StorageSystemName : vserver1
StorageVolumeName : test_vol1
VersionUuid : 49b7b1cf-9fa2-4737-b3b8-df294bb570ea
AccessTime: 1374517978
AccessTimeDT : 7/22/2013 6:32:58 PM
Busy : False
ContainsLunClones :
CumulativePercentageOfTotalBlocks : 0
CumulativePercentageOfUsedBlocks : 0
CumulativeTotalBlocks : 848
CumulativeTotalKb : 868352
Dependency:
Is7ModeSnapshot : False
PercentageOfTotalBlocks : 0
PercentageOfUsedBlocks: 0
SnapshotInstanceUuid : 318d16e2-df58-495c-87ee-cd6a1d054447
SnapshotOwnersList: {}
TotalBlocks : 848
TotalKb : 868352
SnapshotName : local
AccessPoint : \\CIFS_SERV\test_vol1
StorageSystemName : vserver1
StorageVolumeName : test_vol1
VersionUuid : 318d16e2-df58-495c-87ee-cd6a1d054447

```

Example 2: Getting information for the Snapshot copy "test"

```
PS C:\> Get-SdSnapshot -path "\\SQLCifsServer\sqlshare" -snapshot "test"
```

This example syntax gets information for Snapshot copy "test" on the SMB share \\SQLCifsServer\sqlshare.

Example 3: Getting the latest Snapshot backup of the specified SMB share

```
PS C:\> Get-SdSnapshot -path "\\SQLCifsServer\sqlshare" | sort-object  
AccessTimeDT -ascending | select-object -last 1
```

This example syntax gets the latest Snapshot backup of the SMB share \\SQLCifsServer\sqlshare.

Example 4: Getting secondary Snapshot copies for the specified list of SMB shares

```
PS C:\> Get-SdSnapshot -path "\\SQLCifsServer\sqlshare",  
"\\SQLCifsServer\sqlshare2" -GetSecondarySnapshots
```

This example syntax gets a list of secondary Snapshot copies for list of SMB shares that you specify.

Example 5: Getting information for specific Snapshot version for specified SMB share

```
PS C:\> Get-SdSnapshot -path "\\SQLCifsServer\sqlshare"  
-SnapshotVersionUuid "d9bda43e-1e00-4fa9-9c7e-72d8dc5ca0b"
```

This example syntax gets the information for Snapshot copy version "d9bda43e-1e00-4fa9-9c7e-72d8dc5ca0b" on the SMB share \\SQLCifsServer\sqlshare.

Example 6: Getting Snapshot copies for a specified LUN

```
PS C:\> Get-SdSnapshot -path D:
```

This example syntax gets the latest Snapshot copies from the specified disk.

Get-SdStorage

Gets storage system information for Windows disks or SMB shares.

Syntax

```
Get-SdStorage [-StorageSystem] <String[]> [-ComputerName] <String> [-  
ExcludeStorageFootprint] <> [-ExcludeSMB] <> [-ExcludeSAN] <> [-  
GetMirrorInfo] <> [-GetUnmanagedDisks] <> [-CloneLevel] <> [-  
Session] <String> [-Host] <String> [-Path] <Object[]> [-  
ComputerName] <String> [-ExcludeStorageFootprint] <> [-ExcludeSMB] <>  
[-ExcludeSAN] <> [-GetUnmanagedDisks] <> [-CloneLevel] <> [-Session]  
<String> [-Host] <String>
```

Detailed Description

Gets storage system information for Windows disks or SMB shares. You must enable the CSV feature in Windows Server 2008 R2 SP1 if you want to use that feature.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the storage system name or IP address from which you want to get active storage, such as SMB shares. When you use this parameter with ExcludeSMB, this parameter is ignored.	false	true (ByPropertyName)	
ComputerName	Indicates the name of the host from which you want all the LUNs to be returned.	false	true (ByPropertyName)	
ExcludeStorageFoot print	Restricts the storage system path results to the host resource attributes only, and excludes the storage footprint. This parameter is ignored when you specify it with Path.	false	true (ByPropertyName)	
ExcludeSMB	Indicates that you do not want to view information about SMB shares.	false	true (ByPropertyName)	
ExcludeSAN	Indicates that you do not want to view information about LUNs.	false	true (ByPropertyName)	
GetMirrorInfo	Indicates that you want to view volume relationship and state information for the volumes on the source storage resources to which you have provided a path.	false	true (ByPropertyName)	
GetUnmanagedDisk s	Indicates that you want to view information about available unmanaged disks. If a disk is mapped to a LUN on an unregistered storage system, it displays as an unmanaged disk, whether it is or not. If you set the parameter ExcludeSAN, GetUnmanagedDisks is ignored.	false	true (ByPropertyName)	
CloneLevel	If the storage system information is for a clone, specifies the clone level.	false	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
Path	Specifies a list of Windows volumes or SMB share. You cannot mix Windows volumes with SMB shares in the same input path.	false	true (ByPropertyName)	

Examples

Example 1: Getting the storage system for a SMB share

```
PS C:\> Get-SdStorage -Path "\\SQLCifsServer\SalesDBShare"
```

This example syntax gets the storage system path for the SMB share \\SQLCifsServer\SalesDBShare.

Example 2: Getting storage system paths for multiple SMB shares

```
PS C:\> Get-SdStorage -Path
 "\\SQLCifsServer\SalesDBShare", "\\SQLCifsServer2\MarketDBShare"
```

This example syntax gets the storage system path for the SMB Shares \\SQLCifsServer\SalesDBShare and \\SQLCifsServer2\MarketDBShare.

Example 3: Getting detailed information about host and storage system resources

```
PS C:\> Get-SdStorage -Path \\SQLCIFSServer\SalesDBShare |
 %{$_.HostResource,$_.StorageSystemResource}
```

This example syntax gets extended information about the host resource and the storage system resource.

Example 4: Getting all the SMB shares on the specified storage systems

```
PS C:\> Get-SdStorage -StorageSystem "10.225.13.110","172.17.175.75"
-ExcludeSAN
```

This example syntax gets all the SMB shares on storage systems 10.225.13.110 and 172.17.175.75.

Example 5: Getting all Windows disks and SMB shares from registered storage systems

```
PS C:\> Get-SdStorage
```

This example syntax gets all the Windows disks and SMB shares from all registered storage systems.

Example 6: Getting the Windows disks and SMB shares with the host resources details only on the specified storage system

```
PS C:\> Get-SdStorage -StorageSystem 10.225.13.110  
-ExcludeStorageFootprint
```

This example syntax gets information about the host resources for Windows disks and SMB shares on storage system 10.225.13.110. You can use this parameter to help your application achieve better performance if you need information about Windows disks and SMB shares but not their storage footprint.

Example 7: Getting the all the LUNs but not SMB shares

```
PS C:\> Get-SdStorage -ExcludeSMB
```

This example syntax retrieves information about all the LUNs on the local host.

Example 8: Getting volume mirror information

```
PS C:\> (Get-SdStorage -StorageSystem 172.17.165.31  
-GetMirrorInfo).StorageSystemResource.Volume
```

This example syntax uses the -GetMirrorInfo parameter to get volume state and relationship information from the source storage system resource.

Get-SdStorageConnectionSetting

Gets the storage system connection, transport, and credential settings from the configuration repository.

Syntax

```
Get-SdStorageConnectionSetting [-Name] <String[]> [-Session] <String>  
[-Host] <String> [-DefaultSetting] <> [-Session] <String> [-Host]  
<String>
```

Detailed Description

This cmdlet reads the storage system, transport, and credential settings from the configuration repository to make a connection to the storage system. These settings include the storage server name (virtual storage server name or IP,) port, transport type, user login, and password. If you do not include parameters, this cmdlet reads all the storage connection settings from the repository. Related cmdlets: Set-SdStorageConnectionSetting and Remove-SdStorageConnectionSetting

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Name	Specifies the name or IP address of the storage system (storage controller or virtual storage server) for which you want to retrieve connection settings.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
DefaultSetting	Indicates that you want to view the default storage system connection settings. When you do not specify explicit storage system connection values, you use the default settings.	true	false	

Examples

Example 1: Getting a named connection setting

```
PS C:\> Get-SdStorageConnectionSetting -StorageSystem 'vmStorageServer'
```

This example syntax gets the storage system connection settings for the specified storage system "vmStorageServer".

Storage System Name/IP : vmStorageServer
User : vsadmin
Port : 80
Protocol : Http

Example 2: Getting all connection settings

```
PS C:\> Get-SdStorageConnectionSetting
```

This example syntax retrieves all the storage connection settings.

```
Storage System Name/IP : vmStorageServer
User      : vsadmin
Port     : 80
Protocol  : Http
Storage System Name/IP : vmStorageServer2
User     : vsadmin2
Port     : 443
Protocol  : Https
```

Example 3: Getting the default connection setting

```
PS C:\> Get-SdStorageConnectionSetting -DefaultSetting
```

This example syntax retrieves the default connection settings.

```
User : vsadmin
Port : 80
Protocol : Http
```

Get-SdVM

Lists Hyper-V VMs and their attributes.

Syntax

```
Get-SdVM [-NoStorage] <> [-GetHyperVSnapshot] <> [-Name] <String[]>
[-ComputerName] <String[]> [-Session] <String> [-Host] <String>
```

Detailed Description

Lists Hyper-V VMs and their attributes. Related cmdlets: Get-SdStorage

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
NoStorage	Specifies that you do not want to get the Data ONTAP storage footprint of a share or mount.	false	false	

Name	Description	Required ?	Pipeline Input	Default Value
GetHyperVSnapshot	Specifies that you want to get the Snapshot VHDs, the GUIDs associated with them, and the parent VHD.	false	false	
Name	Specifies the name or GUID of the VM you want to get.	false	true (ByPropertyName)	
ComputerName	Indicates the name of the Hyper-V server on which you want the VMs to be returned.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Listing all HyperV VMs

```
PS C:\> Get-SdVM
```

This example syntax lists all Hyper-V VMs and their attributes.

```
ComputerName Name Guid State Clustered VirtualDisks
```

```
-----
clab-a8-7 vm1 94734822-f2a2-4ddb-9794-8139bc1efb0b Running false {\vs1\share1\vm1\vm1.vhd}
clab-a8-8 vm2 d68f7d2a-31cd-437d-a435-e8757e730a01 Off true {\vs2\share1\vm2\vm2.vhd}
```

Example 2: Listing all HyperV VMs on a specific HyperV server

```
PS C:\> Get-SdVM -ComputerName "clab-a8-8"
```

This examples syntax lists all Hyper-V virtual machines on Hyper-V server clab-a8-8.

```
ComputerName Name Guid State Clustered VirtualDisks
```

```
-----
clab-a8-8 vm2 d68f7d2a-31cd-437d-a435-e8757e730a01 Off true {\vs2\share1\vm2\vm2.vhd}
clab-a8-8 vm3 d68f7d2a-31cd-437d-a435-e8757e730a02 Off false {\vs2\share2\vm3\vm3.vhd}
```

Example 3: Getting the attributes for a VM

```
PS C:\> Get-SdVM -Name vm1 | fl
```

This example syntax gets the attributes of VM vm1.

```
Owner      : clab-a8-7
Guid: 94734822-f2a2-4ddb-9794-8139bc1efb0b
State      : Running
StorageType : NAS
SnapShotAttributes :
SnapDrive.Nsf.Interfaces.Virtualization.SnapShotAttributes
ConfigurationAttributes :
SnapDrive.Nsf.Interfaces.Virtualization.VMConfigurationAttributes
HighlyAvailable : False
HAAAttributes:
SnapDrive.Nsf.Interfaces.Virtualization.HighAvailabilityAttributes
StorageFootPrints : {HostResource : \\vs1_cifs\vol2_share
StorageSystemResource : vs1:/vol/vol2/}
VirtualDisks: {\\vs1\share1\vm1\vm1.vhd}
Type: SDHyperv
Name: vm1
```

Example 4: Showing the virtual disks on a VM

```
PS C:\> (Get-SdVM sqltest-vm-01).VirtualDisks
```

This example syntax lists the virtual disks associated with VM sqltest-vm-01.

```
Name      : sqltest-vm-01.vhdx
Type       : SDHyperv
VirtualDisk Location      : \\10.53.14.233\r2
VirtualDisk FullPath      : \\10.53.14.233\r2\sqltest-vm-01\Virtual Hard
Disks\sqltest-vm-01.vhdx
StorageSystemResource     : sqltest-vsim1-bsd.sim.Company.com:/vol/vol2/
StorageSystemResource Type : SDStorageDir
HostResource              : \\10.53.14.233\r2
HostResource Type         : SDSMBShare
BootDisk                  : True
```

Example 5: Showing all virtual disks and Snapshot copies on a VM

```
PS C:\> (Get-SdVm -GetHyperVSnapshot vm_clus_smb4).VirtualDisks
```

This example syntax lists all the virtual disks including the Hyper-V Snapshot copies associated with VM vm_clus_smb4.

```

Name      : vm_clus_smb4.vhdx
Type      : SDHyperv
VirtualDisk Location    : \\172.17.175.82\vol3_share
VirtualDisk FullPath    : \\172.17.175.82\vol3_share\vm_clus_smb4\Virtual
Hard Disks\vm_clus_smb4.vhdx
StorageSystemResource   : vs2:/vol/vol3/
StorageSystemResource Type : SDStorageDir
HostResource            : \\172.17.175.82\vol3_share
HostResource Type       : SDSMBShare
BootDisk                : True
Name                    : vm_clus_smb4_0F10EBD9-01F5-4546-9A99-49CF2EEAA755.avhdx
Type                    : SDHyperv
VirtualDisk Location    : \\172.17.175.82\vol3_share
VirtualDisk FullPath    : \\172.17.175.82\vol3_share\vm_clus_smb4\Virtual
Hard Disks\vm_clus_smb4_0F10EBD9-01F5-4546-9A99-49CF2EEAA755.avhdx
StorageSystemResource   : vs2:/vol/vol3/
StorageSystemResource Type : SDStorageDir
HostResource            : \\172.17.175.82\vol3_share
HostResource Type       : SDSMBShare
BootDisk                : True

```

Get-SdVolumeCloneSplit

Gets information about your clone volume splitting operation status.

Syntax

```

Get-SdVolumeCloneSplit [-JobId] <String[]> [-StorageSystem] <String>
[-Session] <String> [-Host] <String> [-Path] <Object[]> [-Session]
<String> [-Host] <String>

```

Detailed Description

Gets information about your clone volume splitting operation status.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
JobId		true	true (ByPropertyName)	
StorageSystem		true	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
Path	Specifies the clone splitting operation about which you want to retrieve status information.	true	true (ByPropertyName)	

Examples

Get-SdVolumeCloneSplitEstimate

Estimates the amount of space you available, before you begin a clone splitting operation.

Syntax

```
Get-SdVolumeCloneSplitEstimate [-Path] <Object[]> [-Session] <String>
[-Host] <String>
```

Detailed Description

Estimates the amount of space you available, before you begin a clone splitting operation.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies the path to the volume about which you want to retrieve a space estimate, before you begin a clone splitting operation.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Get-SdVsphereSetting

Syntax

```
Get-SdVsphereSetting [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Invoke-SdEmsAutosupportLog

Facilitates logging Event Management System (EMS) AutoSupport messages.

Syntax

```
Invoke-SdEmsAutosupportLog [-Path] <Object> [-EventId] <Int32> [-EventSource] <String> [-AppVersion] <String> [-Category] <String> [-EventDescription] <String> [-LogLevel] <UInt32> [-GenerateAutosupport] <> [-Session] <String> [-Host] <String> [-StorageSystem] <String> [-EventId] <Int32> [-EventSource] <String> [-AppVersion] <String> [-Category] <String> [-EventDescription] <String> [-LogLevel] <UInt32> [-GenerateAutosupport] <> [-Session] <String> [-Host] <String>
```

Detailed Description

Facilitates logging Event Management System (EMS) AutoSupport messages. You can use this cmdlet to determine the underlying administration server, and to send messages to that server, for your specified SMB share or logical disk. Your application can use this cmdlet to log events with different severity levels in EMS and to send corresponding AutoSupport messages about backup, restore, and similar operations, errors, or failures. Related cmdlets: Get-SdSMBShadowCopyEmsMessage

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies the ID for the SMB share, logical disk to which you send the EMS AutoSupport message. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByValue, ByPropertyName)	
EventId	Provides the event ID. This is a user-defined event ID, with a range from 0 to 2 ³² -2.	true	true (ByPropertyName)	
EventSource	Indicates the application invoking the cmdlet.	true	true (ByPropertyName)	
AppVersion	Provides the version of the application invoking the cmdlet.	true	true (ByPropertyName)	
Category	Specifies an application-defined event category.	true	true (ByPropertyName)	
EventDescription	Describes the event you want to log. The event description is an application-defined message.	true	true (ByPropertyName)	
LogLevel	Indicates the EMS message severity. Accepted values are: 0 for "emergency"; 1 for "alert"; 2 for "critical"; 3 for "error"; 4 for "warning"; 5 for "notice"; 6 for "info"; 7 for "debug"	true	true (ByPropertyName)	
GenerateAutosupport	Specifies that you want to generate an AutoSupport message.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
StorageSystem	Names the storage system for resources to which you send the EMS AutoSupport message.	true	true (ByPropertyName)	

Examples

Example 1: Logging a test EMS AutoSupport message

```
PS C:\> Invoke-SdEmsAutosupportLog -Path \\172.17.165.40\root -EventId 111 -EventSource "SDW" -AppVersion "1.0" -Category "test" -EventDescription "This is testing message from NextGenSDW." -LogLevel 6
```

In this example syntax, you send a test EMS log message to the virtual storage server to which the SMB share belongs. The cluster server display the following message:

```
TimeNode Severity Event
-----
8/14/2012 11:47:54 mvaqa-3270-1-01 INFORMATIONAL app.log.info: SNAPMGR-06: SDW 7.0: (111) test: This is testing message from SnapDrive.
```

Example 2: Logging and generating a test EMS AutoSupport message

```
PS C:\> Invoke-SdEmsAutosupportLog -Path \\172.17.165.40\root -EventId 111 -EventSource "SDW" -AppVersion "1.0" -Category "test" -EventDescription "This is testing message from SnapDrive." -LogLevel 6 -GenerateAutosupport
```

In this example syntax, you log a test message in EMS and send an AutoSupport message to the virtual storage server to which the SMB share belongs.

Example 3: Logging a test EMS AutoSupport message in a clustered environment

```
PS C:\> Invoke-SdEmsAutosupportLog -Path E: -EventId 111 -EventSource "SDW" -AppVersion "1.0" -Category "test" -EventDescription "This is testing message from SnapDrive." -LogLevel 6
```

In this example syntax, you send a test EMS log message to the virtual storage server to which the SMB share belongs.

```
The cluster server displays the following message:
TimeNode Severity Event
-----
8/14/2012 11:47:54 mvaqa-3270-1-01 INFORMATIONAL app.log.info: SNAPMGR-06: SDW 7.0: (111) test: This is testing message from SnapDrive.
```

Example 4: Logging a test EMS AutoSupport message using a storage system

```
PS C:\> Invoke-SdEmsAutosupportLog -StorageSystem 172.17.165.39 -EventId 111 -EventSource "SDW" -AppVersion "1.0" -Category "test" -EventDescription "This is testing message from SnapDrive." -LogLevel 6
```

In this example syntax, you send a test EMS log message to the virtual storage server used as the storage system.

The cluster server displays the following message:

```
TimeNode Severity Event
```

```
-----
```

```
----- 11/15/2012 16:13:43 mvaqa-3270-1-02
```

```
INFORMATIONAL app.log.info: CLAB-A13-10: SDW 7.0: (111) test: This is testing message from SnapDrive.
```

Invoke-SdHostVolumeSpaceReclaim

Initiates space reclamation on your host volume.

Syntax

```
Invoke-SdHostVolumeSpaceReclaim [-Path] <String> [-Session] <String> [-Host] <String> [-UnmapSize] <String> [-VdsId] <Guid> [-Session] <String> [-Host] <String> [-UnmapSize] <String>
```

Detailed Description

Initiates space reclamation on your host volume.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	The mount point (i.e. G:\) or path to any file on the volume to process.	true	true (ByValue, ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
UnmapSize	Specifies the size of the blocks you want to reclaim. The size should be greater than 0 and less than 2147483648 bytes.	false	false	
VdsId	Specifies your virtual disk service ID.	true	true (ByValue, ByPropertyName)	

Examples

Example 1: Reclaiming space

```
PS C:\> Invoke-SdHostVolumeSpaceReclaim -Path E:
```

This example syntax reclaims space no longer being used by the host operating system.

Invoke-SdSnapMirrorUpdate

Facilitates updates to mirror and vault relationships, in the context of Windows disks, SMB shares, or clustered Data ONTAP storage system volumes.

Syntax

```
Invoke-SdSnapMirrorUpdate [-Path] <Object> [-MaxTransferRate] <Int64>
[-Snapshot] <String> [-Session] <String> [-Host] <String> [-
SourceStorageSystem] <String> [-SourceVolumeName] <String> [-
DestinationStorageSystemName] <String> [-DestinationStorageVolumeName]
<String> [-MaxTransferRate] <Int64> [-Snapshot] <String> [-Session]
<String> [-Host] <String>
```

Detailed Description

Facilitates updates to mirror and vault relationships, in the context of Windows disks, SMB shares, or clustered Data ONTAP storage system volumes. For the specified resources, you can determine the underlying storage layout and issue SnapMirror updates on the corresponding storage volumes, provided that the SnapMirror relationship is already created and initialized. SnapMirror updates and returns are executed immediately. When you are updating a SnapMirror relationship, you can specify a share, storage system volume, or Windows disk. When you are updating a SnapVault relationship, you can specify a share or storage system volume. Related cmdlets: Restore-SdSnapshot and New-SdSnapshot

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Provides a volume, logical disk, SMB share for which you want SnapMirror updates. You cannot mix a logical disk or mount point with SMB shares in the same input path. When you are updating a SnapMirror relationship, you can specify a share, storage system volume, or Windows disk. When you are updating a SnapVault relationship, you can specify a share or storage system volume.	true	true (ByValue, ByPropertyName)	
MaxTransferRate	Specifies the maximum transfer rate, in bytes per second.	false	true (ByPropertyName)	
Snapshot	Specifies the Snapshot copy you want to transfer. This cmdlet is processed only for vault relationships; in the case of SnapMirror relationships, this parameter is ignored if specified.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	localmachine
SourceStorageSystem	Specifies the storage system from which you want to update your SnapMirror relationships.	true	true (ByPropertyName)	
SourceVolumeName	Specifies the volume from which you want to update your SnapMirror relationships.	true	true (ByPropertyName)	
DestinationStorageSystemName	Specifies the storage system on which you want to update your SnapMirror relationships. Must be used in conjunction with DestinationStorageVolumeName. If you do not specify this parameter, all storage system volumes associated with your source storage system and volume are updated.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
DestinationStorageVolumeName	Specifies the volume on which you want to update your SnapMirror relationships. Must be used in conjunction with DestinationStorageSystemName. If you do not specify this parameter, all storage system volumes associated with your source storage system and volume are updated.	false	true (ByPropertyName)	

Examples

Example 1: Updating SnapMirror for a single share

```
PS C:\> Invoke-SdSnapMirrorUpdate -path "\\fileserver\sqlshare"
```

In this example syntax, you determine the underlying storage footprint for \\fileserver\sqlshare, and initiate a SnapMirror update on the underlying volume, provided that the SnapMirror relationship is created and initialized.

```
PS C:\Users\administrator.NEXTGEN> Invoke-SdSnapMirrorUpdate -Path
\\CIFS_SERV\snapvault_source -Verbose
VERBOSE: Validating input paths.
VERBOSE: SMB Share : \\CIFS_SERV\snapvault_source
VERBOSE: Updating SnapMirror.
SnapMirrorRelationshipType :
SnapMirrorPolicyName      :
SnapMirrorRelationship : vserver : snapvault_source ==> vserver :
snapvault_dest
SnapMirrorState: snapmirrored
SnapMirrorStatus      : Transferring
Lag: 0
LagSpecified      : False
BaseSnapshotName    : local
Message:
VERBOSE: Operation successful.
```

Example 2: Updating your vault for a single share

```
PS C:\> Invoke-SdSnapMirrorUpdate -path "\\fileserver\sqlshare" -snapshot
"weeklybackup"
```

In this example syntax, you determine the underlying storage footprint for \\fileserver\sqlshare, and initiate a

SnapVault update on the underlying volume.

```
PS C:\Users\administrator.NEXTGEN> Invoke-SdSnapMirrorUpdate -Path
\\CIFS_SERV\snapvault_source -Snapshot local -Verbose
VERBOSE: Validating input paths.
VERBOSE: SMB Share : \\CIFS_SERV\snapvault_source
VERBOSE: Updating SnapMirror.
SnapMirrorRelationshipType :
SnapMirrorPolicyName      :
SnapMirrorRelationship    : vserver1 : snapvault_source ==> vserver1 :
snapvault_dest
SnapMirrorState: snapmirrored
SnapMirrorStatus        : Transferring
Lag: 0
LagSpecified           : False
BaseSnapshotName        : DATA
Message:
VERBOSE: Operation successful.
```

Example 3: Updating SnapMirror for a disk

```
PS C:\> Invoke-SdSnapMirrorUpdate -Path E:
```

In this example syntax, you determine the underlying storage footprint for disk drive E:, and initiate a SnapMirror update on the underlying volume, provided that the SnapMirror relationship is created and initialized.

Example 4: Updating all SnapMirror destination storage system volumes

```
PS C:\> Invoke-SdSnapMirrorUpdate -SourceStorageSystem
sdw_jenkins_vserver -SourceVolumeName VOLUME01 -Verbose
```

In this example syntax, you update all destination storage system volumes associated with the source storage system and volume.

```

VERBOSE: Updating Snapmirror..
SnapMirrorRelationshipType :
SnapMirrorPolicyName      :
SnapMirrorRelationship    : sdw_jenkins_vserver : VOLUME01 ==>
sdw_jenkins_vserver      : vserver01
SnapMirrorState: snapmirrored
SnapMirrorStatus        : Transferring
Lag: 0
LagSpecified           : False
BaseSnapshotName       : snapmirror.e0f01251-4d32-11dc-a3b0-
123478563412_2147485514.2013-07-17_143103
Message:
SnapMirrorRelationshipType :
SnapMirrorPolicyName      :
SnapMirrorRelationship    : sdw_jenkins_vserver : VOLUME01 ==>
sdw_jenkins_vserver      : VOLUME01_Sec
SnapMirrorState: snapmirrored
SnapMirrorStatus        : Transferring
Lag: 0
LagSpecified           : False
BaseSnapshotName       : TEST_TEST
Message:
VERBOSE: Operation Successful.

```

Example 5: Updating specified SnapMirror destination storage system volumes

```

PS C:\> Invoke-SdSnapMirrorUpdate -SourceStorageSystem
sdw_jenkins_vserver -SourceVolumeName VOLUME01
-DestinationStorageSystemName sdw_jenkins_vserver
-DestinationStorageVolumeName VOLUME01_Sec -Verbose

```

In this example syntax, you update specific destination storage system volumes associated with the source storage system and volume.

```

VERBOSE: Updating Snapmirror..
SnapMirrorRelationshipType :
SnapMirrorPolicyName      :
SnapMirrorRelationship    : sdw_jenkins_vserver : VOLUME01 ==>
sdw_jenkins_vserver      : VOLUME01_Sec
SnapMirrorState: snapmirrored
SnapMirrorStatus        : Transferring
Lag: 0
LagSpecified           : False
BaseSnapshotName       : TEST_TEST
Message:
VERBOSE: Operation Successful.

```

Map-SdLUNS

Syntax

```

Map-SdLUNS [-LunPath] <String[]> [-Initiators] <String> [-
IgroupProtocol] <IgroupProtocolEnum> [-IgroupOsType] <IgroupOSTypeEnum>
[-RestApiURL] <String> [-Session] <String> [-Host] <String>

```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
LunPath		true	true (ByValue, ByPropertyName)	
Initiators		true	true (ByPropertyName)	
IgroupProtocol		false	true (ByPropertyName)	
IgroupOsType		false	true (ByPropertyName)	
RestApiURL		true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Mount-SdClone

Enables cloning and mounting a source storage from the specified Snapshot copy.

Syntax

```
Mount-SdClone [-SourcePath] <String[]> [-Snapshot] <String> [-ResourceType] <ResourceType> [-Host] <String> [-Igroup] <String> [-Initiators] <String> [-IgroupProtocol] <IgroupProtocolEnum> [-IgroupOsType] <IgroupOsTypeEnum> [-CheckInitiatorSession] <> [-Session] <String>
```

Detailed Description

Enables cloning and mounting a source storage from the specified Snapshot copy. For a LUN, the cloned volume name is automatically appended with a unique identifier, while the LUN name remains the same. For example: If the original volume is PrimarySVM:/vol/SCE_VOL, the cloned volume name is PrimarySVM:/vol/SCE_VOL1201210041488133. Related cmdlets: Dismount-SdClone, Get-SmClone, Remove-SmClone, New-SmClone

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
SourcePath	Specifies a path that you want to clone and mount from the Snapshot copy. For example, the path of a volume.	true	true (ByValue, ByPropertyName)	
Snapshot	Specifies the Snapshot copy that you want to use for cloning and mounting.	true	true (ByPropertyName)	
ResourceType	Specifies the type of the resource in the SourcePath parameter. The possible options are: "SDStorageVolume", "SDStorageLunPath", "SDStorageDir".	false	true (ByPropertyName)	
Host	Specifies the FQDN or IP address of the host on which you want to execute the operation.	false	true (ByPropertyName)	
Igroup		false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Initiators		false	true (ByPropertyName)	
IgroupProtocol		false	true (ByPropertyName)	
IgroupOsType		false	true (ByPropertyName)	
CheckInitiatorSession		false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	

Examples

Example 1: Clone a Volume from a given snapshot

```
PS C:\> Mount-SdClone -SourcePath
Primary_SVM:/vol/Vol1_LM_Port_Issue_Test -Snapshot
r70105ec0a5v1_hnk2_com_L__ValidPath_Data_R70105EC0A5V1_05-24-
2021_12.46.42.3914
```

This example syntax specifies the storage volume path and clones the Snapshot copy onto newly cloned volume.

Source Clone

```
Primary_SVM:/vol/Vol1_LM_Port_Issue_Test
Primary_SVM:/vol/Vol1_LM_Port_Issue_Test0525210820263222
```

Example 2: Clone a volume from a given Snapshot copy with the ResourceType and host name specified

```
PS C:\> Mount-SdClone -SourcePath Primary_SVM:/vol/Vol1 -Snapshot
Host1_Policy1_12-01-2021_02.31.22.3854 -ResourceType SDStorageVolume
-Host Host1.DMN.COM -Verbose
```

This example syntax specifies the storage volume path and clones the Snapshot copy to a newly cloned volume with the ResourceType and host name.

VERBOSE: Operation successful.

Source Clone

```
Primary_SVM:/vol/Vol1 Primary_SVM:/vol/Vol11201210243583210
```

Mount-SdSnapshot

Facilitates mounting the list of SMB shares from the specified Snapshot copy as a different set of shares. Facilitates mounting one LUN at a time from the specified Snapshot copy as a different LUN.

Mounting secondary LUN is not supported, Check Example 9

Syntax

```
Mount-SdSnapshot [-Path] <Object[]> [-Snapshot] <String> [-  
StorageSystem] <String> [-VolumeName] <String> [-PrefixForVolumeClone]  
<String> [-MountPath] <Object[]> [-SharedDisk] <> [-  
ClusteredSharedVolume] <> [-AutopickMountPoint] <> [-  
ValidateCloneDepth] <> [-Session] <String> [-Host] <String>
```

Detailed Description

Facilitates mounting the list of SMB shares from the specified Snapshot copy as a different set of shares. Facilitates mounting one LUN at a time from the specified Snapshot copy as a different LUN. You can use this cmdlet to perform backup verification. Mount the database and log shares/LUN from the Snapshot copy and perform the verification operations. For SMB shares, the mounted share names are automatically appended with a unique identifier. For a LUN, the cloned volume name is automatically appended with a unique identifier, while the LUN name remains the same. For example: If the original share is \\SQLFileServer\DBShare, the mounted share name is \\SQLFileServer\DBShare-GUID. (\\SQLFileServer\DBShare-73111E50-E7C2-49B7-8A63-7279512CB09B) If the original LUN is PrimarySVM:/vol/SCE_VOL/lun1, the mounted LUN name is PrimarySVM:/vol/SCE_VOLGUID/lun1. (PrimarySVM:/vol/SCE_VOLSiClone2b77c074_1d9b_4929_9fac_d361bf342794/lun1) The ACLs on the mounted share are the same as the original share. To mount the shares or a LUN from a secondary Snapshot copy, you must specify the storage system and volume. Ensure that the aggregate of the volume that is the source of the FlexClone operation is assigned to the virtual storage server aggregates list. For the 'Path' parameter below, if file system path of the LUN is specified, it can be mounted on the same host as the source LUN. If the complete storage path of the LUN is specified, it can be mounted on the same host or on a different host. To mount the LUN on a different host, an igroup and an iSCSI session should be present for the host that is accessing the SVM, where the source LUN is present. Related cmdlets: Get-SdSnapshot, Remove-SdSnapshot, Rename-SdSnapshot, New-SdSnapshot, Dismount-SdSnapshot

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies a comma-separated list of shares you want to mount from the Snapshot copy. Only one LUN can be mounted at a time. For a LUN, this parameter specifies one value which is the file system path of the LUN in the host machine or the complete storage path of the LUN in the SVM. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByPropertyName)	
Snapshot	Indicates the Snapshot copy that you want to use for mounting the SMB shares/LUN. For SMB shares, you must use a Snapshot copy that is valid for all the shares in your list.	true	true (ByPropertyName)	
StorageSystem	Indicates the name of the storage system in which the Snapshot copy you want to mount is located.	false	true (ByPropertyName)	
VolumeName	Indicates the name of the storage system volume in which the Snapshot copy you want to mount is located.	false	true (ByPropertyName)	
PrefixForVolumeClone	You can use this optional parameter to set a short name for the share on which the Snapshot copy is mounted. For LUNs, use this parameter to prefix the cloned volume name. Use this parameter when you are working on a system with name length restrictions.	false	true (ByPropertyName)	
MountPath	Indicates the drive letter or mountpoint that you want to assign to the disk mounted from the Snapshot copy. For a LUN mount operation, this parameter takes only one destination value.	false	true (ByPropertyName)	
SharedDisk		false	true (ByPropertyName)	
ClusteredSharedVolume		false	true (ByPropertyName)	
AutopickMountPoint	Specifies that the mountpoint is assigned automatically.	false	true (ByPropertyName)	
ValidateCloneDepth		false	false	

Name	Description	Required ?	Pipeline Input	Default Value
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. For SMB shares, the default is your local machine. For a LUN, this parameter must be provided with the hostname.	false	true (ByPropertyName)	

Examples

Example 1: Mounting shares from a specified backup

```
PS C:\> Mount-SdSnapshot -Path
"\\SQLFileserver\DBShare", "\\SQLFileserver\LogShare" -snapshot
"weekly_backup"
```

This example syntax mounts your shares from "weekly_backup".

OriginalResource MountedResource

=====

```
\\SQLFileserver\DBShare \\SQLFileserver\DBShare-A470FF3A-5107-4B6A-B0C1-FB3D8744F14C
\\SQLFileserver\LogShare \\SQLFileserver\DBShare-E6980DF6-3E64-45BD-965A-7F7A9B02156A
```

Example 2: Mounting shares from piped Snapshot copies that start with "weekly" in the name.

```
PS C:\> Get-SdSnapshot \\SQLFileserver\DBShare -Snapshot weekly* | Mount-
SdSnapshot "\\SQLFileserver\dbshare", "\\SQLFileserver\logshare"
```

This example syntax mounts specified shares from Snapshot copies that start with "weekly." The shares you want to mount must be on the same volume.

OriginalResource MountedResource

=====

```
\\SQLFileserver\DBShare \\SQLFileserver\DBShare-A470FF3A-5107-4B6A-B0C1-FB3D8744F14C
\\SQLFileserver\LogShare \\SQLFileserver \DBShareE6980DF6-3E64-45BD-965A-7F7A9B02156A
```

Example 3: Mounting shares from the specified secondary Snapshot copy

```
PS C:\> Mount-SdSnapshot -Path
"\\SQLFileserver\DBShare", "\\SQLFileserver\LogShare" -snapshot
"weekly_snap" -storagesystem mirror_vserver -volume dbmirrorvolume
```

This example mounts the specified shares from the specified secondary Snapshot copy.

OriginalResource MountedResource

=====

\\SQLFileserver\DBShare \\DRSQLFileServer\DBShare-A470FF3A-5107-4B6A-B0C1-FB3D8744F14C
\\SQLFileserver\LogShare \\DRSQLFileServer\DBShare-E6980DF6-3E64-45BD-965A-7F7A9B02156A

Example 4: Mounting shares using a prefix

```
PS C:\> Mount-SdSnapshot -Path \\172.17.165.40\capital_vol_share  
-Snapshot Newtest -PrefixForVolumeClone capitalShare
```

This example syntax creates a short name for the share on which you mount the Snapshot copy.

Resource ConnectedResource

\\172.17.165.40\capital_vol_share \\JENKINS-CIFS\capitalShare030713155542929

Example 5: Mounting a LUN from a specified Snapshot with file system path.

```
PS C:\> Mount-SdSnapshot -Path L: -Snapshot  
Host1_DMN_COM_SLDB3_Host1_06-10-2020_02.51.43.9645 -MountPath I: -Host  
Host1.DMN.COM
```

This example syntax mounts the Snapshot copy specified for the LUN in L: onto I: on the host Host1.DMN.COM.

Resource ConnectedResource

L:\ I:\

Example 6: Mounting a LUN from a specified Snapshot with AutoMount option

```
PS C:\> Mount-SdSnapshot -Path L: -Snapshot  
Host1_DMN_COM_SLDB3_Host1_06-10-2020_02.51.43.9645 -AutopickMountPoint  
-Host Host1.DMN.COM
```

This example syntax mounts the Snapshot copy specified for the LUN in L: onto the automount location "C:\scmnpt\mpdisk0002\" on the host Host1.DMN.COM.

Resource ConnectedResource

L:\ C:\scmnpt\mpdisk0002\

Example 7: Mounting a LUN to a different host with LUN storage path

```
PS C:\> Mount-SdSnapshot -Path PrimarySVM:/vol/SCE_VOL/lun1 -Snapshot
Host1_DMN_COM_SLDB3_Host1_06-10-2020_02.51.43.9645 -MountPath I: -Host
Host2.DMN.COM
```

This example syntax specifies the storage path of the LUN mounted on Host1 and mounts the Snapshot copy onto I: on the host Host2.DMN.COM. The cmdlet is executed on Host2.DMN.COM.

Resource ConnectedResource

L:\I\

Example 8: Mounting a LUN with LUN storage path using Primary SVM

```
PS C:\> Mount-SdSnapshot -Path
Primary_SVM:/vol/Volume_Vault/Volume_Vault_Lun1 -Snapshot
R70105EC0A5V1_SQL2019_SQL_DB1_R70105EC0A5V1_03-15-2021_22.37.23.2993_1
-PrefixForVolumeClone Clone_01292021_2330 -AutopickMountPoint -Verbose
```

This example syntax specifies the storage path of the Primary LUN mounted and mounts the Snapshot copy onto random drive letter on the same host using Primary Storage . The cmdlet is executed on Host1.

```
VERBOSE: Validating input paths.
VERBOSE: LUN: Primary_SVM:/vol/Volume_Vault/Volume_Vault_Lun1
VERBOSE: The Snapshot 'R70105EC0A5V1_SQL2019_SQL_DB1_R70105EC0A5V1_03-15-
2021_22.37.23.2993_1' of Primary_SVM:/vol/Volume_Vault/Volume_Vault_Lun1
will be mounted.
VERBOSE: Drive letter if available or a mount point will be auto-picked
VERBOSE: Mounting the specified resources from the Snapshot copy.
VERBOSE: Operation successful.
Resource    ConnectedResource
-----
Primary_SVM:/vol/Volume_Vault/Volume_Vault_Lun1    C:\scmnpt\mpdisk0006\
```

Example 9: Mounting a LUN with LUN storage path using Secondary Storage fails

```
PS C:\> Mount-SdSnapshot -Path
Secondary_SVM:/vol/Volume_Secondary_Vault/Volume_Secondary_Vault_Lun1
-Snapshot BCHEXchDAG2016_Backup_kdcbchexch1_01-29-2021_23.30.20.2845
-PrefixForVolumeClone Clone_01292021_2330 -AutopickMountPoint
```

This example syntax specifies the storage path of the LUN mounted and trying to mount the Snapshot copy with random drive letter on the any host using Secondary Storage . The cmdlet is executed on Host1.

```

Mount-SdSnapshot : Failed to mount the Snapshot copy.Failed to mount the
resource:
Secondary_SVM:/vol/Volume_Secondary_Vault/Volume_Secondary_Vault_Lun1 from
snapshot: BCHExchDAG2016_Backup_kdcbchexch1_01-29-2021_23.30.20.2845.
The source LUN's iGroup does not exist.
Possible Resolution: Make sure that Host to storage connectivity is
available.
At line:1 char:1
+ Mount-SdSnapshot -Path
Secondary_SVM:/vol/Volume_Secondary_Vault/Volume_Secondary_Vault_Lun1 ...
+ ~~~~~
+ CategoryInfo      : InvalidResult:
(SnapDrive.Clien...MountSdSnapshot:MountSdSnapshot) [Mount-SdSnapshot],
Exception
+ FullyQualifiedErrorId : 102,SnapDrive.Client.PSModule.MountSdSnapshot

```

New-SdBackup

Syntax

```

New-SdBackup [-Snapshot] <String> [-ConsistencyGroups]
<NewSdBackup+ConsistencyGroupInfo> [-LUNs] <String> [-NasDirs]
<String> [-DisableFallbackToVolumeSnapshot] <> [-RestApiURL] <String>
[-Session] <String> [-Host] <String>

```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Snapshot		true	true (ByValue, ByPropertyName)	
ConsistencyGroups		false	true (ByPropertyName)	
LUNs		false	true (ByPropertyName)	
NasDirs		false	true (ByPropertyName)	
DisableFallbackToVolumeSnapshot		false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
RestApiURL		false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

New-SdIgroup

Creates a new igroup.

Syntax

```
New-SdIgroup [-Name] <String> [-Protocol] <String> [-Type] <String>
[-PortSet] <String> [-Initiators] <String[]> [-StorageSystem]
<String> [-Session] <String> [-Host] <String>
```

Detailed Description

Creates a new igroup.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Name	Specifies the name for your new igroup.	true	true (ByPropertyName)	
Protocol	Specifies the protocol you want to use with your new igroup.	true	true (ByPropertyName)	
Type	Specifies the type of igroup you want to create.	false	true (ByPropertyName)	
PortSet	Specifies the portset to which you want to add your igroup.	false	true (ByPropertyName)	
Initiators	Specifies any initiators you want to add to your igroup.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the storage system on which you want your igroup to reside.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Creating a new igroup

```
PS C:\> New-SdIgroup -Name IG_Demo -StorageSystem 172.17.168.13
-Initiators ign.1991-05.com.microsoft:mva-s24-rx200.sddev.mycompany.com
-Protocol mixed
```

This example syntax creates a new mixed protocol igroup on the specified storage system.

New-SdLun

Creates a LUN on your storage system.

Syntax

```
New-SdLun [-StorageSystem] <String> [-LunPath] <String> [-Size]
<String> [-Type] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Creates a LUN on your storage system.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the storage system on which you want to create a new LUN.	true	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
LunPath	Specifies the path of the LUN on your storage system. If you are working in an ONTAP environment, specify the path to your LUN. If you are working in a Flashray, specify the LUN name.	true	true (ByPropertyName)	
Size	Specifies the size of your new LUN. Valid size specifications are MB, GB, or TB.	true	true (ByPropertyName)	
Type		false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

New-SdPortSet

Creates a new portset.

Syntax

```
New-SdPortSet [-PortSetName] <String> [-PortSetType] <String> [-StorageSystem] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Creates a new portset.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
PortSetName	Specifies the name of the portset you want to create.	true	true (ByPropertyName)	
PortSetType	Specifies the protocol you want to use for your new portset. Valid options are iSCSI, Fibre Channel (FCP), or mixed.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the storage system on which you want your new portset to reside.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

New-SdSMBShare

Provisions SMB shares using templates that encapsulate best practices for provisioning shares for different types of applications.

Syntax

```
New-SdSMBShare [-Name] <String> [-Path] <String> [-CIFSServer]
<String> [-TemplateName] <String> [-ShareProperties] <String[]> [-
SymLinkProperties] <String[]> [-FileUmask] <Int32> [-DirUmask]
<Int32> [-Comment] <String> [-AttributeCacheTtl] <Int32> [-
UserOrGroup] <String> [-Permission] <String> [-Session] <String> [-
Host] <String> [-Name] <String> [-Path] <String> [-StorageSystem]
<String> [-TemplateName] <String> [-ShareProperties] <String[]> [-
SymLinkProperties] <String[]> [-FileUmask] <Int32> [-DirUmask]
<Int32> [-Comment] <String> [-AttributeCacheTtl] <Int32> [-
UserOrGroup] <String> [-Permission] <String> [-Session] <String> [-
Host] <String>
```

Detailed Description

Provisions SMB shares using templates that encapsulate best practices for provisioning shares for different types of applications. Get the provisioning templates from the "templates" folder in your install directory. This cmdlet is supported in clustered Data ONTAP 8.2 and later. Related cmdlets: New-SdVolume

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Name	Specifies the name of the SMB share you want to provision. The SMB share name must be a UTF-8 string. You cannot use following characters: control characters from 0x00 to 0x1F, both inclusive, 0x22 (double quotes) and the special characters <code>\\ <>+=,;?</code>	false	true (ByPropertyName)	
Path	Designates the file system path that is shared through your SMB share.	false	true (ByPropertyName)	
CIFSServer	Specifies the SMB server you want to use for provisioning the share.	false	true (ByPropertyName)	
TemplateName	Specifies the provisioning template name. You should also include the path to the template, if the template resides in a folder other than the Templates folder.	false	true (ByPropertyName)	
ShareProperties	Provides a list of properties for your SMB share. Possible values: "oplocks", "browsable", "showsnapshot", "changenotify", "homedirectory", "attributecache", "continuously-available"	false	true (ByPropertyName)	
SymlinkProperties	Indicates whether you want the symlinks under this shared directory to be hidden, accessible, or read-only (option "read-only" along with option "enable".) Possible values are: "enable", "hide", "read_only"	false	true (ByPropertyName)	
FileUmask	You can use the value of this field to control the file mode creation mask for the SMB share in qtrees with UNIX or mixed security styles. The file mode create mask restricts the initial permissions setting of a newly created file. The input value is a numeric mode comprised of one to three octal digits (0-7), derived by adding up the bits with values 4, 2, and 1. The first digit selects permissions for the user who owns the file: read (4), write (2), and execute (1). The second selects permissions for other users in the file's group, with the same values. The third is for other users not in the file's group, with the same values.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
DirUmask	You can use the value of this field to control the file mode creation mask for the SMB share in qtrees with UNIX or mixed security styles. The mask restricts the initial permissions setting of a newly created directory. The input value is a numeric mode comprising of one to three octal digits (0-7), derived by adding up the bits with values 4, 2, and 1. The first digit selects permissions for the user who owns the file: read (4), write (2), and execute (1); the second selects permissions for other users in the file's group, with the same values; and the third for other users not in the file's group, with the same values.	false	true (ByPropertyName)	
Comment	This optional parameter describes a new SMB share. Your description is visible to SMB clients when they are browsing the virtual storage server's SMB shares.	false	true (ByPropertyName)	
AttributeCacheTtl	Specifies the lifetime of an entry in the file attribute cache, in seconds. You can use this value if you have set the "attributecache" property set for the share. Setting the "attributecache" property improves the performance of certain metadata operations in common workloads. The default is 10 seconds. The value of this field must be in the range of 1 to 86400. Raising this value may improve performance, but it increases the likelihood that you serve stale metadata.	false	true (ByPropertyName)	
UserOrGroup	Specifies the user or group name for which you list the permissions.	false	true (ByPropertyName)	
Permission	Indicates access rights that a user or group has on the defined SMB share. Possible values: "no_access", "read", "change", "full_control".	false	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Indicates the virtual storage server you want to use for provisioning the SMB share. The virtual storage server should already have a SMB server configured. You do not need to use this parameter if the SMB server is qualified.	false	true (ByPropertyName)	

Examples

Example 1: Provisioning SMB shares

```
PS C:\> New-SdSMBShare -Path /Sharename -Name HyperVShare -CIFSServer
HyperVFileServer -TemplateName "C:\Program
Files\NetApp\SnapCenter\SnapCenter Plug-in for Microsoft Windows"
```

This example syntax provisions a SMB share using the specified template.

New-SdSnapshot

Creates Snapshot copies of specified Windows disks or SMB shares.

Syntax

```
New-SdSnapshot [-Path] <Object[]> [-Snapshot] <String> [-
NoCleanUpOnError] <> [-UpdateMirror] <> [-CrashConsistent] <> [-
Session] <String> [-Host] <String>
```

Detailed Description

Creates Snapshot copies of specified Windows disks or SMB shares. Related cmdlets: Get-SdSnapshot, Remove-SdSnapshot and Rename-SdSnapshot

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Provides the volume, logical disk, or a comma-separated list of SMB shares of which you want to make Snapshot copies. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByValue, ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Snapshot	Designates the name of the new Snapshot copy. You cannot use special characters in a Snapshot copy name. If you do not specify a Snapshot copy name, a GUID appended with timestamp is generated and used as the Snapshot copy name.	false	true (ByPropertyName)	A GUID appended with timestamp will be generated and used for the Snapshot copy name
NoCleanUpOnError	Indicates whether you want to delete Snapshot copies if there is an error in backing up one of the specified resources, that results in an incomplete Snapshot backup.	false	true (ByPropertyName)	
UpdateMirror	Initiates a mirror or vault update after your Snapshot operation completes.	false	false	
CrashConsistent		false	false	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Backing up the specified SMB shares

```
PS C:\> New-SdSnapshot -Path
"\\fileserver\sqlshare", "\\fileserver\sqlshare2" -Snapshot "sql_snap"
```

This example syntax backs up the SMB shares by creating Snapshot copies of the corresponding volumes using Snapshot name sql_snap.

Example 2: Backing up the specified disk

```
PS C:\> New-SdSnapshot -Path E: -Snapshot "sql_snap"
```

This example syntax backs up the disk drive by creating Snapshot copies of the corresponding volumes using Snapshot name sql_snap.

New-SdStorage

Provisions a Windows volume or disk on a LUN.

Syntax

```
New-SdStorage [-Path] <String> [-Size] <String> [-LunPath] <String>
[-StorageSystem] <String> [-FileSystemLabel] <String> [-SharedDisk]
<> [-ClusteredSharedVolume] <> [-Igroup] <String> [-InitiatorInfo]
<HostInitiatorInfo> [-PortSet] <String> [-AutopickMountPoint] <> [-
PartitionStyle] <PartitionStyle> [-ResourceGroup] <String> [-Thin] <>
[-AllocationUnitSize] <String> [-RawDeviceMapping] <> [-Datastore]
<String> [-Session] <String> [-Host] <String>
```

Detailed Description

Provisions dedicated disks, shared disks and clustered shared volumes on a LUN.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies the drive letter or mount point: D:, D:\Mount	false	true (ByPropertyName)	
Size	Specifies size of the new Windows disk you are provisioning. Supported units: G, T, K, M	true	true (ByPropertyName)	
LunPath	Specifies your LUN path in the following format: /vol/volx/lunx	true	true (ByPropertyName)	
StorageSystem	Specifies the target virtual storage machine you want to use for provisioning.	true	true (ByPropertyName)	
FileSystemLabel	Specifies the label you want to attach to your new Windows volume.	false	true (ByPropertyName)	
SharedDisk	Indicates whether you need to provision your Windows disk as a shared disk.	false	true (ByPropertyName)	
ClusteredSharedVolume	Indicates whether you will provision your Windows disk as a Clustered Shared Volume.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Igroup	Specifies the igroup you want to use for mapping the LUN. If not specified, SnapCenter Plug-in for Microsoft Windows automatically manages the igroup for mapping the LUN.	false	true (ByPropertyName)	
InitiatorInfo	Specifies the initiators you want to add to your Igroup.	false	true (ByPropertyName)	
PortSet	Specifies the portset you want to use for binding your Igroup. If your Igroup is already bound to a different portset, specifying this parameter unbinds your Igroup and then binds it to the portset specified here.	false	true (ByPropertyName)	
AutopickMountPoint	Specifies that the mount point for the new LUN is assigned automatically.	false	true (ByPropertyName)	
PartitionStyle	Indicates whether you want to use GPT or MBR partition style.	false	true (ByPropertyName)	
ResourceGroup	Specifies a Cluster Resource Group for your shared Windows disk.	false	true (ByPropertyName)	
Thin	Indicates whether you want the LUN to be thin provisioned.	false	false	
AllocationUnitSize	Specifies the custom NTFS allocation unit size. Possible values are: 4 KB, 8 KB, 16 KB, 24 KB, 32 KB, and 64 KB. The minimum allocation size is 4 KB, and the maximum is 64 KB. The default value is 4 KB.	false	true (ByPropertyName)	
RawDeviceMapping	Indicates whether the LUN is raw device mapping for VMWare.	false	true (ByPropertyName)	
Datastore	Specifies the Name of the datastore.	false	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies your target host.	false	true (ByPropertyName)	

Examples

Example 1: Provisioning a dedicated Windows disk

```
PS C:\> new-sdstorage -StorageSystem 172.17.165.31 -path V: -LunPath /vol/santest/b09 -size 1G -InitiatorInfo @{Host="R505143C1AAV1.HNK2.COM"; Initiators="iqn.1991-05.com.microsoft:r505143claav1.hnk2.com"}
```

This example syntax creates a new dedicated Windows disk.

Example 2: Provisioning a shared Windows disk

```
PS C:\> new-sdstorage -StorageSystem 172.17.165.31 -path V: -LunPath /vol/santest/b09 -size 1G -SharedDisk -Igroup Windows2012_igroup
```

In this example syntax, you provision a shared disk in "Available storage" resource group.

Example 3: Provisioning a shared Windows disk in an alternate resource group

```
PS C:\> new-sdstorage -StorageSystem 172.17.165.31 -path V: -LunPath /vol/santest/b09 -size 1G -SharedDisk -ResourceGroup prod -Igroup SqlAG_igroup
```

In this example syntax, you provision a shared disk in prod resource group.

Example 4: Provisioning a new Cluster shared volume

```
PS C:\> new-sdstorage -StorageSystem 172.17.165.31 -LunPath /vol/santest/b09 -size 1G -ClusteredSharedVolume -Igroup Windows2012_igroup
```

In this example syntax, you provision a clustered shared volume.

Example 5: Provisioning a RDM disk with other options:(Datastore, FileSystemLabel, filesystemlablename)

```
PS new-sdstorage -storagesystem autof7f8_vsvr1 -path K:\ -LunPath /vol/C227030162240_1_MDML_Log_Vol/Lun1 -size 3G -igroup C227030162240_1 -Thin -RawDeviceMapping -Datastore C227030162240_1VMFS_DS -FileSystemLabel filesystemlablename -PartitionStyle GPT
```

In this example syntax, you provision a RDM disk.

```

TotalSizeInGB    : 3.00287246704102 GB
UsedSpaceInGB    : 3.00287246704102 GB
Name: K:\
FileSystemIdentifier:
autof7f8_vsvr1:/vol/C227030162240_1_MDML_Log_Vol/Lun1
FileSystemType    : ntfs
MountedFromSnapshot : False
TotalSize        : 3224309760
UsedSpace        : 3224309760
BlockSize        : 4096
Clustered        : False
Expandable       : True
OwnerNode        : False
MountOptions:
MountPaths       : {K:\}
parents :
Message :
ClusterAttributes :
BootFileSystem    : False
BootFileSystemSpecified : False
bIsPathOnCSV: False
bIsPathOnCSVSpecified : True
CSVReparsePointPath :
```

Example 6: Provisioning a RDM disk

```
New-SdStorage -LunPath /vol/Vol_VM180_FC/L2 -Size 1GB -StorageSystem
10.225.21.111 -Igroup Sab_FC_ESX -Path M: -RawDeviceMapping
```

In this example syntax, you provision a RDM disk.

```

                TotalSizeInGB      : 1.00351095199585 GB
UsedSpaceInGB    : 1.00351095199585 GB
Name: M:\
FileSystemIdentifier: sce_svm_1:/vol/Vol_VM180_FC/L2
FileSystemType    : ntfs
MountedFromSnapshot : False
TotalSize        : 1077511680
UsedSpace        : 1077511680
BlockSize        : 4096
Clustered        : False
Expandable       : True
OwnerNode        : False
MountOptions:
MountPaths       : {M:\}
parents :
Message :
ClusterAttributes :
BootFileSystem    : False
BootFileSystemSpecified : False
bIsPathOnCSV: False
bIsPathOnCSVSpecified : True
CSVReparsePointPath :

```

Example 7: Provisioning a RDM/Windows disk with InitiatorInformation

```

$initiatorlist = New-Object Collections.Generic.List[string]
    $initiatorlist.Add("10:00:00:90:fa:a6:32:63")
    $hostname = "Bay8-21264"
    $initiatorInfo = New-Object SMCoreContracts.HostInitiatorInfo
-ArgumentList $hostname, $initiatorlist
    New-SdStorage -LunPath /vol/Abhi_FCOE_Vol1/L5 -Size 1GB
-StorageSystem vs_21264 -Igroup ig_21264 -Path U:\ -InitiatorInfo
$initiatorInfo

```

In this example syntax, you provision a RDM disk.

```

                TotalSizeInGB    : 1.00351095199585 GB
UsedSpaceInGB   : 1.00351095199585 GB
Name: U:\
FileSystemIdentifier: vs_21264:/vol/Abhi_FCOE_VO11/L5
FileSystemType   : ntfs
MountedFromSnapshot : False
TotalSize       : 1077511680
UsedSpace       : 1077511680
BlockSize      : 4096
Clustered       : False
Expandable      : True
OwnerNode       : False
MountOptions:
MountPaths      : {U:\}
parents :
Message :
ClusterAttributes :
BootFileSystem    : False
BootFileSystemSpecified : False
bIsPathOnCSV: False
bIsPathOnCSVSpecified : True
CSVReparsePointPath :
```

New-SdVolume

Provisions volumes using templates that encapsulate best practices for provisioning volumes for different types of applications.

Syntax

```
New-SdVolume [-Name] <String> [-Aggregate] <String> [-Size] <String>
[-JunctionPath] <String> [-StorageSystem] <String> [-TemplateName]
<String> [-Comment] <String> [-AntivirusOnAccessPolicy] <String> [-
ExportPolicy] <String> [-FlexCacheCachePolicy] <String> [-
FlexCacheFillPolicy] <String> [-FlexCacheOriginVolume] <String> [-
GroupId] <Int32> [-IndexDirectoryFormat] <Boolean> [-JunctionActive]
<Boolean> [-MaxDirectorySize] <Decimal> [-NvFailEnabled] <Boolean> [-
SecurityStyle] <String> [-SnapshotPolicy] <String> [-State] <String>
[-Type] <String> [-UnixPermissions] <String> [-UserId] <Int32> [-
VirtualStorageServerRoot] <Boolean> [-QosPolicyGroup] <String> [-
SnapshotCloneDependency] <Boolean> [-EnableSnapdiff] <Boolean> [-
SchedSnapName] <String> [-SpaceGuarantee] <String> [-SnapReserve]
<Int32> [-FractionalReserve] <Int32> [-SpaceMgmtTryFirst] <String> [-
SpaceNearlyFullThresholdPercent] <Int32> [-SpaceFullThresholdPercent]
<Int32> [-Files] <Int32> [-FilesysSizeFixed] <> [-ExtentEnabled]
<String> [-ReadRealloc] <String> [-ExternalCache] <String> [-
VmAlignSector] <Int32> [-VmAlignSuffix] <String> [-AutoSizeMode]
<String> [-MaxAutosize] <String> [-AutosizeIncrement] <String> [-
AutosizeIncrementPercent] <Int32> [-MinAutosize] <String> [-
AutosizeGrowThresholdPercent] <Int32> [-AutosizeShrinkThresholdPercent]
<Int32> [-AutoDeleteEnabled] <> [-Commitment] <String> [-DeferDelete]
<String> [-Deleteorder] <String> [-DeferDeletePrefix] <String> [-
TargetFreeSpace] <Int32> [-Trigger] <String> [-DestroyList] <String>
[-Session] <String> [-Host] <String>
```

Detailed Description

Provisions volumes using templates that encapsulate best practices for provisioning volumes for different types of applications. Gets the provisioning templates from the "templates" folder in your install directory. This cmdlet is supported in clustered Data ONTAP 8.2 and later. Related cmdlets: Remove-SdVolume

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Name	Indicates the name of the new volume.	false	true (ByPropertyName)	
Aggregate	Specifies the name of the containing aggregate.	false	true (ByPropertyName)	
Size	Designates the size of the new volume.	false	true (ByPropertyName)	
JunctionPath	Specifies the junction path at which this volume is to be mounted.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the storage virtual machine for provisioning the storage volume.	false	true (ByPropertyName)	
TemplateName	Indicates the name of the provisioning template. You should qualify path to the template if the template resides in a folder other than SnapDrive Templates folder.	false	true (ByPropertyName)	
Comment	Provides a description for the volume being created.	false	true (ByPropertyName)	
AntivirusOnAccessPolicy	Specifies the name of the Anti-Virus On-Access policy. The default policy name is 'default'.	false	true (ByPropertyName)	
ExportPolicy	Specifies the name of the export policy to be used by NFS/SMB protocols. The default policy name is 'default'.	false	true (ByPropertyName)	
FlexCacheCachePolicy	Specifies the name of the FlexCache cache policy. The default policy name is 'default'.	false	true (ByPropertyName)	
FlexCacheFillPolicy	Specifies the name of the FlexCache prefill policy. The default policy name is 'default'	false	true (ByPropertyName)	
FlexCacheOriginVolume	Specifies the name of the origin volume that contains the authoritative data.	false	true (ByPropertyName)	
GroupId	Specifies the UNIX group ID for the volume. The default value is 0 ('root').	false	true (ByPropertyName)	
IndexDirectoryFormat	Indicates whether you want to enable the index directory format. If true, index directory format is enabled. The default is false.	false	true (ByPropertyName)	
JunctionActive	Indicates whether the mounted volume is accessible. The default is true.	false	true (ByPropertyName)	
MaxDirectorySize	Specifies the maximum size in bytes, to which any directory in this volume can grow.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
NvFailEnabled	Indicates whether you want the controller to identify and attempt to correct NVRAM failure errors. If true, the controller performs additional work at startup and takeover times, if it finds that there has been any potential data loss in this volume due to an NVRAM failure.	false	true (ByPropertyName)	
SecurityStyle	Designates a volume security style. Possible values are: mixed, ntfs, unix.	false	true (ByPropertyName)	
SnapshotPolicy	Specifies the Snapshot copy policy. Default policy is 'default'.	false	true (ByPropertyName)	
State	Indicates the desired state of the volume after it is created. Possible values are: online restricted offline force-online force-offline mixed	false	true (ByPropertyName)	
Type	Specifies the volume type. Possible values are: rw, ls, dp, dc.	false	true (ByPropertyName)	
UnixPermissions	Indicates the UNIX permission bits in an octal string format.	false	true (ByPropertyName)	
UserId	Specifies the UNIX user ID for the volume. The default value is 0 ('root').	false	true (ByPropertyName)	
VirtualStorageServerRoot	Indicates whether you want this value to be the namespace root volume. If true, this volume is the namespace root volume of the virtual storage server which owns this volume. The default value is false.	false	true (ByPropertyName)	
QosPolicyGroup	Optionally specifies which QoS policy group to apply to the volume. This policy group defines measurable service level objectives (SLOs) that apply to the storage objects with which the policy group is associated. If you do not assign a policy group to a volume, the system monitors and controls the traffic to the volume. To remove this volume from a policy group, enter the reserved keyword 'none'. This parameter is not supported on Infinite Volumes.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
SnapshotCloneDependency	{on off} - Snapshot Cloning Dependency Specifies whether the LUN clone dependency on Snapshot copies is enabled. If set to on, LUN clone dependency on Snapshot copies is enabled. This parameter is not supported on Infinite Volumes.	false	true (ByPropertyName)	
EnableSnapdiff	{true false} - Create Namespace Mirrors For Snapdiff Use	false	true (ByPropertyName)	
SchedSnapName	{create_time ordinal} - Naming Scheme for Automatic Snapshots Specifies the naming convention for automatic Snapshot copies. If set to create-time, automatic Snapshot copies are named using the format <schedule_name>.yyyy-mm-dd_hhmm. Example: hourly.2010-04-01_0831. If set to ordinal, automatic Snapshot copies are named using the format <schedule_name>.<n>. Example: hourly.3 This parameter is not supported on Infinite Volumes.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
SpaceGuarantee	Specifies the type of volume guarantee the new volume uses. Possible values: none, file, volume. This option controls whether the volume is guaranteed some amount of space in the aggregate. The default is volume, and file and none can be set by the administrator. Volume guaranteed means that the entire size of the volume is preallocated. The file value means that space is preallocated for all the space-reserved files and LUNs within the volume. Storage is not preallocated for files and LUNs that are not space-reserved. Writes to these can fail if the underlying aggregate has no space available to store the written data. This value can be set if fractional reserve is 100. The none value means that no space is preallocated, even if the volume contains space-reserved files or LUNs. If the aggregate is full, space is not available even for space-reserved files and LUNs within the volume. Setting this parameter to file or none enables you to provision more storage than is physically present in the aggregate (thin provisioning). When you use thin provisioning for a volume, it can run out of space even if it has not yet consumed its nominal size and you should carefully monitor space utilization to avoid unexpected errors due to the volume running out of space. For flexible root volumes, to ensure that system files, log files, and cores can be saved, the space-guarantee must be volume. This ensures technical support for the storage system, if a problem occurs. Disk space is preallocated when the volume is brought online and, if not used, returned to the aggregate when the volume is brought offline. It is possible to bring a volume online even when the aggregate has insufficient free space to preallocate to the volume. In this case, no space is preallocated, just as if the none option had been selected. In this situation, the vol options and vol status command display the actual value of the space-guarantee option, but indicate that it is disabled.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
SnapReserve	Optionally specifies the amount of space reserved on the volume for Snapshot copies. The default setting is 5 percent.	false	true (ByPropertyName)	
FractionalReserve	This option changes the amount of space reserved for overwrites of reserved objects (LUNs, files) in a volume. This parameter is not supported on Infinite Volumes. The option is set to 100 by default with guarantee set to volume or file. A setting of 100 means that 100 percent of the required reserved space is actually reserved, so the objects are fully protected for overwrites. The value is set to 0 by default with guarantee set to none. The value can be either 0 or 100 when guarantee is set to volume or none. If guarantee is set to file, 100 is the only allowed value. Using a value of 0 indicates that no space will be reserved for overwrites. This returns the extra space to the available space for the volume, decreasing the total amount of space used. However, this does leave the protected objects in the volume vulnerable to out of space errors. If the percentage is set to 0%, the administrator must monitor the space usage on the volume and take corrective action.	false	true (ByPropertyName)	
SpaceMgmtTryFirst	{volume_grow snap_delete} - Primary Space Management Strategy A flexible volume can be configured to automatically reclaim space in case the volume is about to run out of space, by either increasing the size of the volume using autogrow or deleting Snapshot copies in the volume using Snapshot autodelete. If this option is set to volume_grow the system will try to first increase the size of volume before deleting Snapshot copies to reclaim space. If the option is set to snap_delete the system first automatically deletes Snapshot copies and in case of failure to reclaim space tries to grow the volume. This parameter is not supported on Infinite Volumes.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
SpaceNearlyFullThresholdPercent	Optionally specifies the percentage at which the volume is considered nearly full, and above which an EMS warning is generated. The default value is 95%. Setting this threshold to 0 disables the volume nearly full space alerts. This parameter is not supported on Infinite Volumes.	false	true (ByPropertyName)	
SpaceFullThresholdPercent	Optionally specifies the percentage at which the volume is considered full, and above which a critical EMS error is generated. The default value is 98%. Setting this threshold to 0 disables the volume full space alerts. This parameter is not supported on Infinite Volumes.	false	true (ByPropertyName)	
Files	Optionally specifies the total number of files permitted on the volume. The default setting is 629. This value can be raised but cannot be lowered; the new value must be larger than the current value.	false	true (ByPropertyName)	
FilesysSizeFixed	This option causes the file system to remain the same size and not grow or shrink when a SnapMirrored volume relationship is broken, or when a volume add is performed on it. It is automatically set to true when a volume becomes a SnapMirrored volume. It stays set to true after the SnapMirror break command is issued for the volume. This allows a volume to be SnapMirrored back to the source without needing to add disks to the source volume. If the volume is a traditional volume and the size is larger than the file system size, setting this option to false forces the file system to grow to the size of the volume. If the volume is a flexible volume and the volume size is larger than the file system size, setting this option to false forces the volume size to equal the file system size. The default setting is false.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
ExtentEnabled	Setting this option to on or space-optimized enables extents in the volume. This causes application writes to be written in the volume as a write of a larger group of related data blocks called an extent. Using extents may help workloads that perform many small random writes followed by large sequential reads. However, using extents may increase the amount of disk operations performed on the controller, so this option should only be used where this trade-off is desired. If the option is set to space-optimized then the reallocation update will not duplicate blocks from Snapshot copies into the active file system, and will result in conservative space utilization. Using space-optimized may be useful when the volume has Snapshot copies or is a SnapMirror source, when it can reduce the storage used in the volume and the amount of data that SnapMirror must move on the next update. The space-optimized value can result in degraded read performance of Snapshot copies. The default value is off; extents are not used.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
ReadRealloc	Setting this option to on or space-optimized enables read reallocation in the volume. This results in the optimization of file layout by writing some blocks to a new location on disk. The layout is updated only after the blocks have been read because of a user read operation, and only when updating their layout will provide better read performance in the future. Using read reallocation may help workloads that perform a mixture of random writes and large sequential reads. If the option is set to space-optimized then the reallocation update will not duplicate blocks from Snapshot copies into the active file system, and will result in conservative space utilization. Using space-optimized may be useful when the volume has Snapshot copies or is a SnapMirror source, when it can reduce the storage used in the volume and the amount of data that SnapMirror must move on the next update. The space-optimized value can result in degraded read performance of Snapshot copies. The default value is off.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
ExternalCache	Optionally specifies which WAFL external cache policy to apply to the volume. This parameter is not supported on Infinite Volumes. A WAFL external cache policy defines how the data blocks are cached for this volume. If an external cache policy is not assigned to this volume, the system uses the external cache policy that is assigned to the containing virtual storage server. If an external cache policy is not assigned to the containing virtual storage server, the system uses the default cluster-wide policy. The available WAFL external cache policies are: - o Uncached - Caches nothing. - o Metadata_Only - Caches indirect blocks and system metafiles. - o Normal_Data - Caches indirect blocks, system metafiles, and randomly read user data. - o Random_Write_Data - Caches normal data blocks and any blocks read as a result of random writes. - o Readahead_Data - Caches normal data blocks and any sequentially read user data blocks. - o Most_Data - Caches normal data blocks and any blocks read as a result of random writes or sequential reads. - o Lopri_Data - Caches everything. - o Default - Current cluster-wide default, which is Normal_Data.	false	true (ByPropertyName)	
VmAlignSector		false	true (ByPropertyName)	
VmAlignSuffix		false	true (ByPropertyName)	
AutoSizeMode	{off grow grow_shrink} - Autosize ModeSpecifies the autosize mode for the volume. The allowed values are grow, grow_shrink, and off. If this parameter is not specified, the existing autosize mode remains in effect. This parameter is not supported in Infinite Volumes. The various autosize modes are explained below: - o off - The volume will not grow or shrink in size in response to the amount of used space. - o grow - The volume will automatically grow when used space in the volume is above the grow threshold. - o grow_shrink - The volume will grow or shrink in size in response to the amount of used space.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
MaxAutosize	Specifies the maximum size to which a flexible volume can grow. The default is 120% of the volume size at creation for a flexible volume, and the greater of the origin volume's size and the current value of max-autosize for a FlexCache volume if a size is not specified upon creation. This parameter is not supported in Infinite Volumes.	false	true (ByPropertyName)	
AutosizeIncrement	The size of the volume is increased by the increment size specified by autosize-increment each time the volume is autogrown. A volume does not automatically grow if the current size of the volume is greater than or equal to the maximum size specified by the max-autosize. The default is 5% of the volume size at the time autosize was enabled for the volume. This parameter is not supported in Infinite Volumes.	false	true (ByPropertyName)	
AutosizeIncrementPercent	The increment percent specified with autosize-increment-percent is converted to a fixed increment size in bytes based on the volume size when volautosize-increment-percent is issued. The size of the volume is increased by the computed increment size each time the volume is autogrown. A volume will not automatically grow if the current size of the volume is greater than or equal to the maximum size specified with the max-autosize parameter. The default is 5% of volume size at the time autosize was enabled for the volume. This parameter is not supported in Infinite Volumes.	false	true (ByPropertyName)	
MinAutosize	{<integer>[KB MB GB TB PB]} - Minimum Autosize Specifies the minimum automatic size to which the volume shrinks. The default value is the volume size at the time when the grow_shrink autosize mode was enabled for the volume. If the volume was created with the grow_shrink autosize mode enabled, then the default minimum size will be equal to the initial volume size. This parameter is not supported in Infinite Volumes.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
AutosizeGrowThresholdPercent	Specifies the used space threshold for the automatic growth of the volume. When the volume used space becomes greater than this threshold, the volume will be grown unless it has reached the maximum autosize. This parameter is not supported in Infinite Volumes.	false	true (ByPropertyName)	
AutosizeShrinkThresholdPercent	Specifies the used space threshold for the automatic shrink of the volume. When the volume used space becomes less than this threshold, the volume will be shrunk unless it has reached the minimum autosize. This parameter is not supported in Infinite Volumes.	false	true (ByPropertyName)	
AutoDeleteEnabled	Specifies whether automatic deletion of Snapshot copies is enabled or disabled. If set to true, automatic deletion of Snapshot copies is enabled. If set to false automatic deletion of Snapshot copies is disabled.	false	true (ByPropertyName)	
Commitment	Specifies which Snapshot copies can be automatically deleted to reclaim back space. When set to try, the Snapshot copies which are not locked by any application are deleted. When set to disrupt, the Snapshot copies which are not locked by Data Backing Functionalities (Volume Clones, LUN Clones, File Clones) are deleted. In disrupt mode, Snapshot locked by Data Protection Utilities like SnapMirror or Volume Move can be deleted. If such a locked Snapshot copy is deleted during the data transfer, the transfer is aborted. When set to destroy, Snapshot copies locked by even the Data Backing Functionalities are deleted.	false	true (ByPropertyName)	
DeferDelete	{scheduled user_created prefix none}} - Defer Delete Specifies which kind of Snapshot copies are deleted in the end. When set to scheduled, scheduled Snapshot copies are deleted in the end. When set to user_created, user Snapshot copies are deleted in the end. When set to prefix, Snapshot copies matching a certain prefix are deleted in the end. When set to none no defer deletion order is honored.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Deleteorder	{newest_first oldest_first} - Delete Order. Specifies whether if the oldest Snapshot copy or the newest Snapshot copy is deleted first.	false	true (ByPropertyName)	
DeferDeletePrefix	Specifies the prefix string for the -defer -delete prefix parameter.	false	true (ByPropertyName)	
TargetFreeSpace	Specifies when you want automatic deletion of Snapshot copies to stop. Depending on the -trigger Snapshot copies are deleted till you reach the target free space percentage.	false	true (ByPropertyName)	
Trigger	{volume snap_reserve space_reserve} - Trigger Specifies the condition which starts the automatic deletion of Snapshot copies. Setting this option to volume triggers automatic deletion of Snapshot copies when the volume reaches threshold capacity and the volume's space reserved for Snapshot copies has been exceeded. Setting the option to snap_reserve triggers automatic deletion of Snapshot copies when the space reserved for Snapshot copies reaches threshold capacity. Setting the option to space_reserve triggers automatic deletion of Snapshot copies when reserved space in the volume reaches threshold capacity and the volume's space reserved for Snapshot copies has been exceeded.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
DestroyList	Specifies a comma-separated list of data backing functions which are affected if automatic deletion of the Snapshot copy backing that service is triggered. Possible values for this option are: vol_clone, lun_clone, file_clone, sfsr, cifs_share, or none. With the exception of none, all options can be combined as a comma-separated list. If you specify vol_clone, the cloned volume backed by the Snapshot copy is deleted. If you specify lun_clone, and the LUN is in the process of being cloned when autodelete is triggered, the cloning operation is aborted. Any access to this LUN results in an error being reported to the client. If you specify file_clone, and the file cloning operation is in progress when autodelete is triggered, the cloning operation is aborted. Any access to this file results in an error being reported to the client. If you specify sfsr, and the file restore is in progress when autodelete is triggered, the restore operation is aborted. If the Snapshot copy is locked either by a lun_clone or file_clone or both, the -destroy-list must be set to lun_clone,file_clone. If the Snapshot copy is locked either by a lun_clone or sfsr operation or both, -destroy-list must be set to lun_clone, file_clone. The options file_clone and sfsr are equivalent to each other. If you set -destroy-list to lun_clone, file_clone and the Snapshot copy is backing a file clone or sfsr operation, both the operations are aborted. This is also the case when you set -destroy-list to lun_clone, sfsr.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Provisioning a storage system volume using a template

```
PS C:\> New-SdVolume -Name sqlldbvolume -Aggregate sqlldbaggregate
-JunctionPath /sqlldbvolume
-TemplateName C:\Program
Files\SnapDrive\Templates\HyperVVHdxProvTemplate.xml -Size 128GB
-StorageSystem sqlvirtualstorageserver
```

This example provisions a storage system volume using the specified template.

```
Name      : sqlldbvolume
Vserver:  sqlvirtualstorageserver
FullPath  : sqlvirtualstorageserver:/vol/sqlldbvolume
JunctionPath : /sqlldbvolume
JunctionParentName :
SizeTotal  :
SizeUsed   :
SnapMirrorSource :
SnapMirrorDest :
SnapVaultPrimary :
SnapVaultSecondary :
FlexCloneEnabled :
IsFlexClone:
Style     : ntfs
ResourceType : SDStorageVolume
ResourceName : sqlvirtualstorageserver:/vol/sqlldbvolume
Ranges :
```

Remove-SdBackup

Syntax

```
Remove-SdBackup [-Snapshot] <String> [-ResourceName] <String> [-
RestApiURL] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Snapshot		true	true (ByValue, ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
ResourceName		true	true (ByPropertyName)	
RestApiURL		false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Remove-SdIgroup

Removes an igroup from your storage system.

Syntax

```
Remove-SdIgroup [-Name] <String> [-StorageSystem] <String> [-Session]
<String> [-Host] <String>
```

Detailed Description

Removes an igroup from your storage system.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Name	Specifies the name of the igroup you want to remove from your storage system.	true	true (ByPropertyName)	
StorageSystem	Specifies the storage system from which you want to remove the igroup.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Removing an igroup

```
PS C:\> Remove-SdIgroup -Name IG_Demo -StorageSystem 172.17.168.13
```

This example syntax removes the a specific igroup from the specified storage system.

Remove-SdLun

Removes a LUN from your storage system.

Syntax

```
Remove-SdLun [-StorageSystem] <String> [-LunPath] <String> [-Session]  
<String> [-Host] <String>
```

Detailed Description

Removes a LUN from your storage system.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the storage system on which your LUN is located.	true	true (ByPropertyName)	
LunPath	Specifies the path of the LUN on your storage system. If you are working in an ONTAP environment, specify the path to your LUN. If you are working in a Flashray, specify the LUN name.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Remove-SdLunMap

Unmaps your LUN from your igroup.

Syntax

```
Remove-SdLunMap [-StorageSystem] <String> [-LunPath] <String> [-Igroup] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Unmaps your LUN from your igroup.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the storage system on which the igroup, to which your LUN is mapped, resides.	true	true (ByPropertyName)	
LunPath	Specifies the path of the LUN on your storage system. If you are working in an ONTAP environment, specify the path to your LUN. If you are working in a Flashray, specify the LUN name.	true	true (ByPropertyName)	
Igroup	Specifies the igroup from which you want to unmap your LUN.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Remove-SdPortSet

Deletes a portset.

Syntax

```
Remove-SdPortSet [-PortSetName] <String> [-ForceDestroy] <> [-StorageSystem] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Deletes a portset.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
PortSetName	Specifies the name of the portset you want to delete.	true	true (ByPropertyName)	
ForceDestroy	Specifies that you want to forcibly delete a portset.	false	true (ByPropertyName)	
StorageSystem	Specifies the name of the storage system on which the portset you want delete resides.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Remove-SdPortSetPort

Deletes a specified port from your portset.

Syntax

```
Remove-SdPortSetPort [-PortSetName] <String> [-Port] <String> [-StorageSystem] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Deletes a specified port from your portset.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
PortSetName	Specifies the name of the portset from which you want to delete a port.	true	true (ByPropertyName)	
Port	Specifies the port you want to delete from your portset.	true	true (ByPropertyName)	
StorageSystem	Specifies the storage system on which your portset resides.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Remove-SdSMBShare

Removes one or more SMB shares from your storage system.

Syntax

```
Remove-SdSMBShare [-Path] <Object[]> [-Session] <String> [-Host] <String>
```

Detailed Description

Removes one or more SMB shares from your storage system. This cmdlet is supported in clustered Data ONTAP 8.2 and later.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies a comma-separated list of SMB shares.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Removing an SMB share

```
PS C:\> Remove-SdSMBShare -Path \\JENKINS-CIFS\RemoveShare03 -Verbose
```

This example syntax removes SMB share "RemoveShare03" from your storage system.

Example 2: Removing multiple SMB shares

```
PS C:\> Remove-SdSMBShare -Path \\JENKINS-
CIFS\RemoveShare01,\\172.17.165.40\RemoveShare02 -Verbose
```

This example syntax removes SMB share "RemoveShare01," and "RemoveShare02" from the your storage system.

Remove-SdSnapMirrorPolicyRule

Removes the rules from the SnapMirror policy associated with the SnapVault relationship.

Syntax

```
Remove-SdSnapMirrorPolicyRule [-SourceStorageSystem] <String> [-
SourceStorageSystemVolume] <String> [-DestinationStorageSystem]
<String> [-DestinationStorageSystemVolume] <String> [-SnapMirrorLabel]
<String[]> [-Session] <String> [-Host] <String>
```

Detailed Description

Removes the rules from the SnapMirror policy associated with the SnapVault relationship. Related cmdlets: Set-SdSnapMirrorPolicyRule, Get-SdSnapMirrorPolicyRule

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
SourceStorageSystem	Specifies the primary storage system name containing the source volumes of the SnapMirror relationship for which you want to remove the SnapMirror policy rules. IP addresses are not supported.	true	true (ByValue, ByPropertyName)	
SourceStorageSystemVolume	Specifies the source volume of the SnapMirror relationship for which you want to remove the SnapMirror policy rules.	true	true (ByPropertyName)	
DestinationStorageSystem	Specifies the secondary storage system name containing the destination volumes of the SnapMirror relationship for which you want to remove the SnapMirror policy rules. IP addresses are not supported.	true	true (ByValue, ByPropertyName)	
DestinationStorageSystemVolume	Specifies the destination volume of the SnapMirror relationship for which you want to remove the SnapMirror policy rules.	true	true (ByPropertyName)	
SnapMirrorLabel	Specifies the SnapMirror policy rule which you want to remove.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Removing SnapMirror policy rule information from the policy for a SnapMirror relationship

```
PS C:\> Remove-SdSnapMirrorPolicyRule -SourceStorageSystem vs01
-SourceStorageSystemVolume src_vol01 -DestinationStorageSystem vs02
-DestinationStorageSystemVolume dest_vol01 -SnapMirrorLabel
myWeekly,myMonthly -verbose -Confirm:$false
```

Removes the SnapMirror policy rules (myWeekly, myMonthly) from the policy on the specified relationship.

Remove-SdSnapshot

Removes Snapshot copies created on Windows disks, SMB shares, or storage system volumes.

Syntax

```
Remove-SdSnapshot [-Path] <Object[]> [-Snapshot] <String[]> [-Session]
<String> [-Host] <String>
```

Detailed Description

Removes Snapshot copies created on Windows disks, SMB shares, or storage system volumes. Related cmdlets: New-SdSnapshot, Rename-SdSnapshot, and Restore-SdSnapshot

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies the SMB shares, volume, or logical disk for the Snapshot copies you want to delete. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByPropertyName)	
Snapshot	Specifies the list of Snapshot copies you want to delete.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Removing a Snapshot copy on a SMB share

```
PS C:\> Remove-SdSnapshot -Path "\\172.17.12.101\share" -Snapshot
"snapshot_1"
```

This example syntax removes the Snapshot copy snapshot_1 created on SMB share \\172.17.12.101\share.

Example 2: Removing specified Snapshot copies on multiple SMB shares

```
PS C:\> Remove-SdSnapshot -Path
"\\172.17.12.101\share1","\\172.17.12.101\share2" -Snapshot
"snapshot_1","snapshot_2"
```

This example removes Snapshot copies snapshot_1 and snapshot_2 created on SMB shares \\172.17.12.101\share1 and \\172.17.12.101\share2.

Example 3: Removing a new Snapshot copy on a SMB share

```
PS C:\> New-SdSnapshot -Path "\\172.17.12.101\share" | Remove-SdSnapshot
```

This example removes the new Snapshot copy on SMB share \\172.17.12.101\share.

Example 4: Removing a Snapshot copy on a disk

```
PS C:\> Remove-SdSnapshot -Path D: -Snapshot "snapshot_1"
```

This example syntax removes the Snapshot copy snapshot_1 created on the disk drive D:.

Remove-SdStorage

Deletes a LUN and everything associated with it.

Syntax

```
Remove-SdStorage [-Path] <String> [-IgnoreVolumeMountPoint] <> [-Session] <String> [-Host] <String>
```

Detailed Description

Deletes a LUN and everything associated with it.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies you LUN share path using this format: :D	true	true (ByPropertyName)	
IgnoreVolumeMountPoint		false	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Deleting a LUN

```
PS C:\> Remove-SdStorage -Path V:
```

This example syntax deletes the specified LUN.

Remove-SdStorageConnectionSetting

Removes the storage connection, transport, and credential settings from the configuration repository for one or more storage system or virtual storage server.

Syntax

```
Remove-SdStorageConnectionSetting [-StorageSystem] <String[]> [-  
HostOnly] <> [-PassThru] <> [-LegacyContext] <> [-Session] <String>  
[-Host] <String> [-All] <> [-HostOnly] <> [-PassThru] <> [-  
LegacyContext] <> [-Session] <String> [-Host] <String> [-  
DefaultSetting] <> [-HostOnly] <> [-PassThru] <> [-LegacyContext]  
<> [-Session] <String> [-Host] <String>
```

Detailed Description

Removes the storage connection, transport and credential settings from the configuration repository for one or more storage system or virtual storage server. Related cmdlets: Set-SdStorageConnectionSetting and Get-SdStorageConnectionSetting

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the name or IP address of the storage system (storage controller or virtual storage server) for which you want to retrieve connection settings.	true	true (ByPropertyName)	
HostOnly	Specifies that you want to remove the storage system credentials only on the cluster node you specify. The default behavior is that HostOnly is not specified, and your storage credential settings are removed from all the nodes in a cluster.	false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
PassThru	Indicates the output setting objects that you removed from the configuration. These objects are written to the pipeline for further processing.	false	true (ByPropertyName)	false
LegacyContext	For internal use only.	false	false	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
All	Indicates that you want to remove all connection settings, including the default settings, from the configuration repository.	true	true (ByPropertyName)	
DefaultSetting	Indicates that you want to remove the default storage system connection settings.	true	false	

Examples

Example 1: Removing named connection settings

```
PS C:\> Remove-SdStorageSystemSetting -StorageSystem
vmStorageServer,sqlServer -PassThru
```

This example syntax removes the specified vmStorageServer and sqlServer storage system connection settings.

Example 2: Removing all connection settings

```
PS C:\> Remove-SdStorageConnectionSetting -All -PassThru
```

This example syntax removes all the connection settings, including the default connection settings.

Example 3: Removing default storage connection settings

```
PS C:\> Remove-SdStorageConnectionSetting -DefaultSetting -PassThru
```

This example syntax removes the default storage system connection settings. You can use the default settings

to attempt a connection to any system that is not explicitly configured.

Example 4: Removing pipeline storage connection settings

```
PS C:\> $settings = Get-SdStorageConnectionSetting
$settings | Remove-SdStorageConnectionSetting -PassThru -confirm:$false
```

This example syntax retrieves the existing storage connection settings. In this case, they are "vmStorageServer" and "sharePointServer". Then the example pipes those names as the connection settings to be removed. Because the confirm value is false, there is no confirmation prompt and the PassThru switch means it outputs the objects removed.

Remove-SdVolume

Removes a volume from your storage system.

Syntax

```
Remove-SdVolume [-Volume] <String> [-StorageSystem] <String> [-
Session] <String> [-Host] <String>
```

Detailed Description

Removes a volume from your storage system. When you remove a volume using this cmdlet, Remove-SdVolume dismounts your volume, brings it offline, and deletes it. You can remove one volume at a time, only. You cannot remove volumes that are in a SnapMirror relationship. When you remove volumes, any active LUNs or shares on the volume are also removed. This cmdlet is supported in clustered Data ONTAP 8.2 and later. Related cmdlets: New-SdVolume

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Volume	Specifies the name of the volume you want to delete.	true	true (ByValue, ByPropertyName)	
StorageSystem	Specifies the name of the storage system from which you want to delete the volume. You can use the administration interface or the storage system name.	true	true (ByValue, ByPropertyName)	
Session		false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Removing a volume

```
PS C:\> Remove-SdVolume -Volume TestRemoval01 -StorageSystem
172.17.165.39 -Verbose
```

This example syntax removes volume TestRemoval01 from storage system 172.17.165.39.

```
VERBOSE: volume 'TestRemoval01' will be removed
Remove-SdVolume
volume 'TestRemoval01' will be removed Do you want to continue?
[Y] Yes [A] Yes to All [N] No [L] No to All [S] Suspend [?] Help
(default is "Y"): y
VERBOSE: Removing volume: TestRemoval01
VERBOSE: Operation Successful.
```

Remove-SdVsphereSetting

Syntax

```
Remove-SdVsphereSetting [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Rename-SdIgroup

Renames your specified igroup.

Syntax

```
Rename-SdIgroup [-Name] <String> [-NewName] <String> [-StorageSystem]
<String> [-Session] <String> [-Host] <String>
```

Detailed Description

Renames your specified igroup.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Name	Specifies the name of the igroup you want to rename.	true	true (ByPropertyName)	
NewName	Specifies the new name of the igroup you are renaming.	true	true (ByPropertyName)	
StorageSystem	Specifies the storage system on which the igroup you want to rename is located.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Renaming an igroup

```
PS C:\> Rename-SdIgroup -Name IG_Demo -NewName IG_Demo_Renamed
-StorageSystem 172.17.168.13
```

This examples syntax renames an existing igroup.

Rename-SdSnapshot

Renames Snapshot copies created on a Windows disk or SMB share.

Syntax

```
Rename-SdSnapshot [-Path] <Object[]> [-Snapshot] <String> [-NewName]
<String> [-Session] <String> [-Host] <String> [-StorageSystem]
<String> [-VolumeName] <String> [-Snapshot] <String> [-NewName]
<String> [-Session] <String> [-Host] <String>
```

Detailed Description

Renames Snapshot backups created on a Windows disk or SMB share. Related cmdlets: New-SdSnapshot and Remove-SdSnapshot

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies a list of SMB shares or Windows volumes. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByPropertyName)	
Snapshot	Specifies the name of the Snapshot copy you want to rename.	true	true (ByPropertyName)	
NewName	Indicates the new name of the Snapshot copy.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
StorageSystem	Specifies the name of storage system name for the Snapshot copy you are renaming.	true	true (ByPropertyName)	
VolumeName	Specifies the storage system volume name for the Snapshot copy.	true	true (ByPropertyName)	

Examples

Example 1: Rename a single Snapshot copy

```
PS C:\> Rename-SdSnapshot -Path \\SQLCIFSServer\SalesDBShare -Snapshot  
MySnap -NewName MyNewSnap
```

This example renames a Snapshot copy from MySnap to MyNewSnap.

SnapshotName	AccessPoint	StorageSystemName	Volume
--------------	-------------	-------------------	--------

MyNewSnap	\\SQLCIFSServer\SalesDBShare	MyStorageSystem1	vol1
-----------	------------------------------	------------------	------

Example 2: Rename a Snapshot copy on two SMB shares

```
PS C:\> Rename-SdSnapshot -Path  
\\SQLCIFSServer1\SalesDBShare,\\SQLCIFSServer2\MarketDBShare -Snapshot  
MySnap -NewName MyNewSnap
```

This example renames a Snapshot copy located two SMB shares.

SnapshotName	AccessPoint	StorageSystemName	Volume
--------------	-------------	-------------------	--------

MyNewSnap	\\SQLCIFSServer1\SalesDBShare	MyStorageSystem1	vol1
MyNewSnap	\\SQLCIFSServer2\MarketDBShare	MyStorageSystem2	vol2

Example 3: Rename a Snapshot copy on a specified storage system and volume

```
PS C:\> Rename-SdSnapshot -StorageSystem MyStorageSystem1 -VolumeName  
vol1 -Snapshot MySnap -NewName MyNewSnap
```

This example renames a Snapshot copy from MySnap to MyNewSnap on a specified storage system and volume.

SnapshotName	AccessPoint	StorageSystemName	Volume
--------------	-------------	-------------------	--------

MyNewSnap		MyStorageSystem1	vol1
-----------	--	------------------	------

Example 4: Renames a single Snapshot copy on a disk

```
PS C:\> Rename-SdSnapshot -Path F: -Snapshot MySnap -NewName MyNewSnap
```

This example renames a Snapshot copy on the disk drive :F from MySnap to MyNewSnap.

Repair-SdAluaPaths

Repairs disks with no active/optimized ALUA paths.

Syntax

```
Repair-SdAluaPaths [-Paths] <String[]> [-Session] <String> [-Host]
<String>
```

Detailed Description

Repairs disks with no active/optimized ALUA paths.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Paths	Specifies the drive letter or mount point of the file system to fix a path.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name of the host.	false	true (ByPropertyName)	

Examples

Example 1: Repairing disks with no optimized ALUA paths

```
PS C:\> Repair-SdAluaPaths
```

This example syntax repairs disks with no optimized ALUA paths.

Restore-SdPlugInResource

Syntax

```
Restore-SdPlugInResource [-SnapInfo] <SnapInfo> [-MappingInfo]
<MappingInfo> [-Context] <String> [-Session] <String> [-Host]
<String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
SnapInfo		true	true (ByPropertyName)	
MappingInfo		true	true (ByPropertyName)	
Context		false	false	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Restore-SdSnapshot

Restores files and directories from a primary or secondary Snapshot copy, on Windows disks or SMB shares.

Syntax

```
Restore-SdSnapshot [-Path] <Object[]> [-Snapshot] <String> [-StorageSystem] <String> [-VolumeName] <String> [-ForceRestore] <> [-Session] <String> [-Host] <String>
```

Detailed Description

Restores files and directories from a primary or secondary Snapshot copy, on Windows disks or SMB shares. When you are restoring from a Snapshot copy on a share, you can restore everything from that Snapshot copy. When you are restoring from a Snapshot copy in a SAN environment, you can restore disks only. When you are restoring from the secondary Snapshot copy, you must have a CIFS server on the secondary server. When you are restoring multiple files or directories under the same SMB share from your SnapVault secondary, you cannot specify the CIFS server name in the path by referring to IP/Name/Fully qualified domain name (FQDN.) You must specify the CIFS server name using only IP or Name or FQDN. Related cmdlets: New-SdSnapshot and Get-SdSnapshot

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies the location of the files, directories, and disks for the Snapshot copies you want to restore. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByPropertyName)	
Snapshot	Specifies the Snapshot copy name you want to restored.	true	true (ByPropertyName)	
StorageSystem	Name of the storage system in which the Snapshot copy specified for the restore operation is located.	false	true (ByPropertyName)	
VolumeName	Name of the storage system volume in which the Snapshot copy specified for the restore operation is located.	false	true (ByPropertyName)	
ForceRestore	Indicates whether the Snapshot copy should be forcibly restored. If you want to overwrite existing versions of the files or directories you are restoring, this parameter is required.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Restoring a Snapshot copy on a SMB share from a Snapshot copy

```
PS C:\> Restore-SdSnapshot -Path "\\172.17.12.101\share\files.txt"
-Snapshot "snapshot_1"
```

This example restores the file named file.txt on SMB share "\\172.17.12.101\share" from specified Snapshot copy "snapshot_1".

Example 2: Restoring a file under a subfolder of a SMB share from a Snapshot copy

```
PS C:\> Restore-SdSnapshot -Path "\\172.17.12.101\share\dir1\file1.txt"
-Snapshot snapshot_1
```

This example restores the file on "\\172.17.12.101\share\dir1\file1.txt" from Snapshot copy snapshot_1.

Example 3: Restoring a directory with its contents under a SMB share from a Snapshot copy

```
PS C:\> Restore-SdSnapshot -Path "\\172.17.12.101\share\folder1\*"
-Snapshot "snapshot_1"
```

This example restores the directory named "folder1" and its contents from the specified Snapshot copy "snapshot_1".

Example 4: Restoring multiple files and directories under a SMB share from a Snapshot copy

```
PS C:\> Restore-SdSnapshot -Path
"\\172.17.12.101\share\file0.txt", "\\172.17.12.101\share\dir1\file1.txt", "
\\172.17.12.101\share\dir2\*", "\\172.17.12.101\share\dir3\*" -Snapshot
snapshot_1
```

This example restores a file named "file0.txt" under the root of the SMB share, a named "file1.txt" under directory "dir1", directory named "dir2" and "dir3" and their contents, from the Snapshot copy named "snapshot_1".

Example 5: Restoring a file on a SMB share from a Snapshot copy on the SnapVault secondary

```
PS C:\> Restore-SdSnapshot -Path "\\172.17.12.101\share\dir1\file1.txt"
-Snapshot "snapshot_1" -StorageSystem 172.17.165.29 -VolumeName
vaultdest_vol
```

This example restores a file named "file1.txt" under directory "dir1" from the Snapshot copy named "snapshot_1" on the SnapVault secondary storage system.

Example 6: Restoring a Snapshot copy on a disk from a Snapshot copy

```
PS C:\> Restore-SdSnapshot -Path E: -Snapshot "snapshot_1"
```

This example restores the Snapshot named file.txt on disk drive E: from specified Snapshot copy "snapshot_1".

Set-SdAluaStateMonitor

Sets the interval for monitoring ALUA path optimization.

Syntax

```
Set-SdAluaStateMonitor [-TimerInterval] <UInt32> [-Session] <String>
[-Host] <String>
```

Detailed Description

Sets the interval for monitoring ALUA path optimization.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
TimerInterval	Sets the time interval, in minutes, for the ALUA state monitor thread. Depending on the interval set, the system performs an optimization check for ALUA paths and repairs the paths as needed.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Example 1: Setting ALUA state monitor with timer interval

```
PS C:\> Set-SdAluaStateMonitor -TimerInterval 10
```

This example syntax sets the ALUA state monitor with the specified timer interval.

Set-SdDiskDriveLetter

Changes the Windows disk drive letter.

Syntax

```
Set-SdDiskDriveLetter [-OldDiskDriveLetter] <String> [-NewDiskDriveLetter] <String> [-Host] <String>
```

Detailed Description

Changes the Windows disk drive letter. This command is supported only for dedicated and shared disk, and not applicable for CSV disk.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
OldDiskDriveLetter	Specifies the drive letter where the disk is mounted currently using the format: D:, D:\	true	true (ByPropertyName)	
NewDiskDriveLetter	Specifies the new drive letter where the disk should be mounted using the format: D:, D:\	true	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Changing a Windows Disk Drive Letter

```
PS C:\> Set-SdDiskDriveLetter -OldDiskDriveLetter L:\ -NewDiskDriveLetter I:\
```

This example changes the drive letter of the specified Windows disk.

```
Change-SdDiskDriveLetter
The Disk drive letter will be changed from L:\ to I:\. Do you want to
continue?
[Y] Yes  [A] Yes to All  [N] No  [L] No to All  [S] Suspend  [?] Help
(default is "Y"):Y
Mount point of Disk which was on L:\ has changed to I:\
```

Set-SdSettings

Syntax

```
Set-SdSettings [-EnableUnsupportedCommands] <> [-Session] <String> [-
Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
EnableUnsupportedCommands		false	false	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Set-SdSnapMirrorPolicyRule

Sets the rules for managing Snapshot retention on the SnapVault secondary storage system.

Syntax

```
Set-SdSnapMirrorPolicyRule [-SourceStorageSystem] <String> [-SourceStorageSystemVolume] <String> [-DestinationStorageSystem] <String> [-DestinationStorageSystemVolume] <String> [-SnapMirrorLabel] <String> [-Retention] <Int32> [-Preserve] <> [-WarnThreshold] <Int32> [-Session] <String> [-Host] <String>
```

Detailed Description

Sets the rules for managing Snapshot retention on the SnapVault secondary storage system. You can create new rules for customizing your virtual storage server level SnapMirror policy. Each SnapMirror policy can have up to 10 rules managing Snapshot copy retention. The default policy rules are daily or weekly Snapshot copy retention, or you can define your own retention rule. You cannot modify cluster-level SnapMirror or SnapVault policies with virtual storage server credentials. Related cmdlets: Remove-SdSnapMirrorPolicyRule, Get-SdSnapMirrorPolicyRule

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
SourceStorageSystem	Specifies the primary storage system name containing the source volumes of the SnapMirror relationship for which you want to create or modify the SnapMirror policy rules. IP addresses are not supported.	true	true (ByValue, ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
SourceStorageSystemVolume	Specifies the source volume of the SnapMirror relationship for which you want to create or modify the SnapMirror policy rules.	true	true (ByPropertyName)	
DestinationStorageSystem	Specifies the secondary storage system name containing the destination volumes of the SnapMirror relationship for which you want to create or modify the SnapMirror policy rules. IP addresses are not supported.	true	true (ByValue, ByPropertyName)	
DestinationStorageSystemVolume	Specifies the destination volume of the SnapMirror relationship for which you want to create or modify the SnapMirror policy rules.	true	true (ByPropertyName)	
SnapMirrorLabel	Specifies the SnapMirror policy rule which you want to create or modify.	true	true (ByPropertyName)	
Retention	Specifies the Snapshot copy retention count.	true	true (ByPropertyName)	
Preserve	Specifies whether Snapshot copy preserve is enabled, which determines the behavior when the Snapshot copy retention count is reached on the SnapMirror Vault destination.	false	true (ByPropertyName)	
WarnThreshold	Specifies the warning threshold count.	false	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Setting SnapMirror policy rule information on the policy for a SnapMirror relationship

```
PS C:\> Set-SdSnapMirrorPolicyRule -SourceStorageSystem vs01
-SourceStorageSystemVolume src_vol01 -DestinationStorageSystem vs02
-DestinationStorageSystemVolume dest_vol01 -SnapMirrorLabel myWeekly
-Retention 8 -Preserve -WarnThreshold 3 -verbose -Confirm:$false
```

Create or modify the SnapMirror policy rule "myWeekly" on the policy of the specified relationship.

```
PS C:\Users\administrator.NEXTGEN> Set-SdSnapMirrorPolicyRule
-SourceStorageSystem vserver1 -SourceStorageSystemVolume snapvault_source
-DestinationStorageSystem vserver1 -DestinationStorageSystemVolume snapvault_dest
-SnapMirrorLabel test -Retention 8 -Preserve -WarnThreshold 3 -Verbose
Set-SdSnapMirrorPolicyRule
Set SnapMirror policy rule on vserver1 : snapvault_source ==> vserver1 :
snapvault_dest.
Do you want to continue?
[Y] Yes [A] Yes to All [N] No [L] No to All [S] Suspend [?] Help
(default is "Y"):
VERBOSE: Setting SnapMirror policy rules.
The setting SnapMirror policy rules operation is successful.
VERBOSE: Operation successful.
```

Set-SdSnapshot

Enables backup administrators to more easily attach labels to Snapshot copies and then select the secondary retention bucket by specifying the appropriate label.

Syntax

```
Set-SdSnapshot [-Snapshot] <String> [-Path] <Object[]> [-
SnapMirrorLabel] <String> [-Session] <String> [-Host] <String> [-
Snapshot] <String> [-StorageSystem] <String> [-VolumeName] <String[]>
[-SnapMirrorLabel] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Enables backup administrators to more easily attach labels to Snapshot copies and then select the secondary retention bucket by specifying the appropriate label. You can manage the secondary Snapshot copy retention using SnapMirror policies. A SnapMirror policy defines secondary retention buckets using various rules. A policy can have a maximum of 10 rules. These rules define how many Snapshot copies must be retained for a given Snapshot label and the behavior when the threshold is reached. You can also use rules to define what happens when you reach your Snapshot copy threshold. Based on your rule definitions, either the older Snapshot copies are deleted or your updates fail. You can use this cmdlet to set the Snapshot copy label based on the secondary retention requirements. You can use this cmdlet in clustered Data ONTAP 8.2 and later.

Relate cmdlets: Restore-SdSnapshot, Remove-SdSnapshot, Rename-SdSnapshot, New-SdSnapshot

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Snapshot	Indicates the name of the Snapshot copy to which you want the label to be attached. The Snapshot copy must exist in all the specified volumes.	true	true (ByPropertyName)	
Path	Specifies avolumes, logical disks, or a comma-separated list of SMB shares. You cannot mix a logical disk or mount point with SMB shares in the same input path.	true	true (ByPropertyName)	
SnapMirrorLabel	Specifies the label you want to attach to the Snapshot copy. If you specify an empty string, existing labels are removed.	true	true (ByPropertyName)	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
StorageSystem	Indicates the name of the storage system in which the Snapshot copy resides.	true	true (ByPropertyName)	
VolumeName	Specifies a comma-separated list of the volumes in which the specified Snapshot copy resides.	true	true (ByPropertyName)	

Examples

Example 1: Attaching a label to the specified Snapshot copy

```
PS C:\> Get-SdSnapshot -storagesystem prodvserver -volume voldb,vollog  
-snapshot salesdb_backup | Set-Sdsnapshot -label monthly
```

In this example syntax, you attach labels to the specified Snapshot copies.

Example 2: Making a Snapshot copy and attaching a label to it

```
PS C:\> New-SdSnapshot \\SQLFileserver\DBShare,\\SQLFileserver\LogShare
-Snapshot salesbackup -UpdateMirror | set-Sdsnapshot -Label weekly
```

In this example, you make a Snapshot copy of the specified shares, attach a weekly retention label, and update the mirror relationship.

Example 3: Getting secondary backups and changing their retention label

```
PS C:\> Get-SdSnapshot \\SQLFileserver\DBShare,\\SQLFileserver\LogShare
-GetSecondarySnapshots | set-Sdsnapshot -label monthly
```

In this example, you get secondary backups and change their retention labels.

Set-SdStorageConnectionSetting

Sets up the storage system transport protocols and credential settings.

Syntax

```
Set-SdStorageConnectionSetting [-StorageSystem] <String> [-HostOnly] <>
[-Protocol] <ConnectProtocol> [-Port] <UInt16> [-Credential]
<PSCredential> [-StorageSystemOSType] <String> [-PreferredIP] <String>
[-Timeout] <Int32> [-Force] <> [-LegacyContext] <> [-Session]
<String> [-Host] <String> [-StorageSystem] <String> [-
UseDefaultSetting] <> [-HostOnly] <> [-StorageSystemOSType] <String>
[-PreferredIP] <String> [-Timeout] <Int32> [-Force] <> [-
LegacyContext] <> [-Session] <String> [-Host] <String> [-
SyncClusterNodes] <> [-HostOnly] <> [-Protocol] <ConnectProtocol> [-
Port] <UInt16> [-StorageSystemOSType] <String> [-PreferredIP]
<String> [-Timeout] <Int32> [-Force] <> [-LegacyContext] <> [-
Session] <String> [-Host] <String> [-DefaultSetting] <> [-HostOnly]
<> [-Protocol] <ConnectProtocol> [-Port] <UInt16> [-Credential]
<PSCredential> [-StorageSystemOSType] <String> [-PreferredIP] <String>
[-Timeout] <Int32> [-Force] <> [-LegacyContext] <> [-Session]
<String> [-Host] <String>
```

Detailed Description

Sets up the storage system transport protocols and credential settings. so that you can make connections to a storage system or a virtual storage server later. These settings include the storage system name, port, transport type, user login, password, and timeout. If the settings already exist in the configuration repository for a specified storage system, those settings are replaced. When you are running this parameter in a clustered Data ONTAP environment, you only need to configure your storage connection settings once, rather than on each node of the cluster. If you want to set storage credentials only on a specific host, use the -HostOnly

parameter.Related cmdlets: Get-SdStorageConnectionSetting and Remove-SdStorageConnectionSetting

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem	Specifies the name or IP address of the storage system (storage controller or virtual storage server) for which you want to set connection settings.	true	true (ByPropertyName)	
HostOnly	Specifies that you want to set the storage system credentials only on the cluster node you specify. The default behavior is that HostOnly is not specified, and your storage credential settings are pushed to all the nodes in a cluster.	false	true (ByPropertyName)	
Protocol	Specifies the protocol type you want to use. By default, connections are attempted with a secure HTTPS connection to the storage controller, but it falls back to HTTP if necessary.Specify HTTPS, or HTTP to only use those protocols without any fallback to another protocol. Possible values are: HTTP, HTTPS, RPC.RPC is supported in 7-mode Data ONTAP version 8.0 and 8.1 storage systems only.	false	true (ByPropertyName)	DefaultWithFallback
Port	Specifies the port on which you want to connect to the storage controller. If you do not set this value, the default is 80 for HTTP and 443 for HTTPS. This parameter only applies to HTTP and HTTPS protocols.	false	true (ByPropertyName)	80/443
Credential	Designates the username and password you want to used to authenticate your connection to the storage system.Credentials are not required for the RPC protocol. You may specify credentials, but they will not be saved.	true	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystemOSType	Indicates the storage system OS type. The available types are DataONTAP and Flashray. If no OS type is specified, SnapCenter Plug-in for Microsoft Windows attempts first to connect to a Data ONTAP storage system. If that attempt fails, it then attempts to connect to a FlashRay storage controller. This parameter is optional.	false	true (ByPropertyName)	
PreferredIP		false	true (ByPropertyName)	
Timeout		false	true (ByPropertyName)	
Force	Indicates that you want to override existing storage system connection settings. If -Force is not specified and storage system connection settings already exist, you will be prompted to indicate whether you want to overwrite existing settings.	false	true (ByPropertyName)	
LegacyContext	For internal use only.	false	false	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
UseDefaultSetting	Indicates that you want to use the default storage system connection settings for setting up a new storage system connection. To set up storage system connection using the default settings, enter: Set-StorageConnectionSetting -UseDefaultSetting -StorageSystem	true	true (ByPropertyName)	
SyncClusterNodes		true	false	
DefaultSetting	Sets the default credentials, protocol and port. To specify default values, run: Set-SdStorageConnectionSetting -DefaultSetting -Protocol <HTTPS> -Port <443> -Credential <name>	true	true (ByPropertyName)	

Examples

Example 1: Setting up named storage system connection settings

```
PS C:\> Set-SdStorageConnectionSetting -StorageSystem  
'VirtualStorageServer1' -Protocol https -Credential vsadmin -Port 443
```

This example saves the specified storage system connection settings into the configuration repository. These settings are later used to connect to the VirtualStorageServer1 virtual storage server storage system. You are prompted for the password using the given login of 'vsadmin'.

Storage System Name/IP : VirtualStorageServer1
User : vsadmin
Port : 443
Protocol : Https

Example 2: Saving default connection settings using PowerShell script code

```
PS C:\> $password = ConvertTo-SecureString "p@ssword" -AsPlainText -Force  
$vserver_cred = New-Object -TypeName  
System.Management.Automation.PSCredential -ArgumentList "vsadmin",  
$password  
  
Set-SdStorageConnectionSetting -DefaultSetting -Credential $vserver_cred  
-protocol http
```

This example saves the default settings for later connections to a storage system. It uses a previously configured credential, the HTTP protocol, and the default port.

User : vsadmin
Port : 80
Protocol : Http

Example 3: Modifying existing settings for a new port and protocol

```
PS C:\> $setting = Get-SdStorageConnectionSetting -StorageSystem  
'vmStorageServer'  
  
$setting.Port = 443  
$setting.Protocol = "Https"  
$setting | Set-SdStorageConnectionSetting
```

This example reads the existing settings for "vmStorageServer" and then saves the storage system connection settings back to the configuration with a new port.

Storage System Name/IP : 10.53.41.214
Name : vmStorageServer

Port : 443
Protocol : Https

Example 4: Modifying existing connection settings based on default settings

```
PS C:\> $settingDef = Get-SdStorageConnectionSetting -DefaultSetting

$settingDef.port = 443
$settingDef | Set-SdStorageConnectionSetting -StorageSystem
"exchangeStorageServer"
```

This example retrieves the original default settings and changes the port to 443. Then, it saves the storage system connection settings back to the configuration repository as the new settings used to connect to the "exchangeStorageServer" storage system.

Storage System Name/IP : exchangeStorageServer
User : vsadmin
Port : 443
Protocol : Https

Example 5: Setting default storage system connection settings using DefaultSetting

```
PS C:\> Set-SdStorageConnectionSetting -DefaultSetting -Protocol http
-Credential vsadmin
```

In this example syntax, you use the -DefaultSetting parameter to set your protocol to HTTP, and your user name to "vsadmin".

User : vsadmin
Port : 80
Protocol : Http

Example 6: Using the default settings to establish a storage system connection

```
PS C:\> Set-SdStorageConnectionSetting -UseDefaultSetting -StorageSystem
172.17.165.33
```

In example syntax, you use the -UseDefaultSetting parameter to apply the default credentials, protocol, and port to your storage system.

Storage System Name/IP : 172.17.165.33
User : vsadmin
Port : 80
Protocol : Http

Set-SdStorageSize

Expands or shrinks the size of a Windows disk.

Syntax

```
Set-SdStorageSize [-Path] <String> [-Size] <String> [-Session]
<String> [-Host] <String>
```

Detailed Description

Expands or shrinks the size of a Windows disk.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies the drive letter or mount point of the file system you want to resize.	true	true (ByPropertyName)	
Size	Specifies the size to which you want to expand or shrink your Windows disk.	true	false	
Session	Specifies the session ID from Open-SmConnection.	false	true (ByPropertyName)	
Host	Specifies the name of the computer or host on which the SnapDrive service you want to perform the operation runs. The default is your local machine.	false	true (ByPropertyName)	

Examples

Example 1: Resizing a CSV

```
PS C:\> Set-SdStorageSize -path C:\ClusterStorage\Volume1\ -Size 1.1G
-Verbose
```

This example syntax resizes a CSV.

Example 2: Resizing a disk without a mount point

```
PS C:\> Set-SdStorageSize -Path D:\Mount -Size 10G -Shrink -Verbose
```

This example syntax resizes a drive without a mount point.

Example 3: Resize a drive

```
PS C:\> Set-SdStorageSize -Path M:\ -Size 10G -Verbose
```

This example syntax resizes a drive.

Set-SdVsphereSetting

Sets your vSphere user credentials, if vSphere is enabled.

Syntax

```
Set-SdVsphereSetting [-VsphereOrEsxHost] <String> [-Credential]  
<PSCredential> [-Session] <String> [-Host] <String>
```

Detailed Description

Sets your vSphere user credentials, if vSphere is enabled.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
VsphereOrEsxHost	Specifies your vSphere or ESX host, on which you want to set your vSphere credentials.	true	true (ByValue, ByPropertyName)	
Credential	Specifies the user name and password you want to use to access vSphere.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Start-SdVolumeCloneSplit

Starts your clone volume splitting operation.

Syntax

```
Start-SdVolumeCloneSplit [-Path] <Object[]> [-Session] <String> [-Host] <String>
```

Detailed Description

Starts your clone volume splitting operation.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
Path	Specifies the path to the clone volume you want to split.	true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	

Examples

Stop-SdVolumeCloneSplit

Stops your clone volume splitting operation.

Syntax

```
Stop-SdVolumeCloneSplit [-JobId] <String[]> [-StorageSystem] <String> [-Session] <String> [-Host] <String> [-JobId] <String[]> [-Path] <Object[]> [-Session] <String> [-Host] <String>
```

Detailed Description

Stops your clone volume splitting operation.

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
JobId		false	true (ByPropertyName)	

Name	Description	Required ?	Pipeline Input	Default Value
StorageSystem		true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host	Specifies the name or IP address of the host on which you execute the operation. The default is your local machine.	false	true (ByPropertyName)	
Path	Specifies the path to the clone volume you want to stop splitting.	true	true (ByPropertyName)	

Examples

UnMap-SdLUNS

Syntax

```
UnMap-SdLUNS [-LunPath] <String[]> [-Initiators] <String> [-RestApiURL] <String> [-Session] <String> [-Host] <String>
```

Detailed Description

Parameters

Name	Description	Required ?	Pipeline Input	Default Value
LunPath		true	true (ByValue, ByPropertyName)	
Initiators		true	true (ByPropertyName)	
RestApiURL		true	true (ByPropertyName)	
Session		false	true (ByPropertyName)	
Host		false	true (ByPropertyName)	

Examples

Copyright information

Copyright © 2025 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.