



What AutoSupport is

SnapManager Oracle

NetApp
April 15, 2021

This PDF was generated from https://docs.netapp.com/us-en/snapmanager-oracle/windows/task_adding_storage_systems_to_the_snapmanager_server_host.html on April 15, 2021. Always check docs.netapp.com for the latest.

Table of Contents

- What AutoSupport is 1
- Adding storage systems operating in clustered Data ONTAP to the SnapManager server host 1
- Enabling AutoSupport in SnapManager 1
- Disabling AutoSupport in SnapManager 2

What AutoSupport is

The AutoSupport feature enables SnapManager server to send AutoSupport messages to the storage system after the backup operation is complete.



SnapManager sends AutoSupport messages only for the successful backup operations.

You can enable or disable AutoSupport by assigning the following values to the `auto_support.on` configuration parameter in the `smo.config` configuration file:

- TRUE - Enables AutoSupport
- FALSE - Disables AutoSupport



By default, AutoSupport is enabled in SnapManager.

Related information

[Adding storage systems operating in clustered Data ONTAP to the SnapManager server host](#)

[Enabling AutoSupport in SnapManager](#)

[Disabling AutoSupport in SnapManager](#)

Adding storage systems operating in clustered Data ONTAP to the SnapManager server host

You must add the storage systems operating in clustered Data ONTAP to the SnapManager server host to enable AutoSupport. In SnapManager 3.3 and earlier, AutoSupport was supported only on storage systems operating in 7-Mode.

1. Add an Admin Storage Virtual Machine (SVM, formerly known as Vserver) and a SVM operating in clustered Data ONTAP to the SnapManager server host: `sdcli transport_protocol set -f AdminVserver_name or Vserver_name -type HTTP -user admin`

The enter the following command: message is displayed.

2. Enter the password that you provided while creating SVM.

After you run the command successfully, the New transport protocol has been set. message is displayed.

Enabling AutoSupport in SnapManager

You must enable AutoSupport, so that storage systems receive messages from the SnapManager server for every successful backup operation.

AutoSupport can be enabled in two ways:

- By default, the new installation of SnapManager does not contain the `auto_support.on` parameter in the `smo.config` configuration file. This implies that autosupport is enabled.

- You can manually configure the `auto_support.on` parameter.
 1. Stop the SnapManager server.
 2. In the `smo.config` configuration file, set the value of the `auto_support.on` parameter to `TRUE`.

```
auto_support.on=TRUE
```
 3. Restart the SnapManager server.

Disabling AutoSupport in SnapManager

You must disable AutoSupport if you do not want the storage system to receive messages from the SnapManager server for every successful backup operation.

By default, AutoSupport is enabled if the configuration file does not contain the `auto_support.on` parameter. In this scenario, you must add the `auto_support.on` parameter in the configuration file and set the value to `FALSE`.

1. Stop the SnapManager server.
2. In the `smo.config` configuration file, set the value of the `auto_support.on` parameter to `FALSE`.

```
auto_support.on=FALSE
```
3. Restart the SnapManager server.

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.