



Troubleshoot hardware installation (SG6000)

StorageGRID

NetApp
October 03, 2025

Table of Contents

- Troubleshoot hardware installation (SG6000) 1
 - View boot-up codes for SG6000-CN controller 1
 - View error codes for SG6000-CN controller 3
 - Hardware setup appears to hang (SG6000) 5
- Troubleshoot connection issues (SG6000) 6
 - Unable to connect to appliance 6
 - Expansion shelves do not appear in Appliance Installer 7
- Reboot SG6000-CN controller while StorageGRID Appliance Installer is running 8

Troubleshoot hardware installation (SG6000)

If you encounter issues during the installation, you might find it helpful to review troubleshooting information related to hardware setup and connectivity issues.

View boot-up codes for SG6000-CN controller

When you apply power to the appliance, the BMC logs a series of boot-up codes for the SG6000-CN controller. You can view these codes in several ways.

What you'll need

- You know how to access the BMC dashboard.
- If you want to use serial-over-LAN (SOL), you have experience using IPMI SOL console applications.

Steps

1. Select one of the following methods for viewing the boot-up codes for the appliance controller, and gather the required equipment.

| Method | Required equipment |
|-------------|---|
| VGA console | <ul style="list-style-type: none">• VGA-capable monitor• VGA cable |
| KVM | <ul style="list-style-type: none">• RJ-45 cable |
| Serial port | <ul style="list-style-type: none">• DB-9 serial cable• Virtual serial terminal |
| SOL | <ul style="list-style-type: none">• Virtual serial terminal |

2. If you are using a VGA console, perform these steps:
 - a. Connect a VGA-capable monitor to the VGA port on the back of the appliance.
 - b. View the codes displayed on the monitor.
3. If you are using BMC KVM, perform these steps:
 - a. Connect to the BMC management port and log into the BMC web interface.
 - b. Select **Remote Control**.
 - c. Launch the KVM.
 - d. View the codes on the virtual monitor.
4. If you are using a serial port and terminal, perform these steps:
 - a. Connect to the DB-9 serial port on the back of the appliance.
 - b. Use settings 115200 8-N-1.
 - c. View the codes printed over the serial terminal.

5. If you are using SOL, perform these steps:

a. Connect to the IPMI SOL using the BMC IP address and login credentials.



If you haven't changed the BMC root account password, the factory-default value might be "calvin".

```
ipmitool -I lanplus -H BMC_Port_IP -U root -P Password sol activate
```

b. View the codes on the virtual serial terminal.

6. Use the table to look up the codes for your appliance.

| Code | Indicates |
|------|---|
| HI | The master boot script has started. |
| HP | The system is checking to see if the network interface card (NIC) firmware needs to be updated. |
| RB | The system is rebooting after applying firmware updates. |
| FP | The hardware subsystem firmware update checks have been completed. Inter-controller communication services are starting. |
| HE | <p>For an appliance Storage Node only:</p> <p>The system is awaiting connectivity with the storage controllers and synchronizing with the SANtricity operating system.</p> <p>Note: If the boot-up procedure does not progress past this stage, perform these steps:</p> <ul style="list-style-type: none">a. Confirm that the four interconnect cables between the SG6000-CN controller and the two storage controllers are securely connected.b. As required, replace one or more of the cables, and try again.c. If this does not resolve the issue, contact technical support. |
| HC | The system is checking for existing StorageGRID installation data. |
| HO | The StorageGRID Appliance Installer is running. |
| HA | StorageGRID is running. |

View error codes for SG6000-CN controller

If a hardware error occurs when the SG6000-CN controller is booting up, the BMC logs an error code. As required, you can view these error codes using the BMC interface, and then work with technical support to resolve the issue.

What you'll need

- You know how to access the BMC dashboard.

Steps

1. From the BMC dashboard, select **BIOS POST Code**.
2. Review the information displayed for Current Code and the Previous Code.

If any of the following error codes are shown, work with technical support to resolve the issue.

| Code | Indicates |
|------|--|
| 0x0E | Microcode not found |
| 0x0F | Microcode not loaded |
| 0x50 | Memory initialization error. Invalid memory type or incompatible memory speed. |
| 0x51 | Memory initialization error. SPD reading has failed. |
| 0x52 | Memory initialization error. Invalid memory size or memory modules do not match. |
| 0x53 | Memory initialization error. No usable memory detected. |
| 0x54 | Unspecified memory initialization error |
| 0x55 | Memory not installed |
| 0x56 | Invalid CPU type or speed |
| 0x57 | CPU mismatch |
| 0x58 | CPU self-test failed, or possible CPU cache error |
| 0x59 | CPU micro-code is not found, or micro-code update failed |
| 0x5A | Internal CPU error |

| Code | Indicates |
|-------------|--|
| 0x5B | Reset PPI is not available |
| 0x5C | PEI phase BMC self-test failure |
| 0xD0 | CPU initialization error |
| 0xD1 | North bridge initialization error |
| 0xD2 | South bridge initialization error |
| 0xD3 | Some architectural protocols are not available |
| 0xD4 | PCI resource allocation error. Out of resources. |
| 0xD5 | No space for legacy option ROM |
| 0xD6 | No console output devices are found |
| 0xD7 | No console input devices are found |
| 0xD8 | Invalid password |
| 0xD9 | Error loading boot option (LoadImage returned error) |
| 0xDA | Boot option failed (StartImage returned error) |
| 0xDB | Flash update failed |
| 0xDC | Reset protocol is not available |
| 0xDD | DXE phase BMC self-test failure |
| 0xE8 | MRC: ERR_NO_MEMORY |
| 0xE9 | MRC: ERR_LT_LOCK |
| 0xEA | MRC: ERR_DDR_INIT |
| 0xEB | MRC: ERR_MEM_TEST |
| 0xEC | MRC: ERR_VENDOR_SPECIFIC |

| Code | Indicates |
|------|-----------------------------|
| 0xED | MRC: ERR_DIMM_COMPAT |
| 0xEE | MRC: ERR_MRC_COMPATIBILITY |
| 0xEF | MRC: ERR_MRC_STRUCT |
| 0xF0 | MRC: ERR_SET_VDD |
| 0xF1 | MRC: ERR_IOT_MEM_BUFFER |
| 0xF2 | MRC: ERR_RC_INTERNAL |
| 0xF3 | MRC: ERR_INVALID_REG_ACCESS |
| 0xF4 | MRC: ERR_SET_MC_FREQ |
| 0xF5 | MRC: ERR_READ_MC_FREQ |
| 0x70 | MRC: ERR_DIMM_CHANNEL |
| 0x74 | MRC: ERR_BIST_CHECK |
| 0xF6 | MRC: ERR_SMBUS |
| 0xF7 | MRC: ERR_PCU |
| 0xF8 | MRC: ERR_NGN |
| 0xF9 | MRC: ERR_INTERLEAVE_FAILURE |

Hardware setup appears to hang (SG6000)

The StorageGRID Appliance Installer might not be available if hardware faults or cabling errors prevent the storage controllers or the SG6000-CN controller from completing their boot-up processing.

Steps

1. For the storage controllers, watch the codes on the seven-segment displays.

While the hardware is initializing during power up, the two seven-segment displays show a sequence of codes. When the hardware boots successfully, both seven-segment displays show 99.

2. Review the LEDs on the SG6000-CN controller and the boot-up and error codes displayed in the BMC.

3. If you need help resolving an issue, contact technical support.

Related information

[View boot-up status codes for SG6000 storage controllers](#)

[E5700 and E2800 System Monitoring Guide](#)

[View status indicators and buttons on SG6000-CN controller](#)

[View boot-up codes for SG6000-CN controller](#)

[View error codes for SG6000-CN controller](#)

Troubleshoot connection issues (SG6000)

If you encounter connection issues during the StorageGRID appliance installation, you should perform the corrective action steps listed.

Unable to connect to appliance

If you cannot connect to the appliance, there might be a network issue, or the hardware installation might not have been completed successfully.

Steps

1. If you are unable to connect to SANtricity System Manager:
 - a. Try to ping the appliance using the IP address for either storage controller on the management network for SANtricity System Manager:
ping *Storage_Controller_IP*
 - b. If you receive no response from the ping, confirm you are using the correct IP address.

Use the IP address for management port 1 on either storage controller.
 - c. If the IP address is correct, check appliance cabling and the network setup.

If that does not resolve the issue, contact technical support.
 - d. If the ping was successful, open a web browser.
 - e. Enter the URL for SANtricity System Manager:
https://*Storage_Controller_IP*

The log in page for SANtricity System Manager appears.
2. If you are unable to connect to the SG6000-CN controller:
 - a. Try to ping the appliance using the IP address for the SG6000-CN controller:
ping *SG6000-CN_Controller_IP*
 - b. If you receive no response from the ping, confirm you are using the correct IP address.

You can use the IP address of the appliance on the Grid Network, the Admin Network, or the Client Network.

- c. If the IP address is correct, check appliance cabling, SFP transceivers, and the network setup.
- d. If physical access to the SG6000-CN is available, you can use a direct connection to the permanent link-local IP 169.254.0.1 to check controller networking configuration and update if necessary. For detailed instructions, see step 2 in [Accessing StorageGRID Appliance Installer](#).

If that does not resolve the issue, contact technical support.

- e. If the ping was successful, open a web browser.
- f. Enter the URL for the StorageGRID Appliance Installer:
https://SG6000-CN_Controller_IP:8443

The Home page appears.

Expansion shelves do not appear in Appliance Installer

If you have installed expansion shelves for the SG6060 or SG6060X and they do not appear in the StorageGRID Appliance Installer, you should verify that the shelves have been completely installed and powered on.

About this task

You can verify that the expansion shelves are connected to the appliance by viewing the following information in the StorageGRID Appliance Installer:

- The **Home** page contains a message about expansion shelves.



i The storage system contains 2 expansion shelves.

- The **Advanced > RAID Mode** page indicates by number of drives whether or not the appliance includes expansion shelves. For example, in the following screen shot, two SSDs and 178 HDDs are shown. An SG6060 with two expansion shelves contains 180 total drives.

Configure RAID Mode

This appliance contains the following drives.

| Type | Size | Number of drives |
|------|---------|------------------|
| SSD | 800 GB | 2 |
| HDD | 11.8 TB | 178 |

If the StorageGRID Appliance Installer pages do not indicate that expansion shelves are present, follow this procedure.

Steps

1. Verify that [all required cables have been firmly connected](#).
2. Verify that you have [powered on the expansion shelves](#).
3. If you need help resolving an issue, contact technical support.

Reboot SG6000-CN controller while StorageGRID Appliance Installer is running


You might need to reboot the SG6000-CN controller while the StorageGRID Appliance Installer is running. For example, you might need to reboot the controller if the installation fails.

About this task

This procedure only applies when the SG6000-CN controller is running the StorageGRID Appliance Installer. Once the installation is completed, this step no longer works because the StorageGRID Appliance Installer is no longer available.

Steps

1. From the StorageGRID Appliance Installer, click **Advanced > Reboot Controller**, and then select one of these options:
 - Select **Reboot into StorageGRID** to reboot the controller with the node rejoining the grid. Select this option if you are done working in maintenance mode and are ready to return the node to normal operation.
 - Select **Reboot into Maintenance Mode** to reboot the controller with the node remaining in maintenance mode. (This option is available only when the controller is in maintenance mode.) Select this option if there are additional maintenance operations you need to perform on the node before rejoining the grid.



The SG6000-CN controller is rebooted.

Copyright information

Copyright © 2025 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.