



# **Hardware maintenance procedures**

## StorageGRID appliances

NetApp  
December 09, 2025

This PDF was generated from <https://docs.netapp.com/us-en/storagegrid-appliances/sg6100/verify-component-to-replace.html> on December 09, 2025. Always check [docs.netapp.com](https://docs.netapp.com) for the latest.

# Table of Contents

Hardware maintenance procedures .....	1
Verify component to replace in the SGF6112 or SG6100-CN .....	1
Replace fan .....	2
Replace fan in an SGF6112 or SG6100-CN (SG6160) .....	3
Replace fan canister in storage controller shelf or expansion shelf (SG6160) .....	8
Replace power supply .....	10
Replace one or both power supplies in the SGF6112 or SG6100-CN .....	10
Replace power canister in storage controller shelf or expansion shelf (SG6160) .....	12
Replace drive .....	15
Replace drives in the SGF6112 .....	15
Replace drive in SG6100-CN .....	17
Replace drive in storage controller shelf or expansion shelf (SG6160) .....	19
Replace NIC .....	22
Replace internal NIC in the SGF6112 or SG6100-CN .....	22
Replace external NIC in the SG6100-CN .....	29
Replace SGF6112 or SG6100-CN CMOS battery .....	31
Remove the CMOS battery .....	31
Reinstall the CMOS battery .....	33
Replace DIMMs in storage controller shelf (SG6160) .....	36
Step 1: Determine if you need to replace a DIMM .....	36
Step 2: Place controller offline .....	36
Step 3: Remove controller canister .....	37
Step 4: Replace the DIMMs .....	38
Step 5: Reinstall the controller canister .....	40
Step 6: Complete DIMMs replacement .....	41
Replace battery in storage controller shelf (SG6160) .....	41
Step 1: Prepare to replace battery .....	42
Step 2: Remove E4000 controller canister .....	43
Step 3: Install the new battery .....	44
Step 4: Reinstall the controller canister .....	45
Step 5: Complete battery replacement .....	46
Replace SGF6112 or SG6100-CN cover .....	47
Remove cover .....	47
Reinstall cover .....	48
Add expansion shelf to deployed SG6160 .....	48
Replace appliance .....	52
Replace SGF6112 appliance .....	52
Replace SG6100-CN controller .....	56
Replace E4000 storage controller (SG6160) .....	58
Relocate SGF6112 or SG6100-CN in cabinet or rack .....	65
Remove SGF6112 or SG6100-CN from cabinet or rack .....	65
Reinstall SGF6112 or SG6100-CN into cabinet or rack .....	66

# Hardware maintenance procedures

## Verify component to replace in the SGF6112 or SG6100-CN

If you are unsure which hardware component to replace in your appliance, complete this procedure to identify the component and the location of the appliance in the data center.

### Before you begin

- You have the serial number of the storage appliance where the component needs to be replaced.
- You are signed in to the Grid Manager using a [supported web browser](#).

### About this task

Use this procedure to identify the appliance with failed hardware and which of the replaceable hardware components is not operating properly. Components that might be identified for replacement can include:

- Power supplies
- Fans
- Solid state drives (SSDs)
- Network Interface Cards (NICs)
- CMOS battery

### Steps

1. Identify the failed component and the name of the appliance that it is installed in.

a. In Grid Manager, Select **ALERTS > Current**.

The Alerts page appears.

b. Select the alert to see the alert details.



Select the alert, not the heading for a group of alerts.

c. Record the node name and unique identifying label of the component that has failed.

# Appliance NIC fault detected

A problem with a network interface card (NIC) in the appliance was detected.

## Recommended actions

1. Reseat the NIC. Refer to the instructions for your appliance.
2. If necessary, replace the NIC. See the maintenance instructions for your appliance.

## Time triggered

2023-02-17 13:36:31 EST (2023-02-17 18:36:31 UTC)

Status  
Active (silence this alert 

Site / Node  
Data Center 1  SGF6112-032-X6606A

Severity  
 Critical

Description  
ConnectX-6 Lx EN adapter card,  
25GbE, Dual-port SFP28, PCIe 4.0 x8,  
No Crypto

Firmware Version  
26.33.1048 (MT\_0000000531)

Device  
hic3

Part number  
X1153A

2. Identify the chassis with the component that needs to be replaced.
  - a. From the Grid Manager, select **NODES**.
  - b. From the table on the Nodes page, select the appliance Storage Node name with the failed component.
  - c. Select the **Hardware** tab.

Check the **Compute controller serial number** in the StorageGRID Appliance section. Check if the serial number matches the serial number of the storage appliance where you are replacing the component. If the serial number matches, you have found the correct appliance.

- If the StorageGRID Appliance section in Grid Manager does not display, the node selected is not a StorageGRID appliance. Select a different node from the tree view.
- If the serial numbers don't match, select a different node from the tree view.

3. After you locate the node where the component needs to be replaced, write down the appliance BMC IP address listed the StorageGRID Appliance section.

To help you locate the appliance in the data center, you can use the BMC IP address to turn on the appliance identify LED.

## Related information

[Turn on the appliance identify LED](#)

# Replace fan

## Replace fan in an SGF6112 or SG6100-CN (SG6160)

The SGF6112 appliance and SG6100-CN controller have eight cooling fans. If one of the fans fails, you must replace it as soon as possible to ensure that the appliance has proper cooling.

### Before you begin

- You have the correct replacement fan.
- You have [determined the location of the fan to replace](#).
- You have [physically located the SGF6112 appliance or SG6100-CN controller](#) where you are replacing the fan in the data center.



A [controlled shutdown of the appliance](#) is required before removing the appliance from the rack.

- You have disconnected all cables and [removed the appliance cover](#).
- You have confirmed that the other fans are installed and running.

### About this task

To prevent service interruptions, confirm that all other Storage Nodes are connected to the grid before starting the fan replacement or replace the fan during a scheduled maintenance window when periods of service disruption are acceptable. See the information about [monitoring node connection states](#).




If you have ever used an ILM rule that creates only one copy of an object, you must replace the fan during a scheduled maintenance window because you might temporarily lose access to those objects during this procedure. See information about [why you should not use single-copy replication](#).

The appliance node will not be accessible while you replace the fan.

The image shows a fan for the appliance with the electrical connector highlighted. The cooling fans are accessible after you take the top cover off of the appliance.




Each of the two power supply units also contain a fan. The power supply fans aren't included in this procedure.



## Steps

1. Wrap the strap end of the ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
2. Locate the fan that you need to replace.


The eight fans are in the following positions in the chassis (front half of StorageGRID appliance with top cover removed shown):



Front

	Fan unit
1	Fan_SYS0
2	Fan_SYS1
3	Fan_SYS2
4	Fan_SYS3
5	Fan_SYS4
6	Fan_SYS5
7	Fan_SYS6
8	Fan_SYS7


3. Using the blue tabs on the fan, lift the failed fan out of the chassis.



4. Slide the replacement fan into the open slot in the chassis.

Align the connector on the fan with the socket in the circuit board.

5. Press the fan's connector firmly into the circuit board (socket highlighted).



#### After you finish

1. [Put the top cover back on the appliance](#), and press the latch down to secure the cover in place.
2. [Power on the appliance](#) and monitor the appliance LEDs and boot-up codes.

Use the BMC interface to monitor boot-up status.

3. Confirm that the appliance node appears in the Grid Manager and that no alerts appear.

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return & Replacements](#) page for further information.

## Replace fan canister in storage controller shelf or expansion shelf (SG6160)

You can replace a fan canister in an SG6160.

### About this task

Each 60-drive controller shelf or drive shelf includes two fan canisters. If a fan canister fails, you must replace it as soon as possible to ensure that the shelf has adequate cooling.



**Possible equipment damage** — If you perform this procedure with the power turned on, you must complete it within 30 minutes to prevent the possibility of overheating the equipment.

### Before you begin

- Navigate to the SANtricity System Manager tab of the Nodes page for the node(s) listed in the alert that notified you of the fan failure. Using the SANtricity UI presented on this tab, review the details in the Recovery Guru to confirm that there is an issue with the fan canister and select **Recheck** from the Recovery Guru to ensure no other items must be addressed first.
- Check that the amber Attention LED on the fan canister is on, indicating that the fan has a fault. Contact technical support for assistance if both fan canisters in the appliance have their amber Attention LEDs on.
- Make sure you have the following:
  - A replacement fan canister (fan) that is supported for your appliance model.
  - An ESD wristband, or you have taken other antistatic precautions.

### Step 1: Prepare to replace fan canister

Prepare to replace a fan canister by collecting support data about your appliance and locating the failed component.

#### Steps

1. Collect support data for your storage array using SANtricity System Manager.
  - a. Select **Support Center > Diagnostics**.
  - b. Select **Collect Support Data**.
  - c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, **support-data.7z**.

2. From SANtricity System Manager, determine which fan canister has failed.
  - a. Select **Hardware**.
  - b. Look at the fan  icon to the right of the **Shelf** drop-down lists to determine which appliance has the failed fan canister.

If a component has failed, this icon is red.

- c. When you find the appliance with a red icon, select **Show back of shelf**.
- d. Select either fan canister or the red fan icon.
- e. On the **Fans** tab, look at the statuses of the fan canisters to determine which fan canister must be replaced.

A component with a **Failed** status must be replaced.



If the second fan canister in the appliance does not have **Optimal** status, do not attempt to hot-swap the failed fan canister. Instead, contact technical support for assistance.

You can also find information about the failed fan canister in the Details area of the Recovery Guru, or you can review the Event Log under Support and filter by Component Type.

3. From the back of the storage array, look at the Attention LEDs to locate the fan canister you need to remove.

You must replace the fan canister that has its Attention LED on.

## Step 2: Remove failed fan canister and install new one

Remove a failed fan canister so you can replace it with a new one.



If you do not turn off the power to your storage array, ensure that you remove and replace the fan canister within 30 minutes to prevent the system from overheating.

### Steps

1. Unpack the new fan canister, and place it on a level surface near the appliance.

Save all packing material for use when returning the failed fan.

2. Press the orange tab to release the fan canister handle.
3. Use the fan canister handle to pull the fan canister out of the appliance.
4. Slide the replacement fan canister all the way into the appliance, and then move the fan canister handle until it latches with the orange tab.

## Step 3: Complete fan canister replacement

Confirm that the new fan canister is working correctly, gather support data, and resume normal operations.

### Steps

1. Check the amber Attention LED on the new fan canister.



After you replace the fan canister, the Attention LED stays on (solid amber) while the firmware checks that the fan canister was installed correctly. The LED goes off after this process is complete.

2. From the Recovery Guru in SANtricity System Manager, select **Recheck** to ensure the problem has been resolved.
3. If a failed fan canister is still being reported, repeat the steps in [Step 2: Remove failed fan canister and install new one](#). If the problem persists, contact technical support.

4. Remove the antistatic protection.
5. Collect support data for your storage array using SANtricity System Manager.
  - a. Select **Support Center > Diagnostics**.
  - b. Select **Collect Support Data**.
  - c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, **support-data.7z**.

6. Return the failed part to NetApp, as described in the RMA instructions shipped with the kit.

#### What's next?

Your fan canister replacement is complete. You can resume normal operations.

## Replace power supply

### Replace one or both power supplies in the SGF6112 or SG6100-CN

The SGF6112 appliance and SG6100-CN compute node have two power supplies for redundancy. If one of the power supplies fails, you must replace it as soon as possible to ensure that the appliance has redundant power. Both power supplies operating in the appliance must be of the same model and wattage.

#### Before you begin

- You have [physically located the appliance](#) with the power supply to be replaced.
- You have [determined the location of the power supply to replace](#).
- If you are replacing only one power supply:
  - You have unpacked the replacement power supply unit and ensured that it is the same model and wattage as the power supply unit you are replacing.
  - You have confirmed that the other power supply is installed and running.
- If you are replacing both power supplies at the same time:
  - You have unpacked the replacement power supply units and ensured they are the same model and wattage.

#### About this task

The figure shows the two power supply units for the SGF6112 appliance or SG6100-CN compute node. The power supplies are accessible from the back of the appliance.



#### Steps

1. If you are replacing only one power supply, you don't need to shut down the appliance. Go to the [Unplug the power cord](#) step. If you are replacing both power supplies at the same time, do the following before unplugging the power cords:

a. Shut down the appliance.




If you have ever used an ILM rule that creates only one copy of an object and you are replacing both power supplies at the same time, you must replace the power supplies during a scheduled maintenance window because you might temporarily lose access to those objects during this procedure. See information about [why you should not use single-copy replication](#).


2. Unplug the power cord from each power supply to be replaced.

When viewed from the rear of the appliance, power supply A (PSU0) is on the right and power supply B (PSU1) is on the left.

3. Lift the handle on the first supply to be replaced.



4. Press the blue latch and pull the power supply out.




5. With the blue latch on the right, slide the replacement power supply into the chassis.



Both installed power supplies must be the same model and wattage.

Ensure that the blue latch is on the right side when you slide the replacement unit in.

You will feel a click when the power supply is locked into place.



6. Push the handle back down against the body of the PSU.
7. If you are replacing both power supplies, repeat steps 2 through 6 to replace the second power supply.
8. [Connect the power cords to the replaced units and apply power.](#)

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return & Replacements](#) page for further information.

## Replace power canister in storage controller shelf or expansion shelf (SG6160)

You can replace a power canister in an SG6160 storage controller shelf or expansion shelf (DE460C).

### About this task

Each 60-drive controller shelf or drive shelf includes two power canisters for power redundancy. If a power canister fails, you must replace it as soon as possible to ensure that the shelf has a redundant power source.

You can replace a power canister while your storage array is powered on and performing host I/O operations, as long as the second power canister in the shelf has an Optimal status and the **OK to remove** field in the Details area of the Recovery Guru in SANtricity System Manager displays **Yes**.

While you perform this task, the other power canister supplies power to both fans to ensure that the equipment does not overheat.

### Before you begin

- Navigate to the SANtricity System Manager tab of the Nodes page for the node(s) listed in the alert that notified you of the PSU failure. Using the SANtricity UI presented on this tab, review the details in the Recovery Guru to confirm that there is an issue with the power canister and select **Recheck** from the Recovery Guru to ensure no other items must be addressed first.
- Check that the amber Attention LED on the power canister is on, indicating that the canister has a fault. Contact technical support for assistance if both power canisters in the shelf have their amber Attention

LEDs on.

- Make sure you have the following:
  - A replacement power canister that is supported for your controller shelf or drive shelf model.
  - An ESD wristband, or you have taken other antistatic precautions.

## Step 1: Prepare to replace power canister

Prepare to replace a power canister in a 60-drive controller shelf or drive shelf.

### Steps

1. Collect support data for your storage array using SANtricity System Manager.
  - a. Select **Support** > **Support Center** > **Diagnostics**.
  - b. Select **Collect Support Data**.
  - c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, **support-data.7z**.
2. From SANtricity System Manager, determine which power canister has failed.
  - a. Select **Hardware**.
  - b. Look at the power  icon to the right of the **Shelf** drop-down lists to determine which shelf has the failed power canister.

If a component has failed, this icon is red.
  - c. When you find the shelf with a red icon, select **Show back of shelf**.
  - d. Select either power canister or the red power icon.
  - e. On the **Power Supplies** tab, look at the statuses of the power canisters to determine which power canister must be replaced.

A component with a **Failed** status must be replaced.



If the second power canister in the shelf does not have **Optimal** status, do not attempt to hot-swap the failed power canister. Instead, contact technical support for assistance.



You can also find information about the failed power canister in the Details area of the Recovery Guru, or you can review the information displayed for the shelf, or you can review the Event Log under Support and filter by Component Type.

3. From the back of the storage array, look at the Attention LEDs to locate the power canister you need to remove.

You must replace the power canister that has its Attention LED on.

## Step 2: Remove failed power canister

Remove a failed power canister so you can replace it with a new one.

### Steps

1. Put on antistatic protection.
2. Unpack the new power canister, and set it on a level surface near the shelf.

Save all packing materials for use when returning the failed power canister.

3. Turn off the power switch on the power canister that you need to remove.
4. Open the power cord retainer of the power canister that you need to remove, and then unplug the power cord from the power canister.
5. Press the orange latch on the power canister cam handle, and then open the cam handle to fully release the power canister from the mid plane.
6. Use the cam handle to slide the power canister out of the shelf.



When removing a power canister, always use two hands to support its weight.

### Step 3: Install new power canister

Install a new power canister to replace the failed one.

#### Steps

1. Make sure the on/off switch of the new power canister is in the Off position.
2. Using both hands, support and align the edges of the power canister with the opening in the system chassis, and then gently push the power canister into the chassis using the cam handle until it locks into place.

Do not use excessive force when sliding the power canister into the system; you can damage the connector.

3. Close the cam handle so that the latch clicks into the locked position and the power canister is fully seated.
4. Reconnect the power cord to the power canister, and secure the power cord to the power canister using the power cord retainer.
5. Turn on the power to the new power canister.

### Step 4: Complete power canister replacement

Confirm that the new power canister is working correctly, gather support data, and resume normal operations.

#### Steps

1. On the new power canister, check that the green Power LED is on and the amber Attention LED is OFF.
2. From the Recovery Guru in SANtricity System Manager, select **Recheck** to ensure the problem has been resolved.
3. If a failed power canister is still being reported, repeat the steps in [Step 2: Remove failed power canister](#) and in [Step 3: Install new power canister](#). If the problem continues to persist, contact technical support.
4. Remove the antistatic protection.
5. Collect support data for your storage array using SANtricity System Manager.
  - a. Select **Support > Support Center > Diagnostics**.
  - b. Select **Collect Support Data**.

c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, **support-data.7z**.

6. Return the failed part to NetApp, as described in the RMA instructions shipped with the kit.

**What's next?**

Your power canister replacement is complete. You can resume normal operations.

## Replace drive

### Replace drives in the SGF6112

The SGF6112 storage appliance contains 12 SSD drives. Data on the drives is protected by a RAID scheme that enables the appliance to recover from any single drive failure without having to copy data from another node.

The failure of a second drive before an initial drive failure has been corrected might require data be copied from other nodes to restore redundancy. This restoration of redundancy can take longer, and might be impossible, if single-copy ILM rules are in use or were used in the past, or if data redundancy has been impacted by failures on other nodes. Therefore, if one of the SGF6112 drives fails, you must replace it as soon as possible to ensure redundancy.

#### Before you begin

- You have [physically located the appliance](#).
- You have verified which drive has failed by noting that the drive's left LED is solid amber or using the Grid Manager to [view the alert caused by the failed drive](#).




See the information about viewing status indicators to verify the failure.

- You have obtained the replacement drive.
- You have obtained proper ESD protection.

#### Steps

1. Verify that the drive's left fault LED is amber or use the drive slot ID from the alert to locate the drive.

The twelve drives are in the following positions in the chassis (front of chassis with bezel removed shown):




Position	Drive
1	HDD00
2	HDD01
3	HDD02
4	HDD03
5	HDD04
6	HDD05
7	HDD06
8	HDD07
9	HDD08
10	HDD09
11	HDD10
12	HDD11

You can also use the Grid Manager to monitor the status of the SSD drives. Select **NODES**. Then select **Storage Node > Hardware**. If a drive has failed, the Storage RAID Mode field contains a message about which drive has failed.

2. Wrap the strap end of the ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
3. Unpack the replacement drive, and set it on a static-free, level surface near the appliance.

Save all packing materials.


4. Press the release button on the failed drive.



The handle on the drive springs open partially, and the drive releases from the slot.

5. Open the handle, slide the drive out, and place it on a static-free, level surface.
6. Press the release button on the replacement drive before you insert it into the drive slot.

The latch springs open.



7. Insert the replacement drive in the slot, and then close the drive handle.



Don't use excessive force while closing the handle.

When the drive is fully inserted, you hear a click.

The replaced drive is automatically rebuilt with mirrored data from the working drives. The drive LED should blink initially, but then stop blinking as soon as the system determines that the drive has enough capacity and is functional.

You can check the status of the rebuild by using the Grid Manager.

8. If more than one drive failed and has been replaced, you might have alerts indicating that some volumes need to have data restored to them. If you receive an alert, before attempting volume recovery, select **NODES > appliance Storage Node > Hardware**. In the StorageGRID Appliance section of the page, verify that the Storage RAID mode is healthy or rebuilding. If the status lists one or more failed drives, correct this condition before attempting volume restoration.
9. In the Grid Manager, go to **NODES > appliance Storage Node > Hardware**. In the StorageGRID Appliance section of the page, verify that the Storage RAID mode is healthy.

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return & Replacements](#) page for further information.

## Replace drive in SG6100-CN

The SG6160 appliance contains two SSD drives in the SG6100-CN controller which function as a read cache. If one of these drives fails, you must replace it as soon as possible to minimize the potential performance impact.

### Before you begin

- You have [physically located the appliance](#).
- You have verified which drive has failed by noting that its left LED is solid amber or using Grid Manager to [view the alert caused by the failed drive](#).
- You have obtained the replacement drive.
- You have obtained proper ESD protection.

## Steps

1. Verify that the drive's left fault LED is amber or use the drive slot ID from the alert to locate the drive.


The drives are in the following positions in the chassis (front of chassis with bezel removed shown).



2. Wrap the strap end of the ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
3. Unpack the replacement drive, and set it on a static-free, level surface near the appliance.

Save all packing materials.


4. Press the release button on the failed drive.



The handle on the drive springs open partially, and the drive releases from the slot.

5. Open the handle, slide the drive out, and place it on a static-free, level surface.
6. Press the release button on the replacement drive before you insert it into the drive slot.

The latch springs open.



7. Insert the replacement drive in the slot, and then close the drive handle.



Don't use excessive force while closing the handle.

When the drive is fully inserted, you hear a click.

When both SSD drives are functioning normally, the system will automatically restore read-cache functionality. You can [run diagnostics](#) to monitor the read-cache hit rate. Since the cache was just rebuilt, the hit rate might be low initially but should increase over time as the cache is repopulated by clients

accessing object data.

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return & Replacements](#) page for further information.

## Replace drive in storage controller shelf or expansion shelf (SG6160)

You can replace a drive in an SG6160 storage controller shelf or expansion shelf (DE460C).

### About this task

StorageGRID Grid Manager monitors storage array status and raises alerts when drive failures occur. When Grid Manager raises an alert, or at any time, you can use the Recovery Guru in SANtricity System Manager to get more information about the specific drive that has failed. When a drive has failed, its amber Attention LED is on. You can hot-swap a failed drive while the storage array is receiving I/O.

### Before you begin

- Review the drive handling requirements.
- Make sure you have the following:
  - A replacement drive that is supported by NetApp for your controller shelf or drive shelf.
  - An ESD wristband, or you have taken other antistatic precautions.
  - Access to SANtricity System Manager:
    - From Grid Manager, select **NODES > appliance node > SANtricity System Manager**. Controller information is on the [SANtricity System Manager tab](#).
    - Point a browser in your management station to the controller's domain name or IP address.

### Step 1: Prepare to replace drive

Prepare to replace a drive by checking the Recovery Guru in SANtricity System Manager and completing any prerequisite steps. Then, you can locate the failed component.

#### Steps

1. If the Recovery Guru in SANtricity System Manager has notified you of an *impending drive failure*, but the drive has not yet failed, follow the instructions in the Recovery Guru to fail the drive.
2. If needed, use SANtricity System Manager to confirm you have a suitable replacement drive.
  - a. Select **Hardware**.
  - b. Select the failed drive on the shelf graphic.
  - c. Click the drive to display its context menu, and then select **View settings**.
  - d. Confirm that the replacement drive has a capacity equal to or greater than the drive you are replacing and that it has the features you expect.
3. If needed, use SANtricity System Manager to locate the drive within the storage array.
  - a. If the shelf has a bezel, remove it so you can see the LEDs.
  - b. From the drive's context menu, select **Turn on locator light**.

The drive drawer's Attention LED (amber) blinks so you can open the correct drive drawer to identify which drive to replace.

4. Unlatch the drive drawer by pulling on both levers.
  - a. Using the extended levers, carefully pull the drive drawer out until it stops.
  - b. Look at the top of the drive drawer to find the Attention LED in front of each drive.

The drive drawer Attention LEDs are on the left side in front of each drive, with an attention icon on the drive handle just behind the LED.

## Step 2: Remove failed drive

Remove a failed drive to replace it with a new one.

### Steps

1. Unpack the replacement drive, and set it on a flat, static-free surface near the shelf.

Save all packing materials for the next time you need to send a drive back.

2. Release the drive drawer levers from the center of the appropriate drive drawer by pulling both towards the sides of the drawer.
3. Carefully pull on the extended drive drawer levers to pull out the drive drawer to its full extension without removing it from the enclosure.
4. Gently pull back the orange release latch that is in front of the drive you want to remove.

The cam handle on the drive springs open partially, and the drive is released from the drawer.

5. Open the cam handle, and lift out the drive slightly.
6. Wait 30 seconds.
7. Use the cam handle to lift the drive from the shelf.
8. Place the drive on an antistatic, cushioned surface away from magnetic fields.
9. Wait 30 seconds for the software to recognize that the drive has been removed.



If you accidentally remove an active drive, wait at least 30 seconds, and then reinstall it. For the recovery procedure, refer to the storage management software.

## Step 3: Install new drive

Install a new drive to replace the failed one.



Install the replacement drive as soon as possible after removing the failed drive. Otherwise, there is a risk that the equipment might overheat.



**Possible loss of data access** — When pushing the drive drawer back into the enclosure, never slam the drawer shut. Push the drawer in slowly to avoid jarring the drawer and causing damage to the storage array.

### Steps

1. Raise the cam handle on the new drive to vertical.
2. Align the two raised buttons on each side of the drive carrier with the matching gap in the drive channel on the drive drawer.

3. Lower the drive straight down, and then rotate the cam handle down until the drive snaps into place under the orange release latch.
4. Carefully push the drive drawer back into the enclosure. Push the drawer in slowly to avoid jarring the drawer and causing damage to the storage array.
5. Close the drive drawer by pushing both levers towards the center.

The green Activity LED for the replaced drive on the front of the drive drawer comes on when the drive is inserted correctly.

Depending on your configuration, the controller might automatically reconstruct data to the new drive. If the shelf uses hot spare drives, the controller might need to perform a complete reconstruction on the hot spare before it can copy the data to the replaced drive. This reconstruction process increases the time that is required to complete this procedure.

## Step 4: Complete drive replacement

Confirm that the new drive is working correctly.

### Steps

1. Check the Power LED and the Attention LED on the drive you replaced. (When you first insert a drive, its Attention LED might be on. However, the LED should go off within a minute.)
  - Power LED is on or blinking, and the Attention LED is off: Indicates that the new drive is working correctly.
  - Power LED is off: Indicates that the drive might not be installed correctly. Remove the drive, wait 30 seconds, and then reinstall it.
  - Attention LED is on: Indicates that the new drive might be defective. Replace it with another new drive.
2. If the Recovery Guru in SANtricity System Manager still shows an issue, select **Recheck** to ensure the problem has been resolved.
3. If the Recovery Guru indicates that drive reconstruction did not start automatically, start reconstruction manually, as follows:



Perform this operation only when instructed to do so by technical support or the Recovery Guru.

- a. Select **Hardware**.
- b. Click the drive that you replaced.
- c. From the drive's context menu, select **Reconstruct**.
- d. Confirm that you want to perform this operation.

When the drive reconstruction completes, the volume group is in an Optimal state.

4. As required, reinstall the bezel.
5. Return the failed part to NetApp, as described in the RMA instructions shipped with the kit.

### What's next?

Your drive replacement is complete. You can resume normal operations.

# Replace NIC

## Replace internal NIC in the SGF6112 or SG6100-CN

You might need to replace an internal Network Interface Card (NIC) in the SGF6112 or SG6100-CN if it is not functioning optimally or if it has failed.

Use these procedures to:

- Remove the NIC
- Reinstall the NIC

### Remove the internal NIC

#### Before you begin

- You have the correct replacement NIC.
- You have determined the [location of the NIC to replace](#).
- You have [physically located the SGF6112 appliance or SG6100-CN controller](#) where you are replacing the NIC in the data center.



A [controlled shutdown of the appliance](#) is required before removing the appliance from the rack.

- You have disconnected all cables and [removed the appliance cover](#).

#### About this task

To prevent service interruptions, confirm that all other Storage Nodes are connected to the grid before starting the Network Interface Card (NIC) replacement or replace the NIC during a scheduled maintenance window when periods of service disruption are acceptable. See the information about [monitoring node connection states](#).




If you have ever used an ILM rule that creates only one copy of an object, you must replace the NIC during a scheduled maintenance window because you might temporarily lose access to those objects during this procedure. See information about [why you should not use single-copy replication](#).

#### Steps


1. Wrap the strap end of the ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
2. Locate the riser assembly that contains the NIC at the rear of the appliance.

The three NICs in the appliance are in two riser assemblies in the positions in the chassis shown in the photograph (Rear of appliance with top cover removed shown):



	Device or Part name	Description
1	hic1/hic2	10/25-GbE Ethernet network ports in the two-port riser assembly
2	mtc1/mtc2	1/10GBase-T management ports in the two-port riser assembly
3	hic3/hic4	10/25-GbE Ethernet network ports in the one-port riser assembly
4	Two-slot riser assembly	Support for one of the 10/25-GbE NICs and the 1/10GBase-T NIC
5	One-slot riser assembly	Support for one of the 10/25-GbE NICs

3. Grasp the riser assembly with the failed NIC through the blue-marked holes and carefully lift it upwards. Move the riser assembly toward the front of the chassis as you lift it to allow the external connectors in its installed NICs to clear the chassis.
4. Place the riser on a flat anti-static surface with the metal frame side down to access the NICs.
  - **Two-slot riser assembly with two NICs**



- One-slot riser assembly with one NIC



5. Open the blue latch (circled) on the NIC to be replaced and carefully remove the NIC from the riser assembly. Rock the NIC slightly to help remove the NIC from its connector. Don't use excessive force.
6. Place the NIC on a flat anti-static surface.

## Reinstall the internal NIC


Install the replacement NIC into the same location as the one that was removed.

### Before you begin


- You have the correct replacement NIC.
- You have removed the existing failed NIC.

### Steps

1. Wrap the strap end of the ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
2. Remove the replacement NIC from its packaging.
3. If you are replacing one of the NICs in the two-slot riser assembly, do the following:
  - a. Ensure the blue latch is in the open position.
  - b. Align the NIC with its connector on the riser assembly. Carefully press the NIC into the connector until it is fully seated, as shown in the photograph, and then close the blue latch.



c. Locate the alignment hole on the two-slot riser assembly (circled) that aligns with a guide pin on the system board to ensure correct riser assembly positioning.



d. Locate the guide pin on the system board




- e. Position the riser assembly in the chassis, making sure that it aligns with the connector on the system board and guide pin.
- f. Carefully press the two-slot riser assembly in place along its center line, next to the blue-marked holes, until it is fully seated.

4. If you are replacing the NIC in the one-slot riser assembly, do the following:


- a. Ensure the blue latch is in the open position.
- b. Align the NIC with its connector on the riser assembly. Carefully press the NIC into the connector until it is fully seated as shown in the photograph and close the blue latch.



c. Locate the alignment hole on the one-slot riser assembly (circled) that aligns with a guide pin on the system board to ensure correct riser assembly positioning.



d. Locate the guide pin on the system board



- e. Position the one-slot riser assembly in the chassis, making sure that it aligns with the connector on the system board and guide pin.
- f. Carefully press the one-slot riser assembly in place along its center line, next to the blue-marked holes, until it is fully seated.

5. Remove the protective caps from the NIC ports where you will be reinstalling cables.

#### After you finish

If you have no other maintenance procedures to perform in the appliance, reinstall the appliance cover, return the appliance to the rack, attach cables, and apply power.

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return & Replacements](#) page for further information.

## Replace external NIC in the SG6100-CN

You might need to replace an external Network Interface Card (NIC) in the SG6100-CN if it is not functioning optimally or if it has failed.

Use these procedures to:

- Remove the NIC
- Reinstall the NIC

#### Before you begin

- You have the correct replacement NIC.
- You have determined the [location of the NIC to replace](#).



- You have [physically located the SG6100-CN controller](#) where you are replacing the NIC in the data center.



Hot-swapping is **not** supported for this procedure. A [controlled shutdown of the appliance](#) is required before disconnecting cables and removing the NIC.

- You have disconnected all cables, including the two power cords on the SG6100-CN.
- **Optional:** You have removed the controller from the rack if required by local regulations. Removal is not required as the the NIC is externally accessible.

## About this task

To prevent service interruptions, confirm that all other Storage Nodes are connected to the grid before started the Network Interface Card (NIC) replacement or replace the NIC during a scheduled maintenance window when periods of service disruption are acceptable. See information about [monitoring node connection states](#).



If you have ever used an ILM rule that creates only one copy of an object, you must replace the NIC during a scheduled maintenance window because you might temporarily lose access to those objects during this procedure. See information about [why you should not use single-copy replication](#).

## Remove the external NIC

### Steps

1. Wrap the strap end of an ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
2. Use a screwdriver to loosen the screw on the faceplate of the NIC.



Hot-swapping is **not** supported for this procedure. The controller must be disconnected from power before removing the NIC.

3. Carefully remove the NIC by pulling on the faceplate handle. Place the NIC on a flat, anti-static surface.

## Reinstall the external NIC

### Steps

1. Wrap the strap end of an ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
2. Remove the replacement NIC from its packaging.
3. Align the NIC with the opening in the chassis and carefully push it in until fully seated.
4. Tighten the screw on the faceplate of the NIC.

## After you finish

If you have no other maintenance procedures to perform in the appliance, return the appliance to the rack if it was removed, attach cables, and apply power.

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the

kit. See the [Part Return & Replacements](#) page for further information.

## Replace SGF6112 or SG6100-CN CMOS battery

Use this procedure to replace the CMOS coin cell battery on the system board.

Use these procedures to:

- Remove the CMOS battery
- Reinstall the CMOS battery

### Remove the CMOS battery

#### Before you begin

- You have [verified the appliance where the CMOS battery needs to be replaced](#).
- You have [physically located the SGF6112 appliance or SG6100-CN controller](#) where you are replacing the CMOS battery in the data center.
- You have recorded the current BMC configuration of the appliance, if it remains available.
  1. Log in to the appliance to be replaced:
    - a. Enter the following command: `ssh admin@grid_node_IP`
    - b. Enter the password listed in the `Passwords.txt` file.
    - c. Enter the following command to switch to root: `su -`
    - d. Enter the password listed in the `Passwords.txt` file.

When you are logged in as root, the prompt changes from `$` to `#`.

2. Enter: `run-host-command ipmitool lan print` to display the current BMC configuration for the appliance.



A [controlled shutdown of the appliance](#) is required before removing the appliance from the rack.

- You have disconnected all cables and [removed the appliance cover](#).

#### About this task

To prevent service interruptions, confirm that all other Storage Nodes are connected to the grid before starting the CMOS battery replacement or replace the battery during a scheduled maintenance window when periods of service disruption are acceptable. See the information about [monitoring node connection states](#).




If you have ever used an ILM rule that creates only one copy of an object, you must replace the battery during a scheduled maintenance window because you might temporarily lose access to those objects during this procedure. See information about [why you should not use single-copy replication](#).

#### Steps

1. Wrap the strap end of the ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.

2. Locate the two-slot riser assembly at the rear of the appliance.



3. Grasp the riser assembly through the blue-marked holes and carefully lift it upwards. Move the riser assembly toward the front of the chassis as you lift it to allow the external connectors in its installed NICs to clear the chassis.
4. Place the riser on a flat anti-static surface with the metal frame side down.
5. Locate the CMOS battery on the system board in the position beneath the removed riser assembly.



6. Use your finger or a plastic pry tool to press the retaining clip (highlighted) away from the battery to spring it from the socket.



7. Remove the battery and dispose of it properly.

## Reinstall the CMOS battery


Install the replacement CMOS battery into the socket on the system board.

### Before you begin

- You have the correct replacement CMOS battery (CR2032).
- You have removed the failed CMOS battery.

### Steps

1. Wrap the strap end of the ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
2. Remove the CMOS battery from its packaging.
3. Press the replacement battery into the empty socket on the system board with the positive (+) side up until the battery snaps in place.
4. Locate the alignment hole on the two-slot riser assembly (circled) that aligns with the guide pin on the system board to ensure correct riser assembly positioning.



5. Locate the guide pin on the system board



6. Position the riser assembly in the chassis, making sure that it aligns with the connector on the system board and guide pin.
7. Carefully press the two-slot riser assembly in place along its center line, next to the blue-marked holes, until it is fully seated.
8. If you have no other maintenance procedures to perform in the appliance, reinstall the appliance cover, return the appliance to the rack, attach cables, and apply power.
9. If the appliance you replaced had drive encryption enabled for the SED drives, you must [enter the drive encryption passphrase](#) to access the encrypted drives when the replacement appliance starts for the first time.
10. If the appliance you replaced used a key management server (KMS) to manage encryption keys for node encryption, additional configuration might be required before the node can join the grid. If the node does not automatically join the grid, make sure that these configuration settings have transferred to the new appliance and manually configure any settings that don't have the expected configuration:
  - [Configure StorageGRID connections](#)
  - [Configure node encryption for the appliance](#)
11. Log in to the appliance:
  - a. Enter the following command: `ssh admin@grid_node_IP`
  - b. Enter the password listed in the `Passwords.txt` file.
  - c. Enter the following command to switch to root: `su -`
  - d. Enter the password listed in the `Passwords.txt` file.
12. Restore BMC network connectivity for the appliance. There are two options:
  - Use static IP, netmask, and gateway
  - Use DHCP to obtain an IP, netmask, and gateway
    - a. To restore the BMC configuration to use a static IP, netmask, and gateway, enter the following commands:

```
run-host-command ipmitool lan set 1 ipsrc static

run-host-command ipmitool lan set 1 ipaddr Appliance_IP

run-host-command ipmitool lan set 1 netmask Netmask_IP

run-host-command ipmitool lan set 1 defgw ipaddr Default_gateway
```
    - b. To restore the BMC configuration to use DHCP to obtain an IP, netmask, and gateway, enter the following command:

```
run-host-command ipmitool lan set 1 ipsrc dhcp
```
13. After restoring BMC network connectivity, connect to the BMC interface to audit and restore any additional custom BMC configuration you might have applied. For example, you should confirm the settings for SNMP trap destinations and email notifications. See [Configure BMC interface](#).
14. Confirm that the appliance node appears in the Grid Manager and that no alerts appear.

# Replace DIMMs in storage controller shelf (SG6160)

You can replace a DIMM in the E4000 if a memory mismatch is present, or if you have a failed DIMM.

## About this task

To replace a DIMM, you must verify the cache size of your controller, place the controller offline, remove the controller, remove the DIMMs, and install the new DIMMs in your controller. Then you can bring your controller back online and verify the storage array is working properly.

## Before you begin

- Make sure you have the following:
  - A replacement DIMM.
  - An ESD wristband, or you have taken other antistatic precautions.
  - A flat, static free work area.
  - Labels to identify each cable that is connected to the controller canister.
  - Access to SANtricity System Manager:
    - From Grid Manager, select **NODES > appliance node > SANtricity System Manager**. Controller information is on the [SANtricity System Manager tab](#).
    - Point a browser in your management station to the controller's domain name or IP address.

## Step 1: Determine if you need to replace a DIMM

Verify the cache size of your controller before replacing the DIMMs.

### Steps

1. Access the Storage Array profile for the controller. From SANtricity System Manager, go to **Support > Support Center**. From the Support Resources page, select **Storage Array Profile**.
2. Scroll down or use the Search field to locate the **Data Cache Module** information.
3. If one of the following is present, note the DIMM's location and continue with remaining procedures in this section to replace the DIMMs on your controller:
  - a. A failed DIMM, or a DIMM reporting **Data Cache Module** as not optimal.
  - b. A DIMM with a mismatched **Data Cache Module** capacity.

## Step 2: Place controller offline

Place the controller offline so you can safely remove and replace the DIMMs.

### Steps

1. From SANtricity System Manager, review the details in the Recovery Guru to confirm that there is an issue with a mismatched memory and to ensure no other items must be addressed first.
2. From the Details area of the Recovery Guru, determine which DIMM to replace.
3. Back up the storage array's configuration database using SANtricity System Manager.

If a problem occurs when you remove a controller, you can use the saved file to restore your configuration. The system will save the current state of the RAID configuration database, which includes all data for

volume groups and disk pools on the controller.

- From System Manager:
  - a. Select **Support** > **Support Center** > **Diagnostics**.
  - b. Select **Collect Configuration Data**.
  - c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, **configurationData-<arrayName>-<dateTime>.7z**.

4. If the controller is not already offline, take it offline now using SANtricity System Manager.
  - a. Select **Hardware**.
  - b. If the graphic shows the drives, select **Show back of shelf** to show the controllers.
  - c. Select the controller that you want to place offline.
  - d. From the context menu, select **Place offline**, and confirm that you want to perform the operation.



If you are accessing SANtricity System Manager using the controller you are attempting to take offline, a SANtricity System Manager Unavailable message is displayed. Select **Connect to an alternate network connection** to automatically access SANtricity System Manager using the other controller.

5. Wait for SANtricity System Manager to update the controller's status to offline.



Do not begin any other operations until after the status has been updated.

6. Select **Recheck** from the Recovery Guru, and confirm that the OK to remove field in the Details area displays Yes, indicating that it is safe to remove this component.

### Step 3: Remove controller canister


Remove the controller canister from the system and then remove the controller canister cover.

#### Steps

1. If you are not already grounded, properly ground yourself.
2. Loosen the hook and loop strap binding the cables to the cable management device, and then unplug the system cables and SFPs (if needed) from the controller canister, keeping track of where the cables were connected.

Leave the cables in the cable management device so that when you reinstall the cable management device, the cables are organized.

3. Remove and set aside the cable management devices from the left and right sides of the controller canister.
4. Squeeze the latch on the cam handle until it releases, open the cam handle fully to release the controller canister from the midplane, and then, using two hands, pull the controller canister out of the chassis.
5. Turn the controller canister over and place it on a flat, stable surface.
6. Open the cover by pressing the blue buttons on the sides of the controller canister to release the cover, and then rotate the cover up and off of the controller canister.



## Step 4: Replace the DIMMs

Locate the DIMM inside the controller, remove it, and replace it.

### Steps

1. If you are not already grounded, properly ground yourself.
2. You must perform a clean system shutdown before replacing system components to avoid losing unwritten data in the nonvolatile memory (NVMEM). The LED is located on the back of the controller canister.
3. If the NVMEM LED is not flashing, there is no content in the NVMEM; you can skip the following steps and proceed to the next task in this procedure.
4. If the NVMEM LED is flashing, there is data in the NVMEM and you must disconnect the battery to clear the memory:
  - a. Remove the battery from the controller canister by pressing the blue button on the side of the controller canister.
  - b. Slide the battery up until it clears the holding brackets, and then lift the battery out of the controller canister.
  - c. Locate the battery cable, press the clip on the battery plug to release the lock clip from the plug socket, and then unplug the battery cable from the socket.
  - d. Confirm that the NVMEM LED is no longer lit.
  - e. Reconnect the battery connector and recheck the LED on the back of the controller.
  - f. Unplug the battery cable.


5. Locate the DIMMs on your controller canister.
6. Note the orientation and location of the DIMM in the socket so that you can insert the replacement DIMM in the proper orientation.
7. Eject the DIMM from its slot by slowly pushing apart the two DIMM ejector tabs on either side of the DIMM, and then slide the DIMM out of the slot.

The DIMM will rotate up a little.

8. Rotate the DIMM as far as it will go, and then slide the DIMM out of the socket.



Carefully hold the DIMM by the edges to avoid pressure on the components on the DIMM circuit board.



1	DIMM ejector tabs
2	DIMMs

9. Remove the replacement DIMM from the antistatic shipping bag, hold the DIMM by the corners, and align it to the slot.

The notch among the pins on the DIMM should line up with the tab in the socket.

10. Insert the DIMM squarely into the slot.

The DIMM fits tightly in the slot, but should go in easily. If not, realign the DIMM with the slot and reinsert it.



Visually inspect the DIMM to verify that it is evenly aligned and fully inserted into the slot.

11. Push carefully, but firmly, on the top edge of the DIMM until the ejector tabs snap into place over the notches at the ends of the DIMM.

12. Reconnect the battery:

- a. Plug in the battery.
- b. Make sure that the plug locks down into the battery power socket on the motherboard.
- c. Align the battery with the holding brackets on the sheet metal side wall.
- d. Slide the battery pack down until the battery latch engages and clicks into the opening on the side wall.

13. Reinstall the controller canister cover.

## Step 5: Reinstall the controller canister

Reinstall the controller canister into the chassis.

### Steps

1. If you are not already grounded, properly ground yourself.
2. If you have not already done so, replace the cover on the controller canister.
3. Turn the controller canister over and align the end with the opening in the chassis.
4. Gently push the controller canister halfway into the system. Align the end of the controller canister with the opening in the chassis, and then gently push the controller canister halfway into the system.



Do not completely insert the controller canister in the chassis until instructed to do so.

5. Recable the system, as needed.

6. Complete the reinstallation of the controller canister:

- a. With the cam handle in the open position, firmly push the controller canister in until it meets the midplane and is fully seated, and then close the cam handle to the locked position.



Do not use excessive force when sliding the controller canister into the chassis to avoid damaging the connectors.

The controller begins to boot as soon as it is seated in the chassis.

- b. If you have not already done so, reinstall the cable management device.
- c. Bind the cables to the cable management device with the hook and loop strap.

7. Reboot the controller canister.

## Step 6: Complete DIMMs replacement

Place the controller online, collect support data, and resume operations.

### Steps

1. Place controller online.
  - a. In System Manager, navigate to the Hardware page.
  - b. Select **Controllers & Components**.
  - c. Select the controller with the replaced DIMMs.
  - d. Select **Place online** from the drop-down list.
2. As the controller boots, check the controller LEDs.

When communication with the other controller is reestablished:

- The amber Attention LED remains on.
- The Host Link LEDs might be on, blinking, or off, depending on the host interface.

3. When the controller is back online, confirm that its status is Optimal and check the controller shelf's Attention LEDs.

If the status is not Optimal or if any of the Attention LEDs are on, confirm that all cables are correctly seated and the controller canister is installed correctly. If necessary, remove and reinstall the controller canister. NOTE: If you cannot resolve the problem, contact technical support.

4. Click **Hardware > Support > Upgrade Center** to ensure that the latest version of SANtricity OS is installed.

As needed, install the latest version.

5. Verify that all volumes have been returned to the preferred owner.

- a. Select **Storage > Volumes**. From the **All Volumes** page, verify that volumes are distributed to their preferred owners. Select **More > Change ownership** to view volume owners.
- b. If volumes are all owned by preferred owner continue to Step 6.
- c. If none of the volumes are returned, you must manually return the volumes. Go to **More > Redistribute volumes**.
- d. If there is no Recovery Guru present or if following the Recovery Guru steps the volumes are still not returned to their preferred owners contact support.

6. Collect support data for your storage array using SANtricity System Manager.

- a. Select **Support > Support Center > Diagnostics**.
- b. Select **Collect Support Data**.
- c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, **support-data.7z**.

## Replace battery in storage controller shelf (SG6160)

You must replace the affected battery in your E4000 controller if the Recovery Guru in SANtricity System Manager indicates a "Battery Failed" or "Battery Replacement

Required" status. To protect your data, the battery must be replaced as soon as possible.

From SANtricity System Manager, review the details in the Recovery Guru to confirm that there is an issue with a battery and to ensure no other items must be addressed first.

### Before you begin

If you plan to replace a failed battery, you must have:

- A replacement battery.
- An ESD wristband, or you have taken other antistatic precautions.
- Labels to identify each cable that is connected to the controller canister.
- Access to SANtricity System Manager:
  - From Grid Manager, select **NODES > appliance node > SANtricity System Manager**. Controller information is on the [SANtricity System Manager tab](#).
  - Point a browser in your management station to the controller's domain name or IP address.
- Verify that no volumes are in use or that you have a multipath driver installed on all hosts using these volumes.

## Step 1: Prepare to replace battery

You must place the affected controller offline so you can safely remove the failed battery. The controller that you are not placing offline must be online (in the optimal state).

### Steps

1. From SANtricity System Manager, review the details in the Recovery Guru to confirm that there is an issue with a battery and to ensure no other items must be addressed first.
2. From the Details area of the Recovery Guru, determine which battery to replace.
3. Back up the storage array's configuration database using SANtricity System Manager.

If a problem occurs when you remove a controller, you can use the saved file to restore your configuration. The system will save the current state of the RAID configuration database, which includes all data for volume groups and disk pools on the controller.

- From System Manager:
  - a. Select **Support > Support Center > Diagnostics**.
  - b. Select **Collect Configuration Data**.
  - c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, **configurationData-<arrayName>-<dateTime>.7z**.

- Alternatively, you can back up the configuration database by using the following CLI command:

```
save storageArray dbmDatabase sourceLocation=onboard contentType=all
file="filename";
```

4. Collect support data for your storage array using SANtricity System Manager.
5. If a problem occurs when you remove a controller, you can use the saved file to troubleshoot the issue. The system will save inventory, status, and performance data about your storage array in a single file.

- a. Select **Support** > **Support Center** > **Diagnostics**.
- b. Select **Collect Support Data**.
- c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, support-data.7z.

6. If the controller is not already offline, take it offline now using SANtricity System Manager.
  - From SANtricity System Manager:
    - a. Select **Hardware**.
    - b. If the graphic shows the drives, select **Show back of shelf** to show the controllers.
    - c. Select the controller that you want to place offline.
    - d. From the context menu, select **Place offline**, and confirm that you want to perform the operation.



If you are accessing SANtricity System Manager using the controller you are attempting to take offline, a SANtricity System Manager Unavailable message is displayed. Select **Connect to an alternate network connection** to automatically access SANtricity System Manager using the other controller.

- Alternatively, you can take the controllers offline by using the following CLI commands:

**For controller A:** `set controller [a] availability=offline`

**For controller B:** `set controller [b] availability=offline`

7. Wait for SANtricity System Manager to update the controller's status to offline.
8. Select **Recheck** from the Recovery Guru, and confirm that the **Okay to remove** field in the **Details** area displays **Yes**. This indicates that it is safe to proceed to removing the controller canister.

## Step 2: Remove E4000 controller canister

You need to remove the controller canister from the controller shelf, so you can remove the battery.

### Before you begin

Make sure you have the following:

- An ESD wristband, or you have taken other antistatic precautions.
- Labels to identify each cable that is connected to the controller canister.

### Steps

1. Disconnect all the cables from the controller canister.



To prevent degraded performance, do not twist, fold, pinch, or step on the cables.

2. If the host ports on the controller canister use SFP+ transceivers, leave them installed.
3. Confirm that the Cache Active LED on the back of the controller is off.
4. Squeeze the latch on the cam handle until it releases, open the cam handle fully to release the controller canister from the midplane, and then, using two hands, pull the controller canister half-way out of the chassis.

## Step 3: Install the new battery

You must remove the failed battery and replace it.


### Steps

1. Unpack the new battery and place it on a flat, static-free surface.




To comply with IATA safety regulations, replacement batteries are shipped with a state of charge (SoC) of 30 percent or less. When you reapply power, keep in mind that write caching will not resume until the replacement battery is fully charged and it has completed its initial learn cycle.

2. If you are not already grounded, properly ground yourself.
3. Remove the controller canister from the chassis.
4. Turn the controller canister over and place it on a flat, stable surface.
5. Open the cover by pressing the blue buttons on the sides of the controller canister to release the cover, and then rotate the cover up and off of the controller canister.



6. Locate the battery in the controller canister.
7. Remove the failed battery from the controller canister:
  - a. Press the blue button on the side of the controller canister.
  - b. Slide the battery up until it clears the holding brackets, and then lift the battery out of the controller canister.

c. Unplug the battery from the controller canister.



1	Battery release tab
2	Battery power connector

8. Remove the replacement battery from its package. Install the replacement battery:

a. Plug the battery plug back into the socket on the controller canister.

Make sure that the plug locks down into the battery socket on the motherboard.

b. Align the battery with the holding brackets on the sheet metal side wall.  
 c. Slide the battery pack down until the battery latch engages and clicks into the opening on the side wall.

9. Reinstall the controller canister cover and lock it into place.

## Step 4: Reinstall the controller canister

After you replace components in the controller canister, reinstall it into the chassis.

### Steps

1. If you are not already grounded, properly ground yourself.
2. If you have not already done so, replace the cover on the controller canister.
3. Turn the controller canister over and align the end with the opening in the chassis.
4. Align the end of the controller canister with the opening in the chassis, and then gently push the controller canister halfway into the system.



Do not completely insert the controller canister in the chassis until instructed to do so.

5. Recable the system, as needed.
6. Complete the reinstallation of the controller canister:
  - a. With the cam handle in the open position, firmly push the controller canister in until it meets the midplane and is fully seated, and then close the cam handle to the locked position.



Do not use excessive force when sliding the controller canister into the chassis to avoid damaging the connectors.

The controller begins to boot as soon as it is seated in the chassis.

- b. If you have not already done so, reinstall the cable management device.
- c. Bind the cables to the cable management device with the hook and loop strap.

## Step 5: Complete battery replacement

Place the controller online.

### Steps

1. Bring the controller online using SANtricity System Manager:
  - From SANtricity System Manager:
    - a. Select **Hardware**.
    - b. If the graphic shows the drives, select **Show back of shelf**.
    - c. Select the controller you want to place online.
    - d. Select **Place Online** from the context menu, and confirm that you want to perform the operation.
  - Alternatively, you can bring the controller back online by using the following CLI commands:  
**For controller A:** `set controller [a] availability=online;`  
**For controller B:** `set controller [b] availability=online;`

The system places the controller online.

- Alternatively, you can bring the controller back online by using the following CLI commands:  
**For controller A:** `set controller [a] availability=online;`  
**For controller B:** `set controller [b] availability=online;`
2. When the controller is back online, check the controller shelf's Attention LEDs.

If the status is not Optimal or if any of the Attention LEDs are on, confirm that all cables are correctly seated, and check that the battery and the controller canister are installed correctly. If necessary, remove and reinstall the controller canister and the battery.



If you cannot resolve the problem, contact technical support. If needed, collect support data for your storage array using SANtricity System Manager.

3. Verify that all volumes have been returned to the preferred owner.
  - a. Select **Storage > Volumes**. From the **All Volumes** page, verify that volumes are distributed to their preferred owners. Select **More > Change ownership** to view volume owners.
  - b. If volumes are all owned by preferred owner continue to step 4.
  - c. If none of the volumes are returned, you must manually return the volumes. Go to **More > Redistribute volumes**.

- d. If only some of the volumes are returned to their preferred owners after auto-distribution or manual distribution, you must check the Recovery Guru for host connectivity issues.
- e. If there is no Recovery Guru present or if after following the recovery guru steps the volumes are still not returned to their preferred owners, contact support.

4. Collect support data for your storage array using SANtricity System Manager.

- a. Select **Support** > **Support Center** > **Diagnostics**.
- b. Select Collect Support Data.
- c. Click Collect.

The file is saved in the Downloads folder for your browser with the name, support-data.7z.

### What's next?

Your battery replacement is complete. You can resume normal operations.

## Replace SGF6112 or SG6100-CN cover

Remove the appliance cover to access internal components for maintenance, and replace the cover when you are finished.

### Remove cover

#### Before you begin

[Remove the appliance from the cabinet or rack](#) to access the top cover.

#### Steps

1. Make sure that the appliance cover latch is not locked. If necessary, turn the blue plastic latch lock one-quarter turn in the unlock direction, as shown on the latch lock.
2. Rotate the latch up and back toward the rear of the appliance chassis until it stops; then, carefully lift the cover from the chassis and set it aside.





Wrap the strap end of an ESD wristband around your wrist and secure the clip end to a metal ground to prevent static discharge when working inside the appliance.

## Reinstall cover

### Before you begin

You have completed all maintenance procedures inside the appliance.

### Steps

1. With the cover latch open, hold the cover above the chassis and align the hole in the top cover latch with the pin in the chassis. When the cover is aligned, lower it onto the chassis.



2. Rotate the cover latch forward and down until it stops and the cover fully seats into the chassis. Verify that there are no gaps along the front edge of the cover.

If the cover is not fully seated, you might not be able to slide the appliance into the rack.

3. Optional: Turn the blue plastic latch lock one-quarter turn in the lock direction, as shown on the latch lock, to lock it.

### After you finish

[Reinstall the appliance in the cabinet or rack.](#)

## Add expansion shelf to deployed SG6160

To increase storage capacity, you can add one or two expansion shelves to an SG6160 that is already deployed in a StorageGRID system.

### Before you begin

- You must have the provisioning passphrase.
- You must be running StorageGRID 11.8 or later.
- You have the expansion shelf and two SAS cables for each expansion shelf.
- You have physically located the storage appliance where you are adding the expansion shelf in the data center.

[Locate controller in data center](#)

## About this task

To add an expansion shelf, you perform these high-level steps:


- Install the hardware in the cabinet or rack.
- Place the SG6160 into maintenance mode.
- Connect the expansion shelf to the E4000 controller shelf or to another expansion shelf.
- Start the expansion using the StorageGRID Appliance Installer.
- Wait until the new volumes are configured.

Completing the procedure for one or two expansion shelves should take one hour or less per appliance node. To minimize downtime, the following steps instruct you to install the new expansion shelves and drives before placing the SG6160 into maintenance mode. The remaining steps should take approximately 20 to 30 minutes per appliance node.

### Steps

1. Follow the instructions for [installing 60-drive shelves into a cabinet or rack](#).
2. From the Grid Manager, [place the SG6100-CN controller into maintenance mode](#).
3. Connect each expansion shelf to the E4000 controller shelf as shown in the diagram.

This drawing shows two expansion shelves. If you have only one, connect IOM A to controller A and connect IOM B to controller B.



Callout	Description
1	SG6100-CN
2	E4000 controller shelf
3	Controller A

Callout	Description
4	Controller B
5	Expansion shelf 1
6	IOM A for expansion shelf 1
7	IOM B for expansion shelf 1
8	Expansion shelf 2
9	IOM A for expansion shelf 2
10	IOM B for expansion shelf 2

4. Connect the power cords and apply power to the expansion shelves.
  - a. Connect a power cord to each of the two power supply units in each expansion shelf.
  - b. Connect the two power cords in each expansion shelf to two different PDUs in the cabinet or rack.
  - c. Turn on the two power switches for each expansion shelf.
    - Don't turn off the power switches during the power-on process.
    - The fans in the expansion shelves might be very loud when they first start up. The loud noise during start-up is normal.
5. Monitor the Home page of the StorageGRID Appliance Installer.

In approximately five minutes, the expansion shelves finish powering up and are detected by the system. The Home page shows the number of new expansion shelves detected, and the Start Expansion button is enabled.

Examples of the messages that could appear on the Home page, depending on the number of existing or new expansion shelves:

- A banner that displays at the top of the page indicates the total number of expansion shelves detected.
  - The banner indicates the total number of expansion shelves, whether the shelves are configured and deployed or new and unconfigured.
  - If no expansion shelves are detected, the banner will not appear.
- A message at the bottom of the page indicates that an expansion is ready to be started.
  - The message indicates the number of new expansion shelves StorageGRID detects. “Attached” indicates that the shelf is detected. “Unconfigured” indicates that the shelf is new and not yet configured using the StorageGRID Appliance Installer.



Expansion shelves that are already deployed aren't included in this message. They are included in the count in the banner at the top of the page.

- The message will not appear if new expansion shelves aren't detected.

6. As necessary, resolve any issues described in the messages on the Home page.

For example, use SANtricity System Manager to resolve any storage hardware issues.

7. Verify that the number of expansion shelves displayed on the Home page matches the number of expansion shelves you are adding.



If the new expansion shelves have not been detected, verify that they are properly cabled and powered up.

8. Click **Start Expansion** to configure the expansion shelves and make them available for object storage.

9. Monitor the progress of the expansion shelf configuration.

Progress bars appear on the web page, just as they do during initial installation.

When configuration is complete, the appliance automatically reboots to exit maintenance mode and rejoin the grid. This process can take up to 20 minutes.



To retry the expansion shelf configuration if it fails, go to the StorageGRID Appliance Installer, select **Advanced > Reboot Controller**, and then select **Reboot into Maintenance Mode**. After the node reboots, retry the [expansion shelf configuration](#).

When the reboot is complete, the **Tasks** tab displays with selections to reboot the node or place the appliance in maintenance mode.

10. Verify the status of the appliance Storage Node and the new expansion shelves.

a. In the Grid Manager, select **NODES** and verify that the appliance Storage Node has a green check mark icon.

The green check mark icon means that no alerts are active and the node is connected to the grid. For a description of node icons, see [Monitor node connection states](#).

b. Select the **Storage** tab and confirm that 16 new object stores are shown in the Object Storage table for each expansion shelf you added.

c. Verify that each new expansion shelf has a shelf status of Nominal and a configuration status of Configured.

## Replace appliance

### Replace SGF6112 appliance

You might need to replace the appliance if it is not functioning optimally or if it has failed.

#### Before you begin

- You have a replacement appliance with the same part number as the appliance you are replacing. Check the tags attached to the front of the appliances to confirm that the part numbers match.
- You have labels to identify each cable that is connected to the appliance.
- You have [physically located the appliance](#).

#### About this task

The StorageGRID node will not be accessible while you replace the appliance. If the appliance is functioning sufficiently, you can perform a controlled shutdown at the start of this procedure.

If you are replacing the appliance before installing StorageGRID software, you might not be able to access the StorageGRID Appliance Installer immediately after completing this procedure.



While you can access the StorageGRID Appliance Installer from other hosts on the same subnet as the appliance, you can't access it from hosts on other subnets. This condition should resolve itself within 15 minutes (when any ARP cache entries for the original appliance time out), or you can clear the condition immediately by purging any old ARP cache entries manually from the local router or gateway.

## Steps

1. Display the current configurations of the appliance and record them.

a. Log in to the appliance to be replaced:

- i. Enter the following command: `ssh admin@grid_node_IP`
- ii. Enter the password listed in the `Passwords.txt` file.
- iii. Enter the following command to switch to root: `su -`
- iv. Enter the password listed in the `Passwords.txt` file.

When you are logged in as root, the prompt changes from `$` to `#`.

b. Enter: `run-host-command ipmitool lan print` to display the current BMC configurations for the appliance.

2. [Shut down the appliance](#).

3. If any of the network interfaces on this StorageGRID appliance are configured for DHCP, you need to update the permanent DHCP lease assignments on the DHCP servers to reference the MAC addresses of the replacement appliance. This ensures that the appliance is assigned the expected IP addresses.

Contact your network or DHCP-server administrator to update the permanent DHCP lease assignments. The administrator can determine the MAC addresses of the replacement appliance from the DHCP server logs or by inspecting the MAC address tables in the switches to which the appliance Ethernet ports are connected.

4. Remove and replace the appliance:

a. Label the cables and then disconnect the cables and any network transceivers.




To prevent degraded performance, don't twist, fold, pinch, or step on the cables.

b. [Remove the failed appliance from the cabinet or rack](#).

c. Note the position of the replaceable components (two power supplies, three NICs, and twelve SSDs) in the failed appliance.

The twelve drives are in the following positions in the chassis (front of chassis with bezel removed shown):



	Drive
1	HDD00
2	HDD01
3	HDD02
4	HDD03
5	HDD04
6	HDD05
7	HDD06
8	HDD07
9	HDD08
10	HDD09
11	HDD10
12	HDD11

d. Transfer the replaceable components to the replacement appliance.

Follow the maintenance instructions provided for reinstalling the replaceable components.



If you want to retain the data on the drives, insert the SSD drives into the same drive slots they occupied in the failed appliance. If you don't, the Appliance Installer will display a warning and you will have to put the drives into the correct slots and reboot the appliance before the appliance can rejoin the grid.

e. [Install the replacement appliance into the cabinet or rack.](#)

- f. Replace the cables and any optical transceivers.
5. Power on the appliance.
6. If the appliance you replaced had hardware drive encryption enabled for the SED drives, see [Access an encrypted drive](#). Follow the guidance to access the encrypted drive when the replacement appliance starts for the first time. A reboot will be required to complete the procedure.
7. Wait for the appliance to rejoin the grid. If the appliance does not rejoin the grid, follow the guidance on the StorageGRID Appliance Installer home page to address any issues.



To prevent data loss if the Appliance Installer indicates that physical hardware changes are required, such as moving disk drives to different slots, power down the appliance before making hardware changes.

8. If the appliance you replaced used a key management server (KMS) to manage encryption keys for node encryption, additional configuration might be required before the node can join the grid. If the node does not automatically join the grid, make sure that these configuration settings have transferred to the new appliance and manually configure any settings that don't have the expected configuration:
  - [Configure StorageGRID connections](#)
  - [Configure node encryption for the appliance](#)
9. Log in to the replaced appliance:
  - a. Enter the following command: `ssh admin@grid_node_IP`
  - b. Enter the password listed in the `Passwords.txt` file.
  - c. Enter the following command to switch to root: `su -`
  - d. Enter the password listed in the `Passwords.txt` file.
10. Restore BMC network connectivity for the replaced appliance. There are two options:
  - Use static IP, netmask, and gateway
  - Use DHCP to obtain an IP, netmask, and gateway
    - a. To restore the BMC configuration to use a static IP, netmask, and gateway, enter the following commands:

```
run-host-command ipmitool lan set 1 ipsrc static

run-host-command ipmitool lan set 1 ipaddr Appliance_IP

run-host-command ipmitool lan set 1 netmask Netmask_IP

run-host-command ipmitool lan set 1 defgw ipaddr Default_gateway
```
    - b. To restore the BMC configuration to use DHCP to obtain an IP, netmask, and gateway, enter the following command:

```
run-host-command ipmitool lan set 1 ipsrc dhcp
```
11. After restoring BMC network connectivity, connect to the BMC interface to audit and restore any additional custom BMC configuration you might have applied. For example, you should confirm the settings for SNMP trap destinations and email notifications. See [Configure BMC interface](#).
12. Confirm that the appliance node appears in the Grid Manager and that no alerts appear.

## After you finish

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return & Replacements](#) page for further information.

## Related information

- [View status indicators](#)
- [View boot-up codes for appliance](#)

## Replace SG6100-CN controller

You might need to replace the SG6100-CN controller if it is not functioning optimally or if it has failed.

### Before you begin

- You have a replacement controller with the same part number as the controller you are replacing. Check the tags attached to the front of the controllers to confirm that the part numbers match.
- You have labels to identify each cable that is connected to the controller.
- You have physically located the controller to replace in the data center.

[Locate controller in data center](#)

### About this task

The appliance Storage Node will not be accessible when you replace the SG6100-CN controller. If the SG6100-CN controller is functioning sufficiently, you can perform a controlled shutdown at the start of this procedure.

If you are replacing the controller before installing StorageGRID software, you might not be able to access the StorageGRID Appliance Installer immediately after completing this procedure.

While you can access the StorageGRID Appliance Installer from other hosts on the same subnet as the appliance, you can't access it from hosts on other subnets. This condition should resolve itself within 15 minutes (when any ARP cache entries for the original controller time out), or you can clear the condition immediately by purging any old ARP cache entries manually from the local router or gateway.

### Steps

1. Display the current configurations of the appliance and record them.
  - a. Log in to the appliance to be replaced:
    - i. Enter the following command: `ssh admin@grid_node_IP`
    - ii. Enter the password listed in the `Passwords.txt` file.
    - iii. Enter the following command to switch to root: `su -`
    - iv. Enter the password listed in the `Passwords.txt` file.
  - When you are logged in as root, the prompt changes from `$` to `#`.
  - b. Enter: `run-host-command ipmitool lan print` to display the current BMC configurations for the appliance.
2. If the SG6100-CN controller is functioning sufficiently to allow for a controlled shutdown, [shut down the](#)

## SG6100-CN controller

3. If any of the network interfaces on this StorageGRID appliance are configured for DHCP, you might need to update the permanent DHCP lease assignments on the DHCP servers to reference the MAC addresses of the replacement appliance. The update ensures the appliance is assigned the expected IP addresses.
4. Remove and replace the SG6100-CN controller:
  - a. Label and then disconnect the cables.



To prevent degraded performance, don't twist, fold, pinch, or step on the cables.

- b. [Remove the failed controller from the cabinet or rack](#).
- c. Note the position of the replaceable components (two power supplies, three NICs, and two SSDs) in the failed controller.

The two drives are in the following positions in the chassis (front of chassis with bezel removed shown):



	Drive
1	HDD00
2	HDD01

- d. Transfer the replaceable components to the replacement controller.

Follow the maintenance instructions provided for reinstalling the replaceable components.



If you want to retain the data on the drives, insert the SSD drives into the same drive slots they occupied in the failed appliance. If you don't, the Appliance Installer will display a warning and you will have to put the drives into the correct slots and reboot the controller before the controller can rejoin the grid.

- e. [Install the replacement controller into the cabinet or rack](#).
- f. Replace the cables and any optical transceivers.
- g. Power on the controller and monitor the controller LEDs.
5. If the appliance you replaced had hardware drive encryption enabled for the SED drives, you must [enter the drive encryption passphrase](#) to access the encrypted drives when the replacement appliance starts for the first time.
6. If the appliance where you replaced the controller used a key management server (KMS) to encrypt data, additional configuration might be required before the node can join the grid. If the node does not automatically join the grid, make sure that these configuration settings have transferred to the new

controller and manually configure any settings that don't have the expected configuration:

- [Configure network links](#)
- [Configure StorageGRID IP addresses](#)
- [Configure node encryption for the appliance](#)

7. Log in to the appliance with the replaced controller:

- Enter the following command: `ssh admin@grid_node_IP`
- Enter the password listed in the `Passwords.txt` file.
- Enter the following command to switch to root: `su -`
- Enter the password listed in the `Passwords.txt` file.

8. Restore BMC network connectivity for the appliance. There are two options:

- Use static IP, netmask, and gateway
- Use DHCP to obtain an IP, netmask, and gateway
  - To restore the BMC configuration to use a static IP, netmask, and gateway, enter the following commands:

```
run-host-command ipmitool lan set 1 ipaddr Appliance_IP
run-host-command ipmitool lan set 1 netmask Netmask_IP
run-host-command ipmitool lan set 1 defgw ipaddr Default_gateway
```
  - To restore the BMC configuration to use DHCP to obtain an IP, netmask, and gateway, enter the following command:

```
run-host-command ipmitool lan set 1 ipsrc dhcp
```

9. After restoring BMC network connectivity, connect to the BMC interface to audit and restore any additional custom BMC configuration you might have applied. For example, you should confirm the settings for SNMP trap destinations and email notifications. See [Configure BMC interface](#).

10. Confirm that the appliance node appears in the Grid Manager and that no alerts appear.

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return & Replacements](#) page for further information.

## Replace E4000 storage controller (SG6160)

You might need to replace an E4000 controller if it is not functioning optimally or if it has failed.

### Before you begin

- You have a replacement controller with the same part number as the controller you are replacing.
- You have labels to identify each cable that is connected to the controller.
- You have an ESD wristband, or you have taken other antistatic precautions.
- You have a #1 Phillips screwdriver.
- You have physically located the storage appliance where you are replacing the controller in the data center.



Don't rely on the E-Series instructions to replace a controller in the StorageGRID appliance, because the procedures aren't the same.

## About this task

You can determine if you have a failed controller in two ways:

- A Grid Manager alert indicates a storage controller failure condition, and Grid Manager or the Recovery Guru in SANtricity System Manager direct you to replace the controller.
- The amber Attention LED on the controller is on, indicating that the controller has a fault.



If both controllers in the shelf have their Attention LEDs on, contact technical support for assistance.

If your appliance contains two storage controllers, you can replace one of the controllers while your appliance is powered on and performing read/write operations, as long as the following conditions are true:

- The second controller in the shelf has Optimal status.
- The **OK to remove** field in the Details area of the Recovery Guru in SANtricity System Manager displays **Yes**, indicating that it is safe to remove this component.



When possible, place the appliance into maintenance mode for this replacement procedure to minimize the potential impact of unforeseen errors or failures.



If the second controller in the shelf does not have Optimal status or if the Recovery Guru indicates that it is not OK to remove the controller, contact technical support.

## Step 1: Prepare the replacement controller

Prepare the replacement E4000 controller.

### Steps

1. Unpack the new controller, and set it on a flat, static-free surface.

Save the packing materials to use when shipping the failed controller.

2. Locate the MAC address and FRU part number labels on the back of the replacement controller.

## Step 2: Take the controller offline

Prepare to remove the failed controller and take it offline. You can use SANtricity System Manager to perform these steps.

### Steps

1. Confirm that the replacement part number for the failed controller is the same as the FRU part number for the replacement controller.

When a controller has a fault and needs to be replaced, the replacement part number is displayed in the Details area of the Recovery Guru. If you need to find this number manually, you can look on the **Base** tab for the controller.



**Possible loss of data access —** If the two part numbers aren't the same, don't attempt this procedure.

2. Back up the configuration database.

If a problem occurs when you remove a controller, you can use the saved file to restore your configuration. The system will save the current state of the RAID configuration database, which includes all data for volume groups and disk pools on the controller.

- a. Select **Support > Support Center > Diagnostics**.
- b. Select **Collect Configuration Data**.
- c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, **configurationData-<arrayName>-<dateTime>.7z**.

3. Collect support data for the appliance.



Collecting support data before and after replacing a component ensures you can send a full set of logs to technical support if the replacement does not resolve the problem.

If a problem occurs when you remove a controller, you can use the saved file to troubleshoot the issue. The system will save inventory, status, and performance data about your storage array in a single file.

- a. Select **Support > Support Center > Diagnostics**.
- b. Select **Collect Support Data**.
- c. Click **Collect**.

4. Take the controller you plan to replace offline.

### Step 3: Remove controller canister

Remove a controller canister.

#### Steps

1. Put on an ESD wristband or take other antistatic precautions.
2. Label each cable that is attached to the controller canister.
3. Disconnect all the cables from the controller canister.



To prevent degraded performance, do not twist, fold, pinch, or step on the cables.

4. Squeeze the latch on the cam handle until it releases, open the cam handle fully to release the controller canister from the midplane, and then, using two hands, pull the controller canister out of the chassis.
5. Place the controller on a flat, static-free surface with the removable cover facing up.
6. Open the cover by pressing the blue buttons on the sides of the controller canister to release the cover, and then rotate the cover up and off of the controller canister.

#### Step 4: Determine parts to transfer to replacement controller

Your replacement controller may come with parts pre-installed. Determine which parts must be transferred to the replacement controller canister.


1. Place the replacement controller on a flat, static-free surface with the removable cover facing up.
2. Open the cover by pressing the blue buttons on the sides of the controller canister to release the cover, and then rotate the cover up and off of the controller canister.
3. Determine if the replacement controller contains a battery and/or DIMMs. If it does, reinstall the controller cover and go to [Step 8: Replace controller](#). Otherwise:
  - If the replacement controller does not include a battery or DIMM, go to [Step 5: Remove the battery](#).
  - If the replacement controller includes a battery but not a DIMM, go to [Step 6: Move the DIMMs](#).

#### Step 5: Remove the battery

Remove the battery from the impaired controller and install it in the replacement controller if necessary.

##### Steps

1. Remove the battery from the controller canister:
  - a. Press the blue button on the side of the controller canister.
  - b. Slide the battery up until it clears the holding brackets, and then lift the battery out of the controller canister.
  - c. Unplug the battery plug by squeezing the clip on the face of the battery plug to release the plug from the socket, and then unplug the battery cable from the socket.



1	Battery release tab
2	Battery power connector

2. Move the battery to the replacement controller canister and install it:
  - a. Align the battery with the holding brackets on the sheet metal side wall, but do not connect it. You will plug it in once the rest of the components are moved to the replacement controller canister.
3. If the replacement controller has pre-installed DIMMs, go to [Step 7: Install the battery](#). Otherwise, continue to the next step.

## Step 6: Move the DIMMs

Remove the DIMMs from the impaired controller canister and install them into the replacement controller canister.

### Steps

1. Locate the DIMMs on your controller canister.



Note the location of the DIMM in the sockets so that you can insert the DIMM in the same location in the replacement controller canister and in the proper orientation. Remove the DIMMs from the impaired controller canister:


- a. Eject the DIMM from its slot by slowly pushing apart the two DIMM ejector tabs on either side of the DIMM.

The DIMM will rotate up a little.

- b. Rotate the DIMM as far as it will go, and then slide the DIMM out of the socket.



Carefully hold the DIMM by the edges to avoid pressure on the components on the DIMM circuit board.



1	DIMM ejector tabs
2	DIMMs

2. Verify that the battery is not plugged into the replacement controller canister.
3. Install the DIMMs in the replacement controller in the same place they were in the impaired controller:
  - a. Push carefully, but firmly, on the top edge of the DIMM until the ejector tabs snap into place over the notches at the ends of the DIMM.

The DIMM fits tightly in the slot, but should go in easily. If not, realign the DIMM with the slot and reinsert it.



Visually inspect the DIMM to verify that it is evenly aligned and fully inserted into the slot.

4. Repeat these steps for the other DIMM.
5. If the replacement controller has a pre-installed battery, go to [Step 8: Replace controller](#). Otherwise, continue to the next step.

## Step 7: Install the battery

Install the battery into the replacement controller canister.

### Steps

1. Plug the battery plug back into the socket on the controller canister.

Make sure that the plug locks down into the battery socket on the motherboard.

2. Aligning the battery with the holding brackets on the sheet metal side wall.
3. Slide the battery pack down until the battery latch engages and clicks into the opening on the side wall.
4. Reinstall the controller canister cover and lock it into place.

## Step 8: Replace controller

Install the replacement controller and verify that the node has rejoined the grid.

### Steps

1. Install the replacement controller into the appliance.
  - a. Turn the controller over, so that the removable cover faces down.
  - b. With the cam handle in the open position, slide the controller all the way into the appliance.
  - c. Move the cam handle to the left to lock the controller in place.
  - d. Replace the cables.
  - e. If the original controller used DHCP for the IP address, locate the MAC address on the label on the back of the replacement controller. Ask your network administrator to associate the DNS/network and IP address for the controller you removed with the MAC address for the replacement controller.



If the original controller did not use DHCP for the IP address, the new controller will adopt the IP address of the controller you removed.

2. Bring the controller online using SANtricity System Manager:
  - a. Select **Hardware**.
  - b. If the graphic shows the drives, select **Controllers & Components**.
  - c. Select the controller you want to place online.
  - d. Select **Place Online** from the context menu, and confirm that you want to perform the operation.
3. As the controller boots, check the controller LEDs.
  - The amber Attention LED on the controller turns on and then turns off, unless there is an error.
  - The Host Link LEDs might be on, blinking, or off, depending on the host interface.
4. When the controller is back online, confirm that its status is Optimal and check the controller shelf's Attention LEDs.

If the status is not Optimal or if any of the Attention LEDs are on, confirm that all cables are correctly seated and the controller canister is installed correctly. If necessary, remove and reinstall the controller canister.



If you cannot resolve the problem, contact technical support.

5. If required, redistribute all volumes back to their preferred owner using SANtricity System Manager.
  - a. Select **Storage > Volumes**.
  - b. Select **More > Redistribute volumes**.
6. Collect support data for your storage array using SANtricity System Manager.
  - a. Select **Support > Support Center > Diagnostics**.
  - b. Select **Collect Support Data**.
  - c. Click **Collect**.

The file is saved in the Downloads folder for your browser with the name, **support-data.7z**.

7. If you placed the appliance in maintenance mode during this procedure, exit maintenance mode and wait for the node to reboot and rejoin the grid. This process can take up to 20 minutes. To confirm that the reboot is complete and that the node has rejoined the grid:
  - a. In the Grid Manager, select **NODES**.
  - b. Verify that the appliance node has a normal status (green check mark icon  to the left of the node name), which indicates that no alerts are active and the node is connected to the grid.

#### What's next?

Your controller replacement is complete. You can resume normal operations.

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return & Replacements](#) page for further information.

## Relocate SGF6112 or SG6100-CN in cabinet or rack

Remove the SGF6112 or SG6100-CN from a cabinet or rack to access the top cover or to move the appliance to a different location, then reinstall the appliance into a cabinet or rack when hardware maintenance is complete.

### Remove SGF6112 or SG6100-CN from cabinet or rack

#### Before you begin

- You have labels to identify each cable that is connected to the SGF6112 or SG6100-CN.
- You have [physically located the SGF6112 or SG6100-CN](#) where you are performing maintenance in the data center.
- You have [shut down the SGF6112 or SG6100-CN](#).



Don't shut down the appliance using the power switch.

#### Steps

1. Label and then disconnect the appliance power cables.
2. Wrap the strap end of the ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
3. Label and then disconnect the appliance data cables and any SFP+ or SFP28 transceivers.



To prevent degraded performance, don't twist, fold, pinch, or step on the cables.

4. Loosen the two captive screws on the appliance front panel.



5. Slide the SGF6112 or SG6100-CN forward out of the rack until the mounting rails are fully extended and you hear the latches on both sides click.

The appliance top cover is accessible.

6. Optional: If you are fully removing the appliance from the cabinet or rack, follow the instructions for the rail kit to remove the appliance from the rails.

After replacing the part, return the failed part to NetApp, as described in the RMA instructions shipped with the kit. See the [Part Return & Replacements](#) page for further information.

## Reinstall SGF6112 or SG6100-CN into cabinet or rack


### Before you begin

You have [reinstalled the appliance cover](#).

### Steps

1. Press the blue rail releases both rack rails at the same time and slide the SGF6112 into the rack until it is fully seated.

When you can't move the controller any further, pull the blue latches on both sides of the chassis to slide the controller all the way in.



Don't attach the front bezel until after you power on the controller.

2. Tighten the captive screws on the controller front panel to secure the controller in the rack.



3. Wrap the strap end of the ESD wristband around your wrist, and secure the clip end to a metal ground to prevent static discharge.
4. [Reconnect the controller data cables and any SFP+ or SFP28 transceivers.](#)



To prevent degraded performance, don't twist, fold, pinch, or step on the cables.

5. [Reconnect the controller power cables.](#)

#### After you finish

[Restart the appliance.](#)

## Copyright information

Copyright © 2025 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

**LIMITED RIGHTS LEGEND:** Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.