



Instale o desempate 1,4

ONTAP MetroCluster

NetApp
January 10, 2025

Índice

- Instale o desempate 1,4 1
- Instale dependências do MetroCluster tiebreaker 1,4 1
- Instale ou atualize para o tiebreaker 1,4 14

Instale o desempate 1,4

Instale dependências do MetroCluster tiebreaker 1,4

Dependendo do sistema operacional Linux host, instale um servidor MySQL ou MariaDB antes de instalar ou atualizar o software tiebreaker.

Passos

1. [Instale o JDK](#).
2. Instale o servidor MySQL ou MariaDB:

Se o host Linux for	Então...
Red Hat Enterprise Linux 7/CentOS 7	Instale as versões do MySQL Server 5.5.30 ou posterior e 5,6.x no Red Hat Enterprise Linux 7 ou CentOS 7
Red Hat Enterprise Linux 8	Instale o servidor MariaDB no Red Hat Enterprise Linux 8

Instale o JDK

Você deve instalar o JDK em seu sistema host antes de instalar ou atualizar o software tiebreaker. O tiebreaker 1,4 e anterior suporta JDK 1,8.0. (JRE 8).

Passos

1. Faça login como um usuário "root".

```
login as: root
root@mcctb's password:
Last login: Fri Jan  8 21:33:00 2017 from host.domain.com
```

2. Instale o JDK 1,8.0:

```
yum install java-1.8.0-openjdk.x86_64
```

```

[root@mcctb ~]# yum install java-1.8.0-openjdk.x86_64
Loaded plugins: fastestmirror, langpacks
Loading mirror speeds from cached hostfile
... shortened....
Dependencies Resolved

=====
Package                Arch    Version                               Repository    Size
=====
Installing:
  java-1.8.0-openjdk    x86_64  1:1.8.0.144-0.b01.el7_4             updates      238 k
  ..
  ..
Transaction Summary
=====
Install 1 Package (+ 4 Dependent packages)

Total download size: 34 M
Is this ok [y/d/N]: y

Installed:
java-1.8.0-openjdk.x86_64 1:1.8.0.144-0.b01.el7_4
Complete!

```

Instale as versões do MySQL Server 5.5.30 ou posterior e 5,6.x no Red Hat Enterprise Linux 7 ou CentOS 7

Você deve instalar o MySQL Server 5.5.30 ou posterior e a versão 5,6.x no sistema host antes de instalar ou atualizar o software tiebreaker. Para Red Hat Enterprise Linux 8, [Instale o servidor MariaDB](#).

Passos

1. Faça login como usuário root.

```

login as: root
root@mcctb's password:
Last login: Fri Jan  8 21:33:00 2016 from host.domain.com

```

2. Adicione o repositório MySQL ao seu sistema host:

```

[root@mcctb ~]# yum localinstall https://dev.mysql.com/get/mysql57-community-release-el6-11.noarch.rpm

```

```

Loaded plugins: product-id, refresh-packagekit, security, subscription-
manager
Setting up Local Package Process
Examining /var/tmp/yum-root-LLUw0r/mysql-community-release-el6-
5.noarch.rpm: mysql-community-release-el6-5.noarch
Marking /var/tmp/yum-root-LLUw0r/mysql-community-release-el6-
5.noarch.rpm to be installed
Resolving Dependencies
--> Running transaction check
---> Package mysql-community-release.noarch 0:el6-5 will be installed
--> Finished Dependency Resolution
Dependencies Resolved

=====
=====
Package                Arch    Version
                        Repository

Size
=====
=====
Installing:
mysql-community-release
                        noarch el6-5 /mysql-community-release-el6-
5.noarch 4.3 k
Transaction Summary
=====
=====
Install                1 Package(s)
Total size: 4.3 k
Installed size: 4.3 k
Is this ok [y/N]: y
Downloading Packages:
Running rpm_check_debug
Running Transaction Test
Transaction Test Succeeded
Running Transaction
  Installing : mysql-community-release-el6-5.noarch
1/1
  Verifying  : mysql-community-release-el6-5.noarch
1/1
Installed:
  mysql-community-release.noarch 0:el6-5
Complete!

```

3. Desative o repositório MySQL 57:

```
[root@mcctb ~]# yum-config-manager --disable mysql57-community
```

4. Ative o repositório MySQL 56:

```
[root@mcctb ~]# yum-config-manager --enable mysql56-community
```

5. Ativar o repositório:

```
[root@mcctb ~]# yum repolist enabled | grep "mysql.-community."
```

```
mysql-connectors-community           MySQL Connectors Community
21
mysql-tools-community                MySQL Tools Community
35
mysql56-community                    MySQL 5.6 Community Server
231
```

6. Instale o servidor da Comunidade MySQL:

```
[root@mcctb ~]# yum install mysql-community-server
```

```
Loaded plugins: product-id, refresh-packagekit, security, subscription-
manager
This system is not registered to Red Hat Subscription Management. You
can use subscription-manager
to register.
Setting up Install Process
Resolving Dependencies
--> Running transaction check
.....Output truncated.....
---> Package mysql-community-libs-compat.x86_64 0:5.6.29-2.el6 will be
obsoleting
--> Finished Dependency Resolution
Dependencies Resolved

=====
=====
Package                               Arch    Version           Repository
Size
=====
Installing:
mysql-community-client                 x86_64  5.6.29-2.el6     mysql56-community
18 M
    replacing mysql.x86_64 5.1.71-1.el6
mysql-community-libs                   x86_64  5.6.29-2.el6     mysql56-community
1.9 M
```

```
replacing mysql-libs.x86_64 5.1.71-1.el6
mysql-community-libs-compat x86_64 5.6.29-2.el6 mysql56-community
1.6 M
replacing mysql-libs.x86_64 5.1.71-1.el6
mysql-community-server x86_64 5.6.29-2.el6 mysql56-community
53 M
replacing mysql-server.x86_64 5.1.71-1.el6
Installing for dependencies:
mysql-community-common x86_64 5.6.29-2.el6 mysql56-community
308 k
```

Transaction Summary

```
=====
=====
```

```
Install          5 Package(s)
Total download size: 74 M
```

Is this ok [y/N]: y

Downloading Packages:

```
(1/5): mysql-community-client-5.6.29-2.el6.x86_64.rpm      | 18 MB
00:28
(2/5): mysql-community-common-5.6.29-2.el6.x86_64.rpm     | 308 kB
00:01
(3/5): mysql-community-libs-5.6.29-2.el6.x86_64.rpm      | 1.9 MB
00:05
(4/5): mysql-community-libs-compat-5.6.29-2.el6.x86_64.rpm | 1.6 MB
00:05
(5/5): mysql-community-server-5.6.29-2.el6.x86_64.rpm    | 53 MB
03:42
```

```
-----
-----
```

```
Total                               289 kB/s | 74 MB
04:24
```

warning: rpmts_HdrFromFdno: Header V3 DSA/SHA1 Signature, key ID <key_id> NOKEY

Retrieving key from file:/etc/pki/rpm-gpg/RPM-GPG-KEY-mysql

Importing GPG key 0x5072E1F5:

Userid : MySQL Release Engineering <mysql-build@oss.oracle.com>

Package: mysql-community-release-el6-5.noarch

(@/mysql-community-release-el6-5.noarch)

From : file:/etc/pki/rpm-gpg/RPM-GPG-KEY-mysql

Is this ok [y/N]: y

Running rpm_check_debug

Running Transaction Test

Transaction Test Succeeded

Running Transaction

Installing : mysql-community-common-5.6.29-2.el6.x86_64

```
....Output truncated....
```

```
1.el6.x86_64
```

```
7/8
```

```
Verifying : mysql-5.1.71-1.el6.x86_64
```

```
8/8
```

```
Installed:
```

```
mysql-community-client.x86_64 0:5.6.29-2.el6
```

```
mysql-community-libs.x86_64 0:5.6.29-2.el6
```

```
mysql-community-libs-compat.x86_64 0:5.6.29-2.el6
```

```
mysql-community-server.x86_64 0:5.6.29-2.el6
```

```
Dependency Installed:
```

```
mysql-community-common.x86_64 0:5.6.29-2.el6
```

```
Replaced:
```

```
mysql.x86_64 0:5.1.71-1.el6 mysql-libs.x86_64 0:5.1.71-1.el6
```

```
mysql-server.x86_64 0:5.1.71-1.el6
```

```
Complete!
```

7. Inicie o servidor MySQL:

```
[root@mcctb ~]# service mysqld start
```



```
Initializing MySQL database: 2016-04-05 19:44:38 0 [Warning] TIMESTAMP
with implicit DEFAULT value is deprecated. Please use
--explicit_defaults_for_timestamp server option (see documentation
for more details).
2016-04-05 19:44:38 0 [Note] /usr/sbin/mysqld (mysqld 5.6.29)
starting as process 2487 ...
2016-04-05 19:44:38 2487 [Note] InnoDB: Using atomics to ref count
buffer pool pages
2016-04-05 19:44:38 2487 [Note] InnoDB: The InnoDB memory heap is
disabled
....Output truncated....
2016-04-05 19:44:42 2509 [Note] InnoDB: Shutdown completed; log sequence
number 1625987
```

PLEASE REMEMBER TO SET A PASSWORD FOR THE MySQL root USER!
To do so, start the server, then issue the following commands:

```
/usr/bin/mysqladmin -u root password 'new-password'
/usr/bin/mysqladmin -u root -h mcctb password 'new-password'
```

Alternatively, you can run:

```
/usr/bin/mysql_secure_installation
```

which will also give you the option of removing the test
databases and anonymous user created by default. This is
strongly recommended for production servers.

.....Output truncated.....

```
WARNING: Default config file /etc/my.cnf exists on the system
This file will be read by default by the MySQL server
If you do not want to use this, either remove it, or use the
--defaults-file argument to mysqld_safe when starting the server
```

```
Starting mysqld: [ OK ]
```

8. Confirme se o servidor MySQL está em execução:

```
[root@mcctb ~]# service mysqld status
```

```
mysqld (pid 2739) is running...
```

9. Configurar definições de segurança e palavra-passe:

```
[root@mcctb ~]# mysql_secure_installation
```

NOTE: RUNNING ALL PARTS OF THIS SCRIPT IS RECOMMENDED FOR ALL MySQL
SERVERS IN PRODUCTION USE! PLEASE READ EACH STEP CAREFULLY!

In order to log into MySQL to secure it, we'll need the current password for the root user. If you've just installed MySQL, and you haven't set the root password yet, the password will be blank, so you should just press enter here.

Enter current password for root (enter for none): <== on default
install

hit enter here

OK, successfully used password, moving on...

Setting the root password ensures that nobody can log into the MySQL root user without the proper authorization.

Set root password? [Y/n] y

New password:

Re-enter new password:

Password updated successfully!

Reloading privilege tables..

... Success!

By default, a MySQL installation has an anonymous user, allowing anyone to log into MySQL without having to have a user account created for them. This is intended only for testing, and to make the installation go a bit smoother. You should remove them before moving into a production environment.

Remove anonymous users? [Y/n] y

... Success!

Normally, root should only be allowed to connect from 'localhost'. This ensures that someone cannot guess at the root password from the network.

Disallow root login remotely? [Y/n] y

... Success!

By default, MySQL comes with a database named 'test' that anyone can access. This is also intended only for testing, and should be removed before moving into a production environment.

Remove test database and access to it? [Y/n] y

- Dropping test database...

ERROR 1008 (HY000) at line 1: Can't drop database 'test';

```
database doesn't exist
```

```
... Failed! Not critical, keep moving...  
- Removing privileges on test database...  
... Success!
```

Reloading the privilege tables will ensure that all changes made so far will take effect immediately.

```
Reload privilege tables now? [Y/n] y
```

```
... Success!
```

All done! If you've completed all of the above steps, your MySQL installation should now be secure.

Thanks for using MySQL!

```
Cleaning up...
```

10. Verifique se o login do MySQL está funcionando:

```
[root@mcctb ~]# mysql -u root -p
```

```
Enter password: <configured_password>
```

```
Welcome to the MySQL monitor. Commands end with ; or \g.
```

```
Your MySQL connection id is 17
```

```
Server version: 5.6.29 MySQL Community Server (GPL)
```

```
Copyright (c) 2000, 2016, Oracle and/or its affiliates. All rights reserved.
```

```
Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.
```

```
Type 'help;' or '\h' for help. Type '\c' to clear the current input statement.
```

```
mysql>
```

Quando o login do MySQL está funcionando como esperado, a saída termina `mysql>` no prompt.

Ative a configuração de inicialização automática do MySQL

Você deve verificar se o recurso autostart está ativado para o daemon MySQL. Ativar o daemon MySQL reinicia automaticamente o MySQL se o sistema no qual o software tiebreaker do MetroCluster reside for reinicializado. Se o daemon MySQL não estiver em execução, o software tiebreaker continua em execução, mas não pode ser reiniciado e as alterações de configuração não podem ser feitas.

Passo

1. Verifique se o MySQL está habilitado para iniciar automaticamente quando inicializado:

```
[root@mcctb ~]# systemctl list-unit-files mysqld.service
```

```
UNIT FILE           State
-----
mysqld.service     enabled
```

Se o MySQL não estiver habilitado para iniciar automaticamente quando inicializado, consulte a documentação do MySQL para ativar o recurso de inicialização automática para sua instalação.

Instale o servidor MariaDB no Red Hat Enterprise Linux 8

Você deve instalar o servidor MariaDB no sistema host antes de instalar ou atualizar o software tiebreaker. Para Red Hat Enterprise Linux 7 ou CentOS 7, [Instale o MySQL Server](#).

Antes de começar

Seu sistema host deve estar em execução no Red Hat Enterprise Linux (RHEL) 8.

Passos

1. Inicie sessão como `root` utilizador.

```
login as: root
root@mcctb's password:
Last login: Fri Jan  8 21:33:00 2017 from host.domain.com
```

2. Instale o servidor MariaDB:

```
[root@mcctb ~]# yum install mariadb-server.x86_64
```

```
[root@mcctb ~]# yum install mariadb-server.x86_64
Loaded plugins: fastestmirror, langpacks
...
...

=====
===
Package                Arch  Version           Repository
Size
=====
Installing:
mariadb-server         x86_64  1:5.5.56-2.el7   base
11 M
```

```
Installing for dependencies:
```

```
Transaction Summary
```

```
=====
```

```
Install 1 Package (+8 Dependent packages)
Upgrade          ( 1 Dependent package)
```

```
Total download size: 22 M
```

```
Is this ok [y/d/N]: y
```

```
Downloading packages:
```

```
No Presto metadata available for base warning:
```

```
/var/cache/yum/x86_64/7/base/packages/mariadb-libs-5.5.56-2.e17.x86_64.rpm:
```

```
Header V3 RSA/SHA256 Signature,
```

```
key ID f4a80eb5: NOKEY] 1.4 MB/s | 3.3 MB 00:00:13 ETA
```

```
Public key for mariadb-libs-5.5.56-2.e17.x86_64.rpm is not installed
```

```
(1/10): mariadb-libs-5.5.56-2.e17.x86_64.rpm | 757 kB 00:00:01
```

```
..
```

```
..
```

```
(10/10): perl-Net-Daemon-0.48-5.e17.noarch.rpm | 51 kB 00:00:01
```

```
-----
```

```
Installed:
```

```
  mariadb-server.x86_64 1:5.5.56-2.e17
```

```
Dependency Installed:
```

```
  mariadb.x86_64 1:5.5.56-2.e17
```

```
  perl-Compress-Raw-Bzip2.x86_64 0:2.061-3.e17
```

```
  perl-Compress-Raw-Zlib.x86_64 1:2.061-4.e17
```

```
  perl-DBD-MySQL.x86_64 0:4.023-5.e17
```

```
  perl-DBI.x86_64 0:1.627-4.e17
```

```
  perl-IO-Compress.noarch 0:2.061-2.e17
```

```
  perl-Net-Daemon.noarch 0:0.48-5.e17
```

```
  perl-PlRPC.noarch 0:0.2020-14.e17
```

```
Dependency Updated:
```

```
  mariadb-libs.x86_64 1:5.5.56-2.e17
```

```
Complete!
```

3. Inicie o servidor MariaDB:

```
[root@mcctb ~]# systemctl start mariadb
```

4. Verifique se o servidor MariaDB foi iniciado:

```
[root@mcctb ~]# systemctl status mariadb
```

```
[root@mcctb ~]# systemctl status mariadb
mariadb.service - MariaDB database server
...
Nov 08 21:28:59 mcctb systemd[1]: Starting MariaDB database server...
...
Nov 08 21:29:01 mcctb systemd[1]: Started MariaDB database server.
```

5. Configure as definições de segurança e palavra-passe:



Quando for solicitada a palavra-passe raiz, deixe-a vazia e prima ENTER para continuar a configurar as definições de segurança e palavra-passe.

```
[root@mcctb ~]# mysql_secure_installation
```

```
root@localhost systemd]# mysql_secure_installation

NOTE: RUNNING ALL PARTS OF THIS SCRIPT IS RECOMMENDED FOR ALL MariaDB
SERVERS IN PRODUCTION USE! PLEASE READ EACH STEP CAREFULLY!

In order to log into MariaDB to secure it, we'll need the current
password for the root user. If you've just installed MariaDB, and
you haven't set the root password yet, the password will be blank,
so you should just press enter here.

Enter current password for root (enter for none):
OK, successfully used password, moving on...

Setting the root password ensures that nobody can log into the MariaDB
root user without the proper authorisation.

Set root password? [Y/n] y
New password:
Re-enter new password:
Password updated successfully!
Reloading privilege tables..
... Success!

By default, a MariaDB installation has an anonymous user, allowing
anyone
to log into MariaDB without having to have a user account created for
them. This is intended only for testing, and to make the installation
go a bit smoother. You should remove them before moving into a
```

production environment.

Remove anonymous users? [Y/n] y

... Success!

Normally, root should only be allowed to connect from 'localhost'. This ensures that someone cannot guess at the root password from the network.

Disallow root login remotely? [Y/n] y

... Success!

By default, MariaDB comes with a database named 'test' that anyone can access. This is also intended only for testing, and should be removed before moving into a production environment.

Remove test database and access to it? [Y/n] y

- Dropping test database...

... Success!

- Removing privileges on test database...

... Success!

Reloading the privilege tables will ensure that all changes made so far will take effect immediately.

Reload privilege tables now? [Y/n]

... Success!

Cleaning up...

All done! If you've completed all of the above steps, your MariaDB installation should now be secure.

Thanks for using MariaDB!

Ative a configuração de início automático para o servidor MariaDB

Você deve verificar se o recurso de inicialização automática está ativado para o servidor MariaDB. Se você não ativar o recurso de inicialização automática e o sistema no qual o software tiebreaker do MetroCluster reside precisar reinicializar, o software tiebreaker continuará em execução, mas o serviço MariaDB não poderá ser reiniciado e as alterações de configuração não poderão ser feitas.

Passos

1. Ative o serviço de arranque automático:

```
[root@mcctb ~]# systemctl enable mariadb.service
```

2. Verifique se o MariaDB está habilitado para iniciar automaticamente quando inicializado:

```
[root@mcctb ~]# systemctl list-unit-files mariadb.service
```

UNIT FILE	State
-----	-----
mariadb.service	enabled

Instale ou atualize para o tiebreaker 1,4

Execute uma nova instalação ou atualização para o tiebreaker 1,4 no sistema operacional Linux host para monitorar as configurações do MetroCluster.

Sobre esta tarefa

- Seu sistema de storage deve estar executando uma versão compatível do ONTAP. Consulte "[Requisitos de software](#)" a tabela para obter mais detalhes.
- Você deve ter instalado o OpenJDK usando o `yum install java-x.x.x-openjdk` comando. O tiebreaker 1,4 e anterior suporta JDK 1.8.0 (JRE 8).

Passos

1. Baixe o software tiebreaker do MetroCluster.

["MetroCluster tiebreaker \(Downloads\) - Site de suporte da NetApp"](#)

2. Faça login no host como usuário raiz.

3. instale ou atualize o software tiebreaker:

Selecione o procedimento correto dependendo se você está executando uma nova instalação ou atualizando uma instalação existente.

Execute uma nova instalação

- a. Instale o software tiebreaker executando o :

```
rpm -ivh NetApp-MetroCluster-Tiebreaker-Software-1.4-1.x86_64.rpm
```

O sistema exibe a seguinte saída para uma instalação bem-sucedida:

```
Verifying...
##### [100%]
Preparing...
##### [100%]
Updating / installing...
   1:NetApp-MetroCluster-Tiebreaker-
So##### [100%]
Post installation start Fri Apr  5 02:28:09 EDT 2024
Enter MetroCluster Tiebreaker user password:

Please enter mysql root password when prompted
Enter password:
Synchronizing state of netapp-metrocluster-tiebreaker-
software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-
metrocluster-tiebreaker-software
Created symlink /etc/systemd/system/multi-
user.target.wants/netapp-metrocluster-tiebreaker-software.service
→ /etc/systemd/system/netapp-metrocluster-tiebreaker-
software.service.
Attempting to start NetApp MetroCluster Tiebreaker software
services
Started NetApp MetroCluster Tiebreaker software services
Enabled autostart of NetApp MetroCluster Tiebreaker software
daemon during boot
Created symbolic link for NetApp MetroCluster Tiebreaker software
CLI
Post installation end Fri Apr  5 02:28:22 EDT 2024
Successfully installed NetApp MetroCluster Tiebreaker software
version 1.4.
```

Atualizar uma instalação existente

- a. Atualize o software tiebreaker.

```
[root@mcctb ~]# rpm -Uvh NetApp-MetroCluster-Tiebreaker-Software-1.4-1.x86_64.rpm
```

O sistema exibe a seguinte saída para uma atualização bem-sucedida:

```
Verifying...
##### [100%]
Preparing...
##### [100%]
Upgrading NetApp MetroCluster Tiebreaker software....
Stopping NetApp MetroCluster Tiebreaker software services before
upgrade.
Updating / installing...
 1:NetApp-MetroCluster-Tiebreaker-
So##### [ 50%]
Post installation start Mon Apr  8 06:29:51 EDT 2024
Synchronizing state of netapp-metrocluster-tiebreaker-
software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-
metrocluster-tiebreaker-software
Attempting to start NetApp MetroCluster Tiebreaker software
services
Started NetApp MetroCluster Tiebreaker software services
Enabled autostart of NetApp MetroCluster Tiebreaker software
daemon during boot
Created symbolic link for NetApp MetroCluster Tiebreaker software
CLI
Post upgrade end Mon Apr  8 06:29:51 EDT 2024
Successfully upgraded NetApp MetroCluster Tiebreaker software to
version 1.4.
Cleaning up / removing...
 2:NetApp-MetroCluster-Tiebreaker-
So##### [100%]
```



Se você digitar a senha raiz errada do MySQL, o software tiebreaker indica que ele foi instalado com sucesso, mas exibe mensagens "Acesso negado". Para resolver o problema, você deve desinstalar o software tiebreaker usando o `rpm -e` comando e reinstalar o software usando a senha raiz do MySQL correta.

4. Verifique a conectividade tiebreaker com o software MetroCluster abrindo uma conexão SSH do host tiebreaker para cada uma das LIFs de gerenciamento de nós e LIFs de gerenciamento de cluster.

Informações relacionadas

"Suporte à NetApp"

Informações sobre direitos autorais

Copyright © 2025 NetApp, Inc. Todos os direitos reservados. Impresso nos EUA. Nenhuma parte deste documento protegida por direitos autorais pode ser reproduzida de qualquer forma ou por qualquer meio — gráfico, eletrônico ou mecânico, incluindo fotocópia, gravação, gravação em fita ou storage em um sistema de recuperação eletrônica — sem permissão prévia, por escrito, do proprietário dos direitos autorais.

O software derivado do material da NetApp protegido por direitos autorais está sujeito à seguinte licença e isenção de responsabilidade:

ESTE SOFTWARE É FORNECIDO PELA NETAPP "NO PRESENTE ESTADO" E SEM QUAISQUER GARANTIAS EXPRESSAS OU IMPLÍCITAS, INCLUINDO, SEM LIMITAÇÕES, GARANTIAS IMPLÍCITAS DE COMERCIALIZAÇÃO E ADEQUAÇÃO A UM DETERMINADO PROPÓSITO, CONFORME A ISENÇÃO DE RESPONSABILIDADE DESTES DOCUMENTOS. EM HIPÓTESE ALGUMA A NETAPP SERÁ RESPONSÁVEL POR QUALQUER DANO DIRETO, INDIRETO, INCIDENTAL, ESPECIAL, EXEMPLAR OU CONSEQUENCIAL (INCLUINDO, SEM LIMITAÇÕES, AQUISIÇÃO DE PRODUTOS OU SERVIÇOS SOBRESSALIENTES; PERDA DE USO, DADOS OU LUCROS; OU INTERRUPÇÃO DOS NEGÓCIOS), INDEPENDENTEMENTE DA CAUSA E DO PRINCÍPIO DE RESPONSABILIDADE, SEJA EM CONTRATO, POR RESPONSABILIDADE OBJETIVA OU PREJUÍZO (INCLUINDO NEGLIGÊNCIA OU DE OUTRO MODO), RESULTANTE DO USO DESTES SOFTWARES, MESMO SE ADVERTIDA DA RESPONSABILIDADE DE TAL DANO.

A NetApp reserva-se o direito de alterar quaisquer produtos descritos neste documento, a qualquer momento e sem aviso. A NetApp não assume nenhuma responsabilidade nem obrigação decorrentes do uso dos produtos descritos neste documento, exceto conforme expressamente acordado por escrito pela NetApp. O uso ou a compra deste produto não representam uma licença sob quaisquer direitos de patente, direitos de marca comercial ou quaisquer outros direitos de propriedade intelectual da NetApp.

O produto descrito neste manual pode estar protegido por uma ou mais patentes dos EUA, patentes estrangeiras ou pedidos pendentes.

LEGENDA DE DIREITOS LIMITADOS: o uso, a duplicação ou a divulgação pelo governo estão sujeitos a restrições conforme estabelecido no subparágrafo (b)(3) dos Direitos em Dados Técnicos - Itens Não Comerciais no DFARS 252.227-7013 (fevereiro de 2014) e no FAR 52.227- 19 (dezembro de 2007).

Os dados aqui contidos pertencem a um produto comercial e/ou serviço comercial (conforme definido no FAR 2.101) e são de propriedade da NetApp, Inc. Todos os dados técnicos e software de computador da NetApp fornecidos sob este Contrato são de natureza comercial e desenvolvidos exclusivamente com despesas privadas. O Governo dos EUA tem uma licença mundial limitada, irrevogável, não exclusiva, intransferível e não sublicenciável para usar os Dados que estão relacionados apenas com o suporte e para cumprir os contratos governamentais desse país que determinam o fornecimento de tais Dados. Salvo disposição em contrário no presente documento, não é permitido usar, divulgar, reproduzir, modificar, executar ou exibir os dados sem a aprovação prévia por escrito da NetApp, Inc. Os direitos de licença pertencentes ao governo dos Estados Unidos para o Departamento de Defesa estão limitados aos direitos identificados na cláusula 252.227-7015(b) (fevereiro de 2014) do DFARS.

Informações sobre marcas comerciais

NETAPP, o logotipo NETAPP e as marcas listadas em <http://www.netapp.com/TM> são marcas comerciais da NetApp, Inc. Outros nomes de produtos e empresas podem ser marcas comerciais de seus respectivos proprietários.