Manage cluster NTP servers

REST API reference

NetApp
September 12, 2025

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-98/cluster_ntp_servers_endpoint_overview.html on September 12, 2025. Always check docs.netapp.com for the latest.

Table of Contents

Manage cluster NTP servers . . . 1
- Cluster NTP servers endpoint overview . . . 1
  - Overview . . . 1
  - Adding an NTP server to a cluster . . . 1
  - Examples . . . 1
- Retrieve external NTP time servers . . . 2
  - Related ONTAP commands . . . 2
  - Learn more . . . 2
  - Parameters . . . 3
  - Response . . . 4
  - Error . . . 5
  - Definitions . . . 6
- Validate an external NTP time server . . . 8
  - Default property values . . . 8
  - Related ONTAP commands . . . 8
  - Learn more . . . 9
  - Parameters . . . 9
  - Request Body . . . 9
  - Response . . . 10
  - Error . . . 10
  - Definitions . . . 11
- Delete an external NTP server . . . 13
  - Related ONTAP commands . . . 13
  - Learn more . . . 13
  - Parameters . . . 13
  - Response . . . 14
  - Error . . . 15
  - Definitions . . . 15
- Retrieve an external NTP server configuration . . . 16
  - Related ONTAP commands . . . 17
  - Learn more . . . 17
  - Parameters . . . 17
  - Response . . . 17
  - Error . . . 18
  - Definitions . . . 19
- Update an NTP server configuration after validation . . . 21
  - Related ONTAP commands . . . 21
  - Learn more . . . 21
  - Parameters . . . 21
  - Request Body . . . 22
  - Response . . . 23
  - Error . . . 23
  - Definitions . . . 24

Manage cluster NTP servers

Cluster NTP servers endpoint overview

Overview

You can use this API to add external NTP servers to a cluster, update the configuration, use NTP keys, and retrieve the current NTP server configuration.

Adding an NTP server to a cluster

To add an NTP server to a cluster, issue a POST /cluster/ntp/servers request.

Fields used for adding an NTP server

Except for the name of the NTP server (host name or IP address), which is specified by the server, all fields are optional:

- `version`
- `key`

If the key is provided in POST, `authentication_enabled` is set to `true` by default.

Examples

Adding an NTP server

```
# Body
add_ntp_server.txt(body):
{
"server": "time.nist.gov"
}

# Request
curl -X POST "https://<mgmt-ip>/api/cluster/ntp/servers" -d
"@add_ntp_server.txt"
```

Adding an NTP server with an authentication key

```
# Body
add_authenticated_ntp_server.txt(body):
{
"server": "time.nist.gov",
"key": { "id": 10 }
}

# Request
curl -X POST "https://<mgmt-ip>/api/cluster/ntp/servers" -d
"@add_authenticated_ntp_server.txt"
```

Enabling a previously configured shared key (ID, type, and value) for an NTP server

A combination of key number or identifier (ID), type of key, and shared key value is created with /api/cluster/ntp/keys. This operation will validate the NTP authentication works.

```
# Body
enable_shared_key.txt(body):
{
"key": { "id": 10 },
"authentication_enabled": true
}

# Request
curl -X PATCH "https://<mgmt-ip>/api/cluster/ntp/servers/time.nist.gov" -d
"@enable_shared_key.txt"
```

Retrieve external NTP time servers

GET `/cluster/ntp/servers`

Introduced In: 9.7

Retrieves the collection of external NTP time servers ONTAP uses for time adjustment and correction.

Related ONTAP commands

- `cluster time-service ntp server show`

Learn more

- DOC /cluster/ntp/servers

Parameters

Name	Type	In	Required	Description
key.id	integer	query	False	Filter by key.id
version	string	query	False	Filter by version
authentication_enabled	boolean	query	False	Filter by authentication_enabled
server	string	query	False	Filter by server
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 1 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records.
records	array[ntp_server]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": "3",
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "authentication_enabled": 1,
      "key": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "id": "10"
      },
      "server": "time.nist.gov",
      "version": "auto"
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

ntp_key_reference

Name	Type	Description
_links	_links	
id	integer	NTP symmetric authentication key identifier or index number (ID). This ID, the type of cryptographic hash, and the cryptographic hash value are all provided by the remote NTP server.

ntp_server

Name	Type	Description
_links	_links	
authentication_enabled	boolean	Set NTP symmetric authentication on (true) or off (false).
key	ntp_key_reference	
server	string	NTP server host name, IPv4, or IPv6 address.
version	string	NTP protocol version for server. Valid versions are 3, 4, or auto.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Validate an external NTP time server

POST `/cluster/ntp/servers`

Introduced In: 9.7

Validates the provided external NTP time server for usage and configures ONTAP so that all nodes in the cluster use it. The required fields are:

- `server`

Default property values

If not specified in POST, the following default property values are assigned:

- `version` - auto
- `key` - not set

If the key is provided in POST, `authentication_enabled` is set to `true` by default.

Related ONTAP commands

- `cluster time-service ntp server create`

Learn more

- DOC /cluster/ntp/servers

Parameters

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 1 • Max value: 120 • Min value: 0
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
key	ntp_key_reference	
server	string	NTP server host name, IPv4, or IPv6 address.
version	string	NTP protocol version for server. Valid versions are 3, 4, or auto.

Example request

```
{
  "authentication_enabled": 1,
  "key": {
    "id": "10"
  },
  "server": "time.nist.gov",
  "version": "auto"
}
```

Response

```
Status: 202, Accepted
```

Name	Type	Description
job	job_link	

Example response

```
{
  "job": {
    "uuid": "string"
  }
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
2097163	NTP server IPv4 address was invalid.
2097164	NTP server IPv6 address was invalid.
2097165	Cannot resolve NTP server name.
2097166	NTP server address query returned no valid IP addresses.
2097167	Failed to connect to NTP server.
2097169	NTP server provided was not synchronized with a clock or another NTP server.
2097174	NTP server provided had too high of root distance.
2097177	NTP server provided an invalid stratum.
2097179	Too many NTP servers have been configured.
2097181	NTP server address was invalid. It is a special purpose address such as loopback, multicast, or broadcast address.
2097182	NTP server address was invalid. The address is neither an IPv4 or IPv6.
2097183	NTP symmetric key authentication cannot be used for a node not in a cluster.
2097185	NTP key authentication failed for the provided key.
2097193	An unknown NTP key was provided.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ntp_key_reference

Name	Type	Description
id	integer	NTP symmetric authentication key identifier or index number (ID). This ID, the type of cryptographic hash, and the cryptographic hash value are all provided by the remote NTP server.

ntp_server

Name	Type	Description
key	ntp_key_reference	
server	string	NTP server host name, IPv4, or IPv6 address.
version	string	NTP protocol version for server. Valid versions are 3, 4, or auto.

job_link

Name	Type	Description
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete an external NTP server

DELETE `/cluster/ntp/servers/{server}`

Introduced In: 9.7

Deletes an external NTP server used by ONTAP.

Related ONTAP commands

- `cluster time-service ntp server delete`

Learn more

- DOC /cluster/ntp/servers

Parameters

Name	Type	In	Required	Description
server	string	path	True	Server address or host name

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 1 • Max value: 120 • Min value: 0

Response

```
Status: 202, Accepted
```

Name	Type	Description
job	job_link	

Example response


```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

job_link

Name	Type	Description
_links	_links	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve an external NTP server configuration

GET `/cluster/ntp/servers/{server}`

Introduced In: 9.7

Retrieves the configuration of an external NTP server used by ONTAP.

Related ONTAP commands

- `cluster time-service ntp server show`

Learn more

- DOC /cluster/ntp/servers

Parameters

Name	Type	In	Required	Description
server	string	path	True	NTP server host name, IPv4, or IPv6 address.
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
authentication_enabled	boolean	Set NTP symmetric authentication on (true) or off (false).
key	ntp_key_reference	
server	string	NTP server host name, IPv4, or IPv6 address.
version	string	NTP protocol version for server. Valid versions are 3, 4, or auto.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "authentication_enabled": 1,
  "key": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "id": "10"
  },
  "server": "time.nist.gov",
  "version": "auto"
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

ntp_key_reference

Name	Type	Description
_links	_links	
id	integer	NTP symmetric authentication key identifier or index number (ID). This ID, the type of cryptographic hash, and the cryptographic hash value are all provided by the remote NTP server.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update an NTP server configuration after validation

PATCH `/cluster/ntp/servers/{server}`

Introduced In: 9.7

Updates the configuration of an NTP server used by the ONTAP cluster after validation. Patchable fields are:

- `version`
- `key.id`
- `authentication_enabled`

If `authentication_enabled` is modified to `false`, the associated NTP key is removed from the server instance. If `authentication_enabled` is modified to `true`, you must provide an NTP key ID in the PATCH body.

Related ONTAP commands

- `cluster time-service ntp server modify`

Learn more

- DOC /cluster/ntp/servers

Parameters

Name	Type	In	Required	Description
server	string	path	True	Server address or host name

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 1 • Max value: 120 • Min value: 0

Request Body

Name	Type	Description
authentication_enabled	boolean	Set NTP symmetric authentication on (true) or off (false).
key	ntp_key_reference	
version	string	NTP protocol version for server. Valid versions are 3, 4, or auto.

Example request

```
{
  "authentication_enabled": 1,
  "key": {
    "id": "10"
  },
  "version": "auto"
}
```

Response

```
Status: 202, Accepted
```

Name	Type	Description
job	job_link	

Example response

```
{
  "job": {
    "uuid": "string"
  }
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
2097163	NTP server address was invalid.
2097164	NTP server address was invalid.
2097165	Could not resolve NTP server hostname.
2097166	NTP server address query returned no valid IP addresses.
2097167	Failed to connect to NTP server.

Error Code	Description
2097169	NTP server provided was not synchronized.
2097174	NTP server provided had too high of root distance.
2097177	NTP server provided had an invalid stratum.
2097181	NTP server address was invalid.
2097182	NTP server address was invalid.
2097183	NTP symmetric key authentication cannot be used for a node not in a cluster.
2097185	NTP key authentication failed for the provided key.
2097188	An invalid key identifier was provided. Identifiers must be in the range from 1 to 65535.
2097193	An unknown key was provided.
2097194	The field "authentication_enabled" cannot be false when the field NTP key is given.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ntp_key_reference

Name	Type	Description
id	integer	NTP symmetric authentication key identifier or index number (ID). This ID, the type of cryptographic hash, and the cryptographic hash value are all provided by the remote NTP server.

ntp_server

Name	Type	Description
authentication_enabled	boolean	Set NTP symmetric authentication on (true) or off (false).
key	ntp_key_reference	
version	string	NTP protocol version for server. Valid versions are 3, 4, or auto.

job_link

Name	Type	Description
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2025 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.