



Installer le logiciel disjoncteur d'attache

ONTAP MetroCluster

NetApp
March 29, 2024

Sommaire

Installer le logiciel disjoncteur d'attache	1
Workflow d'installation de Tiebreaker	1
Préparez l'installation du logiciel Tiebreaker	1
Sécurisez l'installation de l'hôte Tiebreaker et de la base de données	3
Installez le progiciel Tiebreaker	6

Installer le logiciel disjoncteur d'attache

Workflow d'installation de Tiebreaker

Il offre des fonctionnalités de surveillance d'un environnement de stockage en cluster. Il envoie également des notifications SNMP en cas de problèmes de connectivité des nœuds et d'incidents sur site.

A propos de ce flux de travail

Vous pouvez utiliser ce flux de travail pour installer ou mettre à niveau le logiciel Tiebreaker.

1

"Préparez l'installation du logiciel Tiebreaker"

Avant d'installer et de configurer le logiciel Tiebreaker, vérifiez que votre système répond à certaines exigences.

2

"Fixer l'installation"

Pour les configurations qui exécutent MetroCluster Tiebreaker 1.5 et versions ultérieures, vous pouvez sécuriser et renforcer le système d'exploitation hôte et la base de données.

3

"Installez le progiciel Tiebreaker"

Effectuez une nouvelle installation ou une mise à niveau du logiciel Tiebreaker. La procédure d'installation que vous suivez dépend de la version de Tiebreaker que vous souhaitez installer.

Préparez l'installation du logiciel Tiebreaker

Avant d'installer et de configurer le logiciel Tiebreaker, vérifiez que votre système répond à certaines exigences.

Configuration logicielle requise

Selon la version de Tiebreaker que vous installez, vous devez respecter la configuration logicielle suivante.

Version Tiebreaker de ONTAP	Versions de ONTAP prises en charge	Versions Linux prises en charge	Configuration requise pour Java/MariaDB
1.6	ONTAP 9.12.1 et versions ultérieures	Reportez-vous à la "Matrice de prise en charge du système d'exploitation" pour plus d'informations.	Aucune. Les dépendances sont incluses dans l'installation.

1.5	ONTAP 9.13.1 et versions antérieures	<ul style="list-style-type: none"> Red Hat Enterprise Linux 8.1 à 8.7 	<p>Avec Red Hat Enterprise Linux 8.1 à 8.7 :</p> <ul style="list-style-type: none"> MariaDB 10.x (utilisez la version par défaut installée à l'aide de "yum install mariadb-Server.x86_64") OpenJDK 17, 18 ou 19
1.4	ONTAP 9.11.1 et versions antérieures	<ul style="list-style-type: none"> Red Hat Enterprise Linux 8.1 à 8.7 Red Hat Enterprise Linux 7 à 7.9 CentOS 7 à 7.9 64 bits 	<p>Avec CentOS :</p> <ul style="list-style-type: none"> Serveur MariaDB 5.5.52.x/MySQL 5.6x 4 GO DE RAM Ouvrez JRE 8 <p>Avec Red Hat Enterprise Linux 8.1 à 8.7 :</p> <p>*MariaDB 10.x (utilisez la version par défaut installée à l'aide de "yum install mariadb-Server.x86_64") *JRE 8</p>
1.3	ONTAP 9.10.1 et versions antérieures	<ul style="list-style-type: none"> Red Hat Enterprise Linux 8.1 à 8.7 Red Hat Enterprise Linux 7 à 7.9 CentOS 7 à 7.9 64 bits 	<p>Avec CentOS :</p> <ul style="list-style-type: none"> Serveur MariaDB 5.5.52.x/MySQL 5.6x 4 GO DE RAM Ouvrez JRE 8 <p>Avec Red Hat Enterprise Linux 8.1 à 8.7 :</p> <ul style="list-style-type: none"> MariaDB 10.x (utilisez la version par défaut installée à l'aide de "yum install mariadb-Server.x86_64") JRE 8
1,21Px	ONTAP 9.9.1 et versions antérieures	<ul style="list-style-type: none"> Red Hat Enterprise Linux 8.1 à 8.7 Red Hat Enterprise Linux 7 à 7.9 CentOS 7 à 7.9 64 bits 	<p>Avec CentOS :</p> <ul style="list-style-type: none"> Serveur MariaDB 5.5.52.x/MySQL 5.6x 4 GO DE RAM Ouvrez JRE 8 <p>Avec Red Hat Enterprise Linux 8.1 à 8.7 :</p> <ul style="list-style-type: none"> MariaDB 10.x (utilisez la version par défaut installée à l'aide de "yum install mariadb-Server.x86_64") JRE 8

Supplémentaires requise

Vous devez connaître les exigences supplémentaires suivantes :

- Le logiciel disjoncteur d'attache est installé sur un troisième site, ce qui permet au logiciel de distinguer une panne de liaison interswitch (ISL) d'une panne sur un site. Votre système hôte doit respecter certaines exigences avant d'installer ou de mettre à niveau le logiciel disjoncteur d'attache sur votre ordinateur local afin de surveiller la configuration MetroCluster.
- Vous devez disposer de privilèges « root » pour installer le logiciel MetroCluster Tiebreaker et les progiciels dépendants.
- Vous ne pouvez utiliser qu'un seul moniteur Tiebreaker MetroCluster par configuration MetroCluster pour éviter tout conflit avec plusieurs moniteurs Tiebreaker.
- Lorsque vous sélectionnez la source NTP (Network Time Protocol) pour le logiciel Tiebreaker, vous devez utiliser une source NTP locale. Le logiciel Tiebreaker ne doit pas utiliser la même source que les sites MetroCluster surveillés par le logiciel Tiebreaker.
- Capacité du disque : 8 Go
- Pare-feu :
 - Accès direct pour la configuration des messages AutoSupport
 - SSH (port 22/TCP), HTTPS (port 443/TCP) et ping (ICMP)

Sécurisez l'installation de l'hôte Tiebreaker et de la base de données

Pour les configurations qui exécutent MetroCluster Tiebreaker 1.5 et versions ultérieures, vous pouvez sécuriser et renforcer le système d'exploitation hôte et la base de données.

Sécuriser l'hôte

Les instructions suivantes vous indiquent comment sécuriser l'hôte sur lequel le logiciel Tiebreaker est installé.

Recommandations de gestion des utilisateurs

- Limitez l'accès de l'utilisateur « root ».
 - Vous pouvez utiliser des utilisateurs capables de passer à un accès racine pour installer et administrer le logiciel Tiebreaker.
 - Vous pouvez utiliser des utilisateurs qui ne sont pas en mesure de passer à l'accès racine pour administrer le logiciel Tiebreaker.
 - Lors de l'installation, vous devez créer un groupe nommé "mcctbgrp". L'utilisateur root de l'hôte et l'utilisateur créé pendant l'installation doivent tous deux être membres. Seuls les membres de ce groupe peuvent administrer entièrement le logiciel Tiebreaker.



Les utilisateurs qui ne sont pas membres de ce groupe ne peuvent pas accéder au logiciel Tiebreaker ou à l'interface de ligne de commande. Vous pouvez créer des utilisateurs supplémentaires sur l'hôte et les faire membres du groupe. Ces membres supplémentaires ne peuvent pas administrer entièrement le logiciel Tiebreaker. Ils ont un accès en lecture seule et ne peuvent pas ajouter, modifier ou supprimer des moniteurs.

- N'exécutez pas Tiebreaker en tant qu'utilisateur root. Utilisez un compte de service dédié et non privilégié pour exécuter Tiebreaker.
- Modifiez la chaîne de communauté par défaut dans le fichier "/etc/snmp/snmpd.conf".

- Autoriser des priviléges d'écriture minimaux. Le compte de service Tiebreaker non privilégié ne doit pas avoir accès à l'écrasement de son exécutable binaire ou de tout fichier de configuration. Seuls les répertoires et fichiers pour le stockage Tiebreaker local (par exemple, pour le stockage back-end intégré) ou les journaux d'audit doivent être inscriptibles par l'utilisateur Tiebreaker.
- N'autorisez pas les utilisateurs anonymes.
 - Définissez AllowTcpForwarding sur "no" ou utilisez la directive match pour restreindre les utilisateurs anonymes.

Informations associées

- "[Documentation produit de Red Hat Enterprise Linux 8](#)"
- "[Documentation produit de Red Hat Enterprise Linux 9](#)"

Recommandations de sécurité hôte de base

- Utilisez le chiffrement de disque
 - Vous pouvez activer le chiffrement de disque. Il peut s'agir de FullDiskEncryption (matériel), ou du cryptage fourni par HostOS (logiciel), ou par l'hôte SVM.
- Désactivez les services inutilisés qui autorisent les connexions entrantes. Vous pouvez désactiver tout service qui n'est pas utilisé. Le logiciel Tiebreaker ne nécessite pas de service pour les connexions entrantes car toutes les connexions de l'installation Tiebreaker sont sortantes. Les services qui peuvent être activés par défaut et désactivés sont les suivants :
 - Serveur HTTP/HTTPS
 - Serveur FTP
 - Telnet, RSH, rlogin
 - Accès NFS, CIFS et autre protocole
 - RDP (RemoteDesktopProtocol), X11 Server, VNC ou d'autres fournisseurs de services distants « Desktop ».



Vous devez laisser l'accès à la console série (si pris en charge) ou au moins un protocole activé pour administrer l'hôte à distance. Si vous désactivez tous les protocoles, vous devez disposer d'un accès physique à l'hôte pour l'administration.

- Sécurisez l'hôte à l'aide de FIPS
 - Vous pouvez installer le système d'exploitation hôte en mode conforme FIPS, puis Tiebreaker.
- OpenJDK 19 vérifie au démarrage si l'hôte est installé en mode FIPS. Aucune modification manuelle ne doit être nécessaire.
 - Si vous sécurisez l'hôte, vous devez vous assurer qu'il peut démarrer sans intervention de l'utilisateur. Si une intervention de l'utilisateur est nécessaire, il est possible que la fonctionnalité Tiebreaker ne soit pas disponible si l'hôte redémarre de manière inattendue. Si cela se produit, la fonctionnalité Tiebreaker n'est disponible qu'après l'intervention manuelle et lorsque l'hôte est complètement démarré.
- Désactiver l'historique des commandes Shell.
- Mises à niveau fréquentes. Tiebreaker est activement développé, et la mise à jour est souvent importante pour incorporer des correctifs de sécurité et toute modification des paramètres par défaut tels que la longueur des clés ou les suites de chiffrement.

- Abonnez-vous à la liste de diffusion de l'annonce HashiCorp pour recevoir les annonces de nouvelles versions et visitez le Tiebreaker CHANGELOG pour plus de détails sur les dernières mises à jour pour les nouvelles versions.
- Utilisez les autorisations de fichier correctes. Assurez-vous toujours que les autorisations appropriées sont appliquées aux fichiers avant de démarrer le logiciel Tiebreaker, en particulier ceux contenant des informations sensibles.
- L'authentification multifacteur (MFA) renforce la sécurité de votre entreprise en exigeant que les administrateurs s'identifient à l'aide de plusieurs nom d'utilisateur et mot de passe. Bien qu'important, les noms d'utilisateur et les mots de passe sont vulnérables aux attaques par force brute et peuvent être volés par des tiers.
 - Red Hat Enterprise Linux 8 fournit un MFA qui exige que les utilisateurs fournissent plusieurs informations pour s'authentifier avec succès auprès d'un compte ou d'un hôte Linux. Les informations supplémentaires peuvent être un mot de passe à usage unique envoyé à votre téléphone portable par SMS ou des informations d'identification à partir d'une application telle que Google Authenticator, Twilio Authy ou FreeOTP.

Informations associées

- ["Documentation produit de Red Hat Enterprise Linux 8"](#)
- ["Documentation produit de Red Hat Enterprise Linux 9"](#)

Sécurisez l'installation de la base de données

Les directives suivantes montrent comment sécuriser et renforcer l'installation de la base de données MariaDB 10.x.

- Limitez l'accès de l'utilisateur « root ».
 - Tiebreaker utilise un compte dédié. Le compte et les tables de stockage des données (configuration) sont créés lors de l'installation de Tiebreaker. La seule fois que l'accès élevé à la base de données est requis, c'est lors de l'installation.
- Pendant l'installation, les droits d'accès et privilèges suivants sont requis :
 - Possibilité de créer une base de données et des tables
 - Possibilité de créer des options globales
 - Possibilité de créer un utilisateur de base de données et de définir le mot de passe
 - Possibilité d'associer l'utilisateur de la base de données à la base de données et aux tables et d'attribuer des droits d'accès



Le compte utilisateur que vous spécifiez pendant l'installation de Tiebreaker doit disposer de tous ces privilèges. L'utilisation de plusieurs comptes utilisateur pour les différentes tâches n'est pas prise en charge.

- Utiliser le cryptage de la base de données
 - Le chiffrement des données au repos est pris en charge. ["En savoir plus sur le chiffrement des données au repos"](#)
 - Les données en transit ne sont pas chiffrées. Les données en vol utilisent une connexion locale de fichiers « chaussettes ».
 - Conformité FIPS pour MariaDB — vous n'avez pas besoin d'activer la conformité FIPS sur la base de données. L'installation de l'hôte en mode conforme FIPS suffit.

"En savoir plus sur MySQL Enterprise transparent Data Encryption (TDE)"



Les paramètres de cryptage doivent être activés avant l'installation du logiciel Tiebreaker.

Informations associées

- Gestion des utilisateurs de la base de données

["Contrôle d'accès et gestion des comptes"](#)

- Sécurisez la base de données

["Sécuriser MySQL contre les attaquants"](#)

["Sécuriser MariaDB"](#)

- Sécurisez l'installation du coffre-fort

["Renforcement de la production"](#)

Installez le progiciel Tiebreaker

Choisissez votre procédure d'installation

La procédure d'installation de Tiebreaker que vous suivez dépend de la version de Tiebreaker que vous installez.

Version Tiebreaker	Aller à...
Disjoncteur d'attache 1.6	"Monter le Tiebreaker 1.6"
Tiebreaker 1.5 ou 1.4	"Monter le Tiebreaker 1.5 ou 1.4"

Monter le Tiebreaker 1.6

Effectuez une nouvelle installation ou mettez à niveau le logiciel Tiebreaker.

Description de la tâche

- Votre système de stockage doit exécuter ONTAP 9.12.1 ou une version ultérieure.
- Vous pouvez installer MetroCluster Tiebreaker en tant qu'utilisateur non root disposant de priviléges d'administration suffisants pour effectuer l'installation de Tiebreaker, créer des tables et des utilisateurs et définir le mot de passe utilisateur.

Étapes

1. Téléchargez le logiciel MetroCluster Tiebreaker 1.6.

["Site de support NetApp"](#)

2. Connectez-vous à l'hôte en tant qu'utilisateur racine.

3. Si vous effectuez une mise à niveau, vérifiez la version de Tiebreaker que vous exécutez :

L'exemple suivant montre Tiebreaker 1.5.

```
[root@mcctb ~] # netapp-metrocluster-tiebreaker-software-cli
NetApp MetroCluster Tiebreaker :> version show
NetApp MetroCluster Tiebreaker 1.5: Sun Mar 13 09:59:02 IST 2022
NetApp MetroCluster Tiebreaker :> exit
```

4. Installez ou mettez à niveau le logiciel Tiebreaker.

Monter le Tiebreaker 1.6

Procéder comme suit pour une nouvelle installation de Tiebreaker 1.6.

Étapes

- a. Exécutez la commande suivante sur le [root@mcctb ~] # demander de commencer l'installation :

```
sh MetroClusterTiebreakerInstall-1.6
```

Pour une installation réussie, le système affiche les valeurs de sortie suivantes :

```
Extracting the MetroCluster Tiebreaker installation/upgrade archive
Install digest hash is Ok
Performing the MetroCluster Tiebreaker code signature check
Install code signature is Ok
Enter unix user account to use for the installation:
mcctbadminuser
Unix user account "mcctbadminuser" doesn't exist. Do you wish to
create "mcctbadminuser" user account? [Y/N]: y
useradd: warning: the home directory already exists.
Not copying any file from skel directory into it.
Creating mailbox file: File exists
Unix account "mcctbadminuser" created.
Changing password for user mcctbadminuser.
New password:
Retype new password:
passwd: all authentication tokens updated successfully.
MetroCluster Tiebreaker requires unix user account
"mcctbadminuser" to be added to the group "mcctbgrp" for admin
access.
Do you wish to add ? [Y/N]: y
Unix user account "mcctbadminuser" added to "mcctbgrp".
Do you wish to generate your own public-private key pair for
encrypting audit log? [Y/N]: y
Generating public-private key pair...
Configuring Vault...
Starting vault server...
==> Vault server configuration:

          Api Address: <api_address>
          Cgo: disabled
          Cluster Address: <cluster_address>
          Environment Variables: BASH_FUNC_which%%,
```

```
DBUS_SESSION_BUS_ADDRESS, GODEBUG, HISTCONTROL, HISTSIZE, HOME,
HOSTNAME, HOST_ACCOUNT, LANG, LESSOPEN, LOGNAME, LS_COLORS, MAIL,
PATH, PWD, SHELL, SHLVL, SSH_CLIENT, SSH_CONNECTION, SSH_TTY,
STAF_TEMP_DIR, TERM, USER, VAULT_ADDR, VAULT_TOKEN,
XDG_RUNTIME_DIR, XDG_SESSION_ID, _, vault_addr, which_declare
        Go Version: go1.20.5
        Listener 1: tcp (addr: "0.0.0.0:8200", cluster
address: "0.0.0.0:8201", max_request_duration: "1m30s",
max_request_size: "33554432", tls: "enabled")
        Log Level:
        Mlock: supported: true, enabled: true
        Recovery Mode: false
        Storage: file
        Version: Vault v1.14.0, built 2023-06-
19T11:40:23Z
        Version Sha:
13a649f860186dff3f3a4459814d87191efc321

==> Vault server started! Log data will stream in below:

2023-11-23T15:14:28.532+0530 [INFO] proxy environment:
http_proxy="" https_proxy="" no_proxy=""
2023-11-23T15:14:28.577+0530 [INFO] core: Initializing version
history cache for core
2023-11-23T15:14:38.552+0530 [INFO] core: security barrier not
initialized
2023-11-23T15:14:38.552+0530 [INFO] core: seal configuration
missing, not initialized
2023-11-23T15:14:38.554+0530 [INFO] core: security barrier not
initialized
2023-11-23T15:14:38.555+0530 [INFO] core: security barrier
initialized: stored=1 shares=5 threshold=3
2023-11-23T15:14:38.556+0530 [INFO] core: post-unseal setup
starting
2023-11-23T15:14:38.577+0530 [INFO] core: loaded wrapping token
key
2023-11-23T15:14:38.577+0530 [INFO] core: successfully setup
plugin catalog: plugin-directory=""
2023-11-23T15:14:38.577+0530 [INFO] core: no mounts; adding
default mount table
2023-11-23T15:14:38.578+0530 [INFO] core: successfully mounted:
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/
namespace="ID: root. Path: "
2023-11-23T15:14:38.578+0530 [INFO] core: successfully mounted:
type=system version="v1.14.0+builtin.vault" path=sys/
namespace="ID: root. Path: "
```

```
2023-11-23T15:14:38.578+0530 [INFO] core: successfully mounted:  
type=identity version="v1.14.0+builtin.vault" path=identity/  
namespace="ID: root. Path: "  
2023-11-23T15:14:38.581+0530 [INFO] core: successfully mounted:  
type=token version="v1.14.0+builtin.vault" path=token/  
namespace="ID: root. Path: "  
2023-11-23T15:14:38.581+0530 [INFO] rollback: starting rollback  
manager  
2023-11-23T15:14:38.581+0530 [INFO] core: restoring leases  
2023-11-23T15:14:38.582+0530 [INFO] expiration: lease restore  
complete  
2023-11-23T15:14:38.582+0530 [INFO] identity: entities restored  
2023-11-23T15:14:38.582+0530 [INFO] identity: groups restored  
2023-11-23T15:14:38.583+0530 [INFO] core: Recorded vault  
version: vault version=1.14.0 upgrade time="2023-11-23  
09:44:38.582881162 +0000 UTC" build date=2023-06-19T11:40:23Z  
2023-11-23T15:14:38.583+0530 [INFO] core: usage gauge collection  
is disabled  
2023-11-23T15:14:38.998+0530 [INFO] core: post-unseal setup  
complete  
2023-11-23T15:14:38.999+0530 [INFO] core: root token generated  
2023-11-23T15:14:38.999+0530 [INFO] core: pre-seal teardown  
starting  
2023-11-23T15:14:38.999+0530 [INFO] rollback: stopping rollback  
manager  
2023-11-23T15:14:38.999+0530 [INFO] core: pre-seal teardown  
complete  
2023-11-23T15:14:39.311+0530 [INFO] core.cluster-listener.tcp:  
starting listener: listener_address=0.0.0.0:8201  
2023-11-23T15:14:39.311+0530 [INFO] core.cluster-listener:  
serving cluster requests: cluster_listen_address=[::]:8201  
2023-11-23T15:14:39.312+0530 [INFO] core: post-unseal setup  
starting  
2023-11-23T15:14:39.312+0530 [INFO] core: loaded wrapping token  
key  
2023-11-23T15:14:39.312+0530 [INFO] core: successfully setup  
plugin catalog: plugin-directory=""  
2023-11-23T15:14:39.313+0530 [INFO] core: successfully mounted:  
type=system version="v1.14.0+builtin.vault" path=sys/  
namespace="ID: root. Path: "  
2023-11-23T15:14:39.313+0530 [INFO] core: successfully mounted:  
type=identity version="v1.14.0+builtin.vault" path=identity/  
namespace="ID: root. Path: "  
2023-11-23T15:14:39.313+0530 [INFO] core: successfully mounted:  
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/  
namespace="ID: root. Path: "
```

```

2023-11-23T15:14:39.314+0530 [INFO] core: successfully mounted:
type=token version="v1.14.0+builtin.vault" path=token/
namespace="ID: root. Path: "
2023-11-23T15:14:39.314+0530 [INFO] rollback: starting rollback
manager
2023-11-23T15:14:39.314+0530 [INFO] core: restoring leases
2023-11-23T15:14:39.314+0530 [INFO] identity: entities restored
2023-11-23T15:14:39.314+0530 [INFO] expiration: lease restore
complete
2023-11-23T15:14:39.314+0530 [INFO] identity: groups restored
2023-11-23T15:14:39.315+0530 [INFO] core: usage gauge collection
is disabled
2023-11-23T15:14:39.316+0530 [INFO] core: post-unseal setup
complete
2023-11-23T15:14:39.316+0530 [INFO] core: vault is unsealed
Success! Uploaded policy: mcctb-policy
2023-11-23T15:14:39.795+0530 [INFO] core: enabled credential
backend: path=approle/ type=approle version=""
Success! Enabled approle auth method at: approle/
2023-11-23T15:14:39.885+0530 [INFO] core: successful mount:
namespace="" path=mcctb/ type=kv version=""
Success! Enabled the kv secrets engine at: mcctb/
Success! Data written to: auth/approle/role/mcctb-app
Installing the NetApp-MetroCluster-Tiebreaker-Software-1.6-
1.x86_64.rpm
Preparing...                                          #
#####
# [100%]

Updating / installing...

1:NetApp-MetroCluster-Tiebreaker-So#
#####
# [100%]
Performing file integrity check
etc/cron.weekly/metrocluster-tiebreaker-support is Ok
etc/cron.weekly/metrocluster-tiebreaker-support-cov is Ok
etc/init.d/netapp-metrocluster-tiebreaker-software is Ok
etc/init.d/netapp-metrocluster-tiebreaker-software-cov is Ok
etc/logrotate.d/mcctb is Ok
opt/netapp/mcctb/lib/common/activation-1.1.1.jar is Ok
opt/netapp/mcctb/lib/common/aopalliance.jar is Ok
opt/netapp/mcctb/lib/common/args4j.jar is Ok
opt/netapp/mcctb/lib/common/aspectjrt.jar is Ok
opt/netapp/mcctb/lib/common/aspectjweaver.jar is Ok
opt/netapp/mcctb/lib/common/asup.jar is Ok
opt/netapp/mcctb/lib/common/bcpkix-jdk15on.jar is Ok
opt/netapp/mcctb/lib/common/bcprov-jdk15on.jar is Ok

```

```
opt/netapp/mcctb/lib/common/bcprov-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/bctls-fips-1.0.13.jar is Ok
opt/netapp/mcctb/lib/common/bctls-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/bcutil-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/cglib.jar is Ok
opt/netapp/mcctb/lib/common/commons-codec.jar is Ok
opt/netapp/mcctb/lib/common/commons-collections4.jar is Ok
opt/netapp/mcctb/lib/common/commons-compress.jar is Ok
opt/netapp/mcctb/lib/common/commons-daemon.jar is Ok
opt/netapp/mcctb/lib/common/commons-daemon.src.jar is Ok
opt/netapp/mcctb/lib/common/commons-dbcp2.jar is Ok
opt/netapp/mcctb/lib/common/commons-io.jar is Ok
opt/netapp/mcctb/lib/common/commons-lang3.jar is Ok
opt/netapp/mcctb/lib/common/commons-logging.jar is Ok
opt/netapp/mcctb/lib/common/commons-pool2.jar is Ok
opt/netapp/mcctb/lib/common/guava.jar is Ok
opt/netapp/mcctb/lib/common/httpclient.jar is Ok
opt/netapp/mcctb/lib/common/httpcore.jar is Ok
opt/netapp/mcctb/lib/common/jakarta.activation.jar is Ok
opt/netapp/mcctb/lib/common/jakarta.xml.bind-api.jar is Ok
opt/netapp/mcctb/lib/common/java-xmlbuilder.jar is Ok
opt/netapp/mcctb/lib/common/javax.inject.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-api-2.3.1.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-core.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-impl.jar is Ok
opt/netapp/mcctb/lib/common/jline.jar is Ok
opt/netapp/mcctb/lib/common/jna.jar is Ok
opt/netapp/mcctb/lib/common/joda-time.jar is Ok
opt/netapp/mcctb/lib/common/jsch.jar is Ok
opt/netapp/mcctb/lib/common/json.jar is Ok
opt/netapp/mcctb/lib/common/jsvc.zip is Ok
opt/netapp/mcctb/lib/common/junixsocket-common.jar is Ok
opt/netapp/mcctb/lib/common/junixsocket-native-common.jar is Ok
opt/netapp/mcctb/lib/common/logback-classic.jar is Ok
opt/netapp/mcctb/lib/common/logback-core.jar is Ok
opt/netapp/mcctb/lib/common/mail-1.6.2.jar is Ok
opt/netapp/mcctb/lib/common/mariadb-java-client.jar is Ok
opt/netapp/mcctb/lib/common/mcctb-mib.jar is Ok
opt/netapp/mcctb/lib/common/mcctb.jar is Ok
opt/netapp/mcctb/lib/common/mockito-core.jar is Ok
opt/netapp/mcctb/lib/common/slf4j-api.jar is Ok
opt/netapp/mcctb/lib/common/snmp4j.jar is Ok
opt/netapp/mcctb/lib/common/spring-aop.jar is Ok
opt/netapp/mcctb/lib/common/spring-beans.jar is Ok
opt/netapp/mcctb/lib/common/spring-context-support.jar is Ok
opt/netapp/mcctb/lib/common/spring-context.jar is Ok
```

```
opt/netapp/mcctb/lib/common/spring-core.jar is Ok
opt/netapp/mcctb/lib/common/spring-expression.jar is Ok
opt/netapp/mcctb/lib/common/spring-web.jar is Ok
opt/netapp/mcctb/lib/common/vault-java-driver.jar is Ok
opt/netapp/mcctb/lib/common/xz.jar is Ok
opt/netapp/mcctb/lib/org.jacoco.agent-0.8.8-runtime.jar is Ok
opt/netapp/mcctb/bin/mcctb-asup-invoke is Ok
opt/netapp/mcctb/bin/mcctb_postrotate is Ok
opt/netapp/mcctb/bin/netapp-metrocluster-tiebreaker-software-cli
is Ok
/
Synchronizing state of netapp-metrocluster-tiebreaker-
software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-
metrocluster-tiebreaker-software
Created symlink /etc/systemd/system/multi-
user.target.wants/netapp-metrocluster-tiebreaker-software.service
→ /etc/systemd/system/netapp-metrocluster-tiebreaker-
software.service.
```

Attempting to start NetApp MetroCluster Tiebreaker software services

```
Started NetApp MetroCluster Tiebreaker software services
Successfully installed NetApp MetroCluster Tiebreaker software
version 1.6.
```

IMPORTANT: Please ensure you store the following private key used to decrypt audit logs securely in a safe location.

Consider the following recommendations:

- Save it to an encrypted storage device or file.
- Use strong, unique passwords to protect the storage device or file.
- Restrict access to the private key file to authorized individuals only.

The Private key is:

```
-----BEGIN PRIVATE KEY-----
```

```
<private_key_id>
```

```
-----END PRIVATE KEY-----
```

Mise à niveau de Tiebreaker 1.5 vers 1.6

Procédez comme suit pour mettre à niveau la version du logiciel Tiebreaker 1.5 vers Tiebreaker 1.6.

Étapes

- Exécutez la commande suivante sur le [root@mcctb ~] # demander la mise à niveau du logiciel :

```
sh MetroClusterTiebreakerInstall-1.6
```

Le système affiche les résultats suivants pour une mise à niveau réussie :

```
Extracting the MetroCluster Tiebreaker installation/upgrade archive
Install digest hash is Ok
Performing the MetroCluster Tiebreaker code signature check
Install code signature is Ok

Enter database user name : root

Please enter database password for root
Enter password:

Password updated successfully in the database.

Do you wish to generate your own public-private key pair for
encrypting audit log? [Y/N]: y
Generating public-private key pair...
Configuring Vault...
==> Vault shutdown triggered
2023-07-21T00:30:22.335+0530 [INFO] core: marked as sealed
2023-07-21T00:30:22.335+0530 [INFO] core: pre-seal teardown
starting
2023-07-21T00:30:22.335+0530 [INFO] rollback: stopping rollback
manager
2023-07-21T00:30:22.335+0530 [INFO] core: pre-seal teardown
complete
2023-07-21T00:30:22.335+0530 [INFO] core: stopping cluster
listeners
2023-07-21T00:30:22.335+0530 [INFO] core.cluster-listener:
forwarding rpc listeners stopped
2023-07-21T00:30:22.375+0530 [INFO] core.cluster-listener: rpc
listeners successfully shut down
2023-07-21T00:30:22.375+0530 [INFO] core: cluster listeners
successfully shut down
2023-07-21T00:30:22.376+0530 [INFO] core: vault is sealed
```

```

Starting vault server...
==> Vault server configuration:

    Api Address: <api_address>
        Cgo: disabled
    Cluster Address: <cluster_address>
    Environment Variables: BASH_FUNC_which%%,
DBUS_SESSION_BUS_ADDRESS, GODEBUG, HISTCONTROL, HISTSIZE, HOME,
HOSTNAME, HOST_ACCOUNT, LANG, LESSOPEN, LOGNAME, LS_COLORS, MAIL,
PATH, PWD, SHELL, SHLVL, SSH_CLIENT, SSH_CONNECTION, SSH_TTY,
STAF_TEMP_DIR, TERM, USER, VAULT_ADDR, VAULT_TOKEN,
XDG_RUNTIME_DIR, XDG_SESSION_ID, _, vault_addr, which_declare
        Go Version: go1.20.5
        Listener 1: tcp (addr: "0.0.0.0:8200", cluster
address: "0.0.0.0:8201", max_request_duration: "1m30s",
max_request_size: "33554432", tls: "enabled")
        Log Level:
            Mlock: supported: true, enabled: true
        Recovery Mode: false
        Storage: file
        Version: Vault v1.14.0, built 2023-06-
19T11:40:23Z
        Version Sha:
13a649f860186dff3f3a4459814d87191efc321

==> Vault server started! Log data will stream in below:

2023-07-21T00:30:33.065+0530 [INFO] proxy environment:
http_proxy="" https_proxy="" no_proxy=""
2023-07-21T00:30:33.098+0530 [INFO] core: Initializing version
history cache for core
2023-07-21T00:30:43.092+0530 [INFO] core: security barrier not
initialized
2023-07-21T00:30:43.092+0530 [INFO] core: seal configuration
missing, not initialized
2023-07-21T00:30:43.094+0530 [INFO] core: security barrier not
initialized
2023-07-21T00:30:43.096+0530 [INFO] core: security barrier
initialized: stored=1 shares=5 threshold=3
2023-07-21T00:30:43.098+0530 [INFO] core: post-unseal setup
starting
2023-07-21T00:30:43.124+0530 [INFO] core: loaded wrapping token
key
2023-07-21T00:30:43.124+0530 [INFO] core: successfully setup
plugin catalog: plugin-directory=""
2023-07-21T00:30:43.124+0530 [INFO] core: no mounts; adding

```

```
default mount table
2023-07-21T00:30:43.125+0530 [INFO] core: successfully mounted:
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/
namespace="ID: root. Path: "
2023-07-21T00:30:43.126+0530 [INFO] core: successfully mounted:
type=system version="v1.14.0+builtin.vault" path=sys/
namespace="ID: root. Path: "
2023-07-21T00:30:43.126+0530 [INFO] core: successfully mounted:
type=identity version="v1.14.0+builtin.vault" path=identity/
namespace="ID: root. Path: "
2023-07-21T00:30:43.129+0530 [INFO] core: successfully mounted:
type=token version="v1.14.0+builtin.vault" path=token/
namespace="ID: root. Path: "
2023-07-21T00:30:43.130+0530 [INFO] rollback: starting rollback
manager
2023-07-21T00:30:43.130+0530 [INFO] core: restoring leases
2023-07-21T00:30:43.130+0530 [INFO] identity: entities restored
2023-07-21T00:30:43.130+0530 [INFO] identity: groups restored
2023-07-21T00:30:43.131+0530 [INFO] core: usage gauge collection
is disabled
2023-07-21T00:30:43.131+0530 [INFO] expiration: lease restore
complete
2023-07-21T00:30:43.131+0530 [INFO] core: Recorded vault
version: vault version=1.14.0 upgrade time="2023-07-20
19:00:43.131158543 +0000 UTC" build date=2023-06-19T11:40:23Z
2023-07-21T00:30:43.371+0530 [INFO] core: post-unseal setup
complete
2023-07-21T00:30:43.371+0530 [INFO] core: root token generated
2023-07-21T00:30:43.371+0530 [INFO] core: pre-seal teardown
starting
2023-07-21T00:30:43.371+0530 [INFO] rollback: stopping rollback
manager
2023-07-21T00:30:43.372+0530 [INFO] core: pre-seal teardown
complete
2023-07-21T00:30:43.694+0530 [INFO] core.cluster-listener.tcp:
starting listener: listener_address=0.0.0.0:8201
2023-07-21T00:30:43.695+0530 [INFO] core.cluster-listener:
serving cluster requests: cluster_listen_address=[::]:8201
2023-07-21T00:30:43.695+0530 [INFO] core: post-unseal setup
starting
2023-07-21T00:30:43.696+0530 [INFO] core: loaded wrapping token
key
2023-07-21T00:30:43.696+0530 [INFO] core: successfully setup
plugin catalog: plugin-directory=""
2023-07-21T00:30:43.697+0530 [INFO] core: successfully mounted:
type=system version="v1.14.0+builtin.vault" path=sys/
```

```
namespace="ID: root. Path: "
2023-07-21T00:30:43.698+0530 [INFO] core: successfully mounted:
type=identity version="v1.14.0+builtin.vault" path=identity/
namespace="ID: root. Path: "
2023-07-21T00:30:43.698+0530 [INFO] core: successfully mounted:
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/
namespace="ID: root. Path: "
2023-07-21T00:30:43.701+0530 [INFO] core: successfully mounted:
type=token version="v1.14.0+builtin.vault" path=token/
namespace="ID: root. Path: "
2023-07-21T00:30:43.701+0530 [INFO] rollback: starting rollback
manager
2023-07-21T00:30:43.702+0530 [INFO] core: restoring leases
2023-07-21T00:30:43.702+0530 [INFO] identity: entities restored
2023-07-21T00:30:43.702+0530 [INFO] expiration: lease restore
complete
2023-07-21T00:30:43.702+0530 [INFO] identity: groups restored
2023-07-21T00:30:43.702+0530 [INFO] core: usage gauge collection
is disabled
2023-07-21T00:30:43.703+0530 [INFO] core: post-unseal setup
complete
2023-07-21T00:30:43.703+0530 [INFO] core: vault is unsealed
Success! Uploaded policy: mcctb-policy
2023-07-21T00:30:44.226+0530 [INFO] core: enabled credential
backend: path=approle/ type=approle version=""
Success! Enabled approle auth method at: approle/
2023-07-21T00:30:44.315+0530 [INFO] core: successful mount:
namespace="" path=mcctb/ type=kv version=""
Success! Enabled the kv secrets engine at: mcctb/
Success! Data written to: auth/approle/role/mcctb-app
Upgrading to NetApp-MetroCluster-Tiebreaker-Software-1.6-
1.x86_64.rpm
Preparing...
#####
[100%]
Updating / installing...
1:NetApp-MetroCluster-Tiebreaker-
So#####
[ 50%]
Performing file integrity check
etc/cron.weekly/metrocluster-tiebreaker-support is Ok
etc/cron.weekly/metrocluster-tiebreaker-support-cov is Ok
etc/init.d/netapp-metrocluster-tiebreaker-software is Ok
etc/init.d/netapp-metrocluster-tiebreaker-software-cov is Ok
etc/logrotate.d/mcctb is Ok
opt/netapp/mcctb/lib/common/activation-1.1.1.jar is Ok
opt/netapp/mcctb/lib/common/aopalliance.jar is Ok
opt/netapp/mcctb/lib/common/args4j.jar is Ok
```

```
opt/netapp/mcctb/lib/common/aspectjrt.jar is Ok
opt/netapp/mcctb/lib/common/aspectjweaver.jar is Ok
opt/netapp/mcctb/lib/common/asup.jar is Ok
opt/netapp/mcctb/lib/common/bcpkix-jdk15on.jar is Ok
opt/netapp/mcctb/lib/common/bcprov-jdk15on.jar is Ok
opt/netapp/mcctb/lib/common/bcprov-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/bctls-fips-1.0.13.jar is Ok
opt/netapp/mcctb/lib/common/bctls-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/bcutil-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/cglib.jar is Ok
opt/netapp/mcctb/lib/common/commons-codec.jar is Ok
opt/netapp/mcctb/lib/common/commons-collections4.jar is Ok
opt/netapp/mcctb/lib/common/commons-compress.jar is Ok
opt/netapp/mcctb/lib/common/commons-daemon.jar is Ok
opt/netapp/mcctb/lib/common/commons-daemon.src.jar is Ok
opt/netapp/mcctb/lib/common/commons-dbcp2.jar is Ok
opt/netapp/mcctb/lib/common/commons-io.jar is Ok
opt/netapp/mcctb/lib/common/commons-lang3.jar is Ok
opt/netapp/mcctb/lib/common/commons-logging.jar is Ok
opt/netapp/mcctb/lib/common/commons-pool2.jar is Ok
opt/netapp/mcctb/lib/common/guava.jar is Ok
opt/netapp/mcctb/lib/common/httpclient.jar is Ok
opt/netapp/mcctb/lib/common/httpcore.jar is Ok
opt/netapp/mcctb/lib/common/jakarta.activation.jar is Ok
opt/netapp/mcctb/lib/common/jakarta.xml.bind-api.jar is Ok
opt/netapp/mcctb/lib/common/java-xmlbuilder.jar is Ok
opt/netapp/mcctb/lib/common/javax.inject.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-api-2.3.1.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-core.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-impl.jar is Ok
opt/netapp/mcctb/lib/common/jline.jar is Ok
opt/netapp/mcctb/lib/common/jna.jar is Ok
opt/netapp/mcctb/lib/common/joda-time.jar is Ok
opt/netapp/mcctb/lib/common/jsch.jar is Ok
opt/netapp/mcctb/lib/common/json.jar is Ok
opt/netapp/mcctb/lib/common/jsvc.zip is Ok
opt/netapp/mcctb/lib/common/junixsocket-common.jar is Ok
opt/netapp/mcctb/lib/common/junixsocket-native-common.jar is Ok
opt/netapp/mcctb/lib/common/logback-classic.jar is Ok
opt/netapp/mcctb/lib/common/logback-core.jar is Ok
opt/netapp/mcctb/lib/common/mail-1.6.2.jar is Ok
opt/netapp/mcctb/lib/common/mariadb-java-client.jar is Ok
opt/netapp/mcctb/lib/common/mcctb-mib.jar is Ok
opt/netapp/mcctb/lib/common/mcctb.jar is Ok
opt/netapp/mcctb/lib/common/mockito-core.jar is Ok
opt/netapp/mcctb/lib/common/slf4j-api.jar is Ok
```

```
opt/netapp/mcctb/lib/common/snmp4j.jar is Ok
opt/netapp/mcctb/lib/common/spring-aop.jar is Ok
opt/netapp/mcctb/lib/common/spring-beans.jar is Ok
opt/netapp/mcctb/lib/common/spring-context-support.jar is Ok
opt/netapp/mcctb/lib/common/spring-context.jar is Ok
opt/netapp/mcctb/lib/common/spring-core.jar is Ok
opt/netapp/mcctb/lib/common/spring-expression.jar is Ok
opt/netapp/mcctb/lib/common/spring-web.jar is Ok
opt/netapp/mcctb/lib/common/vault-java-driver.jar is Ok
opt/netapp/mcctb/lib/common/xz.jar is Ok
opt/netapp/mcctb/bin/mcctb_postrotate is Ok
opt/netapp/mcctb/bin/netapp-metrocluster-tiebreaker-software-cli
is Ok
/
```

Synchronizing state of netapp-metrocluster-tiebreaker-software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.

Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-metrocluster-tiebreaker-software

Attempting to start NetApp MetroCluster Tiebreaker software services

Started NetApp MetroCluster Tiebreaker software services

Successfully upgraded NetApp MetroCluster Tiebreaker software to version 1.6.

Cleaning up / removing...

2:NetApp-MetroCluster-Tiebreaker-

So##### [100%]

IMPORTANT: Please ensure you store the following private key used to decrypt audit logs securely in a safe location.

Consider the following recommendations:

- Save it to an encrypted storage device or file.
- Use strong, unique passwords to protect the storage device or file.
- Restrict access to the private key file to authorized individuals only.

The Private key is:

```
-----BEGIN PRIVATE KEY-----
<private_key_id>
-----END PRIVATE KEY-----
```

Mise à niveau de Tiebreaker 1.4 vers 1.6

Procédez comme suit pour mettre à niveau la version du logiciel Tiebreaker 1.4 vers Tiebreaker 1.6.

Étapes

- Exécutez la commande suivante sur le [root@mcctb ~] # demander la mise à niveau du logiciel :

```
sh MetroClusterTiebreakerInstall-1.6
```

Le système affiche les résultats suivants pour une mise à niveau réussie :

```
Extracting the MetroCluster Tiebreaker installation/upgrade archive
Install digest hash is Ok
Performing the MetroCluster Tiebreaker code signature check
Install code signature is Ok
Enter unix user account to use for the installation:
mcctbuseradmin1
Unix user account "mcctbuseradmin1" doesn't exist. Do you wish to
create "mcctbuseradmin1" user account? [Y/N]: y
Unix account "mcctbuseradmin1" created.
Changing password for user mcctbuseradmin1.
New password:
Retype new password:
passwd: all authentication tokens updated successfully.

Enter database user name : root

Please enter database password for root
Enter password:

Password updated successfully in the database.

MetroCluster Tiebreaker requires unix user account
"mcctbuseradmin1" to be added to the group "mcctbgrp" for admin
access.
Do you wish to add ? [Y/N]: y
Unix user account "mcctbuseradmin1" added to "mcctbgrp".
Do you wish to generate your own public-private key pair for
encrypting audit log? [Y/N]: y
Generating public-private key pair...
Configuring Vault...
Starting vault server...
==> Vault server configuration:
```

```

        Api Address: <api_address>
                Cgo: disabled
        Cluster Address: <cluster_address>
    Environment Variables: BASH_FUNC_which%%,
DBUS_SESSION_BUS_ADDRESS, GODEBUG, HISTCONTROL, HISTSIZE, HOME,
HOSTNAME, HOST_ACCOUNT, LANG, LESSOPEN, LOGNAME, LS_COLORS, MAIL,
PATH, PWD, SHELL, SHLVL, SSH_CLIENT, SSH_CONNECTION, SSH_TTY,
STAF_TEMP_DIR, TERM, USER, VAULT_ADDR, VAULT_TOKEN,
XDG_RUNTIME_DIR, XDG_SESSION_ID, _, vault_addr, which_declare
        Go Version: go1.20.5
        Listener 1: tcp (addr: "0.0.0.0:8200", cluster
address: "0.0.0.0:8201", max_request_duration: "1m30s",
max_request_size: "33554432", tls: "enabled")
        Log Level:
            Mlock: supported: true, enabled: true
        Recovery Mode: false
            Storage: file
        Version: Vault v1.14.0, built 2023-06-
19T11:40:23Z
        Version Sha:
13a649f860186dfffe3f3a4459814d87191efc321

```

==> Vault server started! Log data will stream in below:

```

2023-11-23T15:58:10.400+0530 [INFO] proxy environment:
http_proxy="" https_proxy="" no_proxy=""
2023-11-23T15:58:10.432+0530 [INFO] core: Initializing version
history cache for core
2023-11-23T15:58:20.422+0530 [INFO] core: security barrier not
initialized
2023-11-23T15:58:20.422+0530 [INFO] core: seal configuration
missing, not initialized
2023-11-23T15:58:20.424+0530 [INFO] core: security barrier not
initialized
2023-11-23T15:58:20.425+0530 [INFO] core: security barrier
initialized: stored=1 shares=5 threshold=3
2023-11-23T15:58:20.427+0530 [INFO] core: post-unseal setup
starting
2023-11-23T15:58:20.448+0530 [INFO] core: loaded wrapping token
key
2023-11-23T15:58:20.448+0530 [INFO] core: successfully setup
plugin catalog: plugin-directory=""
2023-11-23T15:58:20.448+0530 [INFO] core: no mounts; adding
default mount table
2023-11-23T15:58:20.449+0530 [INFO] core: successfully mounted:
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/

```

```
namespace="ID: root. Path: "
2023-11-23T15:58:20.449+0530 [INFO] core: successfully mounted:
type=system version="v1.14.0+builtin.vault" path=sys/
namespace="ID: root. Path: "
2023-11-23T15:58:20.449+0530 [INFO] core: successfully mounted:
type=identity version="v1.14.0+builtin.vault" path=identity/
namespace="ID: root. Path: "
2023-11-23T15:58:20.451+0530 [INFO] core: successfully mounted:
type=token version="v1.14.0+builtin.vault" path=token/
namespace="ID: root. Path: "
2023-11-23T15:58:20.452+0530 [INFO] rollback: starting rollback
manager
2023-11-23T15:58:20.452+0530 [INFO] core: restoring leases
2023-11-23T15:58:20.453+0530 [INFO] identity: entities restored
2023-11-23T15:58:20.453+0530 [INFO] identity: groups restored
2023-11-23T15:58:20.453+0530 [INFO] expiration: lease restore
complete
2023-11-23T15:58:20.453+0530 [INFO] core: usage gauge collection
is disabled
2023-11-23T15:58:20.453+0530 [INFO] core: Recorded vault
version: vault version=1.14.0 upgrade time="2023-11-23
10:28:20.453481904 +0000 UTC" build date=2023-06-19T11:40:23Z
2023-11-23T15:58:20.818+0530 [INFO] core: post-unseal setup
complete
2023-11-23T15:58:20.819+0530 [INFO] core: root token generated
2023-11-23T15:58:20.819+0530 [INFO] core: pre-seal teardown
starting
2023-11-23T15:58:20.819+0530 [INFO] rollback: stopping rollback
manager
2023-11-23T15:58:20.819+0530 [INFO] core: pre-seal teardown
complete
2023-11-23T15:58:21.116+0530 [INFO] core.cluster-listener.tcp:
starting listener: listener_address=0.0.0.0:8201
2023-11-23T15:58:21.116+0530 [INFO] core.cluster-listener:
serving cluster requests: cluster_listen_address=[::]:8201
2023-11-23T15:58:21.117+0530 [INFO] core: post-unseal setup
starting
2023-11-23T15:58:21.117+0530 [INFO] core: loaded wrapping token
key
2023-11-23T15:58:21.117+0530 [INFO] core: successfully setup
plugin catalog: plugin-directory=""
2023-11-23T15:58:21.119+0530 [INFO] core: successfully mounted:
type=system version="v1.14.0+builtin.vault" path=sys/
namespace="ID: root. Path: "
2023-11-23T15:58:21.120+0530 [INFO] core: successfully mounted:
type=identity version="v1.14.0+builtin.vault" path=identity/
```

```
namespace="ID: root. Path: "
2023-11-23T15:58:21.120+0530 [INFO] core: successfully mounted:
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/
namespace="ID: root. Path: "
2023-11-23T15:58:21.123+0530 [INFO] core: successfully mounted:
type=token version="v1.14.0+builtin.vault" path=token/
namespace="ID: root. Path: "
2023-11-23T15:58:21.123+0530 [INFO] rollback: starting rollback
manager
2023-11-23T15:58:21.124+0530 [INFO] core: restoring leases
2023-11-23T15:58:21.124+0530 [INFO] identity: entities restored
2023-11-23T15:58:21.124+0530 [INFO] identity: groups restored
2023-11-23T15:58:21.124+0530 [INFO] expiration: lease restore
complete
2023-11-23T15:58:21.125+0530 [INFO] core: usage gauge collection
is disabled
2023-11-23T15:58:21.125+0530 [INFO] core: post-unseal setup
complete
2023-11-23T15:58:21.125+0530 [INFO] core: vault is unsealed
Success! Uploaded policy: mcctb-policy
2023-11-23T15:58:21.600+0530 [INFO] core: enabled credential
backend: path=approle/ type=approle version=""
Success! Enabled approle auth method at: approle/
2023-11-23T15:58:21.690+0530 [INFO] core: successful mount:
namespace="" path=mcctb/ type=kv version=""
Success! Enabled the kv secrets engine at: mcctb/
Success! Data written to: auth/approle/role/mcctb-app
Upgrading to NetApp-MetroCluster-Tiebreaker-Software-1.6-
1.x86_64.rpm
Preparing...
#####
[100%]
Updating / installing...
1:NetApp-MetroCluster-Tiebreaker-
So#####
[ 50%]
Performing file integrity check
etc/cron.weekly/metrocluster-tiebreaker-support is Ok
etc/cron.weekly/metrocluster-tiebreaker-support-cov is Ok
etc/init.d/netapp-metrocluster-tiebreaker-software is Ok
etc/init.d/netapp-metrocluster-tiebreaker-software-cov is Ok
etc/logrotate.d/mcctb is Ok
opt/netapp/mcctb/lib/common/activation-1.1.1.jar is Ok
opt/netapp/mcctb/lib/common/aopalliance.jar is Ok
opt/netapp/mcctb/lib/common/args4j.jar is Ok
opt/netapp/mcctb/lib/common/aspectjrt.jar is Ok
opt/netapp/mcctb/lib/common/aspectjweaver.jar is Ok
opt/netapp/mcctb/lib/common/asup.jar is Ok
```

```
opt/netapp/mcctb/lib/common/bcpkix-jdk15on.jar is Ok
opt/netapp/mcctb/lib/common/bcprov-jdk15on.jar is Ok
opt/netapp/mcctb/lib/common/bcprov-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/bctls-fips-1.0.13.jar is Ok
opt/netapp/mcctb/lib/common/bctls-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/bcutil-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/cglib.jar is Ok
opt/netapp/mcctb/lib/common/commons-codec.jar is Ok
opt/netapp/mcctb/lib/common/commons-collections4.jar is Ok
opt/netapp/mcctb/lib/common/commons-compress.jar is Ok
opt/netapp/mcctb/lib/common/commons-daemon.jar is Ok
opt/netapp/mcctb/lib/common/commons-daemon.src.jar is Ok
opt/netapp/mcctb/lib/common/commons-dbcop2.jar is Ok
opt/netapp/mcctb/lib/common/commons-io.jar is Ok
opt/netapp/mcctb/lib/common/commons-lang3.jar is Ok
opt/netapp/mcctb/lib/common/commons-logging.jar is Ok
opt/netapp/mcctb/lib/common/commons-pool2.jar is Ok
opt/netapp/mcctb/lib/common/guava.jar is Ok
opt/netapp/mcctb/lib/common/httpclient.jar is Ok
opt/netapp/mcctb/lib/common/httpcore.jar is Ok
opt/netapp/mcctb/lib/common/jakarta.activation.jar is Ok
opt/netapp/mcctb/lib/common/jakarta.xml.bind-api.jar is Ok
opt/netapp/mcctb/lib/common/java-xmlbuilder.jar is Ok
opt/netapp/mcctb/lib/common/javax.inject.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-api-2.3.1.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-core.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-impl.jar is Ok
opt/netapp/mcctb/lib/common/jline.jar is Ok
opt/netapp/mcctb/lib/common/jna.jar is Ok
opt/netapp/mcctb/lib/common/joda-time.jar is Ok
opt/netapp/mcctb/lib/common/jsch.jar is Ok
opt/netapp/mcctb/lib/common/json.jar is Ok
opt/netapp/mcctb/lib/common/jsvc.zip is Ok
opt/netapp/mcctb/lib/common/junixsocket-common.jar is Ok
opt/netapp/mcctb/lib/common/junixsocket-native-common.jar is Ok
opt/netapp/mcctb/lib/common/logback-classic.jar is Ok
opt/netapp/mcctb/lib/common/logback-core.jar is Ok
opt/netapp/mcctb/lib/common/mail-1.6.2.jar is Ok
opt/netapp/mcctb/lib/common/mariadb-java-client.jar is Ok
opt/netapp/mcctb/lib/common/mcctb-mib.jar is Ok
opt/netapp/mcctb/lib/common/mcctb.jar is Ok
opt/netapp/mcctb/lib/common/mockito-core.jar is Ok
opt/netapp/mcctb/lib/common/slf4j-api.jar is Ok
opt/netapp/mcctb/lib/common/snmp4j.jar is Ok
opt/netapp/mcctb/lib/common/spring-aop.jar is Ok
opt/netapp/mcctb/lib/common/spring-beans.jar is Ok
```

```
opt/netapp/mcctb/lib/common/spring-context-support.jar is Ok
opt/netapp/mcctb/lib/common/spring-context.jar is Ok
opt/netapp/mcctb/lib/common/spring-core.jar is Ok
opt/netapp/mcctb/lib/common/spring-expression.jar is Ok
opt/netapp/mcctb/lib/common/spring-web.jar is Ok
opt/netapp/mcctb/lib/common/vault-java-driver.jar is Ok
opt/netapp/mcctb/lib/common/xz.jar is Ok
opt/netapp/mcctb/lib/org.jacoco.agent-0.8.8-runtime.jar is Ok
opt/netapp/mcctb/bin/mcctb-asup-invoke is Ok
opt/netapp/mcctb/bin/mcctb_postrotate is Ok
opt/netapp/mcctb/bin/netapp-metrocluster-tiebreaker-software-cli
is Ok
/
Synchronizing state of netapp-metrocluster-tiebreaker-
software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-
metrocluster-tiebreaker-software

Attempting to start NetApp MetroCluster Tiebreaker software
services
Started NetApp MetroCluster Tiebreaker software services
Successfully upgraded NetApp MetroCluster Tiebreaker software to
version 1.6.
Cleaning up / removing...
2:NetApp-MetroCluster-Tiebreaker-
So#####
[100%]
```

IMPORTANT: Please ensure you store the following private key used to decrypt audit logs securely in a safe location.
Consider the following recommendations:

- Save it to an encrypted storage device or file.
- Use strong, unique passwords to protect the storage device or file.
- Restrict access to the private key file to authorized individuals only.

The Private key is:

```
-----BEGIN PRIVATE KEY-----
<private_key_id>
-----END PRIVATE KEY-----
```

Monter le Tiebreaker 1.5 ou 1.4

Configurez l'accès administrateur à l'API ONTAP et à SSH

Vous pouvez configurer l'accès administrateur à l'API ONTAP et à SSH.

Étapes

1. Créez un utilisateur admin disposant d'un accès API ONTAP : `security login create -user-or-group-name mcctb -application ontapi -authentication-method password`
2. Créez un utilisateur admin disposant d'un accès SSH : `security login create -user-or-group-name mcctb -application ssh -authentication-method password`
3. Vérifier que les nouveaux utilisateurs admin sont créés : `security login show`
4. Répétez cette procédure sur le cluster partenaire.



"Authentification de l'administrateur et RBAC" est implémenté.

Installation des dépendances d'MetroCluster Tiebreaker

Selon votre système d'exploitation Linux hôte, vous devez installer un serveur MySQL ou MariaDB avant d'installer ou de mettre à niveau le logiciel Tiebreaker.

Étapes

1. Installez JRE.

[Installez JRE](#)

2. Installer et configurer le coffre-fort.

[Installer et configurer le coffre-fort](#)

3. Installez le serveur MySQL ou MariaDB :

Si l'hôte Linux est	Alors...
Red Hat Enterprise Linux 7/CentOS 7	Installez MySQL Installation de MySQL Server 5.5.30 ou version ultérieure et des versions 5.6.x sur Red Hat Enterprise Linux 7 ou CentOS 7
Red Hat Enterprise Linux 8	Installez MariaDB Installation du serveur MariaDB sur Red Hat Enterprise Linux 8

Installez JRE

Vous devez installer JRE sur votre système hôte avant d'installer ou de mettre à niveau le logiciel Tiebreaker. Pour les systèmes exécutant Tiebreaker 1.4 et versions antérieures, exécutez JRE 8. Pour les systèmes exécutant Tiebreaker 1.5 et versions ultérieures, exécutez OpenJDK 17, 18 ou 19.



Les sorties de l'exemple suivant montrent JRE 1.8.0. (JRE 8).

Étapes

1. Connectez-vous en tant qu'utilisateur « root » ou utilisateur sudo qui peut passer en mode priviléges avancés.

```
login as: root
root@mcctb's password:
Last login: Fri Jan  8 21:33:00 2017 from host.domain.com
```

2. Vérifiez les versions JRE disponibles :

```
yum search openjdk
```

3. Installez une version JRE appropriée pour la version de Tiebreaker que vous installez :

```
yum install java-<version>-openjdk.x86_64
```

```
[root@mcctb ~]# yum install java-1.8.0-openjdk.x86_64
Loaded plugins: fastestmirror, langpacks
Loading mirror speeds from cached hostfile
... shortened....
Dependencies Resolved

=====
Package           Arch      Version          Repository      Size
=====
Installing:
java-1.8.0-openjdk x86_64  1:1.8.0.144-0.b01.el7_4 updates      238 k
..
..
Transaction Summary
=====
Install 1 Package (+ 4 Dependent packages)

Total download size: 34 M
Is this ok [y/d/N]: y

Installed:
java-1.8.0-openjdk.x86_64 1:1.8.0.144-0.b01.el7_4
Complete!
```

Installer et configurer le coffre-fort

Si vous n'avez pas ou ne souhaitez pas utiliser le serveur Vault local, vous devez installer Vault. Vous pouvez

vous reporter à cette procédure standard pour installer Vault ou consulter les instructions d'installation de Hashicorp pour obtenir d'autres instructions.



Si votre réseau comporte un serveur de coffre-fort, vous pouvez configurer l'hôte MetroCluster Tiebreaker pour qu'il utilise cette installation de coffre-fort. Si vous le faites, vous n'avez pas besoin d'installer Vault sur l'hôte.

Étapes

1. Accédez au /bin répertoire :

```
[root@mcctb ~] cd /bin
```

2. Téléchargez le fichier zip du coffre-fort.

```
[root@mcctb ~]# curl -sO  
https://releases.hashicorp.com/vault/1.12.2/vault_1.12.2_linux_amd64.zip
```

3. Décompressez le fichier du coffre-fort.

```
[root@mcctb ~]# unzip vault_1.12.2_linux_amd64.zip  
Archive: vault_1.12.2_linux_amd64.zip  
inflating: vault
```

4. Vérifiez l'installation.

```
[root@mcctb ~]# vault -version  
Vault v1.12.2 (415e1fe3118eebd5df6cb60d13defdc01aa17b03), built 2022-11-  
23T12:53:46Z
```

5. Accédez au /root répertoire :

```
[root@mcctb ~] cd /root
```

6. Créez un fichier de configuration de coffre-fort sous /root répertoire.

Au [root@mcctb ~] demander, copier et exécuter la commande suivante pour créer le config.hcl fichier :

```
# cat > config.hcl << EOF
storage "file" {
  address = "127.0.0.1:8500"
  path     = "/mcctb_vdata/data"
}
listener "tcp" {
  address      = "127.0.0.1:8200"
  tls_disable  = 1
}
EOF
```

7. Démarrez le serveur Vault :

```
[root@mcctb ~] vault server -config config.hcl &
```

8. Exportez l'adresse du coffre-fort.

```
[root@mcctb ~]# export VAULT_ADDR="http://127.0.0.1:8200"
```

9. Initialiser le coffre-fort.

```
[root@mcctb ~]# vault operator init
2022-12-15T14:57:22.113+0530 [INFO] core: security barrier not
initialized
2022-12-15T14:57:22.113+0530 [INFO] core: seal configuration missing,
not initialized
2022-12-15T14:57:22.114+0530 [INFO] core: security barrier not
initialized
2022-12-15T14:57:22.116+0530 [INFO] core: security barrier initialized:
stored=1 shares=5 threshold=3
2022-12-15T14:57:22.118+0530 [INFO] core: post-unseal setup starting
2022-12-15T14:57:22.137+0530 [INFO] core: loaded wrapping token key
2022-12-15T14:57:22.137+0530 [INFO] core: Recorded vault version: vault
version=1.12.2 upgrade_time="2022-12-15 09:27:22.137200412 +0000 UTC"
build_date=2022-11-23T12:53:46Z
2022-12-15T14:57:22.137+0530 [INFO] core: successfully setup plugin
catalog: plugin-directory=""
2022-12-15T14:57:22.137+0530 [INFO] core: no mounts; adding default
mount table
2022-12-15T14:57:22.143+0530 [INFO] core: successfully mounted backend:
type=cubbyhole version="" path=cubbyhole/
2022-12-15T14:57:22.144+0530 [INFO] core: successfully mounted backend:
type=system version="" path=sys/
```

```
2022-12-15T14:57:22.144+0530 [INFO] core: successfully mounted backend:  
type=identity version="" path=identity/  
2022-12-15T14:57:22.148+0530 [INFO] core: successfully enabled  
credential backend: type=token version="" path=token/ namespace="ID:  
root. Path: "  
2022-12-15T14:57:22.149+0530 [INFO] rollback: starting rollback manager  
2022-12-15T14:57:22.149+0530 [INFO] core: restoring leases  
2022-12-15T14:57:22.150+0530 [INFO] expiration: lease restore complete  
2022-12-15T14:57:22.150+0530 [INFO] identity: entities restored  
2022-12-15T14:57:22.150+0530 [INFO] identity: groups restored  
2022-12-15T14:57:22.151+0530 [INFO] core: usage gauge collection is  
disabled  
2022-12-15T14:57:23.385+0530 [INFO] core: post-unseal setup complete  
2022-12-15T14:57:23.387+0530 [INFO] core: root token generated  
2022-12-15T14:57:23.387+0530 [INFO] core: pre-seal teardown starting  
2022-12-15T14:57:23.387+0530 [INFO] rollback: stopping rollback manager  
2022-12-15T14:57:23.387+0530 [INFO] core: pre-seal teardown complete  
Unseal Key 1: <unseal_key_1_id>  
Unseal Key 2: <unseal_key_2_id>  
Unseal Key 3: <unseal_key_3_id>  
Unseal Key 4: <unseal_key_4_id>  
Unseal Key 5: <unseal_key_5_id>
```

Initial Root Token: <initial_root_token_id>

Vault initialized with 5 key shares and a key threshold of 3. Please securely distribute the key shares printed above. When the Vault is re-sealed, restarted, or stopped, you must supply at least 3 of these keys to unseal it before it can start servicing requests.

Vault does not store the generated root key. Without at least 3 keys to reconstruct the root key, Vault will remain permanently sealed!

It is possible to generate new unseal keys, provided you have a quorum of existing unseal keys shares. See "vault operator rekey" for more information.



Vous devez enregistrer et stocker les ID de clé et le jeton racine initial dans un emplacement sécurisé pour pouvoir les utiliser ultérieurement dans la procédure.

10. Exportez le jeton racine du coffre-fort.

```
[root@mcctb ~]# export VAULT_TOKEN=<initial_root_token_id>
```

11. Déscellez le coffre-fort en utilisant trois des cinq clés créées.

Vous devez exécuter le `vault operator unseal` pour chacune des trois touches :

- Désceller le coffre-fort à l'aide de la première clé :

```
[root@mcctb ~]# vault operator unseal
Unseal Key (will be hidden):
Key          Value
---          -----
Seal Type    shamir
Initialized   true
Sealed       true
Total Shares 5
Threshold    3
Unseal Progress 1/3
Unseal Nonce <unseal_key_1_id>
Version      1.12.2
Build Date   2022-11-23T12:53:46Z
Storage Type file
HA Enabled   false
```

- Désceller le coffre-fort à l'aide de la deuxième clé :

```
[root@mcctb ~]# vault operator unseal
Unseal Key (will be hidden):
Key          Value
---          -----
Seal Type    shamir
Initialized   true
Sealed       true
Total Shares 5
Threshold    3
Unseal Progress 2/3
Unseal Nonce <unseal_key_2_id>
Version      1.12.2
Build Date   2022-11-23T12:53:46Z
Storage Type file
HA Enabled   false
```

- Désceller le coffre-fort à l'aide de la troisième clé :

```

[root@mcctb ~]# vault operator unseal
Unseal Key (will be hidden):
2022-12-15T15:15:00.980+0530 [INFO]  core.cluster-listener.tcp:
starting listener: listener_address=127.0.0.1:8201
2022-12-15T15:15:00.980+0530 [INFO]  core.cluster-listener: serving
cluster requests: cluster_listen_address=127.0.0.1:8201
2022-12-15T15:15:00.981+0530 [INFO]  core: post-unseal setup starting
2022-12-15T15:15:00.981+0530 [INFO]  core: loaded wrapping token key
2022-12-15T15:15:00.982+0530 [INFO]  core: successfully setup plugin
catalog: plugin-directory=""
2022-12-15T15:15:00.983+0530 [INFO]  core: successfully mounted
backend: type=system version="" path=sys/
2022-12-15T15:15:00.984+0530 [INFO]  core: successfully mounted
backend: type=identity version="" path=identity/
2022-12-15T15:15:00.984+0530 [INFO]  core: successfully mounted
backend: type=cubbyhole version="" path=cubbyhole/
2022-12-15T15:15:00.986+0530 [INFO]  core: successfully enabled
credential backend: type=token version="" path=token/ namespace="ID:
root. Path: "
2022-12-15T15:15:00.986+0530 [INFO]  rollback: starting rollback
manager
2022-12-15T15:15:00.987+0530 [INFO]  core: restoring leases
2022-12-15T15:15:00.987+0530 [INFO]  expiration: lease restore
complete
2022-12-15T15:15:00.987+0530 [INFO]  identity: entities restored
2022-12-15T15:15:00.987+0530 [INFO]  identity: groups restored
2022-12-15T15:15:00.988+0530 [INFO]  core: usage gauge collection is
disabled
2022-12-15T15:15:00.989+0530 [INFO]  core: post-unseal setup complete
2022-12-15T15:15:00.989+0530 [INFO]  core: vault is unsealed
Key          Value
---          -----
Seal Type    shamir
Initialized   true
Sealed       false
Total Shares 5
Threshold    3
Version      1.12.2
Build Date   2022-11-23T12:53:46Z
Storage Type file
Cluster Name vault-cluster
Cluster ID   <cluster_id>
HA Enabled   false

```

12. Vérifiez que l'état scellé du coffre-fort est faux.

```
[root@mcctb ~]# vault status
Key          Value
---          -----
Seal Type    shamir
Initialized   true
Sealed       false
Total Shares 5
Threshold    3
Version      1.12.2
Build Date   2022-11-23T12:53:46Z
Storage Type file
Cluster Name vault-cluster
Cluster ID   <cluster_id>
HA Enabled   false
```

13. Configurez le service Vault pour qu'il démarre au démarrage.

- a. Exécutez la commande suivante : cd /etc/systemd/system

```
[root@mcctb ~]# cd /etc/systemd/system
```

- b. Au [root@mcctb system] Demander, copier et exécuter la commande suivante pour créer le fichier de service Vault.

```
# cat > vault.service << EOF
[Unit]
Description=Vault Service
After=mariadb.service

[Service]
Type=forking
ExecStart=/usr/bin/vault server -config /root/config.hcl &
Restart=on-failure

[Install]
WantedBy=multi-user.target
EOF
```

- c. Exécutez la commande suivante : systemctl daemon-reload

```
[root@mcctb system]# systemctl daemon-reload
```

- d. Exécutez la commande suivante : systemctl enable vault.service

```
[root@mcctb system]# systemctl enable vault.service
Created symlink /etc/systemd/system/multi-
user.target.wants/vault.service → /etc/systemd/system/vault.service.
```



Vous êtes invité à utiliser cette fonction lors de l'installation de MetroCluster Tiebreaker. Si vous souhaitez modifier la méthode pour annuler le scellage du coffre-fort, vous devez désinstaller et réinstaller le logiciel MetroCluster Tiebreaker.

Installation de MySQL Server 5.5.30 ou version ultérieure et des versions 5.6.x sur Red Hat Enterprise Linux 7 ou CentOS 7

Vous devez installer MySQL Server 5.5.30 ou version ultérieure et 5.6.x sur votre système hôte avant d'installer ou de mettre à niveau le logiciel disjoncteur d'attache.

Étapes

1. Connectez-vous en tant qu'utilisateur root ou utilisateur sudo qui peut passer en mode priviléges avancés.

```
login as: root
root@mcctb's password:
Last login: Fri Jan  8 21:33:00 2016 from host.domain.com
```

2. Ajoutez le référentiel MySQL à votre système hôte :

```
[root@mcctb ~]# yum localinstall https://dev.mysql.com/get/mysql57-community-
release-el6-11.noarch.rpm
```

```

Loaded plugins: product-id, refresh-packagekit, security, subscription-
manager
Setting up Local Package Process
Examining /var/tmp/yum-root-LLUw0r/mysql-community-release-el6-
5.noarch.rpm: mysql-community-release-el6-5.noarch
Marking /var/tmp/yum-root-LLUw0r/mysql-community-release-el6-
5.noarch.rpm to be installed
Resolving Dependencies
--> Running transaction check
--> Package mysql-community-release.noarch 0:e16-5 will be installed
--> Finished Dependency Resolution
Dependencies Resolved
=====
=====
Package           Arch      Version
                                         Repository
Size
=====
=====
Installing:
mysql-community-release
                           noarch  el6-5 /mysql-community-release-el6-
5.noarch 4.3 k
Transaction Summary
=====
=====
Install          1 Package(s)
Total size: 4.3 k
Installed size: 4.3 k
Is this ok [y/N]: y
Downloading Packages:
Running rpm_check_debug
Running Transaction Test
Transaction Test Succeeded
Running Transaction
  Installing : mysql-community-release-el6-5.noarch
1/1
  Verifying   : mysql-community-release-el6-5.noarch
1/1
Installed:
  mysql-community-release.noarch 0:e16-5
Complete!

```

3. Désactivez le référentiel MySQL 57 :

```
[root@mcctb ~]# yum-config-manager --disable mysql57-community
```

4. Activez le référentiel MySQL 56 :

```
[root@mcctb ~]# yum-config-manager --enable mysql56-community
```

5. Activer le référentiel :

```
[root@mcctb ~]# yum repolist enabled | grep "mysql.-community."
```

mysql-connectors-community 21	MySQL Connectors Community
mysql-tools-community 35	MySQL Tools Community
mysql56-community 231	MySQL 5.6 Community Server

6. Installez le serveur de communauté MySQL :

```
[root@mcctb ~]# yum install mysql-community-server
```

```
Loaded plugins: product-id, refresh-packagekit, security, subscription-
manager
This system is not registered to Red Hat Subscription Management. You
can use subscription-manager
to register.
Setting up Install Process
Resolving Dependencies
--> Running transaction check
.....Output truncated.....
---> Package mysql-community-libs-compat.x86_64 0:5.6.29-2.el6 will be
obsoleting
--> Finished Dependency Resolution
Dependencies Resolved
=====
=====
Package          Arch    Version        Repository
Size
=====
=====
Installing:
  mysql-community-client      x86_64  5.6.29-2.el6  mysql56-community
18 M
    replacing  mysql.x86_64 5.1.71-1.el6
  mysql-community-libs         x86_64  5.6.29-2.el6  mysql56-community
1.9 M
```

```

        replacing mysql-libs.x86_64 5.1.71-1.el6
mysql-community-libs-compat      x86_64  5.6.29-2.el6  mysql56-community
1.6 M
        replacing mysql-libs.x86_64 5.1.71-1.el6
mysql-community-server          x86_64  5.6.29-2.el6  mysql56-community
53 M
        replacing mysql-server.x86_64 5.1.71-1.el6
Installing for dependencies:
mysql-community-common          x86_64  5.6.29-2.el6  mysql56-community
308 k

Transaction Summary
=====
=====
Install      5 Package(s)
Total download size: 74 M
Is this ok [y/N]: y
Downloading Packages:
(1/5): mysql-community-client-5.6.29-2.el6.x86_64.rpm | 18 MB
00:28
(2/5): mysql-community-common-5.6.29-2.el6.x86_64.rpm | 308 kB
00:01
(3/5): mysql-community-libs-5.6.29-2.el6.x86_64.rpm | 1.9 MB
00:05
(4/5): mysql-community-libs-compat-5.6.29-2.el6.x86_64.rpm | 1.6 MB
00:05
(5/5): mysql-community-server-5.6.29-2.el6.x86_64.rpm | 53 MB
03:42
-----
-----
Total                                         289 kB/s | 74 MB
04:24
warning: rpmts_HdrFromFdno: Header V3 DSA/SHA1 Signature, key ID
<key_id> NOKEY
Retrieving key from file:/etc/pki/rpm-gpg/RPM-GPG-KEY-mysql
Importing GPG key 0x5072E1F5:
  Userid : MySQL Release Engineering <mysql-build@oss.oracle.com>
  Package: mysql-community-release-el6-5.noarch
            (@/mysql-community-release-el6-5.noarch)
  From   : file:/etc/pki/rpm-gpg/RPM-GPG-KEY-mysql
Is this ok [y/N]: y
Running rpm_check_debug
Running Transaction Test
Transaction Test Succeeded
Running Transaction
  Installing : mysql-community-common-5.6.29-2.el6.x86_64

```

```
....Output truncated....  
1.el6.x86_64  
7/8  
Verifying : mysql-5.1.71-1.el6.x86_64  
8/8  
Installed:  
mysql-community-client.x86_64 0:5.6.29-2.el6  
mysql-community-libs.x86_64 0:5.6.29-2.el6  
mysql-community-libs-compat.x86_64 0:5.6.29-2.el6  
mysql-community-server.x86_64 0:5.6.29-2.el6  
  
Dependency Installed:  
mysql-community-common.x86_64 0:5.6.29-2.el6  
  
Replaced:  
mysql.x86_64 0:5.1.71-1.el6 mysql-libs.x86_64 0:5.1.71-1.el6  
mysql-server.x86_64 0:5.1.71-1.el6  
Complete!
```

7. Démarrez le serveur MySQL :

```
[root@mcctb ~]# service mysqld start
```

```
Initializing MySQL database: 2016-04-05 19:44:38 0 [Warning] TIMESTAMP  
with implicit DEFAULT value is deprecated. Please use  
--explicit_defaults_for_timestamp server option (see documentation  
for more details).  
2016-04-05 19:44:38 0 [Note] /usr/sbin/mysqld (mysqld 5.6.29)  
      starting as process 2487 ...  
2016-04-05 19:44:38 2487 [Note] InnoDB: Using atomics to ref count  
      buffer pool pages  
2016-04-05 19:44:38 2487 [Note] InnoDB: The InnoDB memory heap is  
      disabled  
.....Output truncated.....  
2016-04-05 19:44:42 2509 [Note] InnoDB: Shutdown completed; log sequence  
      number 1625987
```

PLEASE REMEMBER TO SET A PASSWORD FOR THE MySQL root USER!
To do so, start the server, then issue the following commands:

```
/usr/bin/mysqladmin -u root password 'new-password'  
/usr/bin/mysqladmin -u root -h mcctb password 'new-password'
```

Alternatively, you can run:

```
/usr/bin/mysql_secure_installation
```

which will also give you the option of removing the test
databases and anonymous user created by default. This is
strongly recommended for production servers.

.....Output truncated.....

WARNING: Default config file /etc/my.cnf exists on the system
This file will be read by default by the MySQL server
If you do not want to use this, either remove it, or use the
--defaults-file argument to mysqld_safe when starting the server

[OK]
Starting mysqld: [OK]

8. Vérifiez que le serveur MySQL est en cours d'exécution :

```
[root@mcctb ~]# service mysqld status
```

```
mysqld (pid 2739) is running...
```

9. Configurez les paramètres de sécurité et de mot de passe :

```
[root@mcctb ~]# mysql_secure_installation
```

NOTE: RUNNING ALL PARTS OF THIS SCRIPT IS RECOMMENDED FOR ALL MySQL SERVERS IN PRODUCTION USE! PLEASE READ EACH STEP CAREFULLY!

In order to log into MySQL to secure it, we'll need the current password for the root user. If you've just installed MySQL, and you haven't set the root password yet, the password will be blank, so you should just press enter here.

```
Enter current password for root (enter for none):      <== on default
install                                                 hit enter here
OK, successfully used password, moving on...
```

Setting the root password ensures that nobody can log into the MySQL root user without the proper authorization.

```
Set root password? [Y/n] y
New password:
Re-enter new password:
Password updated successfully!
Reloading privilege tables..
... Success!
```

By default, a MySQL installation has an anonymous user, allowing anyone to log into MySQL without having to have a user account created for them. This is intended only for testing, and to make the installation go a bit smoother. You should remove them before moving into a production environment.

```
Remove anonymous users? [Y/n] y
... Success!
```

Normally, root should only be allowed to connect from 'localhost'. This ensures that someone cannot guess at the root password from the network.

```
Disallow root login remotely? [Y/n] y
... Success!
```

By default, MySQL comes with a database named 'test' that anyone can access. This is also intended only for testing, and should be removed before moving into a production environment.

```
Remove test database and access to it? [Y/n] y
- Dropping test database...
ERROR 1008 (HY000) at line 1: Can't drop database 'test';
```

```
database doesn't exist
... Failed! Not critical, keep moving...
- Removing privileges on test database...
... Success!
```

Reloading the privilege tables will ensure that all changes made so far will take effect immediately.

```
Reload privilege tables now? [Y/n] y
... Success!
```

All done! If you've completed all of the above steps, your MySQL installation should now be secure.

Thanks for using MySQL!

Cleaning up...

10. Vérifiez que la connexion MySQL fonctionne :

```
[root@mcctb ~]# mysql -u root -p
```

```
Enter password: <configured_password>
```

```
Welcome to the MySQL monitor. Commands end with ; or \g.
```

```
Your MySQL connection id is 17
```

```
Server version: 5.6.29 MySQL Community Server (GPL)
```

```
Copyright (c) 2000, 2016, Oracle and/or its affiliates. All rights reserved.
```

```
Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.
```

```
Type 'help;' or '\h' for help. Type '\c' to clear the current input statement.
```

```
mysql>
```

Si le login MySQL fonctionne, la sortie se termine au `mysql>` à l'invite.

Activation du paramètre de démarrage automatique MySQL

Vous devez vérifier que la fonction de démarrage automatique est activée pour le démon MySQL. L'activation du démon MySQL redémarre automatiquement MySQL si le système sur lequel réside le logiciel MetroCluster Tiebreaker. Si le démon MySQL n'est pas en cours d'exécution, le logiciel disjoncteur d'attache continue à fonctionner, mais il ne peut pas être redémarré et des modifications de configuration ne peuvent pas être

effectuées.

Étape

1. Vérifiez que MySQL est activé pour démarrer automatiquement lors du démarrage :

```
[root@mcctb ~]# systemctl list-unit-files mysqld.service
```

UNIT	FILE	State
mysqld.service		enabled

Si MySQL n'est pas activé pour démarrer automatiquement au démarrage, consultez la documentation MySQL pour activer la fonction de démarrage automatique pour votre installation.

Installation du serveur MariaDB sur Red Hat Enterprise Linux 8

Vous devez installer le serveur MariaDB sur votre système hôte avant d'installer ou de mettre à niveau le logiciel disjoncteur d'attache.

Avant de commencer

Votre système hôte doit être exécuté sous Red Hat Enterprise Linux (RHEL) 8.

Étapes

1. Connectez-vous en tant que root utilisateur ou utilisateur qui peut passer en mode de privilège avancé.

```
login as: root
root@mcctb's password:
Last login: Fri Jan  8 21:33:00 2017 from host.domain.com
```

1. Installez le serveur MariaDB :

```
[root@mcctb ~]# yum install mariadb-server.x86_64
```

```
[root@mcctb ~]# yum install mariadb-server.x86_64
Loaded plugins: fastestmirror, langpacks
...
=====
===
  Package          Arch    Version      Repository
Size
=====
===
  Installing:
mariadb-server     x86_64  1:5.5.56-2.el7   base
```

```

11 M
Installing for dependencies:

Transaction Summary
=====
=====
Install 1 Package (+8 Dependent packages)
Upgrade           ( 1 Dependent package)

Total download size: 22 M
Is this ok [y/d/N]: y

Downloading packages:
No Presto metadata available for base warning:
/var/cache/yum/x86_64/7/base/packages/mariadb-libs-5.5.56-
2.el7.x86_64.rpm:
Header V3 RSA/SHA256 Signature,
key ID f4a80eb5: NOKEY] 1.4 MB/s | 3.3 MB  00:00:13 ETA
Public key for mariadb-libs-5.5.56-2.el7.x86_64.rpm is not installed
(1/10): mariadb-libs-5.5.56-2.el7.x86_64.rpm | 757 kB  00:00:01
..
..
(10/10): perl-Net-Daemon-0.48-5.el7.noarch.rpm| 51 kB  00:00:01
-----
-----
Installed:
mariadb-server.x86_64 1:5.5.56-2.el7

Dependency Installed:
mariadb.x86_64 1:5.5.56-2.el7
perl-Compress-Raw-Bzip2.x86_64 0:2.061-3.el7
perl-Compress-Raw-Zlib.x86_64 1:2.061-4.el7
perl-DBD-MySQL.x86_64 0:4.023-5.el7
perl-DBI.x86_64 0:1.627-4.el7
perl-IO-Compress.noarch 0:2.061-2.el7
perl-Net-Daemon.noarch 0:0.48-5.el7
perl-PlRPC.noarch 0:0.2020-14.el7

Dependency Updated:
mariadb-libs.x86_64 1:5.5.56-2.el7
Complete!

```

2. Démarrer le serveur MariaDB :

```
[root@mcctb ~]# systemctl start mariadb
```

3. Vérifiez que le serveur MariaDB a démarré :

```
[root@mcctb ~]# systemctl status mariadb
```

```
[root@mcctb ~]# systemctl status mariadb
mariadb.service - MariaDB database server
...
Nov 08 21:28:59 mcctb systemd[1]: Starting MariaDB database server...
...
Nov 08 21:29:01 mcctb systemd[1]: Started MariaDB database server.
```

4. Configurez les paramètres de sécurité et de mot de passe :



Lorsque vous êtes invité à entrer le mot de passe root, laissez-le vide et appuyez sur entrée pour continuer à configurer les paramètres de sécurité et de mot de passe.

```
[root@mcctb ~]# mysql_secure_installation
```

```
root@localhost systemd]# mysql_secure_installation
```

```
NOTE: RUNNING ALL PARTS OF THIS SCRIPT IS RECOMMENDED FOR ALL MariaDB
      SERVERS IN PRODUCTION USE! PLEASE READ EACH STEP CAREFULLY!
```

```
In order to log into MariaDB to secure it, we'll need the current
password for the root user. If you've just installed MariaDB, and
you haven't set the root password yet, the password will be blank,
so you should just press enter here.
```

```
Enter current password for root (enter for none):
OK, successfully used password, moving on...
```

```
Setting the root password ensures that nobody can log into the MariaDB
root user without the proper authorisation.
```

```
Set root password? [Y/n] y
New password:
Re-enter new password:
Password updated successfully!
Reloading privilege tables..
... Success!
```

```
By default, a MariaDB installation has an anonymous user, allowing
anyone
to log into MariaDB without having to have a user account created for
them. This is intended only for testing, and to make the installation
```

```
go a bit smoother. You should remove them before moving into a  
production environment.
```

```
Remove anonymous users? [Y/n] y  
... Success!
```

Normally, root should only be allowed to connect from 'localhost'. This ensures that someone cannot guess at the root password from the network.

```
Disallow root login remotely? [Y/n] y  
... Success!
```

By default, MariaDB comes with a database named 'test' that anyone can access. This is also intended only for testing, and should be removed before moving into a production environment.

```
Remove test database and access to it? [Y/n] y  
- Dropping test database...  
... Success!  
- Removing privileges on test database...  
... Success!
```

Reloading the privilege tables will ensure that all changes made so far will take effect immediately.

```
Reload privilege tables now? [Y/n]  
... Success!
```

Cleaning up...

All done! If you've completed all of the above steps, your MariaDB installation should now be secure.

Thanks for using MariaDB!

Activation du paramètre de démarrage automatique pour le serveur MariaDB

Vérifiez que la fonction de démarrage automatique est activée pour le serveur MariaDB. Si vous n'activez pas la fonctionnalité de démarrage automatique et si le système sur lequel réside le logiciel MetroCluster Tiebreaker doit être redémarré, alors le logiciel disjoncteur d'attache continue d'être en cours d'exécution, mais le service MariaDB ne peut pas être redémarré et les modifications de configuration ne peuvent pas être effectuées.

Étapes

1. Activer le service de démarrage automatique :

```
[root@mcctb ~]# systemctl enable mariadb.service
```

2. Vérifiez que MariaDB est activé pour démarrer automatiquement au démarrage :

```
[root@mcctb ~]# systemctl list-unit-files mariadb.service
```

UNIT	FILE	State
mariadb.service		enabled

Installation ou mise à niveau du progiciel

Vous devez installer ou mettre à niveau le logiciel MetroCluster Tiebreaker sur votre ordinateur local, afin d'assurer le contrôle des configurations MetroCluster.

Description de la tâche

- Votre système de stockage doit exécuter ONTAP 8.3.x ou une version ultérieure.
- Vous devez avoir installé OpenJDK à l'aide de `yum install java-x.x.x-openjdk` commande. Pour les systèmes exécutant Tiebreaker 1.4 et versions antérieures, exécutez JRE 8. Pour les systèmes exécutant Tiebreaker 1.5 et versions ultérieures, exécutez OpenJDK 17, 18 ou 19. Les sorties de l'exemple montrent JRE 1.8.0. (JRE 8).
- Vous pouvez installer MetroCluster Tiebreaker en tant qu'utilisateur non root disposant de priviléges d'administration suffisants pour effectuer l'installation de Tiebreaker, créer des tables et des utilisateurs et définir le mot de passe utilisateur.

Étapes

1. Téléchargez le logiciel MetroCluster Tiebreaker. Cet exemple utilise la version 1.5.

["Site de support NetApp"](#)

2. Téléchargez le `MetroCluster_Tiebreaker_RPM_GPG` clé :

["Site de support NetApp"](#)

3. Connectez-vous à l'hôte en tant qu'utilisateur racine.
4. Créez un utilisateur non root et le `mcctbgrp` groupe.
 - a. Créez un utilisateur non root et définissez le mot de passe.

Les exemples de commandes suivants créent un utilisateur non root nommé `mcctbuser1`:

```
[root@mcctb ~]# useradd mcctbuser1
[root@mcctb ~]# passwd mcctbuser1
Changing password for user mcctbuser1.
New password:
Retype new password:
passwd: all authentication tokens updated successfully.
```

b. Créez un groupe nommé mcctbgrp:

```
[root@mcctb ~]# groupadd mcctbgrp
```

c. Ajoutez l'utilisateur non racine que vous avez créé à l' mcctbgrp groupe.

La commande suivante ajoute mcctbuser1 à la mcctbgrp groupe :

```
[root@mcctb ~]# usermod -a -G mcctbgrp mcctbuser1
```

5. Vérifiez le fichier RPM.

Exécutez les sous-étapes suivantes à partir du répertoire contenant la clé RPM.

a. Téléchargez et importez le fichier de clé RPM :

```
[root@mcctb ~]# rpm --import MetroCluster_Tiebreaker_RPM_GPG.key
```

b. Vérifiez que la clé correcte a été importée en vérifiant l'empreinte digitale.

L'exemple suivant montre une empreinte de clé correcte :

```
root@mcctb:~/signing/mcctb-rpms# gpg --show-keys --with-fingerprint
MetroCluster_Tiebreaker_RPM_GPG.key
pub    rsa3072 2022-11-17 [SCEA] [expires: 2025-11-16]
      65AC 1562 E28A 1497 7BBD  7251 2855 EB02 3E77 FAE5
uid                               MCCTB-RPM (mcctb RPM production signing)
<mcctb-rpm@netapp.com>
```

a. Vérifiez la signature : `rpm --checksig NetApp-MetroCluster-Tiebreaker-Software-1.5-1.x86_64.rpm`

```
NetApp-MetroCluster-Tiebreaker-Software-1.5-1.x86_64.rpm: digests OK
```



Vous devez procéder à l'installation uniquement après avoir vérifié avec succès la signature.

6. installez ou mettez à niveau le logiciel Tiebreaker :



Vous ne pouvez effectuer une mise à niveau vers la version 1.5 de Tiebreaker que lorsque vous effectuez une mise à niveau à partir de la version 1.4 de Tiebreaker. La mise à niveau à partir de versions antérieures vers Tiebreaker 1.5 n'est pas prise en charge.

Sélectionnez la procédure correcte ci-dessous selon que vous effectuez une nouvelle installation ou une mise à niveau d'une installation existante.

Effectuez une nouvelle installation

- a. Récupérez et enregistrez le chemin absolu pour Java :

```
[root@mcctb ~]# readlink -f /usr/bin/java  
/usr/lib/jvm/java-19-openjdk-19.0.0.36-  
2.rolling.el8.x86_64/bin/java
```

- b. Exécutez la commande suivante : `rpm -ivh NetApp-MetroCluster-Tiebreaker-Software-1.5-1.x86_64.rpm`

Pour une installation réussie, le système affiche les valeurs de sortie suivantes :



Lorsque vous y êtes invité pendant l'installation, indiquez l'utilisateur non root que vous avez créé et affecté au système `mcctbgrp` groupe.

```
Verifying...
#####
Preparing...
#####
Updating / installing...
  1:NetApp-MetroCluster-Tiebreaker-
So#####
Enter the absolute path for Java : /usr/lib/jvm/java-19-openjdk-
19.0.0.0.36-2.rolling.el8.x86_64/bin/java
Verifying if Java exists...
Found Java. Proceeding with the installation.
Enter host user account to use for the installation:
mcctbuser1
User account mcctbuser1 found. Proceeding with the installation
Enter database user name:
root
Please enter database password for root
Enter password:
Sealed          false
Do you wish to auto unseal vault(y/n)?y
Enter the key1:
Enter the key2:
Enter the key3:
Success! Uploaded policy: mcctb-policy
Error enabling approle auth: Error making API request.
URL: POST http://127.0.0.1:8200/v1/sys/auth/approle
Code: 400. Errors:
* path is already in use at approle/
Success! Enabled the kv secrets engine at: mcctb/
Success! Data written to: auth/approle/role/mcctb-app
Password updated successfully in the vault.
Synchronizing state of netapp-metrocluster-tiebreaker-
software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-
metrocluster-tiebreaker-software
Created symlink /etc/systemd/system/multi-
user.target.wants/netapp-metrocluster-tiebreaker-software.service
→ /etc/systemd/system/netapp-metrocluster-tiebreaker-
software.service.
Attempting to start NetApp MetroCluster Tiebreaker software
services
Started NetApp MetroCluster Tiebreaker software services
Successfully installed NetApp MetroCluster Tiebreaker software
version 1.5.
```

Mise à niveau d'une installation existante

- Vérifiez qu'une version prise en charge d'OpenJDK est installée et qu'elle correspond à la version Java actuelle située sur l'hôte.



Pour les mises à niveau vers Tiebreaker 1.5, vous devez installer OpenJDK version 17, 18 ou 19.

```
[root@mcctb ~]# readlink -f /usr/bin/java  
/usr/lib/jvm/java-19-openjdk-19.0.0.36-  
2.rolling.el8.x86_64/bin/java
```

- Vérifiez que le service Vault n'est pas scellé et en cours d'exécution : `vault status`

```
[root@mcctb ~]# vault status  
Key          Value  
---          ----  
Seal Type    shamir  
Initialized   true  
Sealed       false  
Total Shares  5  
Threshold    3  
Version      1.12.2  
Build Date   2022-11-23T12:53:46Z  
Storage Type file  
Cluster Name vault  
Cluster ID   <cluster_id>  
HA Enabled   false
```

- Mettez à niveau le logiciel Tiebreaker.

```
[root@mcctb ~]# rpm -Uvh NetApp-MetroCluster-Tiebreaker-Software-  
1.5-1.x86_64.rpm
```

Le système affiche les résultats suivants pour une mise à niveau réussie :

```
Verifying...
#####
Preparing...
#####
Updating / installing...
1:NetApp-MetroCluster-Tiebreaker-
So#####
Enter the absolute path for Java : /usr/lib/jvm/java-19-openjdk-19.0.0.0.36-2.rolling.el8.x86_64/bin/java
Verifying if Java exists...
Found Java. Proceeding with the installation.
Enter host user account to use for the installation:
mcctbuser1
User account mcctbuser1 found. Proceeding with the installation
Sealed          false
Do you wish to auto unseal vault(y/n)?y
Enter the key1:
Enter the key2:
Enter the key3:
Success! Uploaded policy: mcctb-policy
Error enabling approle auth: Error making API request.
URL: POST http://127.0.0.1:8200/v1/sys/auth/approle
Code: 400. Errors:
* path is already in use at approle/
Success! Enabled the kv secrets engine at: mcctb/
Success! Data written to: auth/approle/role/mcctb-app
Enter database user name : root
Please enter database password for root
Enter password:
Password updated successfully in the database.
Password updated successfully in the vault.
Synchronizing state of netapp-metrocluster-tiebreaker-software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-metrocluster-tiebreaker-software
Attempting to start NetApp MetroCluster Tiebreaker software services
Started NetApp MetroCluster Tiebreaker software services
Successfully upgraded NetApp MetroCluster Tiebreaker software to version 1.5.
Cleaning up / removing...
2:NetApp-MetroCluster-Tiebreaker-
So#####
[100%]
```



Si vous saisissez un mot de passe racine MySQL incorrect, le logiciel disjoncteur d'attache indique qu'il a été installé avec succès, mais affiche des messages « accès refusé ». Pour résoudre ce problème, vous devez désinstaller le logiciel disjoncteur d'attache à l'aide du `rpm -e`. Puis réinstallez le logiciel en utilisant le mot de passe racine MySQL correct.

7. Vérifiez la connectivité Tiebreaker au logiciel MetroCluster en ouvrant une connexion SSH depuis l'hôte Tiebreaker vers chacune des LIFs de node management et des LIFs de cluster management.

Informations associées

["Support NetApp"](#)

Informations sur le copyright

Copyright © 2024 NetApp, Inc. Tous droits réservés. Imprimé aux États-Unis. Aucune partie de ce document protégé par copyright ne peut être reproduite sous quelque forme que ce soit ou selon quelque méthode que ce soit (graphique, électronique ou mécanique, notamment par photocopie, enregistrement ou stockage dans un système de récupération électronique) sans l'autorisation écrite préalable du détenteur du droit de copyright.

Les logiciels dérivés des éléments NetApp protégés par copyright sont soumis à la licence et à l'avis de non-responsabilité suivants :

CE LOGICIEL EST FOURNI PAR NETAPP « EN L'ÉTAT » ET SANS GARANTIES EXPRESSES OU TACITES, Y COMPRIS LES GARANTIES TACITES DE QUALITÉ MARCHANDE ET D'ADÉQUATION À UN USAGE PARTICULIER, QUI SONT EXCLUES PAR LES PRÉSENTES. EN AUCUN CAS NETAPP NE SERA TENU POUR RESPONSABLE DE DOMMAGES DIRECTS, INDIRECTS, ACCESSOIRES, PARTICULIERS OU EXEMPLAIRES (Y COMPRIS L'ACHAT DE BIENS ET DE SERVICES DE SUBSTITUTION, LA PERTE DE JOUSSANCE, DE DONNÉES OU DE PROFITS, OU L'INTERRUPTION D'ACTIVITÉ), QUELLES QU'EN SOIENT LA CAUSE ET LA DOCTRINE DE RESPONSABILITÉ, QU'IL S'AGISSE DE RESPONSABILITÉ CONTRACTUELLE, STRICTE OU DÉLICTUELLE (Y COMPRIS LA NÉGLIGENCE OU AUTRE) DÉCOULANT DE L'UTILISATION DE CE LOGICIEL, MÊME SI LA SOCIÉTÉ A ÉTÉ INFORMÉE DE LA POSSIBILITÉ DE TELS DOMMAGES.

NetApp se réserve le droit de modifier les produits décrits dans le présent document à tout moment et sans préavis. NetApp décline toute responsabilité découlant de l'utilisation des produits décrits dans le présent document, sauf accord explicite écrit de NetApp. L'utilisation ou l'achat de ce produit ne concède pas de licence dans le cadre de droits de brevet, de droits de marque commerciale ou de tout autre droit de propriété intellectuelle de NetApp.

Le produit décrit dans ce manuel peut être protégé par un ou plusieurs brevets américains, étrangers ou par une demande en attente.

LÉGENDE DE RESTRICTION DES DROITS : L'utilisation, la duplication ou la divulgation par le gouvernement sont sujettes aux restrictions énoncées dans le sous-paragraphe (b)(3) de la clause Rights in Technical Data-Noncommercial Items du DFARS 252.227-7013 (février 2014) et du FAR 52.227-19 (décembre 2007).

Les données contenues dans les présentes se rapportent à un produit et/ou service commercial (tel que défini par la clause FAR 2.101). Il s'agit de données propriétaires de NetApp, Inc. Toutes les données techniques et tous les logiciels fournis par NetApp en vertu du présent Accord sont à caractère commercial et ont été exclusivement développés à l'aide de fonds privés. Le gouvernement des États-Unis dispose d'une licence limitée irrévocable, non exclusive, non cessible, non transférable et mondiale. Cette licence lui permet d'utiliser uniquement les données relatives au contrat du gouvernement des États-Unis d'après lequel les données lui ont été fournies ou celles qui sont nécessaires à son exécution. Sauf dispositions contraires énoncées dans les présentes, l'utilisation, la divulgation, la reproduction, la modification, l'exécution, l'affichage des données sont interdits sans avoir obtenu le consentement écrit préalable de NetApp, Inc. Les droits de licences du Département de la Défense du gouvernement des États-Unis se limitent aux droits identifiés par la clause 252.227-7015(b) du DFARS (février 2014).

Informations sur les marques commerciales

NETAPP, le logo NETAPP et les marques citées sur le site <http://www.netapp.com/TM> sont des marques déposées ou des marques commerciales de NetApp, Inc. Les autres noms de marques et de produits sont des marques commerciales de leurs propriétaires respectifs.