



## Installare il software Tiebreaker

### ONTAP MetroCluster

NetApp  
March 29, 2024

# Sommario

Installare il software Tiebreaker . . . . .	1
Flusso di lavoro di installazione di Tiebreaker . . . . .	1
Preparare l'installazione del software Tiebreaker . . . . .	1
Proteggere l'installazione dell'host tiebreaker e del database . . . . .	3
Installare il pacchetto software Tiebreaker . . . . .	6

# Installare il software Tiebreaker

## Flusso di lavoro di installazione di Tiebreaker

Il software Tiebreaker offre funzionalità di monitoraggio per un ambiente di storage in cluster. Inoltre, invia notifiche SNMP in caso di problemi di connettività del nodo e di disastri del sito.

### Questo flusso di lavoro

È possibile utilizzare questo flusso di lavoro per installare o aggiornare il software Tiebreaker.

1

### "Preparare l'installazione del software Tiebreaker"

Prima di installare e configurare il software Tiebreaker, verificare che il sistema soddisfi determinati requisiti.

2

### "Fissare l'installazione"

Per le configurazioni che eseguono MetroCluster Tiebreaker 1.5 e versioni successive, è possibile proteggere e rafforzare il sistema operativo host e il database.

3

### "Installare il pacchetto software Tiebreaker"

Eseguire una nuova installazione o aggiornamento del software Tiebreaker. La procedura di installazione che segui dipende dalla versione di Tiebreaker che desideri installare.

## Preparare l'installazione del software Tiebreaker

Prima di installare e configurare il software Tiebreaker, è necessario verificare che il sistema soddisfi determinati requisiti.

### Requisiti software

È necessario soddisfare i seguenti requisiti software a seconda della versione di Tiebreaker che si sta installando.

Versione Tiebreaker ONTAP	Versioni di ONTAP supportate	Versioni Linux supportate	Requisiti Java/MariaDB
1.6	ONTAP 9.12.1 e versioni successive	Fare riferimento a. <a href="#">"Matrice di supporto del sistema operativo"</a> per ulteriori informazioni.	Nessuno. Le dipendenze vengono fornite in bundle con l'installazione.

1.5	ONTAP 9.13.1 e versioni precedenti	<ul style="list-style-type: none"> <li>Red Hat Enterprise Linux dal 8.1 al 8.7</li> </ul>	Con Red Hat Enterprise Linux da 8,1 a 8,7: <ul style="list-style-type: none"> <li>MariaDB 10.x (utilizzare la versione predefinita installata utilizzando "yum install mariadb-server.x86_64")</li> <li>OpenJDK 17, 18 o 19</li> </ul>
1,4	ONTAP 9.11.1 e versioni precedenti	<ul style="list-style-type: none"> <li>Red Hat Enterprise Linux dal 8.1 al 8.7</li> <li>Red Hat Enterprise Linux da 7 a 7,9</li> <li>CentOS da 7 a 7,9 64 bit</li> </ul>	Con CentOS: <ul style="list-style-type: none"> <li>MariaDB 5.5.52.x/MySQL Server 5.6x</li> <li>4 GB DI RAM</li> <li>Aprire JRE 8</li> </ul> Con Red Hat Enterprise Linux da 8,1 a 8,7: <p>*MariaDB 10.x (usare la versione predefinita installata usando "yum install mariadb-server.x86_64") *JRE 8</p>
1,3	ONTAP 9.10.1 e versioni precedenti	<ul style="list-style-type: none"> <li>Red Hat Enterprise Linux dal 8.1 al 8.7</li> <li>Red Hat Enterprise Linux da 7 a 7,9</li> <li>CentOS da 7 a 7,9 64 bit</li> </ul>	Con CentOS: <ul style="list-style-type: none"> <li>MariaDB 5.5.52.x/MySQL Server 5.6x</li> <li>4 GB DI RAM</li> <li>Aprire JRE 8</li> </ul> Con Red Hat Enterprise Linux da 8,1 a 8,7: <ul style="list-style-type: none"> <li>MariaDB 10.x (utilizzare la versione predefinita installata utilizzando "yum install mariadb-server.x86_64")</li> <li>JRE 8</li> </ul>
1,21Px	ONTAP 9.9.1 e versioni precedenti	<ul style="list-style-type: none"> <li>Red Hat Enterprise Linux dal 8.1 al 8.7</li> <li>Red Hat Enterprise Linux da 7 a 7,9</li> <li>CentOS da 7 a 7,9 64 bit</li> </ul>	Con CentOS: <ul style="list-style-type: none"> <li>MariaDB 5.5.52.x/MySQL Server 5.6x</li> <li>4 GB DI RAM</li> <li>Aprire JRE 8</li> </ul> Con Red Hat Enterprise Linux da 8,1 a 8,7: <ul style="list-style-type: none"> <li>MariaDB 10.x (utilizzare la versione predefinita installata utilizzando "yum install mariadb-server.x86_64")</li> <li>JRE 8</li> </ul>

## Requisiti aggiuntivi

È necessario essere a conoscenza dei seguenti requisiti aggiuntivi:

- Il software Tiebreaker viene installato su un terzo sito, consentendo al software di distinguere tra un errore di collegamento interswitch (ISL) (quando i collegamenti tra siti sono inattivi) e un guasto del sito. Il sistema host deve soddisfare determinati requisiti prima di poter installare o aggiornare il software Tiebreaker sul computer locale per monitorare la configurazione di MetroCluster.
- Per installare il software MetroCluster Tiebreaker e i pacchetti dipendenti, è necessario disporre dei privilegi "root".
- È possibile utilizzare un solo monitor MetroCluster Tiebreaker per ogni configurazione MetroCluster per evitare qualsiasi conflitto con più monitor Tiebreaker.
- Quando si seleziona l'origine NTP (Network Time Protocol) per il software Tiebreaker, è necessario utilizzare un'origine NTP locale. Il software Tiebreaker non deve utilizzare la stessa fonte dei siti MetroCluster monitorati dal software Tiebreaker.
- Capacità del disco: 8 GB
- Firewall:
  - Accesso diretto per la configurazione dei messaggi AutoSupport
  - SSH (porta 22/TCP), HTTPS (porta 443/TCP) e ping (ICMP)

## Proteggere l'installazione dell'host tiebreaker e del database

Per le configurazioni che eseguono MetroCluster Tiebreaker 1.5 e versioni successive, è possibile proteggere e rafforzare il sistema operativo host e il database.

### Proteggere l'host

Le seguenti linee guida mostrano come proteggere l'host in cui è installato il software Tiebreaker.

#### Consigli per la gestione degli utenti

- Limitare l'accesso dell'utente "root".
  - È possibile utilizzare utenti in grado di elevare l'accesso root per installare e amministrare il software Tiebreaker.
  - È possibile utilizzare utenti che non sono in grado di elevare l'accesso root per amministrare il software Tiebreaker.
  - Durante l'installazione, è necessario creare un gruppo denominato "mctbgrp". L'utente root dell'host e l'utente creato durante l'installazione devono essere entrambi membri. Solo i membri di questo gruppo possono amministrare completamente il software di spareggio.



Gli utenti che non sono membri di questo gruppo non possono accedere al software Tiebreaker o alla CLI. È possibile creare utenti aggiuntivi sull'host e renderli membri del gruppo. Questi membri aggiuntivi non possono amministrare completamente il software Tiebreaker. Hanno accesso a ReadOnly e non possono aggiungere, modificare o eliminare i monitor.

- Non eseguire tiebreaker come utente root. Utilizzare un account di servizio dedicato e senza privilegi per eseguire Tiebreaker.
- Modificare la stringa di comunità predefinita nel file "/etc/snmp/snmpd.conf".
- Consentire privilegi di scrittura minimi. L'account di servizio tiebreaker senza privilegi non deve avere accesso per sovrascrivere il binario eseguibile o qualsiasi file di configurazione. Solo le directory e i file per lo storage tiebreaker locale (ad esempio, per lo storage backend integrato) o i log di audit devono essere scrivibili dall'utente di tiebreaker.
- Non consentire utenti anonimi.
  - Impostare AllowTcpForwarding su "no" o utilizzare la direttiva Match per limitare gli utenti anonimi.

## Informazioni correlate

- ["Documentazione del prodotto Red Hat Enterprise Linux 8"](#)
- ["Documentazione del prodotto Red Hat Enterprise Linux 9"](#)

## Raccomandazioni sulla protezione dell'host di base

- Utilizzare la crittografia del disco
  - È possibile attivare la crittografia del disco. Può essere FullDiskEncryption (hardware) o la crittografia fornita dall'host (software) o dall'host SVM.
- Disattiva i servizi inutilizzati che consentono le connessioni in entrata. È possibile disattivare qualsiasi servizio non in uso. Il software Tiebreaker non richiede un servizio per le connessioni in entrata perché tutte le connessioni dall'installazione di Tiebreaker sono in uscita. I servizi che potrebbero essere attivati per impostazione predefinita e che possono essere disattivati sono:
  - Server HTTP/HTTPS
  - Server FTP
  - Telnet, RSH, rlogin
  - Accesso a NFS, CIFS e altri protocolli
  - RDP (RemoteDesktopProtocol), X11 Server, VNC o altri provider di servizi "desktop" remoti.



Per amministrare l'host in remoto, è necessario lasciare attivato l'accesso alla console seriale (se supportato) o almeno un protocollo. Se si disattivano tutti i protocolli, è necessario disporre dell'accesso fisico all'host per l'amministrazione.

- Proteggere l'host utilizzando FIPS

- È possibile installare il sistema operativo host in modalità conforme a FIPS, quindi installare Tiebreaker.



OpenJDK 19 verifica all'avvio se l'host è installato in modalità FIPS. Non devono essere richieste modifiche manuali.

- Se si protegge l'host, è necessario assicurarsi che sia in grado di avviarsi senza l'intervento dell'utente. Se è necessario l'intervento dell'utente, la funzionalità Tiebreaker potrebbe non essere disponibile se l'host si riavvia inaspettatamente. In questo caso, la funzionalità Tiebreaker è disponibile solo dopo l'intervento manuale e quando l'host è completamente avviato.

- Disattiva Cronologia comandi shell.
- Eseguire l'aggiornamento frequentemente. Tiebreaker è sviluppato attivamente e l'aggiornamento

frequente è importante per incorporare correzioni di sicurezza e qualsiasi modifica nelle impostazioni predefinite, come la lunghezza delle chiavi o le suite di crittografia.

- Iscriviti alla mailing list di HashiCorp Announcement per ricevere gli annunci delle nuove release e visita il sito di Tiebreaker CHANGELOG per maggiori dettagli sugli aggiornamenti più recenti delle nuove release.
- Utilizzare le autorizzazioni file corrette. Prima di avviare il software Tiebreaker, assicurarsi sempre che vengano applicate autorizzazioni appropriate ai file, in particolare a quelli contenenti informazioni sensibili.
- L'autenticazione multifattore (MFA) migliora la sicurezza della tua organizzazione richiedendo agli amministratori di identificarsi utilizzando più di un nome utente e una password. Anche se importante, i nomi utente e le password sono vulnerabili agli attacchi di forza bruta e possono essere rubati da terze parti.
  - Red Hat Enterprise Linux 8 fornisce MFA che richiede agli utenti di fornire più di un'informazione per eseguire correttamente l'autenticazione su un account o un host Linux. Le informazioni aggiuntive potrebbero essere una password monouso inviata al telefono cellulare tramite SMS o credenziali da un'applicazione come Google Authenticator, Twilio Authy o FreeOTP.

#### Informazioni correlate

- ["Documentazione del prodotto Red Hat Enterprise Linux 8"](#)
- ["Documentazione del prodotto Red Hat Enterprise Linux 9"](#)

## Proteggere l'installazione del database

Le seguenti linee guida mostrano come proteggere e rafforzare l'installazione del database MariaDB 10.x.

- Limitare l'accesso dell'utente "root".
  - Tiebreaker utilizza un account dedicato. L'account e le tabelle per la memorizzazione dei dati (di configurazione) vengono creati durante l'installazione di Tiebreaker. L'unica volta che è necessario un accesso elevato al database è durante l'installazione.
- Durante l'installazione sono necessari i seguenti privilegi e accesso:
  - La possibilità di creare un database e tabelle
  - La possibilità di creare opzioni globali
  - La possibilità di creare un utente del database e di impostare la password
  - Possibilità di associare l'utente del database al database e alle tabelle e assegnare i diritti di accesso



L'account utente specificato durante l'installazione di Tiebreaker deve disporre di tutti questi privilegi. L'utilizzo di più account utente per le diverse attività non è supportato.

- Utilizzare la crittografia del database
  - È supportata la crittografia dei dati inattivi. ["Scopri di più sulla crittografia dei dati a riposo"](#)
  - I dati in volo non sono critografati. I dati in volo utilizzano una connessione di file locale "SOCKS".
  - Conformità FIPS per MariaDB: Non è necessario attivare la conformità FIPS nel database. È sufficiente installare l'host in modalità conforme a FIPS.

["Ulteriori informazioni su MySQL Enterprise transparent Data Encryption \(TDE\)"](#)



Le impostazioni di crittografia devono essere attivate prima dell'installazione del software Tiebreaker.

## Informazioni correlate

- Gestione degli utenti del database

["Controllo degli accessi e gestione degli account"](#)

- Proteggere il database

["Rendere MySQL sicuro dagli attacchi"](#)

["Protezione di MariaDB"](#)

- Installazione sicura del vault

["Protezione avanzata della produzione"](#)

# Installare il pacchetto software Tiebreaker

## Scegliere la procedura di installazione

La procedura di installazione di Tiebreaker che segue dipende dalla versione di Tiebreaker che si sta installando.

Versione Tiebreaker	Vai a...
Tiebreaker 1,6	<a href="#">"Installare il Tiebreaker 1,6"</a>
Tiebreaker 1,5 o 1,4	<a href="#">"Installare il Tiebreaker 1,5 o 1,4"</a>

## Installare il Tiebreaker 1,6

Eseguire una nuova installazione o aggiornare il software Tiebreaker.

### A proposito di questa attività

- Il sistema storage deve eseguire ONTAP 9.12.1 o versione successiva.
- È possibile installare MetroCluster Tiebreaker come utente non root con privilegi amministrativi sufficienti per eseguire l'installazione di tiebreaker, creare tabelle e utenti e impostare la password utente.

### Fasi

1. Scaricare il software MetroCluster Tiebreaker 1,6.

["Sito di supporto NetApp"](#)

2. Accedere all'host come utente root.

3. Se si sta eseguendo un aggiornamento, verificare la versione di tiebreaker in esecuzione:

L'esempio seguente mostra il tiebreaker 1,5.

```
[root@mcctb ~] # netapp-metrocluster-tiebreaker-software-cli  
NetApp MetroCluster Tiebreaker :> version show  
NetApp MetroCluster Tiebreaker 1.5: Sun Mar 13 09:59:02 IST 2022  
NetApp MetroCluster Tiebreaker :> exit
```

4. Installare o aggiornare il software Tiebreaker.

## Installare il Tiebreaker 1,6

Per una nuova installazione di Tiebreaker 1,6, procedere come segue.

### Fasi

- Eseguire il seguente comando nella [root@mcctb ~] # prompt per iniziare l'installazione:

```
sh MetroClusterTiebreakerInstall-1.6
```

Il sistema visualizza i seguenti output per una corretta installazione:

```
Extracting the MetroCluster Tiebreaker installation/upgrade
archive
Install digest hash is Ok
Performing the MetroCluster Tiebreaker code signature check
Install code signature is Ok
Enter unix user account to use for the installation:
mcctbadminuser
Unix user account "mcctbadminuser" doesn't exist. Do you wish to
create "mcctbadminuser" user account? [Y/N]: y
useradd: warning: the home directory already exists.
Not copying any file from skel directory into it.
Creating mailbox file: File exists
Unix account "mcctbadminuser" created.
Changing password for user mcctbadminuser.
New password:
Retype new password:
passwd: all authentication tokens updated successfully.
MetroCluster Tiebreaker requires unix user account
"mcctbadminuser" to be added to the group "mcctbgrp" for admin
access.
Do you wish to add ? [Y/N]: y
Unix user account "mcctbadminuser" added to "mcctbgrp".
Do you wish to generate your own public-private key pair for
encrypting audit log? [Y/N]: y
Generating public-private key pair...
Configuring Vault...
Starting vault server...
==> Vault server configuration:

    Api Address: <api_address>
                  Cgo: disabled
    Cluster Address: <cluster_address>
Environment Variables: BASH_FUNC_which%%,
DBUS_SESSION_BUS_ADDRESS, GODEBUG, HISTCONTROL, HISTSIZE, HOME,
```

```
HOSTNAME, HOST_ACCOUNT, LANG, LESSOPEN, LOGNAME, LS_COLORS, MAIL,
PATH, PWD, SHELL, SHLVL, SSH_CLIENT, SSH_CONNECTION, SSH_TTY,
STAF_TEMP_DIR, TERM, USER, VAULT_ADDR, VAULT_TOKEN,
XDG_RUNTIME_DIR, XDG_SESSION_ID, _, vault_addr, which_declare
        Go Version: go1.20.5
        Listener 1: tcp (addr: "0.0.0.0:8200", cluster
address: "0.0.0.0:8201", max_request_duration: "1m30s",
max_request_size: "33554432", tls: "enabled")
        Log Level:
        Mlock: supported: true, enabled: true
        Recovery Mode: false
        Storage: file
        Version: Vault v1.14.0, built 2023-06-
19T11:40:23Z
        Version Sha:
13a649f860186dffe3f3a4459814d87191efc321

==> Vault server started! Log data will stream in below:

2023-11-23T15:14:28.532+0530 [INFO] proxy environment:
http_proxy="" https_proxy="" no_proxy=""
2023-11-23T15:14:28.577+0530 [INFO] core: Initializing version
history cache for core
2023-11-23T15:14:38.552+0530 [INFO] core: security barrier not
initialized
2023-11-23T15:14:38.552+0530 [INFO] core: seal configuration
missing, not initialized
2023-11-23T15:14:38.554+0530 [INFO] core: security barrier not
initialized
2023-11-23T15:14:38.555+0530 [INFO] core: security barrier
initialized: stored=1 shares=5 threshold=3
2023-11-23T15:14:38.556+0530 [INFO] core: post-unseal setup
starting
2023-11-23T15:14:38.577+0530 [INFO] core: loaded wrapping token
key
2023-11-23T15:14:38.577+0530 [INFO] core: successfully setup
plugin catalog: plugin-directory=""
2023-11-23T15:14:38.577+0530 [INFO] core: no mounts; adding
default mount table
2023-11-23T15:14:38.578+0530 [INFO] core: successfully mounted:
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/
namespace="ID: root. Path: "
2023-11-23T15:14:38.578+0530 [INFO] core: successfully mounted:
type=system version="v1.14.0+builtin.vault" path=sys/
namespace="ID: root. Path: "
2023-11-23T15:14:38.578+0530 [INFO] core: successfully mounted:
```

```
type=identity version="v1.14.0+builtin.vault" path=identity/
namespace="ID: root. Path: "
2023-11-23T15:14:38.581+0530 [INFO] core: successfully mounted:
type=token version="v1.14.0+builtin.vault" path=token/
namespace="ID: root. Path: "
2023-11-23T15:14:38.581+0530 [INFO] rollback: starting rollback
manager
2023-11-23T15:14:38.581+0530 [INFO] core: restoring leases
2023-11-23T15:14:38.582+0530 [INFO] expiration: lease restore
complete
2023-11-23T15:14:38.582+0530 [INFO] identity: entities restored
2023-11-23T15:14:38.582+0530 [INFO] identity: groups restored
2023-11-23T15:14:38.583+0530 [INFO] core: Recorded vault
version: vault version=1.14.0 upgrade time="2023-11-23
09:44:38.582881162 +0000 UTC" build date=2023-06-19T11:40:23Z
2023-11-23T15:14:38.583+0530 [INFO] core: usage gauge collection
is disabled
2023-11-23T15:14:38.998+0530 [INFO] core: post-unseal setup
complete
2023-11-23T15:14:38.999+0530 [INFO] core: root token generated
2023-11-23T15:14:38.999+0530 [INFO] core: pre-seal teardown
starting
2023-11-23T15:14:38.999+0530 [INFO] rollback: stopping rollback
manager
2023-11-23T15:14:38.999+0530 [INFO] core: pre-seal teardown
complete
2023-11-23T15:14:39.311+0530 [INFO] core.cluster-listener.tcp:
starting listener: listener_address=0.0.0.0:8201
2023-11-23T15:14:39.311+0530 [INFO] core.cluster-listener:
serving cluster requests: cluster_listen_address=[::]:8201
2023-11-23T15:14:39.312+0530 [INFO] core: post-unseal setup
starting
2023-11-23T15:14:39.312+0530 [INFO] core: loaded wrapping token
key
2023-11-23T15:14:39.312+0530 [INFO] core: successfully setup
plugin catalog: plugin-directory=""
2023-11-23T15:14:39.313+0530 [INFO] core: successfully mounted:
type=system version="v1.14.0+builtin.vault" path=sys/
namespace="ID: root. Path: "
2023-11-23T15:14:39.313+0530 [INFO] core: successfully mounted:
type=identity version="v1.14.0+builtin.vault" path=identity/
namespace="ID: root. Path: "
2023-11-23T15:14:39.313+0530 [INFO] core: successfully mounted:
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/
namespace="ID: root. Path: "
2023-11-23T15:14:39.314+0530 [INFO] core: successfully mounted:
```

```
type=token version="v1.14.0+builtin.vault" path=token/
namespace="ID: root. Path: "
2023-11-23T15:14:39.314+0530 [INFO] rollback: starting rollback
manager
2023-11-23T15:14:39.314+0530 [INFO] core: restoring leases
2023-11-23T15:14:39.314+0530 [INFO] identity: entities restored
2023-11-23T15:14:39.314+0530 [INFO] expiration: lease restore
complete
2023-11-23T15:14:39.314+0530 [INFO] identity: groups restored
2023-11-23T15:14:39.315+0530 [INFO] core: usage gauge collection
is disabled
2023-11-23T15:14:39.316+0530 [INFO] core: post-unseal setup
complete
2023-11-23T15:14:39.316+0530 [INFO] core: vault is unsealed
Success! Uploaded policy: mcctb-policy
2023-11-23T15:14:39.795+0530 [INFO] core: enabled credential
backend: path=approle/ type=approle version=""
Success! Enabled approle auth method at: approle/
2023-11-23T15:14:39.885+0530 [INFO] core: successful mount:
namespace="" path=mcctb/ type=kv version=""
Success! Enabled the kv secrets engine at: mcctb/
Success! Data written to: auth/approle/role/mcctb-app
Installing the NetApp-MetroCluster-Tiebreaker-Software-1.6-
1.x86_64.rpm
Preparing... #
#####
# [100%]
```

Updating / installing...

```
1:NetApp-MetroCluster-Tiebreaker-So#
#####
# [100%]
Performing file integrity check
etc/cron.weekly/metrocluster-tiebreaker-support is Ok
etc/cron.weekly/metrocluster-tiebreaker-support-cov is Ok
etc/init.d/netapp-metrocluster-tiebreaker-software is Ok
etc/init.d/netapp-metrocluster-tiebreaker-software-cov is Ok
etc/logrotate.d/mcctb is Ok
opt/netapp/mcctb/lib/common/activation-1.1.1.jar is Ok
opt/netapp/mcctb/lib/common/aopalliance.jar is Ok
opt/netapp/mcctb/lib/common/args4j.jar is Ok
opt/netapp/mcctb/lib/common/aspectjrt.jar is Ok
opt/netapp/mcctb/lib/common/aspectjweaver.jar is Ok
opt/netapp/mcctb/lib/common/asup.jar is Ok
opt/netapp/mcctb/lib/common/bcpkix-jdk15on.jar is Ok
opt/netapp/mcctb/lib/common/bcprov-jdk15on.jar is Ok
opt/netapp/mcctb/lib/common/bcprov-jdk18on.jar is Ok
```

opt/netapp/mcctb/lib/common/bctls-fips-1.0.13.jar is Ok  
opt/netapp/mcctb/lib/common/bctls-jdk18on.jar is Ok  
opt/netapp/mcctb/lib/common/bcutil-jdk18on.jar is Ok  
opt/netapp/mcctb/lib/common/cglib.jar is Ok  
opt/netapp/mcctb/lib/common/commons-codec.jar is Ok  
opt/netapp/mcctb/lib/common/commons-collections4.jar is Ok  
opt/netapp/mcctb/lib/common/commons-compress.jar is Ok  
opt/netapp/mcctb/lib/common/commons-daemon.jar is Ok  
opt/netapp/mcctb/lib/common/commons-daemon.src.jar is Ok  
opt/netapp/mcctb/lib/common/commons-dbcp2.jar is Ok  
opt/netapp/mcctb/lib/common/commons-io.jar is Ok  
opt/netapp/mcctb/lib/common/commons-lang3.jar is Ok  
opt/netapp/mcctb/lib/common/commons-logging.jar is Ok  
opt/netapp/mcctb/lib/common/commons-pool2.jar is Ok  
opt/netapp/mcctb/lib/common/guava.jar is Ok  
opt/netapp/mcctb/lib/common/httpclient.jar is Ok  
opt/netapp/mcctb/lib/common/httpcore.jar is Ok  
opt/netapp/mcctb/lib/common/jakarta.activation.jar is Ok  
opt/netapp/mcctb/lib/common/jakarta.xml.bind-api.jar is Ok  
opt/netapp/mcctb/lib/common/java-xmlbuilder.jar is Ok  
opt/netapp/mcctb/lib/common/javax.inject.jar is Ok  
opt/netapp/mcctb/lib/common/jaxb-api-2.3.1.jar is Ok  
opt/netapp/mcctb/lib/common/jaxb-core.jar is Ok  
opt/netapp/mcctb/lib/common/jaxb-impl.jar is Ok  
opt/netapp/mcctb/lib/common/jline.jar is Ok  
opt/netapp/mcctb/lib/common/jna.jar is Ok  
opt/netapp/mcctb/lib/common/joda-time.jar is Ok  
opt/netapp/mcctb/lib/common/jsch.jar is Ok  
opt/netapp/mcctb/lib/common/json.jar is Ok  
opt/netapp/mcctb/lib/common/jsvc.zip is Ok  
opt/netapp/mcctb/lib/common/junixsocket-common.jar is Ok  
opt/netapp/mcctb/lib/common/junixsocket-native-common.jar is Ok  
opt/netapp/mcctb/lib/common/logback-classic.jar is Ok  
opt/netapp/mcctb/lib/common/logback-core.jar is Ok  
opt/netapp/mcctb/lib/common/mail-1.6.2.jar is Ok  
opt/netapp/mcctb/lib/common/mariadb-java-client.jar is Ok  
opt/netapp/mcctb/lib/common/mcctb-mib.jar is Ok  
opt/netapp/mcctb/lib/common/mcctb.jar is Ok  
opt/netapp/mcctb/lib/common/mockito-core.jar is Ok  
opt/netapp/mcctb/lib/common/slf4j-api.jar is Ok  
opt/netapp/mcctb/lib/common/snmp4j.jar is Ok  
opt/netapp/mcctb/lib/common/spring-aop.jar is Ok  
opt/netapp/mcctb/lib/common/spring-beans.jar is Ok  
opt/netapp/mcctb/lib/common/spring-context-support.jar is Ok  
opt/netapp/mcctb/lib/common/spring-context.jar is Ok  
opt/netapp/mcctb/lib/common/spring-core.jar is Ok

```
opt/netapp/mcctb/lib/common/spring-expression.jar is Ok
opt/netapp/mcctb/lib/common/spring-web.jar is Ok
opt/netapp/mcctb/lib/common/vault-java-driver.jar is Ok
opt/netapp/mcctb/lib/common/xz.jar is Ok
opt/netapp/mcctb/lib/org.jacoco.agent-0.8.8-runtime.jar is Ok
opt/netapp/mcctb/bin/mcctb-asup-invoke is Ok
opt/netapp/mcctb/bin/mcctb_postrotate is Ok
opt/netapp/mcctb/bin/netapp-metrocluster-tiebreaker-software-cli
is Ok
/
```

```
Synchronizing state of netapp-metrocluster-tiebreaker-
software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-
metrocluster-tiebreaker-software
Created symlink /etc/systemd/system/multi-
user.target.wants/netapp-metrocluster-tiebreaker-software.service
→ /etc/systemd/system/netapp-metrocluster-tiebreaker-
software.service.
```

```
Attempting to start NetApp MetroCluster Tiebreaker software
services
```

```
Started NetApp MetroCluster Tiebreaker software services
Successfully installed NetApp MetroCluster Tiebreaker software
version 1.6.
```

**IMPORTANT:** Please ensure you store the following private key used  
to decrypt audit logs securely in a safe location.

Consider the following recommendations:

- Save it to an encrypted storage device or file.
- Use strong, unique passwords to protect the storage device or file.
- Restrict access to the private key file to authorized individuals only.

The Private key is:

```
-----BEGIN PRIVATE KEY-----
```

```
<private_key_id>
```

```
-----END PRIVATE KEY-----
```

## Aggiornamento da tiebreaker 1,5 a 1,6

Per aggiornare la versione software di Tiebreaker 1,5 a Tiebreaker 1,6, procedere come segue.

## Fasi

- a. Eseguire il seguente comando nella [root@mcctb ~] # richiesta di aggiornamento del software:

```
sh MetroClusterTiebreakerInstall-1.6
```

Il sistema visualizza il seguente output per un aggiornamento riuscito:

```
Extracting the MetroCluster Tiebreaker installation/upgrade archive
Install digest hash is Ok
Performing the MetroCluster Tiebreaker code signature check
Install code signature is Ok

Enter database user name : root

Please enter database password for root
Enter password:

Password updated successfully in the database.

Do you wish to generate your own public-private key pair for
encrypting audit log? [Y/N]: y
Generating public-private key pair...
Configuring Vault...
==> Vault shutdown triggered
2023-07-21T00:30:22.335+0530 [INFO] core: marked as sealed
2023-07-21T00:30:22.335+0530 [INFO] core: pre-seal teardown
starting
2023-07-21T00:30:22.335+0530 [INFO] rollback: stopping rollback
manager
2023-07-21T00:30:22.335+0530 [INFO] core: pre-seal teardown
complete
2023-07-21T00:30:22.335+0530 [INFO] core: stopping cluster
listeners
2023-07-21T00:30:22.335+0530 [INFO] core.cluster-listener:
forwarding rpc listeners stopped
2023-07-21T00:30:22.375+0530 [INFO] core.cluster-listener: rpc
listeners successfully shut down
2023-07-21T00:30:22.375+0530 [INFO] core: cluster listeners
successfully shut down
2023-07-21T00:30:22.376+0530 [INFO] core: vault is sealed
Starting vault server...
```

```
--> Vault server configuration:
```

```
    Api Address: <api_address>
        Cgo: disabled
    Cluster Address: <cluster_address>
    Environment Variables: BASH_FUNC_which%%,
DBUS_SESSION_BUS_ADDRESS, GODEBUG, HISTCONTROL, HISTSIZE, HOME,
HOSTNAME, HOST_ACCOUNT, LANG, LESSOPEN, LOGNAME, LS_COLORS, MAIL,
PATH, PWD, SHELL, SHLVL, SSH_CLIENT, SSH_CONNECTION, SSH_TTY,
STAF_TEMP_DIR, TERM, USER, VAULT_ADDR, VAULT_TOKEN,
XDG_RUNTIME_DIR, XDG_SESSION_ID, _, vault_addr, which_declare
    Go Version: go1.20.5
    Listener 1: tcp (addr: "0.0.0.0:8200", cluster
address: "0.0.0.0:8201", max_request_duration: "1m30s",
max_request_size: "33554432", tls: "enabled")
    Log Level:
        Mlock: supported: true, enabled: true
    Recovery Mode: false
        Storage: file
    Version: Vault v1.14.0, built 2023-06-
19T11:40:23Z
    Version Sha:
13a649f860186dff3e3f3a4459814d87191efc321
```

```
--> Vault server started! Log data will stream in below:
```

```
2023-07-21T00:30:33.065+0530 [INFO] proxy environment:
http_proxy="" https_proxy="" no_proxy=""
2023-07-21T00:30:33.098+0530 [INFO] core: Initializing version
history cache for core
2023-07-21T00:30:43.092+0530 [INFO] core: security barrier not
initialized
2023-07-21T00:30:43.092+0530 [INFO] core: seal configuration
missing, not initialized
2023-07-21T00:30:43.094+0530 [INFO] core: security barrier not
initialized
2023-07-21T00:30:43.096+0530 [INFO] core: security barrier
initialized: stored=1 shares=5 threshold=3
2023-07-21T00:30:43.098+0530 [INFO] core: post-unseal setup
starting
2023-07-21T00:30:43.124+0530 [INFO] core: loaded wrapping token
key
2023-07-21T00:30:43.124+0530 [INFO] core: successfully setup
plugin catalog: plugin-directory=""
2023-07-21T00:30:43.124+0530 [INFO] core: no mounts; adding
default mount table
```

```
2023-07-21T00:30:43.125+0530 [INFO] core: successfully mounted:  
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/  
namespace="ID: root. Path: "  
2023-07-21T00:30:43.126+0530 [INFO] core: successfully mounted:  
type=system version="v1.14.0+builtin.vault" path=sys/  
namespace="ID: root. Path: "  
2023-07-21T00:30:43.126+0530 [INFO] core: successfully mounted:  
type=identity version="v1.14.0+builtin.vault" path=identity/  
namespace="ID: root. Path: "  
2023-07-21T00:30:43.129+0530 [INFO] core: successfully mounted:  
type=token version="v1.14.0+builtin.vault" path=token/  
namespace="ID: root. Path: "  
2023-07-21T00:30:43.130+0530 [INFO] rollback: starting rollback  
manager  
2023-07-21T00:30:43.130+0530 [INFO] core: restoring leases  
2023-07-21T00:30:43.130+0530 [INFO] identity: entities restored  
2023-07-21T00:30:43.130+0530 [INFO] identity: groups restored  
2023-07-21T00:30:43.131+0530 [INFO] core: usage gauge collection  
is disabled  
2023-07-21T00:30:43.131+0530 [INFO] expiration: lease restore  
complete  
2023-07-21T00:30:43.131+0530 [INFO] core: Recorded vault  
version: vault version=1.14.0 upgrade time="2023-07-20  
19:00:43.131158543 +0000 UTC" build date=2023-06-19T11:40:23Z  
2023-07-21T00:30:43.371+0530 [INFO] core: post-unseal setup  
complete  
2023-07-21T00:30:43.371+0530 [INFO] core: root token generated  
2023-07-21T00:30:43.371+0530 [INFO] core: pre-seal teardown  
starting  
2023-07-21T00:30:43.371+0530 [INFO] rollback: stopping rollback  
manager  
2023-07-21T00:30:43.372+0530 [INFO] core: pre-seal teardown  
complete  
2023-07-21T00:30:43.694+0530 [INFO] core.cluster-listener.tcp:  
starting listener: listener_address=0.0.0.0:8201  
2023-07-21T00:30:43.695+0530 [INFO] core.cluster-listener:  
serving cluster requests: cluster_listen_address=[::]:8201  
2023-07-21T00:30:43.695+0530 [INFO] core: post-unseal setup  
starting  
2023-07-21T00:30:43.696+0530 [INFO] core: loaded wrapping token  
key  
2023-07-21T00:30:43.696+0530 [INFO] core: successfully setup  
plugin catalog: plugin-directory=""  
2023-07-21T00:30:43.697+0530 [INFO] core: successfully mounted:  
type=system version="v1.14.0+builtin.vault" path=sys/  
namespace="ID: root. Path: "
```

```
2023-07-21T00:30:43.698+0530 [INFO] core: successfully mounted:  
type=identity version="v1.14.0+builtin.vault" path=identity/  
namespace="ID: root. Path: "  
2023-07-21T00:30:43.698+0530 [INFO] core: successfully mounted:  
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/  
namespace="ID: root. Path: "  
2023-07-21T00:30:43.701+0530 [INFO] core: successfully mounted:  
type=token version="v1.14.0+builtin.vault" path=token/  
namespace="ID: root. Path: "  
2023-07-21T00:30:43.701+0530 [INFO] rollback: starting rollback  
manager  
2023-07-21T00:30:43.702+0530 [INFO] core: restoring leases  
2023-07-21T00:30:43.702+0530 [INFO] identity: entities restored  
2023-07-21T00:30:43.702+0530 [INFO] expiration: lease restore  
complete  
2023-07-21T00:30:43.702+0530 [INFO] identity: groups restored  
2023-07-21T00:30:43.702+0530 [INFO] core: usage gauge collection  
is disabled  
2023-07-21T00:30:43.703+0530 [INFO] core: post-unseal setup  
complete  
2023-07-21T00:30:43.703+0530 [INFO] core: vault is unsealed  
Success! Uploaded policy: mcctb-policy  
2023-07-21T00:30:44.226+0530 [INFO] core: enabled credential  
backend: path=approle/ type=approle version=""  
Success! Enabled approle auth method at: approle/  
2023-07-21T00:30:44.315+0530 [INFO] core: successful mount:  
namespace="" path=mcctb/ type=kv version=""  
Success! Enabled the kv secrets engine at: mcctb/  
Success! Data written to: auth/approle/role/mcctb-app  
Upgrading to NetApp-MetroCluster-Tiebreaker-Software-1.6-  
1.x86_64.rpm  
Preparing...  
#####
[100%]  
Updating / installing...  
1:NetApp-MetroCluster-Tiebreaker-  
So#####
[50%]  
Performing file integrity check  
etc/cron.weekly/metrocluster-tiebreaker-support is Ok  
etc/cron.weekly/metrocluster-tiebreaker-support-cov is Ok  
etc/init.d/netapp-metrocluster-tiebreaker-software is Ok  
etc/init.d/netapp-metrocluster-tiebreaker-software-cov is Ok  
etc/logrotate.d/mcctb is Ok  
opt/netapp/mcctb/lib/common/activation-1.1.1.jar is Ok  
opt/netapp/mcctb/lib/common/aopalliance.jar is Ok  
opt/netapp/mcctb/lib/common/args4j.jar is Ok  
opt/netapp/mcctb/lib/common/aspectjrt.jar is Ok
```

opt/netapp/mcctb/lib/common/aspectjweaver.jar is Ok  
opt/netapp/mcctb/lib/common/asup.jar is Ok  
opt/netapp/mcctb/lib/common/bcpkix-jdk15on.jar is Ok  
opt/netapp/mcctb/lib/common/bcprov-jdk15on.jar is Ok  
opt/netapp/mcctb/lib/common/bcprov-jdk18on.jar is Ok  
opt/netapp/mcctb/lib/common/bctls-fips-1.0.13.jar is Ok  
opt/netapp/mcctb/lib/common/bctls-jdk18on.jar is Ok  
opt/netapp/mcctb/lib/common/bcutil-jdk18on.jar is Ok  
opt/netapp/mcctb/lib/common/cglib.jar is Ok  
opt/netapp/mcctb/lib/common/commons-codec.jar is Ok  
opt/netapp/mcctb/lib/common/commons-collections4.jar is Ok  
opt/netapp/mcctb/lib/common/commons-compress.jar is Ok  
opt/netapp/mcctb/lib/common/commons-daemon.jar is Ok  
opt/netapp/mcctb/lib/common/commons-daemon.src.jar is Ok  
opt/netapp/mcctb/lib/common/commons-dbcp2.jar is Ok  
opt/netapp/mcctb/lib/common/commons-io.jar is Ok  
opt/netapp/mcctb/lib/common/commons-lang3.jar is Ok  
opt/netapp/mcctb/lib/common/commons-logging.jar is Ok  
opt/netapp/mcctb/lib/common/commons-pool2.jar is Ok  
opt/netapp/mcctb/lib/common/guava.jar is Ok  
opt/netapp/mcctb/lib/common/httpclient.jar is Ok  
opt/netapp/mcctb/lib/common/httpcore.jar is Ok  
opt/netapp/mcctb/lib/common/jakarta.activation.jar is Ok  
opt/netapp/mcctb/lib/common/jakarta.xml.bind-api.jar is Ok  
opt/netapp/mcctb/lib/common/java-xmlbuilder.jar is Ok  
opt/netapp/mcctb/lib/common/javax.inject.jar is Ok  
opt/netapp/mcctb/lib/common/jaxb-api-2.3.1.jar is Ok  
opt/netapp/mcctb/lib/common/jaxb-core.jar is Ok  
opt/netapp/mcctb/lib/common/jaxb-impl.jar is Ok  
opt/netapp/mcctb/lib/common/jline.jar is Ok  
opt/netapp/mcctb/lib/common/jna.jar is Ok  
opt/netapp/mcctb/lib/common/joda-time.jar is Ok  
opt/netapp/mcctb/lib/common/jsch.jar is Ok  
opt/netapp/mcctb/lib/common/json.jar is Ok  
opt/netapp/mcctb/lib/common/jsvc.zip is Ok  
opt/netapp/mcctb/lib/common/junixsocket-common.jar is Ok  
opt/netapp/mcctb/lib/common/junixsocket-native-common.jar is Ok  
opt/netapp/mcctb/lib/common/logback-classic.jar is Ok  
opt/netapp/mcctb/lib/common/logback-core.jar is Ok  
opt/netapp/mcctb/lib/common/mail-1.6.2.jar is Ok  
opt/netapp/mcctb/lib/common/mariadb-java-client.jar is Ok  
opt/netapp/mcctb/lib/common/mcctb-mib.jar is Ok  
opt/netapp/mcctb/lib/common/mcctb.jar is Ok  
opt/netapp/mcctb/lib/common/mockito-core.jar is Ok  
opt/netapp/mcctb/lib/common/slf4j-api.jar is Ok  
opt/netapp/mcctb/lib/common/snmp4j.jar is Ok

```
opt/netapp/mcctb/lib/common/spring-aop.jar is Ok
opt/netapp/mcctb/lib/common/spring-beans.jar is Ok
opt/netapp/mcctb/lib/common/spring-context-support.jar is Ok
opt/netapp/mcctb/lib/common/spring-context.jar is Ok
opt/netapp/mcctb/lib/common/spring-core.jar is Ok
opt/netapp/mcctb/lib/common/spring-expression.jar is Ok
opt/netapp/mcctb/lib/common/spring-web.jar is Ok
opt/netapp/mcctb/lib/common/vault-java-driver.jar is Ok
opt/netapp/mcctb/lib/common/xz.jar is Ok
opt/netapp/mcctb/bin/mcctb_postrotate is Ok
opt/netapp/mcctb/bin/netapp-metrocluster-tiebreaker-software-cli
is Ok
/
Synchronizing state of netapp-metrocluster-tiebreaker-
software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-
metrocluster-tiebreaker-software

Attempting to start NetApp MetroCluster Tiebreaker software
services
Started NetApp MetroCluster Tiebreaker software services
Successfully upgraded NetApp MetroCluster Tiebreaker software to
version 1.6.
Cleaning up / removing...
2:NetApp-MetroCluster-Tiebreaker-
So#####
[100%]
```

IMPORTANT: Please ensure you store the following private key used to decrypt audit logs securely in a safe location.  
Consider the following recommendations:

- Save it to an encrypted storage device or file.
- Use strong, unique passwords to protect the storage device or file.
- Restrict access to the private key file to authorized individuals only.

The Private key is:

```
-----BEGIN PRIVATE KEY-----
<private_key_id>
-----END PRIVATE KEY-----
```

## Aggiornamento da tiebreaker 1,4 a 1,6

Per aggiornare la versione software di Tiebreaker 1,4 a Tiebreaker 1,6, procedere come segue.

### Fasi

- a. Eseguire il seguente comando nella [root@mcctb ~] # richiesta di aggiornamento del software:

```
sh MetroClusterTiebreakerInstall-1.6
```

Il sistema visualizza il seguente output per un aggiornamento riuscito:

```
Extracting the MetroCluster Tiebreaker installation/upgrade archive
Install digest hash is Ok
Performing the MetroCluster Tiebreaker code signature check
Install code signature is Ok
Enter unix user account to use for the installation:
mcctbuseradmin1
Unix user account "mcctbuseradmin1" doesn't exist. Do you wish to
create "mcctbuseradmin1" user account? [Y/N]: y
Unix account "mcctbuseradmin1" created.
Changing password for user mcctbuseradmin1.
New password:
Retype new password:
passwd: all authentication tokens updated successfully.

Enter database user name : root

Please enter database password for root
Enter password:

Password updated successfully in the database.

MetroCluster Tiebreaker requires unix user account
"mcctbuseradmin1" to be added to the group "mcctbgrp" for admin
access.
Do you wish to add ? [Y/N]: y
Unix user account "mcctbuseradmin1" added to "mcctbgrp".
Do you wish to generate your own public-private key pair for
encrypting audit log? [Y/N]: y
Generating public-private key pair...
Configuring Vault...
Starting vault server...
==> Vault server configuration:

          Api Address: <api_address>
```

```

        Cgo: disabled
        Cluster Address: <cluster_address>
        Environment Variables: BASH_FUNC_which%%,
DBUS_SESSION_BUS_ADDRESS, GODEBUG, HISTCONTROL, HISTSIZE, HOME,
HOSTNAME, HOST_ACCOUNT, LANG, LESSOPEN, LOGNAME, LS_COLORS, MAIL,
PATH, PWD, SHELL, SHLVL, SSH_CLIENT, SSH_CONNECTION, SSH_TTY,
STAF_TEMP_DIR, TERM, USER, VAULT_ADDR, VAULT_TOKEN,
XDG_RUNTIME_DIR, XDG_SESSION_ID, _, vault_addr, which_declare
        Go Version: go1.20.5
        Listener 1: tcp (addr: "0.0.0.0:8200", cluster
address: "0.0.0.0:8201", max_request_duration: "1m30s",
max_request_size: "33554432", tls: "enabled")
        Log Level:
            Mlock: supported: true, enabled: true
        Recovery Mode: false
            Storage: file
        Version: Vault v1.14.0, built 2023-06-
19T11:40:23Z
        Version Sha:
13a649f860186dff3f3a4459814d87191efc321

==> Vault server started! Log data will stream in below:

2023-11-23T15:58:10.400+0530 [INFO] proxy environment:
http_proxy="" https_proxy="" no_proxy=""
2023-11-23T15:58:10.432+0530 [INFO] core: Initializing version
history cache for core
2023-11-23T15:58:20.422+0530 [INFO] core: security barrier not
initialized
2023-11-23T15:58:20.422+0530 [INFO] core: seal configuration
missing, not initialized
2023-11-23T15:58:20.424+0530 [INFO] core: security barrier not
initialized
2023-11-23T15:58:20.425+0530 [INFO] core: security barrier
initialized: stored=1 shares=5 threshold=3
2023-11-23T15:58:20.427+0530 [INFO] core: post-unseal setup
starting
2023-11-23T15:58:20.448+0530 [INFO] core: loaded wrapping token
key
2023-11-23T15:58:20.448+0530 [INFO] core: successfully setup
plugin catalog: plugin-directory=""
2023-11-23T15:58:20.448+0530 [INFO] core: no mounts; adding
default mount table
2023-11-23T15:58:20.449+0530 [INFO] core: successfully mounted:
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/
namespace="ID: root. Path: "

```

```
2023-11-23T15:58:20.449+0530 [INFO] core: successfully mounted:  
type=system version="v1.14.0+builtin.vault" path=sys/  
namespace="ID: root. Path: "  
2023-11-23T15:58:20.449+0530 [INFO] core: successfully mounted:  
type=identity version="v1.14.0+builtin.vault" path=identity/  
namespace="ID: root. Path: "  
2023-11-23T15:58:20.451+0530 [INFO] core: successfully mounted:  
type=token version="v1.14.0+builtin.vault" path=token/  
namespace="ID: root. Path: "  
2023-11-23T15:58:20.452+0530 [INFO] rollback: starting rollback  
manager  
2023-11-23T15:58:20.452+0530 [INFO] core: restoring leases  
2023-11-23T15:58:20.453+0530 [INFO] identity: entities restored  
2023-11-23T15:58:20.453+0530 [INFO] identity: groups restored  
2023-11-23T15:58:20.453+0530 [INFO] expiration: lease restore  
complete  
2023-11-23T15:58:20.453+0530 [INFO] core: usage gauge collection  
is disabled  
2023-11-23T15:58:20.453+0530 [INFO] core: Recorded vault  
version: vault version=1.14.0 upgrade time="2023-11-23  
10:28:20.453481904 +0000 UTC" build date=2023-06-19T11:40:23Z  
2023-11-23T15:58:20.818+0530 [INFO] core: post-unseal setup  
complete  
2023-11-23T15:58:20.819+0530 [INFO] core: root token generated  
2023-11-23T15:58:20.819+0530 [INFO] core: pre-seal teardown  
starting  
2023-11-23T15:58:20.819+0530 [INFO] rollback: stopping rollback  
manager  
2023-11-23T15:58:20.819+0530 [INFO] core: pre-seal teardown  
complete  
2023-11-23T15:58:21.116+0530 [INFO] core.cluster-listener.tcp:  
starting listener: listener_address=0.0.0.0:8201  
2023-11-23T15:58:21.116+0530 [INFO] core.cluster-listener:  
serving cluster requests: cluster_listen_address=[::]:8201  
2023-11-23T15:58:21.117+0530 [INFO] core: post-unseal setup  
starting  
2023-11-23T15:58:21.117+0530 [INFO] core: loaded wrapping token  
key  
2023-11-23T15:58:21.117+0530 [INFO] core: successfully setup  
plugin catalog: plugin-directory=""  
2023-11-23T15:58:21.119+0530 [INFO] core: successfully mounted:  
type=system version="v1.14.0+builtin.vault" path=sys/  
namespace="ID: root. Path: "  
2023-11-23T15:58:21.120+0530 [INFO] core: successfully mounted:  
type=identity version="v1.14.0+builtin.vault" path=identity/  
namespace="ID: root. Path: "
```

```
2023-11-23T15:58:21.120+0530 [INFO] core: successfully mounted:  
type=cubbyhole version="v1.14.0+builtin.vault" path=cubbyhole/  
namespace="ID: root. Path: "  
2023-11-23T15:58:21.123+0530 [INFO] core: successfully mounted:  
type=token version="v1.14.0+builtin.vault" path=token/  
namespace="ID: root. Path: "  
2023-11-23T15:58:21.123+0530 [INFO] rollback: starting rollback  
manager  
2023-11-23T15:58:21.124+0530 [INFO] core: restoring leases  
2023-11-23T15:58:21.124+0530 [INFO] identity: entities restored  
2023-11-23T15:58:21.124+0530 [INFO] identity: groups restored  
2023-11-23T15:58:21.124+0530 [INFO] expiration: lease restore  
complete  
2023-11-23T15:58:21.125+0530 [INFO] core: usage gauge collection  
is disabled  
2023-11-23T15:58:21.125+0530 [INFO] core: post-unseal setup  
complete  
2023-11-23T15:58:21.125+0530 [INFO] core: vault is unsealed  
Success! Uploaded policy: mcctb-policy  
2023-11-23T15:58:21.600+0530 [INFO] core: enabled credential  
backend: path=approle/ type=approle version=""  
Success! Enabled approle auth method at: approle/  
2023-11-23T15:58:21.690+0530 [INFO] core: successful mount:  
namespace="" path=mcctb/ type=kv version=""  
Success! Enabled the kv secrets engine at: mcctb/  
Success! Data written to: auth/approle/role/mcctb-app  
Upgrading to NetApp-MetroCluster-Tiebreaker-Software-1.6-  
1.x86_64.rpm  
Preparing...  
#####
[100%]  
Updating / installing...  
1:NetApp-MetroCluster-Tiebreaker-  
So#####
[ 50%]  
Performing file integrity check  
etc/cron.weekly/metrocluster-tiebreaker-support is Ok  
etc/cron.weekly/metrocluster-tiebreaker-support-cov is Ok  
etc/init.d/netapp-metrocluster-tiebreaker-software is Ok  
etc/init.d/netapp-metrocluster-tiebreaker-software-cov is Ok  
etc/logrotate.d/mcctb is Ok  
opt/netapp/mcctb/lib/common/activation-1.1.1.jar is Ok  
opt/netapp/mcctb/lib/common/aopalliance.jar is Ok  
opt/netapp/mcctb/lib/common/args4j.jar is Ok  
opt/netapp/mcctb/lib/common/aspectjrt.jar is Ok  
opt/netapp/mcctb/lib/common/aspectjweaver.jar is Ok  
opt/netapp/mcctb/lib/common/asup.jar is Ok  
opt/netapp/mcctb/lib/common/bcpkix-jdk15on.jar is Ok
```

```
opt/netapp/mcctb/lib/common/bcprov-jdk15on.jar is Ok
opt/netapp/mcctb/lib/common/bcprov-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/bctls-fips-1.0.13.jar is Ok
opt/netapp/mcctb/lib/common/bctls-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/bcutil-jdk18on.jar is Ok
opt/netapp/mcctb/lib/common/cglib.jar is Ok
opt/netapp/mcctb/lib/common/commons-codec.jar is Ok
opt/netapp/mcctb/lib/common/commons-collections4.jar is Ok
opt/netapp/mcctb/lib/common/commons-compress.jar is Ok
opt/netapp/mcctb/lib/common/commons-daemon.jar is Ok
opt/netapp/mcctb/lib/common/commons-daemon.src.jar is Ok
opt/netapp/mcctb/lib/common/commons-dbcp2.jar is Ok
opt/netapp/mcctb/lib/common/commons-io.jar is Ok
opt/netapp/mcctb/lib/common/commons-lang3.jar is Ok
opt/netapp/mcctb/lib/common/commons-logging.jar is Ok
opt/netapp/mcctb/lib/common/commons-pool2.jar is Ok
opt/netapp/mcctb/lib/common/guava.jar is Ok
opt/netapp/mcctb/lib/common/httpclient.jar is Ok
opt/netapp/mcctb/lib/common/httpcore.jar is Ok
opt/netapp/mcctb/lib/common/jakarta.activation.jar is Ok
opt/netapp/mcctb/lib/common/jakarta.xml.bind-api.jar is Ok
opt/netapp/mcctb/lib/common/java-xmlbuilder.jar is Ok
opt/netapp/mcctb/lib/common/javax.inject.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-api-2.3.1.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-core.jar is Ok
opt/netapp/mcctb/lib/common/jaxb-impl.jar is Ok
opt/netapp/mcctb/lib/common/jline.jar is Ok
opt/netapp/mcctb/lib/common/jna.jar is Ok
opt/netapp/mcctb/lib/common/joda-time.jar is Ok
opt/netapp/mcctb/lib/common/jsch.jar is Ok
opt/netapp/mcctb/lib/common/json.jar is Ok
opt/netapp/mcctb/lib/common/jsvc.zip is Ok
opt/netapp/mcctb/lib/common/junixsocket-common.jar is Ok
opt/netapp/mcctb/lib/common/junixsocket-native-common.jar is Ok
opt/netapp/mcctb/lib/common/logback-classic.jar is Ok
opt/netapp/mcctb/lib/common/logback-core.jar is Ok
opt/netapp/mcctb/lib/common/mail-1.6.2.jar is Ok
opt/netapp/mcctb/lib/common/mariadb-java-client.jar is Ok
opt/netapp/mcctb/lib/common/mcctb-mib.jar is Ok
opt/netapp/mcctb/lib/common/mcctb.jar is Ok
opt/netapp/mcctb/lib/common/mockito-core.jar is Ok
opt/netapp/mcctb/lib/common/slf4j-api.jar is Ok
opt/netapp/mcctb/lib/common/snmp4j.jar is Ok
opt/netapp/mcctb/lib/common/spring-aop.jar is Ok
opt/netapp/mcctb/lib/common/spring-beans.jar is Ok
opt/netapp/mcctb/lib/common/spring-context-support.jar is Ok
```

```
opt/netapp/mcctb/lib/common/spring-context.jar is Ok
opt/netapp/mcctb/lib/common/spring-core.jar is Ok
opt/netapp/mcctb/lib/common/spring-expression.jar is Ok
opt/netapp/mcctb/lib/common/spring-web.jar is Ok
opt/netapp/mcctb/lib/common/vault-java-driver.jar is Ok
opt/netapp/mcctb/lib/common/xz.jar is Ok
opt/netapp/mcctb/lib/org.jacoco.agent-0.8.8-runtime.jar is Ok
opt/netapp/mcctb/bin/mcctb-asup-invoke is Ok
opt/netapp/mcctb/bin/mcctb_postrotate is Ok
opt/netapp/mcctb/bin/netapp-metrocluster-tiebreaker-software-cli
is Ok
/
```

Synchronizing state of netapp-metrocluster-tiebreaker-software.service with SysV service script with  
/usr/lib/systemd/systemd-sysv-install.

Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-metrocluster-tiebreaker-software

Attempting to start NetApp MetroCluster Tiebreaker software services

Started NetApp MetroCluster Tiebreaker software services

Successfully upgraded NetApp MetroCluster Tiebreaker software to version 1.6.

Cleaning up / removing...

2:NetApp-MetroCluster-Tiebreaker-  
So##### [100%]

IMPORTANT: Please ensure you store the following private key used to decrypt audit logs securely in a safe location.

Consider the following recommendations:

- Save it to an encrypted storage device or file.
- Use strong, unique passwords to protect the storage device or file.
- Restrict access to the private key file to authorized individuals only.

The Private key is:

```
-----BEGIN PRIVATE KEY-----
<private_key_id>
-----END PRIVATE KEY-----
```

## Installare il Tiebreaker 1,5 o 1,4

### Configurare l'accesso amministratore all'API e all'SSH ONTAP

È possibile configurare l'accesso admin alle API e SSH ONTAP.

#### Fasi

1. Creare un utente amministratore con accesso API ONTAP: `security login create -user-or-group-name mcctb -application ontapi -authentication-method password`
2. Creare un utente amministratore con accesso SSH: `security login create -user-or-group-name mcctb -application ssh -authentication-method password`
3. Verificare che siano stati creati i nuovi utenti admin: `security login show`
4. Ripetere questi passaggi sul cluster partner.



"Autenticazione amministratore e RBAC" è implementato.

### Installazione delle dipendenze di MetroCluster Tiebreaker

A seconda del sistema operativo Linux host, è necessario installare un server MySQL o MariaDB prima di installare o aggiornare il software tiebreaker.

#### Fasi

1. Installare JRE.

#### [Installare JRE](#)

2. Installare e configurare il vault.

#### [Installare e configurare il vault](#)

3. Installare il server MySQL o MariaDB:

Se l'host Linux è	Quindi...
Red Hat Enterprise Linux 7/CentOS 7	Installare MySQL  <a href="#">Installazione di MySQL Server 5.5.30 o versioni successive e 5.6.x su Red Hat Enterprise Linux 7 o CentOS 7</a>
Red Hat Enterprise Linux 8	Installare MariaDB  <a href="#">Installazione del server MariaDB su Red Hat Enterprise Linux 8</a>

#### [Installare JRE](#)

È necessario installare JRE sul sistema host prima di installare o aggiornare il software Tiebreaker. Per i sistemi che eseguono Tiebreaker 1.4 e versioni precedenti, eseguire JRE 8. Per i sistemi che eseguono Tiebreaker 1.5 e versioni successive, eseguire OpenJDK 17, 18 o 19.



Le uscite nell'esempio seguente mostrano JRE 1.8.0. (JRE 8).

## Fasi

1. Accedere come utente "root" o come utente sudo che può passare alla modalità avanzata dei privilegi.

```
login as: root
root@mcctb's password:
Last login: Fri Jan  8 21:33:00 2017 from host.domain.com
```

2. Controllare le versioni JRE disponibili:

```
yum search openjdk
```

3. Installare una versione JRE appropriata per la versione di Tiebreaker che si sta installando:

```
yum install java-<version>-openjdk.x86_64
```

```
[root@mcctb ~]# yum install java-1.8.0-openjdk.x86_64
Loaded plugins: fastestmirror, langpacks
Loading mirror speeds from cached hostfile
... shortened....
Dependencies Resolved

=====
Package           Arch      Version          Repository      Size
=====
Installing:
java-1.8.0-openjdk x86_64   1:1.8.0.144-0.b01.el7_4 updates      238 k
..
..
Transaction Summary
=====
Install 1 Package (+ 4 Dependent packages)

Total download size: 34 M
Is this ok [y/d/N]: y

Installed:
java-1.8.0-openjdk.x86_64 1:1.8.0.144-0.b01.el7_4
Complete!
```

## Installare e configurare il vault

Se non si dispone o si desidera utilizzare il server del vault locale, è necessario installare Vault. Si può fare riferimento a questa procedura standard per l'installazione del vault o fare riferimento alle istruzioni di

installazione di Hashicorp per linee guida alternative.



Se si dispone di un server vault nella rete, è possibile configurare l'host MetroCluster Tiebreaker per l'utilizzo dell'installazione del vault. In questo caso, non è necessario installare Vault sull'host.

## Fasi

1. Passare a. /bin directory:

```
[root@mcctb ~] cd /bin
```

2. Scaricare il file zip del vault.

```
[root@mcctb /bin]# curl -sO  
https://releases.hashicorp.com/vault/1.12.2/vault_1.12.2_linux_amd64.zip
```

3. Decomprimere il file del vault.

```
[root@mcctb /bin]# unzip vault_1.12.2_linux_amd64.zip  
Archive: vault_1.12.2_linux_amd64.zip  
  inflating: vault
```

4. Verificare l'installazione.

```
[root@mcctb /bin]# vault -version  
Vault v1.12.2 (415e1fe3118eebd5df6cb60d13defdc01aa17b03), built 2022-11-  
23T12:53:46Z
```

5. Passare a. /root directory:

```
[root@mcctb ~] cd /root
```

6. Creare un file di configurazione del vault in /root directory.

Su [root@mcctb ~] prompt, copiare ed eseguire il comando seguente per creare config.hcl file:

```
# cat > config.hcl << EOF
storage "file" {
  address = "127.0.0.1:8500"
  path     = "/mcctb_vdata/data"
}
listener "tcp" {
  address      = "127.0.0.1:8200"
  tls_disable  = 1
}
EOF
```

7. Avviare il server del vault:

```
[root@mcctb ~] vault server -config config.hcl &
```

8. Esportare l'indirizzo del vault.

```
[root@mcctb ~]# export VAULT_ADDR="http://127.0.0.1:8200"
```

9. Inizializzare il vault.

```
[root@mcctb ~]# vault operator init
2022-12-15T14:57:22.113+0530 [INFO] core: security barrier not
initialized
2022-12-15T14:57:22.113+0530 [INFO] core: seal configuration missing,
not initialized
2022-12-15T14:57:22.114+0530 [INFO] core: security barrier not
initialized
2022-12-15T14:57:22.116+0530 [INFO] core: security barrier initialized:
stored=1 shares=5 threshold=3
2022-12-15T14:57:22.118+0530 [INFO] core: post-unseal setup starting
2022-12-15T14:57:22.137+0530 [INFO] core: loaded wrapping token key
2022-12-15T14:57:22.137+0530 [INFO] core: Recorded vault version: vault
version=1.12.2 upgrade_time="2022-12-15 09:27:22.137200412 +0000 UTC"
build_date=2022-11-23T12:53:46Z
2022-12-15T14:57:22.137+0530 [INFO] core: successfully setup plugin
catalog: plugin-directory=""
2022-12-15T14:57:22.137+0530 [INFO] core: no mounts; adding default
mount table
2022-12-15T14:57:22.143+0530 [INFO] core: successfully mounted backend:
type=cubbyhole version="" path=cubbyhole/
2022-12-15T14:57:22.144+0530 [INFO] core: successfully mounted backend:
type=system version="" path=sys/
```

```
2022-12-15T14:57:22.144+0530 [INFO] core: successfully mounted backend:  
type=identity version="" path=identity/  
2022-12-15T14:57:22.148+0530 [INFO] core: successfully enabled  
credential backend: type=token version="" path=token/ namespace="ID:  
root. Path: "  
2022-12-15T14:57:22.149+0530 [INFO] rollback: starting rollback manager  
2022-12-15T14:57:22.149+0530 [INFO] core: restoring leases  
2022-12-15T14:57:22.150+0530 [INFO] expiration: lease restore complete  
2022-12-15T14:57:22.150+0530 [INFO] identity: entities restored  
2022-12-15T14:57:22.150+0530 [INFO] identity: groups restored  
2022-12-15T14:57:22.151+0530 [INFO] core: usage gauge collection is  
disabled  
2022-12-15T14:57:23.385+0530 [INFO] core: post-unseal setup complete  
2022-12-15T14:57:23.387+0530 [INFO] core: root token generated  
2022-12-15T14:57:23.387+0530 [INFO] core: pre-seal teardown starting  
2022-12-15T14:57:23.387+0530 [INFO] rollback: stopping rollback manager  
2022-12-15T14:57:23.387+0530 [INFO] core: pre-seal teardown complete  
Unseal Key 1: <unseal_key_1_id>  
Unseal Key 2: <unseal_key_2_id>  
Unseal Key 3: <unseal_key_3_id>  
Unseal Key 4: <unseal_key_4_id>  
Unseal Key 5: <unseal_key_5_id>
```

Initial Root Token: <initial\_root\_token\_id>

Vault initialized with 5 key shares and a key threshold of 3. Please securely distribute the key shares printed above. When the Vault is re-sealed, restarted, or stopped, you must supply at least 3 of these keys to unseal it before it can start servicing requests.

Vault does not store the generated root key. Without at least 3 keys to reconstruct the root key, Vault will remain permanently sealed!

It is possible to generate new unseal keys, provided you have a quorum of existing unseal keys shares. See "vault operator rekey" for more information.



È necessario registrare e memorizzare gli ID della chiave e il token principale iniziale in una posizione sicura per poterli utilizzare successivamente nella procedura.

10. Esportare il token root del vault.

```
[root@mcctb ~]# export VAULT_TOKEN=<initial_root_token_id>
```

11. Rimuovere il sigillo del vault usando tre delle cinque chiavi create.

È necessario eseguire vault operator unseal comando per ciascuna delle tre chiavi:

a. Rimuovere il sigillo del vault usando la prima chiave:

```
[root@mcctb ~]# vault operator unseal
Unseal Key (will be hidden):
Key          Value
---          -----
Seal Type    shamir
Initialized   true
Sealed       true
Total Shares 5
Threshold    3
Unseal Progress 1/3
Unseal Nonce <unseal_key_1_id>
Version      1.12.2
Build Date   2022-11-23T12:53:46Z
Storage Type file
HA Enabled   false
```

b. Rimuovere il sigillo del vault usando la seconda chiave:

```
[root@mcctb ~]# vault operator unseal
Unseal Key (will be hidden):
Key          Value
---          -----
Seal Type    shamir
Initialized   true
Sealed       true
Total Shares 5
Threshold    3
Unseal Progress 2/3
Unseal Nonce <unseal_key_2_id>
Version      1.12.2
Build Date   2022-11-23T12:53:46Z
Storage Type file
HA Enabled   false
```

c. Rimuovere il sigillo del vault usando la terza chiave:

```

[root@mcctb ~]# vault operator unseal
Unseal Key (will be hidden):
2022-12-15T15:15:00.980+0530 [INFO]  core.cluster-listener.tcp:
starting listener: listener_address=127.0.0.1:8201
2022-12-15T15:15:00.980+0530 [INFO]  core.cluster-listener: serving
cluster requests: cluster_listen_address=127.0.0.1:8201
2022-12-15T15:15:00.981+0530 [INFO]  core: post-unseal setup starting
2022-12-15T15:15:00.981+0530 [INFO]  core: loaded wrapping token key
2022-12-15T15:15:00.982+0530 [INFO]  core: successfully setup plugin
catalog: plugin-directory=""
2022-12-15T15:15:00.983+0530 [INFO]  core: successfully mounted
backend: type=system version="" path=sys/
2022-12-15T15:15:00.984+0530 [INFO]  core: successfully mounted
backend: type=identity version="" path=identity/
2022-12-15T15:15:00.984+0530 [INFO]  core: successfully mounted
backend: type=cubbyhole version="" path=cubbyhole/
2022-12-15T15:15:00.986+0530 [INFO]  core: successfully enabled
credential backend: type=token version="" path=token/ namespace="ID:
root. Path: "
2022-12-15T15:15:00.986+0530 [INFO]  rollback: starting rollback
manager
2022-12-15T15:15:00.987+0530 [INFO]  core: restoring leases
2022-12-15T15:15:00.987+0530 [INFO]  expiration: lease restore
complete
2022-12-15T15:15:00.987+0530 [INFO]  identity: entities restored
2022-12-15T15:15:00.987+0530 [INFO]  identity: groups restored
2022-12-15T15:15:00.988+0530 [INFO]  core: usage gauge collection is
disabled
2022-12-15T15:15:00.989+0530 [INFO]  core: post-unseal setup complete
2022-12-15T15:15:00.989+0530 [INFO]  core: vault is unsealed
Key          Value
---          -----
Seal Type    shamir
Initialized   true
Sealed       false
Total Shares 5
Threshold    3
Version      1.12.2
Build Date   2022-11-23T12:53:46Z
Storage Type file
Cluster Name vault-cluster
Cluster ID   <cluster_id>
HA Enabled   false

```

## 12. Verificare che lo stato del Vault Sealed sia falso.

```
[root@mcctb ~]# vault status
Key          Value
---          -----
Seal Type    shamir
Initialized   true
Sealed       false
Total Shares 5
Threshold    3
Version      1.12.2
Build Date   2022-11-23T12:53:46Z
Storage Type file
Cluster Name vault-cluster
Cluster ID   <cluster_id>
HA Enabled   false
```

13. Configurare il servizio Vault per avviarlo all'avvio.

- a. Eseguire il seguente comando: cd /etc/systemd/system

```
[root@mcctb ~]# cd /etc/systemd/system
```

- b. Su [root@mcctb system] Richiedere, copiare ed eseguire il comando seguente per creare il file di servizio del vault.

```
# cat > vault.service << EOF
[Unit]
Description=Vault Service
After=mariadb.service

[Service]
Type=forking
ExecStart=/usr/bin/vault server -config /root/config.hcl &
Restart=on-failure

[Install]
WantedBy=multi-user.target
EOF
```

- c. Eseguire il seguente comando: systemctl daemon-reload

```
[root@mcctb system]# systemctl daemon-reload
```

- d. Eseguire il seguente comando: systemctl enable vault.service

```
[root@mcctb system]# systemctl enable vault.service
Created symlink /etc/systemd/system/multi-
user.target.wants/vault.service → /etc/systemd/system/vault.service.
```



Viene richiesto di utilizzare questa funzione durante l'installazione di MetroCluster Tiebreaker. Se si desidera modificare il metodo per dissigillare il vault, è necessario disinstallare e reinstallare il software MetroCluster Tiebreaker.

#### Installazione di MySQL Server 5.5.30 o versioni successive e 5.6.x su Red Hat Enterprise Linux 7 o CentOS 7

È necessario installare MySQL Server 5.5.30 o versione successiva e la versione 5.6.x sul sistema host prima di installare o aggiornare il software Tiebreaker.

#### Fasi

1. Accedere come utente root o sudo che può passare alla modalità avanzata dei privilegi.

```
login as: root
root@mcctb's password:
Last login: Fri Jan  8 21:33:00 2016 from host.domain.com
```

2. Aggiungi il repository MySQL al tuo sistema host:

```
[root@mcctb ~]# yum localinstall https://dev.mysql.com/get/mysql57-community-
release-el6-11.noarch.rpm
```

```

Loaded plugins: product-id, refresh-packagekit, security, subscription-
manager
Setting up Local Package Process
Examining /var/tmp/yum-root-LLUw0r/mysql-community-release-el6-
5.noarch.rpm: mysql-community-release-el6-5.noarch
Marking /var/tmp/yum-root-LLUw0r/mysql-community-release-el6-
5.noarch.rpm to be installed
Resolving Dependencies
--> Running transaction check
--> Package mysql-community-release.noarch 0:e16-5 will be installed
--> Finished Dependency Resolution
Dependencies Resolved
=====
=====
Package           Arch      Version
                                         Repository
Size
=====
=====
Installing:
mysql-community-release
                           noarch  el6-5 /mysql-community-release-el6-
5.noarch 4.3 k
Transaction Summary
=====
=====
Install          1 Package(s)
Total size: 4.3 k
Installed size: 4.3 k
Is this ok [y/N]: y
Downloading Packages:
Running rpm_check_debug
Running Transaction Test
Transaction Test Succeeded
Running Transaction
  Installing : mysql-community-release-el6-5.noarch
1/1
  Verifying   : mysql-community-release-el6-5.noarch
1/1
Installed:
  mysql-community-release.noarch 0:e16-5
Complete!

```

### 3. Disattivare il repository MySQL 57:

```
[root@mcctb ~]# yum-config-manager --disable mysql57-community
```

#### 4. Abilitare il repository MySQL 56:

```
[root@mcctb ~]# yum-config-manager --enable mysql56-community
```

#### 5. Abilitare il repository:

```
[root@mcctb ~]# yum repolist enabled | grep "mysql.-community."
```

mysql-connectors-community 21	MySQL Connectors Community
mysql-tools-community 35	MySQL Tools Community
mysql56-community 231	MySQL 5.6 Community Server

#### 6. Installare il server della community MySQL:

```
[root@mcctb ~]# yum install mysql-community-server
```

```
Loaded plugins: product-id, refresh-packagekit, security, subscription-
manager
This system is not registered to Red Hat Subscription Management. You
can use subscription-manager
to register.
Setting up Install Process
Resolving Dependencies
--> Running transaction check
.....Output truncated.....
---> Package mysql-community-libs-compat.x86_64 0:5.6.29-2.el6 will be
obsoleting
--> Finished Dependency Resolution
Dependencies Resolved
=====
=====
Package          Arch    Version        Repository
Size
=====
=====
Installing:
  mysql-community-client      x86_64  5.6.29-2.el6  mysql56-community
18 M
    replacing  mysql.x86_64 5.1.71-1.el6
  mysql-community-libs         x86_64  5.6.29-2.el6  mysql56-community
1.9 M
```

```

        replacing mysql-libs.x86_64 5.1.71-1.el6
mysql-community-libs-compat      x86_64  5.6.29-2.el6  mysql56-community
1.6 M
        replacing mysql-libs.x86_64 5.1.71-1.el6
mysql-community-server          x86_64  5.6.29-2.el6  mysql56-community
53 M
        replacing mysql-server.x86_64 5.1.71-1.el6
Installing for dependencies:
mysql-community-common          x86_64  5.6.29-2.el6  mysql56-community
308 k

Transaction Summary
=====
=====
Install      5 Package(s)
Total download size: 74 M
Is this ok [y/N]: y
Downloading Packages:
(1/5): mysql-community-client-5.6.29-2.el6.x86_64.rpm | 18 MB
00:28
(2/5): mysql-community-common-5.6.29-2.el6.x86_64.rpm | 308 kB
00:01
(3/5): mysql-community-libs-5.6.29-2.el6.x86_64.rpm | 1.9 MB
00:05
(4/5): mysql-community-libs-compat-5.6.29-2.el6.x86_64.rpm | 1.6 MB
00:05
(5/5): mysql-community-server-5.6.29-2.el6.x86_64.rpm | 53 MB
03:42
-----
-----
Total                                         289 kB/s | 74 MB
04:24
warning: rpmts_HdrFromFdno: Header V3 DSA/SHA1 Signature, key ID
<key_id> NOKEY
Retrieving key from file:/etc/pki/rpm-gpg/RPM-GPG-KEY-mysql
Importing GPG key 0x5072E1F5:
  Userid : MySQL Release Engineering <mysql-build@oss.oracle.com>
  Package: mysql-community-release-el6-5.noarch
            (@/mysql-community-release-el6-5.noarch)
  From   : file:/etc/pki/rpm-gpg/RPM-GPG-KEY-mysql
Is this ok [y/N]: y
Running rpm_check_debug
Running Transaction Test
Transaction Test Succeeded
Running Transaction
  Installing : mysql-community-common-5.6.29-2.el6.x86_64

```

```
....Output truncated....  
1.el6.x86_64  
7/8  
Verifying : mysql-5.1.71-1.el6.x86_64  
8/8  
Installed:  
mysql-community-client.x86_64 0:5.6.29-2.el6  
mysql-community-libs.x86_64 0:5.6.29-2.el6  
mysql-community-libs-compat.x86_64 0:5.6.29-2.el6  
mysql-community-server.x86_64 0:5.6.29-2.el6  
  
Dependency Installed:  
mysql-community-common.x86_64 0:5.6.29-2.el6  
  
Replaced:  
mysql.x86_64 0:5.1.71-1.el6 mysql-libs.x86_64 0:5.1.71-1.el6  
mysql-server.x86_64 0:5.1.71-1.el6  
Complete!
```

## 7. Avviare il server MySQL:

```
[root@mcctb ~]# service mysqld start
```

```
Initializing MySQL database: 2016-04-05 19:44:38 0 [Warning] TIMESTAMP  
with implicit DEFAULT value is deprecated. Please use  
--explicit_defaults_for_timestamp server option (see documentation  
for more details).  
2016-04-05 19:44:38 0 [Note] /usr/sbin/mysqld (mysqld 5.6.29)  
      starting as process 2487 ...  
2016-04-05 19:44:38 2487 [Note] InnoDB: Using atomics to ref count  
      buffer pool pages  
2016-04-05 19:44:38 2487 [Note] InnoDB: The InnoDB memory heap is  
      disabled  
.....Output truncated.....  
2016-04-05 19:44:42 2509 [Note] InnoDB: Shutdown completed; log sequence  
      number 1625987
```

PLEASE REMEMBER TO SET A PASSWORD FOR THE MySQL root USER!  
To do so, start the server, then issue the following commands:

```
/usr/bin/mysqladmin -u root password 'new-password'  
/usr/bin/mysqladmin -u root -h mcctb password 'new-password'
```

Alternatively, you can run:

```
/usr/bin/mysql_secure_installation
```

which will also give you the option of removing the test  
databases and anonymous user created by default. This is  
strongly recommended for production servers.

.....Output truncated.....

WARNING: Default config file /etc/my.cnf exists on the system  
This file will be read by default by the MySQL server  
If you do not want to use this, either remove it, or use the  
--defaults-file argument to mysqld\_safe when starting the server

```
[ OK ]  
Starting mysqld: [ OK ]
```

## 8. Verificare che MySQL Server sia in esecuzione:

```
[root@mcctb ~]# service mysqld status
```

```
mysqld (pid 2739) is running...
```

## 9. Configurare le impostazioni di sicurezza e password:

```
[root@mcctb ~]# mysql_secure_installation
```

NOTE: RUNNING ALL PARTS OF THIS SCRIPT IS RECOMMENDED FOR ALL MySQL SERVERS IN PRODUCTION USE! PLEASE READ EACH STEP CAREFULLY!

In order to log into MySQL to secure it, we'll need the current password for the root user. If you've just installed MySQL, and you haven't set the root password yet, the password will be blank, so you should just press enter here.

```
Enter current password for root (enter for none):      <== on default
install                                                 hit enter here
OK, successfully used password, moving on...
```

Setting the root password ensures that nobody can log into the MySQL root user without the proper authorization.

```
Set root password? [Y/n] y
New password:
Re-enter new password:
Password updated successfully!
Reloading privilege tables..
... Success!
```

By default, a MySQL installation has an anonymous user, allowing anyone to log into MySQL without having to have a user account created for them. This is intended only for testing, and to make the installation go a bit smoother. You should remove them before moving into a production environment.

```
Remove anonymous users? [Y/n] y
... Success!
```

Normally, root should only be allowed to connect from 'localhost'. This ensures that someone cannot guess at the root password from the network.

```
Disallow root login remotely? [Y/n] y
... Success!
```

By default, MySQL comes with a database named 'test' that anyone can access. This is also intended only for testing, and should be removed before moving into a production environment.

```
Remove test database and access to it? [Y/n] y
- Dropping test database...
ERROR 1008 (HY000) at line 1: Can't drop database 'test';
```

```
database doesn't exist
... Failed! Not critical, keep moving...
- Removing privileges on test database...
... Success!
```

Reloading the privilege tables will ensure that all changes made so far will take effect immediately.

```
Reload privilege tables now? [Y/n] y
... Success!
```

All done! If you've completed all of the above steps, your MySQL installation should now be secure.

Thanks for using MySQL!

Cleaning up...

## 10. Verificare che l'accesso MySQL funzioni:

```
[root@mcctb ~]# mysql -u root -p
```

```
Enter password: <configured_password>
Welcome to the MySQL monitor. Commands end with ; or \g.
Your MySQL connection id is 17
Server version: 5.6.29 MySQL Community Server (GPL)

Copyright (c) 2000, 2016, Oracle and/or its affiliates. All rights reserved.

Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.

Type 'help;' or '\h' for help. Type '\c' to clear the current input statement.
mysql>
```

Se il login MySQL funziona, l'output terminerà con mysql> prompt.

## Abilitare l'impostazione di avvio automatico di MySQL

Verificare che la funzionalità di autostart sia attivata per il daemon MySQL. L'attivazione del daemon MySQL riavvia automaticamente MySQL se il sistema su cui risiede il software MetroCluster Tiebreaker si riavvia. Se il daemon MySQL non è in esecuzione, il software Tiebreaker continua a funzionare, ma non può essere riavviato e non è possibile apportare modifiche alla configurazione.

## Fase

1. Verificare che MySQL sia abilitato all'avvio automatico all'avvio:

```
[root@mcctb ~]# systemctl list-unit-files mysqld.service
```

UNIT FILE	State
<hr/>	
mysqld.service	enabled

Se MySQL non è abilitato all'avvio automatico all'avvio, consultare la documentazione di MySQL per abilitare la funzione di avvio automatico per l'installazione.

## Installazione del server MariaDB su Red Hat Enterprise Linux 8

È necessario installare il server MariaDB sul sistema host prima di installare o aggiornare il software Tiebreaker.

### Prima di iniziare

Il sistema host deve essere in esecuzione su Red Hat Enterprise Linux (RHEL) 8.

### Fasi

1. Accedere come a. root utente o utente che può passare alla modalità avanzata dei privilegi.

```
login as: root
root@mcctb's password:
Last login: Fri Jan  8 21:33:00 2017 from host.domain.com
```

1. Installare il server MariaDB:

```
[root@mcctb ~]# yum install mariadb-server.x86_64
```

```
[root@mcctb ~]# yum install mariadb-server.x86_64
Loaded plugins: fastestmirror, langpacks
...
=====
=====
====
```

Package	Arch	Version	Repository
Size			
====	====	====	====
Installing:			
mariadb-server	x86_64	1:5.5.56-2.el7	base
11 M			

```
Installing for dependencies:
```

```
Transaction Summary
```

```
=====
```

```
Install 1 Package (+8 Dependent packages)
Upgrade           ( 1 Dependent package)
```

```
Total download size: 22 M
```

```
Is this ok [y/d/N]: y
```

```
Downloading packages:
```

```
No Presto metadata available for base warning:
```

```
/var/cache/yum/x86_64/7/base/packages/mariadb-libs-5.5.56-
2.el7.x86_64.rpm:
Header V3 RSA/SHA256 Signature,
key ID f4a80eb5: NOKEY] 1.4 MB/s | 3.3 MB  00:00:13 ETA
Public key for mariadb-libs-5.5.56-2.el7.x86_64.rpm is not installed
(1/10): mariadb-libs-5.5.56-2.el7.x86_64.rpm | 757 kB  00:00:01
..
..
(10/10): perl-Net-Daemon-0.48-5.el7.noarch.rpm| 51 kB  00:00:01
```

```
-----
```

```
Installed:
```

```
  mariadb-server.x86_64 1:5.5.56-2.el7
```

```
Dependency Installed:
```

```
  mariadb.x86_64 1:5.5.56-2.el7
  perl-Compress-Raw-Bzip2.x86_64 0:2.061-3.el7
  perl-Compress-Raw-Zlib.x86_64 1:2.061-4.el7
  perl-DBD-MySQL.x86_64 0:4.023-5.el7
  perl-DBI.x86_64 0:1.627-4.el7
  perl-IO-Compress.noarch 0:2.061-2.el7
  perl-Net-Daemon.noarch 0:0.48-5.el7
  perl-PlRPC.noarch 0:0.2020-14.el7
```

```
Dependency Updated:
```

```
  mariadb-libs.x86_64 1:5.5.56-2.el7
```

```
Complete!
```

## 2. Avviare il server MariaDB:

```
[root@mcctb ~]# systemctl start mariadb
```

## 3. Verificare che il server MariaDB sia stato avviato:

```
[root@mcctb ~]# systemctl status mariadb
```

```
[root@mcctb ~]# systemctl status mariadb
mariadb.service - MariaDB database server
...
Nov 08 21:28:59 mcctb systemd[1]: Starting MariaDB database server...
...
Nov 08 21:29:01 mcctb systemd[1]: Started MariaDB database server.
```

#### 4. Configurare le impostazioni di sicurezza e password:



Quando viene richiesta la password di root, lasciarla vuota e premere Invio per continuare a configurare le impostazioni di sicurezza e password.

```
[root@mcctb ~]# mysql_secure_installation
```

```
root@localhost systemd]# mysql_secure_installation
```

```
NOTE: RUNNING ALL PARTS OF THIS SCRIPT IS RECOMMENDED FOR ALL MariaDB
      SERVERS IN PRODUCTION USE! PLEASE READ EACH STEP CAREFULLY!
```

```
In order to log into MariaDB to secure it, we'll need the current
password for the root user. If you've just installed MariaDB, and
you haven't set the root password yet, the password will be blank,
so you should just press enter here.
```

```
Enter current password for root (enter for none):
OK, successfully used password, moving on...
```

```
Setting the root password ensures that nobody can log into the MariaDB
root user without the proper authorisation.
```

```
Set root password? [Y/n] y
```

```
New password:
```

```
Re-enter new password:
```

```
Password updated successfully!
```

```
Reloading privilege tables..
```

```
... Success!
```

By default, a MariaDB installation has an anonymous user, allowing anyone

to log into MariaDB without having to have a user account created for them. This is intended only for testing, and to make the installation go a bit smoother. You should remove them before moving into a

production environment.

```
Remove anonymous users? [Y/n] y
... Success!
```

Normally, root should only be allowed to connect from 'localhost'. This ensures that someone cannot guess at the root password from the network.

```
Disallow root login remotely? [Y/n] y
... Success!
```

By default, MariaDB comes with a database named 'test' that anyone can access. This is also intended only for testing, and should be removed before moving into a production environment.

```
Remove test database and access to it? [Y/n] y
- Dropping test database...
... Success!
- Removing privileges on test database...
... Success!
```

Reloading the privilege tables will ensure that all changes made so far will take effect immediately.

```
Reload privilege tables now? [Y/n]
... Success!
```

Cleaning up...

All done! If you've completed all of the above steps, your MariaDB installation should now be secure.

Thanks for using MariaDB!

## Attivazione dell'impostazione di avvio automatico per il server MariaDB

Verificare che la funzione di avvio automatico sia attivata per il server MariaDB. Se non si attiva la funzione di avvio automatico e il sistema su cui risiede il software MetroCluster Tiebreaker deve essere riavviato, il software Tiebreaker continua a funzionare, ma il servizio MariaDB non può essere riavviato e non è possibile apportare modifiche alla configurazione.

### Fasi

#### 1. Attivare il servizio di avvio automatico:

```
[root@mcctb ~]# systemctl enable mariadb.service
```

## 2. Verificare che MariaDB sia abilitato all'avvio automatico all'avvio:

```
[root@mcctb ~]# systemctl list-unit-files mariadb.service
```

UNIT FILE	State
mariadb.service	enabled

## Installazione o aggiornamento del pacchetto software

È necessario installare o aggiornare il software MetroCluster Tiebreaker sul computer locale per monitorare le configurazioni MetroCluster.

### A proposito di questa attività

- Il sistema storage deve eseguire ONTAP 8.3.x o versione successiva.
- OpenJDK deve essere installato utilizzando `yum install java-x.x.x-openjdk` comando. Per i sistemi che eseguono Tiebreaker 1.4 e versioni precedenti, eseguire JRE 8. Per i sistemi che eseguono Tiebreaker 1.5 e versioni successive, eseguire OpenJDK 17, 18 o 19. Gli output dell'esempio mostrano JRE 1.8.0. (JRE 8).
- È possibile installare MetroCluster Tiebreaker come utente non root con privilegi amministrativi sufficienti per eseguire l'installazione di tiebreaker, creare tabelle e utenti e impostare la password utente.

### Fasi

- Scaricare il software MetroCluster Tiebreaker. In questo esempio viene utilizzata la versione 1.5.

["Sito di supporto NetApp"](#)

- Scaricare il `MetroCluster_Tiebreaker_RPM_GPG chiave`:

["Sito di supporto NetApp"](#)

- Accedere all'host come utente root.

- Creare un utente non root e. `mcctbgrp` gruppo.

- a. Creare un utente non root e impostare la password.

I seguenti comandi di esempio creano un utente non root denominato `mcctbuser1`:

```
[root@mcctb ~]# useradd mcctbuser1
[root@mcctb ~]# passwd mcctbuser1
Changing password for user mcctbuser1.
New password:
Retype new password:
passwd: all authentication tokens updated successfully.
```

- b. Creare un gruppo denominato `mcctbgrp`:

```
[root@mcctb ~]# groupadd mcctbgrp
```

- c. Aggiungere l'utente non root creato al mcctbgrp gruppo.

Viene aggiunto il seguente comando mcctbuser1 al mcctbgrp gruppo:

```
[root@mcctb ~]# usermod -a -G mcctbgrp mcctbuser1
```

## 5. Verificare il file RPM.

Eseguire i seguenti passaggi secondari dalla directory che contiene la chiave RPM.

- a. Scaricare e importare il file della chiave RPM:

```
[root@mcctb ~]# rpm --import MetroCluster_Tiebreaker_RPM_GPG.key
```

- b. Verificare che sia stata importata la chiave corretta controllando l'impronta digitale.

L'esempio seguente mostra un'impronta digitale della chiave corretta:

```
root@mcctb:~/signing/mcctb-rpms# gpg --show-keys --with-fingerprint
MetroCluster_Tiebreaker_RPM_GPG.key
pub    rsa3072 2022-11-17 [SCEA] [expires: 2025-11-16]
      65AC 1562 E28A 1497 7BBD  7251 2855 EB02 3E77 FAE5
uid                               MCCTB-RPM (mcctb RPM production signing)
<mcctb-rpm@netapp.com>
```

- a. Verificare la firma: `rpm --checksig NetApp-MetroCluster-Tiebreaker-Software-1.5-1.x86_64.rpm`

```
NetApp-MetroCluster-Tiebreaker-Software-1.5-1.x86_64.rpm: digests OK
```



È necessario procedere con l'installazione solo dopo aver verificato la firma.

## 6. Installa o aggiorna il software tiebreaker:



È possibile eseguire l'aggiornamento alla versione 1.5 di Tiebreaker solo quando si esegue l'aggiornamento dalla versione 1.4 di Tiebreaker. L'aggiornamento da versioni precedenti a tiebreaker 1.5 non è supportato.

Selezionare la procedura corretta in basso, a seconda che si stia eseguendo una nuova installazione o aggiornando un'installazione esistente.

## Eseguire una nuova installazione

- a. Recuperare e registrare il percorso assoluto per Java:

```
[root@mcctb ~]# readlink -f /usr/bin/java  
/usr/lib/jvm/java-19-openjdk-19.0.0.0.36-  
2.rolling.el8.x86_64/bin/java
```

- b. Eseguire il seguente comando: `rpm -ivh NetApp-MetroCluster-Tiebreaker-Software-1.5-1.x86_64.rpm`

Il sistema visualizza i seguenti output per una corretta installazione:



Quando richiesto durante l'installazione, fornire l'utente non root precedentemente creato e assegnato al `mcctbgrp` gruppo.

```
Verifying...
#####
Preparing...
#####
Updating / installing...
  1:NetApp-MetroCluster-Tiebreaker-
So#####
Enter the absolute path for Java : /usr/lib/jvm/java-19-openjdk-
19.0.0.0.36-2.rolling.el8.x86_64/bin/java
Verifying if Java exists...
Found Java. Proceeding with the installation.
Enter host user account to use for the installation:
mcctbuser1
User account mcctbuser1 found. Proceeding with the installation
Enter database user name:
root
Please enter database password for root
Enter password:
Sealed          false
Do you wish to auto unseal vault(y/n)?y
Enter the key1:
Enter the key2:
Enter the key3:
Success! Uploaded policy: mcctb-policy
Error enabling approle auth: Error making API request.
URL: POST http://127.0.0.1:8200/v1/sys/auth/approle
Code: 400. Errors:
* path is already in use at approle/
Success! Enabled the kv secrets engine at: mcctb/
Success! Data written to: auth/approle/role/mcctb-app
Password updated successfully in the vault.
Synchronizing state of netapp-metrocluster-tiebreaker-
software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-
metrocluster-tiebreaker-software
Created symlink /etc/systemd/system/multi-
user.target.wants/netapp-metrocluster-tiebreaker-software.service
→ /etc/systemd/system/netapp-metrocluster-tiebreaker-
software.service.
Attempting to start NetApp MetroCluster Tiebreaker software
services
Started NetApp MetroCluster Tiebreaker software services
Successfully installed NetApp MetroCluster Tiebreaker software
version 1.5.
```

### Aggiornamento di un'installazione esistente

- Verificare che sia installata una versione supportata di OpenJDK e che sia la versione corrente di Java presente sull'host.



Per gli aggiornamenti a tiebreaker 1.5, è necessario installare OpenJDK versione 17, 18 o 19.

```
[root@mcctb ~]# readlink -f /usr/bin/java  
/usr/lib/jvm/java-19-openjdk-19.0.0.36-  
2.rolling.el8.x86_64/bin/java
```

- Verificare che il servizio Vault sia dissigillato e in esecuzione: `vault status`

```
[root@mcctb ~]# vault status  
Key          Value  
---          ----  
Seal Type    shamir  
Initialized   true  
Sealed       false  
Total Shares  5  
Threshold    3  
Version      1.12.2  
Build Date   2022-11-23T12:53:46Z  
Storage Type file  
Cluster Name vault  
Cluster ID   <cluster_id>  
HA Enabled   false
```

- Aggiornare il software Tiebreaker.

```
[root@mcctb ~]# rpm -Uvh NetApp-MetroCluster-Tiebreaker-Software-  
1.5-1.x86_64.rpm
```

Il sistema visualizza il seguente output per un aggiornamento riuscito:

```
Verifying...
#####
Preparing...
#####
Updating / installing...
  1:NetApp-MetroCluster-Tiebreaker-
So#####
Enter the absolute path for Java : /usr/lib/jvm/java-19-openjdk-19.0.0.0.36-2.rolling.el8.x86_64/bin/java
Verifying if Java exists...
Found Java. Proceeding with the installation.
Enter host user account to use for the installation:
mcctbuser1
User account mcctbuser1 found. Proceeding with the installation
Sealed          false
Do you wish to auto unseal vault(y/n)?y
Enter the key1:
Enter the key2:
Enter the key3:
Success! Uploaded policy: mcctb-policy
Error enabling approle auth: Error making API request.
URL: POST http://127.0.0.1:8200/v1/sys/auth/approle
Code: 400. Errors:
* path is already in use at approle/
Success! Enabled the kv secrets engine at: mcctb/
Success! Data written to: auth/approle/role/mcctb-app
Enter database user name : root
Please enter database password for root
Enter password:
Password updated successfully in the database.
Password updated successfully in the vault.
Synchronizing state of netapp-metrocluster-tiebreaker-software.service with SysV service script with
/usr/lib/systemd/systemd-sysv-install.
Executing: /usr/lib/systemd/systemd-sysv-install enable netapp-metrocluster-tiebreaker-software
Attempting to start NetApp MetroCluster Tiebreaker software services
Started NetApp MetroCluster Tiebreaker software services
Successfully upgraded NetApp MetroCluster Tiebreaker software to version 1.5.
Cleaning up / removing...
  2:NetApp-MetroCluster-Tiebreaker-
So#####
[100%]
```



Se si immette la password root MySQL errata, il software Tiebreaker indica che è stato installato correttamente, ma visualizza i messaggi "Access denied" (accesso negato). Per risolvere il problema, è necessario disinstallare il software Tiebreaker utilizzando `rpm -e` E quindi reinstallare il software utilizzando la password root corretta di MySQL.

7. Verificare la connettività di Tiebreaker al software MetroCluster aprendo una connessione SSH dall'host di Tiebreaker a ciascuna delle LIF di gestione dei nodi e delle LIF di gestione del cluster.

#### Informazioni correlate

["Supporto NetApp"](#)

## **Informazioni sul copyright**

Copyright © 2024 NetApp, Inc. Tutti i diritti riservati. Stampato negli Stati Uniti d'America. Nessuna porzione di questo documento soggetta a copyright può essere riprodotta in qualsiasi formato o mezzo (grafico, elettronico o meccanico, inclusi fotocopie, registrazione, nastri o storage in un sistema elettronico) senza previo consenso scritto da parte del detentore del copyright.

Il software derivato dal materiale sottoposto a copyright di NetApp è soggetto alla seguente licenza e dichiarazione di non responsabilità:

IL PRESENTE SOFTWARE VIENE FORNITO DA NETAPP "COSÌ COM'È" E SENZA QUALSIVOGLIA TIPO DI GARANZIA IMPLICITA O ESPRESSA FRA CUI, A TITOLO ESEMPLIFICATIVO E NON ESAUSTIVO, GARANZIE IMPLICITE DI COMMERCIALITÀ E IDONEITÀ PER UNO SCOPO SPECIFICO, CHE VENGONO DECLINATE DAL PRESENTE DOCUMENTO. NETAPP NON VERRÀ CONSIDERATA RESPONSABILE IN ALCUN CASO PER QUALSIVOGLIA DANNO DIRETTO, INDIRETTO, ACCIDENTALE, SPECIALE, ESEMPLARE E CONSEGUENZIALE (COMPRESI, A TITOLO ESEMPLIFICATIVO E NON ESAUSTIVO, PROCUREMENT O SOSTITUZIONE DI MERCI O SERVIZI, IMPOSSIBILITÀ DI UTILIZZO O PERDITA DI DATI O PROFITTI OPPURE INTERRUZIONE DELL'ATTIVITÀ AZIENDALE) CAUSATO IN QUALSIVOGLIA MODO O IN RELAZIONE A QUALUNQUE TEORIA DI RESPONSABILITÀ, SIA ESSA CONTRATTUALE, RIGOROSA O DOVUTA A INSOLVENZA (COMPRESA LA NEGLIGENZA O ALTRO) INSORTA IN QUALSIASI MODO ATTRAVERSO L'UTILIZZO DEL PRESENTE SOFTWARE ANCHE IN PRESENZA DI UN PREAVVISO CIRCA L'EVENTUALITÀ DI QUESTO TIPO DI DANNI.

NetApp si riserva il diritto di modificare in qualsiasi momento qualunque prodotto descritto nel presente documento senza fornire alcun preavviso. NetApp non si assume alcuna responsabilità circa l'utilizzo dei prodotti o materiali descritti nel presente documento, con l'eccezione di quanto concordato espressamente e per iscritto da NetApp. L'utilizzo o l'acquisto del presente prodotto non comporta il rilascio di una licenza nell'ambito di un qualche diritto di brevetto, marchio commerciale o altro diritto di proprietà intellettuale di NetApp.

Il prodotto descritto in questa guida può essere protetto da uno o più brevetti degli Stati Uniti, esteri o in attesa di approvazione.

**LEGENDA PER I DIRITTI SOTTOPOSTI A LIMITAZIONE:** l'utilizzo, la duplicazione o la divulgazione da parte degli enti governativi sono soggetti alle limitazioni indicate nel sottoparagrafo (b)(3) della clausola Rights in Technical Data and Computer Software del DFARS 252.227-7013 (FEB 2014) e FAR 52.227-19 (DIC 2007).

I dati contenuti nel presente documento riguardano un articolo commerciale (secondo la definizione data in FAR 2.101) e sono di proprietà di NetApp, Inc. Tutti i dati tecnici e il software NetApp forniti secondo i termini del presente Contratto sono articoli aventi natura commerciale, sviluppati con finanziamenti esclusivamente privati. Il governo statunitense ha una licenza irrevocabile limitata, non esclusiva, non trasferibile, non cedibile, mondiale, per l'utilizzo dei Dati esclusivamente in connessione con e a supporto di un contratto governativo statunitense in base al quale i Dati sono distribuiti. Con la sola esclusione di quanto indicato nel presente documento, i Dati non possono essere utilizzati, divulgati, riprodotti, modificati, visualizzati o mostrati senza la previa approvazione scritta di NetApp, Inc. I diritti di licenza del governo degli Stati Uniti per il Dipartimento della Difesa sono limitati ai diritti identificati nella clausola DFARS 252.227-7015(b) (FEB 2014).

## **Informazioni sul marchio commerciale**

NETAPP, il logo NETAPP e i marchi elencati alla pagina <http://www.netapp.com/TM> sono marchi di NetApp, Inc. Gli altri nomi di aziende e prodotti potrebbero essere marchi dei rispettivi proprietari.