



# **Fibre Channel API methods**

Element Software

NetApp  
June 11, 2021

# Table of Contents

- Fibre Channel API methods ..... 1
  - Find more information ..... 1
  - GetVolumeAccessGroupLunAssignments ..... 1
  - ListFibreChannelPortInfo ..... 2
  - ListFibreChannelSessions ..... 6
  - ListNodeFibreChannelPortInfo ..... 7
  - ModifyVolumeAccessGroupLunAssignments ..... 10

# Fibre Channel API methods

You can use Fibre Channel API methods to add, modify, or remove Fibre Channel node members of a storage cluster.

- [GetVolumeAccessGroupLunAssignments](#)
- [ListFibreChannelPortInfo](#)
- [ListFibreChannelSessions](#)
- [ListNodeFibreChannelPortInfo](#)
- [ModifyVolumeAccessGroupLunAssignments](#)

## Find more information

- [NetApp SolidFire Resources Page](#)
- [Documentation for earlier versions of NetApp SolidFire and Element products](#)

## GetVolumeAccessGroupLunAssignments

You can use the `GetVolumeAccessGroupLunAssignments` method to retrieve details on LUN mappings of a specified volume access group.

### Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
volumeAccessGroupID	A unique volume access group ID used to return information.	integer	None	Yes

### Return value

This method has the following return value:

Name	Description	Type
volumeAccessGroupLunAssignments	A list of all physical Fibre Channel ports, or a port for a single node.	JSON object

### Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetVolumeAccessGroupLunAssignments",
  "params": {
    "volumeAccessGroupID": 5
  },
  "id" : 1
}
```

## Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "volumeAccessGroupLunAssignments" : {
      "volumeAccessGroupID" : 5,
      "lunAssignments" : [
        {"volumeID" : 5, "lun" : 0},
        {"volumeID" : 6, "lun" : 1},
        {"volumeID" : 7, "lun" : 2},
        {"volumeID" : 8, "lun" : 3}
      ],
      "deletedLunAssignments" : [
        {"volumeID" : 44, "lun" : 44}
      ]
    }
  }
}
```

## New since version

9.6

## ListFibreChannelPortInfo

You can use the `ListFibreChannelPortInfo` method to list information about the Fibre Channel ports.

This API method is intended for use on individual nodes; a userid and password are required for access to individual Fibre Channel nodes. However, this method can be used on the cluster if the force parameter is set to true. When used on the cluster, all Fibre Channel interfaces are listed.

## Parameter

This method has the following input parameter:

Name	Description	Type	Default value	Required
force	Set to true to run on all nodes in the cluster.	boolean	None	No

## Return value

This method has the following return value:

Name	Description	Type
fibreChannelPorts	A list of all physical Fibre Channel ports, or a port for a single node.	<a href="#">fibreChannelPort</a> array

## Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListFibreChannelPortInfo",
  "params": {},
  "id" : 1
}
```

## Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "fibreChannelPortInfo": {
      "5": {
        "result": {
          "fibreChannelPorts": [
            {
              "firmware": "7.04.00 (d0d5)",
              "hbaPort": 1,
              "model": "QLE2672",
              "nPortID": "0xc70084",
              "pciSlot": 3,
            }
          ]
        }
      }
    }
  }
}
```

```

    "serial": "BFE1335E03500",
    "speed": "8 Gbit",
    "state": "Online",
    "switchWwn": "20:01:00:2a:6a:98:a3:41",
    "wwnn": "5f:47:ac:c8:3c:e4:95:00",
    "wwpn": "5f:47:ac:c0:3c:e4:95:0a"
  },
  {
    "firmware": "7.04.00 (d0d5)",
    "hbaPort": 2,
    "model": "QLE2672",
    "nPortID": "0x0600a4",
    "pciSlot": 3,
    "serial": "BFE1335E03500",
    "speed": "8 Gbit",
    "state": "Online",
    "switchWwn": "20:01:00:2a:6a:9c:71:01",
    "wwnn": "5f:47:ac:c8:3c:e4:95:00",
    "wwpn": "5f:47:ac:c0:3c:e4:95:0b"
  },
  {
    "firmware": "7.04.00 (d0d5)",
    "hbaPort": 1,
    "model": "QLE2672",
    "nPortID": "0xc70044",
    "pciSlot": 2,
    "serial": "BFE1335E04029",
    "speed": "8 Gbit",
    "state": "Online",
    "switchWwn": "20:01:00:2a:6a:98:a3:41",
    "wwnn": "5f:47:ac:c8:3c:e4:95:00",
    "wwpn": "5f:47:ac:c0:3c:e4:95:08"
  },
  {
    "firmware": "7.04.00 (d0d5)",
    "hbaPort": 2,
    "model": "QLE2672",
    "nPortID": "0x060044",
    "pciSlot": 2,
    "serial": "BFE1335E04029",
    "speed": "8 Gbit",
    "state": "Online",
    "switchWwn": "20:01:00:2a:6a:9c:71:01",
    "wwnn": "5f:47:ac:c8:3c:e4:95:00",
    "wwpn": "5f:47:ac:c0:3c:e4:95:09"
  }
}

```

```

    ]
  }
},
"6": {
  "result": {
    "fibreChannelPorts": [
      {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 1,
        "model": "QLE2672",
        "nPortID": "0x060084",
        "pciSlot": 3,
        "serial": "BFE1335E04217",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:9c:71:01",
        "wwnn": "5f:47:ac:c8:3c:e4:95:00",
        "wwpn": "5f:47:ac:c0:3c:e4:95:02"
      },
      {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 2,
        "model": "QLE2672",
        "nPortID": "0xc700a4",
        "pciSlot": 3,
        "serial": "BFE1335E04217",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:98:a3:41",
        "wwnn": "5f:47:ac:c8:3c:e4:95:00",
        "wwpn": "5f:47:ac:c0:3c:e4:95:03"
      },
      {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 1,
        "model": "QLE2672",
        "nPortID": "0xc70064",
        "pciSlot": 2,
        "serial": "BFE1341E09515",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:98:a3:41",
        "wwnn": "5f:47:ac:c8:3c:e4:95:00",
        "wwpn": "5f:47:ac:c0:3c:e4:95:00"
      }
    ],
  }
}

```

```

        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 2,
        "model": "QLE2672",
        "nPortID": "0x060064",
        "pciSlot": 2,
        "serial": "BFE1341E09515",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:9c:71:01",
        "wwnn": "5f:47:ac:c8:3c:e4:95:00",
        "wwpn": "5f:47:ac:c0:3c:e4:95:01"
    }
]
}
}
}
}
}
}
}

```

## New since version

9.6

## ListFibreChannelSessions

You can use the `ListFibreChannelSessions` method to list information about the Fibre Channel sessions on a cluster.

### Parameters

This method has no input parameters.

### Return value

This method has the following return value:

Name	Description	Type
sessions	A list of objects describing active Fibre Channel sessions on the cluster.	<a href="#">session</a> array

### Request example

Requests for this method are similar to the following example:



```
{
  "method": "ListFibreChannelSessions",
  "params": {},
  "id" : 1
}
```

## Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {
    "sessions" : [
      {
        "initiatorWWPN" : "21:00:00:0e:1e:14:af:40",
        "nodeID" : 5,
        "serviceID" : 21,
        "targetWWPN": "5f:47:ac:c0:00:00:00:10",
        "volumeAccessGroupID": 7
      },
      {
        "initiatorWWPN" : "21:00:00:0e:1e:14:af:40",
        "nodeID" : 1,
        "serviceID" : 22,
        "targetWWPN": "5f:47:ac:c0:00:00:00:11",
        "volumeAccessGroupID": 7
      }
    ]
  }
}
```

## New since version

9.6

## ListNodeFibreChannelPortInfo

You can use the `ListNodeFibreChannelPortInfo` method to list information about the Fibre Channel ports on a node.

This API method is intended for use on individual nodes; a userid and password are required for access to individual Fibre Channel nodes. When used on the cluster, all Fibre Channel interfaces are listed.

## Parameter

This method has no input parameters.

## Return value

This method has the following return value:

Name	Description	Type
fibreChannelPorts	A list of all physical Fibre Channel ports, or a port for a single node.	<a href="#">fibreChannelPort</a> array

## Request example

Requests for this method are similar to the following example:

```
{
  "method": "ListNodeFibreChannelPortInfo",
  "params": {
    "nodeID": 5,
    "force": true
  },
  "id" : 1
}
```

## Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "fibreChannelPorts": [
      {
        "firmware": "7.04.00 (d0d5)",
        "hbaPort": 1,
        "model": "QLE2672",
        "nPortID": "0xc7002c",
        "pciSlot": 3,
        "serial": "BFE1335E03500",
        "speed": "8 Gbit",
        "state": "Online",
        "switchWwn": "20:01:00:2a:6a:98:a3:41",
        "wwnn": "5f:47:ac:c8:35:54:02:00",
        "wwpn": "5f:47:ac:c0:35:54:02:02"
      }
    ]
  }
}
```

```
},
{
  "firmware": "7.04.00 (d0d5)",
  "hbaPort": 2,
  "model": "QLE2672",
  "nPortID": "0x06002d",
  "pciSlot": 3,
  "serial": "BFE1335E03500",
  "speed": "8 Gbit",
  "state": "Online",
  "switchWwn": "20:01:00:2a:6a:9c:71:01",
  "wwnn": "5f:47:ac:c8:35:54:02:00",
  "wwpn": "5f:47:ac:c0:35:54:02:03"
},
{
  "firmware": "7.04.00 (d0d5)",
  "hbaPort": 1,
  "model": "QLE2672",
  "nPortID": "0xc7002a",
  "pciSlot": 2,
  "serial": "BFE1335E04029",
  "speed": "8 Gbit",
  "state": "Online",
  "switchWwn": "20:01:00:2a:6a:98:a3:41",
  "wwnn": "5f:47:ac:c8:35:54:02:00",
  "wwpn": "5f:47:ac:c0:35:54:02:00"
},
{
  "firmware": "7.04.00 (d0d5)",
  "hbaPort": 2,
  "model": "QLE2672",
  "nPortID": "0x06002a",
  "pciSlot": 2,
  "serial": "BFE1335E04029",
  "speed": "8 Gbit",
  "state": "Online",
  "switchWwn": "20:01:00:2a:6a:9c:71:01",
  "wwnn": "5f:47:ac:c8:35:54:02:00",
  "wwpn": "5f:47:ac:c0:35:54:02:01"
}
]
}
}
```

## New since version

9.6

# ModifyVolumeAccessGroupLunAssignments

You can use the `ModifyVolumeAccessGroupLunAssignments` method to define custom LUN assignments for specific volumes.

This method changes only LUN values set on the `lunAssignments` parameter in the volume access group. All other LUN assignments remain unchanged.

LUN assignment values must be unique for volumes in a volume access group. You cannot define duplicate LUN values within a volume access group. However, you can use the same LUN values again in different volume access groups.



Valid LUN values are 0 through 16383. The system generates an exception if you pass a LUN value outside of this range. None of the specified LUN assignments are modified if there is an exception.

### CAUTION:

If you change a LUN assignment for a volume with active I/O, the I/O can be disrupted. You should change the server configuration before changing volume LUN assignments.

## Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
volumeAccessGroupID	Unique volume access group ID for which the LUN assignments will be modified.	integer	None	Yes
lunAssignments	The volume IDs with new assigned LUN values.	integer array	None	Yes

## Return value

This method has the following return value:

Name	Description	Type
volumeAccessGroupLunAssignments	An object containing details of the modified volume access group LUN assignments.	JSON object

## Request example

Requests for this method are similar to the following example:

```
{
  "method": "ModifyVolumeAccessGroupLunAssignments",
  "params": {
    "volumeAccessGroupID" : 218,
    "lunAssignments" : [
      {"volumeID" : 832, "lun" : 0},
      {"volumeID" : 834, "lun" : 1}
    ]
  },
  "id" : 1
}
```

## Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "volumeAccessGroupLunAssignments": {
      "deletedLunAssignments": [],
      "lunAssignments": [
        {
          "lun": 0,
          "volumeID": 832
        },
        {
          "lun": 1,
          "volumeID": 834
        }
      ]
    },
    "volumeAccessGroupID": 218
  }
}
```

## New since version

9.6

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.