



statistics preset commands

Command reference

NetApp
July 17, 2026

Table of Contents

- statistics preset commands 1
 - statistics preset delete 1
 - Description 1
 - Parameters 1
 - Examples 1
 - statistics preset modify 4
 - Description 4
 - Parameters 4
 - Examples 4
 - statistics preset show 5
 - Description 5
 - Parameters 5
 - Examples 6
 - statistics preset detail show 7
 - Description 7
 - Parameters 7
 - Examples 8

statistics preset commands

statistics preset delete

Delete an existing Performance Preset

Availability: This command is available to *cluster* administrators at the *advanced* privilege level.

Description

Deletes a performance preset configuration and all of its associated details.

Parameters

-preset <text> - Preset Name (privilege: advanced)

Specifies the name of the performance presets that you want to delete.

Examples

```
cluster1::*> statistics preset show
    Preset Name: asup-event
    Preset UUID: 55c03699-01db-11e2-8e3e-123478563412
    Comment: The event-based AutoSupport Data ONTAP Performance
Archive
                preset configuration. This preset configuration is
used
                whenever an event-based AutoSupport is triggered.
    Privilege: diagnostic
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: false
    Generation ID: 0
Preset Name: asup-hourly
    Preset UUID: 56178a2a-01db-11e2-8e3e-123478563412
    Comment: The hourly AutoSupport Data ONTAP Performance Archive
used by
                preset configuration. This preset configuration is
                the hourly AutoSupport collection events.
    Privilege: diagnostic
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: true
    Generation ID: 0
Preset Name: default
```

```

Preset UUID: 55ac6297-01db-11e2-8e3e-123478563412
  Comment: The default Data ONTAP Performance Archive preset
           configuration. This preset configuration includes
troubleshooting of           essential counters to assist in general
           system performance.
    Privilege: diagnostic
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: true
    Generation ID: 0
Preset Name: diagnostic
  Preset UUID: 561db291-01db-11e2-8e3e-123478563412
    Comment: The diagnostic Data ONTAP Performance Archive preset
           configuration. This preset configuration includes more
           counters at faster sample periods than the default
           configuration to assist in troubleshooting abnormal
           system performance.
    Privilege: diagnostic
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: false
    Generation ID: 0
Preset Name: foo
  Preset UUID: 7a04f19d-02a7-11e2-8e40-123478563412
    Comment: Test preset
    Privilege: diagnostic
    Read-Only: false
    Negative Preset: true
    Application Order: 2
    Archive Enabled: false
    Generation ID: 0

5 entries were displayed.

cluster1::*> statistics preset delete -preset foo

cluster1::*> statistics preset show
  Preset Name: asup-event
  Preset UUID: 55c03699-01db-11e2-8e3e-123478563412
    Comment: The event-based AutoSupport Data ONTAP Performance
Archive
           preset configuration. This preset configuration is
used

```

```

        whenever an event-based AutoSupport is triggered.
    Privilege: diagnostic
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: false
    Generation ID: 0
Preset Name: asup-hourly
    Preset UUID: 56178a2a-01db-11e2-8e3e-123478563412
    Comment: The hourly AutoSupport Data ONTAP Performance Archive
        preset configuration. This preset configuration is
used by
        the hourly AutoSupport collection events.
    Privilege: diagnostic
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: true
    Generation ID: 0
Preset Name: default
    Preset UUID: 55ac6297-01db-11e2-8e3e-123478563412
    Comment: The default Data ONTAP Performance Archive preset
        configuration. This preset configuration includes
essential counters to assist in general
troubleshooting of
        system performance.
    Privilege: diagnostic
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: true
    Generation ID: 0
Preset Name: diagnostic
    Preset UUID: 561db291-01db-11e2-8e3e-123478563412
    Comment: The diagnostic Data ONTAP Performance Archive preset
        configuration. This preset configuration includes more
counters at faster sample periods than the default
configuration to assist in troubleshooting abnormal
system performance.
    Privilege: diagnostic
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: false
    Generation ID: 0

```

statistics preset modify

Modify an existing Performance Preset

Availability: This command is available to *cluster* administrators at the *advanced* privilege level.

Description

Modifies an existing performance preset configuration. The command modifies the global properties of a preset, but does not modify the details of the preset, such as specific objects and counters sampled.

Parameters

-preset <text> - Preset Name (privilege: advanced)

Name of the performance preset to be modified.

[-new-name <text>] - New Preset Name (privilege: advanced)

Set preset name to the given new name.

[-comment <text>] - Preset Description (privilege: advanced)

Set comment to the given value.

[-privilege <PrivilegeLevel>] - Preset Privilege Level (privilege: advanced)

Set privilege level at which this preset can be viewed or modified to the given value. Possible values: admin, advanced, diagnostic.

Examples

```

cluster1:*> statistics preset show
    Preset Name: delta
    Preset UUID: 7a04f19d-02a7-11e2-8e40-123478563412
    Comment: custom preset description
    Privilege: diagnostic
    Read-Only: false
    Negative Preset: false
    Application Order: 1
    Archive Enabled: false
    Generation ID: 0

1 entry was displayed.

cluster1:*> statistics preset modify -preset delta -comment "new comment"

cluster1:*> statistics preset show
    Preset Name: delta
    Preset UUID: 7a04f19d-02a7-11e2-8e40-123478563412
    Comment: new comment
    Privilege: diagnostic
    Read-Only: false
    Negative Preset: false
    Application Order: 1
    Archive Enabled: false
    Generation ID: 0

1 entry was displayed.

```

statistics preset show

Display information about Performance Presets

Availability: This command is available to *cluster* administrators at the *advanced* privilege level.

Description

Displays information about performance preset configurations.

Parameters

[*-fields* <fieldname>,...]

Selects which performance preset attributes to display.

[*-instance*] (privilege: advanced) }

Shows details of all attributes of performance preset configuration.

[`-preset <text>`] - Preset Name (privilege: advanced)

Selects the performance presets that match the specified preset name.

[`-comment <text>`] - Preset Description (privilege: advanced)

Selects the performance presets that match the specified comment.

[`-privilege <PrivilegeLevel>`] - Preset Privilege Level (privilege: advanced)

Selects the performance presets that are available with the specified privilege.

[`-store <text>`] - Name of Store Where Data is Saved (privilege: advanced)

Selects the store where data is saved.

[`-is-read-only {true|false}`] - Is Preset Read-Only? (privilege: advanced)

Selects the performance presets that are read-only (true) or are not read-only (false). Read-only presets cannot be modified.

Examples

```
cluster1::*> statistics preset show
    Preset Name: aggregate_overview
    Preset UUID: 4ec14b86-34a0-11ef-8db4-005056bb1920
    Comment: This preset configuration is used by statistics
aggregate
    show command. Provides overview of aggregate object.
    Privilege: admin
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: false
    Store Name: -
    Generation ID: 0
Preset Name: disk_overview
    Preset UUID: 4e7471b3-34a0-11ef-8db4-005056bb1920
    Comment: This preset configuration is used by statistics disk
show
    command. Provides overview of disk object.
    Privilege: advanced
    Read-Only: true
    Negative Preset: false
    Application Order: 1
    Archive Enabled: false
    Store Name: -
    Generation ID: 0
Preset Name: fcp_port_overview
    Preset UUID: 4e77ed6e-34a0-11ef-8db4-005056bb1920
    Comment: This preset configuration is used by statistics port
fcp
```



```

        show command. Provides overview of fcp port object.
        Privilege: admin
        Read-Only: true
        Negative Preset: false
    Application Order: 1
        Archive Enabled: false
        Store Name: -
        Generation ID: 0
    Preset Name: flash_pool_overview
        Preset UUID: 4ecd2576-34a0-11ef-8db4-005056bb1920
        Comment: This preset configuration is used by statistics cache
        flash-pool show command. Provides overview of flash
pool
        object.
        Privilege: admin
        Read-Only: true
        Negative Preset: false
    Application Order: 1
        Archive Enabled: false
        Store Name: -
        Generation ID: 0
[...]
```

statistics preset detail show

Display information about Performance Preset Details

Availability: This command is available to *cluster* administrators at the *advanced* privilege level.

Description

Displays the specific details of each preset, including the objects sampled, the counter sample periods, and the counters sampled.

Parameters

[*-fields* <fieldname>,...]

Selects which performance preset detail attributes to display.

[*-instance*] (privilege: advanced) }

Displays all of the performance preset detail attributes.

[*-preset* <text>] - Preset Name (privilege: advanced)

Selects the performance preset details that match the specified preset name.

[-object <text>] - Performance Object (privilege: advanced)

Selects the performance preset details that match the specified object name.

[-sample-period <sample_period>] - Archive Sample period (privilege: advanced)

Selects the performance preset details that are collected at the specified sample period.

[-counter-set <text>,...] - Performance Counter Name Set (privilege: advanced)

Selects the performance preset details that match the specified counters in the counter set. Use "|" to separate multiple counters.

[-instance-filters <text>,...] - Performance Instance Filters (privilege: advanced)

Selects the performance preset details that match the specified instance filters. Use "|" to separate multiple instance filters. This field is reserved for future use.

Examples

```
cluster1::*> statistics preset detail show
```

Preset Name	Object	Sample Period	Counter Set	Instance Filters
asup-event	aggregate	1w	instance_name, node_name, process_name, parent_host, total_ transfers, user_reads, user_writes, cp_reads, user_read_ blocks, user_write_ blocks, cp_read_ blocks, wv_fsid, wv_vol_type, wv_fsinfo_fs_ version, wv_volinfo_fs_ options,	-
. . .				

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.