



Completing the transition

ONTAP MetroCluster

Ranu Kundu
May 24, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/transition/task_complete_transition.html on September 12, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Completing the transition 1

Completing the transition

To complete the transition you must verify the operation of the new MetroCluster IP configuration.

1. Verify the MetroCluster IP configuration.

You must perform this step on each cluster.

The following example shows the output for cluster_A.

```
cluster_A::> cluster show
Node                Health  Eligibility  Epsilon
-----
node_A_1-IP        true   true         true
node_A_2-IP        true   true         false
2 entries were displayed.

cluster_A::>
```

The following example shows the output for cluster_B.

```
cluster_B::> cluster show
Node                Health  Eligibility  Epsilon
-----
node_B_1-IP        true   true         true
node_B_2-IP        true   true         false
2 entries were displayed.

cluster_B::>
```

2. Enable cluster HA and storage failover.

You must perform this step on each cluster.

3. Verify that cluster HA capability is enabled.

```

cluster_A::> cluster ha show
High Availability Configured: true

cluster_A::>

cluster_A::> storage failover show

Node                Partner                Takeover
-----            -
Possible State Description
-----
node_A_1-IP        node_A_2-IP        true        Connected to node_A_2-IP
node_A_2-IP        node_A_1-IP        true        Connected to node_A_1-IP
2 entries were displayed.

cluster_A::>

```

4. Disable MetroCluster transition mode.

- a. Change to the advanced privilege level: `set -privilege advanced`
- b. Disable transition mode: `metrocluster transition disable`
- c. Return to the admin privilege level: `set -privilege admin`

```

cluster_A::*> metrocluster transition disable

cluster_A::*>

```

5. Verify that transition is disabled: `metrocluster transition show-mode`

You must perform these steps on both clusters.

```

cluster_A::> metrocluster transition show-mode
Transition Mode
-----
not-enabled

cluster_A::>

```

```
cluster_B::> metrocluster transition show-mode
Transition Mode
-----
not-enabled

cluster_B::>
```

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.