



# Retrieve MetroCluster node configurations

## ONTAP 9.10.1 REST API Documentation

NetApp  
January 31, 2025

This PDF was generated from [https://docs.netapp.com/us-en/ontap-restapi-9101/ontap/cluster\\_metrocluster\\_nodes\\_endpoint\\_overview.html](https://docs.netapp.com/us-en/ontap-restapi-9101/ontap/cluster_metrocluster_nodes_endpoint_overview.html) on January 31, 2025. Always check docs.netapp.com for the latest.

# Table of Contents

- Retrieve MetroCluster node configurations ..... 1
  - Cluster MetroCluster nodes endpoint overview ..... 1
  - Retrieve MetroCluster nodes and configurations ..... 4
  - Retrieve the node configuration in MetroCluster ..... 10

# Retrieve MetroCluster node configurations

## Cluster MetroCluster nodes endpoint overview

### Overview

Retrieves the configuration information for the nodes in the MetroCluster configuration.

### Example

```
GET https://<mgmt-ip>/api/cluster/metrocluster/nodes
{
  "records": [
    {
      "dr_group_id": 1,
      "cluster": {
        "name": "cluster1",
        "uuid": "8f77de32-9857-11e9-9a55-005056828eb9",
        "_links": {
          "self": {
            "href": "/api/cluster/8f77de32-9857-11e9-9a55-005056828eb9"
          }
        }
      },
      "node": {
        "name": "cluster1_01",
        "uuid": "46147363-9857-11e9-9a55-005056828eb9",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/46147363-9857-11e9-9a55-005056828eb9"
          }
        }
      },
      "dr_mirroring_state": "enabled",
      "configuration_state": "configured",
      "_links": {
        "self": {
          "href": "/api/cluster/metrocluster/nodes/46147363-9857-11e9-9a55-005056828eb9"
        }
      }
    },
  ]
}
```

```

{
  "dr_group_id": 1,
  "cluster": {
    "name": "cluster1",
    "uuid": "8f77de32-9857-11e9-9a55-005056828eb9",
    "_links": {
      "self": {
        "href": "/api/cluster/8f77de32-9857-11e9-9a55-
005056828eb9"
      }
    }
  },
  "node": {
    "name": "cluster1_02",
    "uuid": "cf1dc67f-9857-11e9-bf80-005056829db6",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/cf1dc67f-9857-11e9-bf80-
005056829db6"
      }
    }
  },
  "dr_mirroring_state": "enabled",
  "configuration_state": "configured",
  "_links": {
    "self": {
      "href": "/api/cluster/metrocluster/nodes/cf1dc67f-9857-
11e9-bf80-005056829db6"
    }
  }
},
{
  "dr_group_id": 1,
  "cluster": {
    "name": "cluster3",
    "uuid": "aa8aa15a-9857-11e9-80c9-00505682e684",
    "_links": {
      "self": {
        "href": "/api/cluster/aa8aa15a-9857-11e9-80c9-
00505682e684"
      }
    }
  },
  "node": {
    "name": "cluster3_01",
    "uuid": "5b3b983b-9857-11e9-80c9-00505682e684",

```

```

    "_links": {
      "self": {
        "href": "/api/cluster/nodes/5b3b983b-9857-11e9-80c9-00505682e684"
      }
    },
    "dr_mirroring_state": "enabled",
    "configuration_state": "configured",
    "_links": {
      "self": {
        "href": "/api/cluster/metrocluster/nodes/5b3b983b-9857-11e9-80c9-00505682e684"
      }
    }
  },
  {
    "dr_group_id": 1,
    "cluster": {
      "name": "cluster3",
      "uuid": "aa8aa15a-9857-11e9-80c9-00505682e684",
      "_links": {
        "self": {
          "href": "/api/cluster/aa8aa15a-9857-11e9-80c9-00505682e684"
        }
      }
    },
    "node": {
      "name": "cluster3_02",
      "uuid": "45bff538-9858-11e9-a624-005056820377",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/45bff538-9858-11e9-a624-005056820377"
        }
      }
    },
    "dr_mirroring_state": "enabled",
    "configuration_state": "configured",
    "_links": {
      "self": {
        "href": "/api/cluster/metrocluster/nodes/45bff538-9858-11e9-a624-005056820377"
      }
    }
  }
}

```

```

    }
  ],
  "num_records": 4,
  "_links": {
    "self": {
      "href": "/api/cluster/metrocluster/nodes?fields=%2A"
    }
  }
}

```

## Retrieve MetroCluster nodes and configurations

GET /cluster/metrocluster/nodes

**Introduced In:** 9.8

Retrieves MetroCluster nodes and their configurations.

### Related ONTAP Commands

- `metrocluster node show`

### Learn more

- [DOC /cluster/metrocluster/nodes](#)

### Parameters

Name	Type	In	Required	Description
configuration_state	string	query	False	Filter by configuration_state
dr_group_id	integer	query	False	Filter by dr_group_id
automatic_uso	boolean	query	False	Filter by automatic_uso  • Introduced in: 9.9
node.uuid	string	query	False	Filter by node.uuid
node.name	string	query	False	Filter by node.name

Name	Type	In	Required	Description
cluster.name	string	query	False	Filter by cluster.name
cluster.uuid	string	query	False	Filter by cluster.uuid
dr_operation_state	string	query	False	Filter by dr_operation_state <ul style="list-style-type: none"> <li>• Introduced in: 9.9</li> </ul>
dr_mirroring_state	string	query	False	Filter by dr_mirroring_state
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none"> <li>• Default value: 1</li> </ul>
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul>

Name	Type	In	Required	Description
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">collection_links</a>	
num_records	integer	Number of Records
records	array[ <a href="#">metrocluster_node</a> ]	



## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "cluster": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "cluster1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "configuration_state": "string",
      "dr_group_id": 0,
      "dr_mirroring_state": "string",
      "dr_operation_state": "string",
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    }
  ]
}
```

## Error

Status: Default

### ONTAP Error Response Codes

Error Code	Description
2425734	An internal error occurred. Wait a few minutes, and try the operation again. For further assistance, contact technical support.

Name	Type	Description
error	<a href="#">error</a>	

### Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

collection\_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

self\_link

Name	Type	Description
self	<a href="#">href</a>	

\_links

Name	Type	Description
self	<a href="#">href</a>	

cluster

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

node

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

metrocluster\_node

Data for a node in a MetroCluster. REST: /api/cluster/metrocluster/nodes

Name	Type	Description
_links	<a href="#">self_link</a>	

Name	Type	Description
automatic_uso	boolean	Specifies if automatic unplanned switchover is enabled.
cluster	<a href="#">cluster</a>	
configuration_state	string	Configuration state of the node.
dr_group_id	integer	DR Group ID.
dr_mirroring_state	string	State of the DR mirroring configuration.
dr_operation_state	string	State of the DR operation.
node	<a href="#">node</a>	

#### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Retrieve the node configuration in MetroCluster

GET /cluster/metrocluster/nodes/{node.uuid}

**Introduced In:** 9.8

Retrieves the node configuration in the MetroCluster.

## Related ONTAP Commands

- `metrocluster node show`

## Parameters

Name	Type	In	Required	Description
node.uuid	string	path	True	Node UUID
fields	array[string]	query	False	Specify the fields to return.

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">self_link</a>	
automatic_uso	boolean	Specifies if automatic unplanned switchover is enabled.
cluster	<a href="#">cluster</a>	
configuration_state	string	Configuration state of the node.
dr_group_id	integer	DR Group ID.
dr_mirroring_state	string	State of the DR mirroring configuration.
dr_operation_state	string	State of the DR operation.
node	<a href="#">node</a>	

## Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "cluster": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "cluster1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "configuration_state": "string",
  "dr_group_id": 0,
  "dr_mirroring_state": "string",
  "dr_operation_state": "string",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  }
}
```

## Error

Status: Default

### ONTAP Error Response Codes

Error Code	Description
2425734	An internal error occurred. Wait a few minutes, and try the operation again. For further assistance, contact technical support.

Name	Type	Description
error	error	

### Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

### Definitions

## See Definitions

href

Name	Type	Description
href	string	

self\_link

Name	Type	Description
self	<a href="#">href</a>	

\_links

Name	Type	Description
self	<a href="#">href</a>	

cluster

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

node

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments



<b>Name</b>	<b>Type</b>	<b>Description</b>
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Copyright information

Copyright © 2025 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.