Networking

REST API reference

NetApp
July 17, 2026

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-9181/networking_overview.html on July 17, 2026. Always check docs.netapp.com for the latest.

Table of Contents

Networking . . . 1
- ONTAP REST API Networking endpoints . . . 1
  - Overview . . . 1
  - IPspaces . . . 1
  - Ethernet . . . 1
  - Fibre Channel . . . 2
  - IP . . . 2
- Manage broadcast domains . . . 3
  - Manage broadcast domains . . . 3
  - Retrieve broadcast domains for the entire cluster . . . 13
  - Create a new broadcast domain . . . 18
  - Delete a broadcast domain . . . 23
  - Retrieve broadcast domain details . . . 25
  - Update broadcast domain properties . . . 30
- Manage network Ethernet ports . . . 34
  - Manage network Ethernet ports . . . 34
  - Retrieve ports . . . 54
  - Create a new VLAN or LAG . . . 77
  - Delete a VLAN or LAG . . . 95
  - Retrieve a physical port, VLAN, or LAG details . . . 98
  - Update a port . . . 113
  - Retrieve historical port performance metrics . . . 128
- Retrieve network Ethernet switch ports . . . 135
  - Retrieve network Ethernet switch ports . . . 135
  - Retrieve Ethernet switch ports . . . 142
  - Retrieve an Ethernet switch port . . . 156
- Manage Ethernet switches . . . 166
  - Manage Ethernet switches . . . 166
  - Retrieve Ethernet switches attached to a chassis . . . 171
  - Create an Ethernet switch . . . 179
  - Delete an Ethernet switch . . . 187
  - Retrieve Ethernet switch details . . . 189
  - Update an Ethernet switch . . . 193
- Retrieve FC fabrics . . . 200
  - Retrieve FC fabrics . . . 200
  - Retrieve FC fabrics . . . 208
  - Retrieve FC fabric switches . . . 216
  - Retrieve an FC switch . . . 226
  - Retrieve FC fabric zones . . . 233
  - Retrieve an FC fabric zone . . . 241
  - Retrieve an FC fabric . . . 248
- Manage FC network interfaces . . . 255
  - Manage FC network interfaces . . . 255

Retrieve FC interfaces . . . 274
Create an FC interface . . . 304
Retrieve historical performance metrics for an FC interface . . . 327
Retrieve historical performance metrics for an FC interface for a specific time . . . 335
Delete an FC interface . . . 340
Retrieve an FC interface . . . 342
Update an FC interface . . . 358
Retrieve FC port information . . . 373
Retrieve FC port information . . . 373
Retrieve FC ports . . . 382
Retrieve historical performance metrics for an FC port . . . 401
Retrieve historical performance metrics for an FC port for a specific time . . . 410
Retrieve an FC port . . . 415
Update an FC port . . . 429
Manage HTTP proxy configuration . . . 443
Manage HTTP proxy configuration . . . 443
Retrieve HTTP proxy configurations for all SVMs and cluster IPspaces . . . 447
Create an HTTP proxy configuration for an SVM or cluster IPspace . . . 454
Delete HTTP proxy configuration for an SVM or cluster IPspace . . . 461
Display HTTP proxy server, port, and IPspace information for an SVM or cluster IPspace . . . 463
Update proxy server, port, username, and password parameters . . . 467
Manage BGP peer groups . . . 471
Manage BGP peer groups . . . 472
Retrieve all BGP peer group details for VIP . . . 480
Create a new BGP peer group for VIP . . . 488
Delete a BGP peer group for VIP . . . 497
Retrieve details of a BGP peer group for VIP . . . 499
Update a BGP peer group for VIP . . . 506
Manage network IP interfaces . . . 512
Manage network IP interfaces . . . 513
Retrieve all IP interface details . . . 529
Create a new cluster-scoped or SVM-scoped interface . . . 552
Delete an IP interface . . . 571
Retrieve details for an IP interface . . . 573
Update an IP interface . . . 587
Retrieve interface historical performance metrics . . . 603
Manage network IP routes . . . 610
Manage network IP routes . . . 610
Retrieve IP routes . . . 617
Create a cluster-scoped or SVM-scoped static route . . . 627
Delete an IP route . . . 634
Retrieve details for an IP route . . . 636
Manage network IP service policies . . . 642
Manage network IP service policies . . . 642
Retrieve service policies . . . 656

Create a service policy for network interfaces . . . 663
Delete a service policy for network interfaces . . . 669
Retrieve a service policy . . . 671
Update a service policy for network interfaces . . . 676
Manage network IP subnets . . . 680
Manage network IP subnets . . . 680
Retrieve details for all subnets . . . 691
Create a new named subnet . . . 700
Delete an IP subnet . . . 709
Retrieve IP subnet details . . . 711
Update an IP subnet . . . 716
Manage network IPspaces . . . 722
Manage network IPspaces . . . 722
Retrieve IPspaces for a cluster . . . 726
Create a new domain with unique IP addresses . . . 731
Delete an IPspace object . . . 733
Retrieve information about an IPspace . . . 735
Update an IPspace object . . . 738

Networking

ONTAP REST API Networking endpoints

Overview

The ONTAP networking APIs enable reporting on networking information, such as IPspaces, interfaces, routes, ports, service policies and broadcast domains. Some can also be used to manage networking.

IPspaces

IPspaces enable you to configure a single ONTAP cluster so that it can be accessed by clients from more than one administratively separate network domain, even if those clients are using the same IP address subnet range. This allows for separation of client traffic for privacy and security.

An IPspace defines a distinct IP address space in which storage virtual machines (SVMs) reside. Ports and IP addresses defined for an IPspace are applicable only within that IPspace. A distinct routing table is maintained for each SVM within an IPspace, so that no cross-SVM or cross-IPspace traffic routing occurs.

Ethernet

Broadcast Domains

A broadcast domain is a set of ports which would all receive a broadcast packet that is sent from any of the ports.

By accurately representing the physical network with an ONTAP broadcast domain, ONTAP ensures that IP interfaces are able to migrate to appropriate ports in case of failure. ONTAP also ensures that characteristics, such as MTU, stay matched across all ports of the broadcast domain.

A broadcast domain resides in an IPspace, and can be used by cluster-scoped or SVM-scoped IP interfaces in that IPspace. The scope of the broadcast domain’s uniqueness is the IPspace it is in. You must create as many broadcast domains in an IPspace as there are IP subnets with interfaces in that IPspace.

Ports are mapped to an IPspace by assigning the port’s broadcast domain.

Ports

A port is a physical or virtual Ethernet network device. Physical ports may be combined into Link Aggregation Groups (LAGs, or ifgrps), or divided into Virtual LANs (VLANs).

The GET and PATCH APIs are available for all port types. The POST and DELETE APIs are available for "lag" and "vlan" port types.

A given port can host zero or more IP interfaces.

A port exists in a broadcast domain and all ports within the same broadcast domain must have layer 2 network connectivity to one another. If a port within a broadcast domain goes down, any IP interfaces hosted by that port can fail over to other ports in the same broadcast domain.

Fibre Channel

Interfaces

Fibre Channel (FC) interfaces are the logical endpoints for Fibre Channel network connections to an SVM. A Fibre Channel interface provides Fibre Channel access to storage within the interface's SVM using either Fibre Channel Protocol (FCP) or Non-Volatile Memory Express over Fibre Channel (NVMe over FC).

The Fibre Channel interface REST API allows you to create, delete, update and discover Fibre Channel interfaces and obtain status information for Fibre Channel interfaces.

A Fibre Channel interface is created on a Fibre Channel port that is located on a cluster node. The Fibre Channel port must be specified to identify the location of the interface for a POST or PATCH that relocates an interface. You can identify the port by either supplying the node and port names or the port UUID.

Ports

Fibre Channel ports are the physical ports of Fibre Channel adapters on ONTAP cluster nodes that can be connected to Fibre Channel networks to provide Fibre Channel network connectivity. A Fibre Channel port defines the location of a Fibre Channel interface within the ONTAP cluster.

The Fibre Channel port REST API allows you to discover Fibre Channel ports, obtain status information for Fibre Channel ports, and configure Fibre Channel port properties.

Learn More

- *Fibre Channel Logins* found in both the *SAN* and *NVMe* sections. Fibre Channel logins represent connections formed by Fibre Channel initiators that have successfully logged in to ONTAP.

IP

Interfaces

An interface (also referred to as a *LIF* in ONTAP documentation) represents a network access point to a node in a cluster. In other words, an interface is essentially an IPv4 or IPv6 address with associated attributes.

IP interfaces are configured on ports to send and receive communications over the network. The port that will host the interface can either be explicitly specified using node and/or port fields or implicitly specified using a broadcast domain.

The IPspace of the interface is required for cluster-scoped interfaces. The SVM owning the interface is required for SVM-scoped interfaces. These interfaces are in the SVM's IPspace.

The service policy of an interface defines what network services are provided by the interface.

Routes

Routes indicate which IPv4 or IPv6 gateway to use to communicate with hosts that are not on the local subnet. Typically, an IP interface (or LIF) can only use a gateway if it has the same address family and is in the LIF's subnet.

It is important that every gateway address belongs to a physical or virtual router that has connectivity to the specified destination network.

SVM-scoped routes can only be used by IP interfaces of the specified SVM. Likewise, cluster-scoped routes can only be used by cluster-scoped IP interfaces in the specified IPspace.

Service Policies

Service policies are named groupings that define what services are supported by an IP interface. These include both built-in service policies (for example: default-data-files or default-management) and custom service policies.

Service policies are scoped to either an SVM or IPspace.

Manage broadcast domains

Manage broadcast domains

Overview

A broadcast domain is a collection of Ethernet ports that have layer 2 connectivity. They are used to determine which Ethernet ports can host interfaces of various types. The broadcast domain REST API allows you to retrieve, create, modify, and delete broadcast domains. The broadcast domain APIs do not manage port membership. To add a port to a broadcast domain or to move a port to a different broadcast domain, use PATCH /network/ethernet/ports/<uuid>.</uuid>

Retrieving network Ethernet broadcast domain information

The broadcast domains GET API retrieves and displays relevant information pertaining to the broadcast domains configured in the cluster. The API retrieves the list of all broadcast domains configured in the cluster, or a specific broadcast domain.

Examples

Retrieving all broadcast domains in the cluster

The following output shows the list of all broadcast domains configured in a cluster.

```
# The API:
/api/network/ethernet/broadcast-domains

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ethernet/broadcast-domains" -H
"accept: application/hal+json"

# The response:
{
"records": [
```

```
  {
    "uuid": "6970c2a9-f34f-11e8-8373-005056bb6b85",
    "name": "Cluster",
    "ipspace": {
      "uuid": "6267eff8-f34f-11e8-8373-005056bb6b85",
      "name": "Cluster",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/6267eff8-f34f-11e8-8373-
005056bb6b85"
        }
      }
    },
    "ports": [
      {
        "uuid": "626b4d19-f34f-11e8-8373-005056bb6b85",
        "name": "e0a",
        "node": {
          "name": "examplecluster-node01"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/626b4d19-f34f-11e8-8373-
005056bb6b85"
          }
        }
      },
      {
        "uuid": "626b77b9-f34f-11e8-8373-005056bb6b85",
        "name": "e0b",
        "node": {
          "name": "examplecluster-node01"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/626b77b9-f34f-11e8-8373-
005056bb6b85"
          }
        }
      }
    ],
    "mtu": 9000,
    "_links": {
      "self": {
        "href": "/api/network/ethernet/broadcast-domains/6970c2a9-f34f-
11e8-8373-005056bb6b85"
```

```
      }
    }
  },
  {
    "uuid": "6972416c-f34f-11e8-8373-005056bb6b85",
    "name": "Default",
    "ipspace": {
      "uuid": "5f650349-f34f-11e8-8373-005056bb6b85",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/5f650349-f34f-11e8-8373-
005056bb6b85"
        }
      }
    },
    "ports": [
      {
        "uuid": "626bae19-f34f-11e8-8373-005056bb6b85",
        "name": "e0c",
        "node": {
          "name": "examplecluster-node01"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/626bae19-f34f-11e8-8373-
005056bb6b85"
          }
        }
      },
      {
        "uuid": "626bd677-f34f-11e8-8373-005056bb6b85",
        "name": "e0d",
        "node": {
          "name": "examplecluster-node01"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/626bd677-f34f-11e8-8373-
005056bb6b85"
          }
        }
      }
    ],
    "mtu": 1500,
    "_links": {
```

```
      "self": {
        "href": "/api/network/ethernet/broadcast-domains/6972416c-f34f-
11e8-8373-005056bb6b85"
      }
    }
  }
],
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/network/ethernet/broadcast-domains?fields=*"
  }
}
}
```

Retrieving a specific broadcast domain

The following output shows the response returned when a specific broadcast domain is requested. The system returns an error if there is no broadcast domain with the requested UUID.

```
# The API:
/api/network/ethernet/broadcast-domains/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ethernet/broadcast-
domains/4475a2c8-f8a0-11e8-8d33-005056bb986f/?fields=*" -H "accept:
application/hal+json"

# The response:
{
"uuid": "4475a2c8-f8a0-11e8-8d33-005056bb986f",
"name": "Cluster",
"ipspace": {
  "uuid": "3e518ed5-f8a0-11e8-8d33-005056bb986f",
  "name": "Cluster",
  "_links": {
    "self": {
      "href": "/api/network/ipspaces/3e518ed5-f8a0-11e8-8d33-005056bb986f"
    }
  }
},
"ports": [
  {
```

```
    "uuid": "3e539a62-f8a0-11e8-8d33-005056bb986f",
    "name": "e0a",
    "node": {
      "name": "examplecluster-node01"
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/3e539a62-f8a0-11e8-8d33-
005056bb986f"
      }
    }
  },
  {
    "uuid": "3e53c94a-f8a0-11e8-8d33-005056bb986f",
    "name": "e0b",
    "node": {
      "name": "examplecluster-node01"
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/3e53c94a-f8a0-11e8-8d33-
005056bb986f"
      }
    }
  }
],
"mtu": 9000,
"_links": {
  "self": {
    "href": "/api/network/ethernet/broadcast-domains/4475a2c8-f8a0-11e8-
8d33-005056bb986f/"
  }
}
}
```

Retrieving all broadcast domains with a specific name

The following output shows the response returned when broadcast domains with a specific name in any IPspace are requested.

```
# The API:
/api/network/ethernet/broadcast-domains

# The call:
curl -X GET "https://10.224.87.121/api/network/ethernet/broadcast-
domains/?name=bd1" -H "accept: application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "66b607e5-4bee-11e9-af6a-005056bb13c0",
    "name": "bd1",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/broadcast-domains/66b607e5-4bee-
11e9-af6a-005056bb13c0"
      }
    }
  }
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/network/ethernet/broadcast-domains/?name=bd1"
  }
}
}
```

Retrieving the broadcast domains for an IPspace

The following output shows the response returned when the broadcast domains for a specified IPspace are requested.

```
# The API:
/api/network/ethernet/broadcast-domains

# The call:
curl -X GET "https://10.224.87.121/api/network/ethernet/broadcast-
domains/?ipspace.name=Cluster&fields=*" -H "accept: application/hal+json"

# The response:
```

```
{
"records": [
  {
    "uuid": "ae69070c-4bed-11e9-af6a-005056bb13c0",
    "name": "Cluster",
    "ipspace": {
      "uuid": "ac466a88-4bed-11e9-af6a-005056bb13c0",
      "name": "Cluster",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/ac466a88-4bed-11e9-af6a-
005056bb13c0"
        }
      }
    },
    "ports": [
      {
        "uuid": "acd67884-4bed-11e9-af6a-005056bb13c0",
        "name": "e0a",
        "node": {
          "name": "examplecluster-node-1"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/acd67884-4bed-11e9-af6a-
005056bb13c0"
          }
        }
      },
      {
        "uuid": "ace1a36f-4bed-11e9-af6a-005056bb13c0",
        "name": "e0b",
        "node": {
          "name": "examplecluster-node-1"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/ace1a36f-4bed-11e9-af6a-
005056bb13c0"
          }
        }
      }
    ],
    "mtu": 1500,
    "_links": {
      "self": {
```

```
        "href": "/api/network/ethernet/broadcast-domains/ae69070c-4bed-
11e9-af6a-005056bb13c0"
      }
    }
  }
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/network/ethernet/broadcast-
domains/?ipspace.name=Cluster&fields=*"
  }
}
}
```

Creating network Ethernet broadcast domains

You can use the POST API to create broadcast domains.

Example

Creating a new broadcast domain

The following example shows how to create a broadcast domain with a name of 'bd1' and an MTU of 1500.

```
# The API:
/api/network/ethernet/broadcast-domains

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ethernet/broadcast-
domains?return_records=true" -H "accept: application/hal+json" -d '{
"name": "bd1", "mtu": 1500 }'

# The response:
{
"num_records": 1,
"records": [
  {
    "name": "bd1",
    "mtu": 1500,
    "_links": {
      "self": {
        "href": "/api/network/ethernet/broadcast-domains/"
      }
    }
  }
]
}
```

Updating network Ethernet broadcast domains

You can use the PATCH API to update the attributes of broadcast domains.

Examples

Updating the name and MTU of a specific broadcast domain

The following example shows how the PATCH request changes the broadcast domain name to 'bd2' and the broadcast domain MTU to 9000.

```
# The API:
/api/network/ethernet/broadcast-domains/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ethernet/broadcast-
domains/6cde03b2-f8a2-11e8-8d33-005056bb986f/" -d '{ "name": "bd2", "mtu":
9000 }'
{
}
```

Updating the IPspace of a specific broadcast domain

The following example shows how the PATCH request changes the IPspace of a broadcast domain to 'ipspace2'.

```
# The API:
/api/network/ethernet/broadcast-domains/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ethernet/broadcast-
domains/c6fe2541-61f4-11e9-a66e-005056bbe83e" -d '{ "ipspace" : { "name" :
"ipspace2" } }'
{
}
```

Deleting network Ethernet broadcast domains

You can use the DELETE API to delete a broadcast domain from the cluster configuration.

Example

Deleting a specific broadcast domain

The following DELETE request deletes a broadcast domain.

```
# The API:
/api/network/ethernet/broadcast-domains/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/network/ethernet/broadcast-
domains/6cde03b2-f8a2-11e8-8d33-005056bb986f/"
```

Retrieve broadcast domains for the entire cluster

GET `/network/ethernet/broadcast-domains`

Introduced In: 9.6

Retrieves a collection of broadcast domains for the entire cluster.

Related ONTAP commands

- `network port broadcast-domain show`

Parameters

Name	Type	In	Required	Description
uuid	string	query	False	Filter by uuid
ipspace.name	string	query	False	Filter by ipspace.name
ipspace.uuid	string	query	False	Filter by ipspace.uuid
ports.node.name	string	query	False	Filter by ports.node.name
ports.uuid	string	query	False	Filter by ports.uuid
ports.name	string	query	False	Filter by ports.name
name	string	query	False	Filter by name
mtu	integer	query	False	Filter by mtu • Min value: 68

Name	Type	In	Required	Description
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Min value: 0 • Default value: 15 • Max value: 120
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[broadcast_domain]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "ipspace": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "mtu": 1500,
      "name": "bd1",
      "ports": [
        {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "e1b",
          "node": {
            "name": "node1"
          },
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      ],
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
```

```
  ]
}
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

node

Name	Type	Description
name	string	Name of node on which the port is located.

ports

Port UUID along with readable names

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

broadcast_domain

Set of ports that will receive a broadcast Ethernet packet from any of them

Name	Type	Description
_links	_links	
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.
mtu	integer	Maximum transmission unit, largest packet size on this network
name	string	Name of the broadcast domain, scoped to its IPspace
ports	array[ports]	Ports that belong to the broadcast domain
uuid	string	Broadcast domain UUID

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create a new broadcast domain

POST `/network/ethernet/broadcast-domains`

Introduced In: 9.6

Creates a new broadcast domain.

Required properties

- `name` - Name of the broadcast-domain to create.
- `mtu` - Maximum transmission unit (MTU) of the broadcast domain.

Recommended optional properties

- `ipspace.name` or `ipspace.uuid` - IPspace the broadcast domain belongs to.

Default property values

If not specified in POST, the following default property values are assigned:

- `ipspace` - *Default*

Related ONTAP commands

- `network port broadcast-domain create`

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.
mtu	integer	Maximum transmission unit, largest packet size on this network
name	string	Name of the broadcast domain, scoped to its IPspace
ports	array[ports]	Ports that belong to the broadcast domain

Name	Type	Description
uuid	string	Broadcast domain UUID

Example request

```
{
  "ipspace": {
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "mtu": 1500,
  "name": "bd1",
  "ports": [
    {
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ],
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

```
Status: 201, Created
```

Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1377267	The specified IPspace does not exist.
1377596	The Cluster IPspace cannot contain more than one broadcast domain. Modifying the system IPspace Cluster is not supported.
1966460	The provided MTU was either too large or too small.
1967082	The specified ipspace.name does not match the IPspace name of ipspace.uuid.
1967102	A POST operation might have left the configuration in an inconsistent state. Check the configuration.
1967104	Invalid IPspace UUID.
53281982	The specified broadcast domain name is reserved by the system.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

node

Name	Type	Description
name	string	Name of node on which the port is located.

ports

Port UUID along with readable names

Name	Type	Description
name	string	
node	node	
uuid	string	

broadcast_domain

Set of ports that will receive a broadcast Ethernet packet from any of them

Name	Type	Description
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.
mtu	integer	Maximum transmission unit, largest packet size on this network

Name	Type	Description
name	string	Name of the broadcast domain, scoped to its IPspace
ports	array[ports]	Ports that belong to the broadcast domain
uuid	string	Broadcast domain UUID

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete a broadcast domain

DELETE `/network/ethernet/broadcast-domains/{uuid}`

Introduced In: 9.6

Deletes a broadcast domain.

Related ONTAP commands

- `network port broadcast-domain delete`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Broadcast domain UUID

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1967103	A broadcast domain with ports cannot be deleted.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve broadcast domain details

GET `/network/ethernet/broadcast-domains/{uuid}`

Introduced In: 9.6

Retrieves details of a broadcast domain.

Related ONTAP commands

- `network port broadcast-domain show`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Broadcast domain UUID
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.
mtu	integer	Maximum transmission unit, largest packet size on this network
name	string	Name of the broadcast domain, scoped to its IPspace
ports	array[ports]	Ports that belong to the broadcast domain
uuid	string	Broadcast domain UUID

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "ipspace": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "mtu": 1500,
  "name": "bd1",
  "ports": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ],
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

node

Name	Type	Description
name	string	Name of node on which the port is located.

ports

Port UUID along with readable names

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

error_arguments

Name	Type	Description
code	string	Argument code

Name	Type	Description
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update broadcast domain properties

PATCH `/network/ethernet/broadcast-domains/{uuid}`

Introduced In: 9.6

Updates the properties of a broadcast domain.

Related ONTAP commands

- `network port broadcast-domain modify`
- `network port broadcast-domain rename`
- `network port broadcast-domain move`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Broadcast domain UUID

Request Body

Name	Type	Description
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.

Name	Type	Description
mtu	integer	Maximum transmission unit, largest packet size on this network
name	string	Name of the broadcast domain, scoped to its IPspace
ports	array[ports]	Ports that belong to the broadcast domain
uuid	string	Broadcast domain UUID

Example request

```
{
  "ipspace": {
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "mtu": 1500,
  "name": "bd1",
  "ports": [
    {
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ],
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1376484	Cannot change the MTU of a VLAN to be greater than the MTU of the port hosting it.
1377267	The specified IPspace does not exist.
1377269	Failed to lookup the specified IPspace.
1377560	Broadcast domain already exists in specified IPspace.
1377575	Remove associated subnets before deleting this broadcast domain.
1377605	Moving the system-generated broadcast domain to another IPspace is not supported.
1377609	Updates are partially complete. Updating broadcast domain attributes on some or all of the ports in the broadcast domain have failed.
1966460	The specified MTU is either too large or too small.
1967082	The specified ipspace.name does not match the IPspace name of ipspace.uuid.
1967150	The specified ipspace.uuid is not valid.
1967151	The specified ipspace.uuid and ipspace.name do not match.
1967152	Patching IPspace for a broadcast domain requires an effective cluster version of 9.7 or later.
53280884	The MTU of the broadcast domain cannot be modified on this platform.
53282013	Broadcast domain cannot be renamed because the name is reserved by the system.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

node

Name	Type	Description
name	string	Name of node on which the port is located.

ports

Port UUID along with readable names

Name	Type	Description
name	string	
node	node	
uuid	string	

broadcast_domain

Set of ports that will receive a broadcast Ethernet packet from any of them

Name	Type	Description
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input.
mtu	integer	Maximum transmission unit, largest packet size on this network

Name	Type	Description
name	string	Name of the broadcast domain, scoped to its IPspace
ports	array[ports]	Ports that belong to the broadcast domain
uuid	string	Broadcast domain UUID

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage network Ethernet ports

Manage network Ethernet ports

Overview

A port is a physical or virtual Ethernet network device. Physical ports may be combined into Link Aggregation Groups (LAGs or ifgrps), or divided into Virtual LANs (VLANs).

GET (collection), GET (instance), and PATCH APIs are available for all port types. POST and DELETE APIs are available for "lag" (ifgrp) and "vlan" port types.

Retrieving network port information

The network ports GET API retrieves and displays relevant information pertaining to the ports configured in the cluster. The API retrieves the list of all ports configured in the cluster, or specifically requested ports. The fields

returned in the response vary for different ports and configurations.

Examples

Retrieving all ports in the cluster

The following output displays the UUID, name, and port type for all ports configured in a 2-node cluster. The port types are physical, vlan, lag (ifgrp), and p-vlan (available in select environments only).

```
# The API:
/api/network/ethernet/ports

# The call:
curl -X GET "https://<mgmt-
ip>/api/network/ethernet/ports?fields=uuid,name,type" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "2d2c90c0-f70d-11e8-b145-005056bb5b8e",
    "name": "e0a",
    "type": "physical",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/2d2c90c0-f70d-11e8-b145-
005056bb5b8e"
      }
    }
  },
  {
    "uuid": "2d3004da-f70d-11e8-b145-005056bb5b8e",
    "name": "e0b",
    "type": "physical",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/2d3004da-f70d-11e8-b145-
005056bb5b8e"
      }
    }
  },
  {
    "uuid": "2d34a2cb-f70d-11e8-b145-005056bb5b8e",
    "name": "e0c",
```

```
    "type": "physical",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/2d34a2cb-f70d-11e8-b145-
005056bb5b8e"
      }
    }
  },
  {
    "uuid": "2d37189f-f70d-11e8-b145-005056bb5b8e",
    "name": "e0d",
    "type": "physical",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/2d37189f-f70d-11e8-b145-
005056bb5b8e"
      }
    }
  },
  {
    "uuid": "35de5d8b-f70d-11e8-abdf-005056bb7fc8",
    "name": "e0a",
    "type": "physical",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/35de5d8b-f70d-11e8-abdf-
005056bb7fc8"
      }
    }
  },
  {
    "uuid": "35de78cc-f70d-11e8-abdf-005056bb7fc8",
    "name": "e0b",
    "type": "physical",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/35de78cc-f70d-11e8-abdf-
005056bb7fc8"
      }
    }
  },
  {
    "uuid": "35dead3c-f70d-11e8-abdf-005056bb7fc8",
    "name": "e0c",
    "type": "physical",
    "_links": {
```

```
      "self": {
        "href": "/api/network/ethernet/ports/35dead3c-f70d-11e8-abdf-
005056bb7fc8"
      }
    }
  },
  {
    "uuid": "35deda90-f70d-11e8-abdf-005056bb7fc8",
    "name": "e0d",
    "type": "physical",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/35deda90-f70d-11e8-abdf-
005056bb7fc8"
      }
    }
  },
  {
    "uuid": "42e25145-f97d-11e8-ade9-005056bb7fc8",
    "name": "e0c-100",
    "type": "vlan",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/42e25145-f97d-11e8-ade9-
005056bb7fc8"
      }
    }
  },
  {
    "uuid": "569e0abd-f97d-11e8-ade9-005056bb7fc8",
    "name": "a0a",
    "type": "lag",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/569e0abd-f97d-11e8-ade9-
005056bb7fc8"
      }
    }
  }
],
"num_records": 10,
"_links": {
  "self": {
    "href": "/api/network/ethernet/ports?fields=uuid,name,type"
  }
}
```

```
}
```

Retrieving a specific physical port

The following output displays the response when a specific physical port is requested. The system returns an error when there is no port with the requested UUID. Also, the "speed" field for the physical port is set only if the state of the port is up.

```
# The API:
/api/network/ethernet/ports/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ethernet/ports/2d37189f-f70d-
11e8-b145-005056bb5b8e?fields=*" -H "accept: application/hal+json"

# The response:
{
"uuid": "2d37189f-f70d-11e8-b145-005056bb5b8e",
"name": "e0d",
"mac_address": "00:50:56:bb:62:2d",
"type": "physical",
"node": {
  "uuid": "faa56898-f70c-11e8-b145-005056bb5b8e",
  "name": "user-cluster-01",
  "_links": {
    "self": {
      "href": "/api/cluster/nodes/faa56898-f70c-11e8-b145-005056bb5b8e"
    }
  }
},
"broadcast_domain": {
  "uuid": "36434bec-f70d-11e8-b145-005056bb5b8e",
  "name": "Default",
  "ipspace": {
    "name": "Default"
  },
  "_links": {
    "self": {
      "href": "/api/network/ethernet/broadcast-domains/36434bec-f70d-11e8-
b145-005056bb5b8e"
    }
  }
},
```

```
"enabled": true,
"state": "up",
"mtu": 1500,
"speed": 1000,
"reachability": "not_repairable",
"reachable_broadcast_domains": [
  {
    "uuid": "36434bec-f70d-11e8-b145-005056bb5b8e",
    "name": "Default",
    "ipspace": {
      "name": "Default"
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/broadcast-domains/36434bec-f70d-
11e8-b145-005056bb5b8e"
      }
    }
  },
  {
    "uuid": "df640ccf-72c4-11ea-b31d-005056bbfb29",
    "name": "Default-1",
    "ipspace": {
      "name": "Default"
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/broadcast-domains/df640ccf-72c4-
11ea-b31d-005056bbfb29"
      }
    }
  }
],
"_links": {
  "self": {
    "href": "/api/network/ethernet/ports/2d37189f-f70d-11e8-b145-
005056bb5b8e"
  }
}
}
```

Retrieving a specific VLAN port

The following output displays the response when a specific VLAN port is requested. The system returns an error when there is no port with the requested UUID. Also, the "speed" field for a VLAN port is always set to

zero if the state of the port is up. If the state of the port is down, the "speed" field is unset and not reported back.

```
# The API:
/api/network/ethernet/ports/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ethernet/ports/42e25145-f97d-
11e8-ade9-005056bb7fc8?fields=*" -H "accept: application/hal+json"

# The response:
{
"uuid": "42e25145-f97d-11e8-ade9-005056bb7fc8",
"name": "e0e-100",
"mac_address": "00:50:56:bb:52:2f",
"type": "vlan",
"node": {
  "uuid": "6042cf47-f70c-11e8-abdf-005056bb7fc8",
  "name": "user-cluster-02",
  "_links": {
    "self": {
      "href": "/api/cluster/nodes/6042cf47-f70c-11e8-abdf-005056bb7fc8"
    }
  }
},
"broadcast_domain": {
  "uuid": "36434bec-f70d-11e8-b145-005056bb5b8e",
  "name": "Default",
  "ipspace": {
    "name": "Default"
  },
  "_links": {
    "self": {
      "href": "/api/network/ethernet/broadcast-domains/36434bec-f70d-11e8-
b145-005056bb5b8e"
    }
  }
},
"enabled": true,
"state": "up",
"mtu": 1500,
"speed": 0,
"reachability": "ok",
"reachable_broadcast_domains": [
  {
```

```
    "uuid": "36434bec-f70d-11e8-b145-005056bb5b8e",
    "name": "Default",
    "ipspace": {
      "name": "Default"
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/broadcast-domains/36434bec-f70d-
11e8-b145-005056bb5b8e"
      }
    }
  }
],
"vlan": {
  "tag": 100,
  "base_port": {
    "uuid": "35deff03-f70d-11e8-abdf-005056bb7fc8",
    "name": "e0e",
    "node": {
      "name": "user-cluster-02"
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/35deff03-f70d-11e8-abdf-
005056bb7fc8"
      }
    }
  }
},
"_links": {
  "self": {
    "href": "/api/network/ethernet/ports/42e25145-f97d-11e8-ade9-
005056bb7fc8"
  }
}
}
```

Retrieving a specific LAG port

The following output displays the response when a specific LAG port is requested. The system returns an error when there is no port with the requested UUID. The "lag.active_ports" field is set only if the state of the port is up. Also, the "speed" field for a LAG port is always set to zero if the state of the port is up. If the state of the port is down, the "speed" field is unset and not reported back.

```
# The API:
/api/network/ethernet/ports/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ethernet/ports/569e0abd-f97d-
11e8-ade9-005056bb7fc8?fields=*" -H "accept: application/hal+json"

# The response:
{
"uuid": "569e0abd-f97d-11e8-ade9-005056bb7fc8",
"name": "a0a",
"mac_address": "02:50:56:bb:7f:c8",
"type": "lag",
"node": {
  "uuid": "6042cf47-f70c-11e8-abdf-005056bb7fc8",
  "name": "user-cluster-02",
  "_links": {
    "self": {
      "href": "/api/cluster/nodes/6042cf47-f70c-11e8-abdf-005056bb7fc8"
    }
  }
},
"broadcast_domain": {
  "uuid": "36434bec-f70d-11e8-b145-005056bb5b8e",
  "name": "Default",
  "ipspace": {
    "name": "Default"
  },
  "_links": {
    "self": {
      "href": "/api/network/ethernet/broadcast-domains/36434bec-f70d-11e8-
b145-005056bb5b8e"
    }
  }
},
"enabled": true,
"state": "up",
"mtu": 1500,
"speed": 0,
"reachability": "repairable",
"reachable_broadcast_domains": [
  {
    "uuid": "c7934b4f-691f-11ea-87fd-005056bb1ad3",
    "name": "Default",
    "ipspace": {
      "name": "Default"
```

```
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/broadcast-domains/c7934b4f-691f-
11ea-87fd-005056bb1ad3"
      }
    }
  }
],
"lag": {
  "mode": "singlemode",
  "distribution_policy": "mac",
  "member_ports": [
    {
      "uuid": "35df318d-f70d-11e8-abdf-005056bb7fc8",
      "name": "e0f",
      "node": {
        "name": "user-cluster-02"
      },
      "_links": {
        "self": {
          "href": "/api/network/ethernet/ports/35df318d-f70d-11e8-abdf-
005056bb7fc8"
        }
      }
    },
    {
      "uuid": "35df5bad-f70d-11e8-abdf-005056bb7fc8",
      "name": "e0g",
      "node": {
        "name": "user-cluster-02"
      },
      "_links": {
        "self": {
          "href": "/api/network/ethernet/ports/35df5bad-f70d-11e8-abdf-
005056bb7fc8"
        }
      }
    },
    {
      "uuid": "35df9926-f70d-11e8-abdf-005056bb7fc8",
      "name": "e0h",
      "node": {
        "name": "user-cluster-02"
      },
      "_links": {
```

```
        "self": {
          "href": "/api/network/ethernet/ports/35df9926-f70d-11e8-abdf-
005056bb7fc8"
        }
      }
    }
  ],
  "active_ports": [
    {
      "uuid": "35df318d-f70d-11e8-abdf-005056bb7fc8",
      "name": "e0f",
      "_links": {
        "self": {
          "href": "/api/network/ethernet/ports/35df318d-f70d-11e8-abdf-
005056bb7fc8"
        }
      }
    }
  ]
},
"_links": {
  "self": {
    "href": "/api/network/ethernet/ports/569e0abd-f97d-11e8-ade9-
005056bb7fc8"
  }
}
}
```

Retrieving all LAG (ifgrp) ports in the cluster

This command retrieves all LAG ports in the cluster (that is, all ports with type=LAG). The example shows how to filter a GET collection based on type.

```
# The API:
/api/network/ethernet/ports

# The call:
curl -X GET "https://<mgmt-
ip>/api/network/ethernet/ports?type=lag&node.name=user-cluster-
01&fields=name,enabled,speed,mtu" -H  "accept: application/hal+json"

# The response:
{
```

```
"records": [
  {
    "uuid": "0c226db0-4b63-11e9-8113-005056bbe040",
    "name": "a0b",
    "type": "lag",
    "node": {
      "name": "user-cluster-01"
    },
    "enabled": true,
    "mtu": 1500,
    "speed": 0,
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/0c226db0-4b63-11e9-8113-
005056bbe040"
      }
    }
  },
  {
    "uuid": "d3a84153-4b3f-11e9-a00d-005056bbe040",
    "name": "a0a",
    "type": "lag",
    "node": {
      "name": "user-cluster-01"
    },
    "enabled": true,
    "mtu": 1500,
    "speed": 0,
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/d3a84153-4b3f-11e9-a00d-
005056bbe040"
      }
    }
  }
],
"num_records": 2,
"_links": {
  "self": {
    "href":
"/api/network/ethernet/ports?fields=name,enabled,speed,mtu&type=lag&node.n
ame=user-cluster-01"
  }
}
}
```

Creating VLAN and LAG ports

You can use the network ports POST API to create VLAN and LAG ports. If you supply the optional broadcast domain property, the specified broadcast domain will be assigned to the new port immediately. Otherwise, within a few minutes automatic probing will determine the correct broadcast domain and will assign it to the port. During that period of time, the port will not be capable of hosting interfaces.

Examples

Creating a VLAN port

The following output displays the record returned after the creation of a VLAN port on "e0e" and VLAN tag "100".

```
# The API:
/api/network/ethernet/ports

# The call:
curl -X POST "https://<mgmt-
ip>/api/network/ethernet/ports?return_records=true" -H "accept:
application/hal+json" -H "Content-Type: application/json" -d "{ \"type\":
\"vlan\", \"node\": { \"name\": \"user-cluster-01\" }, \"enabled\": true,
\"vlan\": { \"tag\": 100, \"base_port\": { \"name\": \"e0e\", \"node\": {
\"name\": \"user-cluster-01\" } } }}"

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "88b2f682-fa42-11e8-a6d7-005056bb5b8e",
    "type": "vlan",
    "node": {
      "uuid": "faa56898-f70c-11e8-b145-005056bb5b8e",
      "name": "user-cluster-01",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/faa56898-f70c-11e8-b145-
005056bb5b8e"
        }
      }
    },
    "enabled": true,
    "vlan": {
      "tag": 100,
```

```
      "base_port": {
        "uuid": "2d39df72-f70d-11e8-b145-005056bb5b8e",
        "name": "e0e",
        "node": {
          "name": "user-cluster-01"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/2d39df72-f70d-11e8-b145-
005056bb5b8e"
          }
        }
      }
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/88b2f682-fa42-11e8-a6d7-
005056bb5b8e"
      }
    }
  }
]
}
```

Creating a VLAN port in a specific broadcast domain

The following output displays the record returned after the creation of a VLAN port on "e0e" and VLAN tag "100". Also, the VLAN port is added to the "Default" broadcast domain in the "Default" IPspace.

```
# The API:
/api/network/ethernet/ports

# The call:
curl -X POST "https://<mgmt-
ip>/api/network/ethernet/ports?return_records=true" -H "accept:
application/hal+json" -H "Content-Type: application/json" -d "{
\"type\": \"vlan\", \"node\": { \"name\": \"user-cluster-01\" },
\"broadcast_domain\": { \"name\": \"Default\", \"ipspace\": { \"name\":
\"Default    \" } }, \"enabled\": true, \"vlan\": { \"tag\": 100,
\"base_port\": { \"name\": \"e0e\", \"node\": { \"name\": \"user-cluster-
01\" } } }}"

# The response:
```

```
{
"num_records": 1,
"records": [
  {
    "uuid": "88b2f682-fa42-11e8-a6d7-005056bb5b8e",
    "type": "vlan",
    "node": {
      "uuid": "faa56898-f70c-11e8-b145-005056bb5b8e",
      "name": "user-cluster-01",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/faa56898-f70c-11e8-b145-
005056bb5b8e"
        }
      }
    },
    "broadcast_domain": {
      "uuid": "36434bec-f70d-11e8-b145-005056bb5b8e",
      "name": "Default",
      "ipspace": {
        "name": "Default"
      },
      "_links": {
        "self": {
          "href": "/api/network/ethernet/broadcast-domains/36434bec-f70d-
11e8-b145-005056bb5b8e"
        }
      }
    },
    "enabled": true,
    "vlan": {
      "tag": 100,
      "base_port": {
        "uuid": "2d39df72-f70d-11e8-b145-005056bb5b8e",
        "name": "e0e",
        "node": {
          "name": "user-cluster-01"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/2d39df72-f70d-11e8-b145-
005056bb5b8e"
          }
        }
      }
    },
```

```
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/88b2f682-fa42-11e8-a6d7-
005056bb5b8e"
      }
    }
  }
]
}
```

Creating a LAG (ifgrp) port

The following output displays the record returned after the creation of a LAG port with "e0f", "e0g" and "e0h" as member ports.

```
# The API:
/api/network/ethernet/ports

# The call:
curl -X POST "https://<mgmt-
ip>/api/network/ethernet/ports?return_records=true" -H  "accept:
application/json" -H  "Content-Type: application/json" -d "{  \"type\":
\"lag\",  \"node\": { \"name\": \"user-cluster-01\"  }, \"enabled\": true,
\"lag\": { \"mode\": \"singlemode\", \"distribution_policy\": \"mac\",
\"member_ports\": [ { \"name\": \"e0f\", \"node\": { \"name\": \"user-
cluster-01\" } }, { \"name\": \"e0g\", \"node\": { \"name\": \"user-
cluster-01\" }}, { \"name\": \"e0h\", \"node\": { \"name\": \"user-
cluster-01\" } } ]  } }"

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "1807772a-fa4d-11e8-a6d7-005056bb5b8e",
    "type": "lag",
    "node": {
      "uuid": "faa56898-f70c-11e8-b145-005056bb5b8e",
      "name": "user-cluster-01"
    },
    "enabled": true,
    "lag": {
      "mode": "singlemode",
```

```
      "distribution_policy": "mac",
      "member_ports": [
        {
          "uuid": "2d3c9adc-f70d-11e8-b145-005056bb5b8e",
          "name": "e0f",
          "node": {
            "name": "user-cluster-01"
          }
        },
        {
          "uuid": "2d40b097-f70d-11e8-b145-005056bb5b8e",
          "name": "e0g",
          "node": {
            "name": "user-cluster-01"
          }
        },
        {
          "uuid": "2d46d01e-f70d-11e8-b145-005056bb5b8e",
          "name": "e0h",
          "node": {
            "name": "user-cluster-01"
          }
        }
      ]
    }
  }
]
}
```

Creating a LAG (ifgrp) port in a specific broadcast domain

The following output displays the record returned after the creation of a LAG port with "e0f", "e0g" and "e0h" as member ports. Also, the LAG port is added to the "Default" broadcast domain in the "Default" IPspace.

```
# The API:
/api/network/ethernet/ports

# The call:
curl -X POST "https://<mgmt-
ip>/api/network/ethernet/ports?return_records=true" -H  "accept:
application/json" -H  "Content-Type: application/json" -d "{  \"type\":
\"lag\",  \"node\": { \"name\": \"user-cluster-01\"  },
\"broadcast_domain\": { \"name\": \"Default\", \"ipspace\": { \"name\":
```

```
\"Default\" } }, \"enabled\": true, \"lag\": { \"mode\": \"singlemode\",
\"distribution_policy\": \"mac\", \"member_ports\": [ { \"name\": \"e0f\",
\"node\": { \"name\": \"user-cluster-01\" } }, { \"name\": \"e0g\",
\"node\": { \"name\": \"user-cluster-01\" }}, { \"name\": \"e0h\",
\"node\": { \"name\": \"user-cluster-01\" } } ]  } }"

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "1807772a-fa4d-11e8-a6d7-005056bb5b8e",
    "type": "lag",
    "node": {
      "uuid": "faa56898-f70c-11e8-b145-005056bb5b8e",
      "name": "user-cluster-01"
    },
    "broadcast_domain": {
      "uuid": "36434bec-f70d-11e8-b145-005056bb5b8e",
      "name": "Default",
      "ipspace": {
        "name": "Default"
      }
    },
    "enabled": true,
    "lag": {
      "mode": "singlemode",
      "distribution_policy": "mac",
      "member_ports": [
        {
          "uuid": "2d3c9adc-f70d-11e8-b145-005056bb5b8e",
          "name": "e0f",
          "node": {
            "name": "user-cluster-01"
          }
        },
        {
          "uuid": "2d40b097-f70d-11e8-b145-005056bb5b8e",
          "name": "e0g",
          "node": {
            "name": "user-cluster-01"
          }
        },
        {
          "uuid": "2d46d01e-f70d-11e8-b145-005056bb5b8e",
          "name": "e0h",
```

```
          "node": {
            "name": "user-cluster-01"
          }
        }
      ]
    }
  }
]
}
```

Updating ports

You can use the network ports PATCH API to update the attributes of ports.

Examples

Updating the broadcast domain of a port

The following PATCH request removes the port from the current broadcast domain and adds it to the specified broadcast domain.

```
# The API:
/api/network/ethernet/ports/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ethernet/ports/6867efaf-d702-
11e8-994f-005056bbc994" -H  "accept: application/hal+json" -H  "Content-
Type: application/json" -d "{ \"broadcast_domain\": { \"name\":
\"Default\", \"ipspace\": { \"name\": \"Default\" }}}"
```

Updating the admin status of a port

The following PATCH request brings the specified port down.

```
# The API:
/api/network/ethernet/ports/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ethernet/ports/51d3ab39-d86d-
11e8-aca6-005056bbc994" -H  "accept: application/hal+json" -H  "Content-
Type: application/json" -d "{ \"enabled\": \"false\" }"
```

Repairing a port

The following PATCH request repairs a port. Only ports that have reachability as "repairable" can be repaired. The "reachability" parameter cannot be patched in the same request as other parameters that might affect the target port's reachability status.

```
# The API:
/api/network/ethernet/ports/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ethernet/ports/51d3ab39-d86d-
11e8-aca6-005056bbc994" -H  "accept: application/hal+json" -H  "Content-
Type: application/json" -d "{ \"reachability\": \"ok\" }"
```

Deleting ports

You can use the network ports DELETE API to delete VLAN and LAG ports in the cluster. Note that physical ports cannot be deleted. Deleting a port also removes the port from the broadcast domain.

Example

Deleting a VLAN port

The network ports DELETE API is used to delete a VLAN port.

```
# The API:
/api/network/ethernet/ports/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/network/ethernet/ports/6867efaf-
d702-11e8-994f-005056bbc994" -H  "accept: application/hal+json" -H
"Content-Type: application/json"
```

Retrieve ports

GET `/network/ethernet/ports`

Introduced In: 9.6

Retrieves a collection of ports (physical, VLAN and LAG) for an entire cluster.

Related ONTAP commands

- `network port show`
- `network port ifgrp show`
- `network port vlan show`

Parameters

Name	Type	In	Required	Description
state	string	query	False	Filter by state
name	string	query	False	Filter by name
mac_address	string	query	False	Filter by mac_address
speed	integer	query	False	Filter by speed
statistics.timestamp	string	query	False	Filter by statistics.timestamp • Introduced in: 9.8

Name	Type	In	Required	Description
statistics.device.timestamp	string	query	False	Filter by statistics.device.timestamp • Introduced in: 9.8
statistics.device.receive_raw.discards	integer	query	False	Filter by statistics.device.receive_raw.discards • Introduced in: 9.8
statistics.device.receive_raw.errors	integer	query	False	Filter by statistics.device.receive_raw.errors • Introduced in: 9.8
statistics.device.receive_raw.packets	integer	query	False	Filter by statistics.device.receive_raw.packets • Introduced in: 9.8
statistics.device.transmit_raw.discards	integer	query	False	Filter by statistics.device.transmit_raw.discards • Introduced in: 9.8
statistics.device.transmit_raw.errors	integer	query	False	Filter by statistics.device.transmit_raw.errors • Introduced in: 9.8
statistics.device.transmit_raw.packets	integer	query	False	Filter by statistics.device.transmit_raw.packets • Introduced in: 9.8

Name	Type	In	Required	Description
statistics.device.link_down_count_raw	integer	query	False	Filter by statistics.device.link_down_count_raw • Introduced in: 9.8
statistics.status	string	query	False	Filter by statistics.status • Introduced in: 9.8
statistics.throughput_raw.write	integer	query	False	Filter by statistics.throughput_raw.write • Introduced in: 9.8
statistics.throughput_raw.read	integer	query	False	Filter by statistics.throughput_raw.read • Introduced in: 9.8
statistics.throughput_raw.total	integer	query	False	Filter by statistics.throughput_raw.total • Introduced in: 9.8
lag.active_ports.node.name	string	query	False	Filter by lag.active_ports.node.name
lag.active_ports.uuid	string	query	False	Filter by lag.active_ports.uuid
lag.active_ports.name	string	query	False	Filter by lag.active_ports.name
lag.distribution_policy	string	query	False	Filter by lag.distribution_policy

Name	Type	In	Required	Description
lag.mode	string	query	False	Filter by lag.mode
lag.member_ports.node.name	string	query	False	Filter by lag.member_ports.node.name
lag.member_ports.uuid	string	query	False	Filter by lag.member_ports.uuid
lag.member_ports.name	string	query	False	Filter by lag.member_ports.name
type	string	query	False	Filter by type
node.name	string	query	False	Filter by node.name
node.uuid	string	query	False	Filter by node.uuid
reachability	string	query	False	Filter by reachability • Introduced in: 9.8
enabled	boolean	query	False	Filter by enabled
interface_count	integer	query	False	Filter by interface_count • Introduced in: 9.11
vlan.base_port.node.name	string	query	False	Filter by vlan.base_port.node.name
vlan.base_port.uuid	string	query	False	Filter by vlan.base_port.uuid
vlan.base_port.name	string	query	False	Filter by vlan.base_port.name

Name	Type	In	Required	Description
vlan.tag	integer	query	False	Filter by vlan.tag • Max value: 4094 • Min value: 1
metric.status	string	query	False	Filter by metric.status • Introduced in: 9.8
metric.duration	string	query	False	Filter by metric.duration • Introduced in: 9.8
metric.timestamp	string	query	False	Filter by metric.timestamp • Introduced in: 9.8
metric.throughput.write	integer	query	False	Filter by metric.throughput.write • Introduced in: 9.8
metric.throughput.read	integer	query	False	Filter by metric.throughput.read • Introduced in: 9.8
metric.throughput.total	integer	query	False	Filter by metric.throughput.total • Introduced in: 9.8
uuid	string	query	False	Filter by uuid

Name	Type	In	Required	Description
broadcast_domain.name	string	query	False	Filter by broadcast_domain.name
broadcast_domain.uuid	string	query	False	Filter by broadcast_domain.uuid
broadcast_domain.ipspace.name	string	query	False	Filter by broadcast_domain.ipspace.name
mtu	integer	query	False	Filter by mtu • Min value: 68
discovered_devices.remaining_hold_time	integer	query	False	Filter by discovered_devices.remaining_hold_time • Introduced in: 9.11
discovered_devices.protocol	string	query	False	Filter by discovered_devices.protocol • Introduced in: 9.11
discovered_devices.version	string	query	False	Filter by discovered_devices.version • Introduced in: 9.11
discovered_devices.ip_addresses	string	query	False	Filter by discovered_devices.ip_addresses • Introduced in: 9.11

Name	Type	In	Required	Description
discovered_devices.chassis_id	string	query	False	Filter by discovered_devices.chassis_id • Introduced in: 9.11
discovered_devices.capabilities	string	query	False	Filter by discovered_devices.capabilities • Introduced in: 9.11
discovered_devices.platform	string	query	False	Filter by discovered_devices.platform • Introduced in: 9.11
discovered_devices.remote_port	string	query	False	Filter by discovered_devices.remote_port • Introduced in: 9.11
discovered_devices.system_name	string	query	False	Filter by discovered_devices.system_name • Introduced in: 9.11
discovered_devices.name	string	query	False	Filter by discovered_devices.name • Introduced in: 9.11
reachable_broadcast_domains.name	string	query	False	Filter by reachable_broadcast_domains.name • Introduced in: 9.8

Name	Type	In	Required	Description
reachable_broadcast_domains.uuid	string	query	False	Filter by reachable_broadcast_domains.uuid • Introduced in: 9.8
reachable_broadcast_domains.ipspace.name	string	query	False	Filter by reachable_broadcast_domains.ipspace.name • Introduced in: 9.8
pfc_queues_admin	integer	query	False	Filter by pfc_queues_admin • Introduced in: 9.16 • Max value: 7 • Min value: 0
flowcontrol_admin	string	query	False	Filter by flowcontrol_admin • Introduced in: 9.16
rdma_protocols	string	query	False	Filter by rdma_protocols • Introduced in: 9.10
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Max value: 120 • Min value: 0 • Default value: 15
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[port]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "broadcast_domain": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "ipspace": {
          "name": "ipspace1"
        },
        "name": "bd1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "discovered_devices": [
        {
          "capabilities": [
            "router",
            "switch"
          ],
          "chassis_id": "string",
          "ip_addresses": [
            "192.168.100.24",
            "192.168.100.26"
          ],
          "name": "ETY-R1S4-510Q13.datacenter.example.com",
          "platform": "93180YC-EX",
          "protocol": "cdp",
          "remote_port": "FastEthernet0/12",
```

```
          "system_name": "string",
          "version": "Cisco Nexus Operating System (NX-OS) Software,
Version 8.1"
        }
      ],
      "flowcontrol_admin": "string",
      "interface_count": 0,
      "lag": {
        "active_ports": [
          {
            "_links": {
              "self": {
                "href": "/api/resourcelink"
              }
            },
            "name": "e1b",
            "node": {
              "name": "node1"
            },
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
          }
        ],
        "distribution_policy": "string",
        "member_ports": [
          {
            "_links": {
              "self": {
                "href": "/api/resourcelink"
              }
            },
            "name": "e1b",
            "node": {
              "name": "node1"
            },
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
          }
        ],
        "mode": "string"
      },
      "mac_address": "01:02:03:04:05:06",
      "metric": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
```

```
      "duration": "PT15S",
      "status": "ok",
      "throughput": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000"
    },
    "mtu": 1500,
    "name": "e1b",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "pfc_queues_admin": [
      "integer"
    ],
    "rdma_protocols": [
      "roce"
    ],
    "reachability": "ok",
    "reachable_broadcast_domains": [
      {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "ipspace": {
          "name": "ipspace1"
        },
        "name": "bd1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    ],
    "speed": 1000,
    "state": "string",
    "statistics": {
      "device": {
        "link_down_count_raw": 3,
```

```
          "receive_raw": {
            "discards": 100,
            "errors": 200,
            "packets": 500
          },
          "timestamp": "2017-01-25 11:20:13 +0000",
          "transmit_raw": {
            "discards": 100,
            "errors": 200,
            "packets": 500
          }
        },
        "status": "ok",
        "throughput_raw": {
          "read": 200,
          "total": 1000,
          "write": 100
        },
        "timestamp": "2017-01-25 11:20:13 +0000"
      },
      "type": "string",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
      "vlan": {
        "base_port": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "e1b",
          "node": {
            "name": "node1"
          },
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "tag": 100
      }
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

ipspace

Name	Type	Description
name	string	Name of the broadcast domain's IPspace

broadcast_domain

Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.

Name	Type	Description
_links	_links	
ipspace	ipspace	
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

discovered_devices

Name	Type	Description
capabilities	array[string]	The list of the capabilities of the discovered device.

Name	Type	Description
chassis_id	string	Identifier associated with this specific discovered device, useful for locating the device in a data center.
ip_addresses	array[string]	The IP addresses on the discovered device.
name	string	Name of the discovered device.
platform	string	Hardware platform of the discovered device.
protocol	string	The protocol used to identify the discovered device. This can have a value of CDP or LLDP.
remaining_hold_time	integer	The number of seconds until the discovered device entry expires and is removed.
remote_port	string	The name of the remote port on the discovered device. The format is dependent on the reporting device.
system_name	string	Additional name used to identify a specific piece of equipment.
version	string	The version of the software running on the discovered device.

node

Name	Type	Description
name	string	Name of node on which the port is located.

active_ports

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	

Name	Type	Description
node	node	
uuid	string	

member_ports

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

lag

Name	Type	Description
active_ports	array[active_ports]	Active ports of a LAG (ifgrp). (Some member ports may be inactive.)
distribution_policy	string	Policy for mapping flows to ports for outbound packets through a LAG (ifgrp).
member_ports	array[member_ports]	Array of ports belonging to the LAG, regardless of their state.
mode	string	Determines how the ports interact with the switch.

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

The most recent sample of I/O metrics for the port.

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.

node

Name	Type	Description
_links	_links	

Name	Type	Description
name	string	
uuid	string	

reachable_broadcast_domains

Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.

Name	Type	Description
_links	_links	
ipspace	ipspace	
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

receive_raw

Packet receive counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

transmit_raw

Packet transmit counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

device

Device-related counters for the port object. These counters are applicable at the lowest layer of the

networking stack. These values can be used to calculate both transmit and receive packet and error rates by comparing two samples taken at different times and calculating the increase in counter value divided by the elapsed time between the two samples.

Name	Type	Description
link_down_count_raw	integer	The number of link state changes from up to down seen on the device.
receive_raw	receive_raw	Packet receive counters for the Ethernet port.
timestamp	string	The timestamp when the device specific counters were collected.
transmit_raw	transmit_raw	Packet transmit counters for the Ethernet port.

throughput_raw

Throughput bytes observed at the port object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

The real time I/O statistics for the port.

Name	Type	Description
device	device	Device-related counters for the port object. These counters are applicable at the lowest layer of the networking stack. These values can be used to calculate both transmit and receive packet and error rates by comparing two samples taken at different times and calculating the increase in counter value divided by the elapsed time between the two samples.
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the port object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the throughput_raw performance data.

base_port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

vlan

Name	Type	Description
base_port	base_port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.
tag	integer	VLAN ID

port

Name	Type	Description
_links	_links	
broadcast_domain	broadcast_domain	Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.
discovered_devices	array[discovered_devices]	Discovered devices
enabled	boolean	
flowcontrol_admin	string	Requested flow control
interface_count	integer	Number of interfaces hosted. This field is only applicable for cluster administrators. No value is returned for SVM administrators. If the node hosting a port is not healthy no value will be returned.
lag	lag	
mac_address	string	
metric	metric	The most recent sample of I/O metrics for the port.

Name	Type	Description
mtu	integer	MTU of the port in bytes. Set by broadcast domain.
name	string	Portname, such as e0a, e1b-100 (VLAN on Ethernet), a0c (LAG/ifgrp), a0d-200 (VLAN on LAG/ifgrp), e0a.pv1 (p-VLAN, in select environments only)
node	node	
pfc_queues_admin	array[integer]	List of PFC queues
rdma_protocols	array[string]	Supported RDMA offload protocols
reachability	string	Reachability status of the port. Enum value "ok" is the only acceptable value for a PATCH request to repair a port.
reachable_broadcast_domains	array[reachable_broadcast_domains]	Reachable broadcast domains.
speed	integer	Link speed in Mbps
state	string	Operational state of the port. The state is set to 'down' if the operational state of the port is down. The state is set to 'up' if the link state of the port is up and the port is healthy. The state is set to 'up' if the link state of the port is up and configured to ignore health status. The state is 'degraded' if the link state of the port is up, and the port is not healthy.
statistics	statistics	The real time I/O statistics for the port.
type	string	Type of physical or virtual port
uuid	string	Port UUID
vlan	vlan	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create a new VLAN or LAG

POST `/network/ethernet/ports`

Introduced In: 9.6

Creates a new VLAN (such as node1:e0a-100) or LAG (ifgrp, such as node2:a0a).

Required properties

- `node` - Node the port will be created on.
- `vlan` - This field cannot be specified at the same time as `lag`.
  - `vlan.base_port` - Physical port or LAG the VLAN will be created on.
  - `vlan.tag` - Tag used to identify VLAN on the base port.
- `lag` - This field cannot be specified at the same time as `vlan`.
  - `lag.mode` - Policy for the LAG that will be created.
  - `lag.distribution_policy` - Indicates how the packets are distributed between ports.
  - `lag.member_ports` - Set of ports the LAG consists of.

Optional properties

- `type` - Defines if a VLAN or LAG will be created:
- `broadcast_domain` - The layer-2 broadcast domain the port is associated with. The port will be placed in a broadcast domain if it is not specified. It may take several minutes for the broadcast domain to be assigned. During that period the port cannot host interfaces.

Related ONTAP commands

- `network port ifgrp create`
- `network port vlan create`

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
broadcast_domain	broadcast_domain	Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.
discovered_devices	array[discovered_devices]	Discovered devices
enabled	boolean	
interface_count	integer	Number of interfaces hosted. This field is only applicable for cluster administrators. No value is returned for SVM administrators. If the node hosting a port is not healthy no value will be returned.
lag	lag	
mac_address	string	
mtu	integer	MTU of the port in bytes. Set by broadcast domain.
name	string	Portname, such as e0a, e1b-100 (VLAN on Ethernet), a0c (LAG/ifgrp), a0d-200 (VLAN on LAG/ifgrp), e0a.pv1 (p-VLAN, in select environments only)
node	node	
rdma_protocols	array[string]	Supported RDMA offload protocols

Name	Type	Description
reachable_broadcast_domains	array[reachable_broadcast_domains]	Reachable broadcast domains.
speed	integer	Link speed in Mbps
state	string	Operational state of the port. The state is set to 'down' if the operational state of the port is down. The state is set to 'up' if the link state of the port is up and the port is healthy. The state is set to 'up' if the link state of the port is up and configured to ignore health status. The state is 'degraded' if the link state of the port is up, and the port is not healthy.
type	string	Type of physical or virtual port
uuid	string	Port UUID
vlan	vlan	

Example request


```
{
  "broadcast_domain": {
    "ipspace": {
      "name": "ipspace1"
    },
    "name": "bd1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "discovered_devices": [
    {
      "capabilities": [
        "router",
        "switch"
      ],
      "chassis_id": "string",
      "ip_addresses": [
        "192.168.100.24",
        "192.168.100.26"
      ],
      "name": "ETY-R1S4-510Q13.datacenter.example.com",
      "platform": "93180YC-EX",
      "protocol": "cdp",
      "remote_port": "FastEthernet0/12",
      "system_name": "string",
      "version": "Cisco Nexus Operating System (NX-OS) Software,
Version 8.1"
    }
  ],
  "interface_count": 0,
  "lag": {
    "active_ports": [
      {
        "name": "e1b",
        "node": {
          "name": "node1"
        },
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    ],
    "distribution_policy": "string",
    "member_ports": [
      {
        "name": "e1b",
        "node": {
```

```
            "name": "node1"
          },
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      ],
      "mode": "string"
    },
    "mac_address": "01:02:03:04:05:06",
    "mtu": 1500,
    "name": "e1b",
    "node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "rdma_protocols": [
      "roce"
    ],
    "reachable_broadcast_domains": [
      {
        "ipspace": {
          "name": "ipspace1"
        },
        "name": "bd1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    ],
    "speed": 1000,
    "state": "string",
    "type": "string",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
    "vlan": {
      "base_port": {
        "name": "e1b",
        "node": {
          "name": "node1"
        },
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "tag": 100
    }
}
```


Response

```
Status: 201, Created
```

Name	Type	Description
num_records	integer	Number of records
records	array[port]	

Example response


```
{
  "num_records": 1,
  "records": [
    {
      "broadcast_domain": {
        "ipspace": {
          "name": "ipspace1"
        },
        "name": "bd1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "discovered_devices": [
        {
          "capabilities": [
            "router",
            "switch"
          ],
          "chassis_id": "string",
          "ip_addresses": [
            "192.168.100.24",
            "192.168.100.26"
          ],
          "name": "ETY-R1S4-510Q13.datacenter.example.com",
          "platform": "93180YC-EX",
          "protocol": "cdp",
          "remote_port": "FastEthernet0/12",
          "system_name": "string",
          "version": "Cisco Nexus Operating System (NX-OS) Software,
Version 8.1"
        }
      ],
      "interface_count": 0,
      "lag": {
        "active_ports": [
          {
            "name": "e1b",
            "node": {
              "name": "node1"
            },
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
          }
        ],
        "distribution_policy": "string",
        "member_ports": [
```

```
          {
            "name": "e1b",
            "node": {
              "name": "node1"
            },
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
          }
        ],
        "mode": "string"
      },
      "mac_address": "01:02:03:04:05:06",
      "mtu": 1500,
      "name": "e1b",
      "node": {
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "rdma_protocols": [
        "roce"
      ],
      "reachable_broadcast_domains": [
        {
          "ipspace": {
            "name": "ipspace1"
          },
          "name": "bd1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      ],
      "speed": 1000,
      "state": "string",
      "type": "string",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
      "vlan": {
        "base_port": {
          "name": "e1b",
          "node": {
            "name": "node1"
          },
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "tag": 100
      }
    }
  ]
}
```

Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1376361	Port is already a member of a LAG.
1376857	Cannot create a VLAN on a port that is a member of a LAG.
1377609	The update is partially complete. Updating broadcast domain attributes on this port has failed.
1966189	Port is the home port or current port of an interface.
1966466	VLAN ID must be a number from 1 to 4094.
1967083	The specified type is not valid.
1967084	The specified node UUID is not valid.
1967085	The specified node name is not valid.
1967086	Node name and UUID must match if both are provided.
1967087	The specified broadcast domain UUID is not valid.
1967088	The specified broadcast domain name does not exist in the specified IPspace.
1967089	The specified broadcast domain UUID, name, and IPspace name do not match.
1967090	The specified VLAN base port UUID is not valid.
1967091	The specified VLAN base port name and node name are not valid.
1967092	The specified node does not match the node specified for the VLAN base port.
1967093	The specified VLAN base port UUID, name, and VLAN base port node name do not match.
1967094	The specified LAG member port UUID is not valid.
1967095	The specified LAG member port name and node name combination is not valid.

Error Code	Description
1967096	The specified node does not match the specified LAG member port node.
1967097	The specified LAG member ports UUID, name, and node name do not match.
1967098	VLAN POST operation has failed because admin status could not be set for the specified port.
1967099	Partial success of the VLAN POST operation. Verify the state of the created VLAN for more information.
1967100	LAG POST operation failed because admin status could not be set.
1967101	Partial success of the LAG POST operation. Verify the state of the created LAG for more information.
1967102	POST operation might have left the configuration in an inconsistent state. Check the configuration.
1967126	A LAG requires at least one member port.
1967148	Failure to remove port from broadcast domain.
1967149	Failure to add port to broadcast domain.
1967175	VLANs cannot be created on ports in the Cluster IPspace.
1967190	Missing or incomplete VLAN specification.
1967191	Missing or incomplete lag specification.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Name	Type	Description
name	string	Name of the broadcast domain's IPspace

broadcast_domain

Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.

Name	Type	Description
ipspace	ipspace	
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

discovered_devices

Name	Type	Description
capabilities	array[string]	The list of the capabilities of the discovered device.
chassis_id	string	Identifier associated with this specific discovered device, useful for locating the device in a data center.
ip_addresses	array[string]	The IP addresses on the discovered device.
name	string	Name of the discovered device.
platform	string	Hardware platform of the discovered device.

Name	Type	Description
protocol	string	The protocol used to identify the discovered device. This can have a value of CDP or LLDP.
remaining_hold_time	integer	The number of seconds until the discovered device entry expires and is removed.
remote_port	string	The name of the remote port on the discovered device. The format is dependent on the reporting device.
system_name	string	Additional name used to identify a specific piece of equipment.
version	string	The version of the software running on the discovered device.

node

Name	Type	Description
name	string	Name of node on which the port is located.

active_ports

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

member_ports

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

lag

Name	Type	Description
active_ports	array[active_ports]	Active ports of a LAG (ifgrp). (Some member ports may be inactive.)
distribution_policy	string	Policy for mapping flows to ports for outbound packets through a LAG (ifgrp).
member_ports	array[member_ports]	Array of ports belonging to the LAG, regardless of their state.
mode	string	Determines how the ports interact with the switch.

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

The most recent sample of I/O metrics for the port.

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.

node

Name	Type	Description
name	string	
uuid	string	

reachable_broadcast_domains

Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.

Name	Type	Description
ipspace	ipspace	
name	string	Name of the broadcast domain, scoped to its IPspace

Name	Type	Description
uuid	string	Broadcast domain UUID

receive_raw

Packet receive counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

transmit_raw

Packet transmit counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

device

Device-related counters for the port object. These counters are applicable at the lowest layer of the networking stack. These values can be used to calculate both transmit and receive packet and error rates by comparing two samples taken at different times and calculating the increase in counter value divided by the elapsed time between the two samples.

Name	Type	Description
link_down_count_raw	integer	The number of link state changes from up to down seen on the device.
timestamp	string	The timestamp when the device specific counters were collected.

throughput_raw

Throughput bytes observed at the port object. This can be used along with delta time to calculate the rate

of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

The real time I/O statistics for the port.

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the port object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
timestamp	string	The timestamp of the throughput_raw performance data.

base_port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

vlan

Name	Type	Description
base_port	base_port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.
tag	integer	VLAN ID

port

Name	Type	Description
broadcast_domain	broadcast_domain	Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.
discovered_devices	array[discovered_devices]	Discovered devices
enabled	boolean	
interface_count	integer	Number of interfaces hosted. This field is only applicable for cluster administrators. No value is returned for SVM administrators. If the node hosting a port is not healthy no value will be returned.
lag	lag	
mac_address	string	

Name	Type	Description
mtu	integer	MTU of the port in bytes. Set by broadcast domain.
name	string	Portname, such as e0a, e1b-100 (VLAN on Ethernet), a0c (LAG/ifgrp), a0d-200 (VLAN on LAG/ifgrp), e0a.pv1 (p-VLAN, in select environments only)
node	node	
rdma_protocols	array[string]	Supported RDMA offload protocols
reachable_broadcast_domains	array[reachable_broadcast_domains]	Reachable broadcast domains.
speed	integer	Link speed in Mbps
state	string	Operational state of the port. The state is set to 'down' if the operational state of the port is down. The state is set to 'up' if the link state of the port is up and the port is healthy. The state is set to 'up' if the link state of the port is up and configured to ignore health status. The state is 'degraded' if the link state of the port is up, and the port is not healthy.
type	string	Type of physical or virtual port
uuid	string	Port UUID
vlan	vlan	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete a VLAN or LAG

DELETE `/network/ethernet/ports/{uuid}`

Introduced In: 9.6

Deletes a VLAN or LAG.

Related ONTAP commands

- `network port ifgrp delete`
- `network port vlan delete`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Port UUID

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 0 • Max value: 120 • Min value: 0

Response

```
Status: 200, Ok
```

Response

```
Status: 202, Accepted
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1376858	Port already has an interface bound.
1966189	Port is the home port or current port of an interface.
1966302	This interface group is hosting VLAN interfaces that must be deleted before running this command.
1967105	Cannot delete a physical port.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve a physical port, VLAN, or LAG details

GET `/network/ethernet/ports/{uuid}`

Introduced In: 9.6

Retrieves the details of a physical port, VLAN, or LAG.

Related ONTAP commands

- `network port show`
- `network port ifgrp show`
- `network port vlan show`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Port UUID
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
broadcast_domain	broadcast_domain	Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.
discovered_devices	array[discovered_devices]	Discovered devices
enabled	boolean	
flowcontrol_admin	string	Requested flow control
interface_count	integer	Number of interfaces hosted. This field is only applicable for cluster administrators. No value is returned for SVM administrators. If the node hosting a port is not healthy no value will be returned.
lag	lag	
mac_address	string	
metric	metric	The most recent sample of I/O metrics for the port.
mtu	integer	MTU of the port in bytes. Set by broadcast domain.
name	string	Portname, such as e0a, e1b-100 (VLAN on Ethernet), a0c (LAG/ifgrp), a0d-200 (VLAN on LAG/ifgrp), e0a.pv1 (p-VLAN, in select environments only)
node	node	
pfc_queues_admin	array[integer]	List of PFC queues
rdma_protocols	array[string]	Supported RDMA offload protocols

Name	Type	Description
reachability	string	Reachability status of the port. Enum value "ok" is the only acceptable value for a PATCH request to repair a port.
reachable_broadcast_domains	array[reachable_broadcast_domains]	Reachable broadcast domains.
speed	integer	Link speed in Mbps
state	string	Operational state of the port. The state is set to 'down' if the operational state of the port is down. The state is set to 'up' if the link state of the port is up and the port is healthy. The state is set to 'up' if the link state of the port is up and configured to ignore health status. The state is 'degraded' if the link state of the port is up, and the port is not healthy.
statistics	statistics	The real time I/O statistics for the port.
type	string	Type of physical or virtual port
uuid	string	Port UUID
vlan	vlan	

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "broadcast_domain": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "ipspace": {
      "name": "ipspace1"
    },
    "name": "bd1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "discovered_devices": [
    {
      "capabilities": [
        "router",
        "switch"
      ],
      "chassis_id": "string",
      "ip_addresses": [
        "192.168.100.24",
        "192.168.100.26"
      ],
      "name": "ETY-R1S4-510Q13.datacenter.example.com",
      "platform": "93180YC-EX",
      "protocol": "cdp",
      "remote_port": "FastEthernet0/12",
      "system_name": "string",
      "version": "Cisco Nexus Operating System (NX-OS) Software,
Version 8.1"
    }
  ],
  "flowcontrol_admin": "string",
  "interface_count": 0,
  "lag": {
    "active_ports": [
      {
        "_links": {
```

```
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "e1b",
        "node": {
          "name": "node1"
        },
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    ],
    "distribution_policy": "string",
    "member_ports": [
      {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "e1b",
        "node": {
          "name": "node1"
        },
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    ],
    "mode": "string"
  },
  "mac_address": "01:02:03:04:05:06",
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "duration": "PT15S",
    "status": "ok",
    "throughput": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 11:20:13 +0000"
  },
  "mtu": 1500,
  "name": "e1b",
```

```
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "pfc_queues_admin": [
    "integer"
  ],
  "rdma_protocols": [
    "roce"
  ],
  "reachability": "ok",
  "reachable_broadcast_domains": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "ipspace": {
        "name": "ipspace1"
      },
      "name": "bd1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ],
  "speed": 1000,
  "state": "string",
  "statistics": {
    "device": {
      "link_down_count_raw": 3,
      "receive_raw": {
        "discards": 100,
        "errors": 200,
        "packets": 500
      },
      "timestamp": "2017-01-25 11:20:13 +0000",
      "transmit_raw": {
        "discards": 100,
        "errors": 200,
        "packets": 500
      }
```

```
    },
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 11:20:13 +0000"
  },
  "type": "string",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "vlan": {
    "base_port": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "tag": 100
  }
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

ipspace

Name	Type	Description
name	string	Name of the broadcast domain's IPspace

broadcast_domain

Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.

Name	Type	Description
_links	_links	
ipspace	ipspace	
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

discovered_devices

Name	Type	Description
capabilities	array[string]	The list of the capabilities of the discovered device.
chassis_id	string	Identifier associated with this specific discovered device, useful for locating the device in a data center.
ip_addresses	array[string]	The IP addresses on the discovered device.

Name	Type	Description
name	string	Name of the discovered device.
platform	string	Hardware platform of the discovered device.
protocol	string	The protocol used to identify the discovered device. This can have a value of CDP or LLDP.
remaining_hold_time	integer	The number of seconds until the discovered device entry expires and is removed.
remote_port	string	The name of the remote port on the discovered device. The format is dependent on the reporting device.
system_name	string	Additional name used to identify a specific piece of equipment.
version	string	The version of the software running on the discovered device.

node

Name	Type	Description
name	string	Name of node on which the port is located.

active_ports

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

member_ports

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

lag

Name	Type	Description
active_ports	array[active_ports]	Active ports of a LAG (ifgrp). (Some member ports may be inactive.)
distribution_policy	string	Policy for mapping flows to ports for outbound packets through a LAG (ifgrp).
member_ports	array[member_ports]	Array of ports belonging to the LAG, regardless of their state.
mode	string	Determines how the ports interact with the switch.

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

The most recent sample of I/O metrics for the port.

Name	Type	Description
_links	_links	

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

reachable_broadcast_domains

Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.

Name	Type	Description
_links	_links	
ipspace	ipspace	
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

receive_raw

Packet receive counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

transmit_raw

Packet transmit counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

device

Device-related counters for the port object. These counters are applicable at the lowest layer of the networking stack. These values can be used to calculate both transmit and receive packet and error rates by comparing two samples taken at different times and calculating the increase in counter value divided by the elapsed time between the two samples.

Name	Type	Description
link_down_count_raw	integer	The number of link state changes from up to down seen on the device.
receive_raw	receive_raw	Packet receive counters for the Ethernet port.
timestamp	string	The timestamp when the device specific counters were collected.
transmit_raw	transmit_raw	Packet transmit counters for the Ethernet port.

throughput_raw

Throughput bytes observed at the port object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

The real time I/O statistics for the port.

Name	Type	Description
device	device	Device-related counters for the port object. These counters are applicable at the lowest layer of the networking stack. These values can be used to calculate both transmit and receive packet and error rates by comparing two samples taken at different times and calculating the increase in counter value divided by the elapsed time between the two samples.

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the port object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the throughput_raw performance data.

base_port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

vlan

Name	Type	Description
base_port	base_port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.
tag	integer	VLAN ID

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update a port

PATCH `/network/ethernet/ports/{uuid}`

Introduced In: 9.6

Updates a port.

Related ONTAP commands

- `network port broadcast-domain add-ports`
- `network port broadcast-domain remove-ports`
- `network port modify`
- `network port ifgrp add-port`
- `network port ifgrp remove-port`
- `network port reachability repair`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Port UUID

Request Body

Name	Type	Description
broadcast_domain	broadcast_domain	Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.
discovered_devices	array[discovered_devices]	Discovered devices
enabled	boolean	
flowcontrol_admin	string	Requested flow control
interface_count	integer	Number of interfaces hosted. This field is only applicable for cluster administrators. No value is returned for SVM administrators. If the node hosting a port is not healthy no value will be returned.
lag	lag	
mac_address	string	
mtu	integer	MTU of the port in bytes. Set by broadcast domain.
name	string	Portname, such as e0a, e1b-100 (VLAN on Ethernet), a0c (LAG/ifgrp), a0d-200 (VLAN on LAG/ifgrp), e0a.pv1 (p-VLAN, in select environments only)
pfc_queues_admin	array[integer]	List of PFC queues
rdma_protocols	array[string]	Supported RDMA offload protocols
reachability	string	Reachability status of the port. Enum value "ok" is the only acceptable value for a PATCH request to repair a port.

Name	Type	Description
reachable_broadcast_domains	array[reachable_broadcast_domains]	Reachable broadcast domains.
speed	integer	Link speed in Mbps
state	string	Operational state of the port. The state is set to 'down' if the operational state of the port is down. The state is set to 'up' if the link state of the port is up and the port is healthy. The state is set to 'up' if the link state of the port is up and configured to ignore health status. The state is 'degraded' if the link state of the port is up, and the port is not healthy.
uuid	string	Port UUID

Example request


```
{
  "broadcast_domain": {
    "ipspace": {
      "name": "ipspace1"
    },
    "name": "bd1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "discovered_devices": [
    {
      "capabilities": [
        "router",
        "switch"
      ],
      "chassis_id": "string",
      "ip_addresses": [
        "192.168.100.24",
        "192.168.100.26"
      ],
      "name": "ETY-R1S4-510Q13.datacenter.example.com",
      "platform": "93180YC-EX",
      "protocol": "cdp",
      "remote_port": "FastEthernet0/12",
      "system_name": "string",
      "version": "Cisco Nexus Operating System (NX-OS) Software,
Version 8.1"
    }
  ],
  "flowcontrol_admin": "string",
  "interface_count": 0,
  "lag": {
    "active_ports": [
      {
        "name": "e1b",
        "node": {
          "name": "node1"
        },
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    ],
    "member_ports": [
      {
        "name": "e1b",
        "node": {
```

```
          "name": "node1"
        },
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    ]
  },
  "mac_address": "01:02:03:04:05:06",
  "mtu": 1500,
  "name": "e1b",
  "pfc_queues_admin": [
    "integer"
  ],
  "rdma_protocols": [
    "roce"
  ],
  "reachability": "ok",
  "reachable_broadcast_domains": [
    {
      "ipspace": {
        "name": "ipspace1"
      },
      "name": "bd1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ],
  "speed": 1000,
  "state": "string",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1376361	Port is already a member of a LAG.

Error Code	Description
1376369	Cannot add port to the interface group because the port hosts one or more VLANs.
1376488	Disabling the last operational cluster port on a node is not allowed.
1376492	Cannot change the MTU of a VLAN to be greater than the MTU of the port hosting it.
1377563	Port is already a member of a LAG.
1377608	Port cannot be used because it is currently the home port or current port of an interface.
1377609	The update is partially complete. Updating broadcast domain attributes on this port has failed.
1966288	Disabling the cluster ports can only be done on the local node.
1967087	The specified broadcast domain UUID is not valid.
1967088	The specified broadcast domain name does not exist in the specified IPspace.
1967089	The specified broadcast domain UUID, name and IPspace name do not match.
1967094	The specified LAG member port UUID is not valid.
1967095	The specified LAG member port name and node name combination is not valid.
1967096	The specified node does not match the specified LAG member port node.
1967097	The specified LAG member ports UUID, name, and node name do not match.
1967126	A LAG requires at least one member port.
1967148	Failure to remove port from broadcast domain.
1967149	Failure to add port to broadcast domain.
1967184	The reachability parameter cannot be patched in the same request as other parameters that might affect the target port’s reachability status.
1967185	The port cannot be repaired because the port is deemed as non-repairable.
1967186	Invalid value for the reachability parameter.
1967195	Missing or incomplete name retrieval for specified port UUID.
1967580	This command is not supported as the effective cluster version is earlier than 9.8.

Error Code	Description
1967582	The reachability parameter is not supported on this cluster.
53216932	Failed to determine whether newly introduced PFC flow control is supported.
53280899	Not all nodes support enabling the PFC feature.
53280900	No PFC queues specified.
53280901	Failed to modify PFC.
53280902	Cluster ports does not support PFC flow control.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Name	Type	Description
name	string	Name of the broadcast domain's IPspace

broadcast_domain

Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.

Name	Type	Description
ipspace	ipspace	
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

discovered_devices

Name	Type	Description
capabilities	array[string]	The list of the capabilities of the discovered device.
chassis_id	string	Identifier associated with this specific discovered device, useful for locating the device in a data center.
ip_addresses	array[string]	The IP addresses on the discovered device.
name	string	Name of the discovered device.
platform	string	Hardware platform of the discovered device.

Name	Type	Description
protocol	string	The protocol used to identify the discovered device. This can have a value of CDP or LLDP.
remaining_hold_time	integer	The number of seconds until the discovered device entry expires and is removed.
remote_port	string	The name of the remote port on the discovered device. The format is dependent on the reporting device.
system_name	string	Additional name used to identify a specific piece of equipment.
version	string	The version of the software running on the discovered device.

node

Name	Type	Description
name	string	Name of node on which the port is located.

active_ports

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

member_ports

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

lag

Name	Type	Description
active_ports	array[active_ports]	Active ports of a LAG (ifgrp). (Some member ports may be inactive.)
member_ports	array[member_ports]	Array of ports belonging to the LAG, regardless of their state.

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

The most recent sample of I/O metrics for the port.

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.

node

Name	Type	Description
name	string	
uuid	string	

reachable_broadcast_domains

Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.

Name	Type	Description
ipspace	ipspace	
name	string	Name of the broadcast domain, scoped to its IPspace

Name	Type	Description
uuid	string	Broadcast domain UUID

receive_raw

Packet receive counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

transmit_raw

Packet transmit counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

device

Device-related counters for the port object. These counters are applicable at the lowest layer of the networking stack. These values can be used to calculate both transmit and receive packet and error rates by comparing two samples taken at different times and calculating the increase in counter value divided by the elapsed time between the two samples.

Name	Type	Description
link_down_count_raw	integer	The number of link state changes from up to down seen on the device.
timestamp	string	The timestamp when the device specific counters were collected.

throughput_raw

Throughput bytes observed at the port object. This can be used along with delta time to calculate the rate

of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

The real time I/O statistics for the port.

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the port object. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
timestamp	string	The timestamp of the throughput_raw performance data.

base_port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

vlan

Name	Type	Description
base_port	base_port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.
tag	integer	VLAN ID

port

Name	Type	Description
broadcast_domain	broadcast_domain	Broadcast domain UUID along with a readable name. Either the UUID or both names may be provided on input.
discovered_devices	array[discovered_devices]	Discovered devices
enabled	boolean	
flowcontrol_admin	string	Requested flow control
interface_count	integer	Number of interfaces hosted. This field is only applicable for cluster administrators. No value is returned for SVM administrators. If the node hosting a port is not healthy no value will be returned.
lag	lag	

Name	Type	Description
mac_address	string	
mtu	integer	MTU of the port in bytes. Set by broadcast domain.
name	string	Portname, such as e0a, e1b-100 (VLAN on Ethernet), a0c (LAG/ifgrp), a0d-200 (VLAN on LAG/ifgrp), e0a.pv1 (p-VLAN, in select environments only)
pfc_queues_admin	array[integer]	List of PFC queues
rdma_protocols	array[string]	Supported RDMA offload protocols
reachability	string	Reachability status of the port. Enum value "ok" is the only acceptable value for a PATCH request to repair a port.
reachable_broadcast_domains	array[reachable_broadcast_domains]	Reachable broadcast domains.
speed	integer	Link speed in Mbps
state	string	Operational state of the port. The state is set to 'down' if the operational state of the port is down. The state is set to 'up' if the link state of the port is up and the port is healthy. The state is set to 'up' if the link state of the port is up and configured to ignore health status. The state is 'degraded' if the link state of the port is up, and the port is not healthy.
uuid	string	Port UUID

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve historical port performance metrics

GET `/network/ethernet/ports/{uuid}/metrics`

Introduced In: 9.8

Retrieves historical performance metrics for a port.

Parameters

Name	Type	In	Required	Description
throughput.write	integer	query	False	Filter by throughput.write
throughput.read	integer	query	False	Filter by throughput.read
throughput.total	integer	query	False	Filter by throughput.total
timestamp	string	query	False	Filter by timestamp
status	string	query	False	Filter by status
duration	string	query	False	Filter by duration
uuid	string	path	True	Unique identifier of the port.

Name	Type	In	Required	Description
interval	string	query	False	The time range for the data. Examples can be 1h, 1d, 1m, 1w, 1y. The period for each time range is as follows: • 1h: Metrics over the most recent hour sampled over 15 seconds. • 1d: Metrics over the most recent day sampled over 5 minutes. • 1w: Metrics over the most recent week sampled over 30 minutes. • 1m: Metrics over the most recent month sampled over 2 hours. • 1y: Metrics over the most recent year sampled over a day. • Default value: 1 • enum: ["1h", "1d", "1w", "1m", "1y"]

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
order_by	array[string]	query	False	Order results by specified fields and optional [asc
desc] direction. Default direction is 'asc' for ascending.	return_records	boolean	query	False

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[records]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "duration": "PT15S",
      "status": "ok",
      "throughput": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

records

Throughput performance for the Ethernet port.

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.
uuid	string	Port UUID

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments

Name	Type	Description
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve network Ethernet switch ports

Retrieve network Ethernet switch ports

Overview

This API can be used to get the port information for an ethernet switch used in a cluster or storage networks. This API supports GET only. The GET operation returns a list of ports with status and configuration information.

Examples

Retrieving the ports for ethernet switches

The following example retrieves the ethernet switch ports for all the ethernet switches used for cluster and/or storage networks. Note that if the *fields*=* parameter is not specified, the fields identity.number, statistics, and mac_address are not returned. Filters can be added on the fields to limit the results.

```
# The API:
GET /network/ethernet/switch/ports

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ethernet/switch/ports?fields=*"
-H  "accept: application/hal+json" -H  "Content-Type:
application/hal+json"

# The response: (abbreviated output due to length, shows a port connected
to a node, a port with no remote connection and a port connected to shelf)
{
"records": [
  {
    "switch": {
      "name": "RTP-CS01-510R11(FOC22092K12)",
      "_links": {
        "self": {
          "href": "/api/network/ethernet/switches/RTP-CS01-
510R11(FOC22092K12)"
        }
```

```
      }
    },
    "identity": {
      "name": "Ethernet1/1",
      "index": 436207616,
      "number": 1,
      "type": "ethernetcsmacd"
    },
    "mtu": 9216,
    "duplex_type": "full_duplex",
    "speed": 100000,
    "configured": "up",
    "state": "up",
    "isl": false,
    "vpc_peer_link": false,
    "statistics": {
      "timestamp": "2024-11-08T19:51:12+00:00",
      "receive_raw": {
        "packets": 1616467751,
        "errors": 0,
        "discards": 0
      },
      "transmit_raw": {
        "packets": 206717534,
        "errors": 0,
        "discards": 0
      }
    },
    "remote_port": {
      "mtu": 9000,
      "name": "e3a",
      "functional_roles": [
        "cluster",
        "ha"
      ],
      "device": {
        "discovered_name": "stiA400-311",
        "node": {
          "name": "stiA400-311",
          "uuid": "54c0f036-8a3a-11ea-893d-00a098fd726d",
          "_links": {
            "self": {
              "href": "/api/cluster/nodes/54c0f036-8a3a-11ea-893d-
00a098fd726d"
            }
          }
```

```
        }
      }
    },
    "mac_address": "00:be:75:ae:2a:d4",
    "vlan_id": [
      1,
      17,
      18
    ],
    "roles": [
      {
        "type": "cluster",
        "zone": 1
      }
    ],
    "_links": {
      "self": {
        "href": "/api/network/ethernet/switch/ports/RTP-CS01-
510R11%28FOC22092K12%29/Ethernet1%2F1/436207616"
      }
    }
  },
  {
    "switch": {
      "name": "RTP-CS01-510R11(FOC22092K12)",
      "_links": {
        "self": {
          "href": "/api/network/ethernet/switches/RTP-CS01-
510R11(FOC22092K12)"
        }
      }
    },
    "identity": {
      "name": "Ethernet1/11",
      "index": 436212736,
      "number": 11,
      "type": "ethernetcsmacd"
    },
    "mtu": 9216,
    "duplex_type": "unknown",
    "speed": 100000,
    "configured": "up",
    "state": "down",
    "isl": false,
    "vpc_peer_link": false,
    "statistics": {
```

```
      "timestamp": "2024-11-08T19:51:12+00:00",
      "receive_raw": {
        "packets": 0,
        "errors": 0,
        "discards": 0
        },
      "transmit_raw": {
        "packets": 0,
        "errors": 0,
        "discards": 0
      }
    },
    "mac_address": "00be75ae2afc",
    "vlan_id": [
      1,
      17,
      18
    ],
    "roles": [
      {
        "type": "cluster",
        "zone": 1
      }
    ],
    "_links": {
      "self": {
        "href": "/api/network/ethernet/switch/ports/RTP-CS01-
510R11%28FOC22092K12%29/Ethernet1%2F11/436212736"
      }
    }
  },
  {
    "switch": {
      "name": "RTP-SS01-510R10(FOC22170DFR)",
      "_links": {
        "self": {
          "href": "/api/network/ethernet/switches/RTP-SS01-
510R10(FOC22170DFR)"
        }
      }
    },
    "identity": {
      "name": "Ethernet1/10",
      "index": 436212224,
      "number": 10,
      "type": "ethernetcsmacd"
```

```
    },
    "mtu": 9216,
    "duplex_type": "full_duplex",
    "speed": 100000,
    "configured": "up",
    "state": "up",
    "isl": false,
    "vpc_peer_link": false,
    "statistics": {
      "timestamp": "2024-11-08T19:51:12+00:00",
      "receive_raw": {
        "packets": 332013844,
        "errors": 0,
        "discards": 0
      },
      "transmit_raw": {
        "packets": 2429595607,
        "errors": 0,
        "discards": 0
      }
    },
    "remote_port": {
      "mtu": 9000,
      "name": "e0a",
      "functional_roles": [
        "storage_shelf"
      ],
      "device": {
        "discovered_name": "1.1",
        "shelf": {
          "name": "1.1",
          "module": "B",
          "uid": "12439000444923584512",
          "_links": {
            "self": {
              "href": "/api/storage/shelves/12439000444923584512"
            }
          }
        }
      }
    },
    "mac_address": "00fcbaead548",
    "vlan_id": [
      1,
      30
    ],
```

```
    "roles": [
      {
        "type": "storage",
        "zone": 1
      }
    ],
    "_links": {
      "self": {
        "href": "/api/network/ethernet/switch/ports/RTP-SS01-
510R10%28FOC22170DFR%29/Ethernet1%2F10/436212224"
      }
    }
  }
],
"num_records": 138,
"_links": {
  "self": {
    "href": "/api/network/ethernet/switch/ports?fields=*"
  }
}
}
```

Retrieving a ports on an ethernet switch

```
# The API:
GET /network/ethernet/switch/ports/{switch.name}/{identity.name}/
{identity.index}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ethernet/switch/ports/RTP-SS02-
510R10%28FOC22131U6T%29/Ethernet1%2F9/436211712" -H  "accept:
application/hal+json" -H  "Content-Type: application/hal+json"

# The response:
{
"switch": {
  "name": "RTP-SS02-510R10(FOC22131U6T)",
  "_links": {
    "self": {
      "href": "/api/network/ethernet/switches/RTP-SS02-
510R10(FOC22131U6T)"
    }
  }
},
```

```
"identity": {
  "name": "Ethernet1/9",
  "index": 436211712,
  "number": 9,
  "type": "ethernetcsmacd"
},
"mtu": 9216,
"duplex_type": "full_duplex",
"speed": 100000,
"configured": "up",
"state": "up",
"isl": false,
"vpc_peer_link": false,
"statistics": {
  "timestamp": "2024-11-08T19:51:12+00:00",
  "receive_raw": {
    "packets": 4012559315,
    "errors": 0,
    "discards": 0
  },
  "transmit_raw": {
    "packets": 337898026,
    "errors": 0,
    "discards": 0
 }
},
"remote_port": {
  "mtu": 9000,
  "name": "e0a",
  "functional_roles": [
    "storage_shelf"
  ],
  "device": {

    # cSpell:disable-next-line
    "discovered_name": "SHFFG1234567890:A",
    "shelf": {
      "name": "1.1",
      "module": "A",
      "uid": "12439000444923584512",
      "_links": {
        "self": {
          "href": "/api/storage/shelves/12439000444923584512"
        }
      }
    }
```

```
    }
  },
  "mac_address": "00fcbaea7228",
  "vlan_id": [
    1,
    30
  ],
  "roles": [
    {
      "type": "storage",
      "zone": 1
    }
  ],
  "_links": {
    "self": {
      "href": "/api/network/ethernet/switch/ports/RTP-SS02-
510R10%28FOC22131U6T%29/Ethernet1%2F9/436211712"
    }
  }
}
```


Retrieve Ethernet switch ports

GET `/network/ethernet/switch/ports`

Introduced In: 9.8

Retrieves the ethernet switch ports.

Related ONTAP commands

- `system switch ethernet interface show`

Learn more

- DOC /network/ethernet/switch/ports

Parameters

Name	Type	In	Required	Description
switch.name	string	query	False	Filter by switch.name

Name	Type	In	Required	Description
identity.breakout.physical_port	string	query	False	Filter by identity.breakout.physical_port • Introduced in: 9.17
identity.breakout.number	integer	query	False	Filter by identity.breakout.number • Introduced in: 9.17
identity.number	integer	query	False	Filter by identity.number
identity.index	integer	query	False	Filter by identity.index
identity.name	string	query	False	Filter by identity.name
vpc_peer_link	boolean	query	False	Filter by vpc_peer_link • Introduced in: 9.15
mtu	integer	query	False	Filter by mtu
configured	string	query	False	Filter by configured
isl	boolean	query	False	Filter by isl
duplex_type	string	query	False	Filter by duplex_type
roles.type	string	query	False	Filter by roles.type • Introduced in: 9.17
roles.dr_group	string	query	False	Filter by roles.dr_group • Introduced in: 9.17

Name	Type	In	Required	Description
roles.zone	integer	query	False	Filter by roles.zone • Introduced in: 9.17 • Min value: 1
mac_address	string	query	False	Filter by mac_address
speed	integer	query	False	Filter by speed
state	string	query	False	Filter by state
remote_port.functional_roles	string	query	False	Filter by remote_port.functional_roles • Introduced in: 9.17
remote_port.device.node.name	string	query	False	Filter by remote_port.device.node.name
remote_port.device.node.uuid	string	query	False	Filter by remote_port.device.node.uuid
remote_port.device.discovered_name	string	query	False	Filter by remote_port.device.discovered_name • Introduced in: 9.17
remote_port.device.dcn.serial_number	string	query	False	Filter by remote_port.device.dcn.serial_number • Introduced in: 9.18
remote_port.device.dcn.name	string	query	False	Filter by remote_port.device.dcn.name • Introduced in: 9.18

Name	Type	In	Required	Description
remote_port.device.dcn.uuid	string	query	False	Filter by remote_port.device.dcn.uuid • Introduced in: 9.18
remote_port.device.shelf.name	string	query	False	Filter by remote_port.device.shelf.name • Introduced in: 9.12
remote_port.device.shelf.uid	string	query	False	Filter by remote_port.device.shelf.uid
remote_port.device.shelf.module	string	query	False	Filter by remote_port.device.shelf.module • Introduced in: 9.12
remote_port.mtu	integer	query	False	Filter by remote_port.mtu
remote_port.name	string	query	False	Filter by remote_port.name
statistics.timestamp	string	query	False	Filter by statistics.timestamp • Introduced in: 9.17
statistics.transmit_raw.discards	integer	query	False	Filter by statistics.transmit_raw.discards
statistics.transmit_raw.errors	integer	query	False	Filter by statistics.transmit_raw.errors
statistics.transmit_raw.packets	integer	query	False	Filter by statistics.transmit_raw.packets

Name	Type	In	Required	Description
statistics.receive_raw.discards	integer	query	False	Filter by statistics.receive_raw.discards
statistics.receive_raw.errors	integer	query	False	Filter by statistics.receive_raw.errors
statistics.receive_raw.packets	integer	query	False	Filter by statistics.receive_raw.packets
type	string	query	False	Filter by type
vlan_id	integer	query	False	Filter by vlan_id
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Min value: 0 • Default value: 15 • Max value: 120

Name	Type	In	Required	Description
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	collection_links	
num_records	integer	Number of Records
records	array[switch_port]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "configured": "string",
      "duplex_type": "string",
      "identity": {
        "breakout": {
          "number": 1,
          "physical_port": "Ethernet1/9"
        },
        "index": 0,
        "name": "string",
        "number": 0
      },
      "mac_address": "string",
      "mtu": 0,
      "remote_port": {
        "device": {
          "dcn": {
            "_links": {
              "self": {
                "href": "/api/resourcelink"
              }
            },
            "name": "node1",
            "serial_number": "4048820-60-9",
            "uuid": "4ea7a442-86d1-11e0-ae1c-123478563412"
          },
          "discovered_name": "stiA400-311",
          "node": {
```

```
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "node1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "shelf": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "module": "string",
          "name": "1.1",
          "uid": "12439000444923584512"
        }
      },
      "functional_roles": [
        "string"
      ],
      "mtu": 0,
      "name": "string"
    },
    "roles": [
      {
        "dr_group": "string",
        "type": "string"
      }
    ],
    "speed": 0,
    "state": "string",
    "statistics": {
      "receive_raw": {
        "discards": 100,
        "errors": 200,
        "packets": 500
      },
      "timestamp": "2024-11-18 15:52:17 +0000",
      "transmit_raw": {
        "discards": 100,
        "errors": 200,
        "packets": 500
      }
    },
```

```
      "switch": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "RTP-SS01-510R03(FOC223443KQ)"
      },
      "type": "string",
      "vlan_id": [
        "integer"
      ]
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

collection_links

Name	Type	Description
next	href	
self	href	

self_link

Name	Type	Description
self	href	

breakout

Name	Type	Description
number	integer	Breakout port sub-interface number.
physical_port	string	Breakout physical port name.

identity

Name	Type	Description
breakout	breakout	
index	integer	Interface Index.
name	string	Interface Name.
number	integer	Interface Number.

_links

Name	Type	Description
self	href	

dcn

Compute node connected to this port.

Name	Type	Description
_links	_links	
name	string	Compute node name.
serial_number	string	Compute node serial number.
uuid	string	Compute node UUID.

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

shelf

Shelf connected to this port.

Name	Type	Description
_links	_links	
module	string	Shelf module connected to this port.
name	string	
uid	string	

device

Device connected to port.

Name	Type	Description
dcn	dcn	Compute node connected to this port.
discovered_name	string	Raw name of the discovered device.
node	node	
shelf	shelf	Shelf connected to this port.

remote_port

Remote port.

Name	Type	Description
device	device	Device connected to port.
functional_roles	array[string]	
mtu	integer	MTU in octets.
name	string	Remote port name.

roles

Allowed use for this port.

Name	Type	Description
dr_group	string	DR group.
type	string	Allowed use type.
zone	integer	Zone ID to differentiate between roles with the same type.

receive_raw

Packet receive counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

transmit_raw

Packet transmit counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.

Name	Type	Description
packets	integer	Total packet count.

statistics

These are raw counters for the device associated with the Ethernet port.

Name	Type	Description
receive_raw	receive_raw	Packet receive counters for the Ethernet port.
timestamp	string	The time the statistics were gathered.
transmit_raw	transmit_raw	Packet transmit counters for the Ethernet port.

switch

The name of the specified cluster or storage switch.

Name	Type	Description
_links	self_link	
name	string	

switch_port

Ethernet Switch Port REST API

Name	Type	Description
_links	self_link	
configured	string	Administrative Status.
duplex_type	string	Duplex Settings.
identity	identity	
isl	boolean	Is configured as an ISL link.
mac_address	string	MAC Address.
mtu	integer	MTU.
remote_port	remote_port	Remote port.

Name	Type	Description
roles	array[roles]	
speed	integer	Interface Speed(Mbps).
state	string	Operational Status.
statistics	statistics	These are raw counters for the device associated with the Ethernet port.
switch	switch	The name of the specified cluster or storage switch.
type	string	Interface Type.
vlan_id	array[integer]	
vpc_peer_link	boolean	Is configured as a Virtual Port Channel (vPC) peer-link.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve an Ethernet switch port

GET `/network/ethernet/switch/ports/{switch}/{identity.name}/{identity.index}`

Introduced In: 9.8

Retrieves an ethernet switch port.

Related ONTAP commands

- `system switch ethernet interface show`

Parameters

Name	Type	In	Required	Description
switch	string	path	True	Switch Name
identity.name	string	path	True	Interface Name
identity.index	integer	path	True	Interface Index
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	self_link	
configured	string	Administrative Status.
duplex_type	string	Duplex Settings.
identity	identity	
isl	boolean	Is configured as an ISL link.
mac_address	string	MAC Address.
mtu	integer	MTU.
remote_port	remote_port	Remote port.
roles	array[roles]	
speed	integer	Interface Speed(Mbps).
state	string	Operational Status.

Name	Type	Description
statistics	statistics	These are raw counters for the device associated with the Ethernet port.
switch	switch	The name of the specified cluster or storage switch.
type	string	Interface Type.
vlan_id	array[integer]	
vpc_peer_link	boolean	Is configured as a Virtual Port Channel (vPC) peer-link.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "configured": "string",
  "duplex_type": "string",
  "identity": {
    "breakout": {
      "number": 1,
      "physical_port": "Ethernet1/9"
    },
    "index": 0,
    "name": "string",
    "number": 0
  },
  "mac_address": "string",
  "mtu": 0,
  "remote_port": {
    "device": {
      "dcn": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "serial_number": "4048820-60-9",
        "uuid": "4ea7a442-86d1-11e0-ae1c-123478563412"
      },
      "discovered_name": "stiA400-311",
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "shelf": {
        "_links": {
          "self": {
```

```
            "href": "/api/resourcelink"
          }
        },
        "module": "string",
        "name": "1.1",
        "uid": "12439000444923584512"
      }
    },
    "functional_roles": [
      "string"
    ],
    "mtu": 0,
    "name": "string"
  },
  "roles": [
    {
      "dr_group": "string",
      "type": "string"
    }
  ],
  "speed": 0,
  "state": "string",
  "statistics": {
    "receive_raw": {
      "discards": 100,
      "errors": 200,
      "packets": 500
    },
    "timestamp": "2024-11-18 15:52:17 +0000",
    "transmit_raw": {
      "discards": 100,
      "errors": 200,
      "packets": 500
    }
  },
  "switch": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "RTP-SS01-510R03(FOC223443KQ)"
  },
  "type": "string",
  "vlan_id": [
    "integer"
```

```
  ]
}
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

self_link

Name	Type	Description
self	href	

breakout

Name	Type	Description
number	integer	Breakout port sub-interface number.
physical_port	string	Breakout physical port name.

identity

Name	Type	Description
breakout	breakout	
index	integer	Interface Index.
name	string	Interface Name.
number	integer	Interface Number.

_links

Name	Type	Description
self	href	

dcn

Compute node connected to this port.

Name	Type	Description
_links	_links	
name	string	Compute node name.

Name	Type	Description
serial_number	string	Compute node serial number.
uuid	string	Compute node UUID.

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

shelf

Shelf connected to this port.

Name	Type	Description
_links	_links	
module	string	Shelf module connected to this port.
name	string	
uid	string	

device

Device connected to port.

Name	Type	Description
dcn	dcn	Compute node connected to this port.
discovered_name	string	Raw name of the discovered device.
node	node	
shelf	shelf	Shelf connected to this port.

remote_port

Remote port.

Name	Type	Description
device	device	Device connected to port.
functional_roles	array[string]	
mtu	integer	MTU in octets.
name	string	Remote port name.

roles

Allowed use for this port.

Name	Type	Description
dr_group	string	DR group.
type	string	Allowed use type.
zone	integer	Zone ID to differentiate between roles with the same type.

receive_raw

Packet receive counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

transmit_raw

Packet transmit counters for the Ethernet port.

Name	Type	Description
discards	integer	Total number of discarded packets.
errors	integer	Number of packet errors.
packets	integer	Total packet count.

statistics

These are raw counters for the device associated with the Ethernet port.

Name	Type	Description
receive_raw	receive_raw	Packet receive counters for the Ethernet port.
timestamp	string	The time the statistics were gathered.
transmit_raw	transmit_raw	Packet transmit counters for the Ethernet port.

switch

The name of the specified cluster or storage switch.

Name	Type	Description
_links	self_link	
name	string	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage Ethernet switches

Manage Ethernet switches

Overview

This endpoint manages Ethernet switches used by ONTAP for monitoring and configuration. You can retrieve, configure, add, or delete Ethernet switches, as well as change SNMP credentials and monitor their status.

Examples

Retrieving a list of Ethernet switches

The following example shows the response with a list of monitored Ethernet switches. Note that if the *fields*=* parameter is not specified, the fields snmp.version, snmp.user, version, monitoring.enabled, and monitoring.reason are not returned.

```
# The API:
/network/ethernet/switches

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ethernet/switches?fields=*" -H
"accept: application/hal+json" -H "Content-Type: application/hal+json"

# The response:
{
"records": [
  {
    "name": "RTP-CS01-510R11(FOC22092K12)",
    "address": "172.26.207.77",
    "discovered": true,
    "model": "NX3232C",
    "monitoring": {
      "enabled": true,
      "monitored": true,
      "reason": "None"
    },
    "network": "cluster",
    "serial_number": "Unknown",
    "snmp": {
      "version": "snmpv2c",
      "user": "cshm1!"
    },
    "version": "Cisco Nexus Operating System (NX-OS) Software, Version
9.2(3)",
    "role": "cluster",
    "rcf_version": "RCF NX3232C v1.13 1-CLUSTER",
```

```
    "_links": {
      "self": {
        "href": "/api/network/ethernet/switches/RTP-CS01-
510R11%28FOC22092K12%29"
      }
    }
  },
  {
    "name": "RTP-CS01-510R12(FOC22373C3P)",
    "address": "172.26.207.82",
    "discovered": true,
    "model": "NX3232C",
    "monitoring": {
      "enabled": true,
      "monitored": true,
      "reason": "None"
    },
    "network": "cluster",
    "serial_number": "FOC22373C3P",
    "snmp": {
      "version": "snmpv2c",
      "user": "cshm1!"
    },
    "version": "Cisco Nexus Operating System (NX-OS) Software, Version
9.2(3)",
    "role": "cluster",
    "rcf_version": "RCF NX3232C v1.13 1-CLUSTER",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/switches/RTP-CS01-
510R12%28FOC22373C3P%29"
      }
    }
  },
  {
    "name": "RTP-SS01-510R10(FOC22170DFR)",
    "address": "172.26.207.65",
    "discovered": true,
    "model": "NX3232C",
    "monitoring": {
      "enabled": true,
      "monitored": true,
      "reason": "None"
    },
    "network": "storage",
    "serial_number": "FOC22170DFR",
```

```
    "snmp": {
      "version": "snmpv2c",
      "user": "cshm1!"
    },
    "version": "Cisco Nexus Operating System (NX-OS) Software, Version
9.3(3)",
    "role": "storage",
    "rcf_version": "RCF NX3232C v1.13 1-STORAGE",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/switches/RTP-SS01-
510R10%28FOC22170DFR%29"
      }
    }
  },
  {
    "name": "RTP-SS02-510R10(FOC22131U6T)",
    "address": "172.26.207.66",
    "discovered": true,
    "model": "NX3232C",
    "monitoring": {
      "enabled": true,
      "monitored": true,
      "reason": "None"
    },
    "network": "storage",
    "serial_number": "FOC22131U6T",
    "snmp": {
      "version": "snmpv2c",
      "user": "cshm1!"
    },
    "version": "Cisco Nexus Operating System (NX-OS) Software, Version
9.3(3)",
    "role": "storage",
    "rcf_version": "RCF NX3232C v1.13 1-STORAGE",
    "_links": {
      "self": {
        "href": "/api/network/ethernet/switches/RTP-SS02-
510R10%28FOC22131U6T%29"
      }
    }
  }
],
"num_records": 4,
"_links": {
  "self": {
```

```
    "href": "/api/network/ethernet/switches?fields=*"
  }
}
}
```

Retrieving an Ethernet switch

The following example shows the response of the requested Ethernet switch. If there is no Ethernet switch with the requested name, an error is returned.

```
# The API:
/network/ethernet/switches/{name}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ethernet/switches/RTP-SS02-
510R10(FOC22131U6T)?fields=*" -H  "accept: application/hal+json" -H
"Content-Type: application/hal+json"

# The response:
{
"name": "RTP-SS02-510R10(FOC22131U6T)",
"address": "172.26.207.66",
"discovered": true,
"model": "NX3232C",
"monitoring": {
  "enabled": true,
  "monitored": true,
  "reason": "None"
},
"network": "storage",
"serial_number": "FOC22131U6T",
"snmp": {
  "version": "snmpv2c",
  "user": "cshm1!"
},
"version": "Cisco Nexus Operating System (NX-OS) Software, Version
9.3(3)",
"role": "storage",
"rcf_version": "RCF NX3232C v1.13 1-STORAGE",
"_links": {
  "self": {
    "href": "/api/network/ethernet/switches/RTP-SS02-510R10(FOC22131U6T)"
  }
}
}
```

Configuring monitoring settings for an Ethernet switch

The following example configures SNMP credential and version settings for an Ethernet switch. If the provided information is not valid, an error is returned.

```
# The API:
/network/ethernet/switches/{name}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ethernet/switches/sconqa-
corduroyl-03" -H "accept: application/hal+json" -H "Content-Type:
application/hal+json" -d '{"snmp": {"version": "snmpv2c", "user":
"cshm1!"}}'

# The response:
{
"job": {
  "uuid": "f84fbb3c-589c-11ec-b181-d039ea48a7dc",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/f84fbb3c-589c-11ec-b181-d039ea48a7dc"
    }
  }
}
}
```

Adding an Ethernet switch

The following example adds an Ethernet switch for monitoring. If the provided information is not valid, an error is returned.

```
# The API:
/network/ethernet/switches

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ethernet/switches" -H "accept:
application/hal+json" -H "Content-Type: application/hal+json" -d '{"name":
"RTP-SS02-510R10(FOC22131U6T)", "address": "172.26.207.66", "model":
"NX3232C", "monitoring": {"enabled": "true"}, "network": "storage",
"snmp": {"version": "snmpv2c", "user": "cshm1!"}}'

# The response:
{
"job": {
  "uuid": "f84fbb3c-589c-11ec-b181-d039ea48a7dc",
  "_links": {
    "self": {
      "href": "/api/cluster/jobs/f84fbb3c-589c-11ec-b181-d039ea48a7dc"
    }
  }
}
}
```

Deleting an Ethernet switch

The following example deletes an Ethernet switch. If there is no Ethernet switch with the requested name, an error is returned.

```
# The API:
/network/ethernet/switches/{name}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/network/ethernet/switches/sconqa-
corduroyl-03" -H "accept: application/hal+json" -H "Content-Type:
application/hal+json"

# The response:
{
}
```

Retrieve Ethernet switches attached to a chassis

GET `/network/ethernet/switches`

Introduced In: 9.8

Retrieves a collection of Ethernet switches.

Related ONTAP commands

- `system switch ethernet show`

Learn more

- DOC /network/ethernet/switches

Parameters

Name	Type	In	Required	Description
monitoring.enabled	boolean	query	False	Filter by monitoring.enabled
monitoring.monitored	boolean	query	False	Filter by monitoring.monitored
monitoring.reason	string	query	False	Filter by monitoring.reason
snmp.version	string	query	False	Filter by snmp.version
snmp.user	string	query	False	Filter by snmp.user
role	string	query	False	Filter by role • Introduced in: 9.17
serial_number	string	query	False	Filter by serial_number
model	string	query	False	Filter by model
address	string	query	False	Filter by address
name	string	query	False	Filter by name
discovered	boolean	query	False	Filter by discovered
network	string	query	False	Filter by network

Name	Type	In	Required	Description
rcf_version	string	query	False	Filter by rcf_version • Introduced in: 9.17
version	string	query	False	Filter by version
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	collection_links	
num_records	integer	Number of Records
records	array[switch]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "address": "string",
      "model": "string",
      "monitoring": {
        "reason": "string"
      },
      "name": "string",
      "network": "string",
      "rcf_version": "RCF NX9336C-FX2 v1.13 1-CLUSTER",
      "role": [
        "cluster+storage"
      ],
      "serial_number": "string",
      "snmp": {
        "user": "string",
        "version": "string"
      },
      "version": "string"
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

collection_links

Name	Type	Description
next	href	
self	href	

self_link

Name	Type	Description
self	href	

monitoring

Name	Type	Description
enabled	boolean	Enable Health Monitoring.
monitored	boolean	Is Monitored.
reason	string	Reason For Not Monitoring.

snmp

Name	Type	Description
user	string	Community String or SNMPv3 Username.
version	string	SNMP Version.

switch

Ethernet Switch REST API

Name	Type	Description
_links	self_link	
address	string	IP Address.

Name	Type	Description
discovered	boolean	Discovered By ONTAP CDP/LLDP • readOnly: 1 • Introduced in: 9.8 • x-nullable: true
model	string	Model Number.
monitoring	monitoring	
name	string	Name.
network	string	Switch Network.
rcf_version	string	The switch reference configuration file (RCF) version.
role	string	Switch role based on the interface configurations. Using '+' to combine multiple roles. Available role types are: cluster, multicluster, storage, multistorage, metrocluster.
serial_number	string	Serial Number.
snmp	snmp	
version	string	Software Version.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code

Name	Type	Description
message	string	Error message
target	string	The target parameter that caused the error.

Create an Ethernet switch

POST `/network/ethernet/switches`

Introduced In: 9.11

Adds an Ethernet switch.

Required properties

- `name` - Name of the switch to create.
- `address` - Switch IP address.
- `model` - Switch model number.
- `monitoring.enabled` - Whether the switch should be monitored by CSHM.
- `network`
  - *cluster* for cluster or shared switches.
  - *storage* for storage switches.
- `snmp.version` - SNMP version.
- `snmp.user` - SNMP user.

Related ONTAP commands

- `system switch ethernet create`

Learn more

- DOC /network/ethernet/switches

Parameters

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 0 • Max value: 120 • Min value: 0
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
address	string	IP Address.

Name	Type	Description
discovered	boolean	Discovered By ONTAP CDP/LLDP • readOnly: 1 • Introduced in: 9.8 • x-nullable: true
model	string	Model Number.
monitoring	monitoring	
name	string	Name.
network	string	Switch Network.
rcf_version	string	The switch reference configuration file (RCF) version.
role	string	Switch role based on the interface configurations. Using '+' to combine multiple roles. Available role types are: cluster, multicluster, storage, multistorage, metrocluster.
serial_number	string	Serial Number.
snmp	snmp	
version	string	Software Version.

Example request

```
{
  "address": "string",
  "model": "string",
  "monitoring": {
    "reason": "string"
  },
  "name": "string",
  "network": "string",
  "rcf_version": "RCF NX9336C-FX2 v1.13 1-CLUSTER",
  "role": [
    "cluster+storage"
  ],
  "serial_number": "string",
  "snmp": {
    "user": "string",
    "version": "string"
  },
  "version": "string"
}
```

Response

```
Status: 202, Accepted
```

Name	Type	Description
job	job_link	

Example response

```
{
  "job": {
    "uuid": "string"
  }
}
```

Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Response

```
Status: 201, Created
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
5636148	Failed to discover SNMPv3 engine ID of the remote switch.
5636149	The "<snmp.user>\" must be a valid SNMPv3 user belonging to remote switch \"<name.>\" and must also be configured in ONTAP.</name.></snmp.user>
5636152	0.0.0.0 cannot be specified as the IP address for the "<address.>\" parameter.</address.>
8912900	Invalid IP address.
9044009	SNMPv3 client feature is not available until the effective cluster version is ONTAP 9.3 or later.
12517377	Model number validation failed. Specify the correct model number and try the command again.
12517378	The IP "<address.>\" is not reachable. Verify that the address is valid, or check the network path.</address.>
12517380	SNMP validation request timed out. Verify that the "<snmp.user>\" parameter is valid.</snmp.user>
12517382	SNMPv3 validation request timed out. Verify that the "<snmp.user>\" parameter is valid (i.e., the SNMPv3 user exists in ONTAP and on the remote switch). If the \"<snmp.user>\" parameter is valid, verify that the SNMPv3 user’s credentials are the same both in ONTAP as well as in the remote switch. If a custom engine-id was provided for the SNMPv3 user, ensure it is the same as that of the remote switch.</snmp.user></snmp.user>
12517384	A switch with the same IP address is already being monitored.

Error Code	Description
12517385	The "<model.>\" is unknown. Use \"OTHER\" if the switch model is not one of the following: {models}.</model.>
12517411	The input value for "<name.>\", \"<address.>\" and/or \"<network.>\" must match its discovered value.</network.></address.></name.>

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

self_link

monitoring

Name	Type	Description
enabled	boolean	Enable Health Monitoring.
monitored	boolean	Is Monitored.
reason	string	Reason For Not Monitoring.

snmp

Name	Type	Description
user	string	Community String or SNMPv3 Username.
version	string	SNMP Version.

switch

Ethernet Switch REST API

Name	Type	Description
address	string	IP Address.
discovered	boolean	Discovered By ONTAP CDP/LLDP • readOnly: 1 • Introduced in: 9.8 • x-nullable: true
model	string	Model Number.
monitoring	monitoring	
name	string	Name.

Name	Type	Description
network	string	Switch Network.
rcf_version	string	The switch reference configuration file (RCF) version.
role	string	Switch role based on the interface configurations. Using '+' to combine multiple roles. Available role types are: cluster, multicluster, storage, multistorage, metrocluster.
serial_number	string	Serial Number.
snmp	snmp	
version	string	Software Version.

_links

job_link

Name	Type	Description
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message

Name	Type	Description
target	string	The target parameter that caused the error.

Delete an Ethernet switch

DELETE `/network/ethernet/switches/{name}`

Introduced In: 9.11

Deletes an Ethernet switch.

Related ONTAP commands

- `system switch ethernet delete`

Learn more

- DOC /network/ethernet/switches

Parameters

Name	Type	In	Required	Description
name	string	path	True	Switch Name.

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
12517412	Cannot remove a discovered switch. To stop monitoring the switch, set "<monitoring.enabled>\" to \"false\".</monitoring.enabled>

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve Ethernet switch details

GET `/network/ethernet/switches/{name}`

Introduced In: 9.8

Retrieves the details of an Ethernet switch.

Related ONTAP commands

- `system switch ethernet show`

Learn more

- DOC /network/ethernet/switches

Parameters

Name	Type	In	Required	Description
name	string	path	True	Name
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	self_link	
address	string	IP Address.
discovered	boolean	Discovered By ONTAP CDP/LLDP • readOnly: 1 • Introduced in: 9.8 • x-nullable: true
model	string	Model Number.
monitoring	monitoring	
name	string	Name.
network	string	Switch Network.

Name	Type	Description
rcf_version	string	The switch reference configuration file (RCF) version.
role	string	Switch role based on the interface configurations. Using '+' to combine multiple roles. Available role types are: cluster, multicluster, storage, multistorage, metrocluster.
serial_number	string	Serial Number.
snmp	snmp	
version	string	Software Version.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "address": "string",
  "model": "string",
  "monitoring": {
    "reason": "string"
  },
  "name": "string",
  "network": "string",
  "rcf_version": "RCF NX9336C-FX2 v1.13 1-CLUSTER",
  "role": [
    "cluster+storage"
  ],
  "serial_number": "string",
  "snmp": {
    "user": "string",
    "version": "string"
  },
  "version": "string"
}
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

self_link

Name	Type	Description
self	href	

monitoring

Name	Type	Description
enabled	boolean	Enable Health Monitoring.
monitored	boolean	Is Monitored.
reason	string	Reason For Not Monitoring.

snmp

Name	Type	Description
user	string	Community String or SNMPv3 Username.
version	string	SNMP Version.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code

Name	Type	Description
message	string	Error message
target	string	The target parameter that caused the error.

Update an Ethernet switch

PATCH `/network/ethernet/switches/{name}`

Introduced In: 9.8

Configures monitoring settings for an Ethernet switch.

Related ONTAP commands

- `system switch ethernet modify`

Learn more

- DOC /network/ethernet/switches

Parameters

Name	Type	In	Required	Description
name	string	path	True	Switch Name

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 0 • Max value: 120 • Min value: 0

Request Body

Name	Type	Description
address	string	IP Address.
discovered	boolean	Discovered By ONTAP CDP/LLDP • readOnly: 1 • Introduced in: 9.8 • x-nullable: true
monitoring	monitoring	

Name	Type	Description
rcf_version	string	The switch reference configuration file (RCF) version.
role	string	Switch role based on the interface configurations. Using '+' to combine multiple roles. Available role types are: cluster, multicluster, storage, multistorage, metrocluster.
serial_number	string	Serial Number.
snmp	snmp	
version	string	Software Version.

Example request

```
{
  "address": "string",
  "monitoring": {
    "reason": "string"
  },
  "rcf_version": "RCF NX9336C-FX2 v1.13 1-CLUSTER",
  "role": [
    "cluster+storage"
  ],
  "serial_number": "string",
  "snmp": {
    "user": "string",
    "version": "string"
  },
  "version": "string"
}
```

Response

```
Status: 200, Ok
```

Name	Type	Description
job	job_link	

Example response


```
{
  "job": {
    "uuid": "string"
  }
}
```


Response

```
Status: 202, Accepted
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
5636148	Failed to discover SNMPv3 engine ID of the remote switch.
5636149	The "<snmp.user>\" must be a valid SNMPv3 user belonging to remote switch \"<name.>\" and must also be configured in ONTAP.</name.></snmp.user>
5636152	0.0.0.0 cannot be specified as the IP address for the "<address.>\" parameter.</address.>
8912900	Invalid IP address.
9044009	SNMPv3 client feature is not available until the effective cluster version is ONTAP 9.3 or later.
12517379	Warning: Settings updated, but the IP "<address.>\" is not reachable. Verify that the address is valid, or check the network path.</address.>
12517381	Warning: Settings updated, but the SNMP validation request timed out. Verify that the "<snmp.user>\" parameter is valid.</snmp.user>

Error Code	Description
12517383	Warning: Settings updated, but the SNMPv3 validation request timed out. Verify that the "<snmp.user>\" parameter is valid (i.e., the SNMPv3 user exists in ONTAP and on the remote switch). If the \"<snmp.user>\" parameter is valid, verify that the SNMPv3 user’s credentials are the same both in ONTAP as well as in the remote switch. If a custom engine-id was provided for the SNMPv3 user, ensure it is the same as that of the remote switch.</snmp.user></snmp.user>
12517411	The input value for "<name.>\", \"<address.>\" and/or \"<network.>\" must match its discovered value.</network.></address.></name.>

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

self_link

monitoring

Name	Type	Description
enabled	boolean	Enable Health Monitoring.
monitored	boolean	Is Monitored.
reason	string	Reason For Not Monitoring.

snmp

Name	Type	Description
user	string	Community String or SNMPv3 Username.
version	string	SNMP Version.

switch

Ethernet Switch REST API

Name	Type	Description
address	string	IP Address.
discovered	boolean	Discovered By ONTAP CDP/LLDP • readOnly: 1 • Introduced in: 9.8 • x-nullable: true
monitoring	monitoring	
rcf_version	string	The switch reference configuration file (RCF) version.

Name	Type	Description
role	string	Switch role based on the interface configurations. Using '+' to combine multiple roles. Available role types are: cluster, multicluster, storage, multistorage, metrocluster.
serial_number	string	Serial Number.
snmp	snmp	
version	string	Software Version.

_links

job_link

Name	Type	Description
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve FC fabrics

Retrieve FC fabrics

Overview

The Fibre Channel (FC) fabric REST APIs provide read-only access to FC network information. This includes:

- the connections between the ONTAP cluster and the FC fabric,
- the switches that comprise the fabric, and
- the zones of the active zoneset of the fabric.

Caching

Obtaining this information from the FC fabric can be time consuming. To allow the REST API to be more responsive, the APIs always return data from a cache that is updated asynchronously, but only on demand. Cache updates are triggered when the age of cached data exceeds the caller-specified maximum age as specified by the query parameter `cache.maximum_age`.

When a GET request initiates a cache refresh, the API attempts to wait for the update to complete before returning. If the cache cannot be updated before the return timeout (see query parameter `return_timeout`), the GET returns the currently cached data, but the cache update continues asynchronously. The caller may examine the returned property `cache.update_time` or `cache.age` to determine if the returned information is sufficiently fresh. If not, the caller should wait several seconds, then make a GET request again until the returned information is updated.

Examples

Fibre Channel fabric data is typically large. The numbers of rows returned in the following examples has been edited to simplify reading.

Retrieving the Fibre Channel fabrics to which the cluster is connected

This example retrieves the names of the cluster's connected Fibre Channel fabrics. It also retrieves the cache timestamp properties so that the caller can verify the currency of the data.

```
# The API:
GET /api/network/fc/fabrics

# The call:
curl -X GET 'https://<mgmt-ip>/api/network/fc/fabrics?fields=cache' -H
'Accept: application/hal+json'

# The response:
{
"records": [
  {
    "name": "10:00:aa:bb:cc:dd:ee:ff",
    "cache": {
      "update_time": "2022-02-07T21:21:29Z",
```

```
      "age": "PT1M16S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10%3A00%3Aaa%3Abb%3Acc%3Add%3Aee%3Aff"
      }
    }
  },
  {
    "name": "10:00:ff:ee:dd:cc:bb:aa",
    "cache": {
      "update_time": "2022-02-07T21:21:29Z",
      "age": "PT1M16S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10%3A00%3Aff%3Aee%3Add%3Acc%3Abb%3Aaa"
      }
    }
  }
],
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/network/fc/fabrics?fields=cache"
  }
}
}
```

Retrieving all switches of a Fibre Channel fabric

This example retrieves the switches of Fibre Channel fabric `10:00:aa:bb:cc:dd:ee:ff`.

```
# The API:
GET /api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/switches

# The call:
curl -X GET 'https://<mgmt-
ip>/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/switches?fields=cache'
-H 'Accept: application/hal+json'
```

```
# The response:
{
"records": [
  {
    "wwn": "10:00:1a:1b:1c:1d:1e:1f",
    "cache": {
      "update_time": "2022-02-07T21:22:00Z",
      "age": "PT45S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/switches/10:00:1a:1b:1c:1
d:1e:1f"
      }
    }
  },
  {
    "wwn": "10:00:2a:2b:2c:2d:2e:1f",
    "cache": {
      "update_time": "2022-02-07T21:22:00Z",
      "age": "PT45S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/switches/10:00:2a:2b:2c:2
d:2e:1f"
      }
    }
  },
  {
    "wwn": "10:00:3a:3b:3c:3d:3e:3f",
    "cache": {
      "update_time": "2022-02-07T21:22:00Z",
      "age": "PT45S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/switches/10:00:3a:3b:3c:3
d:3e:3f"
```

```
      }
    }
  },
  {
    "wwn": "10:00:4a:4b:4c:4d:4e:4f",
    "cache": {
      "update_time": "2022-02-07T21:22:00Z",
      "age": "PT45S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/switches/10:00:4a:4b:4c:4
d:4e:4f"
      }
    }
  },
  {
    "wwn": "10:00:5a:5b:1a:5c:5d:5e",
    "cache": {
      "update_time": "2022-02-07T21:22:00Z",
      "age": "PT45S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/switches/10:00:5a:5b:1a:5
c:5d:5e"
      }
    }
  }
],
"num_records": 5,
"_links": {
  "self": {
    "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/switches?fields=cache"
  }
}
}
```

Retrieving all zones of the active zoneset of a Fibre Channel fabric

This example retrieves the zone of the active set of Fibre Channel fabric `10:00:aa:bb:cc:dd:ee:ff`.

```
# The API:
GET /api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/zones

# The call:
curl -X GET 'https://<mgmt-
ip>/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/zones?fields=cache' -H
'Accept: application/hal+json'

# The response:
{
"records": [
  {
    "name": "zone1",
    "cache": {
      "update_time": "2022-02-07T20:17:06Z",
      "age": "PT1H17M54S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/zones/zone1"
      }
    }
  },
  {
    "name": "zone2",
    "cache": {
      "update_time": "2022-02-07T20:17:06Z",
      "age": "PT1H17M54S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/zones/zone2"
      }
    }
  },
  {
    "name": "zone3",
    "cache": {
```

```
      "update_time": "2022-02-07T20:17:06Z",
      "age": "PT1H17M54S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/zones/zone3"
      }
    }
  },
  {
    "name": "zone4",
    "cache": {
      "update_time": "2022-02-07T20:17:06Z",
      "age": "PT1H17M54S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/zones/zone4"
      }
    }
  }
],
"num_records": 4,
"_links": {
  "self": {
    "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/zones?fields=cache"
  }
}
}
```

Searching all Fibre Channel fabrics for a specific attached device identified by its WWPN

This example finds the Fibre Channel fabric, switch, and switch port to which the device with WWPN `50:0a:2a:2b:2c:2d:2e:2f` is attached. Note the use of the wildcard character in place of a fabric WWN in order to search all Fibre Channel fabrics.

```
# The API:
GET /api/network/fc/fabrics/*/switches
```

```
# The call:
curl -X GET 'https://<mgmt-
ip>/api/network/fc/fabrics/*/switches?fields=ports,cache&ports.attached_de
vice.wwpn=50:0a:2a:2b:2c:2d:2e:2f' -H 'Accept: application/hal+json'

# The response:
{
"records": [
  {
    "fabric": {
      "name": "10:00:aa:bb:cc:dd:ee:ff",
      "_links": {
        "self": {
          "href":
"/api/network/fc/fabrics/10%3A00%3Aaa%3Abb%3Acc%3Add%3Aee%3Aff"
        }
      }
    },
    "wwn": "10:00:6a:6b:6c:6d:6e:6f",
    "ports": [
      {
        "slot": "0",
        "state": "online",
        "type": "f_port",
        "wwpn": "20:00:1a:1b:1c:1d:1e:1f",
        "attached_device": {
          "port_id": "0x999000",
          "wwpn": "50:0a:1a:1b:1c:1d:1e:1f"
        }
      },
      {
        "slot": "1",
        "state": "online",
        "type": "f_port",
        "wwpn": "20:01:2a:2b:1c:2d:2e:2f",
        "attached_device": {
          "port_id": "0x999100",
          "wwpn": "50:0a:2a:2b:2c:2d:2e:2f"
        }
      },
      {
        "slot": "2",
        "state": "offline",
        "type": "none",
        "wwpn": "20:02:3a:3b:3c:3d:3e:3f"
      },
```

```
      {
        "slot": "3",
        "state": "offline",
        "type": "f_port",
        "wwpn": "20:03:4a:4b:4c:4d:4e:4f",
        "attached_device": {
          "port_id": "0x999300",
          "wwpn": "50:0a:4a:4b:4c:4d:4e:4f"
        }
      },
      {
        "slot": "4",
        "state": "online",
        "type": "f_port",
        "wwpn": "20:04:5a:5b:5c:5d:5e:5f",
        "attached_device": {
          "port_id": "0x999400",
          "wwpn": "50:0a:5a:5b:5c:5d:5e:5f"
        }
      }
    ],
    "cache": {
      "update_time": "2022-02-07T21:57:29Z",
      "age": "PT4M49S",
      "is_current": "true"
    },
    "_links": {
      "self": {
        "href":
"/api/network/fc/fabrics/10:00:aa:bb:cc:dd:ee:ff/switches/10:00:6a:6b:6c:6
d:6e:6f"
      }
    }
  }
],
"num_records": 1,
"_links": {
  "self": {
    "href":
"/api/network/fc/fabrics/*/switches?fields=ports,cache&ports.attached_devi
ce.wwpn=50:0a:2a:2b:2c:2d:2e:2f"
  }
}
}
```

Retrieve FC fabrics

GET `/network/fc/fabrics`

Introduced In: 9.11

Retrieves Fibre Channel fabrics.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `connections`
- `zoneset`

Related ONTAP commands

- `network fcp topology show`
- `network fcp zone show`

Learn more

- DOC /network/fc/fabrics

Parameters

Name	Type	In	Required	Description
zoneset.name	string	query	False	Filter by zoneset.name
connections.switch.wwn	string	query	False	Filter by connections.switch.wwn
connections.switch.port.wwpn	string	query	False	Filter by connections.switch.port.wwpn
connections.cluster_port.name	string	query	False	Filter by connections.cluster_port.name
connections.cluster_port.node.name	string	query	False	Filter by connections.cluster_port.node.name

Name	Type	In	Required	Description
connections.cluster_port.uuid	string	query	False	Filter by connections.cluster_port.uuid
connections.cluster_port.wwpn	string	query	False	Filter by connections.cluster_port.wwpn
name	string	query	False	Filter by name
cache.is_current	boolean	query	False	Filter by cache.is_current
cache.update_time	string	query	False	Filter by cache.update_time
cache.age	string	query	False	Filter by cache.age
cache.maximum_age	string	query	False	The maximum age of data in the Fibre Channel fabric cache before it should be refreshed from the fabric. The default is 15 minutes. • Default value: 1 • format: iso8601
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[fabric]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "cache": {
        "age": "PT3M30S",
        "update_time": "string"
      },
      "connections": [
        {
          "cluster_port": {
            "_links": {
              "self": {
                "href": "/api/resourcelink"
              }
            },
            "name": "0a",
            "node": {
              "name": "node1"
            },
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
            "wwpn": "50:0a:11:22:33:44:55:66"
          },
          "switch": {
            "_links": {
              "self": {
                "href": "/api/resourcelink"
              }
            },
            "port": {
              "wwpn": "50:0a:a1:a2:a3:a4:a5:a6"
```

```
            },
            "wwn": "10:00:b1:b2:b3:b4:b4:b6"
          }
        }
      ],
      "name": "10:00:c1:c2:c3:c4:c5:c6",
      "zoneset": {
        "name": "zoneset1"
      }
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

cache

Properties of Fibre Chanel fabric cache.

Name	Type	Description
age	string	The age of the Fibre Channel fabric data cache retrieved. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved. The value is in ISO 8601 duration format.
is_current	boolean	A boolean that indicates if the retrieved data is current relative to the `cache.maximum_age` value of the request. A value of `true` indicates that the data is no older than the requested maximum age. A value of `false` indicates that the data is older than the requested maximum age; if more current data is required, the caller should wait for some time for the cache update to complete and query the data again.

Name	Type	Description
update_time	string	The date and time at which the Fibre Channel fabric data cache retrieved was last updated. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved.

node

The node on which the cluster Fibre Channel port is located.

Name	Type	Description
name	string	The name of the node on which the cluster Fibre Channel port is located.

cluster_port

The cluster Fibre Channel (FC) port that connects the FC fabric.

Name	Type	Description
_links	_links	
name	string	The name of the cluster Fibre Channel port.
node	node	The node on which the cluster Fibre Channel port is located.
uuid	string	The unique identifier of the cluster Fibre Channel port.
wwpn	string	The world wide port name (WWPN) of the cluster Fibre Channel port.

port

The port of the Fibre Channel switch to which the cluster node port is connected.

Name	Type	Description
wwpn	string	The world wide port name (WWPN) of the Fibre Channel switch port.

switch

The Fibre Channel switch to which the cluster node port is connected.

Name	Type	Description
_links	_links	
port	port	The port of the Fibre Channel switch to which the cluster node port is connected.
wwn	string	The world-wide name (WWN) of the Fibre Channel switch to which the cluster node port is attached.

connections

A connection between a cluster node Fibre Channel (FC) port and an FC switch port.

Name	Type	Description
cluster_port	cluster_port	The cluster Fibre Channel (FC) port that connects the FC fabric.
switch	switch	The Fibre Channel switch to which the cluster node port is connected.

zoneset

The active Fibre Channel zoneset in the fabric.

Name	Type	Description
name	string	The name of the Fibre Channel zoneset.

fabric

A Fibre Channel (FC) fabric REST object provides information about an FC network (fabric) connected to the cluster. Logically, the FC fabric also contains FC switches and the FC zones that comprise the active zoneset of the fabric. FC switch and zone information is not reported directly in the FC fabric REST object for reasons of scale and flexibility; they are found by querying the FC switches and FC zones REST endpoints.

Name	Type	Description
_links	_links	
cache	cache	Properties of Fibre Chanel fabric cache.
connections	array[connections]	An array of the connections between the cluster and the switches Fibre Channel fabric.
name	string	The world wide name (WWN) of the primary switch of the Fibre Channel (FC) fabric. This is used as a unique identifier for the FC fabric.
zoneset	zoneset	The active Fibre Channel zoneset in the fabric.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve FC fabric switches

GET `/network/fc/fabrics/{fabric.name}/switches`

Introduced In: 9.11

Retrieves the Fibre Channel switches of a Fibre Channel fabric.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `ports`

Related ONTAP commands

- `network fcp topology show`

Learn more

- DOC /network/fc/fabrics

Parameters

Name	Type	In	Required	Description
fabric.name	string	path	True	The WWN of the primary switch of the Fibre Channel fabric.
name	string	query	False	Filter by name
release	string	query	False	Filter by release
vendor	string	query	False	Filter by vendor
wwn	string	query	False	Filter by wwn
cache.age	string	query	False	Filter by cache.age
cache.update_time	string	query	False	Filter by cache.update_time
cache.is_current	boolean	query	False	Filter by cache.is_current
domain_id	integer	query	False	Filter by domain_id • Max value: 239 • Min value: 1
ports.state	string	query	False	Filter by ports.state
ports.slot	string	query	False	Filter by ports.slot

Name	Type	In	Required	Description
ports.type	string	query	False	Filter by ports.type
ports.attached_device.wwpn	string	query	False	Filter by ports.attached_device.wwpn
ports.attached_device.port_id	string	query	False	Filter by ports.attached_device.port_id
ports.wwpn	string	query	False	Filter by ports.wwpn
cache.maximum_age	string	query	False	The maximum age of data in the Fibre Channel fabric cache before it should be refreshed from the fabric. The default is 15 minutes. • Default value: 1 • format: iso8601
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Max value: 120 • Min value: 0 • Default value: 15
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[fc_switch]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "cache": {
        "age": "PT3M30S",
        "update_time": "string"
      },
      "domain_id": 1,
      "fabric": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "10:00:d1:d2:d3:d4:d5:d6"
      },
      "name": "switch1",
      "ports": [
        {
          "attached_device": {
            "port_id": 70400,
            "wwpn": "50:0a:21:22:23:24:25:26"
          },
          "slot": 1,
          "state": "online",
          "type": "string",
          "wwpn": "50:0a:31:32:33:34:35:36"
        }
      ],
      "release": "1.0.",
```

```
      "vendor": "vendor1",
      "wwn": "10:00:e1:e2:e3:e4:e5:e6"
    }
  ]
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
5373982	An invalid WWN was specified. The length is incorrect.
5373983	An invalid WWN was specified. The format is incorrect.
5375053	The Fibre Channel fabric specified by name in the request URI was not found in the FC fabric cache.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

cache

Properties of Fibre Chanel fabric cache.

Name	Type	Description
age	string	The age of the Fibre Channel fabric data cache retrieved. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved. The value is in ISO 8601 duration format.
is_current	boolean	A boolean that indicates if the retrieved data is current relative to the `cache.maximum_age` value of the request. A value of `true` indicates that the data is no older than the requested maximum age. A value of `false` indicates that the data is older than the requested maximum age; if more current data is required, the caller should wait for some time for the cache update to complete and query the data again.

Name	Type	Description
update_time	string	The date and time at which the Fibre Channel fabric data cache retrieved was last updated. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved.

fabric

A reference to a Fibre Channel fabric.

Name	Type	Description
_links	_links	
name	string	The world wide name (WWN) of the primary switch of the Fibre Channel (FC) fabric. This is used as a unique identifier for the FC fabric.

attached_device

The Fibre Channel (FC) device attached to the FC switch port.

Name	Type	Description
port_id	string	The Fibre Channel port identifier of the attach device.
wwpn	string	The world-wide port name (WWPN) of the attached device.

ports

A Fibre Channel switch port.

Name	Type	Description
attached_device	attached_device	The Fibre Channel (FC) device attached to the FC switch port.
slot	string	The slot of the Fibre Channel switch port.

Name	Type	Description
state	string	The state of the Fibre Channel switch port.
type	string	The type of the Fibre Channel switch port.
wwpn	string	The world wide port name (WWPN) of the Fibre Channel switch port.

fc_switch

A Fibre Channel switch.

Name	Type	Description
_links	_links	
cache	cache	Properties of Fibre Chanel fabric cache.
domain_id	integer	The domain identifier (ID) of the Fibre Channel (FC) switch. The domain ID is a unique identifier for the FC switch in the FC fabric.
fabric	fabric	A reference to a Fibre Channel fabric.
name	string	The logical name of the Fibre Channel switch.
ports	array[ports]	An array of the Fibre Channel (FC) switch's ports and their attached FC devices.
release	string	The firmware release of the Fibre Channel switch.
vendor	string	The vendor of the Fibre Channel switch.
wwn	string	The world-wide name (WWN) for the Fibre Channel switch.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve an FC switch

GET `/network/fc/fabrics/{fabric.name}/switches/{wwn}`

Introduced In: 9.11

Retrieves a Fibre Channel switch.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `ports`

Related ONTAP commands

- `network fcp topology show`

Learn more

- DOC /network/fc/fabrics

Parameters

Name	Type	In	Required	Description
fabric.name	string	path	True	The WWN of the primary switch of the Fibre Channel fabric.
wwn	string	path	True	The WWN of the Fibre Channel switch.
cache.maximum_age	string	query	False	The maximum age of data in the Fibre Channel fabric cache before it should be refreshed from the fabric. The default is 15 minutes. • Default value: 1 • format: iso8601
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
cache	cache	Properties of Fibre Chanel fabric cache.
domain_id	integer	The domain identifier (ID) of the Fibre Channel (FC) switch. The domain ID is a unique identifier for the FC switch in the FC fabric.
fabric	fabric	A reference to a Fibre Channel fabric.
name	string	The logical name of the Fibre Channel switch.

Name	Type	Description
ports	array[ports]	An array of the Fibre Channel (FC) switch's ports and their attached FC devices.
release	string	The firmware release of the Fibre Channel switch.
vendor	string	The vendor of the Fibre Channel switch.
wwn	string	The world-wide name (WWN) for the Fibre Channel switch.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "cache": {
    "age": "PT3M30S",
    "update_time": "string"
  },
  "domain_id": 1,
  "fabric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "10:00:d1:d2:d3:d4:d5:d6"
  },
  "name": "switch1",
  "ports": [
    {
      "attached_device": {
        "port_id": 70400,
        "wwpn": "50:0a:21:22:23:24:25:26"
      },
      "slot": 1,
      "state": "online",
      "type": "string",
      "wwpn": "50:0a:31:32:33:34:35:36"
    }
  ],
  "release": "1.0.",
  "vendor": "vendor1",
  "wwn": "10:00:e1:e2:e3:e4:e5:e6"
}
```


Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
5373982	An invalid WWN was specified. The length is incorrect.
5373983	An invalid WWN was specified. The format is incorrect.
5375053	The Fibre Channel fabric specified by name in the request URI was not found in the FC fabric cache.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

cache

Properties of Fibre Chanel fabric cache.

Name	Type	Description
age	string	The age of the Fibre Channel fabric data cache retrieved. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved. The value is in ISO 8601 duration format.
is_current	boolean	A boolean that indicates if the retrieved data is current relative to the `cache.maximum_age` value of the request. A value of `true` indicates that the data is no older than the requested maximum age. A value of `false` indicates that the data is older than the requested maximum age; if more current data is required, the caller should wait for some time for the cache update to complete and query the data again.

Name	Type	Description
update_time	string	The date and time at which the Fibre Channel fabric data cache retrieved was last updated. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved.

fabric

A reference to a Fibre Channel fabric.

Name	Type	Description
_links	_links	
name	string	The world wide name (WWN) of the primary switch of the Fibre Channel (FC) fabric. This is used as a unique identifier for the FC fabric.

attached_device

The Fibre Channel (FC) device attached to the FC switch port.

Name	Type	Description
port_id	string	The Fibre Channel port identifier of the attach device.
wwpn	string	The world-wide port name (WWPN) of the attached device.

ports

A Fibre Channel switch port.

Name	Type	Description
attached_device	attached_device	The Fibre Channel (FC) device attached to the FC switch port.
slot	string	The slot of the Fibre Channel switch port.

Name	Type	Description
state	string	The state of the Fibre Channel switch port.
type	string	The type of the Fibre Channel switch port.
wwpn	string	The world wide port name (WWPN) of the Fibre Channel switch port.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve FC fabric zones

GET `/network/fc/fabrics/{fabric.name}/zones`

Introduced In: 9.11

Retrieves the zones of the active zoneset of a Fibre Channel fabric.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `members`

Related ONTAP commands

- `network fcp zone show`

Learn more

- DOC /network/fc/fabrics

Parameters

Name	Type	In	Required	Description
fabric.name	string	path	True	The WWN of the primary switch of the Fibre Channel fabric.
name	string	query	False	Filter by name
cache.age	string	query	False	Filter by cache.age
cache.is_current	boolean	query	False	Filter by cache.is_current
cache.update_time	string	query	False	Filter by cache.update_time
members.name	string	query	False	Filter by members.name
members.type	string	query	False	Filter by members.type
cache.maximum_age	string	query	False	The maximum age of data in the Fibre Channel fabric cache before it should be refreshed from the fabric. The default is 15 minutes. • Default value: 1 • format: iso8601
fields	array[string]	query	False	Specify the fields to return.

Name	Type	In	Required	Description
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[fc_zone]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "cache": {
        "age": "PT3M30S",
        "update_time": "string"
      },
      "fabric": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "10:00:d1:d2:d3:d4:d5:d6"
      },
      "members": [
        {
          "name": "10:00:12:34:56:78:9a:bc",
          "type": "port_name"
        }
      ],
      "name": "zone1"
    }
  ]
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
5373982	An invalid WWN was specified. The length is incorrect.
5373983	An invalid WWN was specified. The format is incorrect.
5375053	The Fibre Channel fabric specified by name in the request URI was not found in the FC fabric cache.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

cache

Properties of Fibre Chanel fabric cache.

Name	Type	Description
age	string	The age of the Fibre Channel fabric data cache retrieved. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved. The value is in ISO 8601 duration format.
is_current	boolean	A boolean that indicates if the retrieved data is current relative to the `cache.maximum_age` value of the request. A value of `true` indicates that the data is no older than the requested maximum age. A value of `false` indicates that the data is older than the requested maximum age; if more current data is required, the caller should wait for some time for the cache update to complete and query the data again.

Name	Type	Description
update_time	string	The date and time at which the Fibre Channel fabric data cache retrieved was last updated. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved.

fabric

A reference to a Fibre Channel fabric.

Name	Type	Description
_links	_links	
name	string	The world wide name (WWN) of the primary switch of the Fibre Channel (FC) fabric. This is used as a unique identifier for the FC fabric.

members

A Fibre Channel zone member.

Name	Type	Description
name	string	The identifying property value of the zone member. The format of this value depends on the member type: • `port_id`: A zero-filled 6-digit hexadecimal value with a 0x prefer. Example: 0x0000A0. • `port_name`: A world-wide name. Example: 10:00:12:34:56:78:9a:bc. • `domain_id_port`: A domain ID and a port ID as decimal integers separated by a slash. Example: 1/2. • `node_name`: A world-wide name. Example: 10:00:11:22:33:44:55:66. • `fabric_port_name`: A world-wide name. Example: 10:00:ab:cd:ef:12:34:56. # The following types might not report a name: • `interface` • `domain_interface` • `ip_address` • `symbolic_node_name` • `device_alias`
type	string	The type of Fibre Channel zone member. This value should be used to interpret the contents of the `name` property.

fc_zone

A Fibre Channel zone.

Name	Type	Description
_links	_links	

Name	Type	Description
cache	cache	Properties of Fibre Chanel fabric cache.
fabric	fabric	A reference to a Fibre Channel fabric.
members	array[members]	An array of Fibre Channel zone members.
name	string	The name of the Fibre Channel zone.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve an FC fabric zone

GET `/network/fc/fabrics/{fabric.name}/zones/{name}`

Introduced In: 9.11

Retrieves a zone of the active zoneset of a Fibre Channel fabric.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `members`

Related ONTAP commands

- `network fcp zone show`

Learn more

- DOC /network/fc/fabrics

Parameters

Name	Type	In	Required	Description
fabric.name	string	path	True	The WWN of the primary switch of the Fibre Channel fabric.
name	string	path	True	The name of a zone in the active zoneset the Fibre Channel fabric.
cache.maximum_age	string	query	False	The maximum age of data in the Fibre Channel fabric cache before it should be refreshed from the fabric. The default is 15 minutes. • Default value: 1 • format: iso8601
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
cache	cache	Properties of Fibre Chanel fabric cache.

Name	Type	Description
fabric	fabric	A reference to a Fibre Channel fabric.
members	array[members]	An array of Fibre Channel zone members.
name	string	The name of the Fibre Channel zone.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "cache": {
    "age": "PT3M30S",
    "update_time": "string"
  },
  "fabric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "10:00:d1:d2:d3:d4:d5:d6"
  },
  "members": [
    {
      "name": "10:00:12:34:56:78:9a:bc",
      "type": "port_name"
    }
  ],
  "name": "zone1"
}
```


Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
5373982	An invalid WWN was specified. The length is incorrect.
5373983	An invalid WWN was specified. The format is incorrect.
5375053	The Fibre Channel fabric specified by name in the request URI was not found in the FC fabric cache.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

cache

Properties of Fibre Chanel fabric cache.

Name	Type	Description
age	string	The age of the Fibre Channel fabric data cache retrieved. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved. The value is in ISO 8601 duration format.
is_current	boolean	A boolean that indicates if the retrieved data is current relative to the `cache.maximum_age` value of the request. A value of `true` indicates that the data is no older than the requested maximum age. A value of `false` indicates that the data is older than the requested maximum age; if more current data is required, the caller should wait for some time for the cache update to complete and query the data again.

Name	Type	Description
update_time	string	The date and time at which the Fibre Channel fabric data cache retrieved was last updated. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved.

fabric

A reference to a Fibre Channel fabric.

Name	Type	Description
_links	_links	
name	string	The world wide name (WWN) of the primary switch of the Fibre Channel (FC) fabric. This is used as a unique identifier for the FC fabric.

members

A Fibre Channel zone member.

Name	Type	Description
name	string	The identifying property value of the zone member. The format of this value depends on the member type: • `port_id`: A zero-filled 6-digit hexadecimal value with a 0x prefer. Example: 0x0000A0. • `port_name`: A world-wide name. Example: 10:00:12:34:56:78:9a:bc. • `domain_id_port`: A domain ID and a port ID as decimal integers separated by a slash. Example: 1/2. • `node_name`: A world-wide name. Example: 10:00:11:22:33:44:55:66. • `fabric_port_name`: A world-wide name. Example: 10:00:ab:cd:ef:12:34:56. # The following types might not report a name: • `interface` • `domain_interface` • `ip_address` • `symbolic_node_name` • `device_alias`
type	string	The type of Fibre Channel zone member. This value should be used to interpret the contents of the `name` property.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve an FC fabric

GET `/network/fc/fabrics/{name}`

Introduced In: 9.11

Retrieves a Fibre Channel fabric.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `connections`
- `zoneset`

Related ONTAP commands

- `network fcp topology show`
- `network fcp zone show`

Learn more

- DOC /network/fc/fabrics

Parameters

Name	Type	In	Required	Description
name	string	path	True	The world wide name (WWN) of the primary switch of the Fibre Channel fabric.

Name	Type	In	Required	Description
cache.maximum_age	string	query	False	The maximum age of data in the Fibre Channel fabric cache before it should be refreshed from the fabric. The default is 15 minutes. • Default value: 1 • format: iso8601
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
cache	cache	Properties of Fibre Chanel fabric cache.
connections	array[connections]	An array of the connections between the cluster and the switches Fibre Channel fabric.
name	string	The world wide name (WWN) of the primary switch of the Fibre Channel (FC) fabric. This is used as a unique identifier for the FC fabric.
zoneset	zoneset	The active Fibre Channel zoneset in the fabric.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "cache": {
    "age": "PT3M30S",
    "update_time": "string"
  },
  "connections": [
    {
      "cluster_port": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "0a",
        "node": {
          "name": "node1"
        },
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
        "wwpn": "50:0a:11:22:33:44:55:66"
      },
      "switch": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "port": {
          "wwpn": "50:0a:a1:a2:a3:a4:a5:a6"
        },
        "wwn": "10:00:b1:b2:b3:b4:b4:b6"
      }
    }
  ],
  "name": "10:00:c1:c2:c3:c4:c5:c6",
  "zoneset": {
    "name": "zoneset1"
  }
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
5373982	An invalid WWN was specified. The length is incorrect.
5373983	An invalid WWN was specified. The format is incorrect.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

cache

Properties of Fibre Chanel fabric cache.

Name	Type	Description
age	string	The age of the Fibre Channel fabric data cache retrieved. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved. The value is in ISO 8601 duration format.
is_current	boolean	A boolean that indicates if the retrieved data is current relative to the `cache.maximum_age` value of the request. A value of `true` indicates that the data is no older than the requested maximum age. A value of `false` indicates that the data is older than the requested maximum age; if more current data is required, the caller should wait for some time for the cache update to complete and query the data again.

Name	Type	Description
update_time	string	The date and time at which the Fibre Channel fabric data cache retrieved was last updated. If the FC fabric data cache has not been fully updated for a newly discovered fabric, or a fabric that has been re-discovered after being purged, a value for this property will not be retrieved.

node

The node on which the cluster Fibre Channel port is located.

Name	Type	Description
name	string	The name of the node on which the cluster Fibre Channel port is located.

cluster_port

The cluster Fibre Channel (FC) port that connects the FC fabric.

Name	Type	Description
_links	_links	
name	string	The name of the cluster Fibre Channel port.
node	node	The node on which the cluster Fibre Channel port is located.
uuid	string	The unique identifier of the cluster Fibre Channel port.
wwpn	string	The world wide port name (WWPN) of the cluster Fibre Channel port.

port

The port of the Fibre Channel switch to which the cluster node port is connected.

Name	Type	Description
wwpn	string	The world wide port name (WWPN) of the Fibre Channel switch port.

switch

The Fibre Channel switch to which the cluster node port is connected.

Name	Type	Description
_links	_links	
port	port	The port of the Fibre Channel switch to which the cluster node port is connected.
wwn	string	The world-wide name (WWN) of the Fibre Channel switch to which the cluster node port is attached.

connections

A connection between a cluster node Fibre Channel (FC) port and an FC switch port.

Name	Type	Description
cluster_port	cluster_port	The cluster Fibre Channel (FC) port that connects the FC fabric.
switch	switch	The Fibre Channel switch to which the cluster node port is connected.

zoneset

The active Fibre Channel zoneset in the fabric.

Name	Type	Description
name	string	The name of the Fibre Channel zoneset.

error_arguments

Name	Type	Description
code	string	Argument code

Name	Type	Description
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage FC network interfaces

Manage FC network interfaces

Overview

Fibre Channel (FC) interfaces are the logical endpoints for FC network connections to an SVM. An FC interface provides FC access to storage within the interface SVM using either Fibre Channel Protocol (FCP) or NVMe over FC (NVMe/FC).

The FC interface REST API allows you to create, delete, update, and discover FC interfaces, and obtain status information for FC interfaces.

An FC interface is created on an FC port which is located on a cluster node. The FC port must be specified to identify the location of the interface for a POST or PATCH request that relocates an interface. You can identify the port by supplying either the node and port names or the port UUID.

Performance monitoring

Performance of an FC interface can be monitored by observing the `metric.*` and `statistics.*` properties. These properties show the performance of an FC interface in terms of IOPS, latency, and throughput. The `metric.*` properties denote an average, whereas `statistics.*` properties denote a real-time monotonically increasing value aggregated across all nodes.

Interface placement recommendations

The FC interface REST API can also recommend the placement (cluster nodes and FC ports) for FC interfaces for a new or existing SVM as well as evaluate caller-proposed locations for FC interfaces. This functionality is available to cluster administrators only and is accessed using `GET /network/fc/interfaces` with the `recommend` family of query parameters.

The query parameter `recommend.data_protocol` is required when getting recommendations or evaluating

caller-proposed locations for FC interfaces. It identifies the type of FC interfaces to recommend. Other `recommend` query parameters are optional and are used to modify the recommendation algorithm.

If an SVM is supplied using the query parameter `recommend.svm.name` and/or `recommend.svm.uuid`, existing FC interfaces are considered as part of the overall solution and only additionally recommended interfaces are returned. If no SVM is supplied, recommendations are returned for a new SVM.

FC fabrics connected to the cluster are discovered by the API. By default, FC interfaces are placed and evaluated for each fabric. The query parameter `recommend.fabrics.name` can be used to identify specific FC fabrics to use.

Cluster nodes supporting FC fabric connections for the specific data protocol are discovered by the API. By default, FC interfaces are placed all supported cluster nodes. Either query parameter `recommend.nodes.name` or `recommend.nodes.uuid` can be used to identify specific cluster nodes to use.

FC interfaces for the FC-NVMe data protocol are limited to two (2) interfaces per cluster node with a maximum of four (4) nodes, within a single SVM.

Placement recommendations are best effort and limited by the information available. In situations where an optimum configuration cannot be produced, the API returns the recommendations it can along with messages describing how the caller might improve the configuration. These messages are produced by evaluating the calculated FC interface layout against best practices.

The same best practice evaluation can be applied to a caller-proposed configuration by using the query parameter `recommend.proposed.locations.port.uuid` to specify the locations for proposed FC interfaces. When this query parameter is supplied, the best practice evaluation is performed using the proposed interface locations and messages are produced describing how the caller might improve the configuration.

Examples

Creating an FC interface using the port node and name to identify the location

This example uses the `return_records` query parameter to retrieve the newly created FC interface in the POST response.

```
# The API:
POST /api/network/fc/interfaces

# The call:
curl -X POST 'https://<mgmt-
ip>/api/network/fc/interfaces?return_records=true' -H 'Accept:
application/hal+json' -d '{ "svm": { "name": "svm1" }, "name": "lif1",
"location": { "home_port": { "name": "0a", "home_node": { "name": "node1"
} } }, "data_protocol": "fcp" }'

# The response:
{
"num_records": 1,
"records": [
  {
```

```
    "svm": {
      "uuid": "cf300f5c-db83-11e8-bd46-005056bba0e0",
      "name": "svm1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/cf300f5c-db83-11e8-bd46-005056bba0e0"
        }
      }
    },
    "uuid": "f6045b92-dec7-11e8-a733-005056bba0e0",
    "name": "lif1",
    "location": {
      "home_node": {
        "uuid": "bafe9b9f-db81-11e8-bd46-005056bba0e0",
        "name": "node1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/bafe9b9f-db81-11e8-bd46-
005056bba0e0"
          }
        }
      },
      "home_port": {
        "uuid": "300c1ae3-db82-11e8-bd46-005056bba0e0",
        "name": "0a",
        "node": {
          "name": "node1"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/300c1ae3-db82-11e8-bd46-
005056bba0e0"
          }
        }
      },
      "node": {
        "uuid": "bafe9b9f-db81-11e8-bd46-005056bba0e0",
        "name": "node1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/bafe9b9f-db81-11e8-bd46-
005056bba0e0"
          }
        }
      },
      "port": {
```

```
        "uuid": "300c1ae3-db82-11e8-bd46-005056bba0e0",
        "name": "0a",
        "node": {
          "name": "node1"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/300c1ae3-db82-11e8-bd46-
005056bba0e0"
          }
        }
      }
    },
    "enabled": true,
    "state": "down",
    "data_protocol": "fcp",
    "wwpn": "20:04:00:50:56:bb:a0:e0",
    "wwnn": "20:00:00:50:56:bb:a0:e0",
    "port_address": "9da2cb1",
    "_links": {
      "self": {
        "href": "/api/network/fc/interfaces/f6045b92-dec7-11e8-a733-
005056bba0e0"
      }
    }
  }
]
}
```

Creating an FC interface using the port UUID to identify the location

This example uses the `return_records` query parameter to retrieve the newly created FC interface in the POST response.

```
# The API:
POST /api/network/fc/interfaces

# The call:
curl -X POST 'https://<mgmt-
ip>/api/network/fc/interfaces?return_records=true' -H 'Accept:
application/hal+json' -d '{ "svm": { "name": "svm3" }, "name": "lif2",
"location": { "home_port": { "uuid": "24bb636a-db83-11e8-9a49-
005056bb1ec6" } }, "data_protocol": "fc_nvme" }'
```

```
# The response:
{
"num_records": 1,
"records": [
  {
    "svm": {
      "uuid": "a5060466-dbab-11e8-bd46-005056bba0e0",
      "name": "svm3",
      "_links": {
        "self": {
          "href": "/api/svm/svms/a5060466-dbab-11e8-bd46-005056bba0e0"
        }
      }
    },
    "uuid": "cdeb5591-dec9-11e8-a733-005056bba0e0",
    "name": "lif2",
    "location": {
      "home_node": {
        "uuid": "e85aa147-db83-11e8-9a48-005056bb1ec6",
        "name": "node3",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/e85aa147-db83-11e8-9a48-
005056bb1ec6"
          }
        }
      },
      "home_port": {
        "uuid": "24bb636a-db83-11e8-9a49-005056bb1ec6",
        "name": "1b",
        "node": {
          "name": "node3"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/24bb636a-db83-11e8-9a49-
005056bb1ec6"
          }
        }
      },
      "node": {
        "uuid": "e85aa147-db83-11e8-9a48-005056bb1ec6",
        "name": "node3",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/e85aa147-db83-11e8-9a48-
```

```
005056bb1ec6"
          }
        }
      },
      "port": {
        "uuid": "24bb636a-db83-11e8-9a49-005056bb1ec6",
        "name": "1b",
        "node": {
          "name": "node3"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/24bb636a-db83-11e8-9a49-
005056bb1ec6"
          }
        }
      }
    },
    "enabled": true,
    "state": "down",
    "data_protocol": "fc_nvme",
    "wwpn": "20:05:00:50:56:bb:a0:e0",
    "wwnn": "20:02:00:50:56:bb:a0:e0",
    "port_address": "612e202b",
    "_links": {
      "self": {
        "href": "/api/network/fc/interfaces/cdeb5591-dec9-11e8-a733-
005056bba0e0"
      }
    }
  }
]
}
```

Retrieving all properties for all FC interfaces

This example uses the `fields` query parameter to retrieve all properties.

```
# The API:
GET /api/network/fc/interfaces

# The call:
curl -X GET 'https://<mgmt-ip>/api/network/fc/interfaces?fields=*' -H
'Accept: application/hal+json'
```

```
# The response:
{
"records": [
  {
    "svm": {
      "uuid": "a5060466-dbab-11e8-bd46-005056bba0e0",
      "name": "svm3",
      "_links": {
        "self": {
          "href": "/api/svm/svms/a5060466-dbab-11e8-bd46-005056bba0e0"
        }
      }
    },
    "uuid": "cdeb5591-dec9-11e8-a733-005056bba0e0",
    "name": "lif2",
    "location": {
      "home_node": {
        "uuid": "e85aa147-db83-11e8-9a48-005056bb1ec6",
        "name": "node3",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/e85aa147-db83-11e8-9a48-
005056bb1ec6"
          }
        }
      },
      "home_port": {
        "uuid": "24bb636a-db83-11e8-9a49-005056bb1ec6",
        "name": "1b",
        "node": {
          "name": "node3"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/24bb636a-db83-11e8-9a49-
005056bb1ec6"
          }
        }
      },
      "node": {
        "uuid": "e85aa147-db83-11e8-9a48-005056bb1ec6",
        "name": "node3",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/e85aa147-db83-11e8-9a48-
```

```
005056bb1ec6"
          }
        }
      },
      "port": {
        "uuid": "24bb636a-db83-11e8-9a49-005056bb1ec6",
        "name": "1b",
        "node": {
          "name": "node3"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/24bb636a-db83-11e8-9a49-
005056bb1ec6"
          }
        }
      }
    },
    "enabled": true,
    "state": "down",
    "data_protocol": "fc_nvme",
    "wwpn": "20:05:00:50:56:bb:a0:e0",
    "wwnn": "20:02:00:50:56:bb:a0:e0",
    "port_address": "612e202b",
    "_links": {
      "self": {
        "href": "/api/network/fc/interfaces/cdeb5591-dec9-11e8-a733-
005056bba0e0"
      }
    }
  },
  {
    "svm": {
      "uuid": "cf300f5c-db83-11e8-bd46-005056bba0e0",
      "name": "svm1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/cf300f5c-db83-11e8-bd46-005056bba0e0"
        }
      }
    },
    "uuid": "f6045b92-dec7-11e8-a733-005056bba0e0",
    "name": "lif1",
    "location": {
      "home_node": {
        "uuid": "bafe9b9f-db81-11e8-bd46-005056bba0e0",
```

```
        "name": "node1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/bafe9b9f-db81-11e8-bd46-
005056bba0e0"
          }
        }
      },
      "home_port": {
        "uuid": "300c1ae3-db82-11e8-bd46-005056bba0e0",
        "name": "0a",
        "node": {
          "name": "node1"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/300c1ae3-db82-11e8-bd46-
005056bba0e0"
          }
        }
      },
      "node": {
        "uuid": "bafe9b9f-db81-11e8-bd46-005056bba0e0",
        "name": "node1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/bafe9b9f-db81-11e8-bd46-
005056bba0e0"
          }
        }
      },
      "port": {
        "uuid": "300c1ae3-db82-11e8-bd46-005056bba0e0",
        "name": "0a",
        "node": {
          "name": "node1"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/300c1ae3-db82-11e8-bd46-
005056bba0e0"
          }
        }
      }
    },
    "enabled": true,
```

```
    "state": "down",
    "data_protocol": "fcp",
    "wwpn": "20:04:00:50:56:bb:a0:e0",
    "wwnn": "20:00:00:50:56:bb:a0:e0",
    "port_address": "9da2cb1",
    "_links": {
      "self": {
        "href": "/api/network/fc/interfaces/f6045b92-dec7-11e8-a733-
005056bba0e0"
      }
    }
  }
],
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/network/fc/interfaces?fields=*"
  }
}
}
```

Retrieving a list of selected FC interfaces

This example uses property query parameters to retrieve FC interfaces configured for the FC Protocol that are set to *up*.

```
# The API:
GET /api/network/fc/interfaces

# The call:
curl -X GET 'https://<mgmt-
ip>/api/network/fc/interfaces?data_protocol=fcp&state=up' -H 'Accept:
application/hal+json'

# The response:
{
"records": [
  {
    "svm": {
      "uuid": "cf300f5c-db83-11e8-bd46-005056bba0e0",
      "name": "svm1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/cf300f5c-db83-11e8-bd46-005056bba0e0"
        }
      }
    },
    "uuid": "f6045b92-dec7-11e8-a733-005056bba0e0",
    "name": "lif1",
    "state": "up",
    "data_protocol": "fcp",
    "_links": {
      "self": {
        "href": "/api/network/fc/interfaces/f6045b92-dec7-11e8-a733-
005056bba0e0"
      }
    }
  }
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/network/fc/interfaces?data_protocol=fcp&state=up"
  }
}
}
```

Retrieving a specific FC interface

```
# The API:
GET /api/network/fc/interfaces/{uuid}

# The call:
curl -X GET 'https://<mgmt-ip>/api/network/fc/interfaces/cdeb5591-dec9-
11e8-a733-005056bba0e0' -H 'Accept: application/hal+json'

# The response:
{
"svm": {
  "uuid": "a5060466-dbab-11e8-bd46-005056bba0e0",
  "name": "svm3",
  "_links": {
    "self": {
      "href": "/api/svm/svms/a5060466-dbab-11e8-bd46-005056bba0e0"
    }
  }
},
"uuid": "cdeb5591-dec9-11e8-a733-005056bba0e0",
"name": "lif2",
"location": {
  "home_node": {
    "uuid": "e85aa147-db83-11e8-9a48-005056bb1ec6",
    "name": "node3",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/e85aa147-db83-11e8-9a48-005056bb1ec6"
      }
    }
  },
  "home_port": {
    "uuid": "24bb636a-db83-11e8-9a49-005056bb1ec6",
    "name": "1b",
    "node": {
      "name": "node3"
    },
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/24bb636a-db83-11e8-9a49-
005056bb1ec6"
      }
    }
  },
  "node": {
```

```
    "uuid": "e85aa147-db83-11e8-9a48-005056bb1ec6",
    "name": "node3",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/e85aa147-db83-11e8-9a48-005056bb1ec6"
      }
    }
  },
  "port": {
    "uuid": "24bb636a-db83-11e8-9a49-005056bb1ec6",
    "name": "1b",
    "node": {
      "name": "node3"
    },
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/24bb636a-db83-11e8-9a49-
005056bb1ec6"
      }
    }
  }
},
"enabled": true,
"state": "down",
"data_protocol": "fc_nvme",
"wwpn": "20:05:00:50:56:bb:a0:e0",
"wwnn": "20:02:00:50:56:bb:a0:e0",
"port_address": "612e202b",
"metric": {
  "timestamp": "2019-04-09T05:50:15Z",
  "duration": "PT15S",
  "status": "ok",
  "latency": {
    "other": 0,
    "total": 0,
    "read": 0,
    "write": 0
  },
  "iops": {
    "read": 0,
    "write": 0,
    "other": 0,
    "total": 0
  },
  "throughput": {
    "read": 0,
```

```
    "write": 0,
    "total": 0
  }
},
"statistics": {
  "timestamp": "2019-04-09T05:50:42Z",
  "status": "ok",
  "latency_raw": {
    "other": 38298,
    "total": 38298,
    "read": 0,
    "write": 0
  },
  "iops_raw": {
    "read": 0,
    "write": 0,
    "other": 3,
    "total": 3
  },
  "throughput_raw": {
    "read": 0,
    "write": 0,
    "total": 0
  }
},
"_links": {
  "self": {
    "href": "/api/network/fc/interfaces/cdeb5591-dec9-11e8-a733-
005056bba0e0"
  }
}
}
```

Disabling an FC interface

When updating certain properties of an FC interface, the interface must first be disabled using the following:

```
# The API:
PATCH /api/network/fc/interfaces/{uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/network/fc/interfaces/f6045b92-dec7-
11e8-a733-005056bba0e0' -H 'Accept: application/hal+json' -d '{ "enabled":
false }'
```

Moving an FC interface to a new node and port

To move an FC interface to another node or port, the destination FC port must be specified in a PATCH request. Either the port UUID or node and port names can be used to identify the port.

Note that only FC interfaces configured for the FC Protocol can be moved. FC interfaces configured for NVMe/FC cannot be moved. The interface must also be set to the disabled state before being moved.

```
# The API:
PATCH /api/network/fc/interfaces/{uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/network/fc/interfaces/f6045b92-dec7-
11e8-a733-005056bba0e0' -H 'Accept: application/hal+json' -d '{
"location": { "home_port": { "uuid": "a1dc7aa5-db83-11e8-9ef7-
005056bbbbcc" } } }'
```

Deleting an FC interface

```
# The API:
DELETE /api/network/fc/interfaces/{uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/network/fc/interfaces/f6045b92-dec7-
11e8-a733-005056bba0e0' -H 'Accept: application/hal+json'
```

Recommending interface locations for a new SVM

This example gets recommendations for FCP network interfaces for a new SVM.

```
# The API
```

```
GET /api/network/fc/interfaces

# The call:
curl -X GET 'https://<mgmt-
ip>/api/network/fc/interfaces?recommend.data_protocol=fcp&fields=*' -H
'Accept: application/hal+json'

# The response:
{
"records": [
  {
    "location": {
      "home_port": {
        "uuid": "300c1ae3-db82-11e8-bd46-005056bba0e0",
        "name": "0a",
        "node": {
          "name": "node1"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/300c1ae3-db82-11e8-bd46-
005056bba0e0"
          }
        }
      }
    },
    "data_protocol": "fcp",
    "comment": "fabric: 55:0e:b1:a0:20:40:80:00"
  },
  {
    "location": {
      "home_port": {
        "uuid": "ad7d3915-db82-11e8-b36d-005056bb982e",
        "name": "0a",
        "node": {
          "name": "node2"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/ad7d3915-db82-11e8-b36d-
005056bb982e"
          }
        }
      }
    },
    "data_protocol": "fcp",
```

```
    "comment": "fabric: 55:0e:b1:a0:20:40:80:00"
  },
  {
    "location": {
      "home_port": {
        "uuid": "300c1dfd-db82-11e8-bd46-005056bba0e0",
        "name": "0b",
        "node": {
          "name": "node1"
        },
        "_links": {
          "self": {
            "href": "/api/network/fc/ports/300c1dfd-db82-11e8-bd46-
005056bba0e0"
          }
        }
      }
    },
    "data_protocol": "fcp",
    "comment": "fabric: 55:0e:b1:a0:20:40:80:01"
  }
],
"num_records": 3,
"recommend": {
  "messages": [
    {
      "message": "The following network ports are disabled (cluster
node:port): node2:0b",
      "code": "5375959",
      "arguments": [
        {
          "message": "node2:0b"
        }
      ],
      "severity": "informational"
    }
  ]
},
"_links": {
  "self": {
    "href":
"/api/network/fc/interfaces?recommend.data_protocol=fcp&fields=*"
  }
}
}
```

Proposing interface locations for a new SVM

This example requests that caller-proposed locations for FC-NVMe interfaces on two nodes be evaluated.

```
# The API
GET /api/network/fc/interfaces

# The call:
curl -X GET 'https://<mgmt-
ip>/api/network/fc/interfaces?&recommend.data_protocol=fc_nvme&recommend.p
roposed.locations.port.uuid=300c2786-db82-11e8-bd46-005056bba0e0,ad7d47d6-
db82-11e8-b36d-005056bb982e&fields=*' -H 'Accept: application/hal+json'

# The response:
{
"records": [
],
"num_records": 0,
"recommend": {
  "messages": [
    {
      "message": "Cluster node \"node1\" does not have the requested
number (1) of network interfaces for the following Fibre Channel fabrics:
55:0e:b1:a0:20:40:80:07.",
      "code": "5375969",
      "arguments": [
        {
          "message": "node1"
        },
        {
          "message": "1"
        },
        {
          "message": "55:0e:b1:a0:20:40:80:07"
        }
      ],
      "severity": "warning"
    },
    {
      "message": "Cluster node \"node2\" does not have the requested
number (1) of network interfaces for the following Fibre Channel fabrics:
55:0e:b1:a0:20:40:80:07.",
      "code": "5375969",
      "arguments": [
        {
          "message": "node2"
```

```
        },
        {
          "message": "1"
        },
        {
          "message": "55:0e:b1:a0:20:40:80:07"
        }
      ],
      "severity": "warning"
    },
    {
      "message": "The SVM cannot be reached from all of the Fibre Channel
(FC) fabrics to which the cluster is connected. Cluster FC fabrics:
55:0e:b1:a0:20:40:80:06, 55:0e:b1:a0:20:40:80:07. SVM FC fabrics:
55:0e:b1:a0:20:40:80:06.",
      "code": "5375970",
      "arguments": [
        {
          "message": "55:0e:b1:a0:20:40:80:06, 55:0e:b1:a0:20:40:80:07"
        },
        {
          "message": "55:0e:b1:a0:20:40:80:06"
        }
      ],
      "severity": "warning"
    },
    {
      "message": "The SVM is configured for 1 Fibre Channel (FC) fabrics.
The preferred configuration is 2 FC fabrics.",
      "code": "5375973",
      "arguments": [
        {
          "message": "1"
        },
        {
          "message": "2"
        }
      ],
      "severity": "warning"
    }
  ]
},
"_links": {
  "self": {
    "href":
"/api/network/fc/interfaces?recommend.data_protocol=fc_nvme&recommend.node
```

```
s.name=node1,node2&recommend.proposed.locations.port.uuid=300c2786-db82-
11e8-bd46-005056bba0e0,ad7d47d6-db82-11e8-b36d-005056bb982e&fields=*"
  }
}
}
```

Retrieve FC interfaces

GET `/network/fc/interfaces`

Introduced In: 9.6

Retrieves FC interfaces.

Related ONTAP commands

- `network interface show`
- `vserver fcp interface show`

Learn more

- DOC /network/fc/interfaces

Parameters

Name	Type	In	Required	Description
recommend.svm.name	string	query	False	The name of an existing SVM for which to recommend FC interfaces. If neither query parameter `recommend.svm.name` nor `recommend.svm.uuid` are provided when recommending FC interfaces, recommendations are made for a new, non-existent SVM. • Introduced in: 9.11

Name	Type	In	Required	Description
recommend.svm.uuid	string	query	False	The UUID of an existing SVM for which to recommend FC interfaces. If neither query parameter `recommend.svm.name` nor `recommend.svm.uuid` are provided when recommending FC interfaces, recommendations are made for a new, non-existent SVM. • Introduced in: 9.11
recommend.data_protocol	string	query	False	The target data protocol for which to recommend FC interfaces. This query parameter is required when recommending FC interfaces. • Introduced in: 9.11 • enum: ["fcp", "fc_nvme"]

Name	Type	In	Required	Description
recommend.interfaces_per_node	integer	query	False	The target number of interfaces per FC fabric per cluster node when recommending FC interfaces. If this query parameter is not provided, the default value is one (1). • Introduced in: 9.11 • Default value: 1 • Max value: 4 • Min value: 1
recommend.fabrics.name	array[string]	query	False	The names of the FC fabrics to target when recommending FC interfaces. If this query parameter is not provided, FC interfaces will be recommended for each FC fabric discovered. • Introduced in: 9.11

Name	Type	In	Required	Description
recommend.nodes.name	array[string]	query	False	The names of the cluster nodes to target when recommending FC interfaces. If this query parameter is not provided, FC interfaces will be recommended for all nodes that have FC network ports supporting target data protocol. Query parameters `recommend.nodes.name` and `recommend.nodes.uuid` are mutually exclusive; use either names or UUIDs to identify cluster nodes. • Introduced in: 9.11
recommend.nodes.uuid	array[string]	query	False	The UUIDs of the cluster nodes to target when recommending FC interfaces. If this query parameter is not provided, FC interfaces will be recommended for all nodes that have FC network ports supporting target data protocol. Query parameters `recommend.nodes.name` and `recommend.nodes.uuid` are mutually exclusive; use either names or UUIDs to identify cluster nodes. • Introduced in: 9.11

Name	Type	In	Required	Description
recommend.proposed.locations.port.uuid	array[string]	query	False	The UUIDs of the FC ports on which FC interfaces are proposed. A UUID may be supplied multiple times to proposed multiple FC interfaces. FC ports must be enabled, support the target data protocol and be reporting an FC fabric. • Introduced in: 9.11
svm.name	string	query	False	Filter by svm.name
svm.uuid	string	query	False	Filter by svm.uuid
state	string	query	False	Filter by state
name	string	query	False	Filter by name
statistics.latency_raw.other	integer	query	False	Filter by statistics.latency_raw.other • Introduced in: 9.8
statistics.latency_raw.total	integer	query	False	Filter by statistics.latency_raw.total • Introduced in: 9.8
statistics.latency_raw.write	integer	query	False	Filter by statistics.latency_raw.write • Introduced in: 9.8

Name	Type	In	Required	Description
statistics.latency_raw.read	integer	query	False	Filter by statistics.latency_raw.read • Introduced in: 9.8
statistics.iops_raw.other	integer	query	False	Filter by statistics.iops_raw.other • Introduced in: 9.8
statistics.iops_raw.total	integer	query	False	Filter by statistics.iops_raw.total • Introduced in: 9.8
statistics.iops_raw.write	integer	query	False	Filter by statistics.iops_raw.write • Introduced in: 9.8
statistics.iops_raw.read	integer	query	False	Filter by statistics.iops_raw.read • Introduced in: 9.8
statistics.throughput_raw.write	integer	query	False	Filter by statistics.throughput_raw.write • Introduced in: 9.8
statistics.throughput_raw.read	integer	query	False	Filter by statistics.throughput_raw.read • Introduced in: 9.8

Name	Type	In	Required	Description
statistics.throughput_raw.total	integer	query	False	Filter by statistics.throughput_raw.total • Introduced in: 9.8
statistics.status	string	query	False	Filter by statistics.status • Introduced in: 9.8
statistics.timestamp	string	query	False	Filter by statistics.timestamp • Introduced in: 9.8
location.port.name	string	query	False	Filter by location.port.name
location.port.node.name	string	query	False	Filter by location.port.node.name
location.port.uuid	string	query	False	Filter by location.port.uuid
location.home_port.name	string	query	False	Filter by location.home_port.name • Introduced in: 9.8
location.home_port.node.name	string	query	False	Filter by location.home_port.node.name • Introduced in: 9.8
location.home_port.uuid	string	query	False	Filter by location.home_port.uuid • Introduced in: 9.8

Name	Type	In	Required	Description
location.home_node.name	string	query	False	Filter by location.home_node.name • Introduced in: 9.8
location.home_node.uuid	string	query	False	Filter by location.home_node.uuid • Introduced in: 9.8
location.is_home	boolean	query	False	Filter by location.is_home • Introduced in: 9.8
location.node.name	string	query	False	Filter by location.node.name
location.node.uuid	string	query	False	Filter by location.node.uuid
wwpn	string	query	False	Filter by wwpn
enabled	boolean	query	False	Filter by enabled
port_address	string	query	False	Filter by port_address
comment	string	query	False	Filter by comment
data_protocol	string	query	False	Filter by data_protocol
metric.latency.other	integer	query	False	Filter by metric.latency.other • Introduced in: 9.8

Name	Type	In	Required	Description
metric.latency.total	integer	query	False	Filter by metric.latency.total • Introduced in: 9.8
metric.latency.write	integer	query	False	Filter by metric.latency.write • Introduced in: 9.8
metric.latency.read	integer	query	False	Filter by metric.latency.read • Introduced in: 9.8
metric.iops.other	integer	query	False	Filter by metric.iops.other • Introduced in: 9.8
metric.iops.total	integer	query	False	Filter by metric.iops.total • Introduced in: 9.8
metric.iops.write	integer	query	False	Filter by metric.iops.write • Introduced in: 9.8
metric.iops.read	integer	query	False	Filter by metric.iops.read • Introduced in: 9.8
metric.timestamp	string	query	False	Filter by metric.timestamp • Introduced in: 9.8

Name	Type	In	Required	Description
metric.throughput.write	integer	query	False	Filter by metric.throughput.write • Introduced in: 9.8
metric.throughput.read	integer	query	False	Filter by metric.throughput.read • Introduced in: 9.8
metric.throughput.total	integer	query	False	Filter by metric.throughput.total • Introduced in: 9.8
metric.duration	string	query	False	Filter by metric.duration • Introduced in: 9.8
metric.status	string	query	False	Filter by metric.status • Introduced in: 9.8
wwnn	string	query	False	Filter by wwnn
uuid	string	query	False	Filter by uuid
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	The number of records in the response.
recommend	recommend	Response properties specific to the FC interface placement functionality. See the *Interface placement recommendations* section of DOC /network/fc/interfaces

Name	Type	Description
records	array[fc_interface]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "recommend": {
    "messages": [
      {
        "arguments": [
          {
            "code": "string",
            "message": "string"
          }
        ],
        "code": 5375959,
        "message": "Network ports are disabled.",
        "severity": "informational"
      }
    ]
  },
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "comment": "string",
      "data_protocol": "string",
      "location": {
        "home_node": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "node1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
```

```
      "home_port": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "0a",
        "node": {
          "name": "node1"
        },
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "port": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "0a",
        "node": {
          "name": "node1"
        },
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    },
    "metric": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "duration": "PT15S",
      "iops": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
```

```
      "latency": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "status": "ok",
      "throughput": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000"
    },
    "name": "fc_lif1",
    "port_address": "5060F",
    "state": "string",
    "statistics": {
      "iops_raw": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "latency_raw": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "status": "ok",
      "throughput_raw": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000"
    },
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "uuid": "bce9827d-4d8f-60af-c771-6e8e9af2c6f0",
    "wwnn": "20:00:00:50:56:b4:13:01",
```

```
        "wwpn": "20:00:00:50:56:b4:13:a8"
      }
    ]
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
5373982	An invalid WWN was specified. The length is incorrect.
5373983	An invalid WWN was specified. The format is incorrect.
5374938	Query parameter `recommend.data_protocol` is required when any other `recommend` query parameters are specified.
5374939	Query parameter `recommend.fabrics.name` specifies a duplicate FC fabric.
5374940	Query parameter `recommend.nodes.name` or `recommend.nodes.uuid` specifies a duplicate node.
5375953	Query parameter `recommend.fabrics.name` specifies an FC fabric to which no FC port is connected.
5375954	Query parameter `recommend.nodes.name` or `recommend.nodes.uuid` specifies a node that does not support the specified data protocol.
5375955	Query parameter `recommend.proposed.locations.port.uuid` does not specify a valid port or specifies a port that is support the specified data protocol.
5375956	Query parameter `recommend.proposed.locations.port.uuid` specifies a port that is not located on a node specified by query parameter `recommend.nodes.name` or `recommend.nodes.uuid`. If the nodes are to be constrained, only ports on those nodes may be proposed.
5375957	Query parameter `recommend.proposed.locations.port.uuid` specifies a port that is disabled.

Error Code	Description
5375958	Query parameter `recommend.proposed.locations.port.uuid` specifies a port that is not reporting a connected FC fabric.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

fc_interface_recommend_message

Name	Type	Description
arguments	array[error_arguments]	The message substitution arguments.

Name	Type	Description
code	string	The message code. Possible messages: ONTAP Error Response Codes Error Code — Description 5375959 — Network ports are disabled. 5375960 — Network ports are enabled, but not reporting a connected FC fabric. 5375961 — The limit for the number of FC network interfaces on a cluster node has been reached. 5375962 — The limit for the number of FC network interfaces on a port has been reached. 5375963 — An HA pair of cluster nodes has a discrepancy in the presence of FC ports. 5375964 — An HA pair of cluster nodes has a discrepancy in support for an FC data protocol. 5375965 — An HA pair of cluster nodes cannot be reached from the same FC fabrics. 5375966 — A cluster node cannot be reached from all of the FC fabrics from which other cluster nodes with FC interfaces in the SVM can be reached. 5375967 — The limit for the number of FC network interfaces on a cluster node has been exceeded. 5375968 — The limit for the number of FC network interfaces on an FC port has been exceeded. 5375969 — The requested number of network interfaces per FC fabric per cluster node has not been achieved. 5375970 — The SVM cannot be

Name	Type	Description
message	string	The message text.
severity	string	The severity of the message. Message severities are as follows: • `error` - Messages reporting problems that must be corrected before creating the FC network interfaces. • `warning` - Messages indicating issues that need rectifying in order to achieve an optimal configuration. • `informational` - Messages providing relevant information for consideration.

recommend

Response properties specific to the FC interface placement functionality. See the *Interface placement recommendations* section of DOC /network/fc/interfaces

Name	Type	Description
messages	array[fc_interface_recommend_message]	Messages describing the results of a FC network interface placement operation or evaluation of caller-proposed locations.

_links

Name	Type	Description
self	href	

home_node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

node

The node on which the FC port is located.

Name	Type	Description
name	string	The name of the node on which the FC port is located.

home_port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

Name	Type	Description
_links	_links	
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

Name	Type	Description
_links	_links	
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

location

The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID,

or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH.

`location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.

Name	Type	Description
home_node	home_node	
home_port	home_port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.
is_home	boolean	Indicates if the FC interface is currently on its home node.
node	node	
port	port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

Performance numbers, such as IOPS latency and throughput

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Type	Description
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.

Name	Type	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Type	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

fc_interface

A Fibre Channel (FC) interface is the logical endpoint for FC network connections to an SVM. An FC interface provides FC access to storage within the interface SVM using either Fibre Channel Protocol or NVMe over Fibre Channel (NVMe/FC).

An FC interface is created on an FC port which is located on a cluster node. The FC port must be specified to identify the location of the interface for a POST or PATCH operation that relocates an interface. You can identify the port by supplying either the cluster node and port names or the port UUID.

Name	Type	Description
_links	_links	
comment	string	A user configurable comment. Optional in POST; valid in PATCH. To clear a prior comment, set the property to an empty string in PATCH.
data_protocol	string	The data protocol for which the FC interface is configured. Required in POST.
enabled	boolean	The administrative state of the FC interface. The FC interface can be disabled to block all FC communication with the SVM through this interface. Optional in POST and PATCH; defaults to *true* (enabled) in POST.

Name	Type	Description
location	location	The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID, or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH. `location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The name of the FC interface. Required in POST; optional in PATCH.

Name	Type	Description
port_address	string	The port address of the FC interface. Each FC port in an FC switched fabric has its own unique FC port address for routing purposes. The FC port address is assigned by a switch in the fabric when that port logs in to the fabric. This property refers to the address given by a switch to the FC interface when the SVM performs a port login (PLOGI). This is useful for obtaining statistics and diagnostic information from FC switches. This is a hexadecimal encoded numeric value.
state	string	The current operational state of the FC interface. The state is set to *down* if the interface is not enabled. If the cluster node hosting the port is down or unavailable, no state value is returned.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
svm	svm	SVM, applies only to SVM-scoped objects.
uuid	string	The unique identifier of the FC interface. Required in the URL.

Name	Type	Description
wwnn	string	The world wide node name (WWNN) of the FC interface SVM. The WWNN is generated by ONTAP when Fibre Channel Protocol or the NVMe service is created for the FC interface SVM. • example: 20:00:00:50:56:b4:13:01 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true
wwpn	string	The world wide port name (WWPN) of the FC interface. The WWPN is generated by ONTAP when the FC interface is created. • example: 20:00:00:50:56:b4:13:a8 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create an FC interface

POST `/network/fc/interfaces`

Introduced In: 9.6

Creates an FC interface.

Required properties

- `svm.uuid` or `svm.name` - Existing SVM in which to create the FC interface.
- `name` - Name of the FC interface.
- `location.port.uuid` or both `location.port.name` and `location.port.node.name` - FC port on which to create the FC interface.
- `data_protocol` - Data protocol for the FC interface.

Default property values

If not specified in POST, the following default property values are assigned.

- `enabled` - *true*

Related ONTAP commands

- `network interface create`

Learn more

- DOC /network/fc/interfaces

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
comment	string	A user configurable comment. Optional in POST; valid in PATCH. To clear a prior comment, set the property to an empty string in PATCH.
data_protocol	string	The data protocol for which the FC interface is configured. Required in POST.

Name	Type	Description
enabled	boolean	The administrative state of the FC interface. The FC interface can be disabled to block all FC communication with the SVM through this interface. Optional in POST and PATCH; defaults to *true* (enabled) in POST.
location	location	The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID, or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH. `location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.
name	string	The name of the FC interface. Required in POST; optional in PATCH.

Name	Type	Description
port_address	string	The port address of the FC interface. Each FC port in an FC switched fabric has its own unique FC port address for routing purposes. The FC port address is assigned by a switch in the fabric when that port logs in to the fabric. This property refers to the address given by a switch to the FC interface when the SVM performs a port login (PLOGI). This is useful for obtaining statistics and diagnostic information from FC switches. This is a hexadecimal encoded numeric value.
state	string	The current operational state of the FC interface. The state is set to *down* if the interface is not enabled. If the cluster node hosting the port is down or unavailable, no state value is returned.
svm	svm	SVM, applies only to SVM-scoped objects.
uuid	string	The unique identifier of the FC interface. Required in the URL.
wwnn	string	The world wide node name (WWNN) of the FC interface SVM. The WWNN is generated by ONTAP when Fibre Channel Protocol or the NVMe service is created for the FC interface SVM. • example: 20:00:00:50:56:b4:13:01 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true

Name	Type	Description
wwpn	string	The world wide port name (WWPN) of the FC interface. The WWPN is generated by ONTAP when the FC interface is created. • example: 20:00:00:50:56:b4:13:a8 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true

Example request


```
{
  "comment": "string",
  "data_protocol": "string",
  "location": {
    "home_node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "home_port": {
      "name": "0a",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "port": {
      "name": "0a",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "name": "fc_lif1",
  "port_address": "5060F",
  "state": "string",
  "svm": {
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "bce9827d-4d8f-60af-c771-6e8e9af2c6f0",
  "wwnn": "20:00:00:50:56:b4:13:01",
  "wwpn": "20:00:00:50:56:b4:13:a8"
}
```


Response

```
Status: 201, Created
```

Name	Type	Description
num_records	integer	The number of records in the response.
recommend	recommend	Response properties specific to the FC interface placement functionality. See the *Interface placement recommendations* section of DOC /network/fc/interfaces
records	array[fc_interface]	

Example response


```
{
  "num_records": 1,
  "recommend": {
    "messages": [
      {
        "arguments": [
          {
            "code": "string",
            "message": "string"
          }
        ],
        "code": 5375959,
        "message": "Network ports are disabled.",
        "severity": "informational"
      }
    ]
  },
  "records": [
    {
      "comment": "string",
      "data_protocol": "string",
      "location": {
        "home_node": {
          "name": "node1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "home_port": {
          "name": "0a",
          "node": {
            "name": "node1"
          },
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "node": {
          "name": "node1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "port": {
          "name": "0a",
          "node": {
            "name": "node1"
          },
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
```

```
      },
      "name": "fc_lif1",
      "port_address": "5060F",
      "state": "string",
      "svm": {
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "uuid": "bce9827d-4d8f-60af-c771-6e8e9af2c6f0",
      "wwnn": "20:00:00:50:56:b4:13:01",
      "wwpn": "20:00:00:50:56:b4:13:a8"
    }
  ]
}
```


Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1966140	An interface with the same name already exists.
1966217	The specified port is not valid on the node provided.
2621462	The supplied SVM does not exist.
2621706	The specified `svm.uuid` and `svm.name` do not refer to the same SVM.
2621707	No SVM was specified. Either `svm.name` or `svm.uuid` must be supplied.
5373966	A Fibre Channel interface with the *fcp* protocol cannot be created in an SVM that is configured for NVMe.
5373982	An invalid WWN was specified. The length is incorrect.
5373983	An invalid WWN was specified. The format is incorrect.

Error Code	Description
5374102	The specified Fibre Channel interface cannot be created because the Fibre Channel adapter is down. Bring the adapter up and try again.
5374871	The Fibre Channel port identified by the specified UUID does not refer to the same port as that identified by the specified node name and/or port name.
5374872	If either `location.port.node.name` or `location.port.name` is supplied, both properties must be supplied.
5374873	The Fibre Channel port must be specified using either `location.port.uuid` or `location.port.node.name` and `location.port.name`.
5375057	An FC port with the provided UUID does not exist.
72089652	An NVMe service must be created before creating a Fibre Channel interface using the NVMe over FC data protocol.
72089672	The specified Fibre Channel port does not support the NVMe over FC data protocol.
72089900	A Fibre Channel interface with the *fc_nvme* protocol cannot be created in an SVM that is configured for a SAN protocol.
72089901	NVMe over Fabrics does not support more than 2 LIFs per node per SVM.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

home_node

Name	Type	Description
name	string	
uuid	string	

node

The node on which the FC port is located.

Name	Type	Description
name	string	The name of the node on which the FC port is located.

home_port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

Name	Type	Description
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

node

Name	Type	Description
name	string	
uuid	string	

port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC

network.

Name	Type	Description
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

location

The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID, or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH.

`location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.

Name	Type	Description
home_node	home_node	
home_port	home_port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.
is_home	boolean	Indicates if the FC interface is currently on its home node.
node	node	
port	port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.

Name	Type	Description
write	integer	Performance metric for write I/O operations.

metric

Performance numbers, such as IOPS latency and throughput

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.

Name	Type	Description
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.

Name	Type	Description
write	integer	Performance metric for write I/O operations.

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Type	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

fc_interface

A Fibre Channel (FC) interface is the logical endpoint for FC network connections to an SVM. An FC interface provides FC access to storage within the interface SVM using either Fibre Channel Protocol or NVMe over Fibre Channel (NVMe/FC).

An FC interface is created on an FC port which is located on a cluster node. The FC port must be specified to identify the location of the interface for a POST or PATCH operation that relocates an interface. You can identify the port by supplying either the cluster node and port names or the port UUID.

Name	Type	Description
comment	string	A user configurable comment. Optional in POST; valid in PATCH. To clear a prior comment, set the property to an empty string in PATCH.
data_protocol	string	The data protocol for which the FC interface is configured. Required in POST.
enabled	boolean	The administrative state of the FC interface. The FC interface can be disabled to block all FC communication with the SVM through this interface. Optional in POST and PATCH; defaults to *true* (enabled) in POST.

Name	Type	Description
location	location	The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID, or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH. `location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.
name	string	The name of the FC interface. Required in POST; optional in PATCH.
port_address	string	The port address of the FC interface. Each FC port in an FC switched fabric has its own unique FC port address for routing purposes. The FC port address is assigned by a switch in the fabric when that port logs in to the fabric. This property refers to the address given by a switch to the FC interface when the SVM performs a port login (PLOGI). This is useful for obtaining statistics and diagnostic information from FC switches. This is a hexadecimal encoded numeric value.

Name	Type	Description
state	string	The current operational state of the FC interface. The state is set to *down* if the interface is not enabled. If the cluster node hosting the port is down or unavailable, no state value is returned.
svm	svm	SVM, applies only to SVM-scoped objects.
uuid	string	The unique identifier of the FC interface. Required in the URL.
wwnn	string	The world wide node name (WWNN) of the FC interface SVM. The WWNN is generated by ONTAP when Fibre Channel Protocol or the NVMe service is created for the FC interface SVM. • example: 20:00:00:50:56:b4:13:01 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true
wwpn	string	The world wide port name (WWPN) of the FC interface. The WWPN is generated by ONTAP when the FC interface is created. • example: 20:00:00:50:56:b4:13:a8 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

fc_interface_recommend_message

Name	Type	Description
arguments	array[error_arguments]	The message substitution arguments.

Name	Type	Description
code	string	The message code. Possible messages: ONTAP Error Response Codes Error Code — Description 5375959 — Network ports are disabled. 5375960 — Network ports are enabled, but not reporting a connected FC fabric. 5375961 — The limit for the number of FC network interfaces on a cluster node has been reached. 5375962 — The limit for the number of FC network interfaces on a port has been reached. 5375963 — An HA pair of cluster nodes has a discrepancy in the presence of FC ports. 5375964 — An HA pair of cluster nodes has a discrepancy in support for an FC data protocol. 5375965 — An HA pair of cluster nodes cannot be reached from the same FC fabrics. 5375966 — A cluster node cannot be reached from all of the FC fabrics from which other cluster nodes with FC interfaces in the SVM can be reached. 5375967 — The limit for the number of FC network interfaces on a cluster node has been exceeded. 5375968 — The limit for the number of FC network interfaces on an FC port has been exceeded. 5375969 — The requested number of network interfaces per FC fabric per cluster node has not been achieved. 5375970 — The SVM cannot be

Name	Type	Description
message	string	The message text.
severity	string	The severity of the message. Message severities are as follows: • `error` - Messages reporting problems that must be corrected before creating the FC network interfaces. • `warning` - Messages indicating issues that need rectifying in order to achieve an optimal configuration. • `informational` - Messages providing relevant information for consideration.

recommend

Response properties specific to the FC interface placement functionality. See the *Interface placement recommendations* section of DOC /network/fc/interfaces

Name	Type	Description
messages	array[fc_interface_recommend_message]	Messages describing the results of a FC network interface placement operation or evaluation of caller-proposed locations.

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve historical performance metrics for an FC interface

GET `/network/fc/interfaces/{fc_interface.uuid}/metrics`

Introduced In: 9.14

Retrieves historical performance metrics for a Fibre Channel interface.

Parameters

Name	Type	In	Required	Description
iops.other	integer	query	False	Filter by iops.other
iops.total	integer	query	False	Filter by iops.total
iops.write	integer	query	False	Filter by iops.write
iops.read	integer	query	False	Filter by iops.read
latency.other	integer	query	False	Filter by latency.other
latency.total	integer	query	False	Filter by latency.total
latency.write	integer	query	False	Filter by latency.write
latency.read	integer	query	False	Filter by latency.read
timestamp	string	query	False	Filter by timestamp
throughput.write	integer	query	False	Filter by throughput.write
throughput.read	integer	query	False	Filter by throughput.read
throughput.total	integer	query	False	Filter by throughput.total
status	string	query	False	Filter by status
uuid	string	query	False	Filter by uuid
duration	string	query	False	Filter by duration

Name	Type	In	Required	Description
fc_interface.uuid	string	path	True	The unique identifier of the Fibre Channel interface.
interval	string	query	False	The time range for the data. Examples can be 1h, 1d, 1m, 1w, 1y. The period for each time range is as follows: • 1h: Metrics over the most recent hour sampled over 15 seconds. • 1d: Metrics over the most recent day sampled over 5 minutes. • 1w: Metrics over the most recent week sampled over 30 minutes. • 1m: Metrics over the most recent month sampled over 2 hours. • 1y: Metrics over the most recent year sampled over a day. • Default value: 1 • enum: ["1h", "1d", "1w", "1m", "1y"]

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
order_by	array[string]	query	False	Order results by specified fields and optional [asc
desc] direction. Default direction is 'asc' for ascending.	return_records	boolean	query	False

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[records]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "duration": "PT15S",
      "iops": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "latency": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "status": "ok",
      "throughput": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
8585947	No metrics are available for the requested object.
8586225	An unexpected error occurred retrieving metrics for the requested object.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

records

Performance numbers, such as IOPS latency and throughput

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Type	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.
uuid	string	The unique identifier of the FC interface.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve historical performance metrics for an FC interface for a specific time

GET `/network/fc/interfaces/{fc_interface.uuid}/metrics/{timestamp}`

Introduced In: 9.14

Retrieves historical performance metrics for a Fibre Channel interface for a specific time.

Parameters

Name	Type	In	Required	Description
fc_interface.uuid	string	path	True	The unique identifier of the Fibre Channel interface.
timestamp	string	path	True	The timestamp of the performance data. • format: date-time
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.
uuid	string	The unique identifier of the FC interface.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "duration": "PT15S",
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25 11:20:13 +0000",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
8585947	No metrics are available for the requested object.
8586225	An unexpected error occurred retrieving metrics for the requested object.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Type	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete an FC interface

DELETE `/network/fc/interfaces/{uuid}`

Introduced In: 9.6

Deletes an FC interface.

Related ONTAP commands

- `network interface delete`

Learn more

- DOC /network/fc/interfaces

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
53280992	The FC interface could not be deleted because it is enabled.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve an FC interface

GET `/network/fc/interfaces/{uuid}`

Introduced In: 9.6

Retrieves an FC interface.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `statistics.*`
- `metric.*`

Related ONTAP commands

- `network interface show`
- `vserver fcp interface show`

Learn more

- DOC /network/fc/interfaces

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	The unique identifier for the FC interface.
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
comment	string	A user configurable comment. Optional in POST; valid in PATCH. To clear a prior comment, set the property to an empty string in PATCH.
data_protocol	string	The data protocol for which the FC interface is configured. Required in POST.

Name	Type	Description
enabled	boolean	The administrative state of the FC interface. The FC interface can be disabled to block all FC communication with the SVM through this interface. Optional in POST and PATCH; defaults to *true* (enabled) in POST.
location	location	The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID, or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH. `location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The name of the FC interface. Required in POST; optional in PATCH.

Name	Type	Description
port_address	string	The port address of the FC interface. Each FC port in an FC switched fabric has its own unique FC port address for routing purposes. The FC port address is assigned by a switch in the fabric when that port logs in to the fabric. This property refers to the address given by a switch to the FC interface when the SVM performs a port login (PLOGI). This is useful for obtaining statistics and diagnostic information from FC switches. This is a hexadecimal encoded numeric value.
state	string	The current operational state of the FC interface. The state is set to *down* if the interface is not enabled. If the cluster node hosting the port is down or unavailable, no state value is returned.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
svm	svm	SVM, applies only to SVM-scoped objects.
uuid	string	The unique identifier of the FC interface. Required in the URL.

Name	Type	Description
wwnn	string	The world wide node name (WWNN) of the FC interface SVM. The WWNN is generated by ONTAP when Fibre Channel Protocol or the NVMe service is created for the FC interface SVM. • example: 20:00:00:50:56:b4:13:01 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true
wwpn	string	The world wide port name (WWPN) of the FC interface. The WWPN is generated by ONTAP when the FC interface is created. • example: 20:00:00:50:56:b4:13:a8 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "comment": "string",
  "data_protocol": "string",
  "location": {
    "home_node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "home_port": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "0a",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "port": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
```

```
      },
      "name": "0a",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "duration": "PT15S",
    "iops": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 11:20:13 +0000"
  },
  "name": "fc_lif1",
  "port_address": "5060F",
  "state": "string",
  "statistics": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
```

```
    },
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 11:20:13 +0000"
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "bce9827d-4d8f-60af-c771-6e8e9af2c6f0",
  "wwnn": "20:00:00:50:56:b4:13:01",
  "wwpn": "20:00:00:50:56:b4:13:a8"
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

home_node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

node

The node on which the FC port is located.

Name	Type	Description
name	string	The name of the node on which the FC port is located.

home_port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

Name	Type	Description
_links	_links	
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

Name	Type	Description
_links	_links	
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

location

The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID, or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH.

`location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.

Name	Type	Description
home_node	home_node	
home_port	home_port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.
is_home	boolean	Indicates if the FC interface is currently on its home node.
node	node	

Name	Type	Description
port	port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

Performance numbers, such as IOPS latency and throughput

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.

Name	Type	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Type	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Type	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update an FC interface

PATCH `/network/fc/interfaces/{uuid}`

Introduced In: 9.6

Updates an FC interface.

Related ONTAP commands

- `network interface modify`

Learn more

- DOC /network/fc/interfaces

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	The unique identifier for the FC interface.

Request Body

Name	Type	Description
comment	string	A user configurable comment. Optional in POST; valid in PATCH. To clear a prior comment, set the property to an empty string in PATCH.
enabled	boolean	The administrative state of the FC interface. The FC interface can be disabled to block all FC communication with the SVM through this interface. Optional in POST and PATCH; defaults to *true* (enabled) in POST.

Name	Type	Description
location	location	The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID, or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH. `location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.
name	string	The name of the FC interface. Required in POST; optional in PATCH.
port_address	string	The port address of the FC interface. Each FC port in an FC switched fabric has its own unique FC port address for routing purposes. The FC port address is assigned by a switch in the fabric when that port logs in to the fabric. This property refers to the address given by a switch to the FC interface when the SVM performs a port login (PLOGI). This is useful for obtaining statistics and diagnostic information from FC switches. This is a hexadecimal encoded numeric value.

Name	Type	Description
state	string	The current operational state of the FC interface. The state is set to *down* if the interface is not enabled. If the cluster node hosting the port is down or unavailable, no state value is returned.
uuid	string	The unique identifier of the FC interface. Required in the URL.
wwnn	string	The world wide node name (WWNN) of the FC interface SVM. The WWNN is generated by ONTAP when Fibre Channel Protocol or the NVMe service is created for the FC interface SVM. • example: 20:00:00:50:56:b4:13:01 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true
wwpn	string	The world wide port name (WWPN) of the FC interface. The WWPN is generated by ONTAP when the FC interface is created. • example: 20:00:00:50:56:b4:13:a8 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true

Example request


```
{
  "comment": "string",
  "location": {
    "home_node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "home_port": {
      "name": "0a",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "port": {
      "name": "0a",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "name": "fc_lif1",
  "port_address": "5060F",
  "state": "string",
  "uuid": "bce9827d-4d8f-60af-c771-6e8e9af2c6f0",
  "wwnn": "20:00:00:50:56:b4:13:01",
  "wwpn": "20:00:00:50:56:b4:13:a8"
}
```


Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1966140	An interface with the same name already exists.
1966217	The specified port is not valid on the node provided.
1966238	The node or port of an active SAN data interface cannot be changed.
1966702	The destination node is not healthy.
5373982	An invalid WWN was specified. The length is incorrect.
5373983	An invalid WWN was specified. The format is incorrect.
5374579	The SAN Kernel Agent on the node is unavailable.
5374870	A partial failure occurred; renaming the interface failed. Correct the error and resubmit the request.
5374871	The Fibre Channel port identified by the specified UUID does not refer to the same port as that identified by the specified node name and/or port name.
5374872	If either `location.port.node.name` or `location.port.name` is supplied, both properties must be supplied.
5375057	An FC port with the provided UUID does not exist.
72089674	You cannot move a Fibre Channel interface configured for the NVMe over FC data protocol.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

home_node

Name	Type	Description
name	string	
uuid	string	

node

The node on which the FC port is located.

Name	Type	Description
name	string	The name of the node on which the FC port is located.

home_port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

Name	Type	Description
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

node

Name	Type	Description
name	string	
uuid	string	

port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC

network.

Name	Type	Description
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

location

The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID, or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH.

`location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.

Name	Type	Description
home_node	home_node	
home_port	home_port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.
is_home	boolean	Indicates if the FC interface is currently on its home node.
node	node	
port	port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.

Name	Type	Description
write	integer	Performance metric for write I/O operations.

metric

Performance numbers, such as IOPS latency and throughput

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.

Name	Type	Description
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.

Name	Type	Description
write	integer	Performance metric for write I/O operations.

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Type	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

fc_interface

A Fibre Channel (FC) interface is the logical endpoint for FC network connections to an SVM. An FC interface provides FC access to storage within the interface SVM using either Fibre Channel Protocol or NVMe over Fibre Channel (NVMe/FC).

An FC interface is created on an FC port which is located on a cluster node. The FC port must be specified to identify the location of the interface for a POST or PATCH operation that relocates an interface. You can identify the port by supplying either the cluster node and port names or the port UUID.

Name	Type	Description
comment	string	A user configurable comment. Optional in POST; valid in PATCH. To clear a prior comment, set the property to an empty string in PATCH.
enabled	boolean	The administrative state of the FC interface. The FC interface can be disabled to block all FC communication with the SVM through this interface. Optional in POST and PATCH; defaults to *true* (enabled) in POST.
location	location	The location of the FC interface is defined by the location of its port. An FC port is identified by its UUID, or a combination of its cluster node name and port name. Either the UUID or the cluster node name and port name are required for POST. To move an interface, supply either the port UUID or the cluster node name and port name in a PATCH. `location.node` and `location.port` refer to the current location of the FC interface. This can be different from `location.home_node` and `location.home_port` in instances where the FC interface has failed over to its HA partner node. The `location.node`, `location.port`, and `location.is_home` properties are not available for interfaces on the inactive side of a MetroCluster relationship.

Name	Type	Description
name	string	The name of the FC interface. Required in POST; optional in PATCH.
port_address	string	The port address of the FC interface. Each FC port in an FC switched fabric has its own unique FC port address for routing purposes. The FC port address is assigned by a switch in the fabric when that port logs in to the fabric. This property refers to the address given by a switch to the FC interface when the SVM performs a port login (PLOGI). This is useful for obtaining statistics and diagnostic information from FC switches. This is a hexadecimal encoded numeric value.
state	string	The current operational state of the FC interface. The state is set to *down* if the interface is not enabled. If the cluster node hosting the port is down or unavailable, no state value is returned.
uuid	string	The unique identifier of the FC interface. Required in the URL.
wwnn	string	The world wide node name (WWNN) of the FC interface SVM. The WWNN is generated by ONTAP when Fibre Channel Protocol or the NVMe service is created for the FC interface SVM. • example: 20:00:00:50:56:b4:13:01 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true

Name	Type	Description
wwpn	string	The world wide port name (WWPN) of the FC interface. The WWPN is generated by ONTAP when the FC interface is created. • example: 20:00:00:50:56:b4:13:a8 • readOnly: 1 • Introduced in: 9.6 • x-nullable: true

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve FC port information

Retrieve FC port information

Overview

Fibre Channel (FC) ports are the physical ports of FC adapters on ONTAP cluster nodes that can be connected to FC networks to provide FC network connectivity. An FC port defines the location of an FC interface within the ONTAP cluster.

The Fibre Channel port REST API allows you to discover FC ports, obtain status information for FC ports, and configure FC port properties. POST and DELETE requests are not supported. You must physically add and remove FC adapters to ONTAP nodes to create and remove ports from the ONTAP cluster.

Performance monitoring

Performance of an FC port can be monitored by observing the `metric.*` and `statistics.*` properties. These properties show the performance of an FC port in terms of IOPS, latency, and throughput. The `metric.*` properties denote an average, whereas `statistics.*` properties denote a real-time monotonically increasing value aggregated across all nodes.

Examples

Retrieving all FC ports

```
# The API:
GET /api/network/fc/ports

# The call:
curl -X GET "https://<mgmt-ip>/api/network/fc/ports" -H "Accept:
application/hal+json"

# The response:
{
"records": [
  {
    "node": {
      "name": "node1",
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b20f8-b047-11e8-9af3-005056bb838e",
    "name": "0a",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b20f8-b047-11e8-9af3-
005056bb838e"
      }
    }
  },
  {
    "node": {
      "name": "node1",
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
```

```
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b23f7-b047-11e8-9af3-005056bb838e",
    "name": "0b",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b23f7-b047-11e8-9af3-
005056bb838e"
      }
    }
  },
  {
    "node": {
      "name": "node1",
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b25ba-b047-11e8-9af3-005056bb838e",
    "name": "0c",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b25ba-b047-11e8-9af3-
005056bb838e"
      }
    }
  },
  {
    "node": {
      "name": "node1",
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b2748-b047-11e8-9af3-005056bb838e",
```

```
    "name": "0d",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b2748-b047-11e8-9af3-
005056bb838e"
      }
    }
  },
  {
    "node": {
      "name": "node1",
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b28c2-b047-11e8-9af3-005056bb838e",
    "name": "0e",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b28c2-b047-11e8-9af3-
005056bb838e"
      }
    }
  },
  {
    "node": {
      "name": "node1",
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b2a7b-b047-11e8-9af3-005056bb838e",
    "name": "0f",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b2a7b-b047-11e8-9af3-
005056bb838e"
      }
```

```
    }
  },
  {
    "node": {
      "name": "node1",
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b2e2b-b047-11e8-9af3-005056bb838e",
    "name": "1b",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b2e2b-b047-11e8-9af3-
005056bb838e"
      }
    }
  }
],
"num_records": 8,
"_links": {
  "self": {
    "href": "/api/network/fc/ports"
  }
}
}
```

Retrieving all FC ports with state *online*

The `state` query parameter is used to perform the query.

```
# The API:
GET /api/network/fc/ports

# The call:
curl -X GET "https://<mgmt-ip>/api/network/fc/ports?state=online" -H
"Accept: application/hal+json"

# The response:
{
```

```
"records": [
  {
    "node": {
      "name": "node1",
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b20f8-b047-11e8-9af3-005056bb838e",
    "name": "0a",
    "state": "online",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b20f8-b047-11e8-9af3-
005056bb838e"
      }
    }
  },
  {
    "node": {
      "name": "node1",
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b23f7-b047-11e8-9af3-005056bb838e",
    "name": "0b",
    "state": "online",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b23f7-b047-11e8-9af3-
005056bb838e"
      }
    }
  },
  {
    "node": {
      "name": "node1",
```

```
      "uuid": "3c768e01-1abc-4b3b-b7c0-629ceb62a497",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/3c768e01-1abc-4b3b-b7c0-
629ceb62a497"
        }
      }
    },
    "uuid": "931b25ba-b047-11e8-9af3-005056bb838e",
    "name": "0c",
    "state": "online",
    "_links": {
      "self": {
        "href": "/api/network/fc/ports/931b25ba-b047-11e8-9af3-
005056bb838e"
      }
    }
  }
],
"num_records": 3,
"_links": {
  "self": {
    "href": "/api/network/fc/ports?state=online"
  }
}
}
```

Retrieving an FC port

```
# The API:
GET /api/network/fc/ports/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/fc/ports/931b20f8-b047-11e8-
9af3-005056bb838e" -H "Accept: application/hal+json"

# The response:
{
"node": {
  "name": "node1",
  "uuid": "5a534a72-b047-11e8-9af3-005056bb838e",
  "_links": {
    "self": {
      "href": "/api/cluster/nodes/5a534a72-b047-11e8-9af3-005056bb838e"
```

```
    }
  }
},
"uuid": "931b20f8-b047-11e8-9af3-005056bb838e",
"name": "0a",
"description": "Fibre Channel Target Adapter 0a (ACME Fibre Channel
Adapter, rev. 1.0.0, 8G)",
"enabled": true,
"fabric": {
  "connected": true,
  "connected_speed": 8,
  "name": "55:0e:b1:a0:20:40:80:00",
  "port_address": "52100",
  "switch_port": "ssan-g620-03:1"
},
"physical_protocol": "fibre_channel",
"speed": {
  "maximum": "8",
  "configured": "auto"
},
"state": "online",
"supported_protocols": [
  "fcp"
],
"transceiver": {
  "form_factor": "SFP",
  "manufacturer": "ACME",
  "capabilities": [
    4,
    8
  ],
  "part_number": "1000"
},
"wwnn": "50:0a:09:80:bb:83:8e:00",
"wwpn": "50:0a:09:82:bb:83:8e:00",
"metric": {
  "timestamp": "2019-04-09T05:50:15Z",
  "duration": "PT15S",
  "status": "ok",
  "latency": {
    "other": 0,
    "total": 0,
    "read": 0,
    "write": 0
  },
  "iops": {
```

```
    "read": 0,
    "write": 0,
    "other": 0,
    "total": 0
  },
  "throughput": {
    "read": 0,
    "write": 0,
    "total": 0
  }
},
"statistics": {
  "timestamp": "2019-04-09T05:50:42Z",
  "status": "ok",
  "latency_raw": {
    "other": 38298,
    "total": 38298,
    "read": 0,
    "write": 0
  },
  "iops_raw": {
    "read": 0,
    "write": 0,
    "other": 3,
    "total": 3
  },
  "throughput_raw": {
    "read": 0,
    "write": 0,
    "total": 0
  }
},
"_links": {
  "self": {
    "href": "/api/network/fc/ports/931b20f8-b047-11e8-9af3-005056bb838e"
  }
}
}
```

Disabling an FC port

If an active FC interface exists on an FC port, the port cannot be disabled.

```
# The API:
PATCH /api/network/fc/ports/{uuid}

# The call:
curl -X PATCH "http://<mgmt-ip>/api/network/fc/ports/931b20f8-b047-11e8-
9af3-005056bb838e" -H "Accept: application/hal+json" -d '{ "enabled":
false }'
```

Retrieve FC ports

GET `/network/fc/ports`

Introduced In: 9.6

Retrieves FC ports.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `fabric.name`
- `statistics.*`
- `metric.*`

Related ONTAP commands

- `network fcp adapter show`

Learn more

- DOC /network/fc/ports

Parameters

Name	Type	In	Required	Description
transceiver.capabilities	integer	query	False	Filter by transceiver.capabilities
transceiver.form_factor	string	query	False	Filter by transceiver.form_factor • Introduced in: 9.8

Name	Type	In	Required	Description
transceiver.part_number	string	query	False	Filter by transceiver.part_number
transceiver.manufacturer	string	query	False	Filter by transceiver.manufacturer
fabric.connected_speed	integer	query	False	Filter by fabric.connected_speed
fabric.switch_port	string	query	False	Filter by fabric.switch_port
fabric.connected	boolean	query	False	Filter by fabric.connected
fabric.name	string	query	False	Filter by fabric.name
fabric.port_address	string	query	False	Filter by fabric.port_address
supported_protocols	string	query	False	Filter by supported_protocols
physical_protocol	string	query	False	Filter by physical_protocol
metric.latency.other	integer	query	False	Filter by metric.latency.other • Introduced in: 9.8
metric.latency.total	integer	query	False	Filter by metric.latency.total • Introduced in: 9.8
metric.latency.write	integer	query	False	Filter by metric.latency.write • Introduced in: 9.8

Name	Type	In	Required	Description
metric.latency.read	integer	query	False	Filter by metric.latency.read • Introduced in: 9.8
metric.iops.other	integer	query	False	Filter by metric.iops.other • Introduced in: 9.8
metric.iops.total	integer	query	False	Filter by metric.iops.total • Introduced in: 9.8
metric.iops.write	integer	query	False	Filter by metric.iops.write • Introduced in: 9.8
metric.iops.read	integer	query	False	Filter by metric.iops.read • Introduced in: 9.8
metric.timestamp	string	query	False	Filter by metric.timestamp • Introduced in: 9.8
metric.throughput.write	integer	query	False	Filter by metric.throughput.write • Introduced in: 9.8
metric.throughput.read	integer	query	False	Filter by metric.throughput.read • Introduced in: 9.8

Name	Type	In	Required	Description
metric.throughput.total	integer	query	False	Filter by metric.throughput.total • Introduced in: 9.8
metric.duration	string	query	False	Filter by metric.duration • Introduced in: 9.8
metric.status	string	query	False	Filter by metric.status • Introduced in: 9.8
interface_count	integer	query	False	Filter by interface_count • Introduced in: 9.10
uuid	string	query	False	Filter by uuid
wwnn	string	query	False	Filter by wwnn
statistics.latency_raw.other	integer	query	False	Filter by statistics.latency_raw.other • Introduced in: 9.8
statistics.latency_raw.total	integer	query	False	Filter by statistics.latency_raw.total • Introduced in: 9.8
statistics.latency_raw.write	integer	query	False	Filter by statistics.latency_raw.write • Introduced in: 9.8

Name	Type	In	Required	Description
statistics.latency_raw.read	integer	query	False	Filter by statistics.latency_raw.read • Introduced in: 9.8
statistics.iops_raw.other	integer	query	False	Filter by statistics.iops_raw.other • Introduced in: 9.8
statistics.iops_raw.total	integer	query	False	Filter by statistics.iops_raw.total • Introduced in: 9.8
statistics.iops_raw.write	integer	query	False	Filter by statistics.iops_raw.write • Introduced in: 9.8
statistics.iops_raw.read	integer	query	False	Filter by statistics.iops_raw.read • Introduced in: 9.8
statistics.throughput_raw.write	integer	query	False	Filter by statistics.throughput_raw.write • Introduced in: 9.8
statistics.throughput_raw.read	integer	query	False	Filter by statistics.throughput_raw.read • Introduced in: 9.8

Name	Type	In	Required	Description
statistics.throughput_raw.total	integer	query	False	Filter by statistics.throughput_raw.total • Introduced in: 9.8
statistics.status	string	query	False	Filter by statistics.status • Introduced in: 9.8
statistics.timestamp	string	query	False	Filter by statistics.timestamp • Introduced in: 9.8
description	string	query	False	Filter by description
speed.maximum	string	query	False	Filter by speed.maximum
speed.configured	string	query	False	Filter by speed.configured
name	string	query	False	Filter by name
state	string	query	False	Filter by state
enabled	boolean	query	False	Filter by enabled
wwpn	string	query	False	Filter by wwpn
node.name	string	query	False	Filter by node.name
node.uuid	string	query	False	Filter by node.uuid
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[fc_port]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "description": "Fibre Channel Target Adapter 0a (ACME Fibre
Channel Adapter, rev. 1.0.0, 8G)",
      "fabric": {
        "connected_speed": 16,
        "name": "string",
        "port_address": "52100A",
        "switch_port": "ssan-g620-03:33"
      },
      "interface_count": 0,
      "metric": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "duration": "PT15S",
        "iops": {
          "read": 200,
          "total": 1000,
          "write": 100
        },
        "latency": {
          "read": 200,
          "total": 1000,
          "write": 100
        },
        "status": "ok",
```

```
      "throughput": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000"
    },
    "name": "0a",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "physical_protocol": "string",
    "speed": {
      "configured": "auto",
      "maximum": "32"
    },
    "state": "online",
    "statistics": {
      "iops_raw": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "latency_raw": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "status": "ok",
      "throughput_raw": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000"
    },
    "supported_protocols": [
      "string"
    ],
    "transceiver": {
```

```
        "capabilities": [
          16
        ],
        "form_factor": "string",
        "manufacturer": "Acme, Inc.",
        "part_number": "string"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
      "wwnn": "20:00:00:50:56:b4:13:a8",
      "wwpn": "20:00:00:50:56:b4:13:a8"
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

fabric

Properties of the fabric to which the FC port is attached.

Name	Type	Description
connected	boolean	Reports if the physical port has established a connection with the FC fabric.
connected_speed	integer	The negotiated data rate between the target FC port and the fabric in gigabits per second.
name	string	The name of the fabric to which the port is connected. This is only available when the FC port is connected to a fabric. There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

Name	Type	Description
port_address	string	The FC port address of the host bus adapter (HBA) physical port. Each FC port in an FC switched fabric has its own unique FC port address for routing purposes. The FC port address is assigned by a switch in the fabric when that port logs in to the fabric. This property refers to the FC port address given to the physical host bus adapter (HBA) port when the port performs a fabric login (FLOGI). This is useful for obtaining statistics and diagnostic information from FC switches. This is a six-digit hexadecimal encoded numeric value.
switch_port	string	The switch port to which the FC port is connected.

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

Performance numbers, such as IOPS latency and throughput

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Type	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

speed

The physical device speed related properties of the FC port.

Name	Type	Description
configured	string	The configured speed of the FC port in gigabits per second.
maximum	string	The maximum speed supported by the FC port in gigabits per second.

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.

Name	Type	Description
write	integer	Performance metric for write I/O operations.

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Type	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

transceiver

Properties of the transceiver connected to the FC port.

Name	Type	Description
capabilities	array[integer]	The speeds of which the transceiver is capable in gigabits per second.

Name	Type	Description
form_factor	string	The form factor of the transceiver. Possible values are: • *sfp* - Small Form Factor - Pluggable • *sff* - Small Form Factor • *unknown* - Unknown
manufacturer	string	The manufacturer of the transceiver.
part_number	string	The part number of the transceiver.

fc_port

A Fibre Channel (FC) port is the physical port of an FC adapter on an ONTAP cluster node that can be connected to an FC network to provide FC network connectivity. An FC port defines the location of an FC interface within the ONTAP cluster.

Name	Type	Description
_links	_links	
description	string	A description of the FC port.
enabled	boolean	The administrative state of the FC port. If this property is set to *false*, all FC connectivity to FC interfaces are blocked. Optional in PATCH.
fabric	fabric	Properties of the fabric to which the FC port is attached.
interface_count	integer	The number of FC interfaces currently provisioned on this port. This property is not supported in an SVM context.
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The FC port name.
node	node	

Name	Type	Description
physical_protocol	string	The physical network protocol of the FC port.
speed	speed	The physical device speed related properties of the FC port.
state	string	The operational state of the FC port. • startup - The port is booting up. • link_not_connected - The port has finished initialization, but a link with the fabric is not established. • online - The port is initialized and a link with the fabric has been established. • link_disconnected - The link was present at one point on this port but is currently not established. • offlined_by_user - The port is administratively disabled. • offlined_by_system - The port is set to offline by the system. This happens when the port encounters too many errors. • node_offline - The state information for the port cannot be retrieved. The node is offline or inaccessible.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
supported_protocols	array[string]	The network protocols supported by the FC port.
transceiver	transceiver	Properties of the transceiver connected to the FC port.

Name	Type	Description
uuid	string	The unique identifier of the FC port.
wwnn	string	The base world wide node name (WWNN) for the FC port.
wwpn	string	The base world wide port name (WWPN) for the FC port.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve historical performance metrics for an FC port

GET `/network/fc/ports/{fc_port.uuid}/metrics`

Introduced In: 9.14

Retrieves historical performance metrics for a Fibre Channel port.

Parameters

Name	Type	In	Required	Description
iops.other	integer	query	False	Filter by iops.other
iops.total	integer	query	False	Filter by iops.total

Name	Type	In	Required	Description
iops.write	integer	query	False	Filter by iops.write
iops.read	integer	query	False	Filter by iops.read
latency.other	integer	query	False	Filter by latency.other
latency.total	integer	query	False	Filter by latency.total
latency.write	integer	query	False	Filter by latency.write
latency.read	integer	query	False	Filter by latency.read
timestamp	string	query	False	Filter by timestamp
throughput.write	integer	query	False	Filter by throughput.write
throughput.read	integer	query	False	Filter by throughput.read
throughput.total	integer	query	False	Filter by throughput.total
status	string	query	False	Filter by status
uuid	string	query	False	Filter by uuid
duration	string	query	False	Filter by duration
fc_port.uuid	string	path	True	The unique identifier of the Fibre Channel port.

Name	Type	In	Required	Description
interval	string	query	False	The time range for the data. Examples can be 1h, 1d, 1m, 1w, 1y. The period for each time range is as follows: • 1h: Metrics over the most recent hour sampled over 15 seconds. • 1d: Metrics over the most recent day sampled over 5 minutes. • 1w: Metrics over the most recent week sampled over 30 minutes. • 1m: Metrics over the most recent month sampled over 2 hours. • 1y: Metrics over the most recent year sampled over a day. • Default value: 1 • enum: ["1h", "1d", "1w", "1m", "1y"]

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
order_by	array[string]	query	False	Order results by specified fields and optional [asc
desc] direction. Default direction is 'asc' for ascending.	return_records	boolean	query	False

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[records]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "duration": "PT15S",
      "iops": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "latency": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "status": "ok",
      "throughput": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
8585947	No metrics are available for the requested object.
8586225	An unexpected error occurred retrieving metrics for the requested object.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

records

Performance numbers, such as IOPS latency and throughput

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Type	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.
uuid	string	The unique identifier of the FC port.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve historical performance metrics for an FC port for a specific time

GET `/network/fc/ports/{fc_port.uuid}/metrics/{timestamp}`

Introduced In: 9.14

Retrieves historical performance metrics for a Fibre Channel port for a specific time.

Parameters

Name	Type	In	Required	Description
fc_port.uuid	string	path	True	The unique identifier of the Fibre Channel port.
timestamp	string	path	True	The timestamp of the performance data. • format: date-time
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.
uuid	string	The unique identifier of the FC port.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "duration": "PT15S",
  "iops": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "latency": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "status": "ok",
  "throughput": {
    "read": 200,
    "total": 1000,
    "write": 100
  },
  "timestamp": "2017-01-25 11:20:13 +0000",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
8585947	No metrics are available for the requested object.
8586225	An unexpected error occurred retrieving metrics for the requested object.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Type	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve an FC port

GET `/network/fc/ports/{uuid}`

Introduced In: 9.6

Retrieves an FC port.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `fabric.name`
- `statistics.*`
- `metric.*`

Related ONTAP commands

- `network fcp adapter show`

Learn more

- DOC /network/fc/ports

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	The unique identifier for the FC port.
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
description	string	A description of the FC port.
enabled	boolean	The administrative state of the FC port. If this property is set to *false*, all FC connectivity to FC interfaces are blocked. Optional in PATCH.

Name	Type	Description
fabric	fabric	Properties of the fabric to which the FC port is attached.
interface_count	integer	The number of FC interfaces currently provisioned on this port. This property is not supported in an SVM context.
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The FC port name.
node	node	
physical_protocol	string	The physical network protocol of the FC port.
speed	speed	The physical device speed related properties of the FC port.
state	string	The operational state of the FC port. • startup - The port is booting up. • link_not_connected - The port has finished initialization, but a link with the fabric is not established. • online - The port is initialized and a link with the fabric has been established. • link_disconnected - The link was present at one point on this port but is currently not established. • offlined_by_user - The port is administratively disabled. • offlined_by_system - The port is set to offline by the system. This happens when the port encounters too many errors. • node_offline - The state information for the port cannot be retrieved. The node is offline or inaccessible.

Name	Type	Description
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
supported_protocols	array[string]	The network protocols supported by the FC port.
transceiver	transceiver	Properties of the transceiver connected to the FC port.
uuid	string	The unique identifier of the FC port.
wwnn	string	The base world wide node name (WWNN) for the FC port.
wwpn	string	The base world wide port name (WWPN) for the FC port.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "description": "Fibre Channel Target Adapter 0a (ACME Fibre Channel
Adapter, rev. 1.0.0, 8G)",
  "fabric": {
    "connected_speed": 16,
    "name": "string",
    "port_address": "52100A",
    "switch_port": "ssan-g620-03:33"
  },
  "interface_count": 0,
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "duration": "PT15S",
    "iops": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 11:20:13 +0000"
  },
  "name": "0a",
  "node": {
    "_links": {
      "self": {
```

```
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "physical_protocol": "string",
  "speed": {
    "configured": "auto",
    "maximum": "32"
  },
  "state": "online",
  "statistics": {
    "iops_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "latency_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 11:20:13 +0000"
  },
  "supported_protocols": [
    "string"
  ],
  "transceiver": {
    "capabilities": [
      16
    ],
    "form_factor": "string",
    "manufacturer": "Acme, Inc.",
    "part_number": "string"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "wwnn": "20:00:00:50:56:b4:13:a8",
  "wwpn": "20:00:00:50:56:b4:13:a8"
}
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

fabric

Properties of the fabric to which the FC port is attached.

Name	Type	Description
connected	boolean	Reports if the physical port has established a connection with the FC fabric.
connected_speed	integer	The negotiated data rate between the target FC port and the fabric in gigabits per second.
name	string	The name of the fabric to which the port is connected. This is only available when the FC port is connected to a fabric. There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

Name	Type	Description
port_address	string	The FC port address of the host bus adapter (HBA) physical port. Each FC port in an FC switched fabric has its own unique FC port address for routing purposes. The FC port address is assigned by a switch in the fabric when that port logs in to the fabric. This property refers to the FC port address given to the physical host bus adapter (HBA) port when the port performs a fabric login (FLOGI). This is useful for obtaining statistics and diagnostic information from FC switches. This is a six-digit hexadecimal encoded numeric value.
switch_port	string	The switch port to which the FC port is connected.

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

Performance numbers, such as IOPS latency and throughput

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Type	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

speed

The physical device speed related properties of the FC port.

Name	Type	Description
configured	string	The configured speed of the FC port in gigabits per second.
maximum	string	The maximum speed supported by the FC port in gigabits per second.

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.

Name	Type	Description
write	integer	Performance metric for write I/O operations.

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Type	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

transceiver

Properties of the transceiver connected to the FC port.

Name	Type	Description
capabilities	array[integer]	The speeds of which the transceiver is capable in gigabits per second.

Name	Type	Description
form_factor	string	The form factor of the transceiver. Possible values are: • *sfp* - Small Form Factor - Pluggable • *sff* - Small Form Factor • *unknown* - Unknown
manufacturer	string	The manufacturer of the transceiver.
part_number	string	The part number of the transceiver.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update an FC port

PATCH `/network/fc/ports/{uuid}`

Introduced In: 9.6

Updates an FC port.

Related ONTAP commands

- `network fcp adapter modify`

Learn more

- DOC /network/fc/ports

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	The unique identifier for the FC port.

Request Body

Name	Type	Description
description	string	A description of the FC port.
enabled	boolean	The administrative state of the FC port. If this property is set to *false*, all FC connectivity to FC interfaces are blocked. Optional in PATCH.
fabric	fabric	Properties of the fabric to which the FC port is attached.
interface_count	integer	The number of FC interfaces currently provisioned on this port. This property is not supported in an SVM context.
name	string	The FC port name.
node	node	
physical_protocol	string	The physical network protocol of the FC port.
speed	speed	The physical device speed related properties of the FC port.

Name	Type	Description
state	string	The operational state of the FC port. • startup - The port is booting up. • link_not_connected - The port has finished initialization, but a link with the fabric is not established. • online - The port is initialized and a link with the fabric has been established. • link_disconnected - The link was present at one point on this port but is currently not established. • offlined_by_user - The port is administratively disabled. • offlined_by_system - The port is set to offline by the system. This happens when the port encounters too many errors. • node_offline - The state information for the port cannot be retrieved. The node is offline or inaccessible.
supported_protocols	array[string]	The network protocols supported by the FC port.
transceiver	transceiver	Properties of the transceiver connected to the FC port.
uuid	string	The unique identifier of the FC port.
wwnn	string	The base world wide node name (WWNN) for the FC port.
wwpn	string	The base world wide port name (WWPN) for the FC port.

Example request


```
{
  "description": "Fibre Channel Target Adapter 0a (ACME Fibre Channel
Adapter, rev. 1.0.0, 8G)",
  "fabric": {
    "connected_speed": 16,
    "name": "string",
    "port_address": "52100A",
    "switch_port": "ssan-g620-03:33"
  },
  "interface_count": 0,
  "name": "0a",
  "node": {
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "physical_protocol": "string",
  "speed": {
    "configured": "auto",
    "maximum": "32"
  },
  "state": "online",
  "supported_protocols": [
    "string"
  ],
  "transceiver": {
    "capabilities": [
      16
    ],
    "form_factor": "string",
    "manufacturer": "Acme, Inc.",
    "part_number": "string"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "wwnn": "20:00:00:50:56:b4:13:a8",
  "wwpn": "20:00:00:50:56:b4:13:a8"
}
```


Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
5374085	The node where the Fibre Channel port is located is offline.
5374087	The Fibre Channel port has active Fibre Channel interfaces and cannot be disabled.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

fabric

Properties of the fabric to which the FC port is attached.

Name	Type	Description
connected	boolean	Reports if the physical port has established a connection with the FC fabric.
connected_speed	integer	The negotiated data rate between the target FC port and the fabric in gigabits per second.
name	string	The name of the fabric to which the port is connected. This is only available when the FC port is connected to a fabric. There is an added computational cost to retrieving this property's value. It is not populated for a GET request unless it is explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

Name	Type	Description
port_address	string	The FC port address of the host bus adapter (HBA) physical port. Each FC port in an FC switched fabric has its own unique FC port address for routing purposes. The FC port address is assigned by a switch in the fabric when that port logs in to the fabric. This property refers to the FC port address given to the physical host bus adapter (HBA) port when the port performs a fabric login (FLOGI). This is useful for obtaining statistics and diagnostic information from FC switches. This is a six-digit hexadecimal encoded numeric value.
switch_port	string	The switch port to which the FC port is connected.

iops

The rate of I/O operations observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency

The round trip latency in microseconds observed at the storage object.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

throughput

The rate of throughput bytes per second observed at the storage object.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

Performance numbers, such as IOPS latency and throughput

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Type	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

node

Name	Type	Description
name	string	
uuid	string	

speed

The physical device speed related properties of the FC port.

Name	Type	Description
configured	string	The configured speed of the FC port in gigabits per second.
maximum	string	The maximum speed supported by the FC port in gigabits per second.

iops_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

latency_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.

Name	Type	Description
write	integer	Performance metric for write I/O operations.

throughput_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Type	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Type	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

transceiver

Properties of the transceiver connected to the FC port.

Name	Type	Description
capabilities	array[integer]	The speeds of which the transceiver is capable in gigabits per second.

Name	Type	Description
form_factor	string	The form factor of the transceiver. Possible values are: • *sfp* - Small Form Factor - Pluggable • *sff* - Small Form Factor • *unknown* - Unknown
manufacturer	string	The manufacturer of the transceiver.
part_number	string	The part number of the transceiver.

fc_port

A Fibre Channel (FC) port is the physical port of an FC adapter on an ONTAP cluster node that can be connected to an FC network to provide FC network connectivity. An FC port defines the location of an FC interface within the ONTAP cluster.

Name	Type	Description
description	string	A description of the FC port.
enabled	boolean	The administrative state of the FC port. If this property is set to *false*, all FC connectivity to FC interfaces are blocked. Optional in PATCH.
fabric	fabric	Properties of the fabric to which the FC port is attached.
interface_count	integer	The number of FC interfaces currently provisioned on this port. This property is not supported in an SVM context.
name	string	The FC port name.
node	node	
physical_protocol	string	The physical network protocol of the FC port.
speed	speed	The physical device speed related properties of the FC port.

Name	Type	Description
state	string	The operational state of the FC port. • startup - The port is booting up. • link_not_connected - The port has finished initialization, but a link with the fabric is not established. • online - The port is initialized and a link with the fabric has been established. • link_disconnected - The link was present at one point on this port but is currently not established. • offlined_by_user - The port is administratively disabled. • offlined_by_system - The port is set to offline by the system. This happens when the port encounters too many errors. • node_offline - The state information for the port cannot be retrieved. The node is offline or inaccessible.
supported_protocols	array[string]	The network protocols supported by the FC port.
transceiver	transceiver	Properties of the transceiver connected to the FC port.
uuid	string	The unique identifier of the FC port.
wwnn	string	The base world wide node name (WWNN) for the FC port.
wwpn	string	The base world wide port name (WWPN) for the FC port.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage HTTP proxy configuration

Manage HTTP proxy configuration

Overview

Configuration of an HTTP proxy for an SVM or a Cluster IPspace.

Retrieve HTTP proxy information

The HTTP proxy GET operation retrieves all configurations for an SVM or a Cluster IPspace via '/api/cluster'.

Examples

Retrieving all fields for all HTTP proxy configurations

```
# The API:
/api/network/http-proxy

# The call:
curl -X GET "https://<mgmt-ip>/api/network/http-
proxy?fields=*&return_records=true&return_timeout=15" -H  "accept:
application/json"

# The response:
{
"records": [
  {
    "uuid": "4133a1fc-7228-11e9-b40c-005056bb4f0c",
    "svm": {
        "name": "vs1",
        "uuid": "4133a1fc-7228-11e9-b40c-005056bb4f0c"
    },
    "server": "server1.example.com",
    "port": 3128,
    "authentication_enabled": false
  },
  {
    "uuid": "96219ce3-7214-11e9-828c-005056bb4f0c",
    "svm": {
        "name": "cluster-1",
        "uuid": "96219ce3-7214-11e9-828c-005056bb4f0c"
    },
    "ipspace": {
        "uuid": "7433520f-7214-11e9-828c-005056bb4f0c",
        "name": "Default"
    },
    "server": "1.1.1.",
    "port": 3128,
    "authentication_enabled": true
   }
],
"num_records": 2
}
```

Retrieving the HTTP proxy configuration for a specific SVM

```
# The API:
/api/network/http-proxy/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/http-proxy/96219ce3-7214-11e9-
828c-005056bb4f0c" -H  "accept: application/json"

# The response
{
"uuid": "96219ce3-7214-11e9-828c-005056bb4f0c",
"svm": {
    "name": "cluster-1",
    "uuid": "96219ce3-7214-11e9-828c-005056bb4f0c"
},
"ipspace": {
    "uuid": "7433520f-7214-11e9-828c-005056bb4f0c",
    "name": "Default"
},
"server": "1.1.1.1",
"port": 3128,
"authentication_enabled": false
}
```

Creating an HTTP proxy configuration

You can use the HTTP proxy POST operation to create an HTTP proxy configuration for the specified SVM.

Examples

Creating an HTTP proxy configuration for a particular SVM

```
# The API:
/api/network/http-proxy

# The call:
curl -X POST "https://<mgmt-ip>/api/network/http-proxy" -H  "accept:
application/json" -H  "Content-Type: application/json" -d "{    \"port\":
3128,  \"server\": \"1.1.1.1\",  \"svm\": {      \"name\": \"cluster-1\"
}}"
```

Creating an HTTP proxy configuration for a particular IPspace

```
# The API:
/api/network/http-proxy

# The call:
curl -X POST "https://<mgmt-ip>/api/network/http-proxy" -H  "accept:
application/json" -H  "Content-Type: application/json" -d "{  \"ipspace\":
{    \"name\": \"Default\"  },  \"port\": 3128,  \"server\": \"1.1.1.1\"}"
```

Creating an HTTP proxy configuration with authentication enabled

```
# The API:
/api/network/http-proxy

# The call:
curl -X POST "https://<mgmt-ip>/api/network/http-proxy" -H  "accept:
application/json" -H  "Content-Type: application/json" -d "{  \"ipspace\":
{    \"name\": \"Default\"  },  \"port\": 3128,  \"server\": \"1.1.1.1\",
\"authentication_enabled\":true, \"username\":\"test\",
\"password\":\"test\"}"
```

Update an HTTP proxy configuration for a specified SVM

You can use the HTTP proxy PATCH operation to update the HTTP proxy configuration for the specified SVM.

Example

The following example shows how a PATCH operation is used to update an HTTP proxy configuration for a specific SVM:

```
# The API:
/api/network/http-proxy/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/http-proxy/96219ce3-7214-
11e9-828c-005056bb4f0c" -H  "accept: application/json" -H  "Content-Type:
application/json" -d "{    \"port\": 3128,  \"server\":
\"server2.example.com\"}"
```

Delete an HTTP proxy configuration for a specified SVM

You can use the HTTP proxy DELETE operation to delete the HTTP proxy configuration for the specified SVM.

Example

The following example shows how a DELETE operation is used to delete an HTTP proxy configuration for a

specific SVM:

```
# The API:
/api/network/http-proxy/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/network/http-proxy/96219ce3-7214-
11e9-828c-005056bb4f0c" -H  "accept: application/json"
```

Retrieve HTTP proxy configurations for all SVMs and cluster IPspaces

GET `/network/http-proxy`

Introduced In: 9.7

Retrieves the HTTP proxy configurations of all the SVMs and Cluster IPspaces.

Related ONTAP commands

- `vserver http-proxy show`

Parameters

Name	Type	In	Required	Description
svm.name	string	query	False	Filter by svm.name
svm.uuid	string	query	False	Filter by svm.uuid
authentication_enabled	boolean	query	False	Filter by authentication_enabled • Introduced in: 9.9
server	string	query	False	Filter by server
scope	string	query	False	Filter by scope
ipspace.name	string	query	False	Filter by ipspace.name
ipspace.uuid	string	query	False	Filter by ipspace.uuid
uuid	string	query	False	Filter by uuid

Name	Type	In	Required	Description
port	integer	query	False	Filter by port • Max value: 65535 • Min value: 1
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Max value: 120 • Min value: 0 • Default value: 15
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of HTTP proxy records
records	array[network_http_proxy]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "ipspace": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "port": 3128,
      "scope": "string",
      "server": "string",
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "uuid": "string"
    }
  ]
}
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input. This is mutually exclusive with SVM during POST and PATCH.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

svm

This is mutually exclusive with IPspace during POST and PATCH.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

network_http_proxy

Name	Type	Description
_links	_links	
authentication_enabled	boolean	Specifies whether or not authentication with the HTTP proxy server is enabled.
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input. This is mutually exclusive with SVM during POST and PATCH.
port	integer	The port number on which the HTTP proxy service is configured on the proxy server.
scope	string	Set to “svm” for HTTP proxy owned by an SVM. Otherwise, set to "cluster".
server	string	Fully qualified domain name (FQDN) or IP address of the HTTP proxy server.
svm	svm	This is mutually exclusive with IPspace during POST and PATCH.
uuid	string	The UUID that uniquely identifies the HTTP proxy.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code

Name	Type	Description
message	string	Error message
target	string	The target parameter that caused the error.

Create an HTTP proxy configuration for an SVM or cluster IPspace

POST `/network/http-proxy`

Introduced In: 9.7

Creates an HTTP proxy configuration for an SVM or a Cluster IPspace. Important notes:

- IPv6 must be enabled if IPv6 family addresses are specified in the "server" field.
- The server and the port combination specified using the "server" and "port" fields is validated during this operation. The validation will fail in the following scenarios:
  - The HTTP proxy service is not configured on the server.
  - The HTTP proxy service is not running on the specified port.
  - The server is unreachable.

Required properties

- SVM-scoped HTTP proxy
  - `svm.uuid` or `svm.name` - Existing SVM in which to create the HTTP proxy.
- Cluster-scoped HTTP proxy
  - `ipspace.uuid` or `ipspace.name` - Existing Cluster IPspace in which to create the HTTP proxy.
- `server` - HTTP proxy server FQDN or IP address.
- `port` - HTTP proxy server port.

Optional properties

- `authentication_enabled` - Specifies if authentication is required for the HTTP proxy server.
- `username` - Username used to authenticate with the HTTP proxy server.
- `password` - Password used to authenticate with the HTTP proxy server.

Related ONTAP commands

- `vserver http-proxy create`

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
authentication_enabled	boolean	Specifies whether or not authentication with the HTTP proxy server is enabled.
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input. This is mutually exclusive with SVM during POST and PATCH.
password	string	Password to authenticate with the HTTP proxy server when authentication_enabled is set to "true".
port	integer	The port number on which the HTTP proxy service is configured on the proxy server.
scope	string	Set to “svm” for HTTP proxy owned by an SVM. Otherwise, set to "cluster".
server	string	Fully qualified domain name (FQDN) or IP address of the HTTP proxy server.
svm	svm	This is mutually exclusive with IPspace during POST and PATCH.
username	string	Username to authenticate with the HTTP proxy server when authentication_enabled is set to "true".

Name	Type	Description
uuid	string	The UUID that uniquely identifies the HTTP proxy.

Example request

```
{
  "ipspace": {
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "password": "string",
  "port": 3128,
  "scope": "string",
  "server": "string",
  "svm": {
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "username": "string",
  "uuid": "string"
}
```

Response

```
Status: 201, Created
```

Name	Type	Description
num_records	integer	Number of HTTP proxy records
records	array[network_http_proxy]	

Example response


```
{
  "num_records": 1,
  "records": [
    {
      "ipspace": {
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "password": "string",
      "port": 3128,
      "scope": "string",
      "server": "string",
      "svm": {
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "username": "string",
      "uuid": "string"
    }
  ]
}
```


Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
26214473	HTTP proxy configuration is not valid.
26214476	The "IPspace" parameter should not be specified in the SVM context.
26214477	The specified IPspace does not exist.

Error Code	Description
23724130	Cannot use an IPv6 name server address because there are no IPv6 interfaces.
26214481	Username and password cannot be empty when HTTP proxy authentication is enabled.
26214482	Username and password cannot be specified when HTTP proxy authentication is disabled.
26214480	One of "svm.name", "svm.uuid", "ipspace.name" or "ipspace.uuid" must be specified.
2621462	SVM "vs0" does not exist.
262186	Field "svm.name" cannot be used with field "ipspace.name".

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input. This is mutually exclusive with SVM during POST and PATCH.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

svm

This is mutually exclusive with IPspace during POST and PATCH.

Name	Type	Description
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

network_http_proxy

Name	Type	Description
authentication_enabled	boolean	Specifies whether or not authentication with the HTTP proxy server is enabled.
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input. This is mutually exclusive with SVM during POST and PATCH.

Name	Type	Description
password	string	Password to authenticate with the HTTP proxy server when authentication_enabled is set to "true".
port	integer	The port number on which the HTTP proxy service is configured on the proxy server.
scope	string	Set to “svm” for HTTP proxy owned by an SVM. Otherwise, set to "cluster".
server	string	Fully qualified domain name (FQDN) or IP address of the HTTP proxy server.
svm	svm	This is mutually exclusive with IPspace during POST and PATCH.
username	string	Username to authenticate with the HTTP proxy server when authentication_enabled is set to "true".
uuid	string	The UUID that uniquely identifies the HTTP proxy.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message

Name	Type	Description
target	string	The target parameter that caused the error.

Delete HTTP proxy configuration for an SVM or cluster IPspace

DELETE `/network/http-proxy/{uuid}`

Introduced In: 9.7

Deletes the HTTP proxy configuration of the specified SVM or Cluster IPspace.

Related ONTAP commands

- `vserver http-proxy delete`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	HTTP proxy UUID

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
138281013	The HTTP Proxy cannot be deleted while in use by a cloud agent connection.
2621574	This operation is not permitted on a SVM that is configured as the destination of a Metrocluster SVM relationship.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Display HTTP proxy server, port, and IPspace information for an SVM or cluster IPspace

GET `/network/http-proxy/{uuid}`

Introduced In: 9.7

Displays the HTTP proxy server, port, and IPspace of the specified SVM or Cluster IPspace.

Related ONTAP commands

- `vserver http-proxy show`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	HTTP proxy UUID
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
authentication_enabled	boolean	Specifies whether or not authentication with the HTTP proxy server is enabled.
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input. This is mutually exclusive with SVM during POST and PATCH.
port	integer	The port number on which the HTTP proxy service is configured on the proxy server.
scope	string	Set to “svm” for HTTP proxy owned by an SVM. Otherwise, set to "cluster".

Name	Type	Description
server	string	Fully qualified domain name (FQDN) or IP address of the HTTP proxy server.
svm	svm	This is mutually exclusive with IPspace during POST and PATCH.
uuid	string	The UUID that uniquely identifies the HTTP proxy.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "ipspace": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "port": 3128,
  "scope": "string",
  "server": "string",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "string"
}
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input. This is mutually exclusive with SVM during POST and PATCH.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

svm

This is mutually exclusive with IPspace during POST and PATCH.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update proxy server, port, username, and password parameters

PATCH `/network/http-proxy/{uuid}`

Introduced In: 9.7

Updates the proxy server, port, username, and password parameters. Important notes:

- IPv6 must be enabled if IPv6 family addresses are specified in the "server" field.
- The server and the port combination specified using the "server" and "port" fields is validated during this operation. The validation will fail in the following scenarios:
  - The HTTP proxy service is not configured on the server.
  - The HTTP proxy service is not running on the specified port.
  - The server is unreachable.

Related ONTAP commands

- `vserver http-proxy modify`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	HTTP proxy UUID

Request Body

Name	Type	Description
authentication_enabled	boolean	Specifies whether or not authentication with the HTTP proxy server is enabled.

Name	Type	Description
password	string	Password to authenticate with the HTTP proxy server when authentication_enabled is set to "true".
port	integer	The port number on which the HTTP proxy service is configured on the proxy server.
scope	string	Set to “svm” for HTTP proxy owned by an SVM. Otherwise, set to "cluster".
server	string	Fully qualified domain name (FQDN) or IP address of the HTTP proxy server.
username	string	Username to authenticate with the HTTP proxy server when authentication_enabled is set to "true".
uuid	string	The UUID that uniquely identifies the HTTP proxy.

Example request

```
{
  "password": "string",
  "port": 3128,
  "scope": "string",
  "server": "string",
  "username": "string",
  "uuid": "string"
}
```

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
26214473	The HTTP proxy configuration is not valid.
23724130	Cannot use an IPv6 name server address because there are no IPv6 interfaces.
26214481	Username and password cannot be empty when HTTP proxy authentication is enabled.
26214482	Username and password cannot be specified when HTTP proxy authentication is disabled.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name is supplied on input. This is mutually exclusive with SVM during POST and PATCH.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

svm

This is mutually exclusive with IPspace during POST and PATCH.

Name	Type	Description
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

network_http_proxy

Name	Type	Description
authentication_enabled	boolean	Specifies whether or not authentication with the HTTP proxy server is enabled.
password	string	Password to authenticate with the HTTP proxy server when authentication_enabled is set to "true".

Name	Type	Description
port	integer	The port number on which the HTTP proxy service is configured on the proxy server.
scope	string	Set to “svm” for HTTP proxy owned by an SVM. Otherwise, set to "cluster".
server	string	Fully qualified domain name (FQDN) or IP address of the HTTP proxy server.
username	string	Username to authenticate with the HTTP proxy server when authentication_enabled is set to "true".
uuid	string	The UUID that uniquely identifies the HTTP proxy.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage BGP peer groups

Manage BGP peer groups

Overview

The following operations are supported:

- Creation: POST network/ip/bgp/peer-groups
- Collection Get: GET network/ip/bgp/peer-groups
- Instance Get: GET network/ip/bgp/peer-groups/{uuid}
- Instance Patch: PATCH network/ip/bgp/peer-groups/{uuid}
- Instance Delete: DELETE network/ip/bgp/peer-groups/{uuid}

Retrieving network BGP sessions information

The IP BGP peer-groups GET API retrieves and displays relevant information pertaining to the BGP peer-groups configured in the cluster. The response can contain a list of multiple BGP peer-groups or a specific peer-group. Each BGP peer-group represents a BGP session configured between a local interface and a peer router.

Examples

Retrieving all BGP peer-groups in the cluster

The following example shows the list of all BGP peer-groups configured in a cluster.

```
# The API:
/api/network/ip/bgp/peer-groups

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/bgp/peer-groups" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "5f22ae9d-87b2-11e9-a3a6-005056bb81a4",
    "name": "pg1",
    "_links": {
      "self": {
        "href": "/api/network/ip/bgp/peer-groups/5f22ae9d-87b2-11e9-a3a6-
005056bb81a4"
      }
    }
  },
  {
    "uuid": "5fd08be3-87b2-11e9-952f-005056bb2170",
    "name": "pg2",
    "_links": {
      "self": {
        "href": "/api/network/ip/bgp/peer-groups/5fd08be3-87b2-11e9-952f-
005056bb2170"
      }
    }
  }
],
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/network/ip/bgp/peer-groups"
  }
}
}
```

Retrieving a specific BGP peer-group

The following example shows the response when a specific BGP peer-group is requested. The system returns an error when there is no peer-group with the requested UUID.

```
# The API:
/api/network/ip/bgp/peer-groups/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/bgp/peer-groups/5fd08be3-
87b2-11e9-952f-005056bb2170" -H "accept: application/hal+json"

# The response:
{
"uuid": "5fd08be3-87b2-11e9-952f-005056bb2170",
"name": "pg2",
"ipspace": {
  "uuid": "84fd3375-879a-11e9-a3a6-005056bb81a4",
  "name": "Default",
  "_links": {
    "self": {
      "href": "/api/network/ipspaces/84fd3375-879a-11e9-a3a6-005056bb81a4"
    }
  }
},
"local": {
  "interface": {
    "uuid": "5e76a305-87b2-11e9-952f-005056bb2170",
    "name": "bgp2",
    "ip": {
      "address": "10.10.10.2"
    }
  },
  "port": {
    "uuid": "f8ff73de-879a-11e9-952f-005056bb2170",
    "name": "e0h",
    "node": {
      "name": "node1"
    }
  }
},
"peer": {
  "address": "10.10.10.1",
  "asn": 65501
},
"state": "up",
"_links": {
  "self": {
    "href": "/api/network/ip/bgp/peer-groups/5fd08be3-87b2-11e9-952f-
005056bb2170"
```

```
  }
}
}
```

Retrieving specific fields and limiting the output using filters

The following example shows the response when a filter is applied (location.port.node.name=node1) and only certain fields are requested. Filtered fields are in the output in addition to the default fields and requested fields.

```
# The API:
/api/network/ip/bgp/peer-groups

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/bgp/peer-
groups?local.port.node.name=node1&fields=local.interface.ip,peer" -H
"accept: application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "5f22ae9d-87b2-11e9-a3a6-005056bb81a4",
    "name": "pg1",
    "local": {
      "interface": {
        "ip": {
          "address": "10.10.10.1"
        }
      },
      "port": {
        "node": {
          "name": "node1"
        }
      }
    },
    "peer": {
      "address": "10.10.10.2",
      "asn": 65501
    },
    "_links": {
      "self": {
        "href": "/api/network/ip/bgp/peer-groups/5f22ae9d-87b2-11e9-a3a6-
```

```
005056bb81a4"
      }
    }
  }
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/network/ip/bgp/peer-
groups?local.port.node.name=node1&fields=local.interface.ip,peer"
  }
}
}
```

Creating a BGP peer-group

The BGP peer-group POST API is used to create a peer-group as shown in the following examples.

Examples

Creating a BGP peer-group with an existing interface

The following example shows how to create a BGP peer-group between an existing interface "bgp1" and peer router with the address "10.10.10.10". The local interface "bgp1" needs to support the management-bgp service, otherwise the system returns an error.

```
# The API:
/api/network/ip/bgp/peer-groups

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/bgp/peer-
groups?return_records=true" -d'{"name": "newPg", "ipspace.name":"Default",
"local.interface.name": "bgp1", "peer.address":"10.10.10.10"}'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "e3faacc6-87cb-11e9-a3a6-005056bb81a4",
    "name": "newPg",
    "ipspace": {
      "name": "Default"
    },
    "local": {
      "interface": {
        "name": "bgp1"
      }
    },
    "peer": {
      "address": "10.10.10.10"
    },
    "_links": {
      "self": {
        "href": "/api/network/ip/bgp/peer-groups/e3faacc6-87cb-11e9-a3a6-
005056bb81a4"
      }
    }
  }
]
}
```

Creating a BGP peer-group and provisioning a new local interface

The following example shows how to create a BGP peer-group with any local interface. If the local interface doesn't exist, the system will create it first before creating the peer-group.

```
# The API:
/api/network/ip/bgp/peer-groups

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/bgp/peer-
groups?return_records=true" -d'{"name": "newPg1",
"ipspace.name":"Default", "local": {"interface": {"name": "newlif"}, "ip":
{"address": "9.9.9.9", "netmask": "24"}, "port": {"name": "e0f", "node":
{"name": "node1"}}}, "peer.address":"10.10.10.10"}'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "c292f069-8872-11e9-a3a6-005056bb81a4",
    "name": "newPg1",
    "ipspace": {
      "name": "Default"
    },
    "local": {
      "interface": {
        "name": "newlif"
      },
      "port": {
        "name": "e0f",
        "node": {
          "name": "node1"
        }
      }
    },
    "peer": {
      "address": "10.10.10.10"
    },
    "_links": {
      "self": {
        "href": "/api/network/ip/bgp/peer-groups/c292f069-8872-11e9-a3a6-
005056bb81a4"
      }
    }
  }
]
}
```

Updating BGP peer-groups

The BGP peer-groups PATCH API is used to update attributes of a peer-group.

Examples

Updating the peer router address

The following example shows how the PATCH request changes the peer router IP address.

```
# The API:
/api/network/ip/bgp/peer-groups/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ip/bgp/peer-groups/80d271c9-
1f43-11e9-803e-005056a7646a" -H "accept: application/hal+json" -d
'{"peer.address": "10.10.10.20" }'
{
}
```

Updating the peer-group to a new name

The following example shows how the PATCH request renames the peer-group.

```
# The API:
/api/network/ip/bgp/peer-groups/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ip/bgp/peer-groups/80d271c9-
1f43-11e9-803e-005056a7646a" -H "accept: application/hal+json" -d
'{"name": "NewName"}'
{
}
```

Deleting BGP peer-groups

The BGP peer-groups DELETE API is used to delete an BGP peer-group.

Example

Deleting a BGP peer-group

The following DELETE request deletes a BGP peer-group.

```
# The API:
/api/network/ip/bgp/peer-group/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/network/ip/bgp/peer-groups/80d271c9-
1f43-11e9-803e-005056a7646a"
{
}
```

Retrieve all BGP peer group details for VIP

GET `/network/ip/bgp/peer-groups`

Introduced In: 9.7

Retrieves the details of all BGP peer groups for VIP.

Related ONTAP Commands

- `network bgp peer-group show`

Parameters

Name	Type	In	Required	Description
peer.asn	integer	query	False	Filter by peer.asn
peer.is_next_hop	boolean	query	False	Filter by peer.is_next_hop • Introduced in: 9.9
peer.address	string	query	False	Filter by peer.address

Name	Type	In	Required	Description
peer.md5_enabled	boolean	query	False	Filter by peer.md5_enabled • Introduced in: 9.16
peer.md5_secret	string	query	False	Filter by peer.md5_secret • Introduced in: 9.16 • maxLength: 79 • minLength: 1
ipspace.name	string	query	False	Filter by ipspace.name
ipspace.uuid	string	query	False	Filter by ipspace.uuid
uuid	string	query	False	Filter by uuid
local.interface.ip.address	string	query	False	Filter by local.interface.ip.address
local.interface.name	string	query	False	Filter by local.interface.name
local.interface.uuid	string	query	False	Filter by local.interface.uuid
local.port.node.name	string	query	False	Filter by local.port.node.name
local.port.uuid	string	query	False	Filter by local.port.uuid
local.port.name	string	query	False	Filter by local.port.name
name	string	query	False	Filter by name
state	string	query	False	Filter by state

Name	Type	In	Required	Description
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[bgp_peer_group]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "ipspace": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "local": {
        "interface": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "ip": {
            "address": "10.10.10.7"
          },
          "name": "lif1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "port": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "name": "e1b",
          "node": {
            "name": "node1"
          },
```

```
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      },
      "name": "bgpv4peer",
      "peer": {
        "address": "10.10.10.7",
        "md5_enabled": 1,
        "md5_secret": "SECRET_WORD"
      },
      "state": "string",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

ipspace

Either the UUID or name is supplied on input.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

ip

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address

interface

A network interface. Either UUID or name may be supplied on input.

Name	Type	Description
_links	_links	
ip	ip	IP information

Name	Type	Description
name	string	The name of the interface. If only the name is provided, the SVM scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the interface.

ip

IP information to create a new interface.

Name	Type	Description
address	string	IPv4 or IPv6 address
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

node

Name	Type	Description
name	string	Name of node on which the port is located.

port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

local

Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.

Name	Type	Description
interface	interface	A network interface. Either UUID or name may be supplied on input.
port	port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.

peer

Information describing the router to peer with

Name	Type	Description
address	string	Peer router address
asn	integer	Autonomous system number of peer
is_next_hop	boolean	Use peer address as next hop.
md5_enabled	boolean	Enable or disable TCP MD5 signatures per RFC 2385.
md5_secret	string	The shared TCP MD5 secret key. This can either be given as a password or hexadecimal key.

bgp_peer_group

A BGP peer group between a local network interface and a router, for the purpose of announcing VIP interface locations for SVMs in this IPspace.

Name	Type	Description
ipspace	ipspace	Either the UUID or name is supplied on input.
local	local	Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.

Name	Type	Description
name	string	Name of the peer group
peer	peer	Information describing the router to peer with
state	string	State of the peer group
uuid	string	UUID of the peer group

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create a new BGP peer group for VIP

POST `/network/ip/bgp/peer-groups`

Introduced In: 9.7

Creates a new BGP peer group for VIP. Multipath-routing is turned on cluster-wide automatically if the peer group being created results in multiple paths being available for an existing or future VIP interface.

Required properties

- `name` - Name of the peer-group to create.
- `ipspace.name` or `ipspace.uuid` or `local.port`
  - Required with local.interface.name or local.ip.address to identify a local interface

    - Optional when local.interface.uuid is specified
- `local.interface.uuid` or `local.interface.name` or `local.ip.address`
    - Required when specifying an existing local interface.
- `local.ip` and `local.port`
    - Required to create a new local interface.
- `peer.address` - IP address of the peer router

Default property values

If not specified in POST, the following default property values are assigned:

- `is_next_hop` - *false*
- `peer.md5_enabled` - *false*

Related ONTAP commands

- `network bgp peer-group create`

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
ipspace	ipspace	Either the UUID or name is supplied on input.
local	local	Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.
name	string	Name of the peer group

Name	Type	Description
peer	peer	Information describing the router to peer with
state	string	State of the peer group
uuid	string	UUID of the peer group

Example request

```
{
  "ipspace": {
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "local": {
    "interface": {
      "name": "lif1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "ip": {
      "address": "10.10.10.7",
      "netmask": "24"
    },
    "port": {
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "name": "bgpv4peer",
  "peer": {
    "address": "10.10.10.7",
    "md5_enabled": 1,
    "md5_secret": "SECRET_WORD"
  },
  "state": "string",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

```
Status: 201, Created
```

Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1376963	Duplicate IP address is specified.
1966133	Since masking an address with a netmask represents an entire IP subnet, the masked and unmasked IP addresses cannot be the same.
1966267	IPv6 addresses must have a prefix length of 64.
1966269	IPv4 addresses must have a netmask length between 1 and 32.
1967082	IPspace name and UUID must match if both are given.
1967155	The specified local.port.name does not match the location.port.name for the specified local.interface.
1967156	The specified local.port.node.name does not match the location.port.node.name for the specified local.interface.
1967157	The specified local.port.uuid does not match the location.port.uuid for the specified local.interface.
1967158	The specified local.interface.name does not exist in the associated IPspace. local.ip.address and local.ip.netmask are required to create a new LIF.
1967159	local.interface does not support management-bgp service.
1967160	The specified local.interface.name does not match the specified interface name of local.interface.uuid.
1967161	The specified local.interface.uuid does not exist in the specified IPspace.

Error Code	Description
1967162	Either local.interface or local.ip and local.port are required to specify a local LIF.
1967163	The specified local.port.name does not match the specified port name of local.port.uuid.
1967164	The specified local.port.node.name does not match the specified node name of local.port.uuid.
1967165	The specified local.port does not exist.
1967166	ipspace.uuid or ipspace.name must be provided with local.interface.name together to identify a LIF.
1967167	Internal error. Failed to update BGP configuration for node. Retry the command, if necessary.
1967168	Internal error. Failed to create a VIP port for IPspace on node. Retry the command, if necessary.
1967169	Internal error. BGP configuration changed during the operation. Retry the command, if necessary.
1967170	Internal error. VIP port configuration changed during the operation. Retry the command, if necessary.
1967171	Internal error. Fail to access or update BGP peer group. Retry the command, if necessary.
1967172	Peer group could not be updated because IPspace does not exist. Retry the command, if necessary.
1967173	The specified local.ip.address does not match the address for the specified local.interface.
1967174	The specified local.ip.netmask does not match the netmask for the specified local.interface.
1967176	The specified local.interface.name does not exist in the associated IPspace. local.port.name, local.port.node.name, or local.port.uuid is required to create a new LIF.
1967177	Internal error. Failed to access the local interface. Retry the command, if necessary.
1967178	The IPv6 address specified with local.ip.address is not supported because it is link-local, multicast, v4-compatible, v4-mapped, loopback or "::".
1967179	The IPv4 address specified with local.ip.address is not supported because it is multicast, loopback or 0.0.0.0.
1967187	Configuring 4 bytes peer.asn requires an effective cluster version of 9.9.1 or later.
1967188	Configuring peer address as a next hop requires an effective cluster version of 9.9.1 or later.
1967189	The parameter peer.asn can’t be zero.

Error Code	Description
1967192	Configuring peer.md5_enabled requires an effective cluster version of 9.16.1 or later.
1967193	Configuring peer.md5_enabled requires the peer.md5_secret parameter.
1967194	Configuring peer.md5_secret requires that peer.md5_enabled is set to true.
53281985	Internal error. Failed to update BGP peer group because BGP LIF moved during the operation. Wait a few minutes and try the command again.
53282006	BGP peer group could not be updated to use a peer address because the value provided is not a valid peer address. If necessary, try the command again with a routable host address.
53282007	BGP peer group could not be updated to use a peer address because the address represents a different address family to the address of the associated BGP LIF. If necessary, try the command again with a matching address family.
53282018	Failed to create BGP peer group because an existing peer group has already established a BGP session between LIF and peer address. If necessary, try the command again with a different BGP LIF or a different peer address.
53282021	IPsec must be enabled to use TCP MD5 in BGP sessions with a BGP peer-group.
53282024	peer.md5_secret should be 1-80 bytes.
53282025	peer.md5_secret should have an even length.
53282026	The hex format of peer.md5_secret should have only hex string starting with '0x'.
53282027	peer.md5_secret should be 1-79 characters.
53282028	peer.md5_secret supports only printable ASCII characters such as numbers, alphabets, or special characters.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Either the UUID or name is supplied on input.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

ip

IP information

interface

A network interface. Either UUID or name may be supplied on input.

Name	Type	Description
ip	ip	IP information
name	string	The name of the interface. If only the name is provided, the SVM scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the interface.

ip

IP information to create a new interface.

Name	Type	Description
address	string	IPv4 or IPv6 address

Name	Type	Description
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

node

Name	Type	Description
name	string	Name of node on which the port is located.

port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

local

Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.

Name	Type	Description
interface	interface	A network interface. Either UUID or name may be supplied on input.
ip	ip	IP information to create a new interface.
port	port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.

peer

Information describing the router to peer with

Name	Type	Description
address	string	Peer router address
asn	integer	Autonomous system number of peer
is_next_hop	boolean	Use peer address as next hop.
md5_enabled	boolean	Enable or disable TCP MD5 signatures per RFC 2385.
md5_secret	string	The shared TCP MD5 secret key. This can either be given as a password or hexadecimal key.

bgp_peer_group

A BGP peer group between a local network interface and a router, for the purpose of announcing VIP interface locations for SVMs in this IPspace.

Name	Type	Description
ipspace	ipspace	Either the UUID or name is supplied on input.
local	local	Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.
name	string	Name of the peer group
peer	peer	Information describing the router to peer with
state	string	State of the peer group
uuid	string	UUID of the peer group

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete a BGP peer group for VIP

DELETE `/network/ip/bgp/peer-groups/{uuid}`

Introduced In: 9.7

Deletes a BGP peer group for VIP.

Related ONTAP commands

- `network bgp peer-group delete`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	UUID of the peer group

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
53282019	Internal error. Failed to remove BGP peer group on node. Wait a few minutes and try the command again.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve details of a BGP peer group for VIP

GET `/network/ip/bgp/peer-groups/{uuid}`

Introduced In: 9.7

Retrieves details of a BGP peer group for VIP.

Related ONTAP commands

- `network bgp peer-group show`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	UUID of the peer group
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
ipspace	ipspace	Either the UUID or name is supplied on input.
local	local	Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.
name	string	Name of the peer group
peer	peer	Information describing the router to peer with
state	string	State of the peer group
uuid	string	UUID of the peer group

Example response

```
{
  "ipspace": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "local": {
    "interface": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "ip": {
        "address": "10.10.10.7"
      },
      "name": "lif1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "port": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "name": "bgpv4peer",
  "peer": {
    "address": "10.10.10.7",
    "md5_enabled": 1,
    "md5_secret": "SECRET_WORD"
  },
  "state": "string",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

ipspace

Either the UUID or name is supplied on input.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

ip

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address

interface

A network interface. Either UUID or name may be supplied on input.

Name	Type	Description
_links	_links	
ip	ip	IP information
name	string	The name of the interface. If only the name is provided, the SVM scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the interface.

ip

IP information to create a new interface.

Name	Type	Description
address	string	IPv4 or IPv6 address
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

node

Name	Type	Description
name	string	Name of node on which the port is located.

port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

local

Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.

Name	Type	Description
interface	interface	A network interface. Either UUID or name may be supplied on input.
port	port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.

peer

Information describing the router to peer with

Name	Type	Description
address	string	Peer router address
asn	integer	Autonomous system number of peer
is_next_hop	boolean	Use peer address as next hop.
md5_enabled	boolean	Enable or disable TCP MD5 signatures per RFC 2385.
md5_secret	string	The shared TCP MD5 secret key. This can either be given as a password or hexadecimal key.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update a BGP peer group for VIP

PATCH `/network/ip/bgp/peer-groups/{uuid}`

Introduced In: 9.7

Updates a BGP peer group for VIP.

Related ONTAP commands

- `network bgp peer-group modify`
- `network bgp peer-group rename`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	UUID of the peer group

Request Body

Name	Type	Description
local	local	Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.
name	string	Name of the peer group
peer	peer	Information describing the router to peer with
state	string	State of the peer group
uuid	string	UUID of the peer group

Example request

```
{
  "name": "bgpv4peer",
  "peer": {
    "address": "10.10.10.7",
    "md5_enabled": 1,
    "md5_secret": "SECRET_WORD"
  },
  "state": "string",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1967171	Internal error. Fail to access or update BGP peer group. Retry the command, if necessary.
1967188	Configuring peer address as a next hop requires an effective cluster version of 9.9.1 or later.
1967192	Configuring peer.md5_enabled requires an effective cluster version of 9.16.1 or later.
1967193	Configuring peer.md5_enabled requires the peer.md5_secret parameter.
1967194	Configuring peer.md5_secret requires that peer.md5_enabled is set to true.
53281998	Failed to rename the BGP peer group because that name is already assigned to a different peer group in the IPspace.
53282006	BGP peer group could not be updated to use a peer address because the value provided is not a valid peer address. If necessary, try the command again with a routable host address.
53282007	BGP peer group could not be updated to use a peer address because the address represents a different address family to the address of the associated BGP LIF. If necessary, try the command again with a matching address family.
53282018	Failed to create BGP peer group because an existing peer group has already established a BGP session between LIF and peer address. If necessary, try the command again with a different BGP LIF or a different peer address.
53282020	To utilize the peer as the next hop, the peer IP address must be within the same subnet as the BGP LIF.
53282021	IPsec must be enabled to use TCP MD5 in BGP sessions with a BGP peer-group.

Error Code	Description
53282024	peer.md5_secret should be 1-80 bytes.
53282025	peer.md5_secret should have an even length.
53282026	The hex format of peer.md5_secret should only contain a hex string starting with '0x'. The specified peer.md5-secret contains non-hex characters.
53282027	peer.md5_secret should be 1-79 characters.
53282028	peer.md5_secret supports only printable ASCII characters such as numbers, alphabets, or special characters.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Either the UUID or name is supplied on input.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

ip

IP information

interface

A network interface. Either UUID or name may be supplied on input.

Name	Type	Description
ip	ip	IP information
name	string	The name of the interface. If only the name is provided, the SVM scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the interface.

ip

IP information to create a new interface.

Name	Type	Description
address	string	IPv4 or IPv6 address

Name	Type	Description
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

node

Name	Type	Description
name	string	Name of node on which the port is located.

port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

local

Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.

peer

Information describing the router to peer with

Name	Type	Description
address	string	Peer router address
is_next_hop	boolean	Use peer address as next hop.
md5_enabled	boolean	Enable or disable TCP MD5 signatures per RFC 2385.
md5_secret	string	The shared TCP MD5 secret key. This can either be given as a password or hexadecimal key.

bgp_peer_group

A BGP peer group between a local network interface and a router, for the purpose of announcing VIP interface locations for SVMs in this IPspace.

Name	Type	Description
local	local	Information describing the local interface that is being used to peer with a router using BGP. On a POST operation, an existing BGP interface is used by specifying the interface, or create a new one by specifying the port and IP address.
name	string	Name of the peer group
peer	peer	Information describing the router to peer with
state	string	State of the peer group
uuid	string	UUID of the peer group

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage network IP interfaces

Manage network IP interfaces

Overview

The following operations are supported:

- Creation: POST network/ip/interfaces
- Collection Get: GET network/ip/interfaces
- Instance Get: GET network/ip/interfaces/{uuid}
- Instance Patch: PATCH network/ip/interfaces/{uuid}
- Instance Delete: DELETE network/ip/interfaces/{uuid}

Retrieving network interface information

The IP interfaces GET API retrieves and displays relevant information pertaining to the interfaces configured in the cluster. The response can contain a list of multiple interfaces or a specific interface. The fields returned in the response vary for different interfaces and configurations.

Examples

Retrieving all interfaces in the cluster

The following example shows the list of all interfaces configured in a cluster.

```
# The API:
/api/network/ip/interfaces

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/interfaces" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "14531286-59fc-11e8-ba55-005056b4340f",
    "name": "user-cluster-01_mgmt1",
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/14531286-59fc-11e8-ba55-
005056b4340f"
      }
    }
  },
  {
    "uuid": "145318ba-59fc-11e8-ba55-005056b4340f",
```

```
    "name": "user-cluster-01_clus2",
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/145318ba-59fc-11e8-ba55-
005056b4340f"
      }
    }
  },
  {
    "uuid": "14531e45-59fc-11e8-ba55-005056b4340f",
    "name": "user-cluster-01_clus1",
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/14531e45-59fc-11e8-ba55-
005056b4340f"
      }
    }
  },
  {
    "uuid": "245979de-59fc-11e8-ba55-005056b4340f",
    "name": "cluster_mgmt",
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/245979de-59fc-11e8-ba55-
005056b4340f"
      }
    }
  },
  {
    "uuid": "c670707c-5a11-11e8-8fcb-005056b4340f",
    "name": "lif1",
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/c670707c-5a11-11e8-8fcb-
005056b4340f"
      }
    }
  }
],
"num_records": 5,
"_links": {
  "self": {
    "href": "/api/network/ip/interfaces"
  }
}
}
```

Retrieving a specific Cluster-scoped interface

The following example shows the response when a specific Cluster-scoped interface is requested. The system returns an error when there is no interface with the requested UUID. SVM information is not returned for Cluster-scoped interfaces.

```
# The API:
/api/network/ip/interfaces/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/interfaces/245979de-59fc-
11e8-ba55-005056b4340f" -H "accept: application/hal+json"

# The response:
{
"uuid": "245979de-59fc-11e8-ba55-005056b4340f",
"name": "cluster_mgmt",
"ip": {
  "address": "10.63.41.6",
  "netmask": "18",
  "family": "ipv4",
},
"enabled": true,
"state": "up",
"scope": "cluster",
"ipspace": {
  "uuid": "114ecfb5-59fc-11e8-ba55-005056b4340f",
  "name": "Default",
  "_links": {
    "self": {
            "href": "/api/network/ipspaces/114ecfb5-59fc-11e8-ba55-
005056b4340f"
    }
  }
},
"services": [
  "management_core",
  "management_autosupport",
  "management_access"
],
"location": {
  "is_home": true,
  "auto_revert": false,
  "failover": "broadcast_domain_only",
  "node": {
```

```
    "uuid": "c1db2904-1396-11e9-bb7d-005056acfcbb",
    "name": "user-cluster-01-a",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/c1db2904-1396-11e9-bb7d-005056acfcbb"
      }
    }
  },
  "port": {
    "uuid": "c84d5337-1397-11e9-87c2-005056acfcbb",
    "name": "e0d",
    "node": {
      "name": "user-cluster-01-a"
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/c84d5337-1397-11e9-87c2-
005056acfcbb"
      }
    }
  },
  "home_node": {
    "uuid": "c1db2904-1396-11e9-bb7d-005056acfcbb",
    "name": "user-cluster-01-a",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/c1db2904-1396-11e9-bb7d-005056acfcbb"
      }
    }
  },
  "home_port": {
    "uuid": "c84d5337-1397-11e9-87c2-005056acfcbb",
    "name": "e0d",
    "node": {
      "name": "user-cluster-01-a"
    },
    "_links": {
      "self": {
        "href": "/api/network/ethernet/ports/c84d5337-1397-11e9-87c2-
005056acfcbb"
      }
    }
  }
},
"service_policy": {
  "uuid": "9e0f4151-141b-11e9-851e-005056ac1ce0",
```

```
  "name": "default-management"
},
"vip": false,
"_links": {
  "self": {
    "href": "/api/network/ip/interfaces/245979de-59fc-11e8-ba55-
005056b4340f"
  }
}
}
```

Retrieving a specific SVM-scoped interface using a filter

The following example shows the response when a specific SVM-scoped interface is requested. The SVM object is only included for SVM-scoped interfaces.

```
# The API:
/api/network/ip/interfaces

# The call:
curl -X GET "https://<mgmt-
ip>/api/network/ip/interfaces?name=lif1&fields=*" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "c670707c-5a11-11e8-8fcb-005056b4340f",
    "name": "lif1",
    "ip": {
      "address": "10.10.10.11",
      "netmask": "24",
      "family": "ipv4",
    },
    "enabled": true,
    "state": "up",
    "scope": "svm",
    "ipspace": {
      "uuid": "114ecfb5-59fc-11e8-ba55-005056b4340f",
      "name": "Default",
      "_links": {
        "self": {
```

```
          "href": "/api/network/ipspaces/114ecfb5-59fc-11e8-ba55-
005056b4340f"
        }
      }
    },
    "svm": {
      "uuid": "c2134665-5a11-11e8-8fcb-005056b4340f",
      "name": "user_vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/c2134665-5a11-11e8-8fcb-005056b4340f"
        }
      }
    },
    "services": [
      "data_core",
      "data_nfs",
      "data_cifs",
      "data_flexcache"
    ],
    "location": {
      "is_home": true,
      "auto_revert": false,
      "failover": "broadcast_domain_only",
      "node": {
        "uuid": "c1db2904-1396-11e9-bb7d-005056acfcbb",
        "name": "user-cluster-01-a",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/c1db2904-1396-11e9-bb7d-
005056acfcbb"
          }
        }
      },
      "port": {
        "uuid": "c84d5337-1397-11e9-87c2-005056acfcbb",
        "name": "e0d",
        "node": {
          "name": "user-cluster-01-a"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/c84d5337-1397-11e9-87c2-
005056acfcbb"
          }
        }
```

```
      },
      "home_node": {
        "uuid": "c1db2904-1396-11e9-bb7d-005056acfcbb",
        "name": "user-cluster-01-a",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/c1db2904-1396-11e9-bb7d-
005056acfcbb"
          }
        }
      },
      "home_port": {
        "uuid": "c84d5337-1397-11e9-87c2-005056acfcbb",
        "name": "e0d",
        "node": {
          "name": "user-cluster-01-a"
        },
        "_links": {
          "self": {
            "href": "/api/network/ethernet/ports/c84d5337-1397-11e9-87c2-
005056acfcbb"
          }
        }
      }
    },
    "service_policy": {
      "uuid": "9e53525f-141b-11e9-851e-005056ac1ce0",
      "name": "default-data-files"
    },
    "vip": false,
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/c670707c-5a11-11e8-8fcb-
005056b4340f"
      }
    }
  }
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/network/ip/interfaces?name=lif1&fields=*"
  }
}
}
```

Retrieving specific fields and limiting the output using filters

The following example shows the response when a filter is applied (location.home_port.name=e0a) and only certain fields are requested. Filtered fields are in the output in addition to the default fields and requested fields.

```
# The API:
/api/network/ip/interfaces

# The call:
curl -X GET "https://<mgmt-
ip>/api/network/ip/interfaces?location.home_port.name=e0a&fields=location.
home_node.name,service_policy.name,ip.address,enabled" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "1d1c9dc8-4f17-11e9-9553-005056ac918a",
    "name": "user-cluster-01-a_clus1",
    "ip": {
      "address": "192.168.170.24"
    },
    "enabled": true,
    "location": {
      "home_node": {
        "name": "user-cluster-01-a"
      },
      "home_port": {
        "name": "e0a"
      }
    },
    "service_policy": {
      "name": "default-cluster"
    },
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/1d1c9dc8-4f17-11e9-9553-
005056ac918a"
      }
    }
  },
  {
    "uuid": "d07782c1-4f16-11e9-86e7-005056ace7ee",
```

```
    "name": "user-cluster-01-b_clus1",
    "ip": {
      "address": "192.168.170.22"
    },
    "enabled": true,
    "location": {
      "home_node": {
        "name": "user-cluster-01-b"
      },
      "home_port": {
        "name": "e0a"
      }
    },
    "service_policy": {
      "name": "default-cluster"
    },
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/d07782c1-4f16-11e9-86e7-
005056ace7ee"
      }
    }
  }
],
"num_records": 2,
"_links": {
  "self": {
    "href":
"/api/network/ip/interfaces?location.home_port.name=e0a&fields=location.ho
me_node.name,service_policy.name,ip.address,enabled"
  }
}
}
```

Creating IP interfaces

You can use the IP interfaces POST API to create IP interfaces as shown in the following examples.

Examples

Creating a Cluster-scoped IP interface using names

The following example shows the record returned after the creation of an IP interface on "e0d".

```
# The API:
/api/network/ip/interfaces

# The call:
curl -X POST "https://<mgmt-
ip>/api/network/ip/interfaces?return_records=true" -H "accept:
application/hal+json" -d '{ "name": "cluster_mgmt", "ip": { "address":
"10.63.41.6", "netmask": "18" }, "enabled": true, "scope": "cluster",
"ipspace": { "name": "Default" }, "location": { "auto_revert": false,
"failover": "broadcast_domain_only", "home_port": { "name": "e0d", "node":
{ "name": "user-cluster-01-a" } } }, "service_policy": { "name": "default-
management" } }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "245979de-59fc-11e8-ba55-005056b4340f",
    "name": "cluster_mgmt",
    "ip": {
      "address": "10.63.41.6",
      "netmask": "18"
    },
    "enabled": true,
    "scope": "cluster",
    "ipspace": {
      "name": "Default"
    },
    "location": {
      "auto_revert": false,
      "failover": "broadcast_domain_only",
      "home_port": {
        "name": "e0d",
        "node": {
          "name": "user-cluster-01-a"
        }
      },
    },
    "service_policy": {
      "name": "default-management"
    },
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/245979de-59fc-11e8-ba55-
```

```
005056b4340f"
      }
    }
  }
]
}
```

Creating a SVM-scoped IP interface using a mix of parameter types

The following example shows the record returned after the creation of a IP interface by specifying a broadcast domain as the location.

```
# The API:
/api/network/ip/interfaces

# The call:
curl -X POST "https://<mgmt-
ip>/api/network/ip/interfaces?return_records=true" -H "accept:
application/hal+json" -d '{ "name": "Data1", "ip": { "address":
"10.234.101.116", "netmask": "255.255.240.0" }, "enabled": true, "scope":
"svm", "svm": { "uuid": "137f3618-1e89-11e9-803e-005056a7646a" },
"location": { "auto_revert": true, "broadcast_domain": { "name": "Default"
} }, "service_policy": { "name": "default-data-files" } }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "80d271c9-1f43-11e9-803e-005056a7646a",
    "name": "Data1",
    "ip": {
      "address": "10.234.101.116",
      "netmask": "20"
    },
    "enabled": true,
    "scope": "svm",
    "svm": {
      "uuid": "137f3618-1e89-11e9-803e-005056a7646a",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/137f3618-1e89-11e9-803e-005056a7646a"
```

```
        }
      }
    },
    "location": {
      "auto_revert": true
    },
    "service_policy": {
      "name": "default-data-files"
    },
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/80d271c9-1f43-11e9-803e-
005056a7646a"
      }
    }
  }
]
}
```

Creating a Cluster-scoped IP interface without specifying the scope parameter

The following example shows the record returned after creating an IP interface on "e0d" without specifying the scope parameter. The scope is "cluster" if an "svm" is not specified.

```
# The API:
/api/network/ip/interfaces

# The call:
curl -X POST "https://<mgmt-
ip>/api/network/ip/interfaces?return_records=true" -H "accept:
application/hal+json" -d '{ "name": "cluster_mgmt", "ip": { "address":
"10.63.41.6", "netmask": "18" }, "enabled": true, "ipspace": { "name":
"Default" }, "location": { "auto_revert": false, "home_port": { "name":
"e0d", "node": { "name": "user-cluster-01-a" } } }, "service_policy": {
"name": "default-management" } }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "245979de-59fc-11e8-ba55-005056b4340f",
    "name": "cluster_mgmt",
```

```
    "ip": {
      "address": "10.63.41.6",
      "netmask": "18"
    },
    "enabled": true,
    "scope": "cluster",
    "ipspace": {
      "name": "Default"
    },
    "location": {
      "auto_revert": false,
      "home_port": {
        "name": "e0d",
        "node": {
          "name": "user-cluster-01-a"
        }
      }
    },
    "service_policy": {
      "name": "default-management"
    },
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/245979de-59fc-11e8-ba55-
005056b4340f"
      }
    }
  }
]
}
```

Creating an SVM-scoped IP interface without specifying the scope parameter

The following example shows the record returned after creating an IP interface on "e0d" without specifying the scope parameter. The scope is "svm" if the "svm" field is specified.

```
# The API:
/api/network/ip/interfaces

# The call:
curl -X POST "https://<mgmt-
ip>/api/network/ip/interfaces?return_records=true" -H "accept:
application/hal+json" -d '{ "name": "Data1", "ip": { "address":
```

```
"10.234.101.116", "netmask": "255.255.240.0" }, "enabled": true, "svm": {
"uuid": "137f3618-1e89-11e9-803e-005056a7646a" }, "location": {
"auto_revert": true, "broadcast_domain": { "name": "Default" } },
"service_policy": { "name": "default-data-files" } }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "80d271c9-1f43-11e9-803e-005056a7646a",
    "name": "Data1",
    "ip": {
      "address": "10.234.101.116",
      "netmask": "20"
    },
    "enabled": true,
    "scope": "svm",
    "svm": {
      "uuid": "137f3618-1e89-11e9-803e-005056a7646a",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svms/137f3618-1e89-11e9-803e-005056a7646a"
        }
      }
    },
    "location": {
      "auto_revert": true
    },
    "service_policy": {
      "name": "default-data-files"
    },
    "_links": {
      "self": {
        "href": "/api/network/ip/interfaces/80d271c9-1f43-11e9-803e-
005056a7646a"
      }
    }
  }
]
}
```

Creating an SVM-scoped IP interface using a subnet

The following example shows the record returned after the creation of a IP interface by allocating an IP address from a subnet.

```
# The API:
/api/network/ip/interfaces

# The call:
curl -X POST "https://<mgmt-
ip>/api/network/ip/interfaces?return_records=true" -H "accept:
application/hal+json" -d '{ "name": "Data1", "subnet": { "name":
"Subnet10" }, "enabled": true, "scope": "svm", "svm": { "uuid": "137f3618-
1e89-11e9-803e-005056a7646a" }, "location": { "auto_revert": true,
"broadcast_domain": { "name": "Default" } }, "service_policy": { "name":
"default-data-files" } }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "80d271c9-1f43-11e9-803e-005056a7646a",
    "name": "Data1",
    "enabled": true,
    "scope": "svm",
    "svm": {
      "uuid": "137f3618-1e89-11e9-803e-005056a7646a",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/137f3618-1e89-11e9-803e-005056a7646a"
        }
      }
    },
    "location": {
      "auto_revert": true
    },
    "service_policy": {
      "name": "default-data-files"
    },
    "subnet": {
      "name": "testSubnet"
    },
    "_links": {
```

```
      "self": {
        "href": "/api/network/ip/interfaces/80d271c9-1f43-11e9-803e-
005056a7646a"
      }
    }
  }
]
}
```

Updating IP interfaces

You can use the IP interfaces PATCH API to update the attributes of an IP interface.

Examples

Updating the auto revert flag of an IP interface

The following example shows how the PATCH request changes the auto revert flag to 'false'.

```
# The API:
/api/network/ip/interfaces/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ip/interfaces/80d271c9-1f43-
11e9-803e-005056a7646a" -H "accept: application/hal+json" -d '{
"location": { "auto_revert": "false" } }'
{
}
```

Updating the service policy of an IP interface

The following example shows how the PATCH request changes the service policy to 'default-management'.

```
# The API:
/api/network/ip/interfaces/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ip/interfaces/80d271c9-1f43-
11e9-803e-005056a7646a" -H "accept: application/hal+json" -d '{
"service_policy": { "name": "default-management" }}'
{
}
```

Deleting IP interfaces

You can use the IP interfaces DELETE API to delete an IP interface in the cluster.

Example

Deleting an IP Interface

The following DELETE request deletes a network IP interface.

```
# The API:
/api/network/ip/interfaces/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/network/ip/interfaces/80d271c9-1f43-
11e9-803e-005056a7646a"
{
}
```

Retrieve all IP interface details

GET `/network/ip/interfaces`

Introduced In: 9.6

Retrieves the details of all IP interfaces.

Related ONTAP Commands

- `network interface show`

Parameters

Name	Type	In	Required	Description
vip	boolean	query	False	Filter by vip
svm.name	string	query	False	Filter by svm.name
svm.uuid	string	query	False	Filter by svm.uuid
probe_port	integer	query	False	Filter by probe_port • Introduced in: 9.10
scope	string	query	False	Filter by scope
ipspace.name	string	query	False	Filter by ipspace.name
ipspace.uuid	string	query	False	Filter by ipspace.uuid
rdma_protocols	string	query	False	Filter by rdma_protocols • Introduced in: 9.10
service_policy.uuid	string	query	False	Filter by service_policy.uuid
service_policy.name	string	query	False	Filter by service_policy.name
location.auto_revert	boolean	query	False	Filter by location.auto_revert
location.is_home	boolean	query	False	Filter by location.is_home
location.failover	string	query	False	Filter by location.failover
location.port.node.name	string	query	False	Filter by location.port.node.name

Name	Type	In	Required	Description
location.port.uuid	string	query	False	Filter by location.port.uuid
location.port.name	string	query	False	Filter by location.port.name
location.home_node.name	string	query	False	Filter by location.home_node.name
location.home_node.uuid	string	query	False	Filter by location.home_node.uuid
location.node.name	string	query	False	Filter by location.node.name
location.node.uuid	string	query	False	Filter by location.node.uuid
location.home_port.node.name	string	query	False	Filter by location.home_port.node.name
location.home_port.uuid	string	query	False	Filter by location.home_port.uuid
location.home_port.name	string	query	False	Filter by location.home_port.name
services	string	query	False	Filter by services
enabled	boolean	query	False	Filter by enabled
name	string	query	False	Filter by name
subnet.name	string	query	False	Filter by subnet.name • Introduced in: 9.11

Name	Type	In	Required	Description
subnet.uuid	string	query	False	Filter by subnet.uuid • Introduced in: 9.11
state	string	query	False	Filter by state
statistics.timestamp	string	query	False	Filter by statistics.timestamp • Introduced in: 9.8
statistics.status	string	query	False	Filter by statistics.status • Introduced in: 9.8
statistics.throughput_raw.write	integer	query	False	Filter by statistics.throughput_raw.write • Introduced in: 9.8
statistics.throughput_raw.read	integer	query	False	Filter by statistics.throughput_raw.read • Introduced in: 9.8
statistics.throughput_raw.total	integer	query	False	Filter by statistics.throughput_raw.total • Introduced in: 9.8
ip.family	string	query	False	Filter by ip.family
ip.address	string	query	False	Filter by ip.address
ip.netmask	string	query	False	Filter by ip.netmask
uuid	string	query	False	Filter by uuid

Name	Type	In	Required	Description
ddns_enabled	boolean	query	False	Filter by ddns_enabled • Introduced in: 9.9
metric.status	string	query	False	Filter by metric.status • Introduced in: 9.8
metric.duration	string	query	False	Filter by metric.duration • Introduced in: 9.8
metric.throughput.write	integer	query	False	Filter by metric.throughput.write • Introduced in: 9.8
metric.throughput.read	integer	query	False	Filter by metric.throughput.read • Introduced in: 9.8
metric.throughput.total	integer	query	False	Filter by metric.throughput.total • Introduced in: 9.8
metric.timestamp	string	query	False	Filter by metric.timestamp • Introduced in: 9.8
dns_zone	string	query	False	Filter by dns_zone • Introduced in: 9.9

Name	Type	In	Required	Description
recommend.svm.uuid	string	query	False	The UUID of an existing SVM for which to recommend IP interfaces. • Introduced in: 9.16
recommend.svm.name	string	query	False	The name of an existing SVM for which to recommend IP interfaces. • Introduced in: 9.16
recommend.ipspace.uuid	string	query	False	The UUID of an existing IPspace for which to recommend IP interfaces. • Introduced in: 9.16
recommend.ipspace.name	string	query	False	The name of an existing IPspace for which to recommend IP interfaces. • Introduced in: 9.16
recommend.service_policy.uuid	string	query	False	The UUID of an IP service policy for which to recommend IP interfaces. • Introduced in: 9.16
recommend.service_policy.name	string	query	False	The name of an IP service policy for which to recommend IP interfaces. • Introduced in: 9.17

Name	Type	In	Required	Description
recommend.ip.family	string	query	False	The name of an IP Address Family for which to recommend IP interfaces. Unless ipv6 is specified, the default value is ipv4. • Introduced in: 9.16 • enum: ["ipv4", "ipv6"]
recommend.location.broadcast_domain.uuid	string	query	False	The UUID of an existing broadcast domain for which to recommend IP interfaces. • Introduced in: 9.16
recommend.location.broadcast_domain.name	string	query	False	The name of an existing broadcast domain for which to recommend IP interfaces. • Introduced in: 9.16
recommend.subnet.uuid	string	query	False	The UUID of an existing subnet for which to recommend IP interfaces. • Introduced in: 9.16
recommend.subnet.name	string	query	False	The name of an existing subnet for which to recommend IP interfaces. • Introduced in: 9.16

Name	Type	In	Required	Description
recommend.interfaces_per_node	integer	query	False	The number of IP interfaces to recommend per node. • Introduced in: 9.16
recommend.location.port.rdma_protocol	string	query	False	The RDMA protocol supported on locations for which to recommend IP interfaces. • Introduced in: 9.17
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0

Name	Type	In	Required	Description
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
recommend	recommend	Response properties specific to the LIF recommendation functionality.
records	array[ip_interface]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "recommend": {
    "messages": [
      {}
    ]
  },
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "dns_zone": "storage.company.com",
      "fail_if_subnet_conflicts": true,
      "ip": {
        "address": "10.10.10.7",
        "family": "string",
        "netmask": "24"
      },
      "ipspace": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "location": {
        "failover": "string",
        "home_node": {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
```

```
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "home_port": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "port": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "duration": "PT15S",
```

```
      "status": "ok",
      "throughput": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000"
    },
    "name": "dataLif1",
    "probe_port": 64001,
    "rdma_protocols": [
      "roce"
    ],
    "scope": "string",
    "service_policy": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "default-intercluster",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "services": [
      "data_nfs"
    ],
    "state": "string",
    "statistics": {
      "status": "ok",
      "throughput_raw": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000"
    },
    "subnet": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "subnet1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "svm": {
```

```
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```


Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
53282769	Not all nodes support enabling the LIF recommendations feature.
53282770	No matching subnets are configured in IPspace.
53282772	Not enough available IPs in subnet.
53282773	Not enough locations available on node for subnet.
53282774	The specified SVM UUID is invalid.
53282775	The specified SVM name is invalid.
53282776	The specified SVM name and UUID do not match.
53282777	The specified SVM does not exist in the IPspace.
53282778	The specified SVM does not exist in the IPspace.
53282779	The specified IPspace UUID is invalid.
53282780	The specified IPspace name is invalid.
53282781	The specified IPspace UUID and name do not match.
53282782	The specified service policy UUID does not exist.
53282783	THe specified service policy UUID and name do not match.
53282784	The specified service policy does not exist in the SVM.

Error Code	Description
53282785	The specified service policy does not exist in the IPspace.
53282786	The specified broadcast domain does not exist.
53282787	The specified broadcast domain UUID and name do not match.
53282788	The specified broadcast domain UUID does not exist in the IPspace.
53282789	The specified broadcast domain name does not exist in the IPspace.
53282790	The specified subnet UUID does not exist.
53282791	The specified subnet UUID and name do not match.
53282792	The specified subnet does not exist in the IPspace.
53282793	The specified subnet does not match the specified broadcast domain.
53282794	The specified subnet name does not exist in the IPspace.
53282795	The specified subnet name does not exist in the broadcast domain.
53282796	The specified SVM has a type that is not supported.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

ip_interface_recommend_message

recommend

Response properties specific to the LIF recommendation functionality.

Name	Type	Description
messages	array[ip_interface_recommend_message]	Messages describing the results of a LIF recommendation request.

_links

Name	Type	Description
self	href	

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address
family	string	IPv4 or IPv6
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ipspace

Either the UUID or name must be supplied on POST for cluster-scoped objects.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

broadcast_domain

Broadcast domain UUID along with a readable name.

Name	Type	Description
_links	_links	
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

home_node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

node

Name	Type	Description
name	string	Name of node on which the port is located.

home_port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

location

Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.

Name	Type	Description
auto_revert	boolean	
failover	string	Policy that defines where an interface is permitted to move on failover. The policy named “default” implements the recommended best practice for NAS LIFs on the current platform and cluster, and was known as “system_defined” in the CLI.
home_node	home_node	
home_port	home_port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.
is_home	boolean	
node	node	
port	port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

The most recent sample of I/O metrics for the interface.

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.

service_policy

Name	Type	Description
_links	_links	
name	string	
uuid	string	

throughput_raw

Throughput bytes observed at the interface. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.

Name	Type	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

The real time I/O statistics for the interface.

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the interface. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

ip_subnet_reference

A named subnet. Either UUID or name can be supplied on input.

Name	Type	Description
_links	_links	
name	string	The name of the subnet. If only the name is provided, the IPspace scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the subnet.

svm

Applies only to SVM-scoped objects. Either the UUID or name must be supplied on POST.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

ip_interface

Name	Type	Description
_links	_links	
ddns_enabled	boolean	Indicates whether or not dynamic DNS updates are enabled. Defaults to true if the interface supports "data_nfs" or "data_cifs" services, otherwise false.
dns_zone	string	Fully qualified DNS zone name
enabled	boolean	The administrative state of the interface.
ip	ip_info	IP information
ipspace	ipspace	Either the UUID or name must be supplied on POST for cluster-scoped objects.

Name	Type	Description
location	location	Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.
metric	metric	The most recent sample of I/O metrics for the interface.
name	string	Interface name
probe_port	integer	Probe port for Cloud load balancer
rdma_protocols	array[string]	Supported RDMA offload protocols
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
service_policy	service_policy	
services	array[string]	The services associated with the interface.
state	string	The operational state of the interface.
statistics	statistics	The real time I/O statistics for the interface.
subnet	ip_subnet_reference	A named subnet. Either UUID or name can be supplied on input.
svm	svm	Applies only to SVM-scoped objects. Either the UUID or name must be supplied on POST.

Name	Type	Description
uuid	string	The UUID that uniquely identifies the interface.
vip	boolean	True for a VIP interface, whose location is announced via BGP.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create a new cluster-scoped or SVM-scoped interface

POST `/network/ip/interfaces`

Introduced In: 9.6

Creates a new Cluster-scoped or SVM-scoped interface.

Required properties

- `name` - Name of the interface to create.
- `ip` or `subnet`
  - `ip.address` - IP address for the interface.
  - `ip.netmask` - IP subnet of the interface.
  - `subnet.uuid` or `subnet.name`
- `ipspace.name` or `ipspace.uuid`

    - Required for Cluster-scoped interfaces.
    - Optional for SVM-scoped interfaces.
- `svm.name` or `svm.uuid`
    - Required for an SVM-scoped interface.
    - Invalid for a Cluster-scoped interface.
- If a LIF in the subnet of the specified IP address does not already exist, a location.home_port, a location.home_node, or a location.broadcast_domain needs to be provided.

Recommended property values

- `service_policy`
    - `for SVM scoped interfaces`
        - *default-data-files* for interfaces carrying file-oriented NAS data traffic
        - *default-data-blocks* for interfaces carrying block-oriented SAN data traffic
        - *default-data-iscsi* for interfaces carrying iSCSI data traffic
        - *default-management* for interfaces carrying SVM management requests
    - `for Cluster scoped interfaces`
        - *default-intercluster* for interfaces carrying cluster peering traffic
        - *default-management* for interfaces carrying system management requests
        - *default-route-announce* for interfaces carrying BGP peer connections

Default property values

If not specified in POST, the following default property values are assigned:

- `scope`
    - *svm* if svm parameter is specified.
    - *cluster* if svm parameter is not specified
- `enabled` - *true*
- `location.auto_revert` - *true*
- `service_policy`
    - ***Unified ONTAP**: *default-data-files* if scope is `svm`
    - ***ASA r2**: *default-data-blocks* if scope is `svm`
        - *default-management* if scope is `cluster` and IPspace is not `Cluster`
        - *default-cluster* if scope is `cluster` and IPspace is `Cluster`
- `failover` - Selects the least restrictive failover policy supported by all the services in the service policy.
- `ddns_enabled`
    - *true* if the interface supports *data_nfs* or *data_cifs* services
    - *false* otherwise

- `fail_if_subnet_conflicts` - *true*

Related ONTAP commands

- `network interface create`

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
ddns_enabled	boolean	Indicates whether or not dynamic DNS updates are enabled. Defaults to true if the interface supports "data_nfs" or "data_cifs" services, otherwise false.
dns_zone	string	Fully qualified DNS zone name
enabled	boolean	The administrative state of the interface.
fail_if_subnet_conflicts	boolean	This command fails if the specified IP address falls within the address range of a named subnet. Set this value to false to use the specified IP address and to assign the subnet owning that address to the interface.
ip	ip_info	IP information
ipspace	ipspace	Either the UUID or name must be supplied on POST for cluster-scoped objects.

Name	Type	Description
location	location	Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.
name	string	Interface name
probe_port	integer	Probe port for Cloud load balancer
rdma_protocols	array[string]	Supported RDMA offload protocols
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
service_policy	service_policy	
services	array[string]	The services associated with the interface.
state	string	The operational state of the interface.
subnet	ip_subnet_reference	A named subnet. Either UUID or name can be supplied on input.
svm	svm	Applies only to SVM-scoped objects. Either the UUID or name must be supplied on POST.
uuid	string	The UUID that uniquely identifies the interface.
vip	boolean	True for a VIP interface, whose location is announced via BGP.

Example request

```
{
  "dns_zone": "storage.company.com",
  "ip": {
    "address": "10.10.10.7",
    "netmask": "24"
  },
  "ipspace": {
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "location": {
    "broadcast_domain": {
      "name": "bd1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "failover": "string",
    "home_node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "home_port": {
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "is_home": true
  },
  "name": "dataLif1",
  "probe_port": 64001,
  "rdma_protocols": [
    "roce"
  ],
  "scope": "string",
  "service_policy": {
    "name": "default-intercluster",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "services": [
    "data_nfs"
  ],
  "state": "string",
  "subnet": {
```

```
    "name": "subnet1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "svm": {
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Response

```
Status: 201, Created
```

Name	Type	Description
num_records	integer	Number of records
recommend	recommend	Response properties specific to the LIF recommendation functionality.
records	array[ip_interface]	

Example response


```
{
  "num_records": 1,
  "recommend": {
    "messages": [
      {}
    ]
  },
  "records": [
    {
      "dns_zone": "storage.company.com",
      "ip": {
        "address": "10.10.10.7",
        "netmask": "24"
      },
      "ipspace": {
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "location": {
        "broadcast_domain": {
          "name": "bd1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "failover": "string",
        "home_node": {
          "name": "node1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "home_port": {
          "name": "e1b",
          "node": {
            "name": "node1"
          },
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        },
        "is_home": true
      },
      "name": "dataLif1",
      "probe_port": 64001,
      "rdma_protocols": [
        "roce"
      ],
      "scope": "string",
      "service_policy": {
```

```
        "name": "default-intercluster",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "services": [
        "data_nfs"
      ],
      "state": "string",
      "subnet": {
        "name": "subnet1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "svm": {
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```


Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1376656	Cluster interfaces must be in the same subnet. Verify the address and netmask are set to the correct values.
1376663	All LIFs from a single DNS zone must be in the same SVM.
1376663	Cannot add interface to DNS zone because all interfaces from a single DNS zone must be in the same SVM.
1376963	Duplicate IP address.
1376976	The specified port is not capable of hosting this LIF.

Error Code	Description
1377583	Failed to create the interface because the broadcast domain of the specified subnet is different from the specified broadcast domain.
1377666	Subnet does not have any addresses available.
1966138	The same IP address may not be used for both a mgmt interface and a gateway address.
1966140	An interface with the same name already exists.
1966141	Invalid DNS zone name.
1966142	Only data LIFs can be assigned a DNS zone.
1966191	The interface could not be created because interface identifier creation failed.
1966217	Invalid port on the node.
1966267	IPv6 addresses must have a prefix length between 1 and 127.
1966269	IPv4 addresses must have a prefix length between 1 and 32.
1966270	Operation not support on SAN LIFs.
1966300	The LIF name is too long. The maximum number of characters allowed for iSCSI and FC LIF names is 254.
1966373	Failed to create interface because the home-port is not in the IPspace associated with the SVM.
1966454	A port on the node is not a member of a broadcast domain.
1966476	DNS Update is supported only on data LIFs.
1966477	DNS Update is supported only on LIFs configured with the NFS or CIFS protocol.
1966987	The Vserver Broadcast-Domain Home-Node and Home-Port combination is not valid.
1967081	The specified SVM must exist in the specified IPspace.
1967082	The specified ipspace.name does not match the IPspace name of ipspace.uuid.
1967102	POST operation might have left configuration in an inconsistent state. Check the configuration.
1967106	The specified location.home_port.name does not match the specified port name of location.home_port.uuid.
1967107	The location.home_port.uuid specified is not valid.

Error Code	Description
1967108	The specified location.home_node.name does not match the node name of location.home_node.uuid.
1967109	The specified location.home_port.node.name does not match the node name of location.home_node.uuid.
1967110	The specified location.home_port.node.name does not match location.home_node.name.
1967111	Home node must be specified by at least one location.home_node, location.home_port, or location.broadcast_domain field.
1967112	The specified location.home_node.name does not match the node name of location.home_port.uuid.
1967120	The specified service_policy.name does not match the specified service policy name of service_policy.uuid.
1967121	Invalid service_policy.uuid specified.
1967122	The specified location.broadcast_domain.name does not match the specified broadcast domain name of location.broadcast_domain.uuid.
1967123	The specified IPspace does not match the IPspace name of location.broadcast_domain.uuid.
1967124	The location.broadcast_domain.uuid specified is not valid.
1967127	svm.uuid or svm.name must be provided if scope is "svm".
1967128	ipspace.uuid or ipspace.name must be provided if scope is "cluster".
1967129	The specified location.home_port.uuid is not valid.
1967130	The specified location.home_port.name is not valid.
1967131	The specified location.home_port.uuid and location.home_port.name are not valid.
1967135	The specified location.broadcast_domain.uuid is not valid.
1967136	The specified location.broadcast_domain.name (and ipspace name) is not valid.
1967137	The specified location.broadcast_domain.uuid and location.broadcast_domain.name (and IPspace name) are not valid.
1967145	The specified location.failover is not valid.
1967146	The specified svm.name is not valid.
1967147	The specified svm.uuid is not valid.

Error Code	Description
1967153	No suitable port exists on location.home_node to host the interface.
1967154	Interfaces cannot be created on ports that are down. If a broadcast domain is specified, ensure that it contains at least one port that is operationally up.
1967381	Post VIP interfaces requires an effective cluster version of 9.7 or later.
1967382	VIP interfaces only reside in SVM scope.
1967383	Neither location.home_port.uuid or location.home_port.name should be set with vip=true.
1967384	Failed to create VIP interface because the home node does not have active BGP sessions to support Virtual IP (VIP) traffic.
1967385	VIP interfaces with an IPv4 address must use ip.netmask=32. VIP interfaces with an IPv6 address must use ip.netmask=128.
1967387	The specified IP address is in use by a subnet in this IPspace.
1967391	Setting the DNS zone requires an effective cluster version of 9.9.1 or later.
1967392	Setting the DDNS enable parameter requires an effective cluster version of 9.9.1 or later.
1967394	Setting the probe port parameter requires an effective cluster version of 9.10.1 or later.
1967396	The specified subnet.name does not match the subnet name of subnet.uuid.
1967397	The specified subnet.uuid does not match any configured subnet.";
1967398	Address must be specified by either ip.address and ip.netmask, or at least one subnet field, not both.";
1967401	The specified subnet.name does not match any configured subnet.
1967402	Data SVM cannot be specified with cluster scope.
2621519	Invalid SVM name. The SVM name must begin with a letter or an underscore. The maximum supported length is 41 if the SVM type is "sync-source", otherwise it is 47.
5373966	An iSCSI interface cannot be created in an SVM configured for NVMe.
8847378	Cannot specify DNS zone when DNS updates are enabled for SVM

Error Code	Description
53216540	LIFs on the specified SVM do not have a default service policy.
53281018	Failover policy is not compatible with one or more services in service policy
53281036	Setting the probe port parameter is not allowed on this platform.
53281065	The service_policy does not exist in the SVM.
53281073	IP address and netmask cannot be used because this represents a subnet address rather than a specific host address.
53281086	LIF would exceed the maximum number of supported intercluster LIFs in IPspace.
53281087	Cannot configure SAN LIF on SVM.
53281092	Failed to create interface because the home-port does not support the specified protocol.
53281104	The specified address is in use by the Service Processor
53281106	Failed checking the cluster capabilities.
53281114	The specified parameter is only supported on data SVMs.
53281468	Failed to update external route tables for IP.
53281680	Invalid value for the specified field.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ipspace

Either the UUID or name must be supplied on POST for cluster-scoped objects.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

broadcast_domain

Broadcast domain UUID along with a readable name.

Name	Type	Description
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

home_node

Name	Type	Description
name	string	

Name	Type	Description
uuid	string	

node

Name	Type	Description
name	string	Name of node on which the port is located.

home_port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

node

Name	Type	Description
name	string	
uuid	string	

port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

location

Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.

Name	Type	Description
auto_revert	boolean	

Name	Type	Description
broadcast_domain	broadcast_domain	Broadcast domain UUID along with a readable name.
failover	string	Policy that defines where an interface is permitted to move on failover. The policy named “default” implements the recommended best practice for NAS LIFs on the current platform and cluster, and was known as “system_defined” in the CLI.
home_node	home_node	
home_port	home_port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

The most recent sample of I/O metrics for the interface.

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.

service_policy

Name	Type	Description
name	string	
uuid	string	

throughput_raw

Throughput bytes observed at the interface. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.

Name	Type	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

The real time I/O statistics for the interface.

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the interface. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

ip_subnet_reference

A named subnet. Either UUID or name can be supplied on input.

Name	Type	Description
name	string	The name of the subnet. If only the name is provided, the IPspace scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the subnet.

svm

Applies only to SVM-scoped objects. Either the UUID or name must be supplied on POST.

Name	Type	Description
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

ip_interface

Name	Type	Description
ddns_enabled	boolean	Indicates whether or not dynamic DNS updates are enabled. Defaults to true if the interface supports "data_nfs" or "data_cifs" services, otherwise false.
dns_zone	string	Fully qualified DNS zone name
enabled	boolean	The administrative state of the interface.
fail_if_subnet_conflicts	boolean	This command fails if the specified IP address falls within the address range of a named subnet. Set this value to false to use the specified IP address and to assign the subnet owning that address to the interface.
ip	ip_info	IP information

Name	Type	Description
ipspace	ipspace	Either the UUID or name must be supplied on POST for cluster-scoped objects.
location	location	Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.
name	string	Interface name
probe_port	integer	Probe port for Cloud load balancer
rdma_protocols	array[string]	Supported RDMA offload protocols
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
service_policy	service_policy	
services	array[string]	The services associated with the interface.
state	string	The operational state of the interface.
subnet	ip_subnet_reference	A named subnet. Either UUID or name can be supplied on input.
svm	svm	Applies only to SVM-scoped objects. Either the UUID or name must be supplied on POST.
uuid	string	The UUID that uniquely identifies the interface.

Name	Type	Description
vip	boolean	True for a VIP interface, whose location is announced via BGP.

ip_interface_recommend_message

recommend

Response properties specific to the LIF recommendation functionality.

Name	Type	Description
messages	array[ip_interface_recommend_message]	Messages describing the results of a LIF recommendation request.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete an IP interface

DELETE `/network/ip/interfaces/{uuid}`

Introduced In: 9.6

Deletes an IP interface.

Related ONTAP commands

- `network interface delete`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	IP interface UUID

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1966465	LIF cannot be removed because it is required to maintain quorum on the node.
5376953	The interface is part of one or more portsets. Remove the interface from all portsets before deleting it.
53281112	Failed to delete the interface because it has an associated BGP peer group.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve details for an IP interface

GET `/network/ip/interfaces/{uuid}`

Introduced In: 9.6

Retrieves details for a specific IP interface.

Related ONTAP commands

- `network interface show`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	IP interface UUID
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
ddns_enabled	boolean	Indicates whether or not dynamic DNS updates are enabled. Defaults to true if the interface supports "data_nfs" or "data_cifs" services, otherwise false.
dns_zone	string	Fully qualified DNS zone name
enabled	boolean	The administrative state of the interface.
ip	ip_info	IP information
ipspace	ipspace	Either the UUID or name must be supplied on POST for cluster-scoped objects.

Name	Type	Description
location	location	Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.
metric	metric	The most recent sample of I/O metrics for the interface.
name	string	Interface name
probe_port	integer	Probe port for Cloud load balancer
rdma_protocols	array[string]	Supported RDMA offload protocols
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
service_policy	service_policy	
services	array[string]	The services associated with the interface.
state	string	The operational state of the interface.
statistics	statistics	The real time I/O statistics for the interface.
subnet	ip_subnet_reference	A named subnet. Either UUID or name can be supplied on input.
svm	svm	Applies only to SVM-scoped objects. Either the UUID or name must be supplied on POST.
uuid	string	The UUID that uniquely identifies the interface.

Name	Type	Description
vip	boolean	True for a VIP interface, whose location is announced via BGP.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "dns_zone": "storage.company.com",
  "fail_if_subnet_conflicts": true,
  "ip": {
    "address": "10.10.10.7",
    "family": "string",
    "netmask": "24"
  },
  "ipspace": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "location": {
    "failover": "string",
    "home_node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "home_port": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
```

```
    },
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "port": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "metric": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "duration": "PT15S",
    "status": "ok",
    "throughput": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 11:20:13 +0000"
  },
  "name": "dataLif1",
  "probe_port": 64001,
  "rdma_protocols": [
    "roce"
  ],
  "scope": "string",
  "service_policy": {
    "_links": {
```

```
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "default-intercluster",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "services": [
    "data_nfs"
  ],
  "state": "string",
  "statistics": {
    "status": "ok",
    "throughput_raw": {
      "read": 200,
      "total": 1000,
      "write": 100
    },
    "timestamp": "2017-01-25 11:20:13 +0000"
  },
  "subnet": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "subnet1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address
family	string	IPv4 or IPv6
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ipspace

Either the UUID or name must be supplied on POST for cluster-scoped objects.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

broadcast_domain

Broadcast domain UUID along with a readable name.

Name	Type	Description
_links	_links	

Name	Type	Description
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

home_node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

node

Name	Type	Description
name	string	Name of node on which the port is located.

home_port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	
name	string	
node	node	
uuid	string	

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
_links	_links	

Name	Type	Description
name	string	
node	node	
uuid	string	

location

Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.

Name	Type	Description
auto_revert	boolean	
failover	string	Policy that defines where an interface is permitted to move on failover. The policy named “default” implements the recommended best practice for NAS LIFs on the current platform and cluster, and was known as “system_defined” in the CLI.
home_node	home_node	
home_port	home_port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.
is_home	boolean	
node	node	
port	port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.

Name	Type	Description
write	integer	Performance metric for write I/O operations.

metric

The most recent sample of I/O metrics for the interface.

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.

service_policy

Name	Type	Description
_links	_links	
name	string	
uuid	string	

throughput_raw

Throughput bytes observed at the interface. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

The real time I/O statistics for the interface.

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the interface. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

ip_subnet_reference

A named subnet. Either UUID or name can be supplied on input.

Name	Type	Description
_links	_links	
name	string	The name of the subnet. If only the name is provided, the IPspace scope must be provided by the object this object is embedded in.

Name	Type	Description
uuid	string	The UUID that uniquely identifies the subnet.

svm

Applies only to SVM-scoped objects. Either the UUID or name must be supplied on POST.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update an IP interface

PATCH `/network/ip/interfaces/{uuid}`

Introduced In: 9.6

Updates an IP interface.

Related ONTAP commands

- `network interface migrate`
- `network interface modify`
- `network interface rename`
- `network interface revert`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	IP interface UUID

Request Body

Name	Type	Description
ddns_enabled	boolean	Indicates whether or not dynamic DNS updates are enabled. Defaults to true if the interface supports "data_nfs" or "data_cifs" services, otherwise false.
dns_zone	string	Fully qualified DNS zone name
enabled	boolean	The administrative state of the interface.
fail_if_subnet_conflicts	boolean	This command fails if the specified IP address falls within the address range of a named subnet. Set this value to false to use the specified IP address and to assign the subnet owning that address to the interface.
ip	ip_info	IP information

Name	Type	Description
location	location	Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.
name	string	Interface name
rdma_protocols	array[string]	Supported RDMA offload protocols
service_policy	service_policy	
services	array[string]	The services associated with the interface.
state	string	The operational state of the interface.
subnet	ip_subnet_reference	A named subnet. Either UUID or name can be supplied on input.
uuid	string	The UUID that uniquely identifies the interface.

Example request


```
{
  "dns_zone": "storage.company.com",
  "ip": {
    "address": "10.10.10.7",
    "netmask": "24"
  },
  "location": {
    "failover": "string",
    "home_node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "home_port": {
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "node": {
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "port": {
      "name": "e1b",
      "node": {
        "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  },
  "name": "dataLif1",
  "rdma_protocols": [
    "roce"
  ],
  "service_policy": {
    "name": "default-intercluster",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "services": [
    "data_nfs"
  ],
  "state": "string",
  "subnet": {
```

```
    "name": "subnet1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "vip": true
}
```


Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
262196	Field cannot be set in this operation.
1376663	Cannot add interface to DNS zone because all interfaces from a single DNS zone must be in the same SVM.
1376963	Duplicate IP address.
1376976	The specified port is not capable of hosting this LIF.
1376986	The interface could not migrate because no additional interfaces can be hosted on the specified node.
1376997	Interface failed to migrate because the node hosting the port is not healthy.
1376998	The specified location.node does not own any ports in the same broadcast domain as the home port of the interface.
1376999	Interface failed to migrate because port is in the down admin state.
1377607	The specified location.port is not in the same broadcast domain as the home port of the interface.
1377666	Subnet does not have any addresses available.
1966081	Failed to lookup the port on the node.
1966133	The netmask cannot represent the entire IP subnet.
1966135	Cluster configuration can only be changed from node where the cluster LIF resides.

Error Code	Description
1966138	The same IP address may not be used for both a mgmt interface and a gateway address.
1966141	Invalid DNS zone name.
1966142	Only data LIFs can be assigned a DNS zone.
1966191	The interface could not be created because interface identifier creation failed.
1966197	Migration of cluster interfaces must be done from the local node.
1966238	Cannot change the home-node or home-port of an active SAN or NVMe data interface.
1966267	IPv6 addresses must have a prefix length between 1 and 127.
1966269	IPv4 addresses must have a prefix length between 1 and 32.
1966299	Changing a cluster LIF's administrative status to down is not a supported operation.
1966419	Subnet not found in the IPspace of the SVM.
1966419	Specified subnet not found in the IPspace of the LIF.
1966476	DNS Update is supported only on data interfaces.
1966477	DNS Update is supported only on interfaces configured with the NFS or CIFS protocol.
1966507	A port on the node has been identified as potentially unhealthy.
1966685	There are no ports on the node that are in the broadcast domain associated with the IPspace.
1967106	The specified location.home_port.name does not match the specified port name of location.home_port.uuid.
1967107	The specified location.home_port.uuid is not valid.
1967111	A home node must be specified by at least one location.home_node, location.home_port, or location.broadcast_domain field.
1967113	The specified location.port.name does not match the port name of location.port.uuid.
1967114	The specified location.port.uuid is not valid.
1967115	The specified location.node.name does not match the node name of location.node.uuid.
1967116	The specified location.port.node.name does not match the node name of location.node.uuid.

Error Code	Description
1967117	The specified location.port.node.name does not match location.node.name.
1967118	A node must be specified by at least one location.node or location.port field.
1967119	The specified location.node.name does not match the node name of location.port.uuid.
1967120	The specified service_policy.name does not match the specified service policy name of service_policy.uuid.
1967121	The specified service_policy.uuid is not valid.
1967125	You cannot patch the "location.node" or "location.port" fields to migrate interfaces using the iSCSI data protocol. Instead perform the following PATCH operations on the interface: set the "enabled" field to "false"; change one or more "location.home_port" fields to migrate the interface; and then set the "enabled" field to "true".
1967129	The specified location.home_port.uuid is not valid.
1967130	The specified location.home_port.name is not valid.
1967131	The specified location.home_port.uuid and location.home_port.name are not valid.
1967132	The specified location.port.uuid is not valid.
1967133	The specified location.port.name is not valid.
1967134	The specified location.port.uuid and location.port.name are not valid.
1967138	Cannot patch port for a VIP interface. The specified parameter location.port.uuid is not valid.
1967139	Cannot patch port for a VIP interface. The specified parameter location.port.name is not valid.
1967140	Cannot patch port for a VIP interface. The specified parameters location.port.uuid and location.port.name are not valid.
1967141	Cannot patch home_port for a VIP interface. The specified parameter location.home_port.uuid is not valid.
1967142	Cannot patch home_port for a VIP interface. The specified parameter location.home_port.name is not valid.
1967143	Cannot patch home_port for a VIP interface. The specified parameters location.home_port.uuid and location.home_port.name are not valid.
1967145	The specified location.failover is not valid.

Error Code	Description
1967153	No suitable port exists on location.home_node to host the interface.
1967380	Cannot patch home_port for a VIP interface. The specified parameter location.home_port.node.name is not valid. Consider using location.home_node.name instead.
1967385	VIP interface address and netmask error.
1967386	Cannot patch port for a VIP interface. The specified parameter location.port.node.name is not valid. Consider using location.node.name instead.
1967387	The specified IP address is in use by a subnet in this IPspace.
1967389	Patching location.is_home to the value "false" is not supported. The value "true" would revert a network interface to its home port if the current value is "false".
1967390	Cannot patch a LIF revert as it requires an effective cluster version of 9.9.1 or later.
1967391	Patching the DNS zone requires an effective cluster version of 9.9.1 or later.
1967392	Patching the DDNS enable parameter requires an effective cluster version of 9.9.1 or later.
1967396	The specified subnet.name does not match the subnet name of subnet.uuid.
1967397	The specified subnet.uuid does not match any configured subnet.";
1967398	Address must be specified by either ip.address and ip.netmask, or at least one subnet field, not both.";
2621574	This operation is not permitted on an SVM that is configured as the destination of a MetroCluster SVM relationship.
53281018	Failover policy is not compatible with one or more services in service policy
53281065	The service_policy does not exist in the SVM.
53281072	The failover policy is not valid for interfaces in the SVM.
53281086	LIF would exceed the maximum number of supported intercluster LIFs in IPspace.
53281087	SVM must have an NVMe service to perform this operation.
53281089	LIF on SVM cannot be updated to use service policy because that service policy includes SAN services and the target LIF is not home.

Error Code	Description
53281096	LIF could not be modified because the current port does not support the specified rdma-protocols.
53281106	Failed checking the cluster capabilities.
53281109	The interface could not be updated to use the service policy because the interface is currently associated with BGP peer group.
53281111	Cannot update the service policy because the interface is associated with a BGP peer-group.
53281113	Configuration details for LIF were modified but an error was encountered while updating the LIF's operational status.
53281114	The specified parameter is only supported on data SVMs.
53281468	Failed to update external route tables for IP.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ipspace

Either the UUID or name must be supplied on POST for cluster-scoped objects.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

broadcast_domain

Broadcast domain UUID along with a readable name.

Name	Type	Description
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

home_node

Name	Type	Description
name	string	

Name	Type	Description
uuid	string	

node

Name	Type	Description
name	string	Name of node on which the port is located.

home_port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

node

Name	Type	Description
name	string	
uuid	string	

port

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Type	Description
name	string	
node	node	
uuid	string	

location

Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.

Name	Type	Description
auto_revert	boolean	

Name	Type	Description
failover	string	Policy that defines where an interface is permitted to move on failover. The policy named “default” implements the recommended best practice for NAS LIFs on the current platform and cluster, and was known as “system_defined” in the CLI.
home_node	home_node	
home_port	home_port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.
is_home	boolean	
node	node	
port	port	Port UUID along with readable names. Either the UUID or both names may be supplied on input.

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

metric

The most recent sample of I/O metrics for the interface.

Name	Type	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.

service_policy

Name	Type	Description
name	string	
uuid	string	

throughput_raw

Throughput bytes observed at the interface. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

statistics

The real time I/O statistics for the interface.

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the interface. This can be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

ip_subnet_reference

A named subnet. Either UUID or name can be supplied on input.

Name	Type	Description
name	string	The name of the subnet. If only the name is provided, the IPspace scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the subnet.

svm

Applies only to SVM-scoped objects. Either the UUID or name must be supplied on POST.

Name	Type	Description
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

ip_interface

Name	Type	Description
ddns_enabled	boolean	Indicates whether or not dynamic DNS updates are enabled. Defaults to true if the interface supports "data_nfs" or "data_cifs" services, otherwise false.
dns_zone	string	Fully qualified DNS zone name
enabled	boolean	The administrative state of the interface.

Name	Type	Description
fail_if_subnet_conflicts	boolean	This command fails if the specified IP address falls within the address range of a named subnet. Set this value to false to use the specified IP address and to assign the subnet owning that address to the interface.
ip	ip_info	IP information
location	location	Current or home location can be modified. Specifying a port implies a node. Specifying a node allows an appropriate port to be automatically selected. Ports are not valid and not shown for VIP interfaces. For POST, broadcast_domain can be specified alone or with home_node. For PATCH, set is_home to true to revert a LIF back to its home port.
name	string	Interface name
rdma_protocols	array[string]	Supported RDMA offload protocols
service_policy	service_policy	
services	array[string]	The services associated with the interface.
state	string	The operational state of the interface.
subnet	ip_subnet_reference	A named subnet. Either UUID or name can be supplied on input.
uuid	string	The UUID that uniquely identifies the interface.

error_arguments

Name	Type	Description
code	string	Argument code

Name	Type	Description
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve interface historical performance metrics

GET `/network/ip/interfaces/{uuid}/metrics`

Introduced In: 9.8

Retrieves historical performance metrics for an interface.

Parameters

Name	Type	In	Required	Description
status	string	query	False	Filter by status
duration	string	query	False	Filter by duration
timestamp	string	query	False	Filter by timestamp
throughput.write	integer	query	False	Filter by throughput.write
throughput.read	integer	query	False	Filter by throughput.read
throughput.total	integer	query	False	Filter by throughput.total
uuid	string	path	True	Unique identifier of the interface.

Name	Type	In	Required	Description
interval	string	query	False	The time range for the data. Examples can be 1h, 1d, 1m, 1w, 1y. The period for each time range is as follows: • 1h: Metrics over the most recent hour sampled over 15 seconds. • 1d: Metrics over the most recent day sampled over 5 minutes. • 1w: Metrics over the most recent week sampled over 30 minutes. • 1m: Metrics over the most recent month sampled over 2 hours. • 1y: Metrics over the most recent year sampled over a day. • Default value: 1 • enum: ["1h", "1d", "1w", "1m", "1y"]

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
order_by	array[string]	query	False	Order results by specified fields and optional [asc
desc] direction. Default direction is 'asc' for ascending.	return_records	boolean	query	False

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[records]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "duration": "PT15S",
      "status": "ok",
      "throughput": {
        "read": 200,
        "total": 1000,
        "write": 100
      },
      "timestamp": "2017-01-25 11:20:13 +0000",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```


Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
8585947	No metrics are available for the requested object.
8586225	An unexpected error occurred retrieving metrics for the requested object.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

throughput

The rate of throughput bytes per second observed at the interface.

Name	Type	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Performance metric for write I/O operations.

records

Throughput performance for the interfaces.

Name	Type	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Type	Description
status	string	Errors associated with the sample. For example, if the aggregation of data over multiple nodes fails, then any partial errors might return "ok" on success or "error" on an internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the interface.
timestamp	string	The timestamp of the performance data.
uuid	string	The UUID that uniquely identifies the interface.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments

Name	Type	Description
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage network IP routes

Manage network IP routes

Overview

This endpoint supports the following operations: GET (collection and instance), POST, and DELETE.

Retrieving network routes

You can use the IP routes GET API to retrieve and display relevant information pertaining to the routes configured in the cluster. The API retrieves the list of all routes configured in the cluster, or a specific route. The fields that are returned in the response will differ with the configuration.

Examples

Retrieving all routes in the cluster

The following output shows the list of all routes configured in a cluster.

```
# The API:
/api/network/ip/routes

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/routes?fields=*" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "5fdffb0b-62f8-11e8-853d-005056b4c971",
    "ipspace": {
      "uuid": "84f4beb2-616c-11e8-a4df-005056b4c971",
      "name": "Default",
```

```
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/84f4beb2-616c-11e8-a4df-
005056b4c971"
        }
      }
    },
    "svm": {
      "uuid": "3243312c-62f8-11e8-853d-005056b4c971",
      "name": "vs1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/3243312c-62f8-11e8-853d-005056b4c971"
        }
      }
    },
    "scope": "svm",
    "destination": {
      "address": "10.4.3.14",
      "netmask": "18",
      "family": "ipv4"
    },
    "gateway": "10.4.3.1",
    "_links": {
      "self": {
        "href": "/api/network/ip/routes/5fdffb0b-62f8-11e8-853d-
005056b4c971"
      }
    }
  },
  {
    "uuid": "84c128d2-62f9-11e8-853d-005056b4c971",
    "ipspace": {
      "uuid": "cc71aadc-62f7-11e8-853d-005056b4c971",
      "name": "ips1",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/cc71aadc-62f7-11e8-853d-
005056b4c971"
        }
      }
    },
    "scope": "cluster",
    "destination": {
      "address": "::",
      "netmask": "0",
```

```
      "family": "ipv6"
    },
    "gateway": "fd20:8b1e:b255:814e::1",
    "_links": {
      "self": {
        "href": "/api/network/ip/routes/84c128d2-62f9-11e8-853d-
005056b4c971"
      }
    }
  },
  {
    "uuid": "8cc72bcd-616c-11e8-a4df-005056b4c971",
    "ipspace": {
      "uuid": "84f4beb2-616c-11e8-a4df-005056b4c971",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/84f4beb2-616c-11e8-a4df-
005056b4c971"
        }
      }
    },
    "scope": "cluster",
    "destination": {
      "address": "0.0.0.0",
      "netmask": "0",
      "family": "ipv4"
    },
    "gateway": "10.224.64.1",
    "_links": {
      "self": {
        "href": "/api/network/ip/routes/8cc72bcd-616c-11e8-a4df-
005056b4c971"
      }
    }
  },
  {
    "uuid": "d63b6eee-62f9-11e8-853d-005056b4c971",
    "ipspace": {
      "uuid": "84f4beb2-616c-11e8-a4df-005056b4c971",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/84f4beb2-616c-11e8-a4df-
005056b4c971"
        }
```

```
      }
    },
    "svm": {
      "uuid": "3243312c-62f8-11e8-853d-005056b4c971",
      "name": "vs1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/3243312c-62f8-11e8-853d-005056b4c971"
        }
      }
    },
    "scope": "svm",
    "destination": {
      "address": "fd20:8b1e:b255:814e::",
      "netmask": "64",
      "family": "ipv6"
    },
    "gateway": "fd20:8b1e:b255:814e::1",
    "_links": {
      "self": {
        "href": "/api/network/ip/routes/d63b6eee-62f9-11e8-853d-
005056b4c971"
      }
    }
  }
],
"num_records": 4,
"_links": {
  "self": {
    "href": "/api/network/ip/routes?fields=*"
  }
}
}
```

Retrieving a specific Cluster-scoped route

The following output shows the returned response when a specific Cluster-scoped route is requested. The system returns an error if there is no route with the requested UUID. SVM information is not returned for Cluster-scoped routes.

```
# The API:
/api/network/ip/routes/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/routes/84c128d2-62f9-11e8-
853d-005056b4c971?fields=*" -H "accept: application/hal+json"

# The response:
{
"uuid": "84c128d2-62f9-11e8-853d-005056b4c971",
"ipspace": {
  "uuid": "cc71aadc-62f7-11e8-853d-005056b4c971",
  "name": "ips1",
  "_links": {
    "self": {
      "href": "/api/network/ipspaces/cc71aadc-62f7-11e8-853d-005056b4c971"
    }
  }
},
"scope": "cluster",
"destination": {
  "address": "::",
  "netmask": "0",
  "family": "ipv6"
},
"gateway": "fd20:8b1e:b255:814e::1",
"_links": {
  "self": {
    "href": "/api/network/ip/routes/84c128d2-62f9-11e8-853d-005056b4c971"
  }
}
}
```

Retrieving a specific SVM-scoped route

The following output shows the returned response when a specific SVM-scoped route is requested. The system returns an error if there is no route with the requested UUID. The SVM object is only included for SVM-scoped routes.

```
# The API:
/api/network/ip/routes/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/routes/d63b6eee-62f9-11e8-
853d-005056b4c971?fields=*" -H "accept: application/hal+json"

# The response:
{
"uuid": "d63b6eee-62f9-11e8-853d-005056b4c971",
"ipspace": {
  "uuid": "84f4beb2-616c-11e8-a4df-005056b4c971",
  "name": "Default",
  "_links": {
    "self": {
      "href": "/api/network/ipspaces/84f4beb2-616c-11e8-a4df-005056b4c971"
    }
  }
},
"svm": {
  "uuid": "3243312c-62f8-11e8-853d-005056b4c971",
  "name": "vs1",
  "_links": {
    "self": {
      "href": "/api/svm/svms/3243312c-62f8-11e8-853d-005056b4c971"
    }
  }
},
"scope": "svm",
"destination": {
  "address": "fd20:8b1e:b255:814e::",
  "netmask": "64",
  "family": "ipv6"
},
"gateway": "fd20:8b1e:b255:814e::1",
"_links": {
  "self": {
    "href": "/api/network/ip/routes/d63b6eee-62f9-11e8-853d-005056b4c971"
  }
}
}
```

Creating network routes

You can use the POST API to create an SVM-scoped route by specifying the associated SVM, or a Cluster-scoped route by specifying the associated IPspace.

Examples

Creating a Cluster-scoped route

IPspace is required to create a Cluster-scoped route. If the IPspace is not specified, the route will be created in the Default IPspace. The default destination will be set to "0.0.0.0/0" for IPv4 gateway addresses or "::/0" for IPv6 gateway addresses.

```
# The API:
/api/network/ip/routes

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/routes?return_records=true"
-H "accept: application/json" -d '{ "ipspace": { "name":"ips1" },
"gateway": "10.10.10.1"}'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "ae583c9e-9ac7-11e8-8bc9-005056bbd531",
    "ipspace": {
      "name": "ips1"
    },
    "gateway": "10.10.10.1"
  }
]
}
```

Creating an SVM-scoped route

To create an SVM-scoped route, the associated SVM can be identified by either its UUID or name.

```
# The API:
/api/network/ip/routes

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/routes?return_records=true"
-H "accept: application/json" -d '{ "svm": { "name":"vs0" }, "gateway":
"10.10.10.1"}'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "38805a91-9ac9-11e8-8bc9-005056bbd531",
    "svm": {
      "name": "vs0"
    },
    "gateway": "10.10.10.1"
  }
]
}
```

Deleting network routes

You can use the DELETE API to delete a specific route identified by its UUID.

Example

Deleting a specific route

```
# The API:
/api/network/ip/routes/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/network/ip/routes/38805a91-9ac9-
11e8-8bc9-005056bbd531"
```

Retrieve IP routes

GET `/network/ip/routes`

Introduced In: 9.6

Retrieves the collection of IP routes.

Expensive properties

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See Requesting specific fields to learn more.

- `interfaces.*`

Related ONTAP commands

- `network route show`
- `network route show-lifs`

Parameters

Name	Type	In	Required	Description
interfaces.ip.address	string	query	False	Filter by interfaces.ip.address • Introduced in: 9.9
interfaces.name	string	query	False	Filter by interfaces.name • Introduced in: 9.9
interfaces.uuid	string	query	False	Filter by interfaces.uuid • Introduced in: 9.9
svm.name	string	query	False	Filter by svm.name
svm.uuid	string	query	False	Filter by svm.uuid
scope	string	query	False	Filter by scope
ipspace.name	string	query	False	Filter by ipspace.name
ipspace.uuid	string	query	False	Filter by ipspace.uuid

Name	Type	In	Required	Description
uuid	string	query	False	Filter by uuid
destination.family	string	query	False	Filter by destination.family
destination.address	string	query	False	Filter by destination.address
destination.netmask	string	query	False	Filter by destination.netmask
gateway	string	query	False	Filter by gateway
metric	integer	query	False	Filter by metric • Introduced in: 9.11
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
error	error	
num_records	integer	Number of records
records	array[network_route]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist"
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "destination": {
        "address": "10.10.10.7",
        "family": "string",
        "netmask": "24"
      },
      "gateway": "10.1.1.1",
      "interfaces": [
        {
          "_links": {
            "self": {
              "href": "/api/resourcelink"
            }
          },
          "ip": {
            "address": "10.10.10.7"
          },
          "name": "lif1",
```

```
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      ],
      "ipspace": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "scope": "string",
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message

_links

Name	Type	Description
self	href	

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address
family	string	IPv4 or IPv6

Name	Type	Description
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ip

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address

interfaces

A network interface. Either UUID or name may be supplied on input.

Name	Type	Description
_links	_links	
ip	ip	IP information
name	string	The name of the interface. If only the name is provided, the SVM scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the interface.

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name may be supplied on input.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

svm

Applies only to SVM-scoped objects. Either the UUID or name must be supplied.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

network_route

Name	Type	Description
_links	_links	
destination	ip_info	IP information
gateway	string	The IP address of the gateway router leading to the destination.
interfaces	array[interfaces]	IP interfaces on the same subnet as the gateway.
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name may be supplied on input.
metric	integer	Indicates a preference order between several routes to the same destination. With typical usage, the default metrics provided are adequate, there is no need to specify a metric in the route creation.
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
svm	svm	Applies only to SVM-scoped objects. Either the UUID or name must be supplied.
uuid	string	The UUID that uniquely identifies the route.

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create a cluster-scoped or SVM-scoped static route

POST `/network/ip/routes`

Introduced In: 9.6

Creates a Cluster-scoped or SVM-scoped static route.

Required properties

- `gateway` - IP address to route packets to.
- SVM-scoped routes
  - `svm.name` or `svm.uuid` - SVM that route is applied to.
- cluster-scoped routes
  - There are no additional required fields for Cluster-scoped routes.

Default property values

If not specified in POST, the following default property values are assigned:

- `destination` - *0.0.0.0/0* for IPv4 or *::/0* for IPv6.
- `ipspace.name`
  - *Default* for Cluster-scoped routes.
  - Name of the SVM's IPspace for SVM-scoped routes.
- `metric` - 20.

Related ONTAP commands

- `network route create`

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
destination	ip_info	IP information
gateway	string	The IP address of the gateway router leading to the destination.
interfaces	array[interfaces]	IP interfaces on the same subnet as the gateway.
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name may be supplied on input.
metric	integer	Indicates a preference order between several routes to the same destination. With typical usage, the default metrics provided are adequate, there is no need to specify a metric in the route creation.
svm	svm	Applies only to SVM-scoped objects. Either the UUID or name must be supplied.
uuid	string	The UUID that uniquely identifies the route.

Example request

```
{
  "destination": {
    "address": "10.10.10.7",
    "netmask": "24"
  },
  "gateway": "10.1.1.1",
  "interfaces": [
    {
      "name": "lif1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ],
  "ipspace": {
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "svm": {
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

```
Status: 201, Created
```

Name	Type	Description
num_records	integer	Number of records
records	array[network_route]	

Example response


```
{
  "num_records": 1,
  "records": [
    {
      "destination": {
        "address": "10.10.10.7",
        "netmask": "24"
      },
      "gateway": "10.1.1.1",
      "interfaces": [
        {
          "name": "lif1",
          "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
      ],
      "ipspace": {
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "svm": {
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```


Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1966265	The destination and gateway must belong to the same IP address family.
1966345	Duplicate route exists.
1966505	The gateway address cannot be the same as a LIF address. A LIF is already configured with that IP address.
1967080	The destination.address is missing.
1967081	The specified SVM must exist in the specified IPspace.
1967082	The specified ipspace.uuid and ipspace.name refer to different IPspaces.
1967146	The specified svm.name is not valid.
2621462	The specified SVM does not exist.
2621574	This operation is not permitted on an SVM that is configured as the destination of a MetroCluster SVM relationship.
2621706	The specified UUID and name refer to different SVMs.
53282375	The specified destination is invalid.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ip

IP information

interfaces

A network interface. Either UUID or name may be supplied on input.

Name	Type	Description
ip	ip	IP information
name	string	The name of the interface. If only the name is provided, the SVM scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the interface.

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name may be supplied on input.

Name	Type	Description
name	string	IPspace name

Name	Type	Description
uuid	string	IPspace UUID

svm

Applies only to SVM-scoped objects. Either the UUID or name must be supplied.

Name	Type	Description
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

network_route

Name	Type	Description
destination	ip_info	IP information
gateway	string	The IP address of the gateway router leading to the destination.
interfaces	array[interfaces]	IP interfaces on the same subnet as the gateway.
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name may be supplied on input.
metric	integer	Indicates a preference order between several routes to the same destination. With typical usage, the default metrics provided are adequate, there is no need to specify a metric in the route creation.
svm	svm	Applies only to SVM-scoped objects. Either the UUID or name must be supplied.
uuid	string	The UUID that uniquely identifies the route.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete an IP route

DELETE `/network/ip/routes/{uuid}`

Introduced In: 9.6

Deletes a specific IP route.

Related ONTAP commands

- `network route delete`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Route UUID

Response

```
Status: 200, Ok
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve details for an IP route

GET `/network/ip/routes/{uuid}`

Introduced In: 9.6

Retrieves the details of a specific IP route.

Related ONTAP commands

- `network route show`
- `network route show-lifs`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Route UUID
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
destination	ip_info	IP information
gateway	string	The IP address of the gateway router leading to the destination.
interfaces	array[interfaces]	IP interfaces on the same subnet as the gateway.
ipspace	ipspace	Applies to both SVM and cluster-scoped objects. Either the UUID or name may be supplied on input.
metric	integer	Indicates a preference order between several routes to the same destination. With typical usage, the default metrics provided are adequate, there is no need to specify a metric in the route creation.
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
svm	svm	Applies only to SVM-scoped objects. Either the UUID or name must be supplied.
uuid	string	The UUID that uniquely identifies the route.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "destination": {
    "address": "10.10.10.7",
    "family": "string",
    "netmask": "24"
  },
  "gateway": "10.1.1.1",
  "interfaces": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "ip": {
        "address": "10.10.10.7"
      },
      "name": "lif1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ],
  "ipspace": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "scope": "string",
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
```

```
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address
family	string	IPv4 or IPv6
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ip

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address

interfaces

A network interface. Either UUID or name may be supplied on input.

Name	Type	Description
_links	_links	
ip	ip	IP information

Name	Type	Description
name	string	The name of the interface. If only the name is provided, the SVM scope must be provided by the object this object is embedded in.
uuid	string	The UUID that uniquely identifies the interface.

ipspace

Applies to both SVM and cluster-scoped objects. Either the UUID or name may be supplied on input.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

svm

Applies only to SVM-scoped objects. Either the UUID or name must be supplied.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage network IP service policies

Manage network IP service policies

Overview

Service policies are named groupings that define what services are supported by an IP interface. The following operations are supported:

- Creation: POST network/ip/service-policies
- Collection Get: GET network/ip/service-policies
- Instance Get: GET network/ip/service-policies/{uuid}
- Instance Patch: PATCH network/ip/service-policies/{uuid}
- Instance Delete: DELETE network/ip/service-polices/{uuid}

Examples

Retrieving all service policies in the cluster

The following output shows the collection of all service policies configured in a 2-node cluster. By default (without 'field=*' parameter), only the UUID and name fields are shown for each entry.

```
# The API:
/api/network/ethernet/ip/service-policies

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/service-policies" -H
"accept: application/hal+json"

# The response:
{
"records": [
  {
```

```
    "uuid": "e4e2f193-c1a3-11e8-bb9d-005056bb88c8",
    "name": "net-intercluster",
    "_links": {
      "self": {
        "href": "/api/network/ip/service-policies/e4e2f193-c1a3-11e8-bb9d-
005056bb88c8"
      }
    }
  },
  {
    "uuid": "e4e3f6da-c1a3-11e8-bb9d-005056bb88c8",
    "name": "net-route-announce",
    "_links": {
      "self": {
        "href": "/api/network/ip/service-policies/e4e3f6da-c1a3-11e8-bb9d-
005056bb88c8"
      }
    }
  },
  {
    "uuid": "e5111111-c1a3-11e8-bb9d-005056bb88c8",
    "name": "vserver-route-announce",
    "_links": {
      "self": {
        "href": "/api/network/ip/service-policies/e5111111-c1a3-11e8-bb9d-
005056bb88c8"
      }
    }
  },
  {
    "uuid": "e6111111-c1a3-11e8-bb9d-005056bb88c8",
    "name": "data-route-announce",
    "_links": {
      "self": {
        "href": "/api/network/ip/service-policies/e6111111-c1a3-11e8-bb9d-
005056bb88c8"
      }
    }
  }
],
"num_records": 4,
"_links": {
  "self": {
    "href": "/api/network/ip/service-
policies/?return_records=true&return_timeout=15"
  }
```

```
  }
}
```

Retrieving a specific service policy (scope=svm)

The following output displays the response when a specific "svm" scoped service policy is requested. Among other parameters, the response contains the svm parameters associated with the service policy. The system returns an error when there is no service policy with the requested UUID.

```
# The API:
/api/network/ip/service-policies/{uuid}

# The call:
curl -X GET "http://<mgmt-ip>/api/network/ip/service-policies/dad323ff-
4ce0-11e9-9372-005056bb91a8?fields=*" -H "accept: application/hal+json"

# The response:
{
"uuid": "dad323ff-4ce0-11e9-9372-005056bb91a8",
"name": "default-data-files",
"scope": "svm",
"svm": {
  "uuid": "d9060680-4ce0-11e9-9372-005056bb91a8",
  "name": "vs0",
  "_links": {
    "self": {
      "href": "/api/svm/svms/d9060680-4ce0-11e9-9372-005056bb91a8"
    }
  }
},
"ipspace": {
  "uuid": "45ec2dee-4ce0-11e9-9372-005056bb91a8",
  "name": "Default",
  "_links": {
    "self": {
      "href": "/api/network/ipspaces/45ec2dee-4ce0-11e9-9372-005056bb91a8"
    }
  }
},
"is_built_in": true,
"services": [
  "data_core",
  "data_nfs",
  "data_cifs",
  "data_flexcache"
],
"_links": {
  "self": {
    "href": "/api/network/ip/service-policies/dad323ff-4ce0-11e9-9372-
005056bb91a8"
  }
}
}
```

Retrieving a specific service policy (scope=svm) when requesting commonly used fields

The following output displays the response when commonly used fields are requested for a specific "svm" scoped service policy. Among other parameters, the response contains the svm parameters associated with the service policy. The system returns an error when there is no service policy with the requested UUID.

```
# The API:
/api/network/ip/service-policies/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/service-policies/e0889ce6-
1e6a-11e9-89d6-005056bbdc04?fields=name,scope,svm.name,ipspace.name" -H
"accept: application/hal+json"

# The response:
{
"uuid": "e0889ce6-1e6a-11e9-89d6-005056bbdc04",
"name": "test_policy",
"scope": "svm",
"svm": {
  "name": "vs0"
},
"ipspace": {
  "name": "Default"
},
"_links": {
  "self": {
    "href": "/api/network/ip/service-policies/e0889ce6-1e6a-11e9-89d6-
005056bbdc04"
  }
}
}
```

Retrieving a specific service policy (scope=cluster)

The following output displays the response when a specific cluster-scoped service policy is requested. The SVM object is not included for cluster-scoped service policies. A service policy with a scope of "cluster" is associated with an IPspace. The system returns an error when there is no service policy with the requested UUID.

```
# The API:
/api/network/ip/service-policies/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/service-policies/4c6b72b9-
0f6c-11e9-875d-005056bb21b8?fields=*" -H "accept: application/hal+json"

# The response:
{
"uuid": "4c6b72b9-0f6c-11e9-875d-005056bb21b8",
"name": "net-intercluster",
"scope": "cluster",
"ipspace": {
  "uuid": "4051f13e-0f6c-11e9-875d-005056bb21b8",
  "name": "Default",
  "_links": {
    "self": {
      "href": "/api/network/ipspaces/4051f13e-0f6c-11e9-875d-005056bb21b8"
    }
  }
},
"is_built_in": false,
"services": [
  "intercluster_core"
],
"_links": {
  "self": {
    "href": "/api/network/ip/service-policies/4c6b72b9-0f6c-11e9-875d-
005056bb21b8"
  }
}
}
```

Retrieving a specific service policy (scope=cluster) when requesting commonly used fields

The following output displays the response when commonly used fields are requested for a specific "cluster" scoped service policy. The SVM object is not included for cluster-scoped service policies. A service policy with a scope of "cluster" is associated with an IPspace. The system returns an error when there is no service policy with the requested UUID.

```
# The API:
/api/network/ip/service-policies/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/service-policies/4c6b72b9-
0f6c-11e9-875d-005056bb21b8?fields=name,scope,ipspace.name" -H "accept:
application/hal+json"

# The response:
{
"uuid": "4c6b72b9-0f6c-11e9-875d-005056bb21b8",
"name": "net-intercluster",
"scope": "cluster",
"ipspace": {
  "name": "Default"
},
"services": [
  "intercluster_core"
],
"_links": {
  "self": {
    "href": "/api/network/ip/service-policies/4c6b72b9-0f6c-11e9-875d-
005056bb21b8"
  }
}
}
```

Creating service policies

You can use this API to create an SVM-scoped service policy by specifying the associated SVM, or a cluster-scoped service policy by specifying the associated IPspace. If the scope is not specified, it is inferred from the presence of the IPspace or SVM. Cluster scoped service policies will operate on the IPspace "Default" unless IPspace is explicitly specified.

Examples

Creating a cluster-scoped service policy

The following output displays the response when creating a service policy with a scope of "cluster" and an IPspace of "Default".

```
# The API:
/api/network/ip/service-policies

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/service-
policies?return_records=true" -H "accept: application/json" -d '{ "name":
"new-policy", "scope": "cluster", "ipspace": { "name":"Default" },
"services": [ "intercluster_core" ] }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "74139267-f1aa-11e9-b5d7-005056a73e2e",
    "name": "new-policy",
    "scope": "cluster",
    "ipspace": {
      "uuid": "ba556295-e912-11e9-a1c8-005056a7080e",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/ba556295-e912-11e9-a1c8-
005056a7080e"
        }
      }
    },
    "is_built_in": false,
    "_links": {
      "self": {
        "href": "/api/network/ip/service-policies/74139267-f1aa-11e9-b5d7-
005056a73e2e"
      }
    },
    "services": [
      "intercluster_core"
    ]
  }
]
}
```

Creating a cluster-scoped service policy without specifying IPspace

The following output displays the response when creating a service policy with a scope of "cluster" without specifying an IPspace".

```
# The API:
/api/network/ip/service-policies

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/service-
policies?return_records=true" -H "accept: application/json" -d '{ "name":
"new-policy", "scope": "cluster", "services": [ "intercluster_core" ] }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "74139267-f1aa-11e9-b5d7-005056a73e2e",
    "name": "new-policy",
    "scope": "cluster",
    "ipspace": {
      "uuid": "ba556295-e912-11e9-a1c8-005056a7080e",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/ba556295-e912-11e9-a1c8-
005056a7080e"
        }
      }
    },
    "is_built_in": false,
    "_links": {
      "self": {
        "href": "/api/network/ip/service-policies/74139267-f1aa-11e9-b5d7-
005056a73e2e"
      }
    },
    "services": [
      "intercluster_core"
    ]
  }
]
}
```

Creating a cluster-scoped service policy without specifying scope

The following output displays the response when creating a service policy in the "Default" IPspace without specifying the scope".

```
# The API:
/api/network/ip/service-policies

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/service-
policies?return_records=true" -H "accept: application/json" -d '{ "name":
"new-policy2", "ipspace.name": "Default", "services": [
"intercluster_core" ] }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "59439267-f1aa-11e9-b5d7-005056a73e2e",
    "name": "new-policy2",
    "scope": "cluster",
    "ipspace": {
      "uuid": "ba556295-e912-11e9-a1c8-005056a7080e",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/ba556295-e912-11e9-a1c8-
005056a7080e"
        }
      }
    },
    "is_built_in": false,
    "services": [
      "intercluster_core"
    ],
    "_links": {
      "self": {
        "href": "/api/network/ip/service-policies/74139267-f1aa-11e9-b5d7-
005056a73e2e"
      }
    }
  }
]
}
```

Creating an SVM-scoped service policy

The following output displays the response when creating a service policy with a scope of "svm" in the SVM "vs0".

```
# The API:
/api/network/ip/service-policies

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/service-
policies?return_records=true" -H "accept: application/json" -d '{ "name":
"new-policy", "scope": "svm", "svm": { "name":"vs0" }, "services": [
"data-nfs", "data-cifs" ] }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "f3901097-f2c4-11e9-b5d7-005056a73e2e",
    "name": "new-policy",
    "scope": "svm",
    "svm": {
      "uuid": "07df9cee-e912-11e9-a13a-005056a73e2e",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/07df9cee-e912-11e9-a13a-005056a73e2e"
        }
      }
    },
    "ipspace": {
      "uuid": "1d3199d2-e906-11e9-a13a-005056a73e2e",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/1d3199d2-e906-11e9-a13a-
005056a73e2e"
        }
      }
    },
    "is_built_in": false,
    "services": [
      "data_nfs",
      "data_cifs"
```

```
    ],
    "_links": {
      "self": {
        "href": "/api/network/ip/service-policies/f3901097-f2c4-11e9-b5d7-
005056a73e2e"
      }
    }
  }
]
}
```

Creating an SVM-scoped service policy without specifying scope

The following output displays the response when creating a service policy with a SVM of "vs0" without specifying the scope.

```
# The API:
/api/network/ip/service-policies

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/service-
policies?return_records=true" -H "accept: application/json" -d '{ "name":
"new-policy", "svm": { "name":"vs0" }, "services": [ "data-nfs", "data-
cifs" ] }'

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "f3901097-f2c4-11e9-b5d7-005056a73e2e",
    "name": "new-policy",
    "scope": "svm",
    "svm": {
      "uuid": "07df9cee-e912-11e9-a13a-005056a73e2e",
      "name": "vs0",
      "_links": {
        "self": {
          "href": "/api/svm/svms/07df9cee-e912-11e9-a13a-005056a73e2e"
        }
      }
    },
    "ipspace": {
```

```
      "uuid": "1d3199d2-e906-11e9-a13a-005056a73e2e",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/1d3199d2-e906-11e9-a13a-
005056a73e2e"
        }
      }
    },
    "is_built_in": false,
    "services": [
      "data_nfs",
      "data_cifs"
    ],
    "_links": {
      "self": {
        "href": "/api/network/ip/service-policies/f3901097-f2c4-11e9-b5d7-
005056a73e2e"
      }
    }
  }
]
}
```

Updating the name of a service policy

The following example displays the command used to update the name of a service policy scoped to a specific "svm". The system returns an error when there is no service policy associated with the UUID or the service policy cannot be renamed.

```
# The API:
/api/network/ip/service-policies/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ip/service-policies/734eaf57-
d2fe-11e9-9284-005056acaad4" -d "{ \"name\": \"new-name\" }" -H "accept:
application/hal+json"
```

Updating the services for a service policy

The following example displays the command used to update the services a service policy contains. The

specified services replace the existing services. To retain existing services, they must be included in the PATCH request. The system returns an error when there is no service policy associated with the UUID or the services cannot be applied.

```
# The API:
/api/network/ip/service-policies/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ip/service-policies/734eaf57-
d2fe-11e9-9284-005056acaad4" -d "{ \"services\": [ \"data-nfs\",\"data-
cifs\" ] }" -H "accept: application/hal+json"
```

Deleting a service policy

The following output displays the response for deleting a service policy.

```
# The API:
/api/network/ip/service-policies/{uuid}

# The call:
curl -X  DELETE "https://<mgmt-ip>/api/network/ip/service-
policies/757ed726-bdc1-11e9-8a92-005056a7bf25" -H "accept:
application/hal+json"
```

Retrieve service policies

GET `/network/ip/service-policies`

Introduced In: 9.6

Retrieves a collection of service policies.

Related ONTAP commands

- `network interface service-policy show`

Parameters

Name	Type	In	Required	Description
svm.name	string	query	False	Filter by svm.name
svm.uuid	string	query	False	Filter by svm.uuid
name	string	query	False	Filter by name
services	string	query	False	Filter by services
scope	string	query	False	Filter by scope
is_built_in	boolean	query	False	Filter by is_built_in • Introduced in: 9.11
uuid	string	query	False	Filter by uuid
ipspace.name	string	query	False	Filter by ipspace.name
ipspace.uuid	string	query	False	Filter by ipspace.uuid
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[ip_service_policy]	

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "ipspace": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "name": "default-intercluster",
      "scope": "string",
      "services": [
        "data_nfs"
      ],
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```

Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

ipspace

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

ip_service_policy

Name	Type	Description
_links	_links	

Name	Type	Description
ipspace	ipspace	
is_built_in	boolean	
name	string	
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
services	array[string]	
svm	svm	SVM, applies only to SVM-scoped objects.
uuid	string	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create a service policy for network interfaces

POST `/network/ip/service-policies`

Introduced In: 9.8

Creates a service policy for network interfaces.

Related ONTAP commands

- `network interface service-policy create`

Required properties

- `name` - Name of the service policy to create.
- `ipspace.name` or `ipspace.uuid`
  - Required for cluster-scoped service policies.
  - Optional for SVM-scoped service policies.
- `svm.name` or `svm.uuid`
  - Required for SVM-scoped service policies.
  - Not valid for cluster-scoped service policies.

Default property values

If not specified in POST, the following default property values are assigned:

- `scope`
  - svm if the svm parameter is specified
  - cluster if the svm parameter is not specified

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
ipspace	ipspace	
is_built_in	boolean	
name	string	
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
services	array[string]	

Name	Type	Description
svm	svm	SVM, applies only to SVM-scoped objects.
uuid	string	

Example request

```
{
  "ipspace": {
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "default-intercluster",
  "scope": "string",
  "services": [
    "data_nfs"
  ],
  "svm": {
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

```
Status: 200, Ok
```

Response

```
Status: 201, Created
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1966373	Port must reside in the same IPspace as the interface's SVM.
1967146	Svm.name does not exist.
1967147	Svm.uuid does not exist.
2621740	An unexpected error when trying to determine whether the target Vserver was locked or not on this cluster.
53281895	Custom service policies cannot be created on the specified svm
53281929	Service policies cannot combine block and file services.
53281931	Service policy names cannot start with "default-".
53281932	Service cannot be added because the service does not exist for the specified SVM or IPspace.
53281933	A Cluster-scoped service cannot be added to a SVM-scoped service policy.
53281934	An SVM-scoped service cannot be added to a Cluster-scoped service policy.
53281935	Scope is set to "svm" and svm.uuid or svm.name have not been specified.
53281936	The SVM is not in the specified IPspace.
53281937	Svm.uuid and svm.name are not valid parameters when scope is cluster.
53281938	Svm.uuid or svm.name specify a vserver that does not exist.
53281939	One or more of the svm.uuid, svm.name, ipspace.uuid, and ipspace.name have invalid values.
53281940	SVM or IPspace has not been specified.
53281941	SVM does not exist.
53281942	Service policy cannot be created because the specified SVM does not exist.
53281944	Ipspace.name does not exist.
53281945	Ipspace.uuid is not an IPspace.
53281946	Service policy already exists.
53281958	Service policies cannot contain multiple block-oriented services.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

ip_service_policy

Name	Type	Description
ipspace	ipspace	
is_built_in	boolean	
name	string	
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
services	array[string]	
svm	svm	SVM, applies only to SVM-scoped objects.
uuid	string	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete a service policy for network interfaces

DELETE `/network/ip/service-policies/{uuid}`

Introduced In: 9.8

Deletes a service policy for network interfaces.

Related ONTAP commands

- `network interface service-policy delete`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	UUID of the service policy

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
2621740	An unexpected error when trying to determine whether the target Vserver was locked or not on this cluster.
53281927	Service policies owned by the system cannot be deleted.
53281928	Service policies assigned to LIFs cannot be deleted.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve a service policy

GET `/network/ip/service-policies/{uuid}`

Introduced In: 9.6

Retrieves a specific service policy.

Related ONTAP commands

- `network interface service-policy show`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Service policy UUID
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
ipspace	ipspace	
is_built_in	boolean	
name	string	
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
services	array[string]	

Name	Type	Description
svm	svm	SVM, applies only to SVM-scoped objects.
uuid	string	

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "ipspace": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "default-intercluster",
  "scope": "string",
  "services": [
    "data_nfs"
  ],
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

ipspace

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update a service policy for network interfaces

PATCH `/network/ip/service-policies/{uuid}`

Introduced In: 9.8

Updates a service policy for network interfaces.

Related ONTAP commands

- `network interface service-policy add-service`
- `network interface service-policy modify-service`
- `network interface service-policy remove-service`
- `network interface service-policy rename`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	UUID of the service policy

Request Body

Name	Type	Description
is_built_in	boolean	
name	string	
services	array[string]	
uuid	string	

Example request

```
{
  "name": "default-intercluster",
  "services": [
    "data_nfs"
  ],
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1376669	Port must reside in the same IPspace as the interface's SVM.
2621740	An unexpected error when trying to determine whether the target Vserver was locked or not on this cluster.
53281911	Modifying the service policy is disallowed because policies on this SVM are managed by the system
53281929	Service policies cannot combine block and file services.
53281930	Service policies maintained by the system cannot be renamed.
53281931	Service policy names cannot start with "default-".
53281932	Service cannot be added because the service does not exist for the specified SVM or IPspace.
53281933	A Cluster-scoped service cannot be added to a SVM-scoped service policy.
53281934	An SVM-scoped service cannot be added to a Cluster-scoped service policy.

Error Code	Description
53281952	The service policy on an SVM cannot be updated to include a block service. Use built-in service policies for SAN services.
53281953	The service policy on an SVM cannot be updated to include a new service.
53281960	Service cannot be removed from the service policy because it is used by one or more interfaces.
53281961	Service cannot be removed from the service policy because it is used by one or more interfaces.
53281963	Service cannot be removed from the service policy because it is used by one or more interfaces.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
name	string	The name of the SVM. This field cannot be specified in a PATCH method.
uuid	string	The unique identifier of the SVM. This field cannot be specified in a PATCH method.

ip_service_policy

Name	Type	Description
is_built_in	boolean	
name	string	
services	array[string]	
uuid	string	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage network IP subnets

Manage network IP subnets

Overview

The following operations are supported:

- Creation: POST network/ip/subnets
- Collection Get: GET network/ip/subnets
- Instance Get: GET network/ip/subnets/{uuid}
- Instance Patch: PATCH network/ip/subnets/{uuid}
- Instance Delete: DELETE network/ip/subnets/{uuid}

Retrieving IP subnet information

The IP subnets GET API retrieves and displays relevant information pertaining to the subnets configured in the cluster. The response can contain a list of multiple subnets or a specific subnet.

Examples

Retrieving all subnets in the cluster

The following example shows the list of all subnets configured in a cluster.

```
# The API:
/api/network/ip/subnets

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/subnets" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "451d8d99-582c-11ec-8572-005056acd597",
    "name": "Subnet-002",
    "_links": {
      "self": {
        "href": "/api/network/ip/subnets/451d8d99-582c-11ec-8572-
005056acd597"
      }
    }
  },
  {
    "uuid": "615b722f-5795-11ec-8572-005056acd597",
    "name": "Subnet-001",
    "_links": {
      "self": {
        "href": "/api/network/ip/subnets/615b722f-5795-11ec-8572-
005056acd597"
      }
    }
  }
],
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/network/ip/subnets"
  }
}
}
```

Retrieving a specific subnet

The following example shows the response when a specific subnet is requested. This is equivalent to fields=*, which returns most of the fields. The system returns an error when there is no subnet with the requested UUID.

```
# The API:
/api/network/ip/subnets/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/subnets/451d8d99-582c-11ec-
8572-005056acd597" -H "accept: application/hal+json"

# The response:
{
"uuid": "451d8d99-582c-11ec-8572-005056acd597",
"name": "Subnet-002",
"ipspace": {
  "uuid": "6f62c691-5780-11ec-8572-005056acd597",
  "name": "Default",
  "_links": {
    "self": {
      "href": "/api/network/ipspaces/6f62c691-5780-11ec-8572-005056acd597"
    }
  }
},
"broadcast_domain": {
  "uuid": "9a1dce3b-5780-11ec-8572-005056acd597",
  "name": "Default",
  "_links": {
    "self": {
      "href": "/api/network/ethernet/broadcast-domains/9a1dce3b-5780-11ec-
8572-005056acd597"
    }
  }
},
"subnet": {
  "address": "10.2.1.0",
  "netmask": "24",
  "family": "ipv4"
},
"gateway": "10.2.1.1",
"_links": {
  "self": {
    "href": "/api/network/ip/subnets/451d8d99-582c-11ec-8572-005056acd597"
  }
}
}
```

Retrieving all the fields for a specific subnet

The following example shows the response when all the fields for a specific subnet are requested, returning everything that fields=* returns plus the IP ranges and count fields. The system returns an error when there is no subnet with the requested UUID.

```
# The API:
/api/network/ip/subnets/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ip/subnets/451d8d99-582c-11ec-
8572-005056acd597?fields=**" -H "accept: application/hal+json"

# The response:
{
"uuid": "451d8d99-582c-11ec-8572-005056acd597",
"name": "Subnet-002",
"ipspace": {
  "uuid": "6f62c691-5780-11ec-8572-005056acd597",
  "name": "Default",
  "_links": {
    "self": {
      "href": "/api/network/ipspaces/6f62c691-5780-11ec-8572-005056acd597"
    }
  }
},
"broadcast_domain": {
  "uuid": "9a1dce3b-5780-11ec-8572-005056acd597",
  "name": "Default",
  "_links": {
    "self": {
      "href": "/api/network/ethernet/broadcast-domains/9a1dce3b-5780-11ec-
8572-005056acd597"
    }
  }
},
"subnet": {
  "address": "10.2.1.0",
  "netmask": "24",
  "family": "ipv4"
},
"gateway": "10.2.1.1",
"ip_ranges": [
  {
    "start": "10.2.1.10",
```

```
    "end": "10.2.1.22",
    "family": "ipv4"
  },
  {
    "start": "10.2.1.101",
    "end": "10.2.1.200",
    "family": "ipv4"
  }
],
"available_ip_ranges": [
  {
    "start": "10.2.1.10",
    "end": "10.2.1.22",
    "family": "ipv4"
  },
  {
    "start": "10.2.1.101",
    "end": "10.2.1.200",
    "family": "ipv4"
  }
],
"total_count": 113,
"used_count": 0,
"available_count": 113,
"_links": {
  "self": {
    "href": "/api/network/ip/subnets/451d8d99-582c-11ec-8572-
005056acd597?fields=**"
  }
}
}
```


Creating IP subnets

You can use the IP subnets POST API to create IP subnets as shown in the following examples.

Examples

Creating an IP subnet using the minimum number of parameters.

The following example shows the record returned after the creation of an IP subnet.

```
# The API:
/api/network/ip/subnets

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/subnets" -H "accept:
application/hal+json" -d '{ "name": "Subnet-003", "broadcast_domain": {
"uuid": "6577524b-5863-11ec-8981-005056a7077f" }, "subnet": { "address":
"10.3.0.0", "netmask": "16" } }'

# The response:
{
}

# The result:
curl -X GET "https://<mgmt-ip>/api/network/ip/subnets?name=Subnet-
003&fields=**" -H "accept: application/hal+json"
{
"records": [
  {
    "uuid": "79ff5a5e-59b7-11ec-8981-005056a7077f",
    "name": "Subnet-003",
    "ipspace": {
      "uuid": "36569d0f-5863-11ec-8981-005056a7077f",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/36569d0f-5863-11ec-8981-
005056a7077f"
        }
      }
    },
    "broadcast_domain": {
      "uuid": "6577524b-5863-11ec-8981-005056a7077f",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ethernet/broadcast-domains/6577524b-5863-
11ec-8981-005056a7077f"
        }
      }
    },
    "subnet": {
      "address": "10.3.0.0",
      "netmask": "16",
      "family": "ipv4"
    },
```

```
    "total_count": 0,
    "used_count": 0,
    "available_count": 0,
    "_links": {
      "self": {
        "href": "/api/network/ip/subnets/79ff5a5e-59b7-11ec-8981-
005056a7077f?fields=**"
      }
    }
  }
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/network/ip/subnets?name=Subnet-003&fields=**"
  }
}
}
```

Creating an IP subnet using all parameters.

The following example shows the record returned after the creation of an IP subnet setting all parameters.

```
# The API:
/api/network/ip/subnets

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ip/subnets" -H "accept:
application/hal+json" -d '{ "name": "Subnet-004", "ipspace": { "name":
"Default", "uuid": "36569d0f-5863-11ec-8981-005056a7077f" },
"broadcast_domain": { "name": "Default", "uuid": "6577524b-5863-11ec-8981-
005056a7077f" }, "subnet": { "address": "10.4.1.0", "netmask": "24" },
"gateway": "10.4.1.1", "ip_ranges": [ { "start": "10.4.1.30", "end":
"10.4.1.39" }, { "start": "10.4.1.150", "end": "10.4.1.229" } ],
"fail_if_lifs_conflict": "false" }'

# The response:
{
}

# The result:
curl -X GET "https://<mgmt-ip>/api/network/ip/subnets?name=Subnet-
004&fields=**" -H "accept: application/hal+json"
```

```
{
"records": [
  {
    "uuid": "0e0a19e7-59ba-11ec-8981-005056a7077f",
    "name": "Subnet-004",
    "ipspace": {
      "uuid": "36569d0f-5863-11ec-8981-005056a7077f",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ipspaces/36569d0f-5863-11ec-8981-
005056a7077f"
        }
      }
    },
    "broadcast_domain": {
      "uuid": "6577524b-5863-11ec-8981-005056a7077f",
      "name": "Default",
      "_links": {
        "self": {
          "href": "/api/network/ethernet/broadcast-domains/6577524b-5863-
11ec-8981-005056a7077f"
        }
      }
    },
    "subnet": {
      "address": "10.4.1.0",
      "netmask": "24",
      "family": "ipv4"
    },
    "gateway": "10.4.1.1",
    "ip_ranges": [
      {
        "start": "10.4.1.30",
        "end": "10.4.1.39",
        "family": "ipv4"
      },
      {
        "start": "10.4.1.150",
        "end": "10.4.1.229",
        "family": "ipv4"
      }
    ],
    "available_ip_ranges": [
      {
        "start": "10.4.1.30",
```

```
        "end": "10.4.1.39",
        "family": "ipv4"
      },
      {
        "start": "10.4.1.150",
        "end": "10.4.1.229",
        "family": "ipv4"
      }
    ],
    "total_count": 90,
    "used_count": 0,
    "available_count": 90,
    "_links": {
      "self": {
        "href": "/api/network/ip/subnets/0e0a19e7-59ba-11ec-8981-
005056a7077f?fields=**"
      }
    }
  }
],
"num_records": 1,
"_links": {
  "self": {
    "href": "/api/network/ip/subnets?name=Subnet-004&fields=**"
  }
}
}
```


Updating IP subnets

You can use the IP subnets PATCH API to update the attributes of an IP subnet.

Examples

Updating the name of an IP subnet

The following example shows how the PATCH request changes the name.

```
# The API:
/api/network/ip/subnets/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ip/subnets/0e0a19e7-59ba-
11ec-8981-005056a7077f" -H "accept: application/hal+json" -d '{ "name":
"Subnet-004-NewName" }'

# The response:
{
}

# The result:
curl -X GET "https://<mgmt-ip>/api/network/ip/subnets/0e0a19e7-59ba-11ec-
8981-005056a7077f?fields=name" -H "accept: application/hal+json"
{
"uuid": "0e0a19e7-59ba-11ec-8981-005056a7077f",
"name": "Subnet-004-NewName",
"_links": {
  "self": {
    "href": "/api/network/ip/subnets/0e0a19e7-59ba-11ec-8981-005056a7077f"
  }
}
}
```

Updating the ip_ranges of an IP subnet

The following example shows how the PATCH request updates the ip_ranges.

```
# The API:
/api/network/ip/subnets/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ip/subnets/0e0a19e7-59ba-
11ec-8981-005056a7077f" -H "accept: application/hal+json" -d '{
"ip_ranges": [ { "start": "10.4.1.20", "end": "10.4.1.239" } ] }'

# The response:
{
}

# The result:
curl -X GET "https://<mgmt-ip>/api/network/ip/subnets/0e0a19e7-59ba-11ec-
8981-005056a7077f?fields=ip_ranges" -H "accept: application/hal+json"
{
"uuid": "0e0a19e7-59ba-11ec-8981-005056a7077f",
"name": "Subnet-004-NewName",
"ip_ranges": [
  {
    "start": "10.4.1.20",
    "end": "10.4.1.239",
    "family": "ipv4"
  }
],
"_links": {
  "self": {
    "href": "/api/network/ip/subnets/0e0a19e7-59ba-11ec-8981-005056a7077f"
  }
}
}
```

Deleting IP subnets

You can use the IP subnets DELETE API to delete an IP subnet.

Example

Deleting an IP subnet

The following DELETE request deletes a specific network IP subnet.

```
# The API:
/api/network/ip/subnets/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/network/ip/subnets/0e0a19e7-59ba-
11ec-8981-005056a7077f"

# The response:
{
}

# The result:
curl -X GET "https://<mgmt-ip>/api/network/ip/subnets/0e0a19e7-59ba-11ec-
8981-005056a7077f" -H "accept: application/hal+json"
{
"error": {
  "message": "entry doesn't exist",
  "code": "4",
  "target": "uuid"
}
}
```

Retrieve details for all subnets

GET `/network/ip/subnets`

Introduced In: 9.11

Retrieves details for all subnets.

Related ONTAP Commands

- `network subnet show`

Parameters

Name	Type	In	Required	Description
available_count	integer	query	False	Filter by available_count
subnet.family	string	query	False	Filter by subnet.family

Name	Type	In	Required	Description
subnet.address	string	query	False	Filter by subnet.address
subnet.netmask	string	query	False	Filter by subnet.netmask
name	string	query	False	Filter by name
total_count	integer	query	False	Filter by total_count
broadcast_domain.uuid	string	query	False	Filter by broadcast_domain.uuid
broadcast_domain.name	string	query	False	Filter by broadcast_domain.name
ip_ranges.family	string	query	False	Filter by ip_ranges.family
ip_ranges.start	string	query	False	Filter by ip_ranges.start
ip_ranges.end	string	query	False	Filter by ip_ranges.end
gateway	string	query	False	Filter by gateway
used_count	integer	query	False	Filter by used_count
ipspace.name	string	query	False	Filter by ipspace.name
ipspace.uuid	string	query	False	Filter by ipspace.uuid
uuid	string	query	False	Filter by uuid
available_ip_ranges.family	string	query	False	Filter by available_ip_ranges.family

Name	Type	In	Required	Description
available_ip_ranges.start	string	query	False	Filter by available_ip_ranges.start
available_ip_ranges.end	string	query	False	Filter by available_ip_ranges.end
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[ip_subnet]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "available_count": 0,
      "available_ip_ranges": [
        {
          "end": "10.10.10.7",
          "family": "string",
          "start": "10.10.10.7"
        }
      ],
      "broadcast_domain": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "bd1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "fail_if_lifs_conflict": true,
      "gateway": "10.1.1.1",
      "ip_ranges": [
        {
          "end": "10.10.10.7",
          "family": "string",
          "start": "10.10.10.7"
        }
      ],
      "ipspace": {
```

```
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "name": "subnet1",
      "subnet": {
        "address": "10.10.10.7",
        "family": "string",
        "netmask": "24"
      },
      "total_count": 0,
      "used_count": 0,
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

ip_address_range

IP address range

Name	Type	Description
end	string	IPv4 or IPv6 address
family	string	IPv4 or IPv6
start	string	IPv4 or IPv6 address

broadcast_domain

The broadcast domain that the subnet is associated with. Either the UUID or name must be supplied on POST.

Name	Type	Description
_links	_links	
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

ipspace

The IPspace that the subnet is associated with. Either the UUID or name must be supplied on POST.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address
family	string	IPv4 or IPv6
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ip_subnet

Name	Type	Description
_links	_links	
available_count	integer	
available_ip_ranges	array[ip_address_range]	
broadcast_domain	broadcast_domain	The broadcast domain that the subnet is associated with. Either the UUID or name must be supplied on POST.
gateway	string	The IP address of the gateway for this subnet.
ip_ranges	array[ip_address_range]	
ipspace	ipspace	The IPspace that the subnet is associated with. Either the UUID or name must be supplied on POST.
name	string	Subnet name

Name	Type	Description
subnet	ip_info	IP information
total_count	integer	
used_count	integer	
uuid	string	The UUID that uniquely identifies the subnet.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create a new named subnet

POST `/network/ip/subnets`

Introduced In: 9.11

Creates a new named subnet.

Required properties

- `name` - Name of the subnet to create.
- `broadcast_domain` - Broadcast domain containing the subnet.
- `ipspace` - IPspace containing the subnet. Required only if `broadcast_domain.uuid` is not provided.
- `subnet.address` - IP address for the subnet.
- `subnet.netmask` - IP netmask of the subnet.

Recommended property values

Default property values

If not specified in POST, the following default property values are assigned:

- `gateway` - no gateway
- `ip_ranges` - empty
- `fail_if_lifs_conflict` - *true*

Related ONTAP commands

- `network subnet create`

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
available_count	integer	
available_ip_ranges	array[ip_address_range]	
broadcast_domain	broadcast_domain	The broadcast domain that the subnet is associated with. Either the UUID or name must be supplied on POST.
fail_if_lifs_conflict	boolean	This action will fail if any existing interface is using an IP address in the ranges provided. Set this to false to associate any manually addressed interfaces with the subnet and allow the action to succeed.
gateway	string	The IP address of the gateway for this subnet.
ip_ranges	array[ip_address_range]	

Name	Type	Description
ipspace	ipspace	The IPspace that the subnet is associated with. Either the UUID or name must be supplied on POST.
name	string	Subnet name
subnet	ip_info	IP information
total_count	integer	
used_count	integer	
uuid	string	The UUID that uniquely identifies the subnet.

Example request


```
{
  "available_count": 0,
  "available_ip_ranges": [
    {
      "end": "10.10.10.7",
      "start": "10.10.10.7"
    }
  ],
  "broadcast_domain": {
    "name": "bd1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "gateway": "10.1.1.1",
  "ip_ranges": [
    {
      "end": "10.10.10.7",
      "start": "10.10.10.7"
    }
  ],
  "ipspace": {
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "subnet1",
  "subnet": {
    "address": "10.10.10.7",
    "netmask": "24"
  },
  "total_count": 0,
  "used_count": 0,
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Response

```
Status: 201, Created
```

Name	Type	Description
num_records	integer	Number of records

Name	Type	Description
records	array[ip_subnet]	

Example response


```
{
  "num_records": 1,
  "records": [
    {
      "available_count": 0,
      "available_ip_ranges": [
        {
          "end": "10.10.10.7",
          "start": "10.10.10.7"
        }
      ],
      "broadcast_domain": {
        "name": "bd1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "gateway": "10.1.1.1",
      "ip_ranges": [
        {
          "end": "10.10.10.7",
          "start": "10.10.10.7"
        }
      ],
      "ipspace": {
        "name": "Default",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "name": "subnet1",
      "subnet": {
        "address": "10.10.10.7",
        "netmask": "24"
      },
      "total_count": 0,
      "used_count": 0,
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```

Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1377658	Invalid gateway for subnet in IPspace.
1377659	Subnet would overlap with existing subnet named in IPspace.
1377660	A subnet with the name already exists in the IPspace.
1377661	Subnet in IPspace cannot use subnet address because that address is already used by another subnet in the same IPspace.
1377662	The IP range address is not within the subnet in IPspace.
1377663	The specified IP address range of subnet in IPspace contains an address already in use by a LIF.
1377664	The specified IP address range of subnet in IPspace contains an address already in use by the Service Processor.
1377673	The addresses provided must have the same address family.
1377675	The netmask of the interface did not match the netmask of the subnet.
1377681	Cannot update LIF associations for LIF. The broadcast domain of the LIF does not match the broadcast domain of the subnet.
1377682	IPv6 is not enabled in the cluster.
1966269	IPv4 Addresses must have a prefix length between 1 and 32.
1967082	The specified ipspace.name does not match the IPspace name of specified ipspace.uuid
53282568	The subnet.address must be specified together with subnet.netmask.
53282569	The specified subnet.netmask is not valid.

Error Code	Description
53282570	Each pair of ranges must have ip_ranges.start less than or equal to ip_ranges.end.
53282571	The ip_ranges.start and ip_ranges.end fields must have the same number of items.
53282573	Broadcast domain is a required parameter. The broadcast_domain.name and/or the broadcast_domain.uuid must be specified.
53282574	The specified broadcast_domain and ipspace parameters do not match.
53282575	Operation might have left configuration in an inconsistent state. Unable to set UUID for created entry.
53282576	The specified ipspace.uuid is invalid.
53282577	The specified broadcast_domain.uuid is invalid.
53282578	The specified broadcast_domain.name does not match the IPspace name of specified broadcast_domain.uuid
53282579	Missing the ipspace.name or ipspace.uuid parameter.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ip_address_range

IP address range

Name	Type	Description
end	string	IPv4 or IPv6 address
start	string	IPv4 or IPv6 address

broadcast_domain

The broadcast domain that the subnet is associated with. Either the UUID or name must be supplied on POST.

Name	Type	Description
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

ipspace

The IPspace that the subnet is associated with. Either the UUID or name must be supplied on POST.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address

Name	Type	Description
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ip_subnet

Name	Type	Description
available_count	integer	
available_ip_ranges	array[ip_address_range]	
broadcast_domain	broadcast_domain	The broadcast domain that the subnet is associated with. Either the UUID or name must be supplied on POST.
fail_if_lifs_conflict	boolean	This action will fail if any existing interface is using an IP address in the ranges provided. Set this to false to associate any manually addressed interfaces with the subnet and allow the action to succeed.
gateway	string	The IP address of the gateway for this subnet.
ip_ranges	array[ip_address_range]	
ipspace	ipspace	The IPspace that the subnet is associated with. Either the UUID or name must be supplied on POST.
name	string	Subnet name
subnet	ip_info	IP information
total_count	integer	
used_count	integer	
uuid	string	The UUID that uniquely identifies the subnet.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete an IP subnet

DELETE `/network/ip/subnets/{uuid}`

Introduced In: 9.11

Deletes an IP subnet.

Related ONTAP commands

- `network subnet delete`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	IP subnet UUID

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

Fill error codes below. ONTAP Error Response Codes

Error Code	Description
1377663	The specified IP address range of subnet in IPspace contains an address already in use by a LIF.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve IP subnet details

GET `/network/ip/subnets/{uuid}`

Introduced In: 9.11

Retrieves details for a specific IP subnet.

Related ONTAP commands

- `network subnet show`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	IP subnet UUID
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
available_count	integer	
available_ip_ranges	array[ip_address_range]	
broadcast_domain	broadcast_domain	The broadcast domain that the subnet is associated with. Either the UUID or name must be supplied on POST.
gateway	string	The IP address of the gateway for this subnet.
ip_ranges	array[ip_address_range]	
ipspace	ipspace	The IPspace that the subnet is associated with. Either the UUID or name must be supplied on POST.
name	string	Subnet name
subnet	ip_info	IP information
total_count	integer	
used_count	integer	
uuid	string	The UUID that uniquely identifies the subnet.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "available_count": 0,
  "available_ip_ranges": [
    {
      "end": "10.10.10.7",
      "family": "string",
      "start": "10.10.10.7"
    }
  ],
  "broadcast_domain": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "bd1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "fail_if_lifs_conflict": true,
  "gateway": "10.1.1.1",
  "ip_ranges": [
    {
      "end": "10.10.10.7",
      "family": "string",
      "start": "10.10.10.7"
    }
  ],
  "ipspace": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "Default",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "subnet1",
  "subnet": {
    "address": "10.10.10.7",
```

```
    "family": "string",
    "netmask": "24"
  },
  "total_count": 0,
  "used_count": 0,
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

ip_address_range

IP address range

Name	Type	Description
end	string	IPv4 or IPv6 address
family	string	IPv4 or IPv6
start	string	IPv4 or IPv6 address

broadcast_domain

The broadcast domain that the subnet is associated with. Either the UUID or name must be supplied on POST.

Name	Type	Description
_links	_links	
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

ipspace

The IPspace that the subnet is associated with. Either the UUID or name must be supplied on POST.

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	IPspace UUID

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address
family	string	IPv4 or IPv6
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update an IP subnet

PATCH `/network/ip/subnets/{uuid}`

Introduced In: 9.11

Updates an IP subnet.

Related ONTAP commands

- `network subnet modify`

- `network subnet rename`
- `network subnet add-ranges`
- `network subnet remove-ranges`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	IP subnet UUID

Request Body

Name	Type	Description
available_count	integer	
available_ip_ranges	array[ip_address_range]	
fail_if_lifs_conflict	boolean	This action will fail if any existing interface is using an IP address in the ranges provided. Set this to false to associate any manually addressed interfaces with the subnet and allow the action to succeed.
gateway	string	The IP address of the gateway for this subnet.
ip_ranges	array[ip_address_range]	
name	string	Subnet name
subnet	ip_info	IP information
total_count	integer	
used_count	integer	
uuid	string	The UUID that uniquely identifies the subnet.

Example request


```
{
  "available_count": 0,
  "available_ip_ranges": [
    {
      "end": "10.10.10.7",
      "start": "10.10.10.7"
    }
  ],
  "gateway": "10.1.1.1",
  "ip_ranges": [
    {
      "end": "10.10.10.7",
      "start": "10.10.10.7"
    }
  ],
  "name": "subnet1",
  "subnet": {
    "address": "10.10.10.7",
    "netmask": "24"
  },
  "total_count": 0,
  "used_count": 0,
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

Fill error codes below. ONTAP Error Response Codes

Error Code	Description
1377658	Invalid gateway for subnet in IPspace.
1377659	Subnet would overlap with existing subnet named in IPspace.

Error Code	Description
1377660	A subnet with the name already exists in the IPspace.
1377661	Subnet in IPspace cannot use subnet address because that address is already used by subnet in the same IPspace.
1377662	The IP range address is not within the subnet in IPspace.
1377663	The specified IP address range of subnet in IPspace contains an address already in use by a LIF.
1377664	The specified IP address range of subnet in IPspace contains an address already in use by the Service Processor.
1377669	The specified gateway address exists in a configured range.
1377673	The addresses provided must have the same address family.
1377674	Modifying the netmask is not supported because the subnet has one or more interfaces associated with it.
1377675	The netmask of the interface did not match the netmask of the subnet.
1377681	Cannot update LIF associations for LIF. The broadcast domain of the LIF does not match the broadcast domain of the subnet.
1966269	IPv4 Addresses must have a prefix length between 1 and 32.
1966778	IPv6 addresses must have a prefix length between 1 and 127.
53282568	The subnet.address must be specified together with subnet.netmask.
53282569	The specified subnet.netmask is not valid.
53282570	Each pair of ranges must have ip_ranges.start less than or equal to ip_ranges.end.
53282571	The ip_ranges.start and ip_ranges.end fields must have the same number of items.
53282572	PATCH partially succeeded with error.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ip_address_range

IP address range

Name	Type	Description
end	string	IPv4 or IPv6 address
start	string	IPv4 or IPv6 address

broadcast_domain

The broadcast domain that the subnet is associated with. Either the UUID or name must be supplied on POST.

Name	Type	Description
name	string	Name of the broadcast domain, scoped to its IPspace
uuid	string	Broadcast domain UUID

ipspace

The IPspace that the subnet is associated with. Either the UUID or name must be supplied on POST.

Name	Type	Description
name	string	IPspace name
uuid	string	IPspace UUID

ip_info

IP information

Name	Type	Description
address	string	IPv4 or IPv6 address

Name	Type	Description
netmask	string	Input as netmask length (16) or IPv4 mask (255.255.0.0). For IPv6, the default value is 64 with a valid range of 1 to 127. Output is always the netmask length.

ip_subnet

Name	Type	Description
available_count	integer	
available_ip_ranges	array[ip_address_range]	
fail_if_lifs_conflict	boolean	This action will fail if any existing interface is using an IP address in the ranges provided. Set this to false to associate any manually addressed interfaces with the subnet and allow the action to succeed.
gateway	string	The IP address of the gateway for this subnet.
ip_ranges	array[ip_address_range]	
name	string	Subnet name
subnet	ip_info	IP information
total_count	integer	
used_count	integer	
uuid	string	The UUID that uniquely identifies the subnet.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Manage network IPspaces

Manage network IPspaces

Overview

An IPspace is an addressing domain within which each IP address is unique. The same address may appear in a different IPspace, but the matching addresses are considered to be distinct. SVMs and broadcast domains, and therefore IP interfaces and Ethernet ports, are associated with a single IPspace. This endpoint supports the following operations: GET (collection and instance), POST, PATCH, and DELETE.

Retrieving IPspace information

You can use the IPspaces GET API to retrieve all IPspaces configured in the cluster, including built-in and custom IPspaces, and specifically requested IPspaces.

Examples

Retrieving a list of the IPspaces in the cluster

The following example returns the requested list of IPspaces configured in the cluster.

```
# The API:
/api/network/ipspaces

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ipspaces?fields=*" -H "accept:
application/hal+json"

# The response:
{
"records": [
  {
    "uuid": "dcc7e79c-5acc-11e8-b9de-005056b42b32",
    "name": "Default",
    "_links": {
```

```
      "self": {
        "href": "/api/network/ipspaces/dcc7e79c-5acc-11e8-b9de-
005056b42b32"
      }
    }
  },
  {
    "uuid": "dfd3c1b2-5acc-11e8-b9de-005056b42b32",
    "name": "Cluster",
    "_links": {
      "self": {
        "href": "/api/network/ipspaces/dfd3c1b2-5acc-11e8-b9de-
005056b42b32"
      }
    }
  },
  {
    "uuid": "dedec1be-5aec-1eee-beee-0eee56be2b3e",
    "name": "Ipspace1",
    "_links": {
      "self": {
        "href": "/api/network/ipspaces/dedec1be-5aec-1eee-beee-
0eee56be2b3e"
      }
    }
  }
],
"num_records": 3,
"_links": {
  "self": {
    "href": "/api/network/ipspaces?fields=*"
  }
}
}
```

Retrieving a specific IPspace in the cluster

The following example returns the specific IPspace requested. The system returns an error if there is no IPspace with the requested UUID.

```
# The API:
/api/network/ipspaces/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/network/ipspaces/dfd3c1b2-5acc-11e8-
b9de-005056b42b32?fields=*" -H "accept: application/hal+json"

# The response:
{
  "uuid": "dcc7e79c-5acc-11e8-b9de-005056b42b32",
  "name": "Default",
  "_links": {
    "self": {
      "href": "/api/network/ipspaces/dcc7e79c-5acc-11e8-b9de-005056b42b32"
    }
  }
}
```

Creating IPspaces

You can use the network IPspaces POST API to create IPspaces.

Example

Creating an IPspace

The following output displays the record returned after the creation of an IPspace with the name "ipspace1".

```
# The API:
/api/network/ipspaces

# The call:
curl -X POST "https://<mgmt-ip>/api/network/ipspaces?return_records=true"
-H  "accept: application/hal+json" -d "{  \"name\": \"ipspace2\"}"

# The response:
{
"num_records": 1,
"records": [
  {
    "uuid": "4165655e-0528-11e9-bd68-005056bb046a",
    "name": "ipspace2",
    "_links": {
      "self": {
        "href": "/api/network/ipspaces/4165655e-0528-11e9-bd68-
005056bb046a"
      }
    }
  }
]
}
```

Updating IPspaces

You can use the IPspaces PATCH API to update the attributes of the IPspace.

Example

Updating the name of an IPspace

The following PATCH request is used to update the name of the IPspace from "ipspace2" to "ipspace20".

```
# The API:
/api/network/ipspaces/{uuid}

# The call:
curl -X PATCH "https://<mgmt-ip>/api/network/ipspaces/4165655e-0528-11e9-
bd68-005056bb046a" -H  "accept: application/hal+json" -d "{  \"name\":
\"ipspace20\"}"
```

Deleting IPspaces

You can use the IPspaces DELETE API to delete an IPspace.

Example

Deleting an IPspace

The following DELETE request is used to delete an IPspace.

```
# The API:
/api/network/ipspaces/{uuid}

# The call:
curl -X DELETE "https://<mgmt-ip>/api/network/ipspaces/4165655e-0528-11e9-
bd68-005056bb046a" -H  "accept: application/hal+json" -H  "Content-Type:
application/json"
```

Retrieve IPspaces for a cluster

GET `/network/ipspaces`

Introduced In: 9.6

Retrieves a collection of IPspaces for the entire cluster.

Related ONTAP commands

- `network ipspace show`

Parameters

Name	Type	In	Required	Description
name	string	query	False	Filter by name
uuid	string	query	False	Filter by uuid
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 15 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[ipspace]	

Example response


```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "num_records": 1,
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "ipspace1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  ]
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

ipspace

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	The UUID that uniquely identifies the IPspace.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message

Name	Type	Description
target	string	The target parameter that caused the error.

Create a new domain with unique IP addresses

POST `/network/ipspaces`

Introduced In: 9.6

Creates a new domain within which IP addresses are unique. SVMs, ports, and networks are scoped to a single IPspace.

Required properties

- `name` - Name of the IPspace to create.

Related ONTAP commands

- `network ipspace create`

Parameters

Name	Type	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Type	Description
name	string	IPspace name
uuid	string	The UUID that uniquely identifies the IPspace.

Example request

```
{
  "name": "ipspace1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

```
Status: 201, Created
```

Headers

Name	Description	Type
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1377261	An IPspace with the same name already exists.
1966449	Invalid IPspace name in MetroCluster configurations.
1966586	The specified IPspace name is invalid because it is already used by a peered SVM.
1967102	A POST operation might have left the configuration in an inconsistent state. Check the configuration.
9240587	Name cannot be empty.
9240588	The name is too long.
9240589	Invalid character in name.
9240590	The name is reserved by the system.
9240591	The name is not valid. The name is already in use by a cluster node, Vserver, or it is the name of the local cluster.
53281576	Cannot create IPspace because the maximum number of custom IPspaces has already been reached on the cluster.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Name	Type	Description
name	string	IPspace name
uuid	string	The UUID that uniquely identifies the IPspace.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete an IPspace object

DELETE `/network/ipspaces/{uuid}`

Introduced In: 9.6

Deletes an IPspace object.

Related ONTAP commands

- `network ipspace delete`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	IPspace UUID

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1966309	The IPspace cannot be removed because it is being used by the audit log forwarding feature.
1966333	IPspace can’t be removed because it has SVMs assigned.
1969180	Cannot delete an IPspace with an existing broadcast domain.

Also see the table of common errors in the Response body overview section of this documentation.

Name	Type	Description
error	returned_error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve information about an IPspace

GET `/network/ipspaces/{uuid}`

Introduced In: 9.6

Retrieves information about a specific IPspace.

Related ONTAP commands

- `network ipspace show`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	IPspace UUID
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Type	Description
_links	_links	
name	string	IPspace name
uuid	string	The UUID that uniquely identifies the IPspace.

Example response


```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "ipspace1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```


Error

```
Status: Default, Error
```

Name	Type	Description
error	returned_error	

Example error


```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```


Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update an IPspace object

PATCH `/network/ipspaces/{uuid}`

Introduced In: 9.6

Updates an IPspace object.

Related ONTAP commands

- `network ipspace rename`

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	IPspace UUID

Request Body

Name	Type	Description
name	string	IPspace name
uuid	string	The UUID that uniquely identifies the IPspace.

Example request

```
{
  "name": "ipspace1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
1377256	Another IPspace with the same name exists.
1377259	System-defined IPspaces cannot be modified or removed.
1966449	Invalid IPspace name in MetroCluster configurations.
9240587	IPspace name cannot be empty.
9240588	The specified name is too long.
9240589	Invalid character in specified name.

Error Code	Description
9240590	Invalid name, the name is reserved by the system.
9240591	Invalid name. The name is already in use by a cluster node, Vserver, or it is the name of the local cluster.

Also see the table of common errors in the Response body overview section of this documentation.

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

ipspace

Name	Type	Description
name	string	IPspace name
uuid	string	The UUID that uniquely identifies the IPspace.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

returned_error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.