



Manage FlexCache volumes

ONTAP 9.6 REST API reference

NetApp
May 08, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-96/ontap/storage_flexcache_flexcaches_endpoint_overview.html on May 08, 2024. Always check docs.netapp.com for the latest.

Table of Contents

- Manage FlexCache volumes 1
 - Storage flexcache flexcaches endpoint overview 1
 - Retrieve a FlexCache volume in the cluster..... 5
 - Create a FlexCache volume in the cluster..... 15
 - Delete a FlexCache volume 24
 - Retrieve attributes of the FlexCache volume in the cluster 27

Manage FlexCache volumes

Storage flexcache flexcaches endpoint overview

Overview

FlexCache is a persistent cache of an origin volume. An origin volume can only be a FlexVol while a FlexCache is always a FlexGroup.

The following relationship configurations are supported:

- – Intra-Vserver where FlexCache and the corresponding origin volume reside in the same Vserver.

- – Cross-Vserver but intra-cluster where FlexCache and the origin volume reside in the same cluster but belong to different Vservers.

- – Cross-cluster where FlexCache and the origin volume reside in different clusters.

FlexCache supports fan-out and more than one FlexCache can be created from one origin volume. This API retrieves and manages FlexCache configurations in the cache cluster.

FlexCache APIs

The following APIs can be used to perform operations related with FlexCache:

- – GET /api/storage/flexcache/flexcaches

- – GET /api/storage/flexcache/flexcaches/{uuid}

- – POST /api/storage/flexcache/flexcaches

- – DELETE /api/storage/flexcache/flexcaches/{uuid}

Examples

Creating a FlexCache

The POST request is used to create a FlexCache.

```
# The API:
/api/storage/flexcache/flexcaches

# The call:
curl -X POST "https://<mgmt-ip>/api/storage/flexcache/flexcaches" -H
"accept: application/json" -H "Content-Type: application/json" -d "{
  \"aggregates\": [ { \"name\": \"aggr_1\" } ], \"name\": \"fc_333\",
  \"origins\": [ { \"svm\": { \"name\": \"vs_3\" }, \"volume\": {
    \"name\": \"vol_o1\" } } ], \"svm\": { \"name\": \"vs_1\" } }"

# The response:
{
  "job": {
    "uuid": "e751dd5d-0f3c-11e9-8b2b-0050568e0b79",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/e751dd5d-0f3c-11e9-8b2b-0050568e0b79"
      }
    }
  }
}
```

Retrieving FlexCache attributes

The GET request is used to retrieve FlexCache attributes. The object includes a large set of fields which can be expensive to retrieve. Most notably, the fields size, aggregates, path, origins.ip_address, origins.size, origins.state are expensive to retrieve. The recommended method to use this API is to use filter and retrieve only the required fields.

```
# The API:
/api/storage/flexcache/flexcaches

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/flexcache/flexcaches?" -H
"accept: application/json"

# The response:
{
  "records": [
    {
      "uuid": "04d5e07b-0ebe-11e9-8180-0050568e0b79",
      "name": "fc_322",
      "_links": {
        "self": {
          "href": "/api/storage/flexcache/flexcaches/04d5e07b-0ebe-11e9-
```

```

8180-0050568e0b79"
    }
  }
},
{
  "uuid": "47902654-0ea4-11e9-8180-0050568e0b79",
  "name": "fc_321",
  "_links": {
    "self": {
      "href": "/api/storage/flexcache/flexcaches/47902654-0ea4-11e9-
8180-0050568e0b79"
    }
  }
},
{
  "uuid": "77e911ff-0ebe-11e9-8180-0050568e0b79",
  "name": "fc_323",
  "_links": {
    "self": {
      "href": "/api/storage/flexcache/flexcaches/77e911ff-0ebe-11e9-
8180-0050568e0b79"
    }
  }
},
{
  "uuid": "ddb42bbc-0e95-11e9-8180-0050568e0b79",
  "name": "fc_32",
  "_links": {
    "self": {
      "href": "/api/storage/flexcache/flexcaches/ddb42bbc-0e95-11e9-
8180-0050568e0b79"
    }
  }
},
{
  "uuid": "ec774932-0f3c-11e9-8b2b-0050568e0b79",
  "name": "fc_333",
  "_links": {
    "self": {
      "href": "/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-
8b2b-0050568e0b79"
    }
  }
}
],
"num_records": 5,

```

```

    "_links": {
      "self": {
        "href": "/api/storage/flexcache/flexcaches?"
      }
    }
  }
}

```

Retrieving the attributes of a FlexCache

The GET request is used to retrieve the attributes of a FlexCache. The object includes a large set of fields which can be expensive to retrieve. Most notably, the fields `size`, `aggregates`, `path`, `origins.ip_address`, `origins.size`, `origins.state` are expensive to retrieve. The recommended method to use this API is to use filter and retrieve only the required fields.

```

# The API:
/api/storage/flexcache/flexcaches/{uuid}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-8b2b-0050568e0b79" -H "accept: application/json"

# The response:
{
  "uuid": "ec774932-0f3c-11e9-8b2b-0050568e0b79",
  "name": "fc_333",
  "svm": {
    "name": "vs_1",
    "uuid": "e708fbe2-0e92-11e9-8180-0050568e0b79"
  },
  "size": 4294967296,
  "aggregates": [
    {
      "name": "aggr_1",
      "uuid": "26f34b76-88f8-4a47-b5e0-d8e901fb1114"
    }
  ],
  "origins": [
    {
      "ip_address": "10.140.103.175",
      "size": 20971520,
      "create_time": "2019-01-03T15:19:55+05:30",
      "state": "online",
      "volume": {
        "name": "vol_o1",
        "uuid": "2bc957dd-2617-4afb-8d2f-66ac6070d313"
      }
    }
  ]
}

```

```

    "svm": {
      "name": "vs_3",
      "uuid": "8aa2cd28-0e92-11e9-b391-0050568e4115"
    },
    "cluster": {
      "name": "node2",
      "uuid": "50733f81-0e90-11e9-b391-0050568e4115"
    }
  ],
  "_links": {
    "self": {
      "href": "/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-8b2b-0050568e0b79"
    }
  }
}

```

Deleting a FlexCache

The DELETE request is used to delete a FlexCache.

```

# The API:
/api/storage/flexcache/flexcaches

# The call:
curl -X DELETE "https://<mgmt-
ip>/api/storage/flexcache/flexcaches/ec774932-0f3c-11e9-8b2b-0050568e0b79"
-H "accept: application/json"

# The response:
{
  "job": {
    "uuid": "e17994f2-0f3e-11e9-8b2b-0050568e0b79",
    "_links": {
      "self": {
        "href": "/api/cluster/jobs/e17994f2-0f3e-11e9-8b2b-0050568e0b79"
      }
    }
  }
}

```

Retrieve a FlexCache volume in the cluster

GET /storage/flexcache/flexcaches

Retrieves FlexCaches in the cluster.

Expensive properties

There is an added cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the `fields` query parameter. See [DOC Requesting specific fields](#) to learn more.

- `origins.ip_address` - IP address of origin.
- `origins.size` - Physical size of origin.
- `origins.state` - State of origin.
- `size` - Physical size of FlexCache.
- `aggregates.name` or `aggregates.uuid` - Name or UUID of aggregate of FlexCache volume.
- `path` - Fully-qualified path of the owning SVM's namespace where the FlexCache is mounted.

Related ONTAP commands

- `volume flexcache show`

Learn more

- [DOC /storage/flexcache/flexcaches](#)

Parameters

Name	Type	In	Required	Description
<code>aggregates.uuid</code>	string	query	False	Filter by <code>aggregates.uuid</code>
<code>aggregates.name</code>	string	query	False	Filter by <code>aggregates.name</code>
<code>uuid</code>	string	query	False	Filter by <code>uuid</code>
<code>path</code>	string	query	False	Filter by <code>path</code>
<code>size</code>	integer	query	False	Filter by <code>size</code>
<code>constituents_per_aggregate</code>	integer	query	False	Filter by <code>constituents_per_aggregate</code>
<code>origins.cluster.uuid</code>	string	query	False	Filter by <code>origins.cluster.uuid</code>

Name	Type	In	Required	Description
origins.cluster.name	string	query	False	Filter by origins.cluster.name
origins.ip_address	string	query	False	Filter by origins.ip_address
origins.state	string	query	False	Filter by origins.state
origins.volume.name	string	query	False	Filter by origins.volume.name
origins.volume.uuid	string	query	False	Filter by origins.volume.uuid
origins.size	integer	query	False	Filter by origins.size
origins.svm.uuid	string	query	False	Filter by origins.svm.uuid
origins.svm.name	string	query	False	Filter by origins.svm.name
origins.create_time	string	query	False	Filter by origins.create_time
name	string	query	False	Filter by name
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.

Name	Type	In	Required	Description
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
order_by	array[string]	query	False	Order results by specified fields and optional [asc
desc] direction. Default direction is 'asc' for ascending.	return_records	boolean	query	False

Response

Status: 200, Ok

Name	Type	Description
_links	_links	
num_records	integer	Number of records
records	array[flexcache]	

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "aggregates": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "aggr1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "name": "voll",
    "origins": {
      "cluster": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "cluster1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "create_time": "2018-06-04 19:00:00 UTC",
      "ip_address": "10.10.10.7",
      "size": 0,
      "state": "error",
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        }
      }
    }
  }
}
```

```

    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "volume": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
},
"path": "/user/my_fc",
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
}

```

Error

Status: Default, Error

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

aggregates

Aggregate

Name	Type	Description
_links	_links	
name	string	
uuid	string	

cluster

Name	Type	Description
_links	_links	
name	string	
uuid	string	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

volume

Name	Type	Description
_links	_links	
name	string	The name of the volume.
uuid	string	Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. <ul style="list-style-type: none">• example: 028baa66-41bd-11e9-81d5-00a0986138f7

flexcache_relationship

Name	Type	Description
cluster	cluster	
create_time	string	Creation time of the relationship.
ip_address	string	Cluster management IP of the remote cluster.
size	integer	Size of the remote volume.
state	string	Volume state
svm	svm	SVM, applies only to SVM-scoped objects.
volume	volume	

svm

FlexCache SVM

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

flexcache

Defines the cache endpoint of FlexCache.

Name	Type	Description
_links	_links	
aggregates	array[aggregates]	
constituents_per_aggregate	integer	Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned.
name	string	FlexCache name
origins	array[flexcache_relationship]	
path	string	The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path.
size	integer	Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.
svm	svm	FlexCache SVM
uuid	string	FlexCache UUID. Unique identifier for the FlexCache.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments

Name	Type	Description
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create a FlexCache volume in the cluster

POST /storage/flexcache/flexcaches

Creates a FlexCache in the cluster.

Required properties

- name - Name of FlexCache volume.
- origins.volume.name or origins.volume.uuid - Name or UUID of origin volume.
- origins.svm.name - Name of origin Vserver.
- svm.name or svm.uuid - Name or UUID of Vserver where FlexCache will be created.

Recommended optional properties

- path - Path to mount the FlexCache volume

Default property values

If not specified in POST, the following default property values are assigned:

- size - 10% of origin volume size or 1GB per constituent, whichever is greater.
- constituents_per_aggregate - 4 if aggregates.name or aggregates.uuid is used.

Related ONTAP commands

- volume flexcache create

Learn more

- [DOC /storage/flexcache/flexcaches](#)

Request Body

Name	Type	Description
_links	_links	

Name	Type	Description
aggregates	array[aggregates]	
constituents_per_aggregate	integer	Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned.
name	string	FlexCache name
origins	array[flexcache_relationship]	
path	string	The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path.
size	integer	Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.
svm	svm	FlexCache SVM
uuid	string	FlexCache UUID. Unique identifier for the FlexCache.

Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "voll",
  "origins": {
    "cluster": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "cluster1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "create_time": "2018-06-04 19:00:00 UTC",
    "ip_address": "10.10.10.7",
    "size": 0,
    "state": "error",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      }
    }
  }
}
```

```

    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
},
"path": "/user/my_fc",
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}

```

Response

Status: 202, Accepted

Name	Type	Description
job	job_link	

Example response

```

{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}

```

Error

Status: Default

ONTAP Error Response Codes

Error Code	Description
66846870	Either the SVM name or origin volume name is missing
66846871	Constituents per aggregate are specified but aggregate name is missing
66846872	More than one origin volume is specified
66846873	The specified SVM UUID is incorrect for the specified SVM name
66846874	The specified aggregate UUID is incorrect for the specified aggregate name
66846875	The specified aggregate name does not exist
66846876	The specified SVM does not exist or is not peered
66846877	The specified origin SVM name is of zero length
66846878	The specified SVM UUID is invalid
66846730	Failed to create a FlexCache volume
66846760	The specified SVM is not a data Vserver
66846787	The specified aggregate is a SnapLock aggregate
66846812	The specified aggregate is a Composite aggregate
66846812	The specified junction path is under a FlexCache volume
66846834	FlexCache encryption requires a cluster version of 9.6 or higher
66846835	A volume encryption license is not found

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

aggregates

Aggregate

Name	Type	Description
_links	_links	
name	string	
uuid	string	

cluster

Name	Type	Description
_links	_links	
name	string	
uuid	string	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

volume

Name	Type	Description
_links	_links	

Name	Type	Description
name	string	The name of the volume.
uuid	string	<p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> example: 028baa66-41bd-11e9-81d5-00a0986138f7

flexcache_relationship

Name	Type	Description
cluster	cluster	
create_time	string	Creation time of the relationship.
ip_address	string	Cluster management IP of the remote cluster.
size	integer	Size of the remote volume.
state	string	Volume state
svm	svm	SVM, applies only to SVM-scoped objects.
volume	volume	

svm

FlexCache SVM

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

flexcache

Defines the cache endpoint of FlexCache.

Name	Type	Description
_links	_links	
aggregates	array[aggregates]	
constituents_per_aggregate	integer	Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned.
name	string	FlexCache name
origins	array[flexcache_relationship]	
path	string	The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path.
size	integer	Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.
svm	svm	FlexCache SVM
uuid	string	FlexCache UUID. Unique identifier for the FlexCache.

job_link

Name	Type	Description
_links	_links	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error_arguments

Name	Type	Description
code	string	Argument code

Name	Type	Description
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete a FlexCache volume

```
DELETE /storage/flexcache/flexcaches/{uuid}
```

Deletes a FlexCache. If a FlexCache volume is online, it is offlined before deletion.

Related ONTAP commands

- `volume flexcache delete`

Learn more

- [DOC /storage/flexcache/flexcaches](#)

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	

Response

```
Status: 202, Accepted
```

Name	Type	Description
job	job_link	

Example response

```
{
  "job": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uuid": "string"
  }
}
```

Error

Status: Default

ONTAP Error Response Codes

Error Code	Description	
66846879	The specified volume UUID is not a FlexCache volume	
66846731	Failed to delete the FlexCache volume	
524546	Failed to delete the FlexCache volume because the FlexCache volume is not unmounted	

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

job_link

Name	Type	Description
_links	_links	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve attributes of the FlexCache volume in the cluster

GET /storage/flexcache/flexcaches/{uuid}

Retrieves attributes of the FlexCache in the cluster.

Expensive properties

There is an added cost to retrieving values for these properties. They are included by default in GET. The recommended method to use this API is to use filter and retrieve only the required fields. See [DOC Requesting specific fields](#) to learn more.

- `origins.ip_address` - IP address of origin.
- `origins.size` - Physical size of origin.
- `origins.state` - State of origin.
- `size` - Physical size of FlexCache.
- `aggregates.name` or `aggregates.uuid` - Name or UUID of aggregate of FlexCache volume.
- `path` - Fully-qualified path of the owning SVM's namespace where the FlexCache is mounted.

Related ONTAP commands

- `volume flexcache show`

Learn more

- [DOC /storage/flexcache/flexcaches](#)

Parameters

Name	Type	In	Required	Description
uuid	string	path	True	Unique identifier of FlexCache.
fields	array[string]	query	False	Specify the fields to return.

Response

Status: 200, Ok

Name	Type	Description
<code>_links</code>	_links	
<code>aggregates</code>	array[aggregates]	
<code>constituents_per_aggregate</code>	integer	Number of FlexCache constituents per aggregate when the 'aggregates' field is mentioned.

Name	Type	Description
name	string	FlexCache name
origins	array[flexcache_relationship]	
path	string	The fully-qualified path in the owning SVM's namespace at which the FlexCache is mounted. The path is case insensitive and must be unique within a SVM's namespace. Path must begin with '/' and must not end with '/'. Only one FlexCache be mounted at any given junction path.
size	integer	Physical size of the FlexCache. The recommended size for a FlexCache is 10% of the origin volume. The minimum FlexCache constituent size is 1GB.
svm	svm	FlexCache SVM
uuid	string	FlexCache UUID. Unique identifier for the FlexCache.

Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "aggregates": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "name": "voll",
  "origins": {
    "cluster": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "cluster1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "create_time": "2018-06-04 19:00:00 UTC",
    "ip_address": "10.10.10.7",
    "size": 0,
    "state": "error",
    "svm": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "svm1",
      "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "volume": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      }
    }
  }
}
```



```

    },
    "name": "volume1",
    "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
  }
},
"path": "/user/my_fc",
"svm": {
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}

```

Error

Status: Default, Error

Name	Type	Description
error	error	

Example error

```

{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}

```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

aggregates

Aggregate

Name	Type	Description
_links	_links	
name	string	
uuid	string	

cluster

Name	Type	Description
_links	_links	
name	string	
uuid	string	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

volume

Name	Type	Description
_links	_links	

Name	Type	Description
name	string	The name of the volume.
uuid	string	<p>Unique identifier for the volume. This corresponds to the instance-uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.</p> <ul style="list-style-type: none"> example: 028baa66-41bd-11e9-81d5-00a0986138f7

flexcache_relationship

Name	Type	Description
cluster	cluster	
create_time	string	Creation time of the relationship.
ip_address	string	Cluster management IP of the remote cluster.
size	integer	Size of the remote volume.
state	string	Volume state
svm	svm	SVM, applies only to SVM-scoped objects.
volume	volume	

svm

FlexCache SVM

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

error_arguments

Name	Type	Description
code	string	Argument code

Name	Type	Description
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.