



Manage iSCSI services

ONTAP 9.6 REST API reference

NetApp
August 29, 2024

Table of Contents

- Manage iSCSI services 1
 - Protocols SAN iSCSI services endpoint overview 1
 - Retrieve iSCSI services 7
 - Create an iSCSI service 13
 - Delete an iSCSI service 19
 - Retrieve an iSCSI service 21
 - Update an iSCSI service 26

Manage iSCSI services

Protocols SAN iSCSI services endpoint overview

Overview

An iSCSI service defines the properties of the iSCSI target for an SVM. There can be at most one iSCSI service for an SVM. An SVM's iSCSI service must be created before iSCSI initiators can log in to the SVM.

The iSCSI service REST API allows you to create, update, delete, and discover iSCSI services for SVMs.

Examples

Creating an iSCSI service for an SVM

The simplest way to create an iSCSI service is to specify only the SVM, either by name or UUID. By default, the new iSCSI service is enabled and uses the SVM name as its target alias.

In this example, the `return_records` query parameter is used to retrieve the new iSCSI service object in the REST response.

```

# The API:
POST /api/protocols/san/iscsi/services

# The call:
curl -X POST 'https://<mgmt-
ip>/api/protocols/san/iscsi/services?return_records=true' -H 'accept:
application/hal+json' -d '{ "svm": { "name": "svm1" } }'

# The response:
{
  "num_records": 1,
  "records": [
    {
      "svm": {
        "uuid": "19d04b8e-94d7-11e8-8370-005056b48fd2",
        "name": "svm1",
        "_links": {
          "self": {
            "href": "/api/svm/svms/19d04b8e-94d7-11e8-8370-005056b48fd2"
          }
        }
      },
      "enabled": true,
      "target": {
        "name": "iqn.1992-
08.com.netapp:sn.19d04b8e94d711e88370005056b48fd2:vs.4",
        "alias": "svm1"
      },
      "_links": {
        "self": {
          "href": "/api/protocols/san/iscsi/services/19d04b8e-94d7-11e8-
8370-005056b48fd2"
        }
      }
    }
  ]
}

```

Retrieving the iSCSI services for all SVMs in the cluster

```

# The API:
GET /api/protocols/san/iscsi/services

```

```
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/san/iscsi/services' -H
'accept: application/hal+json'

# The response:
{
"records": [
  {
    "svm": {
      "uuid": "19d04b8e-94d7-11e8-8370-005056b48fd2",
      "name": "svm1",
      "_links": {
        "self": {
          "href": "/api/svm/svms/19d04b8e-94d7-11e8-8370-005056b48fd2"
        }
      }
    },
    "_links": {
      "self": {
        "href": "/api/protocols/san/iscsi/services/19d04b8e-94d7-11e8-8370-005056b48fd2"
      }
    }
  },
  {
    "svm": {
      "uuid": "25f617cf-94d7-11e8-8370-005056b48fd2",
      "name": "svm2",
      "_links": {
        "self": {
          "href": "/api/svm/svms/25f617cf-94d7-11e8-8370-005056b48fd2"
        }
      }
    },
    "_links": {
      "self": {
        "href": "/api/protocols/san/iscsi/services/25f617cf-94d7-11e8-8370-005056b48fd2"
      }
    }
  }
],
"num_records": 2,
"_links": {
  "self": {
    "href": "/api/protocols/san/iscsi/services"
  }
}
```

```
}  
}  
}
```

Retrieving details for a specific iSCSI service

The iSCSI service is identified by the UUID of its SVM.

```
# The API:  
GET /api/protocols/san/iscsi/services/{svm.uuid}  
  
# The call:  
curl -X GET 'https://<mgmt-ip>/api/protocols/san/iscsi/services/19d04b8e-  
94d7-11e8-8370-005056b48fd2' -H 'accept: application/hal+json'  
  
# The response:  
{  
  "svm": {  
    "uuid": "19d04b8e-94d7-11e8-8370-005056b48fd2",  
    "name": "svm1",  
    "_links": {  
      "self": {  
        "href": "/api/svm/svms/19d04b8e-94d7-11e8-8370-005056b48fd2"  
      }  
    }  
  },  
  "enabled": true,  
  "target": {  
    "name": "iqn.1992-  
08.com.netapp:sn.19d04b8e94d711e88370005056b48fd2:vs.4",  
    "alias": "svm1"  
  },  
  "_links": {  
    "self": {  
      "href": "/api/protocols/san/iscsi/services/19d04b8e-94d7-11e8-8370-  
005056b48fd2"  
    }  
  }  
}
```

Disabling an iSCSI service

Disabling an iSCSI service shuts down all active iSCSI sessions for the SVM and prevents the creation of new iSCSI sessions.

The iSCSI service to update is identified by the UUID of its SVM.

```
# The API:
PATCH /api/protocols/san/iscsi/services/{svm.uuid}

# The call:
curl -X PATCH 'https://<mgmt-
ip>/api/protocols/san/iscsi/services/19d04b8e-94d7-11e8-8370-005056b48fd2'
-H 'accept: application/hal+json' -d '{ "enabled": "false" }'
```

You can retrieve the iSCSI service to confirm the change.

In this example, the `fields` query parameter is used to limit the response to the `enabled` property and iSCSI service identifiers.

```

# The API:
GET /api/protocols/san/iscsi/services/{svm.uuid}

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/san/iscsi/services/19d04b8e-94d7-11e8-8370-005056b48fd2?fields=enabled' -H 'accept: application/hal+json'

# The response:
{
  "svm": {
    "uuid": "19d04b8e-94d7-11e8-8370-005056b48fd2",
    "name": "svm1",
    "_links": {
      "self": {
        "href": "/api/svm/svms/19d04b8e-94d7-11e8-8370-005056b48fd2"
      }
    }
  },
  "enabled": false,
  "_links": {
    "self": {
      "href": "/api/protocols/san/iscsi/services/19d04b8e-94d7-11e8-8370-005056b48fd2"
    }
  }
}

```

Deleting an iSCSI service

The iSCSI service must be disabled before it can be deleted.

The iSCSI service to be deleted is identified by the UUID of its SVM.

```

# The API:
DELETE /api/protocols/san/iscsi/services/{svm.uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/protocols/san/iscsi/services/19d04b8e-94d7-11e8-8370-005056b48fd2' -H 'accept: application/hal+json'

```


Retrieve iSCSI services

GET /protocols/san/iscsi/services

Retrieves iSCSI services.

Related ONTAP commands

- `vserver iscsi show`

Learn more

- [DOC /protocols/san/iscsi/services](#)

Parameters

Name	Type	In	Required	Description
enabled	boolean	query	False	Filter by enabled
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
target.name	string	query	False	Filter by target.name
target.alias	string	query	False	Filter by target.alias
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.

Name	Type	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

Status: 200, Ok

Name	Type	Description
_links	_links	
num_records	integer	Number of records.
records	array[iscsi_service]	

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "target": {
        "alias": "svm1",
        "name": "iqn.1992-
08.com.netapp:sn.574caf71890911e8a6b7005056b4ea79:vs.2"
      }
    }
  ]
}
```

Error

Status: Default, Error

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
next	href	
self	href	

_links

Name	Type	Description
self	href	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

target

Name	Type	Description
alias	string	<p>The iSCSI target alias of the iSCSI service.</p> <p>The target alias can contain one (1) to 128 characters and feature any printable character except space (" "). A PATCH request with an empty alias ("") clears the alias.</p> <p>Optional in POST and PATCH. In POST, this defaults to the name of the SVM.</p>

Name	Type	Description
name	string	<p>The iSCSI target name of the iSCSI service. This is generated for the SVM during POST.</p> <p>If required, the target name can be modified using the ONTAP command line.</p> <ul style="list-style-type: none"> example: iqn.1992-08.com.netapp:sn.574caf71890911e8a6b7005056b4ea79:vs.2 maxLength: 128 minLength: 1 readOnly: 1

iscsi_service

An iSCSI service defines the properties of the iSCSI target for an SVM. There can be at most one iSCSI service for an SVM. An SVM's iSCSI service must be created before iSCSI initiators can log in to the SVM.

An iSCSI service is identified by the UUID of its SVM.

Name	Type	Description
_links	_links	
enabled	boolean	<p>The administrative state of the iSCSI service. The iSCSI service can be disabled to block all iSCSI connectivity to the SVM.</p> <p>Optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p>
svm	svm	SVM, applies only to SVM-scoped objects.
target	target	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Create an iSCSI service

POST `/protocols/san/iscsi/services`

Creates an iSCSI service.

Required properties

- `svm.uuid` or `svm.name` - Existing SVM in which to create the iSCSI service.

Related ONTAP commands

- `vserver iscsi create`

Learn more

- [DOC /protocols/san/iscsi/services](#)

Request Body

Name	Type	Description
<code>_links</code>	_links	
<code>enabled</code>	boolean	The administrative state of the iSCSI service. The iSCSI service can be disabled to block all iSCSI connectivity to the SVM. Optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
<code>svm</code>	svm	SVM, applies only to SVM-scoped objects.

Name	Type	Description
target	target	

Example request

```

{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "target": {
    "alias": "svm1",
    "name": "iqn.1992-
08.com.netapp:sn.574caf71890911e8a6b7005056b4ea79:vs.2"
  }
}

```

Response

Status: 201, Created

Name	Type	Description
_links	_links	
num_records	integer	Number of records.
records	array[iscsi_service]	

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": [
    {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "svm": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
      },
      "target": {
        "alias": "svm1",
        "name": "iqn.1992-
08.com.netapp:sn.574caf71890911e8a6b7005056b4ea79:vs.2"
      }
    }
  ]
}
```

Error

Status: Default

ONTAP Error Response Codes

Error Code	Description
1115127	The cluster lacks a valid iSCSI license.
2621462	The supplied SVM does not exist.
2621507	The iSCSI protocol is not allowed for the specified SVM.
2621706	The specified <code>svm.uuid</code> and <code>svm.name</code> do not refer to the same SVM.
2621707	No SVM was specified. Either <code>svm.name</code> or <code>svm.uuid</code> must be supplied.
5374077	An iSCSI service already exists for the specified SVM.
5374893	The SVM is stopped. The SVM must be running to create an iSCSI service.
5373966	An iSCSI service cannot be created in an SVM that is configured for NVMe.

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

target

Name	Type	Description
alias	string	<p>The iSCSI target alias of the iSCSI service.</p> <p>The target alias can contain one (1) to 128 characters and feature any printable character except space (" "). A PATCH request with an empty alias ("") clears the alias.</p> <p>Optional in POST and PATCH. In POST, this defaults to the name of the SVM.</p>

Name	Type	Description
name	string	<p>The iSCSI target name of the iSCSI service. This is generated for the SVM during POST.</p> <p>If required, the target name can be modified using the ONTAP command line.</p> <ul style="list-style-type: none"> example: iqn.1992-08.com.netapp:sn.574caf71890911e8a6b7005056b4ea79:vs.2 maxLength: 128 minLength: 1 readOnly: 1

iscsi_service

An iSCSI service defines the properties of the iSCSI target for an SVM. There can be at most one iSCSI service for an SVM. An SVM's iSCSI service must be created before iSCSI initiators can log in to the SVM.

An iSCSI service is identified by the UUID of its SVM.

Name	Type	Description
_links	_links	
enabled	boolean	<p>The administrative state of the iSCSI service. The iSCSI service can be disabled to block all iSCSI connectivity to the SVM.</p> <p>Optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p>
svm	svm	SVM, applies only to SVM-scoped objects.
target	target	

[_links](#)

Name	Type	Description
next	href	
self	href	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete an iSCSI service

```
DELETE /protocols/san/iscsi/services/{svm.uuid}
```

Deletes an iSCSI service. An iSCSI service must be disabled before it can be deleted.

Related ONTAP commands

- `vserver iscsi delete`

Learn more

- [DOC /protocols/san/iscsi/services](#)

Parameters

Name	Type	In	Required	Description
svm.uuid	string	path	True	

Response

```
Status: 200, Ok
```

Error

Status: Default

ONTAP Error Response Codes

Error Code	Description
2621462	An SVM with the specified UUID does not exist.
5373960	The iSCSI service is enabled. The iSCSI service must be disabled before it can be deleted.
5374078	The SVM does not have an iSCSI service.

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve an iSCSI service

```
GET /protocols/san/iscsi/services/{svm.uuid}
```

Retrieves an iSCSI service.

Related ONTAP commands

- `vserver iscsi show`

Learn more

- [DOC /protocols/san/iscsi/services](#)

Parameters

Name	Type	In	Required	Description
svm.uuid	string	path	True	The unique identifier of the SVM for which to retrieve the iSCSI service.

Name	Type	In	Required	Description
fields	array[string]	query	False	Specify the fields to return.

Response

Status: 200, Ok

Name	Type	Description
_links	_links	
enabled	boolean	<p>The administrative state of the iSCSI service. The iSCSI service can be disabled to block all iSCSI connectivity to the SVM.</p> <p>Optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p>
svm	svm	SVM, applies only to SVM-scoped objects.
target	target	

Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "target": {
    "alias": "svm1",
    "name": "iqn.1992-
08.com.netapp:sn.574caf71890911e8a6b7005056b4ea79:vs.2"
  }
}
```

Error

Status: Default

ONTAP Error Response Codes

Error Code	Description
2621462	An SVM with the specified UUID does not exist.
5374078	The SVM does not have an iSCSI service.

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

target

Name	Type	Description
alias	string	<p>The iSCSI target alias of the iSCSI service.</p> <p>The target alias can contain one (1) to 128 characters and feature any printable character except space (" "). A PATCH request with an empty alias ("") clears the alias.</p> <p>Optional in POST and PATCH. In POST, this defaults to the name of the SVM.</p>

Name	Type	Description
name	string	<p>The iSCSI target name of the iSCSI service. This is generated for the SVM during POST.</p> <p>If required, the target name can be modified using the ONTAP command line.</p> <ul style="list-style-type: none"> example: iqn.1992-08.com.netapp:sn.574caf71890911e8a6b7005056b4ea79:vs.2 maxLength: 128 minLength: 1 readOnly: 1

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update an iSCSI service

PATCH /protocols/san/iscsi/services/{svm.uuid}

Updates an iSCSI service.

Related ONTAP commands

- `vserver iscsi modify`
- `vserver iscsi start`
- `vserver iscsi stop`

Learn more

- [DOC /protocols/san/iscsi/services](#)

Parameters

Name	Type	In	Required	Description
svm.uuid	string	path	True	The unique identifier of the SVM for which to update the iSCSI service.

Request Body

Name	Type	Description
_links	_links	
enabled	boolean	The administrative state of the iSCSI service. The iSCSI service can be disabled to block all iSCSI connectivity to the SVM. Optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
svm	svm	SVM, applies only to SVM-scoped objects.
target	target	

Example request

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "svm": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  },
  "target": {
    "alias": "svm1",
    "name": "iqn.1992-
08.com.netapp:sn.574caf71890911e8a6b7005056b4ea79:vs.2"
  }
}
```

Response

Status: 200, Ok

Error

Status: Default

ONTAP Error Response Codes

Error Code	Description
2621462	An SVM with the specified UUID does not exist.
5374078	The SVM does not have an iSCSI service.

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

svm

SVM, applies only to SVM-scoped objects.

Name	Type	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

target

Name	Type	Description
alias	string	<p>The iSCSI target alias of the iSCSI service.</p> <p>The target alias can contain one (1) to 128 characters and feature any printable character except space (" "). A PATCH request with an empty alias ("") clears the alias.</p> <p>Optional in POST and PATCH. In POST, this defaults to the name of the SVM.</p>

Name	Type	Description
name	string	<p>The iSCSI target name of the iSCSI service. This is generated for the SVM during POST.</p> <p>If required, the target name can be modified using the ONTAP command line.</p> <ul style="list-style-type: none"> • example: iqn.1992-08.com.netapp:sn.574caf71890911e8a6b7005056b4ea79:vs.2 • maxLength: 128 • minLength: 1 • readOnly: 1

iscsi_service

An iSCSI service defines the properties of the iSCSI target for an SVM. There can be at most one iSCSI service for an SVM. An SVM's iSCSI service must be created before iSCSI initiators can log in to the SVM.

An iSCSI service is identified by the UUID of its SVM.

Name	Type	Description
_links	_links	
enabled	boolean	<p>The administrative state of the iSCSI service. The iSCSI service can be disabled to block all iSCSI connectivity to the SVM.</p> <p>Optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.</p>
svm	svm	SVM, applies only to SVM-scoped objects.
target	target	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.