



# **Retrieve cluster chassis**

## **ONTAP 9.6 REST API reference**

NetApp  
April 02, 2024

# Table of Contents

- Retrieve cluster chassis ..... 1
  - Cluster chassis endpoint overview ..... 1
  - Retrieve a collection of chassis ..... 3
  - Retrieve a chassis ..... 8

# Retrieve cluster chassis

## Cluster chassis endpoint overview

### Retrieving chassis information

The chassis GET API retrieves all of the chassis information in the cluster.

---

### Examples

#### 1) Retrieve a list of chassis from the cluster

The following example shows the response with a list of chassis in the cluster:

---

```
# The API:
/api/cluster/chassis

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/chassis" -H "accept:
application/hal+json"

# The response:
{
  "records": [
    {
      "id": "021352005981",
      "_links": {
        "self": {
          "href": "/api/cluster/chassis/021352005981"
        }
      }
    },
  ],
  "num_records": 1,
  "_links": {
    "self": {
      "href": "/api/cluster/chassis"
    }
  }
}
```

---

## 2) Retrieve a specific chassis from the cluster

The following example shows the response of the requested chassis. If there is no chassis with the requested id, an error is returned.

```
# The API:
/api/cluster/chassis/{id}

# The call:
curl -X GET "https://<mgmt-ip>/api/cluster/chassis/021352005981" -H
"accept: application/hal+json"

# The response:
{
  "id": "021352005981",
  "state": "ok",
  "nodes": [
    {
      "name": "node-1",
      "uuid": "6ede364b-c3d0-11e8-a86a-00a098567f31",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/6ede364b-c3d0-11e8-a86a-00a098567f31"
        }
      }
    }
  ],
  "frus": [
    {
      "id": "PSU2",
      "type": "psu",
      "state": "ok"
    },
    {
      "id": "PSU1",
      "type": "psu",
      "state": "ok"
    },
    {
      "id": "Fan2",
      "type": "fan",
      "state": "ok"
    },
    {
      "id": "Fan3",
```

```

    "type": "fan",
    "state": "ok"
  },
  {
    "id": "Fan1",
    "type": "fan",
    "state": "ok"
  }
],
"_links": {
  "self": {
    "href": "/api/cluster/chassis/021352005981"
  }
}
}
}

```

## Retrieve a collection of chassis

GET /cluster/chassis

Retrieves a collection of chassis.

### Related ONTAP commands

- `system chassis show`
- `system chassis fru show`

### Learn more

- [DOC /cluster/chassis](#)

### Parameters

Name	Type	In	Required	Description
frus.type	string	query	False	Filter by frus.type
frus.state	string	query	False	Filter by frus.state
frus.id	string	query	False	Filter by frus.id
nodes.name	string	query	False	Filter by nodes.name

Name	Type	In	Required	Description
nodes.uuid	string	query	False	Filter by nodes.uuid
state	string	query	False	Filter by state
shelves.uuid	string	query	False	Filter by shelves.uuid
id	string	query	False	Filter by id
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">_links</a>	

Name	Type	Description
num_records	integer	Number of records
records	array[chassis]	

### Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "frus": {
      "state": "ok",
      "type": "fan"
    },
    "id": "021352005981",
    "nodes": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "shelves": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "uid": 7777841915827391056
    },
    "state": "ok"
  }
}
```

## Error

Status: Default, Error

Name	Type	Description
error	error	

### Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions



## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

frus

Name	Type	Description
id	string	
state	string	
type	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

nodes

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

shelf\_reference

Shelf

Name	Type	Description
_links	<a href="#">_links</a>	
uid	string	

chassis

Name	Type	Description
frus	array[frus]	List of frus in chassis
id	string	
nodes	array[nodes]	List of nodes in chassis
shelves	array[shelf_reference]	List of shelves in chassis
state	string	

#### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Retrieve a chassis

GET /cluster/chassis/{id}

Retrieves a specific chassis.

### Related ONTAP commands

- `system chassis show`
- `system chassis fru show`

### Learn more

- [DOC /cluster/chassis](#)

## Parameters

Name	Type	In	Required	Description
id	string	path	True	Chassis ID
fields	array[string]	query	False	Specify the fields to return.

## Response

Status: 200, Ok

Name	Type	Description
frus	array[frus]	List of frus in chassis
id	string	
nodes	array[nodes]	List of nodes in chassis
shelves	array[shelf_reference]	List of shelves in chassis
state	string	

## Example response

```
{
  "frus": {
    "state": "ok",
    "type": "fan"
  },
  "id": "021352005981",
  "nodes": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "shelves": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "uid": 7777841915827391056
  },
  "state": "ok"
}
```

## Error

Status: Default, Error

Name	Type	Description
error	error	

## Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

frus

Name	Type	Description
id	string	
state	string	
type	string	

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
self	<a href="#">href</a>	

nodes

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

shelf\_reference

Shelf

Name	Type	Description
_links	<a href="#">_links</a>	
uid	string	

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

<b>Name</b>	<b>Type</b>	<b>Description</b>
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.