



View and update MetroCluster interconnects

ONTAP 9.8 REST API reference

NetApp
April 02, 2024

Table of Contents

- View and update MetroCluster interconnects 1
 - Cluster MetroCluster interconnects endpoint overview 1
 - Retrieve interconnect adapter information for nodes in MetroCluster 7
 - Retrieve information about a MetroCluster interconnect for a partner type and adapter 13

View and update MetroCluster interconnects

Cluster MetroCluster interconnects endpoint overview

Overview

You can use this API to retrieve and display relevant information pertaining to MetroCluster interconnect status. The `/cluster/metrocluster/interconnects` endpoint returns a list of all the interconnects in MetroCluster and their status. Each individual interconnect can be queried individually using the `/cluster/metrocluster/interconnects/{node.uuid}/{partner_type}/{adapter}` endpoint.

Examples

Retrieving MetroCluster interconnects

```
GET https://<mgmt-ip>/api/cluster/metrocluster/interconnects
{
  "records": [
    {
      "node": {
        "name": "cluster1_01",
        "uuid": "6fead8fe-8d81-11e9-b5a9-005056826931",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/6fead8fe-8d81-11e9-b5a9-005056826931"
          }
        }
      },
      "partner_type": "ha",
      "adapter": "e0f",
      "_links": {
        "self": {
          "href": "/api/cluster/metrocluster/interconnects/6fead8fe-8d81-11e9-b5a9-005056826931/ha/e0f"
        }
      }
    },
    {
      "node": {
        "name": "cluster1_01",
        "uuid": "6fead8fe-8d81-11e9-b5a9-005056826931",
        "_links": {
```

```

        "self": {
            "href": "/api/cluster/nodes/6fead8fe-8d81-11e9-b5a9-005056826931"
        }
    },
    "partner_type": "ha",
    "adapter": "e0g",
    "_links": {
        "self": {
            "href":
"/api/cluster/metrocluster/interconnects/6fead8fe-8d81-11e9-b5a9-005056826931/ha/e0g"
        }
    }
},
{
    "node": {
        "name": "cluster1_01",
        "uuid": "6fead8fe-8d81-11e9-b5a9-005056826931",
        "_links": {
            "self": {
                "href": "/api/cluster/nodes/6fead8fe-8d81-11e9-b5a9-005056826931"
            }
        }
    },
    "partner_type": "dr",
    "adapter": "e0f",
    "_links": {
        "self": {
            "href":
"/api/cluster/metrocluster/interconnects/6fead8fe-8d81-11e9-b5a9-005056826931/dr/e0f"
        }
    }
},
{
    "node": {
        "name": "cluster1_01",
        "uuid": "6fead8fe-8d81-11e9-b5a9-005056826931",
        "_links": {
            "self": {
                "href": "/api/cluster/nodes/6fead8fe-8d81-11e9-b5a9-005056826931"
            }
        }
    }
}

```

```

    }
  },
  "partner_type": "dr",
  "adapter": "e0g",
  "_links": {
    "self": {
      "href":
"/api/cluster/metrocluster/interconnects/6fead8fe-8d81-11e9-b5a9-
005056826931/dr/e0g"
    }
  }
},
{
  "node": {
    "name": "cluster1_01",
    "uuid": "6fead8fe-8d81-11e9-b5a9-005056826931",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/6fead8fe-8d81-11e9-b5a9-
005056826931"
      }
    }
  },
  "partner_type": "aux",
  "adapter": "e0f",
  "_links": {
    "self": {
      "href":
"/api/cluster/metrocluster/interconnects/6fead8fe-8d81-11e9-b5a9-
005056826931/aux/e0f"
    }
  }
},
{
  "node": {
    "name": "cluster1_01",
    "uuid": "6fead8fe-8d81-11e9-b5a9-005056826931",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/6fead8fe-8d81-11e9-b5a9-
005056826931"
      }
    }
  },
  "partner_type": "aux",
  "adapter": "e0g",

```

```

    "_links": {
      "self": {
        "href":
"/api/cluster/metrocluster/interconnects/6fead8fe-8d81-11e9-b5a9-
005056826931/aux/e0g"
      }
    },
    {
      "node": {
        "name": "cluster1_02",
        "uuid": "f5435191-8d81-11e9-9d4b-00505682dc8b",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/f5435191-8d81-11e9-9d4b-
00505682dc8b"
          }
        }
      },
      "partner_type": "ha",
      "adapter": "e0f",
      "_links": {
        "self": {
          "href":
"/api/cluster/metrocluster/interconnects/f5435191-8d81-11e9-9d4b-
00505682dc8b/ha/e0f"
        }
      }
    },
    {
      "node": {
        "name": "cluster1_02",
        "uuid": "f5435191-8d81-11e9-9d4b-00505682dc8b",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/f5435191-8d81-11e9-9d4b-
00505682dc8b"
          }
        }
      },
      "partner_type": "ha",
      "adapter": "e0g",
      "_links": {
        "self": {
          "href":
"/api/cluster/metrocluster/interconnects/f5435191-8d81-11e9-9d4b-

```

```

00505682dc8b/ha/e0g"
    }
  },
  {
    "node": {
      "name": "cluster1_02",
      "uuid": "f5435191-8d81-11e9-9d4b-00505682dc8b",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/f5435191-8d81-11e9-9d4b-
00505682dc8b"
        }
      }
    },
    "partner_type": "dr",
    "adapter": "e0f",
    "_links": {
      "self": {
        "href":
"/api/cluster/metrocluster/interconnects/f5435191-8d81-11e9-9d4b-
00505682dc8b/dr/e0f"
      }
    }
  },
  {
    "node": {
      "name": "cluster1_02",
      "uuid": "f5435191-8d81-11e9-9d4b-00505682dc8b",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/f5435191-8d81-11e9-9d4b-
00505682dc8b"
        }
      }
    },
    "partner_type": "dr",
    "adapter": "e0g",
    "_links": {
      "self": {
        "href":
"/api/cluster/metrocluster/interconnects/f5435191-8d81-11e9-9d4b-
00505682dc8b/dr/e0g"
      }
    }
  },

```

```

    {
      "node": {
        "name": "cluster1_02",
        "uuid": "f5435191-8d81-11e9-9d4b-00505682dc8b",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/f5435191-8d81-11e9-9d4b-
00505682dc8b"
          }
        }
      },
      "partner_type": "aux",
      "adapter": "e0f",
      "_links": {
        "self": {
          "href":
"/api/cluster/metrocluster/interconnects/f5435191-8d81-11e9-9d4b-
00505682dc8b/aux/e0f"
        }
      }
    },
    {
      "node": {
        "name": "cluster1_02",
        "uuid": "f5435191-8d81-11e9-9d4b-00505682dc8b",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/f5435191-8d81-11e9-9d4b-
00505682dc8b"
          }
        }
      },
      "partner_type": "aux",
      "adapter": "e0g",
      "_links": {
        "self": {
          "href":
"/api/cluster/metrocluster/interconnects/f5435191-8d81-11e9-9d4b-
00505682dc8b/aux/e0g"
        }
      }
    }
  ],
  "num_records": 12,
  "_links": {
    "self": {

```



```
        "href": "/api/cluster/metrocluster/interconnects"
    }
}
}
```

Retrieves information about a specific MetroCluster interconnect

```
https://<mgmt-ip>/api/cluster/metrocluster/interconnects/774b4fbc-86f9-11e9-9051-005056825c71/aux/e0f
{
  "node": {
    "name": "cluster1_01",
    "uuid": "46147363-9857-11e9-9a55-005056828eb9",
    "_links": {
      "self": {
        "href": "/api/cluster/nodes/46147363-9857-11e9-9a55-005056828eb9"
      }
    }
  },
  "partner_type": "ha",
  "adapter": "e0f",
  "state": "up",
  "type": "iwarp",
  "_links": {
    "self": {
      "href": "/api/cluster/metrocluster/interconnects/46147363-9857-11e9-9a55-005056828eb9/ha/e0f"
    }
  }
}
```

Retrieve interconnect adapter information for nodes in MetroCluster

GET /cluster/metrocluster/interconnects

Introduced In: 9.8

Retrieves a list of interconnect adapter information for nodes in the MetroCluster.

Related ONTAP Commands

- metrocluster interconnect show

Learn more

- [DOC /cluster/metrocluster/interconnects](#)

Parameters

Name	Type	In	Required	Description
node.name	string	query	False	Filter by node.name
node.uuid	string	query	False	Filter by node.uuid
partner_type	string	query	False	Filter by partner_type
adapter	string	query	False	Filter by adapter
state	string	query	False	Filter by state
type	string	query	False	Filter by type
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. <ul style="list-style-type: none">• Default value: 1

Name	Type	In	Required	Description
return_timeout	integer	query	False	<p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> • Default value: 1 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

Status: 200, Ok

Name	Type	Description
_links	collection_links	
num_records	integer	Number of Records
records	array[metrocluster_interconnect]	

Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "adapter": "string",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "partner_type": "aux",
    "state": "down",
    "type": "roce"
  }
}
```

Error

Status: Default

ONTAP Error Response Codes

Error Code	Description
2425734	An internal error occurred. Wait a few minutes, and try the operation again. For further assistance, contact technical support.

Error Code	Description
2427132	MetroCluster is not configured on this cluster.

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

collection_links

Name	Type	Description
next	href	
self	href	

self_link

Name	Type	Description
self	href	

_links

Name	Type	Description
self	href	

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

metrocluster_interconnect

Data for a MetroCluster interconnect. REST: `/api/cluster/metrocluster/interconnects`

Name	Type	Description
_links	self_link	
adapter	string	Adapter
node	node	
partner_type	string	Partner type
state	string	Adapter status

Name	Type	Description
type	string	Adapter type

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve information about a MetroCluster interconnect for a partner type and adapter

GET /cluster/metrocluster/interconnects/{node.uuid}/{partner_type}/{adapter}

Introduced In: 9.8

Retrieves information about a MetroCluster Interconnect for a specific partner type and adapter.

Related ONTAP Commands

- `metrocluster interconnect show`

Parameters

Name	Type	In	Required	Description
node.uuid	string	path	True	Node UUID
partner_type	string	path	True	DR Partner type

Name	Type	In	Required	Description
adapter	string	path	True	Interconnect adapter.
fields	array[string]	query	False	Specify the fields to return.

Response

Status: 200, Ok

Name	Type	Description
_links	self_link	
adapter	string	Adapter
node	node	
partner_type	string	Partner type
state	string	Adapter status
type	string	Adapter type

Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "adapter": "string",
  "node": {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "partner_type": "aux",
  "state": "down",
  "type": "roce"
}
```

Error

Status: Default

ONTAP Error Response Codes

Error Code	Description
2425734	An internal error occurred. Wait a few minutes, and try the operation again. For further assistance, contact technical support.
2427132	MetroCluster is not configured on this cluster.

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
      "code": "string",
      "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

self_link

Name	Type	Description
self	href	

_links

Name	Type	Description
self	href	

node

Name	Type	Description
_links	_links	
name	string	
uuid	string	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.