



应用 RCF 文件并重新交换机布 ONTAP MetroCluster

Ivana Devine, Martin Houser, Megan Bock, Thom Illingworth
August 31, 2021



□用 RCF 文件并重新□交□机布□..... 1

用 RCF 文件并重新交换机布

必用 RCF 文件来重新配置分区以容新点。

1. 到用于的配置的 RCF 文件。
于八点配置，必使用与的交换机型号匹配的 RCF 文件。
2. 按照下面上的明用 RCF 文件，并根据需要整 ISL 置。
3. 保已保存交换机配置。
4. 重新 FC 交换机。
5. 使用先前建的布布局，使用将原有的和新的 FC-SAS 网接到 FC 交换机。

FC 交换机端口使用情况必与 _Fabric-Attached MetroCluster 安装和配置指南_ 中所述的 MetroCluster 八点使用情况匹配，才能使用参考配置文件（ Reference Configuration Files ， RCF ）。

"光接的 MetroCluster 安装和配置"



如果的境无法使用 RCF 文件行布，系技支持。如果布无法使用 RCF 文件，勿使用此操作。

6. 使用用于的交换机的正命令端口是否机。

交换机供商	命令
Brocade	switchshow
Cisco	示接口介

7. 使用先前建的布布局，有控制器和新控制器中的 FC-VI 端口布。

"光接的 MetroCluster 安装和配置"

FC 交换机端口使用情况必与 _Fabric-Attached MetroCluster 安装和配置指南_ 中所述的 MetroCluster 八点使用情况匹配，才能使用参考配置文件（ Reference Configuration Files ， RCF ）。



如果的境无法使用 RCF 文件行布，系技支持。如果布无法使用 RCF 文件，勿使用此操作。

8. 从有点中， FC-VI 端口是否机：

MetroCluster 互配器 show

MetroCluster 互像示

9. 当前控制器和新控制器中的 HBA 端口布。

10. 在有控制器模上，用接到正在的交换机网的端口：

```
storage port enable -node node-name -port port-ID
```

11. 新控制器并将其至模式：

```
boot_ontap maint
```

12. 新控制器模是否只能看到新 DR 要使用的存。

其他 DR 使用的任何存都不可。

13. 返回到此程的，第二个交换机网重新布。

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.