

### Script command structure

SANtricity commands

NetApp August 29, 2024

This PDF was generated from https://docs.netapp.com/us-en/e-series-cli/get-started/structure-of-a-script-command.html on August 29, 2024. Always check docs.netapp.com for the latest.

# **Table of Contents**

Script command structure	
Structure of a script command	
Synopsis of the script commands	
Recurring syntax elements.	

## Script command structure

#### Structure of a script command

All script commands have the following structure:

```
*command operand-data* (*statement-data*)
```

- command identifies the action to be performed.
- operand-data represents the objects associated with a storage array that you want to configure or manage.
- statement-data provides the information needed to perform the command.

The syntax for *operand-data* has the following structure:

```
(*object-type* | all *object-types* | [*qualifier*] (*object-type*
[*identifier*] (*object-type* [*identifier*] | *object-types*
[*identifier-list*])))
```

An object can be identified in four ways:

- Object type Use when the command is not referencing a specific object.
- **all** parameter prefix Use when the command is referencing all of the objects of the specified type in the storage array (for example, **allVolumes**).
- Square brackets Use when performing a command on a specific object to identify the object (for example, **volume** [engineering]).
- A list of identifiers Use to specify a subset of objects. Enclose the object identifiers in square brackets (for example, **volumes** [sales engineering marketing]).

A qualifier is required if you want to include additional information to describe the objects.

The object type and the identifiers that are associated with each object type are listed in this table.

Object Type	Identifier
controller	a or b
drive	For enclosures with drawers, use tray ID, drawer ID, and slot ID. Alternatively, just tray ID and slot ID.
replacementDrive	For enclosures with drawers, use tray ID, drawer ID, and slot ID. Alternatively, just tray ID and slot ID.
driveChannel	Drive channel identifier

Object Type	Identifier
host	User label
hostChannel	Host channel identifier
hostGroup	User label
hostPort	User label
iscsiInitiator	User label or iSCSI Qualified Name (IQN)
iscsiTarget	User label or IQN
storageArray	Not applicable
tray	Tray ID
volume	Volume user label or volume World Wide Identifier (WWID) (set command only)
volumeCopy	Target volume user label and, optionally, the source volume user label
volumeGroup	User label Valid characters are alphanumeric, a hyphen, and an underscore.

Statement data is in the form of:

- Parameter = value (such as **raidLevel=5**)
- Parameter-name (such as **batteryInstallDate**)
- Operation-name (such as redundancyCheck)

A user-defined entry (such as user label) is called a variable. In the syntax, it is shown in italic (such as trayID or volumeGroupName).

#### Synopsis of the script commands

Because you can use the script commands to define and manage the different aspects of a storage array (such as host topology, drive configuration, controller configuration, volume definitions, and volume group definitions), the actual number of commands is extensive. The commands, however, fall into general categories that are reused when you apply the commands to configure or maintain a storage array. The following table lists the general form of the script commands and a definition of each command.

Syntax	Description
accept object {statement-data}	Performs the pending operation.
activate object {statement-data}	Sets up the environment so that an operation can take place or performs the operation if the environment is already set up correctly.
autoConfigure storageArray {statement-data}	Automatically creates a configuration that is based on the parameters that are specified in the command.
check object {statement-data}	Starts an operation to report on errors in the object, which is a synchronous operation.
clear object {statement-data}	Discards the contents of some attributes of an object. This operation is destructive and cannot be reversed.
create object {statement-data}	Creates an object of the specified type.
deactivate object {statement-data}	Removes the environment for an operation.
delete object	Deletes a previously created object.
diagnose object {statement-data}	Runs a test and shows the results.
disable object {statement-data}	Prevents a feature from operating.

Syntax	Description
download object {statement-data}	Transfers data to the storage array or to the hardware that is associated with the storage array.
enable object {statement-data}	Sets a feature to operate.
<pre>load object {statement-data}</pre>	Transfers data to the storage array or to the hardware that is associated with the storage array. This command is functionally similar to the download command.
recopy object {statement-data}	Restarts a volume copy operation by using an existing volume copy pair. You can change the parameters before the operation is restarted.
recover object {statement-data}	Re-creates an object from saved configuration data and the statement parameters. (This command is similar to the create command.)
remove object {statement-data}	Removes a relationship between objects.
repair object {statement-data}	Repairs errors found by the check command.
replace object {statement-data}	The specified object replaces an existing object in the storage array.
reset object {statement-data}	Returns the hardware or an object to an initial state.

Syntax	Description
resume object	Starts a suspended operation. The operation starts where it left off when it was suspended.
revive object	Forces the object from the Failed state to the Optimal state. Use this command only as part of an error recovery procedure.
save object {statement-data}	Writes information about the object to a file.
set object {statement-data}	Changes object attributes. All changes are completed when the command returns.
show object {statement-data}	Shows information about the object.
<pre>start object {statement-data}</pre>	Starts an asynchronous operation. You can stop some operations after they have started. You can query the progress of some operations.
stop object {statement-data}	Stops an asynchronous operation.
suspend object {statement-data}	Stops an operation. You can then restart the suspended operation, and it continues from the point where it was suspended.
validate object {statement-data}	Validates a security key.

### **Recurring syntax elements**

Recurring syntax elements are a general category of parameters and options that you can use in the script commands. The following table lists the conventions used in the recurring syntax elements.

Convention	Definition
a   b	Alternative ("a" or "b")
italicized-words	Needs user input to fulfill a parameter (a response to a variable)
[ ] (square brackets)	Zero or one occurrence (square brackets are also used as a delimiter for some command parameters)
{ } (curly braces)	Zero or more occurrences
( <b>a   b   c</b> )	Choose only one of the alternatives

The following table lists the recurring syntax parameters and the values that you can use with the recurring syntax parameters.

Recurring Syntax	Syntax Value
autoconfigure-vols-attr- value-list	autoconfigure-vols-attr-value-pair {autoconfigure-vols-attr-value-pair}
autoconfigure-vols-attr- value-pair	<pre>driveType=drive-type   driveMediaType=drive-media-type   raidLevel=raid-level   volumeGroupWidth=integer-literal   volumeGroupCount=integer-literal   volumesPerGroupCount=integer- literal6  hotSpareCount=integer-literal   segmentSize=segment-size-spec   cacheReadPrefetch=(TRUE   FALSE) securityType=(none   capable   enabled)7  dataAssurance=(none   enabled)5</pre>
boolean	(TRUE   FALSE)
cache-flush-modifier- setting	<pre>immediate, 0, .25, .5, .75, 1, 1.5, 2, 5, 10, 20, 60, 120, 300, 1200, 3600, infinite</pre>

Recurring Syntax	Syntax Value
capacity-spec	<i>integer-literal</i> [KB   MB   GB   TB   Bytes]
count-based-repository- spec	<pre>repositoryRAIDLevel =repository- raid-level repositoryDriveCount=integer- literal [repositoryVolumeGroupUserLabel =user-label] [driveType=drive- type4 ] [trayLossProtect=(TRUE   FALSE)1]   [drawerLossProtect=(TRUE   FALSE)2]   [dataAssurance=(none   enabled)5]  </pre>
create-raid-vol-attr- value-list	<pre>create-raid-volume-attribute-value-pair {create-raid-volume-attribute-value- pair}</pre>
create-raid-volume- attribute-value- pair	<pre>capacity=capacity-spec   owner=(a   b)   cacheReadPrefetch=(TRUE   FALSE)   segmentSize=integer-literal   usageHint=usage-hint-spec</pre>
create-volume-copy-attr- value-list	create-volume-copy-attr-value-pair {create-volume-copy-attr-value-pair}
create-volume-copy-attr- value-pair	<pre>copyPriority=(highest   high   medium   low   lowest)   targetReadOnlyEnabled=(TRUE   FALSE)   copyType=(offline   online)   repositoryPercentOfBase=(20   40   60   120   default)   repositoryGroupPreference=(sameAsS ource   otherThanSource   default)</pre>

Recurring Syntax	Syntax Value
drive-media-type	(HDD   SSD   unknown   allMedia) <i>HDD</i> means hard disk drive. <i>SSD</i> means solid state disk.
drive-spec	<i>trayID</i> , <i>slotID</i> or trayID, drawerID, slotID A drive is defined as two or three integer literal values separated by a comma. Low-density trays require two values. High-density trays, those trays that have drawers, require three values.
drive-spec-list	drive-spec drive-spec
drive-type	(fibre   SATA   SAS) Only SAS drives are supported for firmware versions 7.86 and later.
error-action	(stop   continue)
ethernet-port-options	<pre>enableIPv4=(TRUE   FALSE)   enableIPv6=(TRUE   FALSE)   IPv6LocalAddress=ipv6-address   IPv6RoutableAddress=ipv6-address   IPv6RouterAddress=ipv6-address   IPv4Address=ip-address   IPv4ConfigurationMethod= (static   dhcp)   IPv4GatewayIP=ip-address   IPv4SubnetMask=ip-address   duplexMode=(TRUE   FALSE)   portSpeed=(autoNegotiate   10   100   1000)</pre>
feature-identifier	All features in SANtricity 11.40 are enabled by default.
filename	string-literal
gid	string-literal
hex-literal	A literal in the range of 0x00 - 0xFF.

Recurring Syntax	Syntax Value
host-card-identifier	(1   2   3   4)
host-type	string-literal integer-literal
instance-based- repository-spec	<pre>(repositoryRAIDLevel =repository- raid-level repositoryDrives= (drive-spec-list) [repositoryVolumeGroupUserLabel =user-label] [trayLossProtect=(TRUE   FALSE)1])   [drawerLossProtect=(TRUE   FALSE)2])   (repositoryVolumeGroup=user-label [freeCapacityArea=integer- literal3])</pre> Specify the repositoryRAIDLevel parameter with the repositoryDrives parameter. Do not specify the RAID level or the drives with the volume group. Do not set a value for the trayLossProtect parameter when you specify a volume group.
ip-address	(0-255).(0-255).(0-255).(0-255)
ipv6-address	(0-FFFF) : (0-FFFF) : (0-FFFF) : (0-FFFF) : (0-FFFF) : (0-FFFF) : (0-FFFF) : (0-FFFF) You must enter all 32 hexadecimal characters.
iscsi-host-port	(1   2   3   4) The host port number might be 2, 3, or 4 depending on the type of controller you are using.

Recurring Syntax	Syntax Value
iscsi-host-port-options	<pre>IPv4Address=ip-address   IPv6LocalAddress=ipv6-address   IPv6RoutableAddress=ipv6-address   enableIPv4=(TRUE   FALSE)   enableIPv6=(TRUE   FALSE)   enableIPv6Priority=(TRUE   FALSE)   enableIPv6Priority=(TRUE   FALSE)   enableIPv6Priority=(TRUE   FALSE)   IPv4ConfigurationMethod=(static   auto)   IPv4GatewayIP=ip-address   IPv6HopLimit=integer   IPv6NdDetectDuplicateAddress=integ er   IPv6NdRetransmitTime=time- interval   IPv4SubnetMask=ip-address   IPv4VlanId=integer   IPv6VlanId=integer   tcpListeningPort=tcp-port-id   portSpeed=(autoNegotiate   1   10)</pre>
iscsiSession	[session-identifier]
nvsram-offset	hex-literal
nvsramBitSetting	<pre>nvsram-mask, nvsram-value = 0xhexadecimal, 0xhexadecimal   integer- literal The 0xhexadecimal value is typically a value from 0x00 to 0xFF.</pre>

Recurring Syntax	Syntax Value
nvsramByteSetting	<pre>nvsram-value = 0xhexadecimal   integer- literal The 0xhexadecimal value is typically a value from 0x00 to 0xFF.</pre>
portID	(0-127)
raid-level	(0   1   3   5   6)
recover-raid-volume-attr- value-list	recover-raid-volume-attr-value-pair {recover-raid-volume-attr-value-pair}
recover-raid-volume-attr- value-pair	owner=(a b)  cacheReadPrefetch=(TRUE   FALSE)   dataAssurance=(none   enabled)
repository-raid-level	(1   3   5   6)
repository-spec	instance-based-repository-spec count- based-repository-spec
segment-size-spec	integer-literal - all capacities are in base-2.
serial-number	string-literal

Recurring Syntax	Syntax Value	
slotID	For high-capacity drive trays, specify the tray ID value, the drawer ID value, and the slot ID value for the drive. For low-capacity drive trays, specify the tray ID value and the slot ID value for the drive. Tray ID values are 0 to 99. Drawer ID values are 1 to 5.	
	All slot ID maximums are 24. Slot ID values either begin at 0 or 1, depending on the tray model.	
	Enclose the tray ID value, the drawer ID value, and the slot ID value in square brackets ([]).	
	<pre>(drive=\(trayID,[drawerID,]slotID\ )  drives=\(trayID1,[drawerID1,]slotI D1 trayIDn,[drawerIDn,]slotIDn\) )</pre>	
test-devices	<pre>controller=(a b) esms=(esm-spec-list)drives=(drive- spec-list)</pre>	
test-devices-list	test-devices{test-devices}	
time-zone-spec	(GMT+HH:MM   GMT-HH:MM) [dayLightSaving=HH:MM]	
trayID-list	trayID{trayID}	
usage-hint-spec	usageHint=(multiMedia   database   fileSystem)	
	The usage hint, or expected I/O characteristics, of the volume are used by the controller to indicate an appropriate default volume segment size and dynamic cache read prefetch. For file system and database, a 128 KB segment size is used. For multimedia, a 256 KB segment size is used. All three usage hints enable dynamic cache read prefetch.	

Recurring Syntax	Syntax Value
user-label	<i>string-literal</i> Valid characters are alphanumeric, the dash, and the underscore.
user-label-list	user-label {user-label}
volumeGroup-number	integer-literal
wwID	string-literal

1For tray loss protection to work, your configuration must adhere to the following guidelines:

Level	Criteria for Tray Loss Protection	Minimum number of trays required
Disk Pool	The disk pool contains no more than two drives in a single tray.	6
RAID 6	The volume group contains no more than two drives in a single tray.	3
RAID 3 or RAID 5	Each drive in the volume group is located in a separate tray.	3
RAID 1	Each drive in a RAID 1 pair must be located in a separate tray.	2
RAID 0	Cannot achieve Tray Loss Protection.	Not applicable

2For drawer loss protection to work, your configuration must adhere to the following guidelines:

Level	Criteria for drawer loss protection	Minimum number of drawers required
Disk Pool	The pool includes drives from all five drawers and there are an equal number of drives in each drawer. A 60-drive tray can achieve Drawer Loss Protection when the disk pool contains 15, 20, 25, 30, 35, 40, 45, 50, 55, or 60 drives.	5

Level	Criteria for drawer loss protection	Minimum number of drawers required
RAID 6	The volume group contains no more than two drives in a single drawer.	3
RAID 3 or RAID 5	Each drive in the volume group is located in a separate drawer.	3
RAID 1	Each drive in a mirrored pair must be located in a separate drawer.	2
RAID 0	Cannot achieve Drawer Loss Protection.	Not applicable

If you have a storage array configuration in which a volume group spans several trays, you must make sure that the setting for drawer loss protection works with the setting for tray loss protection. You can have drawer loss protection without tray loss protection. You cannot have tray loss protection without drawer loss protection. If the trayLossProtect parameter and the drawerLossProtect parameter are not set to the same value, the storage array returns an error message and a storage array configuration will not be created.

3 To determine if a free capacity area exists, run the show volumeGroup command.

4 The default drive (drive type) is SAS.

The **driveType** parameter is not required if only one type of drive is in the storage array. If you use the **driveType** parameter, you also must use the **hotSpareCount** parameter and the **volumeGroupWidth** parameter.

5 The **dataAssurance** parameter relates to the Data Assurance (DA) feature.

The Data Assurance (DA) feature increases data integrity across the entire storage system. DA enables the storage array to check for errors that might occur when data is moved between the hosts and the drives. When this feature is enabled, the storage array appends error-checking codes (also known as cyclic redundancy checks or CRCs) to each block of data in the volume. After a data block is moved, the storage array uses these CRC codes to determine if any errors occurred during transmission. Potentially corrupted data is neither written to disk nor returned to the host.

If you want to use the DA feature, start with a pool or volume group that includes only drives that support DA. Then, create DA-capable volumes. Finally, map these DA-capable volumes to the host using an I/O interface that is capable of DA. I/O interfaces that are capable of DA include Fibre Channel, SAS, and iSER over InfiniBand (iSCSI Extensions for RDMA/IB). DA is not supported by iSCSI over Ethernet, or by the SRP over InfiniBand.



When all the required hardware and the I/O interface is DA-capable, you can set the **dataAssurance** parameter to enabled and then use DA with certain operations. For example, you can create a volume group that includes DA-capable drives, and then create a volume within that volume group that is DA-enabled. Other operations that use a DA-enabled volume have options to support the DA feature.

6 The **volumesPerGroupCount** parameter is the number of equal-capacity volumes per volume group.

7 The **securityType** parameter enables you to specify the security setting for a volume group that you are creating. All of the volumes are also set to the security setting that you choose. Available options for setting the security setting include:

- none The volume group is not secure.
- capable The volume group is security capable, but security has not been enabled.
- enabled The volume group is security enabled.



A storage array security key must already be created for the storage array if you want to set **securityType=enabled**. (To create a storage array security key, use the create storageArray securityKey command.)

#### **Copyright information**

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

#### **Trademark information**

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.