

Upgrade, refresh, or expand the MetroCluster configuration

ONTAP MetroCluster

NetApp April 25, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontapmetrocluster/upgrade/concept_choosing_an_upgrade_method_mcc.html on April 25, 2024. Always check docs.netapp.com for the latest.

Table of Contents

Upgrade, refresh, or expand the MetroCluster configuration
Start here - Choose your procedure
Upgrade controllers in a four-node MetroCluster IP configuration using switchover and switchback with
"system controller replace" commands (ONTAP 9.13.1 and later)
Upgrading controllers in a MetroCluster FC configuration using switchover and switchback
Upgrade controllers from AFF A700/FAS9000 to AFF A900/FAS9500 in a MetroCluster FC configuration
using switchover and switchback (ONTAP 9.10.1 or later)
Upgrading controllers in a four-node MetroCluster FC configuration using switchover and switchback
with "system controller replace" commands (ONTAP 9.10.1 and later)
Upgrading controllers in a MetroCluster IP configuration using switchover and switchback (ONTAP 9.8
and later)
Upgrade controllers from AFF A700/FAS9000 to AFF A900/FAS9500 in a MetroCluster IP configuration
using switchover and switchback (ONTAP 9.10.1 or later)
Refreshing a four-node MetroCluster FC configuration
Refreshing a four-node or an eight-node MetroCluster IP configuration (ONTAP 9.8 and later)
Expand a two-node MetroCluster FC configuration to a four-node configuration
Expand a four-node MetroCluster FC configuration to an eight-node configuration
Expanding a MetroCluster IP configuration
Removing a Disaster Recovery group 270
Where to find additional information

Upgrade, refresh, or expand the MetroCluster configuration

Start here - Choose your procedure

Start here: Choose between controller upgrade, system refresh, or expansion

Depending on the scope of the equipment upgrade, you choose a controller upgrade procedure, a system refresh procedure, or an expansion procedure.

• Controller upgrade procedures apply only to the controller modules. The controllers are replaced with a new controller model.

The storage shelf models are not upgraded.

- In switchover and switchback procedures, the MetroCluster switchover operation is used to provide nondisruptive service to clients while the controller modules on the partner cluster are upgraded.
- In an ARL-based controller upgrade procedure, the aggregate relocation operations are used to nondisruptively move data from the old configuration to the new, upgraded configuration.
- Refresh procedures apply to the controllers and the storage shelves.

In the refresh procedures, new controllers and shelves are added to the MetroCluster configuration, creating a second DR group, and then data is nondisruptively migrated to the new nodes.

The original controllers are then retired.

• Expansion procedures add additional controllers and shelves to the MetroCluster configuration without removing any.

The procedure you	use depends on	the type of Me	etroCluster and n	number of existing	controllers.
				i anno an ar ar ar ar ag	

Upgrade type	Go to
Controller upgrade	Choose a controller upgrade procedure
System refresh	Choose a system refresh procedure
Expansion	 Two-node MetroCluster to four Four-node MetroCluster FC to eight Four-node MetroCluster IP to eight

Choose a controller upgrade procedure

The controller upgrade procedure you use depends on the platform model and type of MetroCluster configuration.

In an upgrade procedure, the controllers are replaced with a new controller model. The storage shelf models

are not upgraded.

- In switchover and switchback procedures, the MetroCluster switchover operation is used to provide nondisruptive service to clients while the controller modules on the partner cluster are upgraded.
- In an ARL-based controller upgrade procedure, the aggregate relocation operations are used to nondisruptively move data from the old configuration to the new, upgraded configuration.

Choosing a procedure that uses the switchover and switchback process

Select your Current platform from the FC or IP table below. If the intersection of the Current platform row and Target platform column is blank, the upgrade is not supported.

Supported MetroCluster IP controller upgrades

If your platform is not listed, there is no supported controller upgrade combination.

When you perform a controller upgrade, the old and the new platform type **must** match.

- You can upgrade a FAS system to a FAS system, or an AFF A-Series to an AFF A-Series.
- You cannot upgrade a FAS system to an AFF A-Series, or an AFF A-Series to an AFF C-Series.

For example, if the platform you want to upgrade is a FAS8200, you can upgrade to a FAS9000. You cannot upgrade a FAS8200 system to an AFF A700 system.

	1	Target MetroCluster IP platform									
		AFF A150	FAS2750 AFF A220	FAS500f AFF C250 ASA C250 AFF A250 ASA A250	FAS8200 AFF A300	AFF A320	FAS8300 AFF C400 ASA C400 AFF A400 ASA A400	FAS8700	FAS9000 AFF A700	AFF C800 ASA C800 AFF A800 ASA A800	FAS9500 AFF A900 ASA A900
	AFF A150										
	FAS2750										
	AFF A220										
	FAS500f										
	AFF C250										
	ASA C250										
	AFF A250										
	ASA A250										
	FAS8200										Note 2
	AFF A300										
	AFF A320										
Source	FAS8300										
MetroCluster IP	AFF C400										
platform	ASA C400										Note 2
	AFF A400										
	ASA A400										
	FAS8700										Note 2
	FAS9000										Note 1
	AFF A700										
	AFF C800										
	ASA C800										
	AFF A800										
	EAS9500										
	AFE A900										
	ASA A900										

• Note 1: For this upgrade use the procedure Upgrade controllers from AFF A700/FAS9000 to AFF A900/FAS9500 in a MetroCluster IP configuration using switchover and switchback (ONTAP 9.10.1 or later)

- Note 2: Controller upgrades are supported on systems running ONTAP 9.13.1 or later.
- All nodes in the MetroCluster configuration must be running the same ONTAP version. For example, the new controllers must be running the same ONTAP version as the old controllers.

Supported MetroCluster FC controller upgrades

i

If your platform is not listed, there is no supported controller upgrade combination.

When you perform a controller upgrade, the old and the new platform type **must** match.

- You can upgrade a FAS system to a FAS system, or an AFF A-Series to an AFF A-Series.
- You cannot upgrade a FAS system to an AFF A-Series, or an AFF A-Series to an AFF C-Series.

For example, if the platform you want to upgrade is a FAS8200, you can upgrade to a FAS9000. You cannot upgrade a FAS8200 system to an AFF A700 system.



- Note 1: For upgrading controllers when FCVI connections on existing FAS8020 or AFF8020 nodes use ports 1c and 1d, see the following Knowledge base article.
- Note 2: Controller upgrades from AFF A300 or FAS8200 platforms using onboard ports 0e and 0f as FC-VI connections are only supported on the following systems:
 - ONTAP 9.9.1 and earlier
 - ONTAP 9.10.1P9
 - ONTAP 9.11.1P5
 - ONTAP 9.12.1GA
 - ONTAP 9.13.1 and later

For more information, review the Public Report.

- Note 3: For this upgrade refer to Upgrade controllers from AFF A700/FAS9000 to AFF A900/FAS9500 in a MetroCluster FC configuration using switchover and switchback (ONTAP 9.10.1 or later)
- Note 4: Controller upgrades are supported on systems running ONTAP 9.13.1 or later.
- Note 5: Controller upgrades are supported on systems running ONTAP 9.14.1 or later.
- All nodes in the MetroCluster configuration must be running the same ONTAP version. For example, the new controllers must be running the same ONTAP version as the old controllers.

MetroCluster type	Upgrade method	ONTAP version	Procedure
-------------------	-------------------	---------------	-----------

IP	Upgrade with 'system controller replace' commands	9.13.1 and later	Link to procedure
FC	Upgrade with 'system controller replace' commands	9.10.1 and later	Link to procedure
FC	Manual upgrade with CLI commands (AFF A700/FAS9000 to AFF A900/FAS9500 only)	9.10.1 and later	Link to procedure
IP	Manual upgrade with CLI commands (AFF A700/FAS9000 to AFF A900/FAS9500 only)	9.10.1 and later	Link to procedure
FC	Manual upgrade with CLI commands	9.8 and later	Link to procedure
IP	Manual upgrade with CLI commands	9.8 and later	Link to procedure

Choosing a procedure using aggregate relocation

In an ARL-based controller upgrade procedure, the aggregate relocation operations are used to nondisruptively move data from the old configuration to the new, upgraded configuration.

MetroCluster type	Aggregate relocation	ONTAP version	Procedure
FC	Using "system controller replace" commands to upgrade controller models in the same chassis	9.10.1 and later	Link to procedure

MetroCluster type	Aggregate relocation	ONTAP version	Procedure
FC	Using system controller replace commands	9.8 and later	Link to procedure
FC	Using system controller replace commands	9.5 through 9.7	Link to procedure
FC	Using manual ARL commands	9.8	Link to procedure
FC	Using manual ARL commands	9.7 and earlier	Link to procedure

Choosing a system refresh method

The system refresh procedure you use depends on the platform model, and type of MetroCluster configuration. Refresh procedures apply to the controllers and the storage shelves. In the refresh procedures, new controllers and shelves are added to the MetroCluster configuration, creating a second DR group, and then data is nondisruptively migrated to the new nodes. The original controllers are then retired.

Supported MetroCluster FC tech refresh combinations

		Target MetroCluster FC platform									
		FA68200	AFE A200	FA68200	AFF A 400				EASOF00	455 4000	454 4000
		FA58200	AFF A300	FA58300	AFF A400	ASA A400	FA59000	AFF A700	FA59500	AFF A900	ASA A900
	FAS8200										
	AFF A300										
	FAS8300										
	AFF A400										
Source MetroCluster FC	ASA A400										
platform	FAS9000										
	AFF A700										
	FAS9500										
	AFF A900										
	ASA A900										

- You must complete the tech refresh procedure before adding a new load.
- All nodes in the MetroCluster configuration must be running the same ONTAP version. For example, if you have an eight-node configuration, all eight nodes must be running the same ONTAP version.
- Do not exceed any object limits of the 'lower' of the platforms in the combination. Apply the lower object limit of the two platforms.
- If the target platform limits are lower then the MetroCluster limits, you must reconfigure the MetroCluster to be at, or below, the target platform limits before you add the new nodes.
- Refer to the Hardware universe for platform limits.

Supported MetroCluster IP tech refresh combinations

		Target MetroCluster IP platform									
		AFF A150 ASA A150	FAS2750 AFF A220	FAS500F AFF C250 ASA C250 AFF A250 ASA A250	FAS8200 AFF A300	AFF A320	FAS8300 AFF C400 ASA C400 AFF A400 ASA A400	FAS8700	FAS9000 AFF A700	AFF C800 ASA C800 AFF A800 ASA A800	FAS9500 AFF A900 ASA A900
	AFF A150 ASA A150	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1
	FAS2750 AFF A220	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1
	FAS500f AFF C250 ASA C250 AFF A250 ASA A250	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1	Note 1
	FAS8200										
	AFE A320	-		2		-					
Source	FAS8300	- C.	2	8	1						
MetroCluster IP	AFF C400										
platform	ASA C400										
	AFF A400										
	ASA A400										
	FAS8700				29 24 5		с. - С				
	FAS9000										
2	AFF A700				1		1				
	ASA C800										
	AFF A800										
	ASA A800										
	FAS9500										
	AFF A900										
	ASA A900										

Note 1: This combination requires ONTAP 9.13.1 or later.

- You must complete the tech refresh procedure before adding a new load.
- All nodes in the MetroCluster configuration must be running the same ONTAP version. For example, if you have an eight-node configuration, all eight nodes must be running the same ONTAP version.
- Do not exceed any object limits of the 'lower' of the platforms in the combination. Apply the lower object limit of the two platforms.
- If the target platform limits are lower than the MetroCluster limits, you must reconfigure the MetroCluster to be at, or below, the target platform limits before you add the new nodes.
- Refer to the Hardware universe for platform limits.

Refresh method	Configuration type	ONTAP version	Procedure
 Method: Expand the MetroCluster configuration and then remove the old nodes 	Four-node FC	9.6 and later	Link to procedure
• Method: Expand the MetroCluster configuration and then remove the old nodes	Four-node IP	9.8 and later	Link to procedure

Choose an expansion procedure

The expansion procedure you use depends on the type of MetroCluster configuration and the ONTAP version.

An expansion procedure involves adding new controllers and storage to the MetroCluster configuration. The expansion must maintain an even number of controllers on each site and the procedure you use depends on the number of nodes in the original MetroCluster configuration.

Expansion method	Configuration type	ONTAP version	Procedure
Method: Expand a two-node MetroCluster FC to four	Two-node FC	ONTAP 9 and later (platforms must be supported in ONTAP 9.2 and later)	Link to procedure
Method: Expand a four-node MetroCluster FC to eight	Four-node FC	ONTAP 9 or later	Link to procedure
Method: Expand a four-node MetroCluster IP to eight	Four-node IP	ONTAP 9.9.1 and later	Link to procedure

Upgrade controllers in a four-node MetroCluster IP configuration using switchover and switchback with "system controller replace" commands (ONTAP 9.13.1 and later)

You can use this guided automated MetroCluster switchover operation to perform a nondisruptive controller upgrade on a four-node MetroCluster IP configuration. Other components (such as storage shelves or switches) cannot be upgraded as part of this procedure.

Supported platform combinations

This procedure supports the following controller upgrades on systems running ONTAP 9.13.1 and later.

Old controller	Replacement controller	
AFF A300	AFF A900	
FAS8200	FAS9500	

You can perform the controller upgrades listed in the above table on systems running ONTAP 9.12.1 or 9.11.1 using the manual upgrade procedure described here.

For more information on platform upgrade combinations, review the MetroCluster IP upgrade table in Choose a controller upgrade procedure.

Refer to Choosing an upgrade or refresh method for additional procedures.

About this task

(;)

• You can use this procedure only for controller upgrade.

Other components in the configuration, such as storage shelves or switches, cannot be upgraded at the

same time.

• This procedure applies to controller modules in a four-node MetroCluster IP configuration running ONTAP 9.13.1 or later.

NetApp Hardware Universe

- The MetroCluster systems must be running the same ONTAP version at both sites.
- You can use this procedure to upgrade controllers in a four-node MetroCluster IP configuration using NSO based automated switchover and switchback.



Performing an upgrade using aggregate relocation (ARL) with "systems controller replace" commands" is not supported for a four-node MetroCluster IP configuration.

- You must use the automated NSO controller upgrade procedure to upgrade the controllers at both sites in sequence.
- This automated NSO based controller upgrade procedure gives you the capability to initiate controller replacement to a MetroCluster disaster recovery (DR) site. You can only initiate a controller replacement at one site at a time.
- To initiate a controller replacement at site A, you need to run the controller replacement start command from site B. The operation guides you to replace controllers of both the nodes at site A only. To replace the controllers at site B, you need to run the controller replacement start command from site A. A message displays identifying the site at which the controllers are being replaced.

The following example names are used in this procedure:

- site_A
 - Before upgrade:
 - node_A_1-old
 - node_A_2-old
 - After upgrade:
 - node_A_1-new
 - node_A_2-new
- site_B
 - Before upgrade:
 - node_B_1-old
 - node_B_2-old
 - After upgrade:
 - node_B_1-new
 - node_B_2-new

Prepare for the upgrade

To prepare for the controller upgrade, you need to perform system prechecks and collect the configuration information.

Before the prechecks start, if ONTAP Mediator is installed, it is automatically detected and removed. To confirm

the removal, you are prompted to enter a username and password. When you complete the upgrade, or if prechecks fail or you choose not to proceed with the upgrade, you must manually reconfigure ONTAP Mediator.

At any stage during the upgrade, you can run the system controller replace show or system controller replace show-details command from site A to check the status. If the commands return a blank output, wait for a few minutes and rerun the command.

Steps

1. Start the automated controller replacement procedure from site A to replace the controllers at site B:

system controller replace start -nso true

The automated operation executes the prechecks. If no issues are found, the operation pauses so you can manually collect the configuration related information.

- If you do not run the system controller replace start -nso true command, the controller upgrade procedure chooses NSO based automated switchover and switchback as the default procedure on MetroCluster IP systems.
- The current source system and all compatible target systems are displayed. If you have replaced the source controller with a controller that has a different ONTAP version or a non-compatible platform, the automation operation halts and reports an error after the new nodes are booted up. To bring the cluster back to a healthy state, you need to follow the manual recovery procedure.

The system controller replace start command might report the following precheck error:

Cluster-A::*>system controller replace show Node Status Error-Action ------Node-A-1 Failed MetroCluster check failed. Reason : MCC check showed errors in component aggregates

Check if this error occurred because you have unmirrored aggregates or due to another aggregate issue. Verify that all mirrored aggregates are healthy and not degraded or mirror-degraded. If this error is due to unmirrored aggregates only, you can override this error by selecting the <code>-skip-metrocluster-check true</code> option on the <code>system controller replace start command</code>. If remote storage is accessible, the unmirrored aggregates come online after switchover. If the remote storage link fails, the unmirrored aggregates fail to come online.

2. Manually collect the configuration information by logging in at site B and following the commands listed in the console message under the system controller replace show or system controller replace show-details command.

Gathering information before the upgrade

Before upgrading, if the root volume is encrypted, you must gather the backup key and other information to boot the new controllers with the old encrypted root volumes.

About this task

This task is performed on the existing MetroCluster IP configuration.

Steps

- 1. Label the cables for the existing controllers, so you can easily identify the cables when setting up the new controllers.
- 2. Display the commands to capture the backup key and other information:

system controller replace show

Run the commands listed under the show command from the partner cluster.

The show command output displays three tables containing the MetroCluster interface IPs, system IDs, and system UUIDs. This information is required later in the procedure to set the bootargs when you boot the new node.

3. Gather the system IDs of the nodes in the MetroCluster configuration:

metrocluster node show -fields node-systemid, dr-partner-systemid

During the upgrade procedure, you will replace these old system IDs with the system IDs of the new controller modules.

In this example for a four-node MetroCluster IP configuration, the following old system IDs are retrieved:

- node_A_1-old: 4068741258
- node_A_2-old: 4068741260
- node_B_1-old: 4068741254
- node_B_2-old: 4068741256

metrocluster-siteA::> metrocluster node show -fields node-systemid, hapartner-systemid, dr-partner-systemid, dr-auxiliary-systemid dr-group-id cluster node node-systemid ha-partner-systemid dr-partner-systemid dr-auxiliary-systemid _____ -----_____ _____ _____ _____ 1 Cluster A Node A 1-old 4068741258 4068741260 4068741256 4068741256 Cluster_A Node_A_2-old 4068741260 1 4068741258 4068741254 4068741254 Cluster B Node B 1-old 4068741254 1 4068741256 4068741258 4068741260 1 Cluster B Node B 2-old 4068741256 4068741254 4068741260 4068741258 4 entries were displayed.

In this example for a two-node MetroCluster IP configuration, the following old system IDs are retrieved:

- node A 1: 4068741258
- node_B_1: 4068741254

4. Gather port and LIF information for each old node.

You should gather the output of the following commands for each node:

network interface show -role cluster, node-mgmt
network port show -node node-name -type physical
network port vlan show -node node-name
network port ifgrp show -node node_name -instance
network port broadcast-domain show
network port reachability show -detail
network ipspace show
volume show
storage aggregate show

° system node run -node node-name sysconfig -a

5. If the MetroCluster nodes are in a SAN configuration, collect the relevant information.

You should gather the output of the following commands:

- ° fcp adapter show -instance
- ° fcp interface show -instance
- ° iscsi interface show
- ° ucadmin show
- 6. If the root volume is encrypted, collect and save the passphrase used for key-manager:

security key-manager backup show

7. If the MetroCluster nodes are using encryption for volumes or aggregates, copy information about the keys and passphrases.

For additional information, see Backing up onboard key management information manually.

a. If Onboard Key Manager is configured:

security key-manager onboard show-backup

You will need the passphrase later in the upgrade procedure.

b. If enterprise key management (KMIP) is configured, issue the following commands:

security key-manager external show -instance

security key-manager key query

8. After you finish collecting the configuration information, resume the operation:

system controller replace resume

Removing the existing configuration from the Tiebreaker or other monitoring software

If the existing configuration is monitored with the MetroCluster Tiebreaker configuration or other third-party applications (for example, ClusterLion) that can initiate a switchover, you must remove the MetroCluster configuration from the Tiebreaker or other software prior to replacing the old controller.

Steps

- 1. Remove the existing MetroCluster configuration from the Tiebreaker software.
- 2. Remove the existing MetroCluster configuration from any third-party application that can initiate switchover.

Refer to the documentation for the application.

Replacing the old controllers and booting up the new controllers

After you gather information and resume the operation, the automation proceeds with the switchover operation.

About this task

The automation operation initiates the switchover operations. After these operations complete, the operation pauses at **paused for user intervention** so you can rack and install the controllers, boot up the partner controllers, and reassign the root aggregate disks to the new controller module from flash backup using the sysids gathered earlier.

Before you begin

Before initiating switchover, the automation operation pauses so you can manually verify that all LIFs are "up" at site B. If necessary, bring any LIFs that are "down" to "up" and resume the automation operation by using the system controller replace resume command.

Preparing the network configuration of the old controllers

To ensure that the networking resumes cleanly on the new controllers, you must move LIFs to a common port and then remove the networking configuration of the old controllers.

About this task

- This task must be performed on each of the old nodes.
- You will use the information gathered in Prepare for the upgrade.

Steps

1. Boot the old nodes and then log in to the nodes:

boot_ontap

- 2. Assign the home port of all data LIFs on the old controller to a common port that is the same on both the old and new controller modules.
 - a. Display the LIFs:

network interface show

All data LIFS including SAN and NAS will be admin "up" and operationally "down" since those are up at switchover site (cluster_A).

b. Review the output to find a common physical network port that is the same on both the old and new controllers that is not used as a cluster port.

For example, "e0d" is a physical port on old controllers and is also present on new controllers. "e0d" is not used as a cluster port or otherwise on the new controllers.

For port usage for platform models, see the NetApp Hardware Universe

c. Modify all data LIFS to use the common port as the home port:

```
network interface modify -vserver svm-name -lif data-lif -home-port port-id
```

In the following example, this is "e0d".

For example:

network interface modify -vserver vs0 -lif datalif1 -home-port e0d

3. Modify broadcast domains to remove VLAN and physical ports that need to be deleted:

broadcast-domain remove-ports -broadcast-domain broadcast-domain-name -ports
node-name:port-id

Repeat this step for all VLAN and physical ports.

- 4. Remove any VLAN ports using cluster ports as member ports and interface groups using cluster ports as member ports.
 - a. Delete VLAN ports:

network port vlan delete -node node-name -vlan-name portid-vlandid

For example:

network port vlan delete -node node1 -vlan-name e1c-80

b. Remove physical ports from the interface groups:

```
network port ifgrp remove-port -node node-name -ifgrp interface-group-name
-port portid
```

For example:

network port ifgrp remove-port -node node1 -ifgrp ala -port e0d

c. Remove VLAN and interface group ports from broadcast domain:

network port broadcast-domain remove-ports -ipspace ipspace -broadcast -domain broadcast-domain-name -ports nodename:portname,nodename:portname,..

d. Modify interface group ports to use other physical ports as member as needed .:

ifgrp add-port -node node-name -ifgrp interface-group-name -port port-id

5. Halt the nodes:

halt -inhibit-takeover true -node node-name

This step must be performed on both nodes.

Setting up the new controllers

You must rack and cable the new controllers.

Steps

1. Plan out the positioning of the new controller modules and storage shelves as needed.

The rack space depends on the platform model of the controller modules, the switch types, and the number of storage shelves in your configuration.

- 2. Properly ground yourself.
- 3. Install the controller modules in the rack or cabinet.

ONTAP Hardware Systems Documentation

4. If the new controller modules did not come with FC-VI cards of their own and if FC-VI cards from old controllers are compatible on new controllers, swap FC-VI cards and install those in correct slots.

See the NetApp Hardware Universe for slot info for FC-VI cards.

5. Cable the controllers' power, serial console and management connections as described in the *MetroCluster Installation and Configuration Guides*.

Do not connect any other cables that were disconnected from old controllers at this time.

ONTAP Hardware Systems Documentation

6. Power up the new nodes and press Ctrl-C when prompted to display the LOADER prompt.

Netbooting the new controllers

After you install the new nodes, you need to netboot to ensure the new nodes are running the same version of ONTAP as the original nodes. The term netboot means you are booting from an ONTAP image stored on a remote server. When preparing for netboot, you must put a copy of the ONTAP 9 boot image onto a web server that the system can access.

This task is performed on each of the new controller modules.

Steps

- 1. Access the NetApp Support Site to download the files used for performing the netboot of the system.
- 2. Download the appropriate ONTAP software from the software download section of the NetApp Support Site and store the ontap-version_image.tgz file on a web-accessible directory.
- 3. Go to the web-accessible directory and verify that the files you need are available.

Your directory listing should contain a netboot folder with a kernel file: ontap-version_image.tgz

You do not need to extract the ontap-version_image.tgz file.

- 4. At the LOADER prompt, configure the netboot connection for a management LIF:
 - If IP addressing is DHCP, configure the automatic connection:

ifconfig eOM -auto

 $\circ\,$ If IP addressing is static, configure the manual connection:

ifconfig eOM -addr=ip_addr -mask=netmask-gw=gateway

- 5. Perform the netboot.
 - If the platform is an 80xx series system, use this command:

netboot http://web server ip/path to web-accessible directory/netboot/kernel

• If the platform is any other system, use the following command:

```
netboot http://web_server_ip/path_to_web-accessible_directory/ontap-
version image.tgz
```

6. From the boot menu, select option (7) Install new software first to download and install the new software image to the boot device.

Disregard the following message: "This procedure is not supported for Non-Disruptive Upgrade on an HA pair". It applies to nondisruptive upgrades of software, not to upgrades of controllers.

7. If you are prompted to continue the procedure, enter y, and when prompted for the package, enter the URL of the image file: http://web_server_ip/path_to_web-accessible_directory/ontap-version_image.tgz

Enter username/password if applicable, or press Enter to continue.

8. Be sure to enter n to skip the backup recovery when you see a prompt similar to the following:

Do you want to restore the backup configuration now? {y|n}

9. Reboot by entering y when you see a prompt similar to the following:

```
The node must be rebooted to start using the newly installed software. Do you want to reboot now? \{y|n\}
```

Clearing the configuration on a controller module

Before using a new controller module in the MetroCluster configuration, you must clear the existing configuration.

Steps

1. If necessary, halt the node to display the LOADER prompt:

halt

2. At the LOADER prompt, set the environmental variables to default values:

set-defaults

3. Save the environment:

saveenv

4. At the LOADER prompt, launch the boot menu:

boot_ontap menu

5. At the boot menu prompt, clear the configuration:

wipeconfig

Respond yes to the confirmation prompt.

The node reboots and the boot menu is displayed again.

6. At the boot menu, select option **5** to boot the system into Maintenance mode.

Respond yes to the confirmation prompt.

Restoring the HBA configuration

Depending on the presence and configuration of HBA cards in the controller module, you need to configure them correctly for your site's usage.

Steps

- 1. In Maintenance mode configure the settings for any HBAs in the system:
 - a. Check the current settings of the ports: ucadmin show
 - b. Update the port settings as needed.

If you have this type of HBA and desired mode	Use this command
CNA FC	ucadmin modify -m fc -t initiator <i>adapter-name</i>
CNA Ethernet	ucadmin modify -mode cna adapter-name
FC target	fcadmin config -t target <i>adapter-name</i>
FC initiator	fcadmin config -t initiator <i>adapter-</i> <i>name</i>

2. Exit Maintenance mode:

halt

After you run the command, wait until the node stops at the LOADER prompt.

3. Boot the node back into Maintenance mode to enable the configuration changes to take effect:

boot_ontap maint

4. Verify the changes you made:

If you have this type of HBA	Use this command	
CNA	ucadmin show	
FC	fcadmin show	

Set the HA state on the new controllers and chassis

You must verify the HA state of the controllers and chassis, and, if necessary, update the state to match your system configuration.

Steps

1. In Maintenance mode, display the HA state of the controller module and chassis:

ha-config show

The HA state for all components should be mccip.

2. If the displayed system state of the controller or chassis is not correct, set the HA state:

ha-config modify controller mccip

ha-config modify chassis mccip

3. Halt the node: halt

The node should stop at the LOADER> prompt.

- 4. On each node, check the system date, time, and time zone: show date
- 5. If necessary, set the date in UTC or GMT: set date <mm/dd/yyyy>
- 6. Check the time by using the following command at the boot environment prompt: show time
- 7. If necessary, set the time in UTC or GMT: set time <hh:mm:ss>
- 8. Save the settings: saveenv
- 9. Gather environment variables: printenv

Update the switch RCF files to accommodate the new platforms

You must update the switches to a configuration that supports the new platform models.

About this task

You perform this task at the site containing the controllers that are currently being upgraded. In the examples shown in this procedure we are upgrading site_B first.

The switches at site_A will be upgraded when the controllers on site_A are upgraded.

Steps

1. Prepare the IP switches for the application of the new RCF files.

Follow the steps in the section for your switch vendor from the *MetroCluster IP Installation and Configuration* section.

MetroCluster IP installation and configuration

- · Resetting the Broadcom IP switch to factory defaults
- Resetting the Cisco IP switch to factory defaults
- 2. Download and install the RCF files.

Follow the steps in the section for your switch vendor from the MetroCluster IP installation and configuration.

- Downloading and installing the Broadcom RCF files
- · Downloading and installing the Cisco IP RCF files

Set the MetroCluster IP bootarg variables

Certain MetroCluster IP bootarg values must be configured on the new controller modules. The values must match those configured on the old controller modules.

About this task

In this task, you will use the UUIDs and system IDs identified earlier in the upgrade procedure in Gathering information before the upgrade.

Steps

1. At the LOADER> prompt, set the following bootargs on the new nodes at site_B:

```
setenv bootarg.mcc.port_a_ip_config local-IP-address/local-IP-mask,0,HA-
partner-IP-address,DR-partner-IP-address,DR-aux-partnerIP-address,vlan-id
```

```
setenv bootarg.mcc.port_b_ip_config local-IP-address/local-IP-mask,0,HA-
partner-IP-address,DR-partner-IP-address,DR-aux-partnerIP-address,vlan-id
```

The following example sets the values for node_B_1 using VLAN 120 for the first network and VLAN 130 for the second network:

setenv bootarg.mcc.port_a_ip_config
172.17.26.10/23,0,172.17.26.11,172.17.26.13,172.17.26.12,120
setenv bootarg.mcc.port_b_ip_config
172.17.27.10/23,0,172.17.27.11,172.17.27.13,172.17.27.12,130

The following example sets the values for node_B_2 using VLAN 120 for the first network and VLAN 130 for the second network:

```
setenv bootarg.mcc.port_a_ip_config
172.17.26.11/23,0,172.17.26.10,172.17.26.12,172.17.26.13,120
setenv bootarg.mcc.port_b_ip_config
172.17.27.11/23,0,172.17.27.10,172.17.27.12,172.17.27.13,130
```

2. At the new nodes' LOADER prompt, set the UUIDs:

```
setenv bootarg.mgwd.partner_cluster_uuid partner-cluster-UUID
setenv bootarg.mgwd.cluster_uuid local-cluster-UUID
setenv bootarg.mcc.pri_partner_uuid DR-partner-node-UUID
setenv bootarg.mcc.aux_partner_uuid DR-aux-partner-node-UUID
setenv bootarg.mcc_iscsi.node_uuid local-node-UUID
```

a. Set the UUIDs on node_B_1.

The following example shows the commands for setting the UUIDs on node_B_1:

```
setenv bootarg.mgwd.cluster_uuid ee7db9d5-9a82-11e7-b68b-00a098908039
setenv bootarg.mgwd.partner_cluster_uuid 07958819-9ac6-11e7-9b42-
00a098c9e55d
setenv bootarg.mcc.aux_partner_uuid f37b240b-9ac1-11e7-bd4e-
00a098ca379f
setenv bootarg.mcc_iscsi.node_uuid f03cb63c-9a7e-11e7-b68b-
00a098908039
```

b. Set the UUIDs on node_B_2:

The following example shows the commands for setting the UUIDs on node_B_2:

```
setenv bootarg.mgwd.cluster_uuid ee7db9d5-9a82-11e7-b68b-00a098908039
setenv bootarg.mgwd.partner_cluster_uuid 07958819-9ac6-11e7-9b42-
00a098c9e55d
setenv bootarg.mcc.aux_partner_uuid bf8e3f8f-9ac4-11e7-9b42-
00a098c9e55d
setenv bootarg.mcc_iscsi.node_uuid aa9a7a7a-9a81-11e7-a4e9-
00a098908c35
```

3. If the original systems were configured for ADP, at each of the replacement nodes' LOADER prompt, enable ADP:

setenv bootarg.mcc.adp enabled true

4. Set the following variables:

setenv bootarg.mcc.local config id original-sys-id



The setenv bootarg.mcc.local_config_id variable must be set to the sys-id of the original controller module, node_B_1.

a. Set the variables on node_B_1.

The following example shows the commands for setting the values on node B_1:

```
setenv bootarg.mcc.local_config_id 537403322
setenv bootarg.mcc.dr partner 537403324
```

b. Set the variables on node_B_2.

The following example shows the commands for setting the values on node_B_2:

setenv bootarg.mcc.local_config_id 537403321
setenv bootarg.mcc.dr_partner 537403323

5. If using encryption with external key manager, set the required bootargs:

setenv bootarg.kmip.init.ipaddr

setenv bootarg.kmip.kmip.init.netmask

setenv bootarg.kmip.kmip.init.gateway

setenv bootarg.kmip.kmip.init.interface

Reassigning root aggregate disks

Reassign the root aggregate disks to the new controller module, using the sysids gathered earlier

About this task

This task is performed in Maintenance mode.

The old system IDs were identified in Gathering information before the upgrade.

The examples in this procedure use controllers with the following system IDs:

Node	Old system ID	New system ID
node_B_1	4068741254	1574774970

Steps

1. Cable all other connections to the new controller modules (FC-VI, storage, cluster interconnect, etc.).

2. Halt the system and boot to Maintenance mode from the LOADER prompt:

boot_ontap maint

3. Display the disks owned by node B_1-old:

disk show -a

The command output shows the system ID of the new controller module (1574774970). However, the root aggregate disks are still owned by the old system ID (4068741254). This example does not show drives owned by other nodes in the MetroCluster configuration.

```
*> disk show -a
Local System ID: 1574774970
  DISK
            OWNER
                                      POOL SERIAL NUMBER
                                                            HOME
DR HOME
_____
              _____
                                      ____
                                             _____
_____
                        _____
. . .
rr18:9.126L44 node B 1-old(4068741254) Pool1 PZHYNOMD
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:9.126L49 node B 1-old(4068741254) Pool1 PPG3J5HA
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:8.126L21 node B 1-old(4068741254) Pool1 PZHTDSZD
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:8.126L2 node B 1-old(4068741254) Pool0 SOM1J2CF
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:8.126L3 node B 1-old(4068741254) Pool0 SOM0CQM5
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:9.126L27 node B 1-old(4068741254) Pool0 SOM1PSDW
node B 1-old(4068741254) node B 1-old(4068741254)
. . .
```

4. Reassign the root aggregate disks on the drive shelves to the new controller:

disk reassign -s old-sysid -d new-sysid



If your MetroCluster IP system is configured with Advanced Disk Partitioning, you must include the DR partner system id by running the disk reassign -s old-sysid -d new-sysid -r dr-partner-sysid command.

The following example shows reassignment of drives:

```
*> disk reassign -s 4068741254 -d 1574774970
Partner node must not be in Takeover mode during disk reassignment from
maintenance mode.
Serious problems could result!!
Do not proceed with reassignment if the partner is in takeover mode.
Abort reassignment (y/n)? n
After the node becomes operational, you must perform a takeover and
giveback of the HA partner node to ensure disk reassignment is
successful.
Do you want to continue (y/n)? Jul 14 19:23:49
[localhost:config.bridge.extra.port:error]: Both FC ports of FC-to-SAS
bridge rtp-fc02-41-rr18:9.126L0 S/N [FB7500N107692] are attached to this
controller.
У
Disk ownership will be updated on all disks previously belonging to
Filer with sysid 4068741254.
Do you want to continue (y/n)? y
```

5. Check that all disks are reassigned as expected:

disk show

```
*> disk show
Local System ID: 1574774970
 DISK
           OWNER
                                      POOL SERIAL NUMBER
                                                          HOME
DR HOME
_____
             _____
                                             _____
_____
rr18:8.126L18 node B 1-new(1574774970) Pool1 PZHYNOMD
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:9.126L49 node B 1-new(1574774970) Pool1 PPG3J5HA
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:8.126L21 node B 1-new(1574774970) Pool1 PZHTDSZD
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:8.126L2 node B 1-new(1574774970) Pool0 SOM1J2CF
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:9.126L29 node B 1-new(1574774970) Pool0 SOMOCQM5
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:8.126L1 node B 1-new(1574774970) Pool0 SOM1PSDW
node B 1-new(1574774970) node B 1-new(1574774970)
*>
```

6. Display the aggregate status:

aggr status

```
*> aggr status
    Aggr State Status Options
aggr0_node_b_1-root online raid_dp, aggr root, nosnap=on,
    mirrored
mirror_resync_priority=high(fixed)
    fast zeroed
    64-bit
```

7. Repeat the above steps on the partner node (node_B_2-new).

Booting up the new controllers

You must reboot the controllers from the boot menu to update the controller flash image. Additional steps are required if encryption is configured.

You can reconfigure VLANs and interface groups. If required, manually modify the ports for the cluster LIFs and broadcast domain details before resuming the operation by using the system controller replace resume command.

About this task

This task must be performed on all the new controllers.

Steps

1. Halt the node:

halt

2. If external key manager is configured, set the related bootargs:

```
setenv bootarg.kmip.init.ipaddr ip-address
```

setenv bootarg.kmip.init.netmask netmask

setenv bootarg.kmip.init.gateway gateway-address

setenv bootarg.kmip.init.interface interface-id

3. Display the boot menu:

boot_ontap menu

4. If root encryption is used, select the boot menu option for your key management configuration.

If you are using Select this boot menu option

Onboard key management	Option "10" Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.
External key management	Option "11" Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.

5. From the boot menu, run option "6".



Option "6" will reboot the node twice before completing.

Respond "y" to the system id change prompts. Wait for the second reboot messages:

Successfully restored env file from boot media...

Rebooting to load the restored env file...

During one of the reboots after option "6", the confirmation prompt Override system ID? $\{y|n\}$ appears. Enter y.

6. If root encryption is used, select the boot menu option again for your key management configuration.

If you are using	Select this boot menu option
Onboard key management	Option "10"
	Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.
External key management	Option "11"
	Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.

Depending on the key manager setting, perform the recovery procedure by selecting option "10" or option "11", followed by option "6" at the first boot menu prompt. To boot the nodes completely, you might need to repeat the recovery procedure continued by option "1" (normal boot).

7. Boot the nodes:

boot_ontap

8. Wait for the replaced nodes to boot up.

If either node is in takeover mode, perform a giveback using the storage failover giveback command.

- 9. Verify that all ports are in a broadcast domain:
 - a. View the broadcast domains:

network port broadcast-domain show

b. Add any ports to a broadcast domain as needed.

Adding or removing ports from a broadcast domain

- c. Add the physical port that will host the intercluster LIFs to the corresponding broadcast domain.
- d. Modify intercluster LIFs to use the new physical port as home port.
- e. After the intercluster LIFs are up, check the cluster peer status and re-establish cluster peering as needed.

You may need to reconfigure cluster peering.

Creating a cluster peer relationship

f. Recreate VLANs and interface groups as needed.

VLAN and interface group membership might be different than that of the old node.

Creating a VLAN

Combining physical ports to create interface groups

g. Verify that the partner cluster is reachable and that the configuration is successfully resynchronized on the partner cluster:

metrocluster switchback -simulate true

10. If encryption is used, restore the keys using the correct command for your key management configuration.

If you are using	Use this command
Onboard key management	security key-manager onboard sync For more information, see Restoring onboard key management encryption keys.
External key management	<pre>security key-manager external restore -vserver SVM -node node -key-server host_name IP_address:port -key-id key_id -key-tag key_tag node-name For more information, see Restoring external key management encryption keys.</pre>

11. Before you resume the operation, verify that the MetroCluster is configured correctly. Check the node status:

metrocluster node show

Verify that the new nodes (site_B) are in Waiting for switchback state from site_A.

12. Resume the operation:

```
system controller replace resume
```

Completing the upgrade

The automation operation runs verification system checks and then pauses so you can verify the network reachability. After verification, the resource regain phase is initiated and the automation operation executes switchback at site A and pauses at the post upgrade checks. After you resume the automation operation, it performs the post upgrade checks and if no errors are detected, marks the upgrade as complete.

Steps

- 1. Verify the network reachability by following the console message.
- 2. After you complete the verification, resume the operation:

system controller replace resume

- 3. The automation operation performs heal-aggregate, heal-root-aggregate, and switchback operations at site A, and the post upgrade checks. When the operation pauses, manually check the SAN LIF status and verify the network configuration by following the console message.
- 4. After you complete the verification, resume the operation:

system controller replace resume

5. Check the post upgrade checks status:

system controller replace show

If the post upgrade checks did not report any errors, the upgrade is complete.

6. After you complete the controller upgrade, log in at site B and verify that the replaced controllers are configured correctly.

Reconfigure ONTAP Mediator

Manually configure ONTAP Mediator which was automatically removed before you started the upgrade.

1. Use the steps in Configure the ONTAP Mediator service from a MetroCluster IP configuration.

Restoring Tiebreaker monitoring

If the MetroCluster configuration was previously configured for monitoring by the Tiebreaker software, you can restore the Tiebreaker connection.

1. Use the steps in Adding MetroCluster configurations.

Upgrading controllers in a MetroCluster FC configuration using switchover and switchback

You can use the MetroCluster switchover operation to provide nondisruptive service to clients while the controller modules on the partner cluster are upgraded. Other components (such as storage shelves or switches) cannot be upgraded as part of this procedure.

Supported platform combinations

You can upgrade certain platforms using the switchover and switchback operation in a MetroCluster FC configuration.

For information on what platform upgrade combinations are supported review the MetroCluster FC upgrade table in Choose a controller upgrade procedure.

Refer to Choosing an upgrade or refresh method for additional procedures.

About this task

• You can use this procedure only for controller upgrade.

Other components in the configuration, such as storage shelves or switches, cannot be upgraded at the same time.

- You can use this procedure with certain ONTAP versions:
 - Two-node configurations are supported in ONTAP 9.3 and later.
 - $\circ\,$ Four- and eight-node configurations are supported in ONTAP 9.8 and later.

Do not use this procedure on four- or eight-node configurations running ONTAP versions prior to 9.8.

• Your original and new platforms must be compatible and supported.

NetApp Hardware Universe



If the original or new platforms are FAS8020 or AFF8020 systems using ports 1c and 1d in FC-VI mode, see the Knowledge Base article Upgrading controllers when FCVI connections on existing FAS8020 or AFF8020 nodes use ports 1c and 1d.

- The licenses at both sites must match. You can obtain new licenses from NetApp Support.
- This procedure applies to controller modules in a MetroCluster FC configuration (a two-node stretch MetroCluster or a two, four-node, or eight-node fabric-attached MetroCluster configuration).
- All controllers in the same DR group should be upgraded during the same maintenance period.

Operating the MetroCluster configuration with different controller types in the same DR group is not supported outside of this maintenance activity. For eight-node MetroCluster configurations, the controllers within a DR Group must be the same, but both DR groups can use different controller types.

• Mapping of storage, FC and Ethernet connections between original nodes and new nodes in advance is recommended.

• If the new platform has fewer slots than the original system, or if it has fewer or different types of ports, you might need to add an adapter to the new system.

For more information, see the NetApp Hardware Universe

The following example names are used in this procedure:

- site_A
 - Before upgrade:
 - node_A_1-old
 - node_A_2-old
 - After upgrade:
 - node_A_1-new
 - node_A_2-new
- site_B
 - Before upgrade:
 - node_B_1-old
 - node_B_2-old
 - After upgrade:
 - node_B_1-new
 - node_B_2-new

Preparing for the upgrade

Before making any changes to the existing MetroCluster configuration, you must check the health of the configuration, prepare the new platforms, and perform other miscellaneous tasks.

Verifying the health of the MetroCluster configuration

You must verify the health and connectivity of the MetroCluster configuration prior to performing the upgrade.

Steps

- 1. Verify the operation of the MetroCluster configuration in ONTAP:
 - a. Check whether the nodes are multipathed: node run -node *node-name* sysconfig -a

You should issue this command for each node in the MetroCluster configuration.

b. Verify that there are no broken disks in the configuration:

storage disk show -broken

You should issue this command on each node in the MetroCluster configuration.

c. Check for any health alerts:

system health alert show

You should issue this command on each cluster.

d. Verify the licenses on the clusters:

system license show

You should issue this command on each cluster.

e. Verify the devices connected to the nodes:

network device-discovery show

You should issue this command on each cluster.

f. Verify that the time zone and time are set correctly on both sites:

cluster date show

You should issue this command on each cluster. You can use the cluster date commands to configure the time and time zone.

2. Check for any health alerts on the switches (if present):

storage switch show

You should issue this command on each cluster.

- 3. Confirm the operational mode of the MetroCluster configuration and perform a MetroCluster check.
 - a. Confirm the MetroCluster configuration and that the operational mode is normal:

metrocluster show

b. Confirm that all expected nodes are shown:

metrocluster node show

c. Issue the following command:

metrocluster check run

d. Display the results of the MetroCluster check:

metrocluster check show

- 4. Check the MetroCluster cabling with the Config Advisor tool.
 - a. Download and run Config Advisor.

NetApp Downloads: Config Advisor

b. After running Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.

Mapping ports from the old nodes to the new nodes

You must plan the mapping of the LIFs on physical ports on the old nodes to the physical ports on the new nodes.

About this task

When the new node is first booted during the upgrade process, it will replay the most recent configuration of the old node it is replacing. When you boot node_A_1-new, ONTAP attempts to host LIFs on the same ports that were used on node_A_1-old. Therefore, as part of the upgrade you must adjust the port and LIF configuration so it is compatible with that of the old node. During the upgrade procedure, you will perform steps on both the old and new nodes to ensure correct cluster, management, and data LIF configuration.

The following table shows examples of configuration changes related to the port requirements of the new nodes.

Cluster interconnect physical ports				
Old controller New controller Required action				
e0a, e0b	e3a, e3b	No matching port. After upgrade, you must recreate cluster ports. Preparing cluster ports on an existing controller module		
e0c, e0d	e0a,e0b,e0c,e0d	e0c and e0d are matching ports. You do not have to change the configuration, but after upgrade you can spread your cluster LIFs across the available cluster ports.		

Steps

1. Determine what physical ports are available on the new controllers and what LIFs can be hosted on the ports.

The controller's port usage depends on the platform module and which switches you will use in the MetroCluster IP configuration. You can gather the port usage of the new platforms from the NetApp Hardware Universe.

Also identify the FC-VI card slot usage.

2. Plan your port usage and, if desired, fill in the following tables for reference for each of the new nodes.

You will refer to the table as you carry out the upgrade procedure.

	node_A_1-old			node_A_1-new		
LIF	Ports	IPspaces	Broadcast domains	Ports	IPspaces	Broadcast domains
Cluster 1						
Cluster 2						
Cluster 3						
Cluster 4						

Node management			
Cluster management			
Data 1			
Data 2			
Data 3			
Data 4			
SAN			
Intercluster port			

Gathering information before the upgrade

Before upgrading, you must gather information for each of the old nodes, and, if necessary, adjust the network broadcast domains, remove any VLANs and interface groups, and gather encryption information.

About this task

This task is performed on the existing MetroCluster FC configuration.

Steps

- 1. Label the cables for the existing controllers, to allow easy identification of cables when setting up the new controllers.
- 2. Gather the system IDs of the nodes in the MetroCluster configuration:

metrocluster node show -fields node-systemid, dr-partner-systemid

During the upgrade procedure, you will replace these old system IDs with the system IDs of the new controller modules.

In this example for a four-node MetroCluster FC configuration, the following old system IDs are retrieved:

- node_A_1-old: 4068741258
- node_A_2-old: 4068741260
- node_B_1-old: 4068741254
- node_B_2-old: 4068741256

metrocluster-siteA::> metrocluster node show -fields nodesystemid, ha-partner-systemid, dr-partner-systemid, dr-auxiliarysystemid dr-group-id cluster node node-systemid ha-partner-systemid dr-partner-systemid dr-auxiliary-systemid _____ ----- -----_____ _____ _____ _____ 1 Cluster A Node A 1-old 4068741258 4068741260 4068741256 4068741256 1 Cluster A Node A 2-old 4068741260 4068741258 4068741254 4068741254 1 Cluster B Node B 1-old 4068741254 4068741256 4068741258 4068741260 Node B 2-old 1 Cluster B 4068741256 4068741254 4068741260 4068741258 4 entries were displayed.

In this example for a two-node MetroCluster FC configuration, the following old system IDs are retrieved:

- node A 1: 4068741258
- node_B_1: 4068741254

3. Gather port and LIF information for each old node.

You should gather the output of the following commands for each node:

- ° network interface show -role cluster, node-mgmt
- ° network port show -node node-name -type physical
- ° network port vlan show -node node-name

° network port ifgrp show -node node name -instance

- ° network port broadcast-domain show
- ° network port reachability show -detail
- ° network ipspace show
- ° volume show
- ° storage aggregate show
- ° system node run -node *node-name* sysconfig -a
- 4. If the MetroCluster nodes are in a SAN configuration, collect the relevant information.

You should gather the output of the following commands:

- ° fcp adapter show -instance
- ° fcp interface show -instance
- ° iscsi interface show
- ° ucadmin show
- 5. If the root volume is encrypted, collect and save the passphrase used for key-manager:

security key-manager backup show

6. If the MetroCluster nodes are using encryption for volumes or aggregates, copy information about the keys and passphrases.

For additional information, see Backing up onboard key management information manually.

a. If Onboard Key Manager is configured:

security key-manager onboard show-backup

You will need the passphrase later in the upgrade procedure.

b. If enterprise key management (KMIP) is configured, issue the following commands:

security key-manager external show -instance

security key-manager key query

Removing the existing configuration from the Tiebreaker or other monitoring software

If the existing configuration is monitored with the MetroCluster Tiebreaker configuration or other third-party applications (for example, ClusterLion) that can initiate a switchover, you must remove the MetroCluster configuration from the Tiebreaker or other software prior to transition.

Steps

1. Remove the existing MetroCluster configuration from the Tiebreaker software.

Removing MetroCluster configurations
2. Remove the existing MetroCluster configuration from any third-party application that can initiate switchover.

Refer to the documentation for the application.

Sending a custom AutoSupport message prior to maintenance

Before performing the maintenance, you should issue an AutoSupport message to notify NetApp technical support that maintenance is underway. Informing technical support that maintenance is underway prevents them from opening a case on the assumption that a disruption has occurred.

About this task

This task must be performed on each MetroCluster site.

Steps

- 1. To prevent automatic support case generation, send an Autosupport message to indicate maintenance is underway.
 - a. Issue the following command:

```
system node autosupport invoke -node * -type all -message MAINT=maintenance-
window-in-hours
```

maintenance-window-in-hours specifies the length of the maintenance window, with a maximum of 72 hours. If the maintenance is completed before the time has elapsed, you can invoke an AutoSupport message indicating the end of the maintenance period:

system node autosupport invoke -node * -type all -message MAINT=end

b. Repeat the command on the partner cluster.

Switching over the MetroCluster configuration

You must switch over the configuration to site_A so that the platforms on site_B can be upgraded.

About this task

This task must be performed on site_A.

After completing this task, cluster_A is active and serving data for both sites. cluster_B is inactive, and ready to begin the upgrade process, as shown in the following illustration.



Steps

- 1. Switch over the MetroCluster configuration to site_A so that site_B's nodes can be upgraded:
 - a. Select the option that matches your configuration and issue the correct command on cluster_A:

Option 1: Four- or eight-node FC configuration running ONTAP 9.8 or later Run the command: metrocluster switchover -controller-replacement true

Option 2: Two-node FC configuration running ONTAP 9.3 and later

Run the command: metrocluster switchover

The operation can take several minutes to complete.

b. Monitor the switchover operation:

```
metrocluster operation show
```

c. After the operation is complete, confirm that the nodes are in switchover state:

metrocluster show

d. Check the status of the MetroCluster nodes:

```
metrocluster node show
```

- 2. Heal the data aggregates.
 - a. Heal the data aggregates:

metrocluster heal data-aggregates

b. Confirm the heal operation is complete by running the metrocluster operation show command on the healthy cluster:

```
cluster_A::> metrocluster operation show
Operation: heal-aggregates
    State: successful
Start Time: 7/29/2020 20:54:41
End Time: 7/29/2020 20:54:42
Errors: -
```

- 3. Heal the root aggregates.
 - a. Heal the data aggregates:

```
metrocluster heal root-aggregates
```

b. Confirm the heal operation is complete by running the metrocluster operation show command on the healthy cluster:

```
cluster_A::> metrocluster operation show
Operation: heal-root-aggregates
State: successful
Start Time: 7/29/2020 20:58:41
End Time: 7/29/2020 20:59:42
Errors: -
```

Preparing the network configuration of the old controllers

To ensure that the networking resumes cleanly on the new controllers, you must move LIFs to a common port and then remove the networking configuration of the old controllers.

About this task

- This task must be performed on each of the old nodes.
- You will use the information gathered in Mapping ports from the old nodes to the new nodes.

Steps

1. Boot the old nodes and then log in to the nodes:

boot_ontap

- 2. Assign the home port of all data LIFs on the old controller to a common port that is the same on both the old and new controller modules.
 - a. Display the LIFs:

```
network interface show
```

All data LIFS including SAN and NAS will be admin up and operationally down since those are up at switchover site (cluster_A).

b. Review the output to find a common physical network port that is the same on both the old and new

controllers that is not used as a cluster port.

For example, e0d is a physical port on old controllers and is also present on new controllers. e0d is not used as a cluster port or otherwise on the new controllers.

For port usage for platform models, see the NetApp Hardware Universe

c. Modify all data LIFS to use the common port as the home port:

network interface modify -vserver svm-name -lif data-lif -home-port port-id

In the following example, this is "e0d".

For example:

network interface modify -vserver vs0 -lif datalif1 -home-port e0d

3. Modify broadcast domains to remove vlan and physical ports that need to be deleted:

```
broadcast-domain remove-ports -broadcast-domain broadcast-domain-name -ports
node-name:port-id
```

Repeat this step for all VLAN and physical ports.

- 4. Remove any VLAN ports using cluster ports as member ports and ifgrps using cluster ports as member ports.
 - a. Delete VLAN ports:

network port vlan delete -node node-name -vlan-name portid-vlandid

For example:

network port vlan delete -node nodel -vlan-name elc-80

b. Remove physical ports from the interface groups:

```
network port ifgrp remove-port -node node-name -ifgrp interface-group-name
-port portid
```

For example:

network port ifgrp remove-port -node nodel -ifgrp ala -port e0d

c. Remove VLAN and interface group ports from broadcast domain::

network port broadcast-domain remove-ports -ipspace ipspace -broadcast -domain broadcast-domain-name -ports nodename:portname,nodename:portname,..

d. Modify interface group ports to use other physical ports as member as needed .:

```
ifgrp add-port -node node-name -ifgrp interface-group-name -port port-id
```

5. Halt the nodes:

halt -inhibit-takeover true -node node-name

This step must be performed on both nodes.

Removing the old platforms

The old controllers must be removed from the configuration.

About this task

This task is performed on site_B.

Steps

- 1. Connect to the serial console of the old controllers (node_B_1-old and node_B_2-old) at site_B and verify it is displaying the LOADER prompt.
- 2. Disconnect the storage and network connections on node_B_1-old and node_B_2-old and label the cables so they can be reconnected to the new nodes.
- 3. Disconnect the power cables from node_B_1-old and node_B_2-old.
- 4. Remove the node_B_1-old and node_B_2-old controllers from the rack.

Configuring the new controllers

You must rack and install the controllers, perform required setup in Maintenance mode, and then boot the controllers, and verify the LIF configuration on the controllers.

Setting up the new controllers

You must rack and cable the new controllers.

Steps

1. Plan out the positioning of the new controller modules and storage shelves as needed.

The rack space depends on the platform model of the controller modules, the switch types, and the number of storage shelves in your configuration.

- 2. Properly ground yourself.
- 3. Install the controller modules in the rack or cabinet.

ONTAP Hardware Systems Documentation

4. If the new controller modules did not come with FC-VI cards of their own and if FC-VI cards from old controllers are compatible on new controllers, swap FC-VI cards and install those in correct slots.

See the NetApp Hardware Universe for slot info for FC-VI cards.

5. Cable the controllers' power, serial console and management connections as described in the *MetroCluster Installation and Configuration Guides*.

Do not connect any other cables that were disconnected from old controllers at this time.

ONTAP Hardware Systems Documentation

6. Power up the new nodes and press Ctrl-C when prompted to display the LOADER prompt.

Netbooting the new controllers

After you install the new nodes, you need to netboot to ensure the new nodes are running the same version of ONTAP as the original nodes. The term netboot means you are booting from an ONTAP image stored on a remote server. When preparing for netboot, you must put a copy of the ONTAP 9 boot image onto a web server that the system can access.

This task is performed on each of the new controller modules.

Steps

- 1. Access the NetApp Support Site to download the files used for performing the netboot of the system.
- 2. Download the appropriate ONTAP software from the software download section of the NetApp Support Site and store the ontap-version_image.tgz file on a web-accessible directory.
- 3. Go to the web-accessible directory and verify that the files you need are available.

If the platform model is	Then
FAS/AFF8000 series systems	Extract the contents of the ontap- version_image.tgzfile to the target directory: tar -zxvf ontap-version_image.tgz
	NOTE: If you are extracting the contents on Windows, use 7-Zip or WinRAR to extract the netboot image.
	Your directory listing should contain a netboot folder with a kernel file:netboot/kernel
All other systems	Your directory listing should contain a netboot folder with a kernel file: ontap-version_image.tgz
	You do not need to extract the ontap- version_image.tgz file.

- 4. At the LOADER prompt, configure the netboot connection for a management LIF:
 - If IP addressing is DHCP, configure the automatic connection:

ifconfig eOM -auto

• If IP addressing is static, configure the manual connection:

ifconfig eOM -addr=ip addr -mask=netmask-gw=gateway

- 5. Perform the netboot.
 - If the platform is an 80xx series system, use this command:

netboot http://web_server_ip/path_to_web-accessible_directory/netboot/kernel

• If the platform is any other system, use the following command:

```
netboot http://web_server_ip/path_to_web-accessible_directory/ontap-
version image.tgz
```

From the boot menu, select option (7) Install new software first to download and install the new software image to the boot device.

Disregard the following message: "This procedure is not supported for Non-Disruptive Upgrade on an HA pair". It applies to nondisruptive upgrades of software, not to upgrades of controllers.

7. If you are prompted to continue the procedure, enter y, and when prompted for the package, enter the URL of the image file: http://web_server_ip/path_to_web-accessible_directory/ontap-version_image.tgz

Enter username/password if applicable, or press Enter to continue.

8. Be sure to enter n to skip the backup recovery when you see a prompt similar to the following:

Do you want to restore the backup configuration now? {y|n}

9. Reboot by entering y when you see a prompt similar to the following:

```
The node must be rebooted to start using the newly installed software. Do you want to reboot now? \{y|n\}
```

Clearing the configuration on a controller module

Before using a new controller module in the MetroCluster configuration, you must clear the existing configuration.

Steps

1. If necessary, halt the node to display the LOADER prompt:

halt

2. At the LOADER prompt, set the environmental variables to default values:

set-defaults

3. Save the environment:

saveenv

4. At the LOADER prompt, launch the boot menu:

boot_ontap menu

5. At the boot menu prompt, clear the configuration:

wipeconfig

Respond yes to the confirmation prompt.

The node reboots and the boot menu is displayed again.

6. At the boot menu, select option **5** to boot the system into Maintenance mode.

Respond yes to the confirmation prompt.

Restoring the HBA configuration

Depending on the presence and configuration of HBA cards in the controller module, you need to configure them correctly for your site's usage.

Steps

- 1. In Maintenance mode configure the settings for any HBAs in the system:
 - a. Check the current settings of the ports: ucadmin show
 - b. Update the port settings as needed.

If you have this type of HBA and desired mode…	Use this command
CNA FC	ucadmin modify -m fc -t initiator <i>adapter-name</i>
CNA Ethernet	ucadmin modify -mode cna adapter-name
FC target	fcadmin config -t target <i>adapter-name</i>
FC initiator	fcadmin config -t initiator adapter-name

2. Exit Maintenance mode:

halt

After you run the command, wait until the node stops at the LOADER prompt.

3. Boot the node back into Maintenance mode to enable the configuration changes to take effect:

boot_ontap maint

4. Verify the changes you made:

If you have this type of HBA	Use this command
CNA	ucadmin show
FC	fcadmin show

Setting the HA state on the new controllers and chassis

You must verify the HA state of the controllers and chassis, and, if necessary, update the state to match your system configuration.

Steps

1. In Maintenance mode, display the HA state of the controller module and chassis:

ha-config show

The HA state for all components should be mcc.

If the MetroCluster configuration has	The HA state should be
Two nodes	mcc-2n
Four or eight nodes	mcc

2. If the displayed system state of the controller is not correct, set the HA state for the controller module and chassis:

If the MetroCluster configuration has	Issue these commands
Two nodes	ha-config modify controller mcc-2n
	ha-config modify chassis mcc-2n
Four or eight nodes	ha-config modify controller mcc
	ha-config modify chassis mcc

Reassigning root aggregate disks

Reassign the root aggregate disks to the new controller module, using the sysids gathered earlier

About this task

This task is performed in Maintenance mode.

The old system IDs were identified in Gathering information before the upgrade.

The examples in this procedure use controllers with the following system IDs:

Node	Old system ID	New system ID
node_B_1	4068741254	1574774970

Steps

- 1. Cable all other connections to the new controller modules (FC-VI, storage, cluster interconnect, etc.).
- 2. Halt the system and boot to Maintenance mode from the LOADER prompt:

boot_ontap maint

3. Display the disks owned by node_B_1-old:

disk show -a

The command output shows the system ID of the new controller module (1574774970). However, the root aggregate disks are still owned by the old system ID (4068741254). This example does not show drives owned by other nodes in the MetroCluster configuration.

```
*> disk show -a
Local System ID: 1574774970
  DISK
             OWNER
                                      POOL
                                            SERIAL NUMBER
                                                             HOME
DR HOME
_____
              _____
                                             _____
_____
                        _____
rr18:9.126L44 node B 1-old(4068741254) Pool1 PZHYNOMD
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:9.126L49 node B 1-old(4068741254) Pool1 PPG3J5HA
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:8.126L21 node B 1-old(4068741254) Pool1 PZHTDSZD
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:8.126L2 node B 1-old(4068741254) Pool0 SOM1J2CF
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:8.126L3 node B 1-old(4068741254) Pool0 SOM0CQM5
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:9.126L27 node B 1-old(4068741254)
                                      Pool0 SOM1PSDW
node B 1-old(4068741254) node B 1-old(4068741254)
. . .
```

4. Reassign the root aggregate disks on the drive shelves to the new controller:

disk reassign -s old-sysid -d new-sysid

The following example shows reassignment of drives:

```
*> disk reassign -s 4068741254 -d 1574774970
Partner node must not be in Takeover mode during disk reassignment from
maintenance mode.
Serious problems could result!!
Do not proceed with reassignment if the partner is in takeover mode.
Abort reassignment (y/n)? n
After the node becomes operational, you must perform a takeover and
giveback of the HA partner node to ensure disk reassignment is
successful.
Do you want to continue (y/n)? Jul 14 19:23:49
[localhost:config.bridge.extra.port:error]: Both FC ports of FC-to-SAS
bridge rtp-fc02-41-rr18:9.126L0 S/N [FB7500N107692] are attached to this
controller.
У
Disk ownership will be updated on all disks previously belonging to
Filer with sysid 4068741254.
Do you want to continue (y/n)? y
```

5. Check that all disks are reassigned as expected:

disk show

```
*> disk show
Local System ID: 1574774970
 DISK
           OWNER
                                      POOL SERIAL NUMBER
                                                          HOME
DR HOME
_____
             _____
                                             _____
_____
rr18:8.126L18 node B 1-new(1574774970) Pool1 PZHYNOMD
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:9.126L49 node B 1-new(1574774970) Pool1 PPG3J5HA
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:8.126L21 node B 1-new(1574774970) Pool1 PZHTDSZD
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:8.126L2 node B 1-new(1574774970) Pool0 SOM1J2CF
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:9.126L29 node B 1-new(1574774970) Pool0 SOMOCQM5
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:8.126L1 node B 1-new(1574774970) Pool0 SOM1PSDW
node B 1-new(1574774970) node B 1-new(1574774970)
*>
```

6. Display the aggregate status:

aggr status

7. Repeat the above steps on the partner node (node_B_2-new).

Booting up the new controllers

You must reboot the controllers from the boot menu to update the controller flash image. Additional steps are required if encryption is configured.

About this task

This task must be performed on all the new controllers.

Steps

1. Halt the node:

halt

2. If external key manager is configured, set the related bootargs:

```
setenv bootarg.kmip.init.ipaddr ip-address
```

setenv bootarg.kmip.init.netmask netmask

setenv bootarg.kmip.init.gateway gateway-address

setenv bootarg.kmip.init.interface interface-id

3. Display the boot menu:

boot_ontap menu

4. If root encryption is used, depending on the ONTAP version you are using, select the boot menu option or issue the boot menu command for your key management configuration.

ONTAP 9.8 and later

Beginning with ONTAP 9.8, select the boot menu option.

If you are using	Select this boot menu option…
Onboard key management	Option "10" Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.
External key management	Option "11" Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.

ONTAP 9.7 and earlier

For ONTAP 9.7 and earlier, issue the boot menu command.

If you are using	Issue this command at the boot menu prompt
Onboard key management	recover_onboard_keymanager
External key management	recover_external_keymanager

- 5. If autoboot is enabled, interrupt autoboot by pressing CTRL-C.
- 6. From the boot menu, run option "6".



Option "6" will reboot the node twice before completing.

Respond "y" to the system id change prompts. Wait for the second reboot messages:

Successfully restored env file from boot media...

Rebooting to load the restored env file...

7. Double-check that the partner-sysid is correct:

printenv partner-sysid

If the partner-sysid is not correct, set it:

```
setenv partner-sysid partner-sysID
```

8. If root encryption is used, depending on the ONTAP version you are using, select the boot menu option or issue the boot menu command again for your key management configuration.

ONTAP 9.8 and later

Beginning with ONTAP 9.8, select the boot menu option.

If you are using	Select this boot menu option
Onboard key management	Option "10" Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.
External key management	Option "11" Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.

Depending on the key manager setting, perform the recovery procedure by selecting option "10" or option "11", followed by option "6" at the first boot menu prompt. To boot the nodes completely, you might need to repeat the recovery procedure continued by option "1" (normal boot).

ONTAP 9.7 and earlier

For ONTAP 9.7 and earlier, issue the boot menu command.

If you are using	Issue this command at the boot menu prompt
Onboard key management	recover_onboard_keymanager
External key management	recover_external_keymanager

You might need to issue the recover_xxxxxx_keymanager command at the boot menu prompt multiple times until the nodes completely boot.

9. Boot the nodes:

boot_ontap

10. Wait for the replaced nodes to boot up.

If either node is in takeover mode, perform a giveback:

storage failover giveback

- 11. Verify that all ports are in a broadcast domain:
 - a. View the broadcast domains:

network port broadcast-domain show

b. Add any ports to a broadcast domain as needed.

Adding or removing ports from a broadcast domain

- c. Add the physical port that will host the intercluster LIFs to the corresponding Broadcast domain.
- d. Modify intercluster LIFs to use the new physical port as home port.
- e. After the intercluster LIFs are up, check the cluster peer status and re-establish cluster peering as needed.

You might need to reconfigure cluster peering.

Creating a cluster peer relationship

f. Recreate VLANs and interface groups as needed.

VLAN and interface group membership might be different than that of the old node.

Creating a VLAN

Combining physical ports to create interface groups

12. If encryption is used, restore the keys using the correct command for your key management configuration.

If you are using	Use this command
Onboard key management	security key-manager onboard sync For more information, see Restoring onboard key management encryption keys.
External key management	<pre>security key-manager external restore -vserver SVM -node node -key-server host_name IP_address:port -key-id key_id -key-tag key_tag node-name For more information, see Restoring external key management encryption keys.</pre>

Verifying LIF configuration

Verify that LIFs are hosted on appropriate node/ports prior to switchback. The following steps need to be performed

About this task

This task is performed on site_B, where the nodes have been booted up with root aggregates.

Steps

1. Verify that LIFs are hosted on the appropriate node and ports prior to switchback.

a. Change to the advanced privilege level:

set -privilege advanced

b. Override the port configuration to ensure proper LIF placement:

```
vserver config override -command "network interface modify -vserver
vserver_name -home-port active_port_after_upgrade -lif lif_name -home-node
new node name"
```

When entering the network interface modify command within the vserver config override command, you cannot use the tab autocomplete feature. You can create the network interface modify using autocomplete and then enclose it in the vserver config override command.

- c. Return to the admin privilege level: set -privilege admin
- 2. Revert the interfaces to their home node:

```
network interface revert * -vserver vserver-name
```

Perform this step on all SVMs as required.

Install the new licenses

Before the switchback operation, you must install licenses for the new controllers.

Steps

1. Installing licenses for the new controller module

Switching back the MetroCluster configuration

After the new controllers have been configured, you switch back the MetroCluster configuration to return the configuration to normal operation.

About this task

In this task, you will perform the switchback operation, returning the MetroCluster configuration to normal operation. The nodes on site_A are still awaiting upgrade.



Steps

- 1. Issue the metrocluster node show command on site_B and check the output.
 - a. Verify that the new nodes are represented correctly.
 - b. Verify that the new nodes are in "Waiting for switchback state."
- 2. Switchback the cluster:

metrocluster switchback

3. Check the progress of the switchback operation:

metrocluster show

The switchback operation is still in progress when the output displays waiting-for-switchback:

```
cluster B::> metrocluster show
Cluster
                      Entry Name
                                        State
_____
                  ____ ____
Local: cluster B
                      Configuration state configured
                      Mode
                                        switchover
                      AUSO Failure Domain -
Remote: cluster A
                      Configuration state configured
                      Mode
                                        waiting-for-switchback
                      AUSO Failure Domain -
```

The switchback operation is complete when the output displays normal:

cluster_B::> metrocluster Cluster	show Entry Name	State
Local: cluster_B	Configuration state Mode	configured normal
Remote: cluster_A	AUSO Failure Domain Configuration state Mode	- configured normal
	AUSO Failure Domain	-

If a switchback takes a long time to finish, you can check on the status of in-progress baselines by using the metrocluster config-replication resync-status show command. This command is at the advanced privilege level.

Checking the health of the MetroCluster configuration

After upgrading the controller modules you must verify the health of the MetroCluster configuration.

About this task

This task can be performed on any node in the MetroCluster configuration.

Steps

- 1. Verify the operation of the MetroCluster configuration:
 - a. Confirm the MetroCluster configuration and that the operational mode is normal:

metrocluster show

b. Perform a MetroCluster check:

metrocluster check run

c. Display the results of the MetroCluster check:

metrocluster check show



After you run metrocluster check run and metrocluster check show, you see an error message similar to the following:

Example

Failed to validate the node and cluster components before the switchover operation. Cluster_A:: node_A_1 (non-overridable veto): DR partner NVLog mirroring is not online. Make sure that the links between the two sites are healthy and properly configured.

This is expected behavior due to a controller mismatch during the upgrade process and the error

message can be safely ignored.

Upgrading the nodes on cluster_A

You must repeat the upgrade tasks on cluster_A.

Step

1. Repeat the steps to upgrade the nodes on cluster_A, beginning with Preparing for the upgrade.

As you perform the tasks, all example references to the clusters and nodes are reversed. For example, when the example is given to switchover from cluster_A, you will switchover from cluster_B.

Sending a custom AutoSupport message after maintenance

After completing the upgrade, you should send an AutoSupport message indicating the end of maintenance, so automatic case creation can resume.

Step

- 1. To resume automatic support case generation, send an AutoSupport message to indicate that the maintenance is complete.
 - a. Issue the following command:

system node autosupport invoke -node * -type all -message MAINT=end

b. Repeat the command on the partner cluster.

Restoring Tiebreaker monitoring

If the MetroCluster configuration was previously configured for monitoring by the Tiebreaker software, you can restore the Tiebreaker connection.

1. Use the steps in Adding MetroCluster configurations in MetroCluster Tiebreaker Installation and Configuration.

Upgrade controllers from AFF A700/FAS9000 to AFF A900/FAS9500 in a MetroCluster FC configuration using switchover and switchback (ONTAP 9.10.1 or later)

You can use the MetroCluster switchover operation to provide nondisruptive service to clients while the controller modules on the partner cluster are upgraded. You cannot upgrade other components (such as storage shelves or switches) as part of this procedure.

About this task

• You can use this procedure only for controller upgrade.

You cannot upgrade other components in the configuration, such as storage shelves or switches, at the same time.

- You can use this procedure to upgrade an AFF A700 to AFF A900 with ONTAP 9.10.1 and later.
- You can use this procedure to upgrade a FAS9000 to FAS9500 with ONTAP 9.10.1P3 and later.
 - Four and eight-node configurations are supported in ONTAP 9.10.1 and later.



The AFF A900 system is only supported in ONTAP 9.10.1 or later.

NetApp Hardware Universe

• All controllers in the configuration should be upgraded during the same maintenance period.

The following table shows the supported model matrix for the controller upgrade.

Old platform model	New platform model
• AFF A700	• AFF A900
• FAS9000	• FAS9500

- During the upgrade procedure, you are required to change the MetroCluster fabric, including the RCF and physical changes of cabling. You can perform the RCF and cabling changes before performing the controller upgrade.
- This upgrade procedure does not require you do not change the storage, FC, and Ethernet connections between the original nodes and the new nodes.
- During the upgrade procedure, you should not add or remove other cards from the AFF A700 or FAS9000 system. For more information, see the NetApp Hardware Universe

The following example names are used in examples and graphics in this procedure:

- site_A
 - Before upgrade:
 - node_A_1-A700
 - node_A_2-A700
 - After upgrade:
 - node_A_1-A900
 - node_A_2-A900
- site_B
 - Before upgrade:
 - node_B_1-A700
 - node_B_2-A700
 - After upgrade:
 - node_B_1-A900
 - node_B_2-A900

Prepare for the upgrade

Before making any changes to the existing MetroCluster configuration, you must check the health of the configuration, change the RCF files and cabling to match to new port connectivity topology required for the AFF A900 or FAS9000 fabric MetroCluster configuration, and perform other miscellaneous tasks.

Clear slot 7 on the AFF A700 controller

The MetroCluster configuration on an AFF A900 or FAS9500 requires 8 FC-VI ports across FC-VI cards in slots 5 and 7. Before starting the upgrade, if there are cards in slot 7 on the AFF A700 or FAS9000, you must move them to other slots for all the nodes of the cluster.

Verify the health of the MetroCluster configuration

Before you update the RCF files and cabling for the AFF A900 or FAS9500 fabric MetroCluster configuration, you must verify the health and connectivity of the configuration.

Steps

- 1. Verify the operation of the MetroCluster configuration in ONTAP:
 - a. Check whether the nodes are multipathed: node run -node *node-name* sysconfig -a

You should issue this command for each node in the MetroCluster configuration.

b. Verify that there are no broken disks in the configuration:

storage disk show -broken

You should issue this command on each node in the MetroCluster configuration.

c. Check for any health alerts:

system health alert show

You should issue this command on each cluster.

d. Verify the licenses on the clusters:

system license show

You should issue this command on each cluster.

e. Verify the devices connected to the nodes:

network device-discovery show

You should issue this command on each cluster.

f. Verify that the time zone and time are set correctly on both sites:

cluster date show

You should issue this command on each cluster. You can use the cluster date commands to configure the time and time zone.

2. Check for any health alerts on the switches (if present):

storage switch show

You should issue this command on each cluster.

- 3. Confirm the operational mode of the MetroCluster configuration and perform a MetroCluster check.
 - a. Confirm the MetroCluster configuration and that the operational mode is normal:

metrocluster show

b. Confirm that all expected nodes are shown:

metrocluster node show

c. Issue the following command:

metrocluster check run

d. Display the results of the MetroCluster check:

metrocluster check show

- 4. Check the MetroCluster cabling with the Config Advisor tool.
 - a. Download and run Config Advisor.

NetApp Downloads: Config Advisor

b. After running Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.

Update the fabric switch RCF files

The AFF A900 or FAS9500 fabric MetroCluster requires two four-port FC-VI adapters per node compared to a single four-port FC-VI adapter required by an AFF A700. Before you start the controller upgrade to the AFF A900 or FAS9500 controller, you must modify the fabric switch RCF files to support the AFF A900 or FAS9500 connection topology.

- 1. From the MetroCluster RCF file download page, download the correct RCF file for an AFF A900 or FAS9500 fabric MetroCluster and the switch model that is in use on the AFF A700 or FAS9000 configuration.
- 2. Update the RCF file on the fabric A switches, switch A1, and switch B1 by following the steps in Configuring the FC switches.



The RCF file update to support the AFF A900 or FAS9500 fabric MetroCluster configuration does not affect the port and connections used for the AFF A700 or FAS9000 fabric MetroCluster configuration.

3. After updating the RCF files on the fabric A switches, all storage and FC-VI connections should come online. Check the FC-VI connections:

metrocluster interconnect mirror show

- a. Verify that the local and remote site disks are listed in the sysconfig output.
- 4. You must verify that MetroCluster is in a healthy state after the RCF file update for fabric A switches.
 - a. Check metro cluster connections: metrocluster interconnect mirror show
 - b. Run metrocluster check: metrocluster check run
 - c. See the MetroCluster run results when the run completes: metrocluster check show
- 5. Update the fabric B switches (switches 2 and 4) by repeating Step 2 to Step 5.

Verify the health of the MetroCluster configuration after the RCF file update

You must verify the health and connectivity of the MetroCluster configuration before performing the upgrade.

Steps

- 1. Verify the operation of the MetroCluster configuration in ONTAP:
 - a. Check whether the nodes are multipathed: node run -node node-name sysconfig -a

You should issue this command for each node in the MetroCluster configuration.

b. Verify that there are no broken disks in the configuration:

storage disk show -broken

You should issue this command on each node in the MetroCluster configuration.

c. Check for any health alerts:

system health alert show

You should issue this command on each cluster.

d. Verify the licenses on the clusters:

system license show

You should issue this command on each cluster.

e. Verify the devices connected to the nodes:

network device-discovery show

You should issue this command on each cluster.

f. Verify that the time zone and time are set correctly on both sites:

cluster date show

You should issue this command on each cluster. You can use the cluster date commands to configure the time and time zone.

2. Check for any health alerts on the switches (if present):

storage switch show

You should issue this command on each cluster.

- 3. Confirm the operational mode of the MetroCluster configuration and perform a MetroCluster check.
 - a. Confirm the MetroCluster configuration and that the operational mode is normal:

metrocluster show

b. Confirm that all expected nodes are shown:

metrocluster node show

c. Issue the following command:

metrocluster check run

d. Display the results of the MetroCluster check:

metrocluster check show

- 4. Check the MetroCluster cabling with the Config Advisor tool.
 - a. Download and run Config Advisor.

NetApp Downloads: Config Advisor

b. After running Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.

Map ports from the AFF A700 or FAS9000 nodes to the AFF A900 or FAS9500 nodes

During the controller upgrade process, you must only change the connections that are mentioned in this procedure.

If the AFF A700 or FAS9000 controllers have a card in slot 7, you should move it to another slot before starting the controller upgrade procedure. You must have slot 7 available for the addition of the second FC-VI adapter that is required for the functioning of fabric MetroCluster on the AFF A900 or FAS9500 controllers.

Gather information before the upgrade

Before upgrading, you must gather information for each of the old nodes, and, if necessary, adjust the network broadcast domains, remove any VLANs and interface groups, and gather encryption information.

About this task

This task is performed on the existing MetroCluster FC configuration.

Steps

1. Gather the MetroCluster configuration node system IDs:

metrocluster node show -fields node-systemid, dr-partner-systemid

During the upgrade procedure, you will replace these old system IDs with the system IDs of the controller modules.

In this example for a four-node MetroCluster FC configuration, the following old system IDs are retrieved:

- node_A_1-A700: 537037649
- node_A_2-A700: 537407030
- node_B_1-A700: 0537407114
- node_B_2-A700: 537035354

```
Cluster A::*> metrocluster node show -fields node-systemid, ha-partner-
systemid, dr-partner-systemid, dr-auxiliary-systemid
dr-group-id cluster
                 node
                              node-systemid ha-partner-systemid
dr-partner-systemid dr-auxiliary-systemid
 _____ _ ____
-----
        Cluster A nodeA 1-A700 537407114 537035354
1
537411005
               537410611
       Cluster A nodeA 2-A700 537035354 537407114
1
               537411005
537410611
                                         537411005
1
       Cluster B nodeB 1-A700 537410611
537035354
               537407114
         Cluster B nodeB 2-A700 537411005
1
4 entries were displayed.
```

2. Gather port and LIF information for each old node.

You should gather the output of the following commands for each node:

 $^\circ$ network interface show -role cluster,node-mgmt

- ° network port show -node node-name -type physical
- ° network port vlan show -node node-name
- ° network port ifgrp show -node node_name -instance
- ° network port broadcast-domain show
- ° network port reachability show -detail
- ° network ipspace show
- ° volume show
- ° storage aggregate show
- ° system node run -node node-name sysconfig -a
- 3. If the MetroCluster nodes are in a SAN configuration, collect the relevant information.

You should gather the output of the following commands:

° fcp adapter show -instance

° fcp interface show -instance

° iscsi interface show

° ucadmin show

4. If the root volume is encrypted, collect and save the passphrase used for key-manager:

security key-manager backup show

5. If the MetroCluster nodes are using encryption for volumes or aggregates, copy information about the keys and passphrases.

For additional information, see Backing up onboard key management information manually.

a. If Onboard Key Manager is configured:

security key-manager onboard show-backup

You will need the passphrase later in the upgrade procedure.

b. If enterprise key management (KMIP) is configured, issue the following commands:

security key-manager external show -instance security key-manager key query

Remove the existing configuration from the Tiebreaker or other monitoring software

If the existing configuration is monitored with the MetroCluster Tiebreaker configuration or other third-party applications (for example, ClusterLion) that can initiate a switchover, you must remove the MetroCluster configuration from the Tiebreaker or other software prior to transition.

Steps

1. Remove the existing MetroCluster configuration from the Tiebreaker software.

Removing MetroCluster Configurations

2. Remove the existing MetroCluster configuration from any third-party application that can initiate switchover.

Refer to the documentation for the application.

Send a custom AutoSupport message prior to maintenance

Before performing the maintenance, you should issue an AutoSupport message to notify NetApp technical support that maintenance is underway. Informing technical support that maintenance is underway prevents them from opening a case on the assumption that a disruption has occurred.

About this task

This task must be performed on each MetroCluster site.

Steps

1. To prevent automatic support case generation, send an Autosupport message to indicate maintenance is underway.

a. Issue the following command:

system node autosupport invoke -node * -type all -message MAINT=maintenancewindow-in-hours

maintenance-window-in-hours specifies the length of the maintenance window, with a maximum of 72 hours. If the maintenance is completed before the time has elapsed, you can invoke an AutoSupport message indicating the end of the maintenance period:

system node autosupport invoke -node * -type all -message MAINT=end

b. Repeat the command on the partner cluster.

Switch over the MetroCluster configuration

You must switch over the configuration to site_A so that the platforms on site_B can be upgraded.

About this task

This task must be performed on site_A.

After completing this task, site_A is active and serving data for both sites. Site_B is inactive, and ready to begin the upgrade process, as shown in the following illustration. (This illustration also applies to upgrading a FAS9000 to a FAS9500 controller.)



Steps

- 1. Switch over the MetroCluster configuration to site_A so that site_B's nodes can be upgraded:
 - a. Issue the following command on site_A:

metrocluster switchover -controller-replacement true

The operation can take several minutes to complete.

b. Monitor the switchover operation:

metrocluster operation show

c. After the operation is complete, confirm that the nodes are in switchover state:

metrocluster show

d. Check the status of the MetroCluster nodes:

metrocluster node show

- 2. Heal the data aggregates.
 - a. Heal the data aggregates:

metrocluster heal data-aggregates

b. Confirm the heal operation is complete by running the metrocluster operation show command on the healthy cluster:

```
cluster_A::> metrocluster operation show
Operation: heal-aggregates
State: successful
Start Time: 7/29/2020 20:54:41
End Time: 7/29/2020 20:54:42
Errors: -
```

- 3. Heal the root aggregates.
 - a. Heal the data aggregates:

metrocluster heal root-aggregates

b. Confirm the heal operation is complete by running the metrocluster operation show command on the healthy cluster:

```
cluster_A::> metrocluster operation show
Operation: heal-root-aggregates
State: successful
Start Time: 7/29/2020 20:58:41
End Time: 7/29/2020 20:59:42
Errors: -
```

Remove the AFF A700 or FAS9000 controller module and NVS at site_B

You must remove the old controllers from the configuration.

You perform this task on site_B.

Before you begin

If you are not already grounded, properly ground yourself.

Steps

- 1. Connect to the serial console of the old controllers (node_B_1-700 and node_B_2-700) at site_B and verify it is displaying the LOADER prompt.
- 2. Gather the bootarg values from both nodes at site_B: printenv
- 3. Power off the chassis at site_B.

Remove the controller module and NVS from both nodes at site_B

Remove the AFF A700 or FAS9000 controller module

Use the following procedure to remove the AFF A700 or FAS9000 controller module.

Steps

- 1. Detach the console cable, if any, and the management cable from the controller module before removing the controller module.
- 2. Unlock and remove the controller module from the chassis.
 - a. Slide the orange button on the cam handle downward until it unlocks.





Cam handle release button



b. Rotate the cam handle so that it completely disengages the controller module from the chassis, and then slide the controller module out of the chassis. Make sure that you support the bottom of the controller module as you slide it out of the chassis.

Remove the AFF A700 or FAS9000 NVS module

Use the following procedure to remove the AFF A700 or FAS9000 NVS module.



The AFF A700 or FAS9000 NVS module is in slot 6 and is double the height compared to the other modules in the system.

- 1. Unlock and remove the NVS from slot 6.
 - a. Depress the lettered and numbered cam button. The cam button moves away from the chassis.
 - b. Rotate the cam latch down until it is in a horizontal position. The NVS disengages from the chassis and moves a few inches.
 - c. Remove the NVS from the chassis by pulling on the pull tabs on the sides of the module face.



Lettered and numbered I/O cam latch
I/O latch completely unlocked

- Do not transfer any add-on modules used as coredump devices on the AFF A700 nonvolatile storage module in slot 6 to the AFF A900 NVS module. Do not transfer any parts from the AFF A700 controller and NVS modules to the AFF A900 controller module.
- For FAS9000 to FAS9500 upgrades, you should only transfer Flash Cache modules on the FAS9000 NVS module to the FAS9500 NVS module. Do not transfer any other parts from the FAS9000 controller and NVS modules to the FAS9500 controller module.

÷.

Install the AFF A900 or FAS9500 NVS and controller module

You must install the AFF A900 or FAS9500 NVS and controller module from the upgrade kit on both nodes at Site_B. Do not move the coredump device from the AFF A700 or FAS9000 NVS module to the AFF A900 or FAS9500 NVS module.

Before you start

If you are not already grounded, properly ground yourself.

Install the AFF A900 or FAS9500 NVS

Use the following procedure to install the AFF A900 or FAS9500 NVS in slot 6 of both nodes at site_B

Steps

- 1. Align the NVS with the edges of the chassis opening in slot 6.
- 2. Gently slide the NVS into the slot until the lettered and numbered I/O cam latch begins to engage with the I/O cam pin, and then push the I/O cam latch all the way up to lock the NVS in place.



Lettered and numbered I/O cam latch
I/O latch completely unlocked

Install the AFF A900 or FAS9500 controller module

Use the following procedure to install the AFF A900 or FAS9500 controller module.

Steps

- 1. Align the end of the controller module with the opening in the chassis, and then gently push the controller module halfway into the system.
- 2. Firmly push the controller module into the chassis until it meets the midplane and is fully seated. The locking latch rises when the controller module is fully seated.



Do not use excessive force when sliding the controller module into the chassis to avoid damaging the connectors.

3. Cable the management and console ports to the controller module.



Cam handle release button
Cam handle

- 4. Install the second X91129A card in slot 7 of each node.
 - a. Connect FC-VI ports from slot 7 to the switches. Refer to the Fabric-attached installation and configuration documentation and go to the AFF A900 or FAS9500 fabric MetroCluster connection requirements for the type of switch in your environment.
- 5. Power ON the chassis and connect to the serial console.
- 6. After BIOS initialization, if the node starts to autoboot, interrupt the AUTOBOOT by pressing Control-C.
- 7. After you interrupt the autoboot, the nodes stop at the LOADER prompt. If you do not interrupt autoboot on time and node1 starts booting, wait for the prompt to press Control-C to go into the boot menu. After the node stops at the boot menu, use option 8 to reboot the node and interrupt the autoboot during the reboot.
- 8. At the LOADER prompt, set the default environment variables: set-defaults
- 9. Save the default environment variables settings: saveenv

Netboot the nodes at site_B

After swapping the AFF A900 or FAS9500 controller module and NVS, you need to netboot the AFF A900 or FAS9500 nodes and install the same ONTAP version and patch level that is running on the cluster. The term netboot means you are booting from an ONTAP image stored on a remote server. When preparing for netboot, you must add a copy of the ONTAP 9 boot image onto a web server that the system can access.

It is not possible to check the ONTAP version installed on the boot media of an AFF A900 or FAS9500 controller module unless it is installed in a chassis and powered ON. The ONTAP version on the AFF A900 or FAS9500 boot media must be same as the ONTAP version running on the AFF A700 or FAS9000 system that is being upgraded and both the primary and backup boot images should match. You can configure the images

by performing a netboot followed by the wipeconfig command from the boot menu. If the controller module was previously used in another cluster, the wipeconfig command clears any residual configuration on the boot media.

Before you start

- Verify that you can access a HTTP server with the system.
- You need to download the necessary system files for your system and the correct version of ONTAP from the NetApp Support site. About this task You must netboot the new controllers if the version of ONTAP installed is not the same as the version installed on the original controllers. After you install each new controller, you boot the system from the ONTAP 9 image stored on the web server. You can then download the correct files to the boot media device for subsequent system boots.

Steps

- 1. Access NetApp Support to download the files required to perform a system netboot used for performing the netboot of the system.
- 2. Download the appropriate ONTAP software from the software download section of the NetApp Support Site and store the <ontap_version>_image.tgz file on a web-accessible directory.
- 3. Change to the web-accessible directory and verify that the files you need are available. Your directory listing should contain <ontap_version>_image.tgz.
- 4. Configure the netboot connection by choosing one of the following actions. Note: You should use the management port and IP as the netboot connection. Do not use a data LIF IP or a data outage might occur while the upgrade is being performed.

If Dynamic Host Configuration Protocol (DHCP) is	Then
Running	Configure the connection automatically by using the following command at the boot environment prompt: ifconfig eOM -auto
Not running	Manually configure the connection by using the following command at the boot environment prompt: ifconfig eOM -addr= <filer_addr> -mask=<netmask> -gw=<gateway> - dns=<dns_addr> domain=<dns_domain> <filer_addr> is the IP address of the storage system. <netmask> is the network mask of the storage system. <gateway> is the gateway for the storage system. <dns_addr> is the IP address of a name server on your network. This parameter is optional. <dns_domain> is the Domain Name Service (DNS) domain name. This parameter is optional.</dns_domain></dns_addr></gateway></netmask></filer_addr></dns_domain></dns_addr></gateway></netmask></filer_addr>

5. Perform netboot on node 1: netboot http://<web_server_ip/ path_to_web_accessible_directory>/netboot/kernel The <path_to_the_web-</p>

accessible_directory> should lead to where you downloaded the <ontap_version>_image.tgz



Do not interrupt the boot.

6. Wait for node 1 that is running on the AFF A900 or FAS9500 controller module to boot and display the boot menu options as shown below:

```
Please choose one of the following:
(1) Normal Boot.
(2) Boot without /etc/rc.
(3) Change password.
(4)
   Clean configuration and initialize all disks.
(5) Maintenance mode boot.
   Update flash from backup config.
(6)
   Install new software first.
(7)
(8) Reboot node.
(9) Configure Advanced Drive Partitioning.
(10) Set Onboard Key Manager recovery secrets.
(11) Configure node for external key management.
Selection (1-11)?
```

7. From the boot menu, select option (7) Install new software first. This menu option downloads and installs the new ONTAP image to the boot device.



Disregard the following message: This procedure is not supported for Non-Disruptive Upgrade on an HA pair. This note applies to nondisruptive ONTAP software upgrades, and not controller upgrades. Always use netboot to update the new node to the desired image. If you use another method to install the image on the new controller, the wrong incorrect image might install. This issue applies to all ONTAP releases.

8. If you are prompted to continue the procedure, enter y, and when prompted for the package, enter the URL:

```
http://<web_server_ip/path_to_web-
accessible directory>/<ontap version> image.tgz
```

- 9. Complete the following substeps to reboot the controller module:
 - a. Enter n to skip the backup recovery when you see the following prompt: Do you want to restore the backup configuration now? {y|n}
 - b. Enter y to reboot when you see the following prompt: The node must be rebooted to start using the newly installed software. Do you want to reboot now? {y|n}

The controller module reboots but stops at the boot menu because the boot device was reformatted, and the configuration data needs to be restored.

10. At the prompt, run the wipeconfig command to clear any previous configuration on the boot media:

- a. When you see the message below, answer yes: This will delete critical system configuration, including cluster membership. Warning: do not run this option on a HA node that has been taken over. Are you sure you want to continue?:
- b. The node reboots to finish the wipeconfig and then stops at the boot menu.
- 11. Select option 5 to go to maintenance mode from the boot menu. Answer yes to the prompts until the node stops at maintenance mode and the command prompt *>.

Restore the HBA configuration

Depending on the presence and configuration of HBA cards in the controller module, you need to configure them correctly for your site's usage.

Steps

- 1. In Maintenance mode configure the settings for any HBAs in the system:
 - a. Check the current settings of the ports: ucadmin show
 - b. Update the port settings as needed.

If you have this type of HBA and desired mode	Use this command
CNA FC	ucadmin modify -m fc -t initiator adapter-name
CNA Ethernet	ucadmin modify -mode cna adapter-name
FC target	fcadmin config -t target <i>adapter-name</i>
FC initiator	fcadmin config -t initiator <i>adapter-</i> <i>name</i>

Set the HA state on the new controllers and chassis

You must verify the HA state of the controllers and chassis, and, if necessary, update the state to match your system configuration.

Steps

1. In Maintenance mode, display the HA state of the controller module and chassis:

ha-config show

The HA state for all components should be mcc.

2. If the displayed system state of the controller or chassis is not correct, set the HA state:

ha-config modify controller mcc

ha-config modify chassis mcc

3. Halt the node: halt The node should stop at the LOADER> prompt.

- 4. On each node, check the system date, time, and time zone: Show date
- 5. If necessary, set the date in UTC or Greenwich Mean Time (GMT): set date <mm/dd/yyyy>
- 6. Check the time by using the following command at the boot environment prompt: show time
- 7. If necessary, set the time in UTC or GMT: set time <hh:mm:ss>
- 8. Save the settings: saveenv
- 9. Gather environment variables: printenv
- 10. Boot the node back into Maintenance mode to enable the configuration changes to take effect: boot_ontap maint
- 11. Verify the changes you made are effective and ucadmin shows FC initiator ports online.

If you have this type of HBA	Use this command
CNA	ucadmin show
FC	fcadmin show

- 12. Verify the ha-config mode: ha-config show
 - a. Verify that you have the following output:

```
*> ha-config show
Chassis HA configuration: mcc
Controller HA configuration: mcc
```

Set the HA state on the new controllers and chassis

You must verify the HA state of the controllers and chassis, and, if necessary, update the state to match your system configuration.

Steps

1. In Maintenance mode, display the HA state of the controller module and chassis:

ha-config show

The HA state for all components should be mcc.

If the MetroCluster configuration has	The HA state should be
Two nodes	mcc-2n
Four or eight nodes	mcc

2. If the displayed system state of the controller is not correct, set the HA state for the controller module and chassis:
| If the MetroCluster configuration has | Issue these commands |
|---------------------------------------|------------------------------------|
| Two nodes | ha-config modify controller mcc-2n |
| | ha-config modify chassis mcc-2n |
| Four or eight nodes | ha-config modify controller mcc |
| | ha-config modify chassis mcc |

Reassign root aggregate disks

Reassign the root aggregate disks to the new controller module, using the sysids gathered earlier

About this task

This task is performed in Maintenance mode.

The old system IDs were identified in Gathering information before the upgrade.

The examples in this procedure use controllers with the following system IDs:

Node	Old system ID	New system ID
node_B_1	4068741254	1574774970

Steps

- 1. Cable all other connections to the new controller modules (FC-VI, storage, cluster interconnect, etc.).
- 2. Halt the system and boot to Maintenance mode from the LOADER prompt:

boot_ontap maint

3. Display the disks owned by node_B_1-A700:

disk show -a

The example output shows the system ID of the new controller module (1574774970). However, the root aggregate disks are still owned by the old system ID (4068741254). This example does not show drives owned by other nodes in the MetroCluster configuration.

```
*> disk show -a
Local System ID: 1574774970
 DISK OWNER
                                     POOL SERIAL NUMBER
                                                          HOME
DR HOME
-----
                                     _____
_____
                       _____
rr18:9.126L44 node B 1-A700(4068741254) Pool1 PZHYNOMD
node B 1-A700(4068741254) node B 1-A700(4068741254)
rr18:9.126L49 node_B_1-A700(4068741254) Pool1 PPG3J5HA
node B 1-A700(4068741254) node B 1-A700(4068741254)
rr18:8.126L21 node B 1-A700(4068741254) Pool1 PZHTDSZD
node B 1-A700(4068741254) node B 1-A700(4068741254)
rr18:8.126L2 node B 1-A700(4068741254) Pool0 SOM1J2CF
node B 1-A700(4068741254) node B 1-A700(4068741254)
rr18:8.126L3 node B 1-A700(4068741254) Pool0 SOM0CQM5
node B 1-A700(4068741254) node B 1-A700(4068741254)
rr18:9.126L27 node B 1-A700(4068741254) Pool0 SOM1PSDW
node B 1-A700(4068741254) node B 1-A700(4068741254)
. . .
```

4. Reassign the root aggregate disks on the drive shelves to the new controller:

disk reassign -s old-sysid -d new-sysid

The following example shows reassignment of drives:

```
*> disk reassign -s 4068741254 -d 1574774970
Partner node must not be in Takeover mode during disk reassignment from
maintenance mode.
Serious problems could result!!
Do not proceed with reassignment if the partner is in takeover mode.
Abort reassignment (y/n)? n
After the node becomes operational, you must perform a takeover and
giveback of the HA partner node to ensure disk reassignment is
successful.
Do you want to continue (y/n)? Jul 14 19:23:49
[localhost:config.bridge.extra.port:error]: Both FC ports of FC-to-SAS
bridge rtp-fc02-41-rr18:9.126L0 S/N [FB7500N107692] are attached to this
controller.
V
Disk ownership will be updated on all disks previously belonging to
Filer with sysid 4068741254.
Do you want to continue (y/n)? y
```

5. Check that all disks are reassigned as expected: disk show

```
*> disk show
Local System ID: 1574774970
  DISK
           OWNER
                                     POOL SERIAL NUMBER HOME
DR HOME
_____
                                            _____
_____
rr18:8.126L18 node B 1-A900(1574774970) Pool1 PZHYNOMD
node B 1-A900(1574774970) node B 1-A900(1574774970)
rr18:9.126L49 node B 1-A900(1574774970) Pool1 PPG3J5HA
node B 1-A900(1574774970) node B 1-A900(1574774970)
rr18:8.126L21 node B 1-A900(1574774970) Pool1 PZHTDSZD
node B 1-A900(1574774970) node B 1-A900(1574774970)
rr18:8.126L2 node B 1-A900(1574774970) Pool0 SOM1J2CF
node B 1-A900(1574774970) node B 1-A900(1574774970)
rr18:9.126L29 node B 1-A900(1574774970) Pool0 SOMOCQM5
node B 1-A900(1574774970) node B 1-A900(1574774970)
rr18:8.126L1 node B 1-A900(1574774970) Pool0 SOM1PSDW
node B 1-A900(1574774970) node B 1-A900(1574774970)
*>
```

6. Display the aggregate status: aggr status

7. Repeat the above steps on the partner node (node_B_2-A900).

Boot up the new controllers

You must reboot the controllers from the boot menu to update the controller flash image. Additional steps are required if encryption is configured.

About this task

This task must be performed on all the new controllers.

Steps

- 1. Halt the node: halt
- 2. If external key manager is configured, set the related bootargs:

setenv bootarg.kmip.init.ipaddr ip-address

setenv bootarg.kmip.init.netmask netmask

setenv bootarg.kmip.init.gateway gateway-address

setenv bootarg.kmip.init.interface interface-id

- 3. Display the boot menu: boot ontap menu
- 4. If root encryption is used, issue the boot menu command for your key management configuration.

If you are using	Select this boot menu option…
Onboard key management	Option 10 and follow the prompts to provide the required inputs to recover or restore the key- manager configuration
External key management	Option 11 and follow the prompts to provide the required inputs to recover or restore the key- manager configuration

- 5. If autoboot is enabled, interrupt autoboot by pressing control-C.
- 6. From the boot menu, run option (6).



Option 6 will reboot the node twice before completing.

Respond y to the system id change prompts. Wait for the second reboot messages:

Successfully restored env file from boot media...

Rebooting to load the restored env file...

7. Double-check that the partner-sysid is correct: printenv partner-sysid

If the partner-sysid is not correct, set it: setenv partner-sysid partner-sysID

8. If root encryption is used, issue the boot menu command again for your key management configuration.

If you are using…	Select this boot menu option
Onboard key management	Option 10 and follow the prompts to provide the required inputs to recover or restore the key- manager configuration
External key management	Option 11 and follow the prompts to provide the required inputs to recover or restore the key- manager configuration

You might need to issue the recover_xxxxxx_keymanager command at the boot menu prompt multiple times until the nodes completely boot.

- 9. Boot the nodes: boot ontap
- 10. Wait for the replaced nodes to boot up.

If either node is in takeover mode, perform a giveback using the storage failover giveback command.

- 11. Verify that all ports are in a broadcast domain:
 - a. View the broadcast domains:

network port broadcast-domain show

b. Add any ports to a broadcast domain as needed.

Add or remove ports from a broadcast domain

- c. Add the physical port that will host the intercluster LIFs to the corresponding Broadcast domain.
- d. Modify intercluster LIFs to use the new physical port as home port.
- e. After the intercluster LIFs are up, check the cluster peer status and re-establish cluster peering as needed.

You may need to reconfigure cluster peering.

Creating a cluster peer relationship

f. Recreate VLANs and interface groups as needed.

VLAN and interface group membership might be different than that of the old node.

Creating a VLAN

Combining physical ports to create interface groups

12. If encryption is used, restore the keys using the correct command for your key management configuration.

If you are using	Use this command
Onboard key management	security key-manager onboard sync For more information, see Restoring onboard key management encryption keys.
External key management	<pre>security key-manager external restore -vserver SVM -node node -key-server host_name IP_address:port -key-id key_id -key-tag key_tag node-name For more information, see Restoring external key management encryption keys.</pre>

Verify LIF configuration

Verify that LIFs are hosted on appropriate node/ports prior to switchback. The following steps need to be performed

About this task

This task is performed on site_B, where the nodes have been booted up with root aggregates.

Steps

- 1. Verify that LIFs are hosted on the appropriate node and ports prior to switchback.
 - a. Change to the advanced privilege level:

set -privilege advanced

b. Override the port configuration to ensure proper LIF placement:

```
vserver config override -command "network interface modify" -vserver
vserver_name -home-port active_port_after_upgrade -lif lif_name -home-node
new_node_name"
```

When entering the network interface modify command within the vserver config override command, you cannot use the tab autocomplete feature. You can create the network interface modify using autocomplete and then enclose it in the vserver config override command.

c. Return to the admin privilege level:

set -privilege admin

2. Revert the interfaces to their home node:

network interface revert * -vserver vserver-name

Perform this step on all SVMs as required.

Switch back the MetroCluster configuration

After the new controllers have been configured, you switch back the MetroCluster configuration to return the configuration to normal operation.

About this task

In this task, you will perform the switchback operation, returning the MetroCluster configuration to normal operation. The nodes on site_A are still awaiting upgrade as shown in the following illustration. (This illustration also applies to upgrading a FAS9000 to a FAS9500 controller).



Steps

- 1. Issue the metrocluster node show command on site_B and check the output.
 - a. Verify that the new nodes are represented correctly.
 - b. Verify that the new nodes are in "Waiting for switchback state."
- 2. Switchback the cluster:

metrocluster switchback

3. Check the progress of the switchback operation:

metrocluster show

The switchback operation is still in progress when the output displays waiting-for-switchback:

The switchback operation is complete when the output displays normal:

```
cluster_B::> metrocluster show
Cluster Entry Name State
Local: cluster_B Configuration state configured
Mode normal
AUSO Failure Domain -
Configuration state configured
Mode normal
AUSO Failure Domain -
```

If a switchback takes a long time to finish, you can check on the status of in-progress baselines by using the metrocluster config-replication resync-status show command. This command is at the advanced privilege level.

Check the health of the MetroCluster configuration

After upgrading the controller modules you must verify the health of the MetroCluster configuration.

About this task

This task can be performed on any node in the MetroCluster configuration.

Steps

- 1. Verify the operation of the MetroCluster configuration:
 - a. Confirm the MetroCluster configuration and that the operational mode is normal:

metrocluster show

b. Perform a MetroCluster check:

metrocluster check run

c. Display the results of the MetroCluster check:

metrocluster check show

After running the metrocluster check run and metrocluster check show commands, you might see an error similar to the following example:

```
Cluster_A:: node_A_1 (non-overridable veto): DR partner NVLog mirroring is not online. Make sure that the links between the two sites are healthy and properly configured.
```

This error occurs due to a controller mismatch during the upgrade process. You can safely ignore the error and proceed to upgrade the nodes on site_A.

Upgrade the nodes on site_A

You must repeat the upgrade tasks on site_A.

Step

1. Repeat the steps to upgrade the nodes on site_A, beginning with Prepare for the upgrade.

As you perform the tasks, all example references to the sites and nodes are reversed. For example, when the example is given to switchover from site_A, you will switchover from Site_B.

Send a custom AutoSupport message after maintenance

After completing the upgrade, you should send an AutoSupport message indicating the end of maintenance, so automatic case creation can resume.

Step

- 1. To resume automatic support case generation, send an Autosupport message to indicate that the maintenance is complete.
 - a. Issue the following command:

system node autosupport invoke -node * -type all -message MAINT=end

b. Repeat the command on the partner cluster.

Restore Tiebreaker monitoring

If the MetroCluster configuration was previously configured for monitoring by the Tiebreaker software, you can restore the Tiebreaker connection.

1. Use the steps in: Adding MetroCluster configurations in the MetroCluster Tiebreaker Installation and Configuration section.

Upgrading controllers in a four-node MetroCluster FC configuration using switchover and switchback with "system controller replace" commands (ONTAP 9.10.1 and later)

You can use this guided automated MetroCluster switchover operation to perform a nondisruptive controller upgrade on a four-node MetroCluster FC configuration. Other components (such as storage shelves or switches) cannot be upgraded as part of this procedure.

Supported platform combinations

• For information on what platform upgrade combinations are supported, review the MetroCluster FC upgrade table in Choose a controller upgrade procedure.

Refer to Choosing an upgrade or refresh method for additional procedures.

About this task

• You can use this procedure only for controller upgrade.

Other components in the configuration, such as storage shelves or switches, cannot be upgraded at the same time.

- This procedure applies to controller modules in a four-node MetroCluster FC configuration.
- The platforms must be running ONTAP 9.10.1 or later.

NetApp Hardware Universe

- You can use this procedure to upgrade controllers in a four-node MetroCluster FC configuration using NSO based automated switchover and switchback. If you want to perform a controller upgrade using aggregate relocation (ARL), refer to Use "system controller replace" commands to upgrade controller hardware running ONTAP 9.8 or later. It is recommended to use the NSO based automated procedure.
- If your MetroCluster sites are physically at two different locations, you should use the automated NSO controller upgrade procedure to upgrade the controllers at both sites in sequence.
- This automated NSO based controller upgrade procedure gives you the capability to initiate controller replacement to a MetroCluster disaster recovery (DR) site. You can only initiate a controller replacement at one site at a time.
- To initiate a controller replacement at site A, you need to run the controller replacement start command from site B. The operation guides you to replace controllers of both the nodes at site A only. To replace the controllers at site B, you need to run the controller replacement start command from site A. A message displays identifying the site at which the controllers are being replaced.

The following example names are used in this procedure:

- site_A
 - Before upgrade:
 - node_A_1-old

- node_A_2-old
- After upgrade:
 - node_A_1-new
 - node_A_2-new
- site_B
 - Before upgrade:
 - node_B_1-old
 - node_B_2-old
 - After upgrade:
 - node_B_1-new
 - node_B_2-new

Preparing for the upgrade

To prepare for the controller upgrade, you need to perform system prechecks and collect the configuration information.

At any stage during the upgrade, you can run the system controller replace show or system controller replace show-details command from site A to check the status. If the commands return a blank output, wait for a few minutes and rerun the command.

Steps

1. Start the automated controller replacement procedure from site A to replace the controllers at site B:

system controller replace start

The automated operation executes the prechecks. If no issues are found, the operation pauses so you can manually collect the configuration related information.



The current source system and all compatible target systems are displayed. If you have replaced the source controller with a controller that has a different ONTAP version or a non-compatible platform, the automation operation halts and reports an error after the new nodes are booted up. To bring the cluster back to a healthy state, you need to follow the manual recovery procedure.

The system controller replace start command might report the following precheck error:

Check if this error occurred because you have unmirrored aggregates or due to another aggregate issue. Verify that all mirrored aggregates are healthy and not degraded or mirror-degraded. If this error is due to unmirrored aggregates only, you can override this error by selecting the <code>-skip-metrocluster-check</code>

true option on the system controller replace start command. If remote storage is accessible, the unmirrored aggregates come online after switchover. If the remote storage link fails, the unmirrored aggregates fail to come online.

2. Manually collect the configuration information by logging in at site B and following the commands listed in the console message under the system controller replace show or system controller replace show-details command.

Gathering information before the upgrade

Before upgrading, if the root volume is encrypted, you must gather the backup key and other information to boot the new controllers with the old encrypted root volumes.

About this task

This task is performed on the existing MetroCluster FC configuration.

Steps

- 1. Label the cables for the existing controllers, so you can easily identify the cables when setting up the new controllers.
- 2. Display the commands to capture the backup key and other information:

system controller replace show

Run the commands listed under the show command from the partner cluster.

3. Gather the system IDs of the nodes in the MetroCluster configuration:

metrocluster node show -fields node-systemid, dr-partner-systemid

During the upgrade procedure, you will replace these old system IDs with the system IDs of the new controller modules.

In this example for a four-node MetroCluster FC configuration, the following old system IDs are retrieved:

- node_A_1-old: 4068741258
- node_A_2-old: 4068741260
- node_B_1-old: 4068741254
- node_B_2-old: 4068741256

metrocluster-siteA::> metrocluster node show -fields node-systemid, hapartner-systemid, dr-partner-systemid, dr-auxiliary-systemid dr-group-id cluster node node-systemid ha-partner-systemid dr-partner-systemid dr-auxiliary-systemid _____ -----_____ _____ _____ _____ 1 Cluster A Node A 1-old 4068741258 4068741260 4068741256 4068741256 Cluster_A Node_A_2-old 4068741260 1 4068741258 4068741254 4068741254 Cluster B Node B 1-old 4068741254 1 4068741256 4068741258 4068741260 1 Cluster B Node B 2-old 4068741256 4068741254 4068741260 4068741258 4 entries were displayed.

In this example for a two-node MetroCluster FC configuration, the following old system IDs are retrieved:

node A 1: 4068741258

node_B_1: 4068741254

4. Gather port and LIF information for each old node.

You should gather the output of the following commands for each node:

network interface show -role cluster, node-mgmt
network port show -node node-name -type physical
network port vlan show -node node-name
network port ifgrp show -node node_name -instance
network port broadcast-domain show
network port reachability show -detail
network ipspace show
volume show
storage aggregate show

° system node run -node node-name sysconfig -a

5. If the MetroCluster nodes are in a SAN configuration, collect the relevant information.

You should gather the output of the following commands:

- ° fcp adapter show -instance
- ° fcp interface show -instance
- ° iscsi interface show
- ° ucadmin show
- 6. If the root volume is encrypted, collect and save the passphrase used for key-manager:

security key-manager backup show

7. If the MetroCluster nodes are using encryption for volumes or aggregates, copy information about the keys and passphrases.

For additional information, see Backing up onboard key management information manually.

a. If Onboard Key Manager is configured:

security key-manager onboard show-backup

You will need the passphrase later in the upgrade procedure.

b. If enterprise key management (KMIP) is configured, issue the following commands:

security key-manager external show -instance

security key-manager key query

8. After you finish collecting the configuration information, resume the operation:

system controller replace resume

Removing the existing configuration from the Tiebreaker or other monitoring software

If the existing configuration is monitored with the MetroCluster Tiebreaker configuration or other third-party applications (for example, ClusterLion) that can initiate a switchover, you must remove the MetroCluster configuration from the Tiebreaker or other software prior to replacing the old controller.

Steps

- 1. Remove the existing MetroCluster configuration from the Tiebreaker software.
- 2. Remove the existing MetroCluster configuration from any third-party application that can initiate switchover.

Refer to the documentation for the application.

Replacing the old controllers and booting up the new controllers

After you gather information and resume the operation, the automation proceeds with the switchover operation.

About this task

The automation operation initiates the switchover, heal-aggregates, and heal root-aggregates operations. After these operations complete, the operation pauses at **paused for user intervention** so you can rack and install the controllers, boot up the partner controllers, and reassign the root aggregate disks to the new controller module from flash backup using the sysids gathered earlier.

Before you begin

Before initiating switchover, the automation operation pauses so you can manually verify that all LIFs are "up" at site B. If necessary, bring any LIFs that are "down" to "up" and resume the automation operation by using the system controller replace resume command.

Preparing the network configuration of the old controllers

To ensure that the networking resumes cleanly on the new controllers, you must move LIFs to a common port and then remove the networking configuration of the old controllers.

About this task

- This task must be performed on each of the old nodes.
- You will use the information gathered in Preparing for the upgrade.

Steps

1. Boot the old nodes and then log in to the nodes:

boot_ontap

- 2. Assign the home port of all data LIFs on the old controller to a common port that is the same on both the old and new controller modules.
 - a. Display the LIFs:

network interface show

All data LIFS including SAN and NAS will be admin "up" and operationally "down" since those are up at switchover site (cluster_A).

b. Review the output to find a common physical network port that is the same on both the old and new controllers that is not used as a cluster port.

For example, "e0d" is a physical port on old controllers and is also present on new controllers. "e0d" is not used as a cluster port or otherwise on the new controllers.

For port usage for platform models, see the NetApp Hardware Universe

c. Modify all data LIFS to use the common port as the home port:

```
network interface modify -vserver svm-name -lif data-lif -home-port port-id
```

In the following example, this is "e0d".

For example:

network interface modify -vserver vs0 -lif datalif1 -home-port e0d

3. Modify broadcast domains to remove VLAN and physical ports that need to be deleted:

broadcast-domain remove-ports -broadcast-domain broadcast-domain-name -ports
node-name:port-id

Repeat this step for all VLAN and physical ports.

- 4. Remove any VLAN ports using cluster ports as member ports and interface groups using cluster ports as member ports.
 - a. Delete VLAN ports:

network port vlan delete -node node-name -vlan-name portid-vlandid

For example:

network port vlan delete -node node1 -vlan-name e1c-80

b. Remove physical ports from the interface groups:

```
network port ifgrp remove-port -node node-name -ifgrp interface-group-name
-port portid
```

For example:

network port ifgrp remove-port -node node1 -ifgrp ala -port e0d

c. Remove VLAN and interface group ports from broadcast domain:

network port broadcast-domain remove-ports -ipspace ipspace -broadcast -domain broadcast-domain-name -ports nodename:portname,nodename:portname,..

d. Modify interface group ports to use other physical ports as member as needed .:

ifgrp add-port -node node-name -ifgrp interface-group-name -port port-id

5. Halt the nodes:

halt -inhibit-takeover true -node node-name

This step must be performed on both nodes.

Setting up the new controllers

You must rack and cable the new controllers.

Steps

1. Plan out the positioning of the new controller modules and storage shelves as needed.

The rack space depends on the platform model of the controller modules, the switch types, and the number of storage shelves in your configuration.

- 2. Properly ground yourself.
- 3. Install the controller modules in the rack or cabinet.

ONTAP Hardware Systems Documentation

4. If the new controller modules did not come with FC-VI cards of their own and if FC-VI cards from old controllers are compatible on new controllers, swap FC-VI cards and install those in correct slots.

See the NetApp Hardware Universe for slot info for FC-VI cards.

5. Cable the controllers' power, serial console and management connections as described in the *MetroCluster Installation and Configuration Guides*.

Do not connect any other cables that were disconnected from old controllers at this time.

ONTAP Hardware Systems Documentation

6. Power up the new nodes and press Ctrl-C when prompted to display the LOADER prompt.

Netbooting the new controllers

After you install the new nodes, you need to netboot to ensure the new nodes are running the same version of ONTAP as the original nodes. The term netboot means you are booting from an ONTAP image stored on a remote server. When preparing for netboot, you must put a copy of the ONTAP 9 boot image onto a web server that the system can access.

This task is performed on each of the new controller modules.

Steps

- 1. Access the NetApp Support Site to download the files used for performing the netboot of the system.
- 2. Download the appropriate ONTAP software from the software download section of the NetApp Support Site and store the ontap-version_image.tgz file on a web-accessible directory.
- 3. Go to the web-accessible directory and verify that the files you need are available.

If the platform model is	Then
FAS/AFF8000 series systems	Extract the contents of the ontap- version_image.tgzfile to the target directory: tar -zxvf ontap-version_image.tgz
	NOTE: If you are extracting the contents on Windows, use 7-Zip or WinRAR to extract the netboot image.
	Your directory listing should contain a netboot folder with a kernel file:netboot/kernel
All other systems	Your directory listing should contain a netboot folder with a kernel file: ontap-version_image.tgz
	You do not need to extract the ontap- version_image.tgz file.

- 4. At the LOADER prompt, configure the netboot connection for a management LIF:
 - If IP addressing is DHCP, configure the automatic connection:

ifconfig eOM -auto

• If IP addressing is static, configure the manual connection:

```
ifconfig eOM -addr=ip addr -mask=netmask-gw=gateway
```

- 5. Perform the netboot.
 - If the platform is an 80xx series system, use this command:

```
netboot http://web_server_ip/path_to_web-accessible_directory/netboot/kernel
```

• If the platform is any other system, use the following command:

```
netboot http://web_server_ip/path_to_web-accessible_directory/ontap-
version image.tgz
```

From the boot menu, select option (7) Install new software first to download and install the new software image to the boot device.

Disregard the following message: "This procedure is not supported for Non-Disruptive Upgrade on an HA pair". It applies to nondisruptive upgrades of software, not to upgrades of controllers.

7. If you are prompted to continue the procedure, enter y, and when prompted for the package, enter the URL of the image file: http://web_server_ip/path_to_web-accessible_directory/ontap-version_image.tgz

Enter username/password if applicable, or press Enter to continue.

8. Be sure to enter n to skip the backup recovery when you see a prompt similar to the following:

Do you want to restore the backup configuration now? {y|n}

9. Reboot by entering y when you see a prompt similar to the following:

The node must be rebooted to start using the newly installed software. Do you want to reboot now? $\{y|n\}$

Clearing the configuration on a controller module

Before using a new controller module in the MetroCluster configuration, you must clear

the existing configuration.

Steps

1. If necessary, halt the node to display the LOADER prompt:

halt

2. At the LOADER prompt, set the environmental variables to default values:

set-defaults

3. Save the environment:

saveenv

4. At the LOADER prompt, launch the boot menu:

boot_ontap menu

5. At the boot menu prompt, clear the configuration:

wipeconfig

Respond yes to the confirmation prompt.

The node reboots and the boot menu is displayed again.

6. At the boot menu, select option **5** to boot the system into Maintenance mode.

Respond yes to the confirmation prompt.

Restoring the HBA configuration

Depending on the presence and configuration of HBA cards in the controller module, you need to configure them correctly for your site's usage.

Steps

- 1. In Maintenance mode configure the settings for any HBAs in the system:
 - a. Check the current settings of the ports: ucadmin show
 - b. Update the port settings as needed.

If you have this type of HBA and desired mode…	Use this command
CNA FC	ucadmin modify -m fc -t initiator <i>adapter-name</i>
CNA Ethernet	ucadmin modify -mode cna adapter-name
FC target	fcadmin config -t target adapter-name

2. Exit Maintenance mode:

halt

After you run the command, wait until the node stops at the LOADER prompt.

3. Boot the node back into Maintenance mode to enable the configuration changes to take effect:

boot_ontap maint

4. Verify the changes you made:

If you have this type of HBA	Use this command
CNA	ucadmin show
FC	fcadmin show

Reassigning root aggregate disks

Reassign the root aggregate disks to the new controller module, using the sysids gathered earlier

About this task

This task is performed in Maintenance mode.

The old system IDs were identified in Gathering information before the upgrade.

The examples in this procedure use controllers with the following system IDs:

Node	Old system ID	New system ID
node_B_1	4068741254	1574774970

Steps

- 1. Cable all other connections to the new controller modules (FC-VI, storage, cluster interconnect, etc.).
- 2. Halt the system and boot to Maintenance mode from the LOADER prompt:

boot_ontap maint

3. Display the disks owned by node_B_1-old:

disk show -a

The command output shows the system ID of the new controller module (1574774970). However, the root aggregate disks are still owned by the old system ID (4068741254). This example does not show drives owned by other nodes in the MetroCluster configuration.

```
*> disk show -a
Local System ID: 1574774970
 DISK OWNER
                                     POOL SERIAL NUMBER
                                                          HOME
DR HOME
-----
                                     _____
_____
                       _____
. . .
rr18:9.126L44 node B 1-old(4068741254) Pool1 PZHYNOMD
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:9.126L49 node B 1-old(4068741254) Pool1 PPG3J5HA
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:8.126L21 node B 1-old(4068741254) Pool1 PZHTDSZD
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:8.126L2 node B 1-old(4068741254) Pool0 SOM1J2CF
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:8.126L3 node B 1-old(4068741254) Pool0 SOMOCQM5
node B 1-old(4068741254) node B 1-old(4068741254)
rr18:9.126L27 node B 1-old(4068741254) Pool0 SOM1PSDW
node B 1-old(4068741254) node B 1-old(4068741254)
. . .
```

4. Reassign the root aggregate disks on the drive shelves to the new controller:

disk reassign -s old-sysid -d new-sysid

The following example shows reassignment of drives:

```
*> disk reassign -s 4068741254 -d 1574774970
Partner node must not be in Takeover mode during disk reassignment from
maintenance mode.
Serious problems could result!!
Do not proceed with reassignment if the partner is in takeover mode.
Abort reassignment (y/n)? n
After the node becomes operational, you must perform a takeover and
giveback of the HA partner node to ensure disk reassignment is
successful.
Do you want to continue (y/n)? Jul 14 19:23:49
[localhost:config.bridge.extra.port:error]: Both FC ports of FC-to-SAS
bridge rtp-fc02-41-rr18:9.126L0 S/N [FB7500N107692] are attached to this
controller.
У
Disk ownership will be updated on all disks previously belonging to
Filer with sysid 4068741254.
Do you want to continue (y/n)? y
```

5. Check that all disks are reassigned as expected:

disk show

```
*> disk show
Local System ID: 1574774970
 DISK
        OWNER
                                     POOL SERIAL NUMBER HOME
DR HOME
_____
                                     ____
                                            _____
_____
                        _____
rr18:8.126L18 node B 1-new(1574774970) Pool1 PZHYNOMD
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:9.126L49 node B 1-new(1574774970) Pool1 PPG3J5HA
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:8.126L21 node B 1-new(1574774970) Pool1 PZHTDSZD
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:8.126L2 node B 1-new(1574774970) Pool0 SOM1J2CF
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:9.126L29 node B 1-new(1574774970) Pool0 SOMOCQM5
node B 1-new(1574774970) node B 1-new(1574774970)
rr18:8.126L1 node B 1-new(1574774970) Pool0 SOM1PSDW
node B 1-new(1574774970) node B 1-new(1574774970)
*>
```

6. Display the aggregate status:

aggr status

```
*> aggr status
    Aggr State Status Options
aggr0_node_b_1-root online raid_dp, aggr root, nosnap=on,
    mirrored
mirror_resync_priority=high(fixed)
    fast zeroed
    64-bit
```

7. Repeat the above steps on the partner node (node_B_2-new).

Booting up the new controllers

You must reboot the controllers from the boot menu to update the controller flash image. Additional steps are required if encryption is configured.

You can reconfigure VLANs and interface groups. If required, manually modify the ports for the cluster LIFs and broadcast domain details before resuming the operation by using the system controller replace resume command.

About this task

This task must be performed on all the new controllers.

Steps

1. Halt the node:

halt

2. If external key manager is configured, set the related bootargs:

```
setenv bootarg.kmip.init.ipaddr ip-address
```

setenv bootarg.kmip.init.netmask netmask

setenv bootarg.kmip.init.gateway gateway-address

setenv bootarg.kmip.init.interface interface-id

3. Display the boot menu:

boot_ontap menu

4. If root encryption is used, select the boot menu option for your key management configuration.

Onboard key management	Option "10" Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.
External key management	Option "11" Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.

- 5. If autoboot is enabled, interrupt autoboot by pressing Ctrl-C.
- 6. From the boot menu, run option "6".



Option "6" will reboot the node twice before completing.

Respond "y" to the system id change prompts. Wait for the second reboot messages:

Successfully restored env file from boot media...

Rebooting to load the restored env file...

7. Double-check that the partner-sysid is correct:

printenv partner-sysid

If the partner-sysid is not correct, set it:

setenv partner-sysid partner-sysID

8. If root encryption is used, select the boot menu option again for your key management configuration.

If you are using	Select this boot menu option
Onboard key management	Option "10"
	Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.
External key management	Option "11"
	Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.

Depending on the key manager setting, perform the recovery procedure by selecting option "10" or option "11", followed by option "6" at the first boot menu prompt. To boot the nodes completely, you might need to repeat the recovery procedure continued by option "1" (normal boot).

9. Boot the nodes:

boot_ontap

10. Wait for the replaced nodes to boot up.

If either node is in takeover mode, perform a giveback using the storage failover giveback command.

- 11. Verify that all ports are in a broadcast domain:
 - a. View the broadcast domains:

network port broadcast-domain show

b. Add any ports to a broadcast domain as needed.

Adding or removing ports from a broadcast domain

- c. Add the physical port that will host the intercluster LIFs to the corresponding broadcast domain.
- d. Modify intercluster LIFs to use the new physical port as home port.
- e. After the intercluster LIFs are up, check the cluster peer status and re-establish cluster peering as needed.

You may need to reconfigure cluster peering.

Creating a cluster peer relationship

f. Recreate VLANs and interface groups as needed.

VLAN and interface group membership might be different than that of the old node.

Creating a VLAN

Combining physical ports to create interface groups

g. Verify that the partner cluster is reachable and that the configuration is successfully resynchronized on the partner cluster:

metrocluster switchback -simulate true

12. If encryption is used, restore the keys using the correct command for your key management configuration.

If you are using	Use this command
Onboard key management	security key-manager onboard sync
	For more information, see Restoring onboard key management encryption keys.

External key management	<pre>security key-manager external restore -vserver SVM -node node -key-server host_name IP_address:port -key-id key_id -key-tag key_tag node-name For more information, see Restoring external key management encryption keys.</pre>
-------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

13. Before you resume the operation, verify that the MetroCluster is configured correctly. Check the node status:

metrocluster node show

Verify that the new nodes (site_B) are in Waiting for switchback state from site_A.

14. Resume the operation:

system controller replace resume

Completing the upgrade

The automation operation runs verification system checks and then pauses so you can verify the network reachability. After verification, the resource regain phase is initiated and the automation operation executes switchback at site A and pauses at the post upgrade checks. After you resume the automation operation, it performs the post upgrade checks and if no errors are detected, marks the upgrade as complete.

Steps

- 1. Verify the network reachability by following the console message.
- 2. After you complete the verification, resume the operation:

system controller replace resume

- 3. The automation operation performs switchback at site A and the post upgrade checks. When the operation pauses, manually check the SAN LIF status and verify the network configuration by following the console message.
- 4. After you complete the verification, resume the operation:

system controller replace resume

5. Check the post upgrade checks status:

system controller replace show

If the post upgrade checks did not report any errors, the upgrade is complete.

6. After you complete the controller upgrade, log in at site B and verify that the replaced controllers are configured correctly.

Restoring Tiebreaker monitoring

If the MetroCluster configuration was previously configured for monitoring by the Tiebreaker software, you can

restore the Tiebreaker connection.

1. Use the steps in Adding MetroCluster configurations.

Upgrading controllers in a MetroCluster IP configuration using switchover and switchback (ONTAP 9.8 and later)

Beginning with ONTAP 9.8, you can use the MetroCluster switchover operation to provide nondisruptive service to clients while the controller modules on the partner cluster are upgraded. Other components (such as storage shelves or switches) cannot be upgraded as part of this procedure.

Platforms supported by this procedure

- The platforms must be running ONTAP 9.8 or later.
- The target (new) platform must be a different model than the original platform.
- Platform models with internal shelves are not supported.
- You can only upgrade specific platform models using this procedure in a MetroCluster IP configuration.
 - For information on what platform upgrade combinations are supported review the MetroCluster IP upgrade table in Choose a controller upgrade procedure.

Refer to Choosing an upgrade or refresh method for additional procedures.

About this task

- This procedure applies to controller modules in a MetroCluster IP configuration.
- All controllers in the configuration should be upgraded during the same maintenance period.

Operating the MetroCluster configuration with different controller types is not supported outside of this maintenance activity.

- The IP switches must be running a supported firmware version.
- If the new platform has fewer slots than the original system, or if it has fewer or different types of ports, you might need to add an adapter to the new system.

For more information, see the NetApp Hardware Universe.

- You will reuse the IP addresses, netmasks, and gateways of the original platforms on the new platforms.
- The following example names are used in this procedure:

∘ site_A

- Before upgrade:
 - node_A_1-old
 - node_A_2-old
- After upgrade:
 - node_A_1-new

- node_A_2-new
- ∘ site_B
 - Before upgrade:
 - node_B_1-old
 - node_B_2-old
 - After upgrade:
 - node_B_1-new
 - node_B_2-new

Workflow for upgrading controllers in an MetroCluster IP configuration

You can use the workflow diagram to help you plan the upgrade tasks.



Preparing for the upgrade

Before making any changes to the existing MetroCluster configuration, you must check the health of the configuration, prepare the new platforms, and perform other miscellaneous tasks.

Updating the MetroCluster switch RCF files before upgrading controllers

Depending on the old platform models, or if switch configuration is not on the minimum version, or if you want to change VLAN IDs used by the back-end MetroCluster connections, you must update the switch RCF files before you begin the platform upgrade procedure.

About this task

You must update the RCF file in the following scenarios:

• For certain platform models, the switches must be using a supported VLAN ID for the back-end MetroCluster IP connections. If the old or new platform models are in the following table, **and not** using a supported VLAN ID, you must update the switch RCF files.



The local cluster connections can use any VLAN, they do not need to be in the given range.

Platform model (old or new)	Supported VLAN IDs
• AFF A400	• 10
	• 20
	• Any value in the range 101 to 4096 inclusive.

• The switch configuration was not configured with minimum supported RCF version:

Switch model	Required RCF file version
Cisco 3132Q-V	1.7 or later
Cisco 3232C	1.7 or later
Broadcom BES-53248	1.3 or later

• You want to change the VLAN configuration.

The VLAN ID range is 101 to 4096 inclusive.

The switches at site_A will be upgraded when the controllers on site_A are upgraded.

Steps

1. Prepare the IP switches for the application of the new RCF files.

Follow the steps in the section for your switch vendor from the MetroCluster IP installation and configuration.

• Resetting the Broadcom IP switch to factory defaults

- Resetting the Cisco IP switch to factory defaults
- 2. Download and install the RCF files.

Follow the steps in the MetroCluster IP installation and configuration.

- Downloading and installing the Broadcom RCF files
- Downloading and installing the Cisco IP RCF files

Mapping ports from the old nodes to the new nodes

You must verify that the physical ports on node_A_1-old map correctly to the physical ports on node_A_1-new, which will allow node_A_1-new to communicate with other nodes in the cluster and with the network after the upgrade.

About this task

When the new node is first booted during the upgrade process, it will replay the most recent configuration of the old node it is replacing. When you boot node_A_1-new, ONTAP attempts to host LIFs on the same ports that were used on node_A_1-old. Therefore, as part of the upgrade you must adjust the port and LIF configuration so it is compatible with that of the old node. During the upgrade procedure, you will perform steps on both the old and new nodes to ensure correct cluster, management, and data LIF configuration.

The following table shows examples of configuration changes related to the port requirements of the new nodes.

Cluster interconnect physical ports		
Old controller New controller		Required action
e0a, e0b	e3a, e3b	No matching port. After upgrade, you must recreate cluster ports.
e0c, e0d	e0a,e0b,e0c,e0d	e0c and e0d are matching ports. You do not have to change the configuration, but after upgrade you can spread your cluster LIFs across the available cluster ports.

Steps

1. Determine what physical ports are available on the new controllers and what LIFs can be hosted on the ports.

The controller's port usage depends on the platform module and which switches you will use in the MetroCluster IP configuration. You can gather the port usage of the new platforms from the NetApp Hardware Universe.

2. Plan your port usage and fill in the following tables for reference for each of the new nodes.

You will refer to the table as you carry out the upgrade procedure.

	node_A_1-old	node_A_1-new
--	--------------	--------------

LIF	Ports	IPspaces	Broadcast domains	Ports	IPspaces	Broadcast domains
Cluster 1						
Cluster 2						
Cluster 3						
Cluster 4						
Node management						
Cluster management						
Data 1						
Data 2						
Data 3						
Data 4						
SAN						
Intercluster port						

Netbooting the new controllers

After you install the new nodes, you need to netboot to ensure the new nodes are running the same version of ONTAP as the original nodes. The term netboot means you are booting from an ONTAP image stored on a remote server. When preparing for netboot, you must put a copy of the ONTAP 9 boot image onto a web server that the system can access.

Steps

- 1. Netboot the new controllers:
 - a. Access the NetApp Support Site to download the files used for performing the netboot of the system.
 - b. Download the appropriate ONTAP software from the software download section of the NetApp Support Site and store the ontap-version image.tgz file on a web-accessible directory.
 - c. Change to the web-accessible directory and verify that the files you need are available.

If the platform model	Then
is	

8000 series systems	Extract the contents of the <i>ontap-version_image.tgz</i> file to the target directory:	
	tar -zx	vf ontap-version_image.tgz
	(i) If you are extracting the contents on Windows, use 7-Zip WinRAR to extract the netboot image. Your directory listin should contain a netboot folder with a kernel file:netboot/kernel	
	Your directory listing should contain a netboot folder with a kernel file	
	netboot	/kernel
All other systems	Your directory listing should contain a netboot folder with a kernel file: ontap-version_image.tgz You do not need to extract theontap-version_image.tgz file.	

d. At the LOADER prompt, configure the netboot connection for a management LIF:

If IP addressing is	Then
DHCP	Configure the automatic connection:
	ifconfig eOM -auto
Static	Configure the manual connection:
	ifconfig eOM -addr= <i>ip_addr</i> - mask= <i>netmask</i> -gw= <i>gateway</i>

e. Perform the netboot.

If the platform model is…	Then
FAS/AFF8000 series systems	<pre>netboot http://web_server_ip/path_to_web- accessible_directory/netboot/kernel</pre>
All other systems	<pre>netboot http://_web_server_ip/path_to_web- accessible_directory/ontap- version_image.tgz</pre>

f. From the boot menu, select option (7) **Install new software first** to download and install the new software image to the boot device.

Disregard the following message:

"This procedure is not supported for Non-Disruptive Upgrade on an HA pair". It applies to nondisruptive upgrades of software, not to upgrades of controllers.

g. If you are prompted to continue the procedure, enter y, and when prompted for the package, enter the URL of the image file:

http://web_server_ip/path_to_web-accessible_directory/ontapversion image.tgz

- h. Enter the user name and password if applicable, or press Enter to continue.
- i. Be sure to enter n to skip the backup recovery when you see a prompt similar to the following:

Do you want to restore the backup configuration now? {y|n} **n**

j. Reboot by entering **y** when you see a prompt similar to the following:

The node must be rebooted to start using the newly installed software. Do you want to reboot now? $\{y|n\}$

Clearing the configuration on a controller module

Before using a new controller module in the MetroCluster configuration, you must clear the existing configuration.

Steps

1. If necessary, halt the node to display the LOADER prompt:

halt

2. At the LOADER prompt, set the environmental variables to default values:

set-defaults

3. Save the environment:

saveenv

4. At the LOADER prompt, launch the boot menu:

boot_ontap menu

5. At the boot menu prompt, clear the configuration:

wipeconfig

Respond yes to the confirmation prompt.

The node reboots and the boot menu is displayed again.

6. At the boot menu, select option **5** to boot the system into Maintenance mode.

Respond yes to the confirmation prompt.

Verifying MetroCluster health before site upgrade

You must verify the health and connectivity of the MetroCluster configuration prior to performing the upgrade.

Steps

1. Verify the operation of the MetroCluster configuration in ONTAP:

a. Check whether the nodes are multipathed: node run -node node-name sysconfig -a

You should issue this command for each node in the MetroCluster configuration.

b. Verify that there are no broken disks in the configuration: storage disk show -broken

You should issue this command on each node in the MetroCluster configuration.

c. Check for any health alerts:

system health alert show

You should issue this command on each cluster.

d. Verify the licenses on the clusters:

system license show

You should issue this command on each cluster.

e. Verify the devices connected to the nodes:

network device-discovery show

You should issue this command on each cluster.

f. Verify that the time zone and time is set correctly on both sites:

cluster date show

You should issue this command on each cluster. You can use the cluster date commands to configure the time and time zone.

- 2. Confirm the operational mode of the MetroCluster configuration and perform a MetroCluster check.
 - a. Confirm the MetroCluster configuration and that the operational mode is normal: metrocluster show
 - b. Confirm that all expected nodes are shown: metrocluster node show

c. Issue the following command:

metrocluster check run

d. Display the results of the MetroCluster check:

metrocluster check show

- 3. Check the MetroCluster cabling with the Config Advisor tool.
 - a. Download and run Config Advisor.

NetApp Downloads: Config Advisor

b. After running Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.

Gathering information before the upgrade

Before upgrading, you must gather information for each of the nodes, and, if necessary, adjust the network broadcast domains, remove any VLANs and interface groups, and gather encryption information.

Steps

- 1. Record the physical cabling for each node, labelling cables as needed to allow correct cabling of the new nodes.
- 2. Gather interconnect, port and LIF information for each node.

You should gather the output of the following commands for each node:

- ° metrocluster interconnect show
- ° metrocluster configuration-settings connection show
- ° network interface show -role cluster, node-mgmt
- ° network port show -node node name -type physical
- ° network port vlan show -node node-name
- ° network port ifgrp show -node node name -instance
- ° network port broadcast-domain show
- ° network port reachability show -detail
- ° network ipspace show
- ° volume show
- $^{\circ}$ storage aggregate show
- ° system node run -node *node-name* sysconfig -a
- $^{\circ}$ vserver fcp initiator show
- ° storage disk show
- ° metrocluster configuration-settings interface show
- 3. Gather the UUIDs for the site_B (the site whose platforms are currently being upgraded):

These values must be configured accurately on the new site_B controller modules to ensure a successful upgrade. Copy the values to a file so that you can copy them into the proper commands later in the upgrade process.

The following example shows the command output with the UUIDs:

```
cluster B::> metrocluster node show -fields node-cluster-uuid, node-uuid
  (metrocluster node show)
dr-group-id cluster node node-uuid
node-cluster-uuid
_____ _
_____
           cluster A node A 1 f03cb63c-9a7e-11e7-b68b-00a098908039
1
ee7db9d5-9a82-11e7-b68b-00a098908039
           cluster A node A 2 aa9a7a7a-9a81-11e7-a4e9-00a098908c35
1
ee7db9d5-9a82-11e7-b68b-00a098908039
1
           cluster B node B 1 f37b240b-9ac1-11e7-9b42-00a098c9e55d
07958819-9ac6-11e7-9b42-00a098c9e55d
           cluster B node B 2 bf8e3f8f-9ac4-11e7-bd4e-00a098ca379f
1
07958819-9ac6-11e7-9b42-00a098c9e55d
4 entries were displayed.
cluster B::*
```

It is recommended that you record the UUIDs into a table similar to the following.

Cluster or node	UUID
cluster_B	07958819-9ac6-11e7-9b42-00a098c9e55d
node_B_1	f37b240b-9ac1-11e7-9b42-00a098c9e55d
node_B_2	bf8e3f8f-9ac4-11e7-bd4e-00a098ca379f
cluster_A	ee7db9d5-9a82-11e7-b68b-00a098908039
node_A_1	f03cb63c-9a7e-11e7-b68b-00a098908039
node_A_2	aa9a7a7a-9a81-11e7-a4e9-00a098908c35

4. If the MetroCluster nodes are in a SAN configuration, collect the relevant information.

You should gather the output of the following commands:

[°] fcp adapter show -instance
° fcp interface show -instance

° iscsi interface show

° ucadmin show

5. If the root volume is encrypted, collect and save the passphrase used for key-manager:

security key-manager backup show

6. If the MetroCluster nodes are using encryption for volumes or aggregates, copy information about the keys and passphrases.

For additional information, see Backing up onboard key management information manually.

a. If Onboard Key Manager is configured: security key-manager onboard show-backup

You will need the passphrase later in the upgrade procedure.

b. If enterprise key management (KMIP) is configured, issue the following commands:

security key-manager external show -instance security key-manager key query

7. Gather the system IDs of the existing nodes:

metrocluster node show -fields node-systemid,ha-partner-systemid,dr-partnersystemid,dr-auxiliary-systemid

The following output shows the reassigned drives.

```
::> metrocluster node show -fields node-systemid, ha-partner-systemid, dr-
partner-systemid, dr-auxiliary-systemid
                          node-systemid ha-partner-systemid dr-
dr-group-id cluster
                   node
partner-systemid dr-auxiliary-systemid
  _____
1
        cluster A node A 1
                           537403324
                                      537403323
537403321
                537403322
         cluster_A node_A_2
1
                           537403323
                                      537403324
                537403321
537403322
         cluster B node B 1
1
                           537403322
                                      537403321
537403323
                537403324
         cluster B node B 2
1
                           537403321
                                      537403322
                537403323
537403324
4 entries were displayed.
```

Removing Mediator or Tiebreaker monitoring

Before the upgrading the platforms, you must remove monitoring if the MetroCluster configuration is monitored with the Tiebreaker or Mediator utility.

Steps

1. Collect the output for the following command:

```
storage iscsi-initiator show
```

2. Remove the existing MetroCluster configuration from Tiebreaker, Mediator, or other software that can initiate switchover.

If you are using	Use this procedure
Tiebreaker	Removing MetroCluster Configurations
Mediator	Issue the following command from the ONTAP prompt: metrocluster configuration-settings mediator remove
Third-party applications	Refer to the product documentation.

Sending a custom AutoSupport message prior to maintenance

Before performing the maintenance, you should issue an AutoSupport message to notify NetApp technical support that maintenance is underway. Informing technical support that maintenance is underway prevents them from opening a case on the assumption that a disruption has occurred.

About this task

This task must be performed on each MetroCluster site.

Steps

- 1. Log in to the cluster.
- 2. Invoke an AutoSupport message indicating the start of the maintenance:

```
system node autosupport invoke -node * -type all -message MAINT=maintenance-
window-in-hours
```

The maintenance-window-in-hours parameter specifies the length of the maintenance window, with a maximum of 72 hours. If the maintenance is completed before the time has elapsed, you can invoke an AutoSupport message indicating the end of the maintenance period:

system node autosupport invoke -node * -type all -message MAINT=end

3. Repeat these steps on the partner site.

Switching over the MetroCluster configuration

You must switch over the configuration to site_A so that the platforms on site_B can be upgraded.

About this task

This task must be performed on site_A.

After completing this task, cluster_A is active and serving data for both sites. cluster_B is inactive, and ready to begin the upgrade process.



Steps

- 1. Switch over the MetroCluster configuration to site_A so that site_B's nodes can be upgraded:
 - a. Issue the following command on cluster_A:

metrocluster switchover -controller-replacement true

The operation can take several minutes to complete.

b. Monitor the switchover operation:

metrocluster operation show

c. After the operation is complete, confirm that the nodes are in switchover state:

metrocluster show

d. Check the status of the MetroCluster nodes:

metrocluster node show

Automatic healing of aggregates after negotiated switchover is disabled during controller upgrade.

Removing interface configurations and uninstalling the old controllers

You must move data LIFs to a common port, remove VLANs and interface groups on the old controllers and

then physically uninstall the controllers.

About this task

- These steps are performed on the old controllers (node_B_1-old, node_B_2-old).
- See the information you gathered in Mapping ports from the old nodes to the new nodes.

Steps

1. Boot the old nodes and log in to the nodes:

boot_ontap

- 2. Assign the home port of all data LIFs on the old controller to a common port that is the same on both the old and new controller modules.
 - a. Display the LIFs:

network interface show

All data LIFS including SAN and NAS will be admin up and operationally down since those are up at switchover site (cluster_A).

b. Review the output to find a common physical network port that is the same on both the old and new controllers that is not used as a cluster port.

For example, e0d is a physical port on old controllers and is also present on new controllers. e0d is not used as a cluster port or otherwise on the new controllers.

For port usage for platform models, see the NetApp Hardware Universe

c. Modify all data LIFS to use the common port as the home port: network interface modify -vserver svm-name -lif data-lif -home-port port-id

In the following example, this is "e0d".

For example:

network interface modify -vserver vs0 -lif datalif1 -home-port e0d

- Remove any VLAN ports using cluster ports as member ports and ifgrps using cluster ports as member ports.
 - a. Delete VLAN ports:

```
network port vlan delete -node node-name -vlan-name portid-vlandid
```

For example:

network port vlan delete -node nodel -vlan-name elc-80

b. Remove physical ports from the interface groups:

network port ifgrp remove-port -node node-name -ifgrp interface-group-name

-port portid

For example:

network port ifgrp remove-port -node node1 -ifgrp ala -port e0d

c. Remove VLAN and interface group ports from broadcast domain::

network port broadcast-domain remove-ports -ipspace ipspace -broadcast -domain broadcast-domain-name -ports nodename:portname,nodename:portname,...

d. Modify interface group ports to use other physical ports as member as needed .:

ifgrp add-port -node node-name -ifgrp interface-group-name -port port-id

4. Halt the nodes to the LOADER prompt:

halt -inhibit-takeover true

- 5. Connect to the serial console of the old controllers (node_B_1-old and node_B_2-old) at site_B and verify it is displaying the LOADER prompt.
- 6. Gather the bootarg values:

printenv

- 7. Disconnect the storage and network connections on node_B_1-old and node_B_2-old and label the cables so they can be reconnected to the new nodes.
- 8. Disconnect the power cables from node B 1-old and node B 2-old.
- 9. Remove the node_B_1-old and node_B_2-old controllers from the rack.

Updating the switch RCFs to accommodate the new platforms

You must update the switches to a configuration that supports the new platform models.

About this task

You perform this task at the site containing the controllers that are currently being upgraded. In the examples shown in this procedure we are upgrading site_B first.

The switches at site_A will be upgraded when the controllers on site_A are upgraded.

Steps

1. Prepare the IP switches for the application of the new RCF files.

Follow the steps in the procedure for your switch vendor:

MetroCluster IP installation and configuration

- · Resetting the Broadcom IP switch to factory defaults
- · Resetting the Cisco IP switch to factory defaults
- 2. Download and install the RCF files.

Follow the steps in the section for your switch vendor from the MetroCluster IP installation and configuration.

- Downloading and installing the Broadcom RCF files
- Downloading and installing the Cisco IP RCF files

Configuring the new controllers

You must rack and install the controllers, perform required setup in Maintenance mode, and then boot the controllers, and verify the LIF configuration on the controllers.

Setting up the new controllers

You must rack and cable the new controllers.

Steps

1. Plan out the positioning of the new controller modules and storage shelves as needed.

The rack space depends on the platform model of the controller modules, the switch types, and the number of storage shelves in your configuration.

- 2. Properly ground yourself.
- 3. Install the controller modules in the rack or cabinet.

ONTAP Hardware Systems Documentation

- 4. Cable the controllers to the IP switches as described in MetroCluster IP installation and configuration.
 - Cabling the IP switches
- 5. Power up the new nodes and boot them to Maintenance mode.

Restoring the HBA configuration

Depending on the presence and configuration of HBA cards in the controller module, you need to configure them correctly for your site's usage.

Steps

- 1. In Maintenance mode configure the settings for any HBAs in the system:
 - a. Check the current settings of the ports:

ucadmin show

b. Update the port settings as needed.

If you have this type of HBA and desired mode…	Use this command
CNA FC	ucadmin modify -m fc -t initiator adapter-name
CNA Ethernet	ucadmin modify -mode cna adapter-name

FC target	fcadmin config -t target <i>adapter-name</i>
FC initiator	fcadmin config -t initiator <i>adapter-</i> name

2. Exit Maintenance mode:

halt

After you run the command, wait until the node stops at the LOADER prompt.

3. Boot the node back into Maintenance mode to enable the configuration changes to take effect:

boot_ontap maint

4. Verify the changes you made:

If you have this type of HBA	Use this command
CNA	ucadmin show
FC	fcadmin show

Setting the HA state on the new controllers and chassis

You must verify the HA state of the controllers and chassis, and, if necessary, update the state to match your system configuration.

Steps

1. In Maintenance mode, display the HA state of the controller module and chassis:

ha-config show

The HA state for all components should be "mccip".

2. If the displayed system state of the controller or chassis is not correct, set the HA state:

ha-config modify controller mccip

ha-config modify chassis mccip

Setting the MetroCluster IP bootarg variables

Certain MetroCluster IP bootarg values must be configured on the new controller modules. The values must match those configured on the old controller modules.

About this task

In this task, you will use the UUIDs and system IDs identified earlier in the upgrade procedure in Gathering information before the upgrade.

Steps

1. If the nodes being upgraded are AFF A400, FAS8300, or FAS8700 models, set the following bootargs at the LOADER prompt:

```
setenv bootarg.mcc.port_a_ip_config local-IP-address/local-IP-mask,0,HA-
partner-IP-address,DR-partner-IP-address,DR-aux-partnerIP-address,vlan-id
```

```
setenv bootarg.mcc.port_b_ip_config local-IP-address/local-IP-mask,0,HA-
partner-IP-address,DR-partner-IP-address,DR-aux-partnerIP-address,vlan-id
```



If the interfaces are using the default VLANs, the vlan-id is not necessary.

The following commands set the values for node_B_1-new using VLAN 120 for the first network and VLAN 130 for the second network:

setenv bootarg.mcc.port_a_ip_config
172.17.26.10/23,0,172.17.26.11,172.17.26.13,172.17.26.12,120
setenv bootarg.mcc.port_b_ip_config
172.17.27.10/23,0,172.17.27.11,172.17.27.13,172.17.27.12,130

The following commands set the values for node_B_2-new using VLAN 120 for the first network and VLAN 130 for the second network:

setenv bootarg.mcc.port_a_ip_config
172.17.26.11/23,0,172.17.26.10,172.17.26.12,172.17.26.13,120
setenv bootarg.mcc.port_b_ip_config
172.17.27.11/23,0,172.17.27.10,172.17.27.12,172.17.27.13,130

The following example shows the commands for node_B_1-new when the default VLAN is used:

setenv bootarg.mcc.port_a_ip_config
172.17.26.10/23,0,172.17.26.11,172.17.26.13,172.17.26.12
setenv bootarg.mcc.port_b_ip_config
172.17.27.10/23,0,172.17.27.11,172.17.27.13,172.17.27.12

The following example shows the commands for node_B_2-new when the default VLAN is used:

```
setenv bootarg.mcc.port_a_ip_config
172.17.26.11/23,0,172.17.26.10,172.17.26.12,172.17.26.13
setenv bootarg.mcc.port_b_ip_config
172.17.27.11/23,0,172.17.27.10,172.17.27.12,172.17.27.13
```

If the nodes being upgraded are not systems listed in the previous step, at the LOADER prompt for each of the surviving nodes, set the following bootargs with local_IP/mask:

```
setenv bootarg.mcc.port_a_ip_config local-IP-address/local-IP-mask,0,HA-
partner-IP-address,DR-partner-IP-address,DR-aux-partnerIP-address
```

```
setenv bootarg.mcc.port_b_ip_config local-IP-address/local-IP-mask,0,HA-
partner-IP-address,DR-partner-IP-address,DR-aux-partnerIP-address
```

The following commands set the values for node_B_1-new:

```
setenv bootarg.mcc.port_a_ip_config
172.17.26.10/23,0,172.17.26.11,172.17.26.13,172.17.26.12
setenv bootarg.mcc.port_b_ip_config
172.17.27.10/23,0,172.17.27.11,172.17.27.13,172.17.27.12
```

The following commands set the values for node_B_2-new:

```
setenv bootarg.mcc.port_a_ip_config
172.17.26.11/23,0,172.17.26.10,172.17.26.12,172.17.26.13
setenv bootarg.mcc.port_b_ip_config
172.17.27.11/23,0,172.17.27.10,172.17.27.12,172.17.27.13
```

3. At the new nodes' LOADER prompt, set the UUIDs:

```
setenv bootarg.mgwd.partner_cluster_uuid partner-cluster-UUID
setenv bootarg.mgwd.cluster_uuid local-cluster-UUID
setenv bootarg.mcc.pri_partner_uuid DR-partner-node-UUID
setenv bootarg.mcc.aux_partner_uuid DR-aux-partner-node-UUID
setenv bootarg.mcc_iscsi.node_uuid local-node-UUID
```

a. Set the UUIDs on node_B_1-new.

The following example shows the commands for setting the UUIDs on node_B_1-new:

```
setenv bootarg.mgwd.cluster_uuid ee7db9d5-9a82-11e7-b68b-00a098908039
setenv bootarg.mgwd.partner_cluster_uuid 07958819-9ac6-11e7-9b42-
00a098c9e55d
setenv bootarg.mcc.aux_partner_uuid f37b240b-9ac1-11e7-bd4e-
00a098ca379f
setenv bootarg.mcc_iscsi.node_uuid f03cb63c-9a7e-11e7-b68b-
00a098908039
```

b. Set the UUIDs on node B 2-new:

The following example shows the commands for setting the UUIDs on node_B_2-new:

```
setenv bootarg.mgwd.cluster_uuid ee7db9d5-9a82-11e7-b68b-00a098908039
setenv bootarg.mgwd.partner_cluster_uuid 07958819-9ac6-11e7-9b42-
00a098c9e55d
setenv bootarg.mcc.aux_partner_uuid bf8e3f8f-9ac4-11e7-bd4e-
00a098c9e55d
setenv bootarg.mcc_iscsi.node_uuid aa9a7a7a-9a81-11e7-a4e9-
00a098908c35
```

If the original systems were configured for ADP, at each of the replacement nodes' LOADER prompt, enable ADP:

setenv bootarg.mcc.adp enabled true

5. Set the following variables:

```
setenv bootarg.mcc.local config id original-sys-id
```

setenv bootarg.mcc.dr partner dr-partner-sys-id



The setenv bootarg.mcc.local_config_id variable must be set to the sys-id of the original controller module, node_B_1-old.

a. Set the variables on node_B_1-new.

The following example shows the commands for setting the values on node_B_1-new:

setenv bootarg.mcc.local_config_id 537403322
setenv bootarg.mcc.dr partner 537403324

b. Set the variables on node_B_2-new.

The following example shows the commands for setting the values on node_B_2-new:

setenv bootarg.mcc.local_config_id 537403321
setenv bootarg.mcc.dr partner 537403323

6. If using encryption with external key manager, set the required bootargs:

```
setenv bootarg.kmip.init.ipaddr
```

```
setenv bootarg.kmip.kmip.init.netmask
```

setenv bootarg.kmip.kmip.init.gateway

setenv bootarg.kmip.kmip.init.interface

Reassigning root aggregate disks

Reassign the root aggregate disks to the new controller module, using the sysids gathered earlier.

About this task

These steps are performed in Maintenance mode.



Root aggregate disks are the only disks that must be reassigned during the controller upgrade process. Disk ownership of data aggregates is handled as part of the switchover/switchback operation.

Steps

1. Boot the system to Maintenance mode:

boot_ontap maint

2. Display the disks on node_B_1-new from the Maintenance mode prompt:

disk show -a

The command output shows the system ID of the new controller module (1574774970). However, the root aggregate disks are still owned by the old system ID (537403322). This example does not show drives owned by other nodes in the MetroCluster configuration.

```
*> disk show -a
Local System ID: 1574774970
DISK
                    OWNER
                                         POOL
                                               SERIAL NUMBER
                                                              HOME
DR HOME
_____
                    _____
                                         ____
                                                _____
_____
                    _____
prod3-rk18:9.126L44 node B 1-old(537403322) Pool1 PZHYNOMD
node B 1-old(537403322) node B 1-old(537403322)
prod4-rk18:9.126L49 node B 1-old(537403322) Pool1 PPG3J5HA
node B 1-old(537403322) node B 1-old(537403322)
prod4-rk18:8.126L21 node B 1-old(537403322) Pool1 PZHTDSZD
node B 1-old(537403322) node B 1-old(537403322)
                    node B 1-old(537403322) Pool0 SOM1J2CF
prod2-rk18:8.126L2
node B 1-old(537403322) node B 1-old(537403322)
prod2-rk18:8.126L3 node B 1-old(537403322) Pool0
                                                  SOM0CQM5
node B 1-old(537403322) node B 1-old(537403322)
prod1-rk18:9.126L27 node B 1-old(537403322) Pool0 SOM1PSDW
node B 1-old(537403322) node B 1-old(537403322)
•
```

3. Reassign the root aggregate disks on the drive shelves to the new controllers.

If you are using ADP…	Then use this command
Yes	disk reassign -s <i>old-sysid</i> -d <i>new-</i> <i>sysid</i> -r <i>dr-partner-sysid</i>
No	disk reassign -s <i>old-sysid</i> -d <i>new-</i> <i>sysid</i>

4. Reassign the root aggregate disks on the drive shelves to the new controllers:

disk reassign -s old-sysid -d new-sysid

The following example shows reassignment of drives in a non-ADP configuration:

```
*> disk reassign -s 537403322 -d 1574774970
Partner node must not be in Takeover mode during disk reassignment from
maintenance mode.
Serious problems could result!!
Do not proceed with reassignment if the partner is in takeover mode.
Abort reassignment (y/n)? n

After the node becomes operational, you must perform a takeover and
giveback of the HA partner node to ensure disk reassignment is
successful.
Do you want to continue (y/n)? y
Disk ownership will be updated on all disks previously belonging to
Filer with sysid 537403322.
Do you want to continue (y/n)? y
```

5. Verify that the disks of the root aggregate are properly reassigned old-remove:

```
disk show
storage aggr status
```

*> disk show Local System ID: 537097247 DISK OWNER POOL SERIAL NUMBER HOME DR HOME _____ _____ ____ _____ _____ _____ prod03-rk18:8.126L18 node B 1-new(537097247) Pool1 PZHYN0MD node B 1-new(537097247) node B 1-new(537097247) prod04-rk18:9.126L49 node B 1-new(537097247) Pool1 PPG3J5HA node B 1-new(537097247) node B 1-new(537097247) prod04-rk18:8.126L21 node B 1-new(537097247) Pool1 PZHTDSZD node B 1-new(537097247) node B 1-new(537097247) prod02-rk18:8.126L2 node B 1-new(537097247) Pool0 SOM1J2CF node B 1-new(537097247) node B 1-new(537097247) prod02-rk18:9.126L29 node B 1-new(537097247) Pool0 S0M0COM5 node B 1-new(537097247) node B 1-new(537097247) prod01-rk18:8.126L1 node B 1-new(537097247) Pool0 SOM1PSDW node B 1-new(537097247) node B 1-new(537097247) ::> ::> aggr status Status Options State Aggr root, aggr0 node B 1 online raid dp, aggr nosnap=on, mirrored mirror resync priority=high(fixed) fast zeroed 64-bit

Booting up the new controllers

You must boot the new controllers, taking care to ensure that the bootarg variables are correct and, if needed, perform the encryption recovery steps.

Steps

1. Halt the new nodes:

halt

2. If external key manager is configured, set the related bootargs:

setenv bootarg.kmip.init.ipaddr ip-address

setenv bootarg.kmip.init.netmask netmask

setenv bootarg.kmip.init.gateway gateway-address

setenv bootarg.kmip.init.interface interface-id

3. Check if the partner-sysid is the current:

printenv partner-sysid

If the partner-sysid is not correct, set it:

setenv partner-sysid partner-sysID

4. Display the ONTAP boot menu:

boot_ontap menu

5. If root encryption is used, select the boot menu option for your key management configuration.

If you are using	Select this boot menu option
Onboard key management	Option 10
	Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.
External key management	Option 11
	Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.

6. From the boot menu, select "(6) Update flash from backup config".



Option 6 will reboot the node twice before completing.

Respond "y" to the system id change prompts. Wait for the second reboot messages:

Successfully restored env file from boot media...

Rebooting to load the restored env file...

7. On LOADER, double-check the bootarg values and update the values as needed.

Use the steps in Setting the MetroCluster IP bootarg variables.

8. Double-check that the partner-sysid is the correct:

printenv partner-sysid

If the partner-sysid is not correct, set it:

```
setenv partner-sysid partner-sysID
```

9. If root encryption is used, select the boot menu option again for your key management configuration.

If you are using	Select this boot menu option
Onboard key management	Option 10
	Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.
External key management	Option "11"
	Follow the prompts to provide the required inputs to recover and restore the key-manager configuration.

Depending on the key manager setting, perform the recovery procedure by selecting option "10" or option "11", followed by option 6 at the first boot menu prompt. To boot the nodes completely, you might need to repeat the recovery procedure continued by option "1" (normal boot).

10. Wait for the replaced nodes to boot up.

If either node is in takeover mode, perform a giveback using the storage failover giveback command.

11. If encryption is used, restore the keys using the correct command for your key management configuration.

If you are using	Use this command
Onboard key management	security key-manager onboard sync For more information, see Restoring onboard key management encryption keys.
External key management	<pre>security key-manager external restore -vserver SVM -node node -key-server host_name IP_address:port -key-id key_id -key-tag key_tag node-name For more information, see Restoring external key management encryption keys.</pre>

- 12. Verify that all ports are in a broadcast domain:
 - a. View the broadcast domains:

network port broadcast-domain show

b. Add any ports to a broadcast domain as needed.

Adding or removing ports from a broadcast domain

c. Recreate VLANs and interface groups as needed.

VLAN and interface group membership might be different than that of the old node.

Creating a VLAN

Combining physical ports to create interface groups

Verifying and restoring LIF configuration

Verify that LIFs are hosted on appropriate nodes and ports as mapped out at the beginning of the upgrade procedure.

About this tsak

- This task is performed on site_B.
- See the port mapping plan you created in Mapping ports from the old nodes to the new nodes.

Steps

- 1. Verify that LIFs are hosted on the appropriate node and ports prior to switchback.
 - a. Change to the advanced privilege level:

set -privilege advanced

b. Override the port configuration to ensure proper LIF placement:

```
vserver config override -command "network interface modify -vserver
vserver_name -home-port active_port_after_upgrade -lif lif_name -home-node
new node name"
```

When entering the network interface modify command within the vserver config override command, you cannot use the tab autocomplete feature. You can create the network interface modify using autocomplete and then enclose it in the vserver config override command.

c. Return to the admin privilege level:

set -privilege admin

2. Revert the interfaces to their home node:

network interface revert * -vserver vserver-name

Perform this step on all SVMs as required.

Switching back the MetroCluster configuration

In this task, you will perform the switchback operation, and the MetroCluster configuration returns to normal operation. The nodes on site_A are still awaiting upgrade.



Steps

- 1. Issue the metrocluster node show command on site_B and check the output.
 - a. Verify that the new nodes are represented correctly.
 - b. Verify that the new nodes are in "Waiting for switchback state."
- 2. Perform the healing and switchback by running the required commands from any node in the active cluster (the cluster that is not undergoing upgrade).
 - a. Heal the data aggregates: metrocluster heal aggregates
 - b. Heal the root aggregates:

metrocluster heal root

c. Switchback the cluster:

metrocluster switchback

3. Check the progress of the switchback operation:

metrocluster show

The switchback operation is still in progress when the output displays waiting-for-switchback:

cluster_B::> metrocluster Cluster	show Entry Name	State
Local: cluster_B	Configuration state Mode AUSO Failure Domain	configured switchover -
Remote: cluster_A	Configuration state Mode AUSO Failure Domain	configured waiting-for-switchback -

The switchback operation is complete when the output displays normal:

```
cluster B::> metrocluster show
Cluster
                      Entry Name
                                 State
_____ _
                              _____
Local: cluster B
                     Configuration state configured
                     Mode
                                      normal
                     AUSO Failure Domain -
Remote: cluster A
                     Configuration state configured
                     Mode
                                      normal
                      AUSO Failure Domain -
```

If a switchback takes a long time to finish, you can check on the status of in-progress baselines by using the metrocluster config-replication resync-status show command. This command is at the advanced privilege level.

Checking the health of the MetroCluster configuration

After upgrading the controller modules you must verify the health of the MetroCluster configuration.

About this task

This task can be performed on any node in the MetroCluster configuration.

Steps

1. Verify the operation of the MetroCluster configuration:

- a. Confirm the MetroCluster configuration and that the operational mode is normal: metrocluster show
- b. Perform a MetroCluster check: metrocluster check run
- c. Display the results of the MetroCluster check:

metrocluster check show

2. Verify the MetroCluster connectivity and status.

a. Check the MetroCluster IP connections:

storage iscsi-initiator show

b. Check that the nodes are operating:

metrocluster node show

c. Check that the MetroCluster IP interfaces are up:

metrocluster configuration-settings interface show

d. Check that local failover is enabled:

storage failover show

Upgrading the nodes on cluster_A

You must repeat the upgrade tasks on cluster_A.

Steps

1. Repeat the steps to upgrade the nodes on cluster_A, beginning with Preparing for the upgrade.

As you perform the tasks, all example references to the clusters and nodes are reversed. For example, when the example is given to switchover from cluster_A, you will switchover from cluster_B.

Restoring Tiebreaker or Mediator monitoring

After completing the upgrade of the MetroCluster configuration, you can resume monitoring with the Tiebreaker or Mediator utility.

Steps

1. Restore monitoring if necessary, using the procedure for your configuration.

If you are using	Use this procedure
Tiebreaker	Adding MetroCluster configurations.
Mediator	Configuring the ONTAP Mediator service from a MetroCluster IP configuration.
Third-party applications	Refer to the product documentation.

Sending a custom AutoSupport message after maintenance

After completing the upgrade, you should send an AutoSupport message indicating the end of maintenance, so automatic case creation can resume.

Steps

1. To resume automatic support case generation, send an Autosupport message to indicate that the

maintenance is complete.

- a. Issue the following command: system node autosupport invoke -node * -type all -message MAINT=end
- b. Repeat the command on the partner cluster.

Upgrade controllers from AFF A700/FAS9000 to AFF A900/FAS9500 in a MetroCluster IP configuration using switchover and switchback (ONTAP 9.10.1 or later)

You can use the MetroCluster switchover operation to provide nondisruptive service to clients while the controller modules on the partner cluster are upgraded. Other components (such as storage shelves or switches) cannot be upgraded as part of this procedure.

About this task

- To upgrade AFF A700 controller modules to AFF A900, the controllers must be running ONTAP 9.10.1 or later.
- To upgrade FAS9000 controller modules to FAS9500, the controllers must be running ONTAP 9.10.1P3 or later.
- All controllers in the configuration should be upgraded during the same maintenance period.

Operating the MetroCluster configuration with an AFF A700 and an AFF A900, or a FAS9000 and a FAS9500 controller is not supported outside of this maintenance activity.

- The IP switches must be running a supported firmware version.
- You will reuse the IP addresses, netmasks, and gateways of the original platforms on the new platforms.
- The following example names are used in this procedure, in both examples and graphics:
 - ∘ Site_A
 - Before upgrade:
 - node_A_1-A700
 - node_A_2-A700
 - After upgrade:
 - node_A_1-A900
 - node_A_2-A900
 - ∘ Site_B
 - Before upgrade:
 - node_B_1-A700
 - node_B_2-A700
 - After upgrade:
 - node_B_1-A900
 - node_B_2-A900

Workflow for upgrading controllers in a MetroCluster IP configuration



You can use the workflow diagram to help you plan the upgrade tasks.

Prepare for the upgrade

Before making any changes to the existing MetroCluster configuration, you must check the health of the configuration, prepare the new platforms, and perform other miscellaneous tasks.

Clear slot 7 on the AFF A700 or FAS9000 controller

The MetroCluster configuration on an AFF A900 or FAS9500 uses one of each of the ports on the DR cards located in slots 5 and 7. Before starting the upgrade, if there are cards in slot 7 on the AFF A700 or FAS9000, you must move them to other slots for all the nodes of the cluster.

Update the MetroCluster switch RCF files before upgrading controllers

You must update the RCF files on MetroCluster switches when performing this upgrade. The following table provides the VLAN ranges supported for AFF A900/FAS9500 MetroCluster IP configurations.

Platform model	Supported VLAN IDs
• AFF A900 or FAS9500	• 10
	• 20
	• Any value in the range 101 to 4096 inclusive.

• If the switch is not configured with the minimum supported RCF file version, you must update the RCF file. For the correct RCF file version for your switch model, refer to the RcfFileGenerator Tool. The following steps are for the RCF file application.

Steps

1. Prepare the IP switches for the application of the new RCF files.

Follow the steps in the section for your switch vendor from the MetroCluster IP Installation and Configuration content.

- · Resetting the Broadcom IP switch to factory defaults
- Resetting the Cisco IP switch to factory defaults
- 2. Download and install the RCF files.

Follow the steps in the MetroCluster IP Installation and Configuration content.

- Downloading and installing the Broadcom RCF files
- Downloading and installing the Cisco IP RCF files

Map ports from the old nodes to the new nodes

When upgrading from an AFF A700 to an AFF A900, or FAS9000 to FAS9500, you do not change the data network ports, FCP SAN adapter ports, and SAS and NVMe storage ports. Data LIFs stay where they are during and after the upgrade. Therefore, you are not required to map the network ports from the old nodes to the new nodes.

Verify MetroCluster health before site upgrade

You must verify the health and connectivity of the MetroCluster configuration prior to performing the upgrade.

Steps

- 1. Verify the operation of the MetroCluster configuration in ONTAP:
 - a. Check whether the nodes are multipathed: node run -node *node-name* sysconfig -a

You should issue this command for each node in the MetroCluster configuration.

b. Verify that there are no broken disks in the configuration: storage disk show -broken

You should issue this command on each node in the MetroCluster configuration.

c. Check for any health alerts:

system health alert show

You should issue this command on each cluster.

d. Verify the licenses on the clusters:

system license show

You should issue this command on each cluster.

e. Verify the devices connected to the nodes:

network device-discovery show

You should issue this command on each cluster.

f. Verify that the time zone and time is set correctly on both sites:

cluster date show

You should issue this command on each cluster. You can use the cluster date command to configure the time and time zone.

- 2. Confirm the operational mode of the MetroCluster configuration and perform a MetroCluster check.
 - a. Confirm the MetroCluster configuration and that the operational mode is normal: metrocluster show
 - b. Confirm that all expected nodes are shown: metrocluster node show
 - c. Issue the following command:

metrocluster check run

d. Display the results of the MetroCluster check:

metrocluster check show

- 3. Check the MetroCluster cabling with the Config Advisor tool.
 - a. Download and run Config Advisor.

NetApp Downloads: Config Advisor

b. After running Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.

Gather information before the upgrade

Before upgrading, you must gather information for each of the nodes, and, if necessary, adjust the network broadcast domains, remove any VLANs and interface groups, and gather encryption information.

Steps

1. Record the physical cabling for each node, labelling cables as needed to allow correct cabling of the new nodes.

- 2. Gather the output of the following commands for each node:
 - $^{\circ}$ metrocluster interconnect show
 - ° metrocluster configuration-settings connection show
 - ° network interface show -role cluster, node-mgmt
 - ° network port show -node node name -type physical
 - ° network port vlan show -node node-name
 - ° network port ifgrp show -node node_name -instance
 - ° network port broadcast-domain show
 - ° network port reachability show -detail
 - ° network ipspace show
 - ° volume show
 - ° storage aggregate show
 - ° system node run -node node-name sysconfig -a
 - ° vserver fcp initiator show
 - ° storage disk show
 - ° metrocluster configuration-settings interface show
- 3. Gather the UUIDs for the site_B (the site whose platforms are currently being upgraded): metrocluster node show -fields node-cluster-uuid, node-uuid

These values must be configured accurately on the new site_B controller modules to ensure a successful upgrade. Copy the values to a file so that you can copy them into the proper commands later in the upgrade process.

The following example shows the command output with the UUIDs:

```
cluster B::> metrocluster node show -fields node-cluster-uuid, node-uuid
  (metrocluster node show)
dr-group-id cluster node node-uuid
node-cluster-uuid
_____
_____
          cluster A node A 1-A700 f03cb63c-9a7e-11e7-b68b-00a098908039
1
ee7db9d5-9a82-11e7-b68b-00a098908039
          cluster A node A 2-A700 aa9a7a7a-9a81-11e7-a4e9-00a098908c35
1
ee7db9d5-9a82-11e7-b68b-00a098908039
1
          cluster B node B 1-A700 f37b240b-9ac1-11e7-9b42-00a098c9e55d
07958819-9ac6-11e7-9b42-00a098c9e55d
1
          cluster B node B 2-A700 bf8e3f8f-9ac4-11e7-bd4e-00a098ca379f
07958819-9ac6-11e7-9b42-00a098c9e55d
4 entries were displayed.
cluster B::*
```

It is recommended that you record the UUIDs into a table similar to the following.

Cluster or node	UUID
cluster_B	07958819-9ac6-11e7-9b42-00a098c9e55d
node_B_1-A700	f37b240b-9ac1-11e7-9b42-00a098c9e55d
node_B_2-A700	bf8e3f8f-9ac4-11e7-bd4e-00a098ca379f
cluster_A	ee7db9d5-9a82-11e7-b68b-00a098908039
node_A_1-A700	f03cb63c-9a7e-11e7-b68b-00a098908039
node_A_2-A700	aa9a7a7a-9a81-11e7-a4e9-00a098908c35

4. If the MetroCluster nodes are in a SAN configuration, collect the relevant information.

You should gather the output of the following commands:

- ° fcp adapter show -instance
- ° fcp interface show -instance
- ° iscsi interface show
- ° ucadmin show
- 5. If the root volume is encrypted, collect and save the passphrase used for key-manager: security keymanager backup show
- 6. If the MetroCluster nodes are using encryption for volumes or aggregates, copy information about the keys and passphrases. For additional information, see Backing up onboard key management information manually.
 - a. If Onboard Key Manager is configured: security key-manager onboard show-backup You will need the passphrase later in the upgrade procedure.
 - b. If enterprise key management (KMIP) is configured, issue the following commands:

```
security key-manager external show -instance security key-manager key query
```

7. Gather the system IDs of the existing nodes: metrocluster node show -fields nodesystemid, ha-partner-systemid, dr-partner-systemid, dr-auxiliary-systemid

The following output shows the reassigned drives.

::> metrocluster node show -fields node-systemid, ha-partner-systemid, drpartner-systemid, dr-auxiliary-systemid dr-group-id cluster node node-systemid ha-partner-systemid drpartner-systemid dr-auxiliary-systemid ----cluster A node A 1-A700 1 537403324 537403323 537403321 537403322 1 cluster A node A 2-A700 537403323 537403324 537403321 537403322 1 cluster B node B 1-A700 537403322 537403321 537403323 537403324 cluster B node B 2-A700 537403321 537403322 1 537403323 537403324 4 entries were displayed.

Remove Mediator or Tiebreaker monitoring

Before the upgrading the platforms, you must remove monitoring if the MetroCluster configuration is monitored with the Tiebreaker or Mediator utility.

Steps

1. Collect the output for the following command:

storage iscsi-initiator show

2. Remove the existing MetroCluster configuration from Tiebreaker, Mediator, or other software that can initiate switchover.

If you are using	Use this procedure
Tiebreaker	Removing MetroCluster Configurations in the MetroCluster Tiebreaker Installation and Configuration content
Mediator	Issue the following command from the ONTAP prompt:
	metrocluster configuration-settings mediator remove
Third-party applications	Refer to the product documentation.

Send a custom AutoSupport message prior to maintenance

Before performing the maintenance, you should issue an AutoSupport message to notify technical support that maintenance is underway. Informing technical support that maintenance is underway prevents them from opening a case on the assumption that a disruption has occurred.

About this task

This task must be performed on each MetroCluster site.

Steps

- 1. Log in to the cluster.
- 2. Invoke an AutoSupport message indicating the start of the maintenance:

```
system node autosupport invoke -node * -type all -message MAINT=maintenance-
window-in-hours
```

The maintenance-window-in-hours parameter specifies the length of the maintenance window, with a maximum of 72 hours. If the maintenance is completed before the time has elapsed, you can invoke an AutoSupport message indicating the end of the maintenance period:

system node autosupport invoke -node * -type all -message MAINT=end

3. Repeat these steps on the partner site.

Switch over the MetroCluster configuration

You must switch over the configuration to site_A so that the platforms on site_B can be upgraded.

About this task

This task must be performed on site_A.

After completing this task, site_A is active and serving data for both sites. site_B is inactive, and ready to begin the upgrade process.



Steps

- 1. Switch over the MetroCluster configuration to site_A so that site_B's nodes can be upgraded:
 - a. Issue the following command on site_A:

metrocluster switchover -controller-replacement true

The operation can take several minutes to complete.

b. Monitor the switchover operation:

metrocluster operation show

c. After the operation is complete, confirm that the nodes are in switchover state:

metrocluster show

d. Check the status of the MetroCluster nodes:

metrocluster node show

Automatic healing of aggregates after negotiated switchover is disabled during controller upgrade. Nodes at site_B are halted and stopped at the LOADER prompt.

Remove AFF A700 or FAS9000 platform controller module and NVS

About this task

If you are not already grounded, properly ground yourself.

Steps

- 1. Gather the bootarg values from both nodes at site_B: printenv
- 2. Power off the chassis at site_B.

Remove the AFF A700 or FAS9000 controller module

Use the following procedure to remove the AFF A700 or FAS9000 controller module

Steps

- 1. Detach the console cable, if any, and the management cable from the controller module before removing the controller module.
- 2. Unlock and remove the controller module from the chassis.
 - a. Slide the orange button on the cam handle downward until it unlocks.



Cam handle release button
Cam handle

b. Rotate the cam handle so that it completely disengages the controller module from the chassis, and then slide the controller module out of the chassis. Make sure that you support the bottom of the controller module as you slide it out of the chassis.

Remove the AFF A700 or FAS9000 NVS module

Use the following procedure to remove the AFF A700 or FAS9000 NVS module.

Note: The NVS module is in slot 6 and is double the height compared to other modules in the system.

Steps

1. Unlock and remove the NVS from slot 6.

- a. Depress the lettered and numbered 'cam' button. The cam button moves away from the chassis.
- b. Rotate the cam latch down until it is in a horizontal position. The NVS disengages from the chassis and moves a few inches.
- c. Remove the NVS from the chassis by pulling on the pull tabs on the sides of the module face.



Lettered and numbered I/O cam latch
I/O latch completely unlocked

 If you are using add-on modules used as coredump devices on the AFF A700 or FAS9000 NVS, do not transfer them to the AFF A900 or FAS9500 NVS. Do not transfer any parts from the AFF A700 or FAS9000 controller module and NVS to the AFF A900 or FAS9500 module.

Install the AFF A900 or FAS9500 NVS and controller modules

You must install the AFF A900 or FAS9500 NVS and controller module that you received in the upgrade kit on both nodes at site_B. Do not move the coredump device from the AFF A700 or FAS9000 NVS module to the AFF A900 or FAS9500 NVS module.

About this task

If you are not already grounded, properly ground yourself.

Install the AFF A900 or FAS9500 NVS

Use the following procedure to install the AFF A900 or FAS9500 NVS in slot 6 of both nodes at site_B.

Steps

- 1. Align the NVS with the edges of the chassis opening in slot 6.
- 2. Gently slide the NVS into the slot until the lettered and numbered I/O cam latch begins to engage with the I/O cam pin, and then push the I/O cam latch all the way up to lock the NVS in place.



Lettered and numbered I/O cam latch
I/O latch completely unlocked

Install the AFF A900 or FAS9500 controller module.

Use the following procedure to install the AFF A900 or FAS9500 controller module.

Steps

- 1. Align the end of the controller module with the opening in the chassis, and then gently push the controller module halfway into the system.
- 2. Firmly push the controller module into the chassis until it meets the midplane and is fully seated. The locking latch rises when the controller module is fully seated. Attention: To avoid damaging the connectors, do not use excessive force when sliding the controller module into the chassis.
- 3. Cable the management and console ports to the controller module.





- 4. Install the second X91146A card in slot 7 of each node.
 - a. Move the e5b connection to e7b.
 - b. Move the e5a connection to e5b.



Slot 7 on all nodes of the cluster should be empty as mentioned in Map ports from the old nodes to the new nodes section.

- 5. Power ON the chassis and connect to serial console.
- 6. After BIOS initialization, if the node starts autoboot, interrupt the AUTOBOOT by pressing Control-C.
- 7. After autoboot is interrupted, the nodes stop at the LOADER prompt. If you do not interrupt autoboot on time and node1 starts booting, wait for the prompt to press Ctrl-C to go into the boot menu. After the node stops at the boot menu, use option 8 to reboot the node and interrupt the autoboot during reboot.
- 8. At the LOADER prompt, set the default environment variables: set-defaults
- 9. Save the default environment variables settings: saveenv

Netboot nodes at site_B

After swapping the AFF A900 or FAS9500 controller module and NVS, you need to netboot the AFF A900 or FAS9500 nodes and install the same ONTAP version and patch level that is running on the cluster. The term netboot means you are booting from an ONTAP image stored on a remote server. When preparing for netboot, you must add a copy of the ONTAP 9 boot image onto a web server that the system can access. It is not possible to check the version of ONTAP installed on the boot media of an AFF A900 or FAS9500 controller module unless it is installed in a chassis and powered ON. The ONTAP version on the AFF A900 or FAS9500 boot media must be the same as the ONTAP version running on the AFF A700 or FAS9000 system that is being upgraded and both the primary and backup boot images should match. You can configure the images by performing a netboot followed by the wipeconfig command from the boot menu. If the controller module was previously used in another cluster, the wipeconfig command clears any residual configuration on the boot media.

Before you start

- Verify that you can access a HTTP server with the system.
- You need to download the necessary system files for your system and the correct version of ONTAP from the NetApp Support Site.

About this task

You must netboot the new controllers, if the version of ONTAP installed is not the same as the version installed on the original controllers. After you install each new controller, you boot the system from the ONTAP 9 image stored on the web server. You can then download the correct files to the boot media device for subsequent system boots.

Steps

- 1. Access the NetApp Support Site to download the files used for performing the netboot of the system.
- 2. Download the appropriate ONTAP software from the software download section of the NetApp Support

Site and store the ontap-version image.tgz file on a web-accessible directory.

- 3. Change to the web-accessible directory and verify that the files you need are available.
- 4. Your directory listing should contain <ontap_version>_image.tgz.
- 5. Configure the netboot connection by choosing one of the following actions.



You should use the management port and IP as the netboot connection. Do not use a data LIF IP or a data outage might occur while the upgrade is being performed.

RunningConfigure the connection automatically by using the following command at the boot environment prompt: ifconfig e0M -autoNot RunningManually configure the connection by using the following command at the boot environment prompt: ifconfig e0M -addr= <filer_addr> -mask=<netmask> -gw=<gateway> - dns=<dns_addr> domain=<dns_domain><filer_addr> is the IP address of the storage system. <netmask> is the network mask of the storage system. <gateway> is the gateway for the storage system. <dns_addr> is the IP address of a name server on your network. This parameter is optional. <dns_domain> is the Domain Name Service (DNS) domain name. This parameter is optional. NOTE: Other parameters might be necessary for your interface. Enter help</dns_domain></dns_addr></gateway></netmask></filer_addr></dns_domain></dns_addr></gateway></netmask></filer_addr>	If the Dynamic Host Configuration Protocol (DCHP) is	Then
Not RunningManually configure the connection by using the following command at the boot environment prompt: ifconfig e0M -addr= <filer_addr> -mask=<netmask> -gw=<gateway> - dns=<dns_addr> domain=<dns_domain><filer_addr> is the IP address of the storage system. <netmask> is the network mask of the storage system. <gateway> is the gateway for the storage system. <dns_addr> is the IP address of a name server on your network. This parameter is optional. <dns_domain> is the Domain Name Service (DNS) domain name. This parameter is optional. NOTE: Other parameters might be necessary for your interface. Enter help</dns_domain></dns_addr></gateway></netmask></filer_addr></dns_domain></dns_addr></gateway></netmask></filer_addr>	Running	Configure the connection automatically by using the following command at the boot environment prompt: ifconfig eOM -auto
ifconfig at the firmware prompt for details.	Not Running	Manually configure the connection by using the following command at the boot environment prompt: ifconfig eOM -addr= <filer_addr> -mask=<netmask> -gw=<gateway> - dns=<dns_addr> domain=<dns_domain> <filer_addr> is the IP address of the storage system. <netmask> is the network mask of the storage system. <gateway> is the gateway for the storage system. <dns_addr> is the IP address of a name server on your network. This parameter is optional. <dns_domain> is the Domain Name Service (DNS) domain name. This parameter is optional. NOTE: Other parameters might be necessary for your interface. Enter help ifconfig at the firmware prompt for details.</dns_domain></dns_addr></gateway></netmask></filer_addr></dns_domain></dns_addr></gateway></netmask></filer_addr>

6. Perform netboot on node_B_1: netboot

http://<web_server_ip/path_to_web_accessible_directory>/netboot/kernel

 $\label{eq:linear} The < \texttt{path_to_the_web-accessible_directory} > \texttt{should lead to where you downloaded the} < \texttt{ontap version} & \texttt{image.tgz in Step 2}.$



Do not interrupt the boot.

7. Wait for the node_B_1 now running on the AFF A900 or FAS9500 controller module to boot and display the boot menu options as shown below:

Please choose one of the following: Normal Boot. (1)Boot without /etc/rc. (2)(3) Change password. Clean configuration and initialize all disks. (4) (5) Maintenance mode boot. (6) Update flash from backup config. Install new software first. (7) (8) Reboot node. (9) Configure Advanced Drive Partitioning. (10) Set Onboard Key Manager recovery secrets. (11) Configure node for external key management. Selection (1-11)?

8. From the boot menu, select option (7) Install new software first. This menu option downloads and installs the new ONTAP image to the boot device. NOTE: Disregard the following message: This procedure is not supported for Non-Disruptive Upgrade on an HA pair. This note applies to nondisruptive ONTAP software upgrades, and not controller upgrades.

Always use netboot to update the new node to the desired image. If you use another method to install the image on the new controller, the incorrect image might install. This issue applies to all ONTAP releases.

- 9. If you are prompted to continue the procedure, enter y, and when prompted for the package, enter the URL: http://<web_server_ip/path_to_web-accessible directory>/<ontap version>\ image.tgz
- 10. Complete the following substeps to reboot the controller module:
 - a. Enter n to skip the backup recovery when you see the following prompt: Do you want to restore the backup configuration now? {y|n}
 - b. Enter y to reboot when you see the following prompt: `The node must be rebooted to start using the newly installed software. Do you want to reboot now? {y|n} The controller module reboots but stops at the boot menu because the boot device was reformatted, and the configuration data needs to be restored.
- 11. At the prompt, run the wipeconfig command to clear any previous configuration on the boot media:
 - a. When you see the following message, answer yes: This will delete critical system configuration, including cluster membership. Warning: do not run this option on a HA node that has been taken over. Are you sure you want to continue?:
 - b. The node reboots to finish the wipeconfig and then stops at the boot menu.
- 12. Select option 5 to go to maintenance mode from the boot menu. Answer yes to the prompts until the node stops at maintenance mode and the command prompt *>.
- 13. Repeat these steps to netboot node_B_2.

Restore the HBA configuration

Depending on the presence and configuration of HBA cards in the controller module, you need to configure

them correctly for your site's usage.

Steps

- 1. In Maintenance mode configure the settings for any HBAs in the system:
 - a. Check the current settings of the ports:

ucadmin show

b. Update the port settings as needed.

If you have this type of HBA and desired mode	Use this command
CNA FC	ucadmin modify -m fc -t initiator <i>adapter-name</i>
CNA Ethernet	ucadmin modify -mode cna <i>adapter-name</i>
FC target	fcadmin config -t target <i>adapter-name</i>
FC initiator	fcadmin config -t initiator adapter- name

2. Exit Maintenance mode:

halt

After you run the command, wait until the node stops at the LOADER prompt.

3. Boot the node back into Maintenance mode to enable the configuration changes to take effect:

boot_ontap maint

4. Verify the changes you made:

If you have this type of HBA	Use this command
CNA	ucadmin show
FC	fcadmin show

Set the HA state on the new controllers and chassis

You must verify the HA state of the controllers and chassis, and, if necessary, update the state to match your system configuration.

Steps

1. In Maintenance mode, display the HA state of the controller module and chassis:

ha-config show
The HA state for all components should be mccip.

2. If the displayed system state of the controller or chassis is not correct, set the HA state:

ha-config modify controller mccip

ha-config modify chassis mccip

3. Halt the node: halt

The node should stop at the LOADER> prompt.

- 4. On each node, check the system date, time, and time zone: show date
- 5. If necessary, set the date in UTC or GMT: set date <mm/dd/yyyy>
- 6. Check the time by using the following command at the boot environment prompt: show time
- 7. If necessary, set the time in UTC or GMT: set time <hh:mm:ss>
- 8. Save the settings: saveenv
- 9. Gather environment variables: printenv

Update the switch RCF files to accommodate the new platforms

You must update the switches to a configuration that supports the new platform models.

About this task

You perform this task at the site containing the controllers that are currently being upgraded. In the examples shown in this procedure we are upgrading site_B first.

The switches at site_A will be upgraded when the controllers on site_A are upgraded.

Steps

1. Prepare the IP switches for the application of the new RCF files.

Follow the steps in the section for your switch vendor from the *MetroCluster IP Installation and Configuration* section.

MetroCluster IP installation and configuration

- · Resetting the Broadcom IP switch to factory defaults
- Resetting the Cisco IP switch to factory defaults
- 2. Download and install the RCF files.

Follow the steps in the section for your switch vendor from the MetroCluster IP installation and configuration.

- Downloading and installing the Broadcom RCF files
- Downloading and installing the Cisco IP RCF files

Configure the new controllers

New controllers should be ready and cabled at this point.

Set the MetroCluster IP bootarg variables

Certain MetroCluster IP bootarg values must be configured on the new controller modules. The values must match those configured on the old controller modules.

About this task

In this task, you will use the UUIDs and system IDs identified earlier in the upgrade procedure in Gathering information before the upgrade.

Steps

1. At the LOADER> prompt, set the following bootargs on the new nodes at site_B:

setenv bootarg.mcc.port_a_ip_config local-IP-address/local-IP-mask,0,HApartner-IP-address,DR-partner-IP-address,DR-aux-partnerIP-address,vlan-id

setenv bootarg.mcc.port_b_ip_config local-IP-address/local-IP-mask,0,HApartner-IP-address,DR-partner-IP-address,DR-aux-partnerIP-address,vlan-id

The following example sets the values for node_B_1-A900 using VLAN 120 for the first network and VLAN 130 for the second network:

setenv bootarg.mcc.port_a_ip_config
172.17.26.10/23,0,172.17.26.11,172.17.26.13,172.17.26.12,120
setenv bootarg.mcc.port_b_ip_config
172.17.27.10/23,0,172.17.27.11,172.17.27.13,172.17.27.12,130

The following example sets the values for node_B_2-A900 using VLAN 120 for the first network and VLAN 130 for the second network:

setenv bootarg.mcc.port_a_ip_config
172.17.26.11/23,0,172.17.26.10,172.17.26.12,172.17.26.13,120
setenv bootarg.mcc.port_b_ip_config
172.17.27.11/23,0,172.17.27.10,172.17.27.12,172.17.27.13,130

2. At the new nodes' LOADER prompt, set the UUIDs:

```
setenv bootarg.mgwd.partner_cluster_uuid partner-cluster-UUID
setenv bootarg.mgwd.cluster_uuid local-cluster-UUID
setenv bootarg.mcc.pri_partner_uuid DR-partner-node-UUID
setenv bootarg.mcc.aux_partner_uuid DR-aux-partner-node-UUID
setenv bootarg.mcc_iscsi.node_uuid local-node-UUID
```

a. Set the UUIDs on node_B_1-A900.

The following example shows the commands for setting the UUIDs on node_B_1-A900:

```
setenv bootarg.mgwd.cluster_uuid ee7db9d5-9a82-11e7-b68b-00a098908039
setenv bootarg.mgwd.partner_cluster_uuid 07958819-9ac6-11e7-9b42-
00a098c9e55d
setenv bootarg.mcc.aux_partner_uuid f37b240b-9ac1-11e7-bd4e-
00a098ca379f
setenv bootarg.mcc_iscsi.node_uuid f03cb63c-9a7e-11e7-b68b-
00a098908039
```

b. Set the UUIDs on node_B_2-A900:

The following example shows the commands for setting the UUIDs on node_B_2-A900:

```
setenv bootarg.mgwd.cluster_uuid ee7db9d5-9a82-11e7-b68b-00a098908039
setenv bootarg.mgwd.partner_cluster_uuid 07958819-9ac6-11e7-9b42-
00a098c9e55d
setenv bootarg.mcc.aux_partner_uuid bf8e3f8f-9ac4-11e7-bd4e-
00a098c9e55d
setenv bootarg.mcc_iscsi.node_uuid aa9a7a7a-9a81-11e7-a4e9-
00a098908c35
```

3. If the original systems were configured for ADP, at each of the replacement nodes' LOADER prompt, enable ADP:

setenv bootarg.mcc.adp enabled true

4. Set the following variables:

setenv bootarg.mcc.local_config_id original-sys-id

setenv bootarg.mcc.dr partner dr-partner-sys-id



The setenv bootarg.mcc.local_config_id variable must be set to the sys-id of the original controller module, node_B_1-A700.

a. Set the variables on node_B_1-A900.

The following example shows the commands for setting the values on node_B_1-A900:

```
setenv bootarg.mcc.local_config_id 537403322
setenv bootarg.mcc.dr partner 537403324
```

b. Set the variables on node_B_2-A900.

The following example shows the commands for setting the values on node_B_2-A900:

```
setenv bootarg.mcc.local_config_id 537403321
setenv bootarg.mcc.dr partner 537403323
```

5. If using encryption with external key manager, set the required bootargs:

setenv bootarg.kmip.init.ipaddr
setenv bootarg.kmip.kmip.init.netmask
setenv bootarg.kmip.kmip.init.gateway
setenv bootarg.kmip.kmip.init.interface

Reassign root aggregate disks

Reassign the root aggregate disks to the new controller module, using the sysids gathered earlier.

About this task

These steps are performed in Maintenance mode.

Steps

1. Boot the system to Maintenance mode:

boot ontap maint

2. Display the disks on node_B_1-A900 from the Maintenance mode prompt:

disk show -a

The command output shows the system ID of the new controller module (1574774970). However, the root aggregate disks are still owned by the old system ID (537403322). This example does not show drives owned by other nodes in the MetroCluster configuration.

```
*> disk show -a
Local System ID: 1574774970
DISK
                    OWNER
                                         POOL
                                               SERIAL NUMBER
                                                               HOME
DR HOME
_____
                    _____
                                         ____
                                                _____
_____
                    _____
prod3-rk18:9.126L44 node B 1-A700(537403322) Pool1 PZHYN0MD
node B 1-A700(537403322) node B 1-A700(537403322)
prod4-rk18:9.126L49 node B 1-A700(537403322) Pool1 PPG3J5HA
node B 1-A700(537403322) node B 1-700(537403322)
prod4-rk18:8.126L21
                    node B 1-A700(537403322) Pool1
                                                   PZHTDSZD
node B 1-A700(537403322) node B 1-A700(537403322)
prod2-rk18:8.126L2 node B 1-A700(537403322) Pool0
                                                   SOM1J2CF
node B 1-(537403322) node B 1-A700(537403322)
prod2-rk18:8.126L3 node B 1-A700(537403322) Pool0
                                                   SOM0CQM5
node B 1-A700(537403322) node B 1-A700(537403322)
prod1-rk18:9.126L27 node B 1-A700(537403322) Pool0
                                                   SOM1PSDW
node B 1-A700(537403322) node B 1-A700(537403322)
•
```

3. Reassign the root aggregate disks on the drive shelves to the new controllers.

If you are using ADP…	Then use this command
Yes	disk reassign -s <i>old-sysid</i> -d <i>new-</i> <i>sysid</i> -r <i>dr-partner-sysid</i>
No	disk reassign -s <i>old-sysid</i> -d <i>new-</i> <i>sysid</i>

4. Reassign the root aggregate disks on the drive shelves to the new controllers:

disk reassign -s old-sysid -d new-sysid

The following example shows reassignment of drives in a non-ADP configuration:

```
*> disk reassign -s 537403322 -d 1574774970
Partner node must not be in Takeover mode during disk reassignment from
maintenance mode.
Serious problems could result!!
Do not proceed with reassignment if the partner is in takeover mode.
Abort reassignment (y/n)? n

After the node becomes operational, you must perform a takeover and
giveback of the HA partner node to ensure disk reassignment is
successful.
Do you want to continue (y/n)? y
Disk ownership will be updated on all disks previously belonging to
Filer with sysid 537403322.
Do you want to continue (y/n)? y
```

5. Verify that the disks of the root aggregate are correctly reassigned old-remove:

```
disk show
storage aggr status
```

*> disk show				
Local System ID: 5370972	47			
DISK	OWNER		POOL	SERIAL NUMBER
HOME	DR HOME			
prod03-rk18:8.126L18 nod	e_B_1-A900(53709	7247) Pool	ll PZH	YNOMD
node_B_1-A900(537097247)	node_B_1-A900	(537097247))	
prod04-rk18:9.126L49 nod	e_B_1-A900(53709	7247) Pool	ll PPG	ЗЈ5НА
node_B_1-A900(537097247)	node_B_1-A900	(537097247))	
prod04-rk18:8.126L21 nod	e_B_1-A900(53709	7247) Pool	ll PZH	TDSZD
node_B_1-A900(537097247)	node_B_1-A900	(537097247))	
prod02-rk18:8.126L2 nod	e_B_1-A900(53709	7247) Pool	LO SOM	I1J2CF
node_B_1-A900(537097247)	node_B_1-A900	(537097247))	
prod02-rk18:9.126L29 nod	e_B_1-A900(53709	7247) Pool	LO SOM	IOCQM5
node_B_1-A900(537097247)	node_B_1-A900	(537097247))	
prod01-rk18:8.126L1 nod	e_B_1-A900(53709	7247) Pool	LO SOM	Ilpsdw
node_B_1-A900(537097247)	node_B_1-A900	(537097247))	
::>				
::> aggr status				
Aggr	State	Status		Options
aggr0_node_B_1	online	raid_dp, a	aggr	root,
nosnap=on,				
		mirrored		
<pre>mirror_resync_priority=h</pre>	igh(fixed)			
		fast zeroe	ed	
		64-bit		

Boot up the new controllers

You must boot the new controllers, taking care to ensure that the bootarg variables are correct and, if needed, perform the encryption recovery steps.

Steps

1. Halt the new nodes:

halt

2. If external key manager is configured, set the related bootargs:

setenv bootarg.kmip.init.ipaddr ip-address

setenv bootarg.kmip.init.netmask netmask

```
setenv bootarg.kmip.init.gateway gateway-address
```

setenv bootarg.kmip.init.interface interface-id

3. Check if the partner-sysid is the current:

printenv partner-sysid

If the partner-sysid is not correct, set it:

setenv partner-sysid partner-sysID

4. Display the ONTAP boot menu:

boot_ontap menu

5. If root encryption is used, select the boot menu option for your key management configuration.

If you are using	Select this boot menu option
Onboard key management	Option 10 and follow the prompts to provide the required inputs to recover or restore the key- manager configuration
External key management	Option 11 and follow the prompts to provide the required inputs to recover or restore the key- manager configuration

6. From the boot menu, select (6) Update flash from backup config.



Option 6 will reboot the node twice before completing.

Respond y to the system id change prompts. Wait for the second reboot messages:

Successfully restored env file from boot media...

Rebooting to load the restored env file...

7. Interrupt the AUTOBOOT to stop the controllers at LOADER.



On each node, check the bootargs set in Setting the MetroCluster IP bootarg variables and correct any incorrect values. Only move to the next step after you have checked the bootarg values.

8. Double-check that the partner-sysid is the correct:

printenv partner-sysid

If the partner-sysid is not correct, set it:

```
setenv partner-sysid partner-sysID
```

9. If root encryption is used, select the boot menu option for your key management configuration.

If you are using	Select this boot menu option
Onboard key management	Option 10 and follow the prompts to provide the required inputs to recover or restore the key- manager configuration
External key management	Option 11 and follow the prompts to provide the required inputs to recover or restore the key- manager configuration

You need to perform the recovery procedure by selecting Option 10 or option 11 depending on the key manager setting and Option 6 at the boot menu prompt. To boot the nodes completely, you might need to perform the recovery procedure continued by option 1 (normal boot).

10. Wait for the new nodes, node_B_1-A900 and node_B_2-A900 to boot up.

If either node is in takeover mode, perform a giveback using the storage failover giveback command.

11. If encryption is used, restore the keys using the correct command for your key management configuration.

If you are using…	Use this command
Onboard key management	security key-manager onboard sync For more information, see Restoring onboard key management encryption keys.
External key management	<pre>security key-manager external restore -vserver SVM -node node -key-server host_name IP_address:port -key-id key_id -key-tag key_tag node-name For more information, see Restoring external key management encryption keys.</pre>

- 12. Verify that all ports are in a broadcast domain:
 - a. View the broadcast domains:

network port broadcast-domain show

b. Add any ports to a broadcast domain as needed.

Adding or removing ports from a broadcast domain

c. Recreate VLANs and interface groups as needed.

VLAN and interface group membership might be different than that of the old node.

Creating a VLAN

Verify and restore LIF configuration

Verify that LIFs are hosted on appropriate nodes and ports as mapped out at the beginning of the upgrade procedure.

About this task

- This task is performed on site_B.
- See the port mapping plan you created in Mapping ports from the old nodes to the new nodes.

Steps

- 1. Verify that LIFs are hosted on the appropriate node and ports prior to switchback.
 - a. Change to the advanced privilege level:

set -privilege advanced

b. Override the port configuration to ensure proper LIF placement:

```
vserver config override -command "network interface modify -vserver
vserver_name -home-port active_port_after_upgrade -lif lif_name -home-node
new_node_name"
```

When entering the network interface modify command within the vserver config override command, you cannot use the tab autocomplete feature. You can create the network interface modify using autocomplete and then enclose it in the vserver config override command.

c. Return to the admin privilege level:

set -privilege admin

2. Revert the interfaces to their home node:

network interface revert * -vserver vserver-name

Perform this step on all SVMs as required.

Switch back the MetroCluster configuration

In this task, you will perform the switchback operation, and the MetroCluster configuration returns to normal operation. The nodes on site_A are still awaiting upgrade.



Steps

- 1. Issue the metrocluster node show command from site_B and check the output.
 - a. Verify that the new nodes are represented correctly.
 - b. Verify that the new nodes are in "Waiting for switchback state."
- 2. Perform the healing and switchback by running the required commands from any node in the active cluster (the cluster that is not undergoing upgrade).
 - a. Heal the data aggregates: metrocluster heal aggregates
 - b. Heal the root aggregates:

metrocluster heal root

c. Switchback the cluster:

```
metrocluster switchback
```

3. Check the progress of the switchback operation:

```
metrocluster show
```

The switchback operation is still in progress when the output displays waiting-for-switchback:

cluster_B::> metrocluster Cluster	show Entry Name	State
Local: cluster_B Remote: cluster_A	Configuration state Mode AUSO Failure Domain Configuration state Mode AUSO Failure Domain	configured switchover - configured waiting-for-switchback -

The switchback operation is complete when the output displays normal:

```
cluster B::> metrocluster show
Cluster
                     Entry Name
                                 State
_____ _
                              _____
Local: cluster B
                     Configuration state configured
                     Mode
                                      normal
                     AUSO Failure Domain -
Remote: cluster A
                     Configuration state configured
                     Mode
                                     normal
                     AUSO Failure Domain -
```

If a switchback takes a long time to finish, you can check on the status of in-progress baselines by using the metrocluster config-replication resync-status show command. This command is at the advanced privilege level.

Check the health of the MetroCluster configuration

After upgrading the controller modules you must verify the health of the MetroCluster configuration.

About this task

This task can be performed on any node in the MetroCluster configuration.

Steps

1. Verify the operation of the MetroCluster configuration:

- a. Confirm the MetroCluster configuration and that the operational mode is normal: metrocluster show
- b. Perform a MetroCluster check: metrocluster check run
- c. Display the results of the MetroCluster check:

metrocluster check show

2. Verify the MetroCluster connectivity and status.

a. Check the MetroCluster IP connections:

storage iscsi-initiator show

b. Check that the nodes are operating:

metrocluster node show

c. Check that the MetroCluster IP interfaces are up:

metrocluster configuration-settings interface show

d. Check that local failover is enabled:

storage failover show

Upgrade the nodes on site_A

You must repeat the upgrade tasks on site_A.

Steps

1. Repeat the steps to upgrade the nodes on site_A, beginning with Prepare for the upgrade.

As you perform the tasks, all example references to the sites and nodes are reversed. For example, when the example is given to switchover from site_A, you will switchover from site_B.

Restore Tiebreaker or Mediator monitoring

After completing the upgrade of the MetroCluster configuration, you can resume monitoring with the Tiebreaker or Mediator utility.

Steps

1. Restore monitoring if necessary, using the procedure for your configuration.

If you are using	Use this procedure
Tiebreaker	Adding MetroCluster configurations in the <i>MetroCluster Tiebreaker Installation and Configuration</i> section.
Mediator	Configuring the ONTAP Mediator service from a MetroCluster IP configuration in the MetroCluster IP Installation and Configuration section.
Third-party applications	Refer to the product documentation.

Send a custom AutoSupport message after maintenance

After completing the upgrade, you should send an AutoSupport message indicating the end of maintenance, so automatic case creation can resume.

Steps

- 1. To resume automatic support case generation, send an Autosupport message to indicate that the maintenance is complete.
 - a. Issue the following command: system node autosupport invoke -node * -type all -message MAINT=end
 - b. Repeat the command on the partner cluster.

Refreshing a four-node MetroCluster FC configuration

You can upgrade the controllers and storage in a four-node MetroCluster configuration by expanding the configuration to become an eight-node configuration and then removing the old disaster recovery (DR) group.

About this task

References to "old nodes" mean the nodes that you intend to replace.

- You can only refresh specific platform models using this procedure in a MetroCluster FC configuration.
 - For information on what platform upgrade combinations are supported review the MetroCluster FC refresh table in Choosing a system refresh method.

Steps

1. Gather information from the old nodes.

At this stage, the four-node configuration appears as shown in the following image:



2. Perform all of the steps in the four-node expansion procedure for your MetroCluster type.

Expanding a four-node MetroCluster FC configuration to an eight-node configuration

When the expansion procedure is complete, the configuration appears as shown in the following image:



3. Move the CRS volumes.

Perform the steps in Move a metadata volume in MetroCluster configurations.

- 4. Move the data from the old nodes to new nodes using the following procedures:
 - a. Perform all the steps in Create an aggregate and moving volumes to the new nodes.



You might choose to mirror the aggregate when or after it is created.

- b. Perform all the steps in Move non-SAN data LIFs and cluster management LIFs to the new nodes.
- c. Perform all the steps in Delete SAN LIFs no longer required from the original nodes.
- 5. Follow the steps in the procedure for removing the old DR group.

Removing a Disaster Recovery group

After you have removed the old DR group (DR group one), the configuration appears as shown in the following image:



Refreshing a four-node or an eight-node MetroCluster IP configuration (ONTAP 9.8 and later)

You can use this procedure to upgrade controllers and storage in four-node or eight-node configurations.

Beginning with ONTAP 9.13.1, you can upgrade the controllers and storage in an eight-node MetroCluster IP configuration by expanding the configuration to become a temporary twelve-node configuration and then removing the old disaster recovery (DR) groups.

Beginning with ONTAP 9.8, you can upgrade the controllers and storage in a four-node MetroCluster IP configuration by expanding the configuration to become a temporary eight-node configuration and then removing the old DR group.

About this task

- If you have an eight-node configuration, your system must be running ONTAP 9.13.1 or later.
- If you have a four-node configuration, your system must be running ONTAP 9.8 or later.
- If you are also upgrading the IP switches, you must upgrade them before performing this refresh procedure.
- This procedure describes the steps required to refresh one four-node DR group. If you have an eight-node configuration (two DR groups) you can refresh one or both DR groups.

If you refresh both DR groups, you must refresh one DR group at a time.

- References to "old nodes" mean the nodes that you intend to replace.
- For eight-node configurations, the source and target eight-node MetroCluster platform combination must be supported.



If you refresh both DR groups, the platform combination might not be supported after you refresh the first DR group. You must refresh both DR groups to achieve a supported eight-node configuration.

- You can only refresh specific platform models using this procedure in a MetroCluster IP configuration.
 - For information on which platform upgrade combinations are supported, review the MetroCluster IP

refresh table in Choosing a system refresh method.

- The lower limits of the source and target platforms apply. If you transition to a higher platform, the limits of the new platform applies only after the tech refresh of all DR groups completes.
- If you perform a tech refresh to a platform with lower limits than the source platform, you must adjust and reduce the limits to be at, or below, the target platform limits before performing this procedure.

Steps

1. Verify that you have a default broadcast domain created on the old nodes.

When you add new nodes to an existing cluster without a default broadcast domain, node management LIFs are created for the new nodes using universal unique identifiers (UUIDs) instead of the expected names. For more information, see the Knowledge Base article Node management LIFs on newly-added nodes generated with UUID names.

2. Gather information from the old nodes.

At this stage, the four-node configuration appears as shown in the following image:



The eight-node configuration appears as shown in the following image:



- 3. To prevent automatic support case generation, send an AutoSupport message to indicate the upgrade is underway.
 - a. Issue the following command:

```
system node autosupport invoke -node * -type all -message "MAINT=10h
Upgrading old-model to new-model"
```

The following example specifies a 10 hour maintenance window. You might want to allow additional time depending on your plan.

If the maintenance is completed before the time has elapsed, you can invoke an AutoSupport message indicating the end of the maintenance period:

system node autosupport invoke -node * -type all -message MAINT=end

- b. Repeat the command on the partner cluster.
- 4. Remove the existing MetroCluster configuration from Tiebreaker, Mediator, or other software that can initiate switchover.

If you are using	Use this procedure
------------------	--------------------

Tiebreaker	 Use the Tiebreaker CLI monitor remove command to remove the MetroCluster configuration. In the following example, "cluster_A" is remove from the software: NetApp MetroCluster Tiebreaker :> monitor remove -monitor -name cluster_A Successfully removed monitor from NetApp MetroCluster Tiebreaker software. Confirm that the MetroCluster configuration is removed correctly by using the Tiebreaker CLI monitor show -status command. 	
	NetApp MetroCluster Tiebreaker :> monitor show -status	
Mediator	Issue the following command from the ONTAP prompt: metrocluster configuration-settings mediator remove	
Third-party applications	Refer to the product documentation.	

5. Perform all of the steps in Expanding a MetroCluster IP configuration to add the new nodes and storage to the configuration.

When the expansion procedure is complete, the temporary configuration appears as shown in the following images:



Figure 1. Temporary eight-node configuration



Figure 2. Temporary twelve-node configuration

6. Confirm that takeover is possible and the nodes are connected by running the following command on both clusters:

storage failover show

```
cluster A::> storage failover show
                                 Takeover
Node
                                 Possible
                                            State Description
              Partner
                     -----
                                            _____
      _____ __
                                   true
Node FC 1
             Node FC 2
                                            Connected to Node FC 2
Node FC 2
             Node FC 1
                                            Connected to Node FC 1
                                  true
Node IP 1
             Node IP 2
                                            Connected to Node IP 2
                                  true
                                            Connected to Node IP 1
Node IP 2
             Node IP 1
                                   true
```

7. Move the CRS volumes.

Perform the steps in Moving a metadata volume in MetroCluster configurations.

- 8. Move the data from the old nodes to the new nodes by using the following procedures:
 - a. Perform all the steps in Create an aggregate and move volumes to the new nodes.



You might choose to mirror the aggregate when or after it is created.

- b. Perform all the steps in Move non-SAN data LIFs and cluster-management LIFs to the new nodes.
- 9. Modify the IP address for the cluster peer of the transitioned nodes for each cluster:
 - a. Identify the cluster_A peer by using the cluster peer show command:

```
cluster_A::> cluster peer show
Peer Cluster Name Cluster Serial Number Availability
Authentication
------
cluster_B 1-80-00011 Unavailable absent
```

i. Modify the cluster_A peer IP address:

```
cluster peer modify -cluster cluster_A -peer-addrs node_A_3_IP -address
-family ipv4
```

b. Identify the cluster_B peer by using the cluster peer show command:

cluster_B::> cluster peer show
Peer Cluster Name Cluster Serial Number Availability
Authentication
----cluster_A 1-80-000011 Unavailable absent

i. Modify the cluster_B peer IP address:

```
cluster peer modify -cluster cluster_B -peer-addrs node_B_3_IP -address
-family ipv4
```

- c. Verify that the cluster peer IP address is updated for each cluster:
 - i. Verify that the IP address is updated for each cluster by using the cluster peer show -instance command.

The Remote Intercluster Addresses field in the following examples displays the updated IP address.

Example for cluster_A:

```
cluster A::> cluster peer show -instance
Peer Cluster Name: cluster B
           Remote Intercluster Addresses: 172.21.178.204,
172.21.178.212
      Availability of the Remote Cluster: Available
                     Remote Cluster Name: cluster B
                     Active IP Addresses: 172.21.178.212,
172.21.178.204
                   Cluster Serial Number: 1-80-000011
                    Remote Cluster Nodes: node B 3-IP,
                                          node B 4-IP
                   Remote Cluster Health: true
                 Unreachable Local Nodes: -
          Address Family of Relationship: ipv4
    Authentication Status Administrative: use-authentication
       Authentication Status Operational: ok
                        Last Update Time: 4/20/2023 18:23:53
            IPspace for the Relationship: Default
Proposed Setting for Encryption of Inter-Cluster Communication: -
Encryption Protocol For Inter-Cluster Communication: tls-psk
 Algorithm By Which the PSK Was Derived: jpake
cluster A::>
```

Example for cluster_B

cluster B::> cluster peer show -instance Peer Cluster Name: cluster A Remote Intercluster Addresses: 172.21.178.188, 172.21.178.196 <<<<<< Should reflect the modified address Availability of the Remote Cluster: Available Remote Cluster Name: cluster A Active IP Addresses: 172.21.178.196, 172.21.178.188 Cluster Serial Number: 1-80-000011 Remote Cluster Nodes: node A 3-IP, node A 4-IP Remote Cluster Health: true Unreachable Local Nodes: -Address Family of Relationship: ipv4 Authentication Status Administrative: use-authentication Authentication Status Operational: ok Last Update Time: 4/20/2023 18:23:53 IPspace for the Relationship: Default Proposed Setting for Encryption of Inter-Cluster Communication: -Encryption Protocol For Inter-Cluster Communication: tls-psk Algorithm By Which the PSK Was Derived: jpake cluster B::>

- 10. Follow the steps in Removing a Disaster Recovery group to remove the old DR group.
- 11. If you want to refresh both DR groups in an eight-node configuration, you must repeat the entire procedure for each DR group.

After you have removed the old DR group, the configuration appears as shown in the following images:



Figure 3. Four-node configuration



Figure 4. Eight-node configuration

- 12. Confirm the operational mode of the MetroCluster configuration and perform a MetroCluster check.
 - a. Confirm the MetroCluster configuration and that the operational mode is normal:

metrocluster show

b. Confirm that all expected nodes are shown:

metrocluster node show

c. Issue the following command:

metrocluster check run

d. Display the results of the MetroCluster check:

metrocluster check show

13. Restore monitoring if necessary, using the procedure for your configuration.

If you are using	Use this procedure
Tiebreaker	Adding MetroCluster configurations in the <i>MetroCluster Tiebreaker Installation and Configuration</i> .

Mediator	Configuring the ONTAP Mediator service from a MetroCluster IP configuration in the MetroCluster IP Installation and Configuration.
Third-party applications	Refer to the product documentation.

- 14. To resume automatic support case generation, send an Autosupport message to indicate that the maintenance is complete.
 - a. Issue the following command:

```
system node autosupport invoke -node * -type all -message MAINT=end
```

b. Repeat the command on the partner cluster.

Expand a two-node MetroCluster FC configuration to a fournode configuration

Expanding a two-node MetroCluster FC configuration to a four-node configuration

Expanding a two-node MetroCluster FC configuration to a four-node MetroCluster FC configuration involves adding a controller to each cluster to form an HA pair at each MetroCluster site, and then refreshing the MetroCluster FC configuration.

Before you begin

• The nodes must be running ONTAP 9 or later in a MetroCluster FC configuration.

This procedure is not supported on earlier versions of ONTAP or in MetroCluster IP configurations.

- If the platforms in your two-node configuration are not supported in ONTAP 9.2 and you plan to upgrade to platforms supported in ONTAP 9.2 *and* expand to a four-node cluster, you must upgrade the platforms in the two-node configuration *before* expanding the MetroCluster FC configuration.
- The existing MetroCluster FC configuration must be healthy.
- The equipment you are adding must be supported and meet all of the requirements described in the following procedures:

Fabric-attached MetroCluster installation and configuration

Stretch MetroCluster installation and configuration

- You must have available FC switch ports to accommodate the new controllers and any new bridges.
- Verify that you have a default broadcast domain created on the old nodes.

When you add new nodes to an existing cluster without a default broadcast domain, node management LIFs are created for the new nodes using universal unique identifiers (UUIDs) instead of the expected names. For more information, see the Knowledge Base article Node management LIFs on newly-added nodes generated with UUID names.

• You need the admin password and access to an FTP or SCP server.

About this task

- This procedure applies only to MetroCluster FC configurations.
- This procedure is disruptive and takes approximately four hours to complete.
- Before performing this procedure, the MetroCluster FC configuration consists of two single-node clusters:



After completing this procedure, the MetroCluster FC configuration consists of two HA pairs, one at each site:



• Both sites must be expanded equally.

A MetroCluster configuration cannot consist of an uneven number of nodes.

• This procedure can take over an hour per site, with additional time for tasks such as initializing the disks and netbooting the new nodes.

The time to initialize the disks depends on the size of the disks.

• This procedure uses the following workflow:



Verifying the state of the MetroCluster configuration

You should identify the existing controllers and confirm the disaster recovery (DR) relationships between them, that the controllers are in normal mode, and that the aggregates are mirrored.

Steps

1. Display the details of the nodes in the MetroCluster configuration from any node in the configuration:

```
metrocluster node show -fields node, dr-partner, dr-partner-systemid
```

The following output shows that this MetroCluster configuration has a single DR group and one node in each cluster.

```
cluster A::> metrocluster node show -fields node,dr-partner,dr-partner-
systemid
dr-group-id cluster node
                                      dr-partner dr-partner-
systemid
  _____
                                      _____
           _____
                         _____
_____
1
                        controller A 1 controller B 1 536946192
           cluster A
           cluster B
                        controller B 1 controller A 1 536946165
1
2 entries were displayed.
```

2. Display the state of the MetroCluster configuration:

The following output shows that the existing nodes in the MetroCluster configuration are in normal mode:

<pre>cluster_A::> metrocluster show</pre>		
Configuration: two-node-fabric		
Cluster	Entry Name	State
Local: cluster_A	Configuration State Mode	configured normal
disaster	AUSO Failure Domain	auso-on-cluster-
Remote: controller_B_1_siteB		
	Configuration State Mode	configured normal
disaster	AUSO Failure Domain	auso-on-cluster-

3. Check the state of the aggregates on each node in the MetroCluster configuration:

storage aggregate show

The following output shows that the aggregates on cluster_A are online and mirrored:

```
cluster A::> storage aggregate show
Aggregate
                Size Available Used% State #Vols Nodes
RAID Status
_____
                   -----
aggr0 controller A 1 0 1.38TB 68.63GB 95% online 1
controller A 1 raid dp,mirrored
controller_A_1_aggr1 4.15TB
                        4.14TB 0% online
                                              2
controller_A_1 raid_dp,mirrored
controller A 1 aggr2 4.15TB
                        4.14TB 0% online 1
controller A 1 raid dp, mirrored
3 entries were displayed.
cluster A::>
```

Sending a custom AutoSupport message before adding nodes to the MetroCluster configuration

You should issue an AutoSupport message to notify NetApp technical support that maintenance is underway. Informing technical support that maintenance is underway prevents them from opening a case on the assumption that a disruption has occurred.

About this task

This task must be performed on each MetroCluster site.

Steps

- 1. Log in to the cluster at Site_A.
- 2. Invoke an AutoSupport message indicating the start of the maintenance:

```
system node autosupport invoke -node * -type all -message MAINT=maintenance-
window-in-hours
```

The maintenance-window-in-hours parameter specifies the length of the maintenance window and can be a maximum of 72 hours. If you complete the maintenance before the time has elapsed, you can issue the following command to indicate that the maintenance period has ended:

system node autosupport invoke -node * -type all -message MAINT=end

3. Repeat this step on the partner site.

Zoning for the new controller ports when adding a controller module in a fabricattached MetroCluster configuration

The FC switch zoning must accommodate the new controller connections. If you used the NetApp-supplied reference configuration files (RCFs) to configure your switches, the zoning is preconfigured and you do not need to make any changes.

If you manually configured your FC switches, you must ensure that the zoning is correct for the initiator connections from the new controller modules. See the sections on zoning in Fabric-attached MetroCluster installation and configuration.

Add a new controller module to each cluster

Adding a new controller module to each cluster

You must add a new controller module to each site, creating an HA pair in each site. This is a multistep process involving both hardware and software changes that must be performed in the proper order at each site.

About this task

• The new controller module must be received from NetApp as part of the upgrade kit.

You should verify that PCIe cards in the new controller module are compatible and supported by the new controller module.

NetApp Hardware Universe

• Your system must have an empty slot available for the new controller module when upgrading to a singlechassis HA pair (an HA pair in which both controller modules reside in the same chassis).



This configuration is not supported on all systems. Platforms with single chassis configurations that are supported in ONTAP 9 are AFF A300, FAS8200, FAS8300, AFF A400, AFF80xx, FAS8020, FAS8060, FAS8080, and FAS9000.

• You must have rack space and cables for the new controller module when upgrading to a dual-chassis HA pair (an HA pair in which the controller modules reside in separate chassis).



This configuration is not supported on all systems.

- You must connect each controller module to the management network through its e0a port or, if your system has one, you can connect to the e0M port as the management port.
- These tasks must be repeated at each site.
- The preexisting controller modules are referred to as the *existing* controller modules.

The examples in this procedure have the console prompt existing_ctlr>.

- The controller modules that are being added are referred to as the *new* controller modules; the examples in this procedure have the console prompt new ctlr>.
- This task uses the following workflow:



Preparing for the upgrade

Before upgrading to an HA pair, you must verify that your system meets all requirements and that you have all of the necessary information.

Steps

1. Identify unassigned disks or spare disks that you can assign to the new controller module using the following commands:

° storage disk show -container-type spare

- ° storage disk show -container-type unassigned
- 2. Complete the following substeps:
 - a. Determine where the aggregates for the existing node are located:

storage aggregate show

b. If disk ownership automatic assignment is on, turn it off:

storage disk option modify -node node_name -autoassign off

c. Remove ownership on disks that do not have aggregates on them:

storage disk removeowner disk name

- d. Repeat the previous step for as many disks as you need for the new node.
- 3. Verify that you have cables ready for the following connections:
 - Cluster connections

If you are creating a two-node switchless cluster, you require two cables to connect the controller modules. Otherwise, you require a minimum of four cables, two for each controller module connection to the cluster-network switch. Other systems (like the 80xx series) have defaults of either four or six cluster connections.

- · HA interconnect connections, if the system is in a dual-chassis HA pair
- 4. Verify that you have a serial port console available for the controller modules.
- 5. Verify that your environment meets the site and system requirements.

NetApp Hardware Universe

6. Gather all of the IP addresses and other network parameters for the new controller module.

Clearing the configuration on a controller module

Before using a new controller module in the MetroCluster configuration, you must clear the existing configuration.

Steps

1. If necessary, halt the node to display the LOADER prompt:

halt

2. At the LOADER prompt, set the environmental variables to default values:

set-defaults

3. Save the environment:

saveenv

4. At the LOADER prompt, launch the boot menu:

boot_ontap menu

5. At the boot menu prompt, clear the configuration:

wipeconfig

Respond yes to the confirmation prompt.

The node reboots and the boot menu is displayed again.

6. At the boot menu, select option **5** to boot the system into Maintenance mode.

Respond yes to the confirmation prompt.

Preparing cluster ports on an existing controller module

Before installing a new controller module, you must configure cluster ports on the existing controller module so that the cluster ports can provide cluster communication with the new controller module.

About this task

If you are creating a two-node switchless cluster (with no cluster network switches), you must enable the switchless cluster networking mode.

For detailed information about port, LIF, and network configuration in ONTAP, see Network Management.

Steps

1. Determine which ports should be used as the node's cluster ports.

For a list of the default port roles for your platform, see the Hardware Universe

The *Installation and Setup Instructions* for your platform on the NetApp Support Site contains information about the ports for cluster network connections.

2. For each cluster port, identify the port roles:

network port show

In the following example, ports "e0a", "e0b", "e0c", and "e0d" must be changed to cluster ports:

cluster_A::> network port show											
Node: controller_A_1 Speed(Mbps) Health											
Port	IPspace	Broadcast Domain	Link	MTU	Admin/Oper	Status					
eOM	Default	mgmt_bd_1500	up	1500	auto/1000	healthy					
e0a	Default	Default	up	1500	auto/10000	healthy					
e0b	Default	Default	up	1500	auto/10000	healthy					
eOc	Default	Default	up	1500	auto/10000	healthy					
e0d	Default	Default	up	1500	auto/10000	healthy					
eOi	Default	Default	down	1500	auto/10	-					
eOj	Default	Default	down	1500	auto/10	-					
e0k	Default	Default	down	1500	auto/10	-					
e0l	Default	Default	down	1500	auto/10	-					
e2a	Default	Default	up	1500	auto/10000	healthy					
e2b	Default	Default	up	1500	auto/10000	healthy					
e4a	Default	Default	up	1500	auto/10000	healthy					
e4b	Default	Default	up	1500	auto/10000	healthy					
13 entries were displayed.											

For any data LIF that is using a cluster port as the home-port or current-port, modify the LIF to use a data port as its home-port:

network interface modify

The following example changes the home port of a data LIF to a data port:

```
cluster1::> network interface modify -lif datalif1 -vserver vs1 -home
-port elb
```

4. For each LIF that you modified, revert the LIF to its new home port:

```
network interface revert
```

The following example reverts the LIF "datalif1" to its new home port "e1b":

cluster1::> network interface revert -lif datalif1 -vserver vs1

- 5. Remove any VLAN ports using cluster ports as member ports and ifgrps using cluster ports as member ports.
 - a. Delete VLAN ports: network port vlan delete -node *node-name* -vlan-name *portid-vlandid*

For example:

network port vlan delete -node node1 -vlan-name e1c-80

b. Remove physical ports from the interface groups:

```
network port ifgrp remove-port -node node-name -ifgrp interface-group-name
-port portid
```

For example:

network port ifgrp remove-port -node nodel -ifgrp ala -port e0d

c. Remove VLAN and interface group ports from broadcast domain::

network port broadcast-domain remove-ports -ipspace ipspace -broadcast -domain broadcast-domain-name -ports nodename:portname,nodename:portname,..

- d. Modify interface group ports to use other physical ports as member as needed.: ifgrp add-port -node node-name -ifgrp interface-group-name -port port-id
- 6. Verify that the port roles have changed:

network port show

The following example shows that ports "e0a", "e0b", "e0c", and "e0d" are now cluster ports:

Node: controller_A_1 Speed(Mbps) Health										
Port	IPspace	Broadcast Domain	Link	MTU	Admin/Oper	Status				
eOM	Default	mgmt_bd_1500	up	1500	auto/1000	healthy				
e0a	Cluster	Cluster	up	9000	auto/10000	healthy				
e0b	Cluster	Cluster	up	9000	auto/10000	healthy				
eOc	Cluster	Cluster	up	9000	auto/10000	healthy				
e0d	Cluster	Cluster	up	9000	auto/10000	healthy				
eOi	Default	Default	down	1500	auto/10 -					
eOj	Default	Default	down	1500	auto/10 -					
e0k	Default	Default	down	1500	auto/10 -					
e0l	Default	Default	down	1500	auto/10 -					
e2a	Default	Default	up	1500	auto/10000	healthy				
e2b	Default	Default	up	1500	auto/10000	healthy				
e4a	Default	Default	up	1500	auto/10000	healthy				
e4b	Default	Default	up	1500	auto/10000	healthy				
13 entrie	es were displa	ayed.								
7. Add the ports to the cluster broadcast domain:

```
broadcast-domain add-ports -ipspace Cluster -broadcast-domain Cluster -ports
port-id, port-id..
```

For example:

```
broadcast-domain add-ports -ipspace Cluster -broadcast-domain Cluster
-ports cluster1-01:e0a
```

8. If your system is part of a switched cluster, create cluster LIFs on the cluster ports: network interface create

The following example creates a cluster LIF on one of the node's cluster ports. The -auto parameter configures the LIF to use a link-local IP address.

cluster1::> network interface create -vserver Cluster -lif clus1 -role cluster -home-node node0 -home-port ela -auto true

- 9. If you are creating a two-node switchless cluster, enable the switchless cluster networking mode:
 - a. Change to the advanced privilege level from either node:

set -privilege advanced

You can respond y when prompted whether you want to continue into advanced mode. The advanced mode prompt appears (*>).

b. Enable the switchless cluster networking mode:

```
network options switchless-cluster modify -enabled true
```

c. Return to the admin privilege level:

set -privilege admin



Cluster interface creation for the existing node in a two-node switchless cluster system is completed after cluster setup is completed through a netboot on the new controller module.

Preparing the netboot server to download the image

When you are ready to prepare the netboot server, you must download the correct ONTAP netboot image from the NetApp Support Site to the netboot server and note the IP address.

About this task

• You must be able to access an HTTP server from the system before and after adding the new controller module.

• You must have access to the NetApp Support Site to download the necessary system files for your platform and your version of ONTAP.

NetApp Support Site

• Both controller modules in the HA pair must run the same version of ONTAP.

Steps

1. Download the appropriate ONTAP software from the software download section of the NetApp Support Site and store the <ontap_version>_image.tgz file on a web-accessible directory.

The <ontap version> image.tgz file is used for performing a netboot of your system.

2. Change to the web-accessible directory and verify that the files you need are available.

For	Then		
FAS2200, FAS2500, FAS3200, FAS6200, FAS/AFF8000 series systems	Extract the contents of the <ontap_version>_image.tgz file to the target directory: tar -zxvf <ontap_version>_image.tgz</ontap_version></ontap_version>		
	i If you are extracting the contents on Windows, use 7-Zip or WinRAR to extract the netboot image.		
	Your directory listing should contain a netboot folder with a kernel file:		
	netboot/kernel		
All other systems	Your directory listing should contain the following file:		
	<ontap_version>_image.tgz</ontap_version>		
	There is no need to extract the file contents.		

3. Determine the IP address of the existing controller module.

This address is referred to later in this procedure as *ip-address-of-existing* controller.

4. Ping *ip-address-of-existing controller* to verify that the IP address is reachable.

Setting the HA mode on the existing controller module

You must use the storage failover modify command to set the mode on the existing controller module. The mode value is enabled later, after you reboot the controller module.

Steps

1. Set the mode to HA:

storage failover modify -mode ha -node existing_node_name

Shutting down the existing controller module

You must perform a clean shutdown of the existing controller module to verify that all of the data has been written to disk. You must also disconnect the power supplies.

About this task



You must perform a clean system shutdown before replacing the system components to avoid losing unwritten data in the NVRAM or NVMEM.

Steps

1. Halt the node from the existing controller module prompt:

```
halt local -inhibit-takeover true
```

If you are prompted to continue the halt procedure, enter $_{\rm Y}$ when prompted, and then wait until the system stops at the LOADER prompt.

In an 80xx system, the NVRAM LED is located on the controller module to the right of the network ports, marked with a battery symbol.

This LED blinks if there is unwritten data in the NVRAM. If this LED is flashing amber after you enter the halt command, you need to reboot your system and try halting it again.

- 2. If you are not already grounded, properly ground yourself.
- 3. Turn off the power supplies and disconnect the power, using the correct method for your system and power-supply type:

If your system uses	Then		
AC power supplies	Unplug the power cords from the power source, and then remove the power cords.		
DC power supplies	Remove the power at the DC source, and then remove the DC wires, if necessary.		

Install and cable the new controller module

Installing and cabling the new controller module

You must physically install the new controller module in the chassis, and then cable it.

Steps

1. If you have an I/O expansion module (IOXM) in your system and are creating a single-chassis HA pair, you must uncable and remove the IOXM.

You can then use the empty bay for the new controller module. However, the new configuration will not have the extra I/O provided by the IOXM.

2. Physically install the new controller module and, if necessary, install additional fans:

If you are adding a controller module	Then perform these steps			
To an empty bay to create a single-chassis HA pair and the system belongs to one of the following platforms:	a. Remove the blank plate in the rear of the chassis that covers the empty bay that will contain the new controller module.			
	b. Gently push the controller module halfway into the chassis.			
	To prevent the controller module from automatically booting, do not fully seat it in the chassis until later in this procedure.			
In a separate chassis from its HA partner to create a dual-chassis HA pair when the existing configuration is in a controller-IOX module configuration.	Install the new system in the rack or system cabinet.			
• FAS8200				
• 80xx				

- 3. Cable the cluster network connections, as necessary:
 - a. Identify the ports on the controller module for the cluster connections.
 - AFF A320 systems: Installation and setup
 - AFF A220/FAS2700 Systems Installation and Setup Instructions
 - AFF A800 Systems Installation and Setup Instructions
 - AFF A300 Systems Installation and Setup Instructions
 - FAS8200 Systems Installation and Setup Instructions
 - b. If you are configuring a switched cluster, identify the ports that you will use on the cluster network switches.

See the Clustered Data ONTAP Switch Setup Guide for Cisco Switches, ^NetApp 10G Cluster-Mode Switch Installation Guide or NetApp 1G Cluster-Mode Switch Installation Guide, depending on what switches you are using.

c. Connect cables to the cluster ports:

If the cluster is	Then
-------------------	------

A two-node switchless cluster	Directly connect the cluster ports on the existing controller module to the corresponding cluster ports on the new controller module.
A switched cluster	Connect the cluster ports on each controller to the ports on the cluster network switches identified in Substep b.

Cabling the new controller module's FC-VI and HBA ports to the FC switches

The new controller module's FC-VI ports and HBAs (host bus adapters) must be cabled to the site FC switches.

Steps

1. Cable the FC-VI ports and HBA ports, using the table for your configuration and switch model.

- $\circ\,$ Port assignments for FC switches when using ONTAP 9.1 and later
- Port assignments for FC switches when using ONTAP 9.0
- Port assignments for systems using two initiator ports

Cabling the new controller module's cluster peering connections

You must cable the new controller module to the cluster peering network so that it has connectivity with the cluster on the partner site.

About this task

At least two ports on each controller module should be used for cluster peering.

The recommended minimum bandwidth for the ports and network connectivity is 1 GbE.

Steps

1. Identify and cable at least two ports for cluster peering and verify they have network connectivity with the partner cluster.

Powering up both controller modules and displaying the LOADER prompt

You power up the existing controller module and the new controller module to display the LOADER prompt.

Steps

Power up the controller modules and interrupt the boot process, using the steps for your configuration:

If the controller modules	Then
are	

In the same chassis	a. Verify that the new controller module is not fully inserted into the bay.			
	The existing controller module should be fully inserted into the bay because i was never removed from the chassis, but the new controller module should not be.			
	 b. Connect the power and turn on the power supplies so that the existing controller module receives power. 			
	c. Interrupt the boot process on the existing controller module by pressing Ctrl- C.			
	d. Push the new controller module firmly into the bay.			
	When fully seated, the new controller module receives power and automatically boots.			
	e. Interrupt the boot process by pressing Ctrl-C.			
	f. Tighten the thumbscrew on the cam handle, if present.			
	g. Install the cable management device, if present.			
	 h. Bind the cables to the cable management device with the hook and loop strap. 			
In separate chassis	a. Turn on the power supplies on the existing controller module.			
	b. Interrupt the boot process by pressing Ctrl-C.			
	c. Repeat these steps for the new controller module			

Each controller module should display the LOADER prompt (LOADER>, LOADER-A>, or LOADER-B>).



If there is no LOADER prompt, record the error message. If the system displays the boot menu, reboot and attempt to interrupt the boot process again.

Changing the ha-config setting on the existing and new controller modules

When you expand a MetroCluster configuration, you must update the ha-config setting of the existing controller module and the new controller module. You must also determine the system ID of the new controller module.

About this task

This task is performed in Maintenance mode on both the existing and new controller modules.

Steps

- 1. Change the ha-config setting of the existing controller module:
 - a. Display the ha-config setting of the existing controller module and chassis:

ha-config show

The ha-config setting is "mcc-2n" for all components because the controller module was in a two-node MetroCluster configuration.

- b. Change the ha-config setting of the existing controller module to "mcc": ha-config modify controller mcc
- c. Change the ha-config setting of the existing chassis to "mcc":

ha-config modify chassis mcc

d. Retrieve the system ID for the existing controller module:

sysconfig

Note the system ID. You need it when you set the partner ID on the new controller module.

e. Exit Maintenance mode to return to the LOADER prompt:

halt

- 2. Change the ha-config setting and retrieve the system ID of the new controller module:
 - a. If the new controller module is not already in Maintenance mode, boot it to Maintenance mode:

boot_ontap maint

b. Change the ha-config setting of the new controller module to "mcc":

ha-config modify controller mcc

c. Change the ha-config setting of the new chassis to mcc:

ha-config modify chassis mcc

d. Retrieve the system ID for the new controller module:

sysconfig

Note the system ID. You need it when you set the partner ID and assign disks to the new controller module.

e. Exit Maintenance mode to return to the LOADER prompt:

halt

Setting the partner system ID for both controller modules

You must set the partner system ID on both controller modules so that they can form an HA pair.

About this task

This task is performed with both controller modules at the LOADER prompt.

Steps

1. On the existing controller module, set the partner system ID to that of the new controller module:

```
setenv partner-sysid sysID_of_new_controller
```

2. On the new controller module, set the partner system ID to that of the existing controller module:

setenv partner-sysid sysID_of_existing_controller

Booting the existing controller module

You must boot the existing controller module to ONTAP.

Steps

1. At the LOADER prompt, boot the existing controller module to ONTAP:

boot_ontap

Assigning disks to the new controller module

Before you complete the configuration of the new controller module through netboot, you must assign disks to it.

About this task

You must have made sure that there are enough spares, unassigned disks, or assigned disks that are not part of an existing aggregate.

Preparing for the upgrade

These steps are performed on the existing controller module.

Steps

1. Assign the root disk to the new controller module:

storage disk assign -disk disk name -sysid new controller sysID -force true

If your platform model uses the Advanced Drive Partitioning (ADP) feature, you must include the -root true parameter:

```
storage disk assign -disk disk_name -root true -sysid new_controller_sysID
-force true
```

2. Assign the remaining required disks to the new controller module by entering the following command for each disk:

storage disk assign -disk disk_name -sysid new_controller_sysID -force true

3. Verify that the disk assignments are correct:

storage disk show -partitionownership*



Ensure that you have assigned all disks that you intend to assign to the new node.

Netbooting and setting up ONTAP on the new controller module

You must perform a specific sequence of steps to netboot and install the ONTAP operating system on the new controller module when adding controller modules to an existing MetroCluster configuration.

About this task

- This task starts at the LOADER prompt of the new controller module.
- This task includes initializing disks.

The amount of time you need to initialize the disks depends on the size of the disks.

• The system automatically assigns two disks to the new controller module.

Disk and aggregate management

Steps

1. At the LOADER prompt, configure the IP address of the new controller module based on DHCP availability:

If DHCP is	Then enter the following command					
Available	ifconfig eOM -auto					
Not available	ifconfig eOM -addr=filer_addr -mask=netmask -gw=gateway -dns=dns_addr -domain=dns_domain					
	filer_addr is the IP address of the storage system.					
	netmask is the network mask of the storage system.					
	<i>gateway</i> is the gateway for the storage system. <i>dns_addr</i> is the IP address of a name server on your network.					
	<i>dns_domain</i> is the Domain Name System (DNS) domain name. If you use this optional parameter, you do not need a fully qualified domain name in the netboot server URL; you need only the server's host name.					
	Other parameters might be necessary for your interface. For details, use the help ifconfig command at the LOADER prompt.					

2. At the LOADER prompt, netboot the new node:

For	Issue this command
-----	--------------------

FAS2200, FAS2500, FAS3200, FAS6200, FAS/AFF8000 series systems	<pre>netboot http://web_server_ip/path_to_web- accessible_directory/netboot/kernel</pre>
All other systems	<pre>netboot \http://web_server_ip/path_to_web- accessible_directory/<ontap_version>_image.tgz</ontap_version></pre>

The <code>path_to_the_web-accessible_directory</code> is the location of the downloaded <code><ontap_version>_image.tgz</code> file.

3. Select the Install new software first option from the displayed menu.

This menu option downloads and installs the new ONTAP image to the boot device.

- You should enter "y" when prompted with the message that this procedure is not supported for nondisruptive upgrade on an HA pair.
- You should enter "y" when warned that this process replaces the existing ONTAP software with new software.
- You should enter the path as follows when prompted for the URL of the image.tgz file:

http://path to the web-accessible directory/image.tgz

- 4. Enter "y" when prompted regarding nondisruptive upgrade or replacement of the software.
- 5. Enter the path to the image.tgz file when prompted for the URL of the package.

```
What is the URL for the package? `http://path_to_web-
accessible_directory/image.tgz`
```

6. Enter "n" to skip the backup recovery when prompted to restore the backup configuration.

```
*
          Restore Backup Configuration
                                                *
 This procedure only applies to storage controllers that
*
  are configured as an HA pair.
*
*
  Choose Yes to restore the "varfs" backup configuration
*
 from the SSH server. Refer to the Boot Device Replacement
*
                                                *
* guide for more details.
* Choose No to skip the backup recovery and return to the
                                                *
* boot menu.
Do you want to restore the backup configuration
now? {y|n} `n`
```

7. Enter "y" when prompted to reboot now.

```
The node must be rebooted to start using the newly installed software. Do you want to reboot now? {y|n} `y`
```

8. If necessary, select the option to Clean configuration and initialize all disks after the node has booted.

Because you are configuring a new controller module and the new controller module's disks are empty, you can respond "y" when the system warns you that this will erase all disks.



The amount of time needed to initialize disks depends on the size of your disks and configuration.

9. After the disks are initialized and the Cluster Setup wizard starts, set up the node:

Enter the node management LIF information on the console.

10. Log in to the node, and enter the cluster setup and then enter "join" when prompted to join the cluster.

```
Do you want to create a new cluster or join an existing cluster? {create, join}: `join`
```

11. Respond to the remaining prompts as appropriate for your site.

The Setup ONTAP for your version of ONTAP contains additional details.

12. If the system is in a two-node switchless cluster configuration, create the cluster interfaces on the existing node using the network interface create command to create cluster LIFs on the cluster ports.

The following is an example command for creating a cluster LIF on one of the node's cluster ports. The -auto parameter configures the LIF to use a link-local IP address.

cluster_A::> network interface create -vserver Cluster -lif clus1 -role cluster -home-node node_A_1 -home-port ela -auto true

13. After setup is complete, verify that the node is healthy and eligible to participate in the cluster:

cluster show

The following example shows a cluster after the second node (cluster1-02) has been joined to it:

cluster_A::> cluster	show	
Node	Health	Eligibility
node_A_1	true	true
node_A_2	true	true

You can access the Cluster Setup wizard to change any of the values you entered for the admin storage virtual machine (SVM) or node SVM by using the cluster setup command.

14. Confirm that you have four ports configured as cluster interconnects:

network port show

The following example shows output for two controller modules in cluster_A:

cluster_A::> network port show						
						Speed
(Mode) Node	Port	TPspace	Broadcast Domain	Link M	ͲIJ	Admin/Oper
node_A	_1					
	**e0a	Cluster	Cluster	up	900	00
auto/1	000					
	e0b	Cluster	Cluster	up	9000	
auto/1	000**					
	eOc	Default	Default	up	1500	auto/1000
	e0d	Default	Default	up	1500	auto/1000
	e0e	Default	Default	up	1500	auto/1000
	eOf	Default	Default	up	1500	auto/1000
	eOg	Default	Default	up	1500	auto/1000
node_A_2						
	**e0a	Cluster	Cluster	up	900	00
auto/1	000					
	e0b	Cluster	Cluster	up	9000	
auto/1	000**					
	e0c	Default	Default	up	1500	auto/1000
	e0d	Default	Default	up	1500	auto/1000
	e0e	Default	Default	up	1500	auto/1000
	eOf	Default	Default	up	1500	auto/1000
	eOg	Default	Default	up	1500	auto/1000
14 entries were displayed.						

Mirroring the root aggregate on the new controller

You must mirror the root aggregate to provide data protection when you are adding a controller to a MetroCluster configuration.

This task must be performed on the new controller module.

1. Mirror the root aggregate:

storage aggregate mirror aggr_name

The following command mirrors the root aggregate for controller_A_1:

controller_A_1::> storage aggregate mirror aggr0_controller_A_1

This mirrors the aggregate, so it consists of a local plex and a remote plex located at the remote MetroCluster site.

Configure intercluster LIFs

Configuring intercluster LIFs on dedicated ports

You can configure intercluster LIFs on dedicated ports. Doing so typically increases the available bandwidth for replication traffic.

Steps

1. List the ports in the cluster:

network port show

For complete command syntax, see the man page.

The following example shows the network ports in cluster01:

cluster01::> network port show						
						Speed
(Mbps)						
Node	Port	IPspace	Broadcast Domain	Link	MTU	Admin/Oper
cluste	r01-01					
	e0a	Cluster	Cluster	up	1500	auto/1000
	e0b	Cluster	Cluster	up	1500	auto/1000
	eOc	Default	Default	up	1500	auto/1000
	e0d	Default	Default	up	1500	auto/1000
	e0e	Default	Default	up	1500	auto/1000
	eOf	Default	Default	up	1500	auto/1000
cluste	r01-02					
	e0a	Cluster	Cluster	up	1500	auto/1000
	e0b	Cluster	Cluster	up	1500	auto/1000
	eOc	Default	Default	up	1500	auto/1000
	e0d	Default	Default	up	1500	auto/1000
	e0e	Default	Default	up	1500	auto/1000
	eOf	Default	Default	up	1500	auto/1000

2. Determine which ports are available to dedicate to intercluster communication:

network interface show -fields home-port, curr-port

For complete command syntax, see the man page.

The following example shows that ports "e0e" and "e0f" have not been assigned LIFs:

```
cluster01::> network interface show -fields home-port,curr-port
vserver lif
                        home-port curr-port
----- ------
Cluster cluster01-01 clus1 e0a
                               e0a
Cluster cluster01-01 clus2 e0b
                               e0b
Cluster cluster01-02 clus1 e0a
                                e0a
Cluster cluster01-02 clus2 e0b
                               e0b
cluster01
      cluster mgmt
                       e0c e0c
cluster01
      cluster01-01_mgmt1 e0c
                                e0c
cluster01
                        e0c
      cluster01-02 mgmt1
                                e0c
```

3. Create a failover group for the dedicated ports:

network interface failover-groups create -vserver system_SVM -failover-group failover_group -targets physical_or_logical_ports

The following example assigns ports "e0e" and "e0f" to the failover group "intercluster01" on the system SVM "cluster01":

```
cluster01::> network interface failover-groups create -vserver cluster01
-failover-group
intercluster01 -targets
cluster01-01:e0e,cluster01-01:e0f,cluster01-02:e0e,cluster01-02:e0f
```

4. Verify that the failover group was created:

network interface failover-groups show

For complete command syntax, see the man page.

```
cluster01::> network interface failover-groups show
                              Failover
Vserver
              Group
                              Targets
-----
 _____
Cluster
               Cluster
                              cluster01-01:e0a, cluster01-01:e0b,
                              cluster01-02:e0a, cluster01-02:e0b
cluster01
               Default
                              cluster01-01:e0c, cluster01-01:e0d,
                              cluster01-02:e0c, cluster01-02:e0d,
                              cluster01-01:e0e, cluster01-01:e0f
                              cluster01-02:e0e, cluster01-02:e0f
               intercluster01
                              cluster01-01:e0e, cluster01-01:e0f
                              cluster01-02:e0e, cluster01-02:e0f
```

5. Create intercluster LIFs on the system SVM and assign them to the failover group.

ONTAP version	Command
9.6 and later	<pre>network interface create -vserver system_SVM -lif LIF_name -service-policy default-intercluster -home-node node -home -port port -address port_IP -netmask netmask -failover -group failover_group</pre>

9.5 and earlier	network interface create -vserver system_SVM -lif LIF_name
	-role intercluster -home-node node -home-port port
	-address port_IP -netmask netmask -failover-group
	failover_group

For complete command syntax, see the man page.

The following example creates intercluster LIFs "cluster01_icl01" and "cluster01_icl02" in the failover group "intercluster01":

```
cluster01::> network interface create -vserver cluster01 -lif
cluster01_icl01 -service-
policy default-intercluster -home-node cluster01-01 -home-port e0e
-address 192.168.1.201
-netmask 255.255.255.0 -failover-group intercluster01
cluster01::> network interface create -vserver cluster01 -lif
cluster01_icl02 -service-
policy default-intercluster -home-node cluster01-02 -home-port e0e
-address 192.168.1.202
-netmask 255.255.255.0 -failover-group intercluster01
```

6. Verify that the intercluster LIFs were created:

In ONTAP 9.6 and later:

network interface show -service-policy default-intercluster

In ONTAP 9.5 and earlier:

```
network interface show -role intercluster
```

For complete command syntax, see the man page.

cluster01::> network interface show -service-policy default-intercluster Logical Status Network Current Current Is Interface Admin/Oper Address/Mask Node Port Vserver Home _____ ____ _____ ____ cluster01 cluster01 icl01 up/up 192.168.1.201/24 cluster01-01 e0e true cluster01 icl02 up/up 192.168.1.202/24 cluster01-02 eOf true

7. Verify that the intercluster LIFs are redundant:

In ONTAP	9.6 and later:
network	interface show -service-policy default-intercluster -failover
In ONTAP	9.5 and earlier:

For complete command syntax, see the man page.

The following example shows that the intercluster LIFs "cluster01_icl01" and "cluster01_icl02" on the SVM "e0e" port will fail over to the "e0f" port.

cluster0 -failove	1::> network int r	erface show -service-p	olicy default-in	tercluster
	Logical	Home	Failover	Failover
Vserver	Interface	Node:Port	Policy	Group
cluster0	1			
	cluster01_icl01	cluster01-01:e0e lo	cal-only	
interclu	ster01			
		Failover Targets:	cluster01-01:e0	e, f
interclu	cluster01_icl02 ster01	cluster01-02:e0e lo	cal-only	
		Failover Targets:	cluster01-02:e0 cluster01-02:e0	e, f

You can configure intercluster LIFs on ports shared with the data network. Doing so reduces the number of ports you need for intercluster networking.

Steps

1. List the ports in the cluster:

network port show

For complete command syntax, see the man page.

The following example shows the network ports in cluster01:

cluste:	cluster01::> network port show						
						Speed	
(Mbps)							
Node	Port	IPspace	Broadcast Domain	Link	MTU	Admin/Oper	
cluste	r01-01						
	e0a	Cluster	Cluster	up	1500	auto/1000	
	e0b	Cluster	Cluster	up	1500	auto/1000	
	eOc	Default	Default	up	1500	auto/1000	
	e0d	Default	Default	up	1500	auto/1000	
cluste	r01-02						
	e0a	Cluster	Cluster	up	1500	auto/1000	
	e0b	Cluster	Cluster	up	1500	auto/1000	
	eOc	Default	Default	up	1500	auto/1000	
	e0d	Default	Default	up	1500	auto/1000	

2. Create intercluster LIFs on the system SVM:

In ONTAP 9.6 and later:

```
network interface create -vserver system_SVM -lif LIF_name -service-policy
default-intercluster -home-node node -home-port port -address port_IP -netmask
netmask
```

In ONTAP 9.5 and earlier:

```
network interface create -vserver system_SVM -lif LIF_name -role intercluster
-home-node node -home-port port -address port_IP -netmask netmask
```

For complete command syntax, see the man page.

The following example creates intercluster LIFs cluster01_icl01 and cluster01_icl02:

```
cluster01::> network interface create -vserver cluster01 -lif
cluster01_icl01 -service-
policy default-intercluster -home-node cluster01-01 -home-port e0c
-address 192.168.1.201
-netmask 255.255.255.0
cluster01::> network interface create -vserver cluster01 -lif
cluster01_icl02 -service-
policy default-intercluster -home-node cluster01-02 -home-port e0c
-address 192.168.1.202
-netmask 255.255.255.0
```

3. Verify that the intercluster LIFs were created:

In ONTAP 9.6 and later:

network interface show -service-policy default-intercluster

In ONTAP 9.5 and earlier:

```
network interface show -role intercluster
```

For complete command syntax, see the man page.

4. Verify that the intercluster LIFs are redundant:

In ONTAP 9.6 and later:

network interface show -service-policy default-intercluster -failover

network interface show -role intercluster -failover

For complete command syntax, see the man page.

In ONTAP 9.5 and earlier:

The following example shows that the intercluster LIFs "cluster01_icl01" and "cluster01_icl02" on the "e0c" port will fail over to the "e0d" port.

```
cluster01::> network interface show -service-policy default-intercluster
-failover
       Logical
                    Home
                                       Failover
                                                    Failover
Vserver Interface
                   Node:Port
                                      Policy
                                                    Group
_____ _ ____
cluster01
       cluster01 icl01 cluster01-01:e0c local-only
192.168.1.201/24
                       Failover Targets: cluster01-01:e0c,
                                      cluster01-01:e0d
       cluster01 icl02 cluster01-02:e0c local-only
192.168.1.201/24
                       Failover Targets: cluster01-02:e0c,
                                      cluster01-02:e0d
```

Creating a mirrored data aggregate on each node

You must create a mirrored data aggregate on each node in the DR group.

About this task

- You should know what drives will be used in the new aggregate.
- If you have multiple drive types in your system (heterogeneous storage), you should understand how you can ensure that the correct drive type is selected.
- Drives are owned by a specific node; when you create an aggregate, all drives in that aggregate must be owned by the same node, which becomes the home node for that aggregate.

In systems using ADP, aggregates are created using partitions in which each drive is partitioned in to P1, P2 and P3 partitions.

• Aggregate names should conform to the naming scheme you determined when you planned your MetroCluster configuration.

Disk and aggregate management

It's recommended you maintain at least 20% free space for mirrored aggregates for optimal storage performance and availability. Although the recommendation is 10% for non-mirrored aggregates, the additional 10% of space may be used by the filesystem to absorb incremental changes. Incremental changes increase space utilization for mirrored aggregates due to ONTAP's copy-on-write Snapshot-based architecture. Failure to adhere to these best practices may have a negative impact on performance.

Steps

(i)

1. Display a list of available spares:

storage disk show -spare -owner node name

2. Create the aggregate:

storage aggregate create -mirror true

If you are logged in to the cluster on the cluster management interface, you can create an aggregate on any node in the cluster. To ensure that the aggregate is created on a specific node, use the -node parameter or specify drives that are owned by that node.

You can specify the following options:

- Aggregate's home node (that is, the node that owns the aggregate in normal operation)
- · List of specific drives that are to be added to the aggregate
- Number of drives to include



In the minimum supported configuration, in which a limited number of drives are available, you must use the force-small-aggregate option to allow the creation of a three disk RAID-DP aggregate.

- · Checksum style to use for the aggregate
- Type of drives to use
- Size of drives to use
- Drive speed to use
- RAID type for RAID groups on the aggregate
- Maximum number of drives that can be included in a RAID group
- Whether drives with different RPM are allowed

For more information about these options, see the storage aggregate create man page.

The following command creates a mirrored aggregate with 10 disks:

```
cluster_A::> storage aggregate create aggr1_node_A_1 -diskcount 10
-node node_A_1 -mirror true
[Job 15] Job is queued: Create aggr1_node_A_1.
[Job 15] The job is starting.
[Job 15] Job succeeded: DONE
```

3. Verify the RAID group and drives of your new aggregate:

storage aggregate show-status -aggregate aggregate-name

Installing licenses for the new controller module

You must add licenses for the new controller module for any ONTAP services that require standard (node-locked) licenses. For features with standard licenses, each node in the cluster must have its own key for the feature.

For detailed information about licensing, see the knowledgebase article 3013749: Data ONTAP 8.2 Licensing Overview and References on the NetApp Support Site and the *System Administration Reference*.

Steps

1. If necessary, obtain license keys for the new node on the NetApp Support Site in the My Support section under Software licenses.

For further information on license replacements, see the Knowledge Base article Post Motherboard Replacement Process to update Licensing on a AFF/FAS system.

2. Issue the following command to install each license key:

system license add -license-code license_key

The *license_key* is 28 digits in length.

3. Repeat this step for each required standard (node-locked) license.

Creating unmirrored data aggregates

You can optionally create unmirrored data aggregates for data that does not require the redundant mirroring provided by MetroCluster configurations.

About this task

- You should know what drives or array LUNs will be used in the new aggregate.
- If you have multiple drive types in your system (heterogeneous storage), you should understand how you can verify that the correct drive type is selected.



In MetroCluster IP configurations, remote unmirrored aggregates are not accessible after a switchover



The unmirrored aggregates must be local to the node owning them.

- Drives and array LUNs are owned by a specific node; when you create an aggregate, all drives in that aggregate must be owned by the same node, which becomes the home node for that aggregate.
- Aggregate names should conform to the naming scheme you determined when you planned your MetroCluster configuration.
- Disks and aggregates management contains more information about mirroring aggregates.

Steps

1. Install and cable the disk shelves that will contain the unmirrored aggregates.

You can use the procedures in the Installation and Setup documentation for your platform and disk shelves.

ONTAP Hardware Systems Documentation

2. Manually assign all disks on the new shelf to the appropriate node:

disk assign -disk disk-id -owner owner-node-name

3. Create the aggregate:

storage aggregate create

If you are logged in to the cluster on the cluster management interface, you can create an aggregate on any node in the cluster. To verify that the aggregate is created on a specific node, you should use the -node parameter or specify drives that are owned by that node.

You must also ensure that you are only including drives on the unmirrored shelf to the aggregate.

You can specify the following options:

- Aggregate's home node (that is, the node that owns the aggregate in normal operation)
- · List of specific drives or array LUNs that are to be added to the aggregate
- Number of drives to include
- · Checksum style to use for the aggregate
- Type of drives to use
- Size of drives to use
- Drive speed to use
- RAID type for RAID groups on the aggregate
- Maximum number of drives or array LUNs that can be included in a RAID group
- · Whether drives with different RPM are allowed

For more information about these options, see the storage aggregate create man page.

The following command creates a unmirrored aggregate with 10 disks:

```
controller_A_1::> storage aggregate create aggr1_controller_A_1
-diskcount 10 -node controller_A_1
[Job 15] Job is queued: Create aggr1_controller_A_1.
[Job 15] The job is starting.
[Job 15] Job succeeded: DONE
```

4. Verify the RAID group and drives of your new aggregate:

storage aggregate show-status -aggregate aggregate-name

Related information

Installing the firmware after adding a controller module

After adding the controller module, you must install the latest firmware on the new controller module so that the controller module functions properly with ONTAP.

Steps

1. Download the most current version of firmware for your system and follow the instructions for downloading and installing the new firmware.

NetApp Downloads: System Firmware and Diagnostics

Refreshing the MetroCluster configuration with new controllers

You must refresh the MetroCluster configuration when expanding it from a two-node configuration to a four-node configuration.

Steps

- 1. Refresh the MetroCluster configuration:
 - a. Enter advanced privilege mode: set -privilege advanced
 - b. Refresh the MetroCluster configuration: metrocluster configure -refresh true -allow-with-one-aggregate true

The following command refreshes the MetroCluster configuration on all of the nodes in the DR group that contains controller_A_1:

```
controller_A_1::*> metrocluster configure -refresh true -allow-with
-one-aggregate true
```

[Job 726] Job succeeded: Configure is successful.

c. Return to admin privilege mode:

set -privilege admin

2. Verify the networking status on site A:

network port show

The following example shows the network port usage on a four-node MetroCluster configuration:

cluste	cluster A::> network port show							
	Speed (Mbps)							
Node	Port	IPspace	Broadcast Domai	n Link	MTU	Admin/Oper		
contro	ller_A_1							
	e0a	Cluster	Cluster	up	9000	auto/1000		
	e0b	Cluster	Cluster	up	9000	auto/1000		
	eOc	Default	Default	up	1500	auto/1000		
	e0d	Default	Default	up	1500	auto/1000		
	e0e	Default	Default	up	1500	auto/1000		
	eOf	Default	Default	up	1500	auto/1000		
	eOg	Default	Default	up	1500	auto/1000		
contro	ller_A_2							
	e0a	Cluster	Cluster	up	9000	auto/1000		
	e0b	Cluster	Cluster	up	9000	auto/1000		
	eOc	Default	Default	up	1500	auto/1000		
	e0d	Default	Default	up	1500	auto/1000		
	e0e	Default	Default	up	1500	auto/1000		
	eOf	Default	Default	up	1500	auto/1000		
	eOg	Default	Default	up	1500	auto/1000		
14 ent	ries were	displayed.						

- 3. Verify the MetroCluster configuration from both sites in the MetroCluster configuration.
 - a. Verify the configuration from site A:

metrocluster show

```
cluster_A::> metrocluster show

Cluster Entry Name State

------ Configuration state configured

Mode normal

AUSO Failure Domain auso-on-cluster-

disaster

Remote: cluster_B Configuration state configured

Mode normal

AUSO Failure Domain auso-on-cluster-

disaster
```

b. Verify the configuration from site B:

metrocluster show

cluster_B::> metrocluster	show	
Cluster	Entry Name	State
Local: cluster_B	Configuration state	configured
	Mode	normal
	AUSO Failure Domain	auso-on-cluster-
disaster		
Remote: cluster_A	Configuration state	configured
	Mode	normal
	AUSO Failure Domain	auso-on-cluster-
disaster		

c. Verify that the DR relationships have been created correctly:

metrocluster node show -fields dr-cluster,dr-auxiliary,node-objectlimit,automatic-uso,ha-partner,dr-partner

<pre>metrocluster limit,automa dr-group-id dr-auxiliary</pre>	r node show - atic-uso,ha-g cluster / node-objec	-fields dr partner,dr node h ct-limit a 	-cluster,dr -partner a-partner d: utomatic-us	-auxiliary, r-cluster o o	node-object- dr-partner
2 2	cluster_A	node_A_1	node_A_2	- cluster_B	node_B_1
поde_в_2 2	cluster_A	node_A_2	node_A_1	cluster_B	node_B_2
node_B_1	on	t	rue		
2	cluster_B	node_B_1	node_B_2	cluster_A	node_A_1
node_A_2	on	t	rue		
2	cluster_B	node_B_2	node_B_1	cluster_A	node_A_2
node_A_1	on	t	rue		
4 entries we	ere displayed	d.			

Enabling storage failover on both controller modules and enabling cluster HA

After adding new controller modules to the MetroCluster configuration, you must enable storage failover on both controller modules and separately enable cluster HA.

Before you begin

The MetroCluster configuration must have previously been refreshed using the metrocluster configure -refresh true command.

About this task

This task must be performed on each MetroCluster site.

Steps

1. Enable storage failover:

storage failover modify -enabled true -node existing-node-name

The single command enables storage failover on both controller modules.

2. Verify that storage failover is enabled:

storage failover show

The output should be similar to the following:

Node	Partner	Possible	State Description
old-ctlr	new-ctlr	true	Connected to new-ctlr
new-ctlr	old-ctlr	true	Connected to old-ctlr
2 entries were	displayed.		

3. Enable cluster HA:

cluster ha modify -configured true

Cluster high availability (HA) must be configured in a cluster if it contains only two nodes and it differs from the HA provided by storage failover.

Restarting the SVMs

After expanding the MetroCluster configuration, you must restart the SVMs.

Steps

1. Identify the SVMs that need to be restarted:

metrocluster vserver show

This command shows the SVMs on both MetroCluster clusters.

- 2. Restart the SVMs on the first cluster:
 - a. Enter advanced privilege mode, pressing y when prompted:

set -privilege advanced

b. Restart the SVMs:

vserver start -vserver SVM_name -force true

c. Return to admin privilege mode:

set -privilege admin

- 3. Repeat the previous step on the partner cluster.
- 4. Verify that the SVMs are in a healthy state:

metrocluster vserver show

Expand a four-node MetroCluster FC configuration to an eight-node configuration

Expanding a four-node MetroCluster FC configuration to an eight-node configuration

Expanding a four-node MetroCluster FC configuration to an eight-node MetroCluster FC configuration involves adding two controllers to each cluster to form a second HA pair at each MetroCluster site, and then running the MetroCluster FC configuration operation.

About this task

• The nodes must be running ONTAP 9 in a MetroCluster FC configuration.

This procedure is not supported on earlier versions of ONTAP or in MetroCluster IP configurations.

- The existing MetroCluster FC configuration must be healthy.
- The equipment you are adding must be supported and meet all the requirements described in Fabricattached MetroCluster installation and configuration
- You must have available FC switch ports to accommodate the new controllers and any new bridges.
- You need the admin password and access to an FTP or SCP server.
- This procedure applies only to MetroCluster FC configurations.
- This procedure is nondisruptive and takes approximately one day to complete (excluding rack and stack) when disks are zeroed.

Before performing this procedure, the MetroCluster FC configuration consists of four nodes, with one HA pair at each site:



At the conclusion of this procedure, the MetroCluster FC configuration consists of two HA pairs at each site:



Both sites must be expanded equally. A MetroCluster FC configuration cannot consist of an uneven number of nodes.

Supported platform combinations when adding a second DR group

The following table shows the supported platform combinations for eight-node MetroCluster FC configurations.

• All nodes in the MetroCluster configuration must be running the same ONTAP version. For example, if you have an eight-node configuration, all eight nodes must be running the same ONTAP version.



- The combinations in this table apply only to regular or permanent eight-node configurations.
- The platform combinations in this table **do not** apply if you are using the the transition or refresh procedures.
- All nodes in one DR group must be of the same type and configuration.

		8Node DrGroup 2									
		FAS8200	AFF A300	FAS8300	AFF A400	ASA A400	FAS9000	AFF A700	FAS9500	AFF A900	ASA A900
8Node DrGroup 1	FAS8200										
	AFF A300										
	FAS8300										
	AFF A400										
	ASA A400										
	FAS9000										
	AFF A700										
	FAS9500										
	AFF A900										
	ASA A900										

Determining the new cabling layout

You must determine the cabling for the new controller modules and any new disk shelves to the existing FC switches.

About this task

This task must be performed at each MetroCluster site.

Steps

1. Use the procedure in Fabric-attached MetroCluster installation and configuration to create a cabling layout for your switch type, using the port usage for an eight-node MetroCluster configuration.

The FC switch port usage must match the usage described in the procedure so that the Reference Configuration Files (RCFs) can be used.



If your environment cannot be cabled in such a way that RCF files can be used, you must manually configure the system according to instructions found in Fabric-attached MetroCluster installation and configuration. Do not use this procedure if the cabling cannot use RCF files.

Racking the new equipment

You must rack the equipment for the new nodes.

Steps

1. Use the procedure in Fabric-attached MetroCluster installation and configuration to rack the new storage systems, disk shelves, and FC-to-SAS bridges.

Verifying the health of the MetroCluster configuration

You should check the health of the MetroCluster configuration to verify proper operation.

Steps

1. Check that the MetroCluster is configured and in normal mode on each cluster:

metrocluster show

```
cluster_A::> metroclustershowClusterEntry NameState--------------------Local: cluster_AConfiguration stateconfiguredModenormalAUSO Failure Domainauso-on-cluster-disasterRemote: cluster_BConfiguration stateconfiguredModenormalAUSO Failure Domainauso-on-cluster-disaster
```

2. Check that mirroring is enabled on each node:

3. Check that the MetroCluster components are healthy:

metrocluster check run

or sub-commands in "metrocluster check" directory for detailed results. To check if the nodes are ready to do a switchover or switchback operation, run "metrocluster switchover -simulate" or "metrocluster switchback -simulate", respectively.

4. Check that there are no health alerts:

system health alert show

- 5. Simulate a switchover operation:
 - a. From any node's prompt, change to the advanced privilege level: set -privilege advanced

You need to respond with \mathbf{y} when prompted to continue into advanced mode and see the advanced mode prompt (*>).

- b. Perform the switchover operation with the -simulate parameter: metrocluster switchover -simulate
- c. Return to the admin privilege level: set -privilege admin

Checking for MetroCluster configuration errors with Config Advisor

You can go to the NetApp Support Site and download the Config Advisor tool to check for common configuration errors.

About this task

Config Advisor is a configuration validation and health check tool. You can deploy it at both secure sites and non-secure sites for data collection and system analysis.



Support for Config Advisor is limited, and available only online.

Steps

1. Go to the Config Advisor download page and download the tool.

NetApp Downloads: Config Advisor

2. Run Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.

Sending a custom AutoSupport message prior to adding nodes to the MetroCluster configuration

You should issue an AutoSupport message to notify NetApp technical support that maintenance is underway. Informing technical support that maintenance is underway prevents them from opening a case on the assumption that a disruption has occurred.

About this task

This task must be performed on each MetroCluster site.

Steps

- 1. Log in to the cluster at Site_A.
- 2. Invoke an AutoSupport message indicating the start of the maintenance:

```
system node autosupport invoke -node * -type all -message MAINT=maintenance-
window-in-hours
```

The maintenance-window-in-hours parameter specifies the length of the maintenance window and can be a maximum of 72 hours. If the maintenance is completed before the time has elapsed, you can issue the following command to indicating that the maintenance period has ended:

system node autosupport invoke -node * -type all -message MAINT=end

3. Repeat this step on the partner site.

Recable and zone a switch fabric for the new nodes

Disconnecting the existing DR group from the fabric

You must disconnect the existing controller modules from the FC switches in the fabric.

About this task

This task must be performed at each MetroCluster site.

Steps

1. Disable the HBA ports that connect the existing controller modules to the switch fabric undergoing maintenance:

storage port disable -node node-name -port port-number

2. On the local FC switches, remove the cables from the ports for the existing controller module's HBA, FC-VI, and ATTO bridges.

You should label the cables for easy identification when you re-cable them. Only the ISL ports should remain cabled.

Recable and reconfigure the switches

You must apply the RCF files to reconfigure your zoning to accommodate the new nodes.

If you cannot use the RCF files to configure the switches, you must configure the switches manually. See:

- Configure the Brocade FC switches manually
- · Configure the Cisco FC switches manually

Steps

1. Locate the RCF files for your configuration.

You must use the RCF files for an eight-node configuration and that match your switch model.

- 2. Apply the RCF files, following the directions on the download page, adjusting the ISL settings as needed.
- 3. Ensure that the switch configuration is saved.
- 4. Reboot the FC switches.
- 5. Cable both the pre-existing and the new FC-to-SAS bridges to the FC switches, using the cabling layout you created previously.

The FC switch port usage must match the MetroCluster eight-node usage described in Fabric-attached MetroCluster installation and configuration so that the Reference Configuration Files (RCFs) can be used.

6. Verify that the ports are online by using the correct command for your switch.

Switch vendor	Command
Brocade	switchshow

```
Cisco show interface brief
```

7. Use the procedure in Fabric-attached MetroCluster installation and configuration to cable the FC-VI ports from the existing and new controllers, using the cabling layout you created previously.

The FC switch port usage must match the MetroCluster eight-node usage described in Fabric-attached MetroCluster installation and configuration so that the Reference Configuration Files (RCFs) can be used.

8. From the existing nodes, verify that the FC-VI ports are online:

metrocluster interconnect adapter show

metrocluster interconnect mirror show

- 9. Cable the HBA ports from the current and the new controllers.
- 10. On the existing controller modules, e-enable the ports connected to the switch fabric undergoing maintenance:

storage port enable -node node-name -port port-ID

11. Start the new controllers and boot them into Maintenance mode:

boot_ontap maint

12. Verify that only storage that will be used by the new DR group is visible to the new controller modules.

None of the storage that is used by the other DR group should be visible.

13. Return to the beginning of this process to re-cable the second switch fabric.

Configure ONTAP on the new controllers

Clearing the configuration on a controller module

Before using a new controller module in the MetroCluster configuration, you must clear the existing configuration.

Steps

1. If necessary, halt the node to display the LOADER prompt:

halt

2. At the LOADER prompt, set the environmental variables to default values:

set-defaults

3. Save the environment:

saveenv

4. At the LOADER prompt, launch the boot menu:

boot ontap menu

5. At the boot menu prompt, clear the configuration:

wipeconfig

Respond yes to the confirmation prompt.

The node reboots and the boot menu is displayed again.

6. At the boot menu, select option **5** to boot the system into Maintenance mode.

Respond yes to the confirmation prompt.

Assigning disk ownership in AFF systems

If you are using AFF systems in a configuration with mirrored aggregates and the nodes do not have the disks (SSDs) correctly assigned, you should assign half the disks on each shelf to one local node and the other half of the disks to its HA partner node. You should create a configuration in which each node has the same number of disks in its local and remote disk pools.

About this task

The storage controllers must be in Maintenance mode.

This does not apply to configurations which have unmirrored aggregates, an active/passive configuration, or that have an unequal number of disks in local and remote pools.

This task is not required if disks were correctly assigned when received from the factory.



Pool 0 always contains the disks that are found at the same site as the storage system that owns them, while Pool 1 always contains the disks that are remote to the storage system that owns them.

Steps

- 1. If you have not done so, boot each system into Maintenance mode.
- 2. Assign the disks to the nodes located at the first site (site A):

You should assign an equal number of disks to each pool.

a. On the first node, systematically assign half the disks on each shelf to pool 0 and the other half to the HA partner's pool 0:

disk assign -disk disk-name -p pool -n number-of-disks

If storage controller Controller_A_1 has four shelves, each with 8 SSDs, you issue the following commands:

```
*> disk assign -shelf FC_switch_A_1:1-4.shelf1 -p 0 -n 4
*> disk assign -shelf FC_switch_A_1:1-4.shelf2 -p 0 -n 4
*> disk assign -shelf FC_switch_B_1:1-4.shelf1 -p 1 -n 4
*> disk assign -shelf FC switch B 1:1-4.shelf2 -p 1 -n 4
```

 B. Repeat the process for the second node at the local site, systematically assigning half the disks on each shelf to pool 1 and the other half to the HA partner's pool 1: disk assign -disk disk-name -p pool

If storage controller Controller_A_1 has four shelves, each with 8 SSDs, you issue the following commands:

```
*> disk assign -shelf FC_switch_A_1:1-4.shelf3 -p 0 -n 4
*> disk assign -shelf FC_switch_B_1:1-4.shelf4 -p 1 -n 4
*> disk assign -shelf FC_switch_A_1:1-4.shelf3 -p 0 -n 4
*> disk assign -shelf FC switch B 1:1-4.shelf4 -p 1 -n 4
```

3. Assign the disks to the nodes located at the second site (site B):

You should assign an equal number of disks to each pool.

a. On the first node at the remote site, systematically assign half the disks on each shelf to pool 0 and the other half to the HA partner's pool 0:

disk assign -disk disk-name -p pool

If storage controller Controller_B_1 has four shelves, each with 8 SSDs, you issue the following commands:

```
*> disk assign -shelf FC_switch_B_1:1-5.shelf1 -p 0 -n 4
*> disk assign -shelf FC_switch_B_1:1-5.shelf2 -p 0 -n 4
*> disk assign -shelf FC_switch_A_1:1-5.shelf1 -p 1 -n 4
*> disk assign -shelf FC_switch_A_1:1-5.shelf2 -p 1 -n 4
```

b. Repeat the process for the second node at the remote site, systematically assigning half the disks on each shelf to pool 1 and the other half to the HA partner's pool 1:

disk assign -disk disk-name -p pool

If storage controller Controller_B_2 has four shelves, each with 8 SSDs, you issue the following commands:
```
*> disk assign -shelf FC_switch_B_1:1-5.shelf3 -p 0 -n 4
*> disk assign -shelf FC_switch_B_1:1-5.shelf4 -p 0 -n 4
*> disk assign -shelf FC_switch_A_1:1-5.shelf3 -p 1 -n 4
*> disk assign -shelf FC switch A 1:1-5.shelf4 -p 1 -n 4
```

4. Confirm the disk assignments:

storage show disk

5. Exit Maintenance mode:

halt

6. Display the boot menu:

boot_ontap menu

7. On each node, select option 4 to initialize all disks.

Assigning disk ownership in non-AFF systems

If the MetroCluster nodes do not have the disks correctly assigned, or if you are using DS460C disk shelves in your configuration, you must assign disks to each of the nodes in the MetroCluster configuration on a shelf-by-shelf basis. You will create a configuration in which each node has the same number of disks in its local and remote disk pools.

About this task

The storage controllers must be in Maintenance mode.

If your configuration does not include DS460C disk shelves, this task is not required if disks were correctly assigned when received from the factory.



Pool 0 always contains the disks that are found at the same site as the storage system that owns them.

Pool 1 always contains the disks that are remote to the storage system that owns them.

If your configuration includes DS460C disk shelves, you should manually assign the disks using the following guidelines for each 12-disk drawer:

Assign these disks in the drawer	To this node and pool
0 - 2	Local node's pool 0
3 - 5	HA partner node's pool 0
6 - 8	DR partner of the local node's pool 1

This disk assignment pattern ensures that an aggregate is minimally affected in case a drawer goes offline.

Steps

- 1. If you have not done so, boot each system into Maintenance mode.
- 2. Assign the disk shelves to the nodes located at the first site (site A):

Disk shelves at the same site as the node are assigned to pool 0 and disk shelves located at the partner site are assigned to pool 1.

You should assign an equal number of shelves to each pool.

a. On the first node, systematically assign the local disk shelves to pool 0 and the remote disk shelves to pool 1:

```
disk assign -shelf local-switch-name:shelf-name.port -p pool
```

If storage controller Controller_A_1 has four shelves, you issue the following commands:

```
*> disk assign -shelf FC_switch_A_1:1-4.shelf1 -p 0
*> disk assign -shelf FC_switch_A_1:1-4.shelf2 -p 0
*> disk assign -shelf FC_switch_B_1:1-4.shelf1 -p 1
*> disk assign -shelf FC_switch_B_1:1-4.shelf2 -p 1
```

b. Repeat the process for the second node at the local site, systematically assigning the local disk shelves to pool 0 and the remote disk shelves to pool 1:

disk assign -shelf local-switch-name:shelf-name.port -p pool

If storage controller Controller_A_2 has four shelves, you issue the following commands:

```
*> disk assign -shelf FC_switch_A_1:1-4.shelf3 -p 0
*> disk assign -shelf FC_switch_B_1:1-4.shelf4 -p 1
*> disk assign -shelf FC_switch_A_1:1-4.shelf3 -p 0
*> disk assign -shelf FC_switch_B_1:1-4.shelf4 -p 1
```

3. Assign the disk shelves to the nodes located at the second site (site B):

Disk shelves at the same site as the node are assigned to pool 0 and disk shelves located at the partner site are assigned to pool 1.

You should assign an equal number of shelves to each pool.

a. On the first node at the remote site, systematically assign its local disk shelves to pool 0 and its remote disk shelves to pool 1:

```
disk assign -shelf local-switch-nameshelf-name -p pool
```

If storage controller Controller_B_1 has four shelves, you issue the following commands:

```
*> disk assign -shelf FC_switch_B_1:1-5.shelf1 -p 0
*> disk assign -shelf FC_switch_B_1:1-5.shelf2 -p 0
*> disk assign -shelf FC_switch_A_1:1-5.shelf1 -p 1
*> disk assign -shelf FC switch A 1:1-5.shelf2 -p 1
```

b. Repeat the process for the second node at the remote site, systematically assigning its local disk shelves to pool 0 and its remote disk shelves to pool 1:

```
disk assign -shelf shelf-name -p pool
```

If storage controller Controller_B_2 has four shelves, you issue the following commands:

```
*> disk assign -shelf FC_switch_B_1:1-5.shelf3 -p 0
*> disk assign -shelf FC_switch_B_1:1-5.shelf4 -p 0
*> disk assign -shelf FC_switch_A_1:1-5.shelf3 -p 1
*> disk assign -shelf FC_switch_A_1:1-5.shelf4 -p 1
```

4. Confirm the shelf assignments:

storage show shelf

5. Exit Maintenance mode:

halt

6. Display the boot menu:

boot_ontap menu

7. On each node, select option 4 to initialize all disks.

Verifying the ha-config state of components

In a MetroCluster configuration, the ha-config state of the controller module and chassis components must be set to **mcc** so they boot up properly.

About this task

- The system must be in Maintenance mode.
- This task must be performed on each new controller module.

Steps

1. In Maintenance mode, display the HA state of the controller module and chassis:

ha-config show

The HA state for all components should be "mcc".

2. If the displayed system state of the controller is not correct, set the HA state for the controller module:

ha-config modify controller mcc

3. If the displayed system state of the chassis is not correct, set the HA state for the chassis:

ha-config modify chassis mcc

4. Repeat these steps on the other replacement node.

Booting the new controllers and joining them to the cluster

To join the new controllers to the cluster, you must boot each new controller module and use the ONTAP cluster setup wizard to identify the cluster will join.

Before you begin

You must have cabled the MetroCluster configuration.

You must not have configured the Service Processor prior to performing this task.

About this task

This task must be performed on each of the new controllers at both clusters in the MetroCluster configuration.

Steps

1. If you have not already done so, power up each node and let them boot completely.

If the system is in Maintenance mode, issue the halt command to exit Maintenance mode, and then issue the following command from the LOADER prompt:

boot_ontap

The controller module enters the node setup wizard.

The output should be similar to the following:

- 2. Enable the AutoSupport tool by following the directions provided by the system.
- 3. Respond to the prompts to configure the node management interface.

The prompts are similar to the following:

```
Enter the node management interface port: [eOM]:
Enter the node management interface IP address: 10.228.160.229
Enter the node management interface netmask: 225.225.252.0
Enter the node management interface default gateway: 10.228.160.1
```

4. Confirm that nodes are configured in high-availability mode:

storage failover show -fields mode

If not, you must issue the following command on each node, and then reboot the node:

storage failover modify -mode ha -node localhost

This command configures high availability mode but does not enable storage failover. Storage failover is automatically enabled when you issue the metrocluster configure command later in the configuration process.

5. Confirm that you have four ports configured as cluster interconnects:

network port show

The following example shows output for two controllers in cluster_A. If it is a two-node MetroCluster configuration, the output shows only one node.

cluster_A::> network port show							
						Speed	
(Mbps)							
Node	Port	IPspace	Broadcast Domain	Link M	ΓU	Admin/Oper	
node N	1						
noue_A	_ [⊥]	Cluster	Cluster	110	150	0	
au + a/1	~~e0a	CIUSCEI	Cluster	up	100	0	
auto/1	000	Cluston	Cluster	1170	1500		
au + a/1	409	Clustel	Cluster	up	1000		
auto/1		Dofault	Dofault	1170	1500	$-11 \pm 0/1000$	
	209	Default	Default	up	1500	auto/1000	
	eua	Default	Default	up	1500	auto/1000	
	eve	Default	Default	up	1500	auto/1000	
	eOf	Default	Default	up	1500	auto/1000	
	eOg	Default	Default	up	1500	auto/1000	
node_A	_2						
	**e0a	Cluster	Cluster	up	150	0	
auto/1	000						
	e0b	Cluster	Cluster	up	1500		
auto/1	000**						
	eOc	Default	Default	up	1500	auto/1000	
	e0d	Default	Default	up	1500	auto/1000	
	e0e	Default	Default	up	1500	auto/1000	
	eOf	Default	Default	up	1500	auto/1000	
	eOg	Default	Default	up	1500	auto/1000	
14 ent	ries were	displayed.					

6. Because you are using the CLI to set up the cluster, exit the Node Setup wizard:

exit

- 7. Log in to the admin account by using the admin user name.
- 8. Start the Cluster Setup wizard, and then join the existing cluster:

cluster setup

```
::> cluster setup
Welcome to the cluster setup wizard.
You can enter the following commands at any time:
   "help" or "?" - if you want to have a question clarified,
   "back" - if you want to change previously answered questions, and
   "exit" or "quit" - if you want to quit the cluster setup wizard.
    Any changes you made before quitting will be saved.
You can return to cluster setup at any time by typing "cluster setup".
To accept a default or omit a question, do not enter a value.
```

After you complete the Cluster Setup wizard and it exits, verify that the cluster is active and the node is healthy:

cluster show

The following example shows a cluster in which the first node (cluster1-01) is healthy and eligible to participate:

```
cluster_A::> cluster show
Node Health Eligibility
-----
node_A_1 true true
node_A_2 true true
node_A_3 true true
```

If it becomes necessary to change any of the settings you entered for the admin SVM or node SVM, you can access the **Cluster Setup** wizard by using the cluster setup command.

Configure the clusters into a MetroCluster configuration

Configure intercluster LIFs

Configuring intercluster LIFs on dedicated ports

You can configure intercluster LIFs on dedicated ports. Doing so typically increases the available bandwidth for replication traffic.

Steps

1. List the ports in the cluster:

For complete command syntax, see the man page.

The following example shows the network ports in cluster01:

cluster01::> network port show									
Speed									
(Mbps)									
Node	Port	IPspace	Broadcast Domain	Link	MTU	Admin/Oper			
cluste	r01-01								
	e0a	Cluster	Cluster	up	1500	auto/1000			
	e0b	Cluster	Cluster	up	1500	auto/1000			
	eOc	Default	Default	up	1500	auto/1000			
	e0d	Default	Default	up	1500	auto/1000			
	e0e	Default	Default	up	1500	auto/1000			
	eOf	Default	Default	up	1500	auto/1000			
cluste	r01-02								
	e0a	Cluster	Cluster	up	1500	auto/1000			
	e0b	Cluster	Cluster	up	1500	auto/1000			
	e0c	Default	Default	up	1500	auto/1000			
	e0d	Default	Default	up	1500	auto/1000			
	e0e	Default	Default	up	1500	auto/1000			
	eOf	Default	Default	up	1500	auto/1000			
				-					

2. Determine which ports are available to dedicate to intercluster communication:

network interface show -fields home-port,curr-port

For complete command syntax, see the man page.

The following example shows that ports "e0e" and "e0f" have not been assigned LIFs:

cluster01::> network interfac	ce show -f	ields home-port,curr-port
vserver lif	home-port	curr-port
Cluster cluster01-01_clus1	e0a	e0a
Cluster cluster01-01_clus2	e0b	e0b
Cluster cluster01-02_clus1	e0a	e0a
Cluster cluster01-02_clus2	e0b	e0b
cluster01		
cluster_mgmt	eOc	eOc
cluster01		
cluster01-01_mgmt1	eOc	eOc
cluster01		
cluster01-02_mgmt1	eOc	eOc

3. Create a failover group for the dedicated ports:

```
network interface failover-groups create -vserver system_SVM -failover-group
failover group -targets physical or logical ports
```

The following example assigns ports "e0e" and "e0f" to the failover group "intercluster01" on the system SVM "cluster01":

```
cluster01::> network interface failover-groups create -vserver cluster01
-failover-group
intercluster01 -targets
cluster01-01:e0e,cluster01-01:e0f,cluster01-02:e0e,cluster01-02:e0f
```

4. Verify that the failover group was created:

network interface failover-groups show

For complete command syntax, see the man page.

cluster01::> network interface failover-groups show Failover Group Vserver Targets _____ _____ _____ Cluster Cluster cluster01-01:e0a, cluster01-01:e0b, cluster01-02:e0a, cluster01-02:e0b cluster01 Default cluster01-01:e0c, cluster01-01:e0d, cluster01-02:e0c, cluster01-02:e0d, cluster01-01:e0e, cluster01-01:e0f cluster01-02:e0e, cluster01-02:e0f intercluster01 cluster01-01:e0e, cluster01-01:e0f cluster01-02:e0e, cluster01-02:e0f

5. Create intercluster LIFs on the system SVM and assign them to the failover group.

ONTAP version	Command
9.6 and later	<pre>network interface create -vserver system_SVM -lif LIF_name -service-policy default-intercluster -home-node node -home -port port -address port_IP -netmask netmask -failover -group failover_group</pre>
9.5 and earlier	<pre>network interface create -vserver system_SVM -lif LIF_name -role intercluster -home-node node -home-port port -address port_IP -netmask netmask -failover-group failover_group</pre>

For complete command syntax, see the man page.

The following example creates intercluster LIFs "cluster01_icl01" and "cluster01_icl02" in the failover group "intercluster01":

```
cluster01::> network interface create -vserver cluster01 -lif
cluster01_icl01 -service-
policy default-intercluster -home-node cluster01-01 -home-port e0e
-address 192.168.1.201
-netmask 255.255.255.0 -failover-group intercluster01
cluster01::> network interface create -vserver cluster01 -lif
cluster01_icl02 -service-
policy default-intercluster -home-node cluster01-02 -home-port e0e
-address 192.168.1.202
-netmask 255.255.255.0 -failover-group intercluster01
```

6. Verify that the intercluster LIFs were created:

In ONTAP 9.6 and later:

network interface show -service-policy default-intercluster

In ONTAP 9.5 and earlier:

```
network interface show -role intercluster
```

For complete command syntax, see the man page.

7. Verify that the intercluster LIFs are redundant:

In ONTAP 9.6 and later:

network interface show -service-policy default-intercluster -failover

In ONTAP 9.5 and earlier: network interface show -role intercluster -failover

For complete command syntax, see the man page.

The following example shows that the intercluster LIFs "cluster01_icl01" and "cluster01_icl02" on the SVM "e0e" port will fail over to the "e0f" port.

```
cluster01::> network interface show -service-policy default-intercluster
-failover
      Logical
                  Home
                                    Failover
                                                 Failover
Vserver Interface Node:Port
                                    Policy
                                                 Group
cluster01
       cluster01 icl01 cluster01-01:e0e local-only
intercluster01
                      Failover Targets: cluster01-01:e0e,
                                     cluster01-01:e0f
       cluster01 icl02 cluster01-02:e0e local-only
intercluster01
                      Failover Targets: cluster01-02:e0e,
                                     cluster01-02:e0f
```

Configuring intercluster LIFs on shared data ports

You can configure intercluster LIFs on ports shared with the data network. Doing so reduces the number of ports you need for intercluster networking.

Steps

1. List the ports in the cluster:

network port show

For complete command syntax, see the man page.

The following example shows the network ports in cluster01:

cluster01::> network port show								
Speed								
(Mbps)								
Node	Port	IPspace	Broadcast Domain	Link	MTU	Admin/Oper		
cluster	r01-01							
	e0a	Cluster	Cluster	up	1500	auto/1000		
	e0b	Cluster	Cluster	up	1500	auto/1000		
	eOc	Default	Default	up	1500	auto/1000		
	e0d	Default	Default	up	1500	auto/1000		
cluster	r01-02							
	e0a	Cluster	Cluster	up	1500	auto/1000		
	e0b	Cluster	Cluster	up	1500	auto/1000		
	eOc	Default	Default	up	1500	auto/1000		
	e0d	Default	Default	up	1500	auto/1000		

2. Create intercluster LIFs on the system SVM:

In ONTAP 9.6 and later:

```
network interface create -vserver system_SVM -lif LIF_name -service-policy
default-intercluster -home-node node -home-port port -address port_IP -netmask
netmask
```

In ONTAP 9.5 and earlier:

```
network interface create -vserver system_SVM -lif LIF_name -role intercluster
-home-node node -home-port port -address port_IP -netmask netmask
```

For complete command syntax, see the man page.

The following example creates intercluster LIFs cluster01 icl01 and cluster01 icl02:

```
cluster01::> network interface create -vserver cluster01 -lif
cluster01_icl01 -service-
policy default-intercluster -home-node cluster01-01 -home-port e0c
-address 192.168.1.201
-netmask 255.255.255.0
cluster01::> network interface create -vserver cluster01 -lif
cluster01_icl02 -service-
policy default-intercluster -home-node cluster01-02 -home-port e0c
-address 192.168.1.202
-netmask 255.255.255.0
```

3. Verify that the intercluster LIFs were created:

In ONTAP 9.6 and later:

network interface show -service-policy default-intercluster

In ONTAP 9.5 and earlier:

```
network interface show -role intercluster
```

For complete command syntax, see the man page.

cluster01::> network interface show -service-policy default-intercluster							
	Logical	Status	Network	Current			
Current Is							
Vserver	Interface	Admin/Oper	Address/Mask	Node	Port		
Home							
	_						
cluster01							
	cluster01_	icl01					
		up/up	192.168.1.201/24	cluster01-01	eOc		
true							
	cluster01_	icl02					
		up/up	192.168.1.202/24	cluster01-02	eOc		
true							

4. Verify that the intercluster LIFs are redundant:

In ONTAP 9.6 and later:

network interface show -service-policy default-intercluster -failover

In ONTAP 9.5 and earlier:

```
network interface show -role intercluster -failover
```

For complete command syntax, see the man page.

The following example shows that the intercluster LIFs "cluster01_icl01" and "cluster01_icl02" on the "e0c" port will fail over to the "e0d" port.

cluster01::> network interface show -service-policy default-intercluster -failover Home Logical Failover Failover Vserver Interface Node:Port Policy Group _____ ___________ ______ ____ _ _____ ____ cluster01 cluster01 icl01 cluster01-01:e0c local-only 192.168.1.201/24 Failover Targets: cluster01-01:e0c, cluster01-01:e0d cluster01 icl02 cluster01-02:e0c local-only 192.168.1.201/24 Failover Targets: cluster01-02:e0c, cluster01-02:e0d

Mirroring the root aggregates

You must mirror the root aggregates to provide data protection.

By default, the root aggregate is created as RAID-DP type aggregate. You can change the root aggregate from RAID-DP to RAID4 type aggregate. The following command modifies the root aggregate for RAID4 type aggregate:

```
storage aggregate modify -aggregate aggr name -raidtype raid4
```



On non-ADP systems, the RAID type of the aggregate can be modified from the default RAID-DP to RAID4 before or after the aggregate is mirrored.

Steps

1. Mirror the root aggregate:

storage aggregate mirror aggr_name

The following command mirrors the root aggregate for controller_A_1:

controller A_1::> storage aggregate mirror aggr0_controller A_1

This mirrors the aggregate, so it consists of a local plex and a remote plex located at the remote MetroCluster site.

2. Repeat the previous step for each node in the MetroCluster configuration.

Implementing the MetroCluster configuration

You must run the metrocluster configure -refresh true command to start data

protection on the nodes that you have added to a MetroCluster configuration.

About this task

You issue the metrocluster configure -refresh true command once, on one of the newly added nodes, to refresh the MetroCluster configuration. You do not need to issue the command on each of the sites or nodes.

The metrocluster configure -refresh true command automatically pairs the two nodes with the lowest system IDs in each of the two clusters as disaster recovery (DR) partners. In a four-node MetroCluster configuration, there are two DR partner pairs. The second DR pair is created from the two nodes with higher system IDs.

Steps

- 1. Refresh the MetroCluster configuration:
 - a. Enter advanced privilege mode:

set -privilege advanced

b. Refresh the MetroCluster configuration on one of the new nodes: metrocluster configure -refresh true

The following example shows the MetroCluster configuration refreshed on both DR groups:

```
controller A 2::*> metrocluster configure -refresh true
```

```
[Job 726] Job succeeded: Configure is successful.
```

controller A 4::*> metrocluster configure -refresh true

[Job 740] Job succeeded: Configure is successful.

c. Return to admin privilege mode:

set -privilege admin

2. Verify the networking status on site A:

network port show

The following example shows the network port usage on a four-node MetroCluster configuration:

cluste	cluster_A::> network port show								
						Speed (Mbps)			
Node	Port	IPspace	Broadcast Domain	Link	MTU	Admin/Oper			
contro	ller_A_1								
	e0a	Cluster	Cluster	up	9000	auto/1000			
	e0b	Cluster	Cluster	up	9000	auto/1000			
	e0c	Default	Default	up	1500	auto/1000			
	e0d	Default	Default	up	1500	auto/1000			
	e0e	Default	Default	up	1500	auto/1000			
	eOf	Default	Default	up	1500	auto/1000			
	eOg	Default	Default	up	1500	auto/1000			
contro	ller_A_2								
	e0a	Cluster	Cluster	up	9000	auto/1000			
	e0b	Cluster	Cluster	up	9000	auto/1000			
	eOc	Default	Default	up	1500	auto/1000			
	e0d	Default	Default	up	1500	auto/1000			
	e0e	Default	Default	up	1500	auto/1000			
	eOf	Default	Default	up	1500	auto/1000			
	e0g	Default	Default	up	1500	auto/1000			
14 ent	ries were	displayed.							

- 3. Verify the MetroCluster configuration from both sites in the MetroCluster configuration:
 - a. Verify the configuration from site A:

metrocluster show

```
cluster_A::> metrocluster show
Configuration: IP fabric
Cluster Entry Name State
Local: cluster_A Configuration state configured
Node normal
Remote: cluster_B Configuration state configured
Node normal
```

b. Verify the configuration from site B: metrocluster show

Creating a mirrored data aggregate on each node

You must create a mirrored data aggregate on each node in the DR group.

About this task

- · You should know what drives will be used in the new aggregate.
- If you have multiple drive types in your system (heterogeneous storage), you should understand how you can ensure that the correct drive type is selected.
- Drives are owned by a specific node; when you create an aggregate, all drives in that aggregate must be owned by the same node, which becomes the home node for that aggregate.

In systems using ADP, aggregates are created using partitions in which each drive is partitioned in to P1, P2 and P3 partitions.

• Aggregate names should conform to the naming scheme you determined when you planned your MetroCluster configuration.

Disk and aggregate management



It's recommended you maintain at least 20% free space for mirrored aggregates for optimal storage performance and availability. Although the recommendation is 10% for non-mirrored aggregates, the additional 10% of space may be used by the filesystem to absorb incremental changes. Incremental changes increase space utilization for mirrored aggregates due to ONTAP's copy-on-write Snapshot-based architecture. Failure to adhere to these best practices may have a negative impact on performance.

Steps

1. Display a list of available spares:

storage disk show -spare -owner node_name

2. Create the aggregate:

storage aggregate create -mirror true

If you are logged in to the cluster on the cluster management interface, you can create an aggregate on any node in the cluster. To ensure that the aggregate is created on a specific node, use the -node

parameter or specify drives that are owned by that node.

You can specify the following options:

- Aggregate's home node (that is, the node that owns the aggregate in normal operation)
- · List of specific drives that are to be added to the aggregate
- Number of drives to include



In the minimum supported configuration, in which a limited number of drives are available, you must use the force-small-aggregate option to allow the creation of a three disk RAID-DP aggregate.

- · Checksum style to use for the aggregate
- Type of drives to use
- Size of drives to use
- Drive speed to use
- RAID type for RAID groups on the aggregate
- · Maximum number of drives that can be included in a RAID group
- Whether drives with different RPM are allowed

For more information about these options, see the storage aggregate create man page.

The following command creates a mirrored aggregate with 10 disks:

```
cluster_A::> storage aggregate create aggr1_node_A_1 -diskcount 10
-node node_A_1 -mirror true
[Job 15] Job is queued: Create aggr1_node_A_1.
[Job 15] The job is starting.
[Job 15] Job succeeded: DONE
```

3. Verify the RAID group and drives of your new aggregate:

storage aggregate show-status -aggregate aggregate-name

Configuring FC-to-SAS bridges for health monitoring

Learn how to configure the FC-to-SAS bridges for health monitoring.

About this task

- Third-party SNMP monitoring tools are not supported for FibreBridge bridges.
- Beginning with ONTAP 9.8, FC-to-SAS bridges are monitored via in-band connections by default, and additional configuration is not required.



Beginning with ONTAP 9.8, the storage bridge command is replaced with system bridge. The following steps show the storage bridge command, but if you are running ONTAP 9.8 or later, the system bridge command is preferred.

Step

- 1. From the ONTAP cluster prompt, add the bridge to health monitoring:
 - a. Add the bridge, using the command for your version of ONTAP:

ONTAP version	Command
9.5 and later	storage bridge add -address 0.0.0.0 -managed-by in-band -name bridge-name
9.4 and earlier	storage bridge add -address bridge- ip-address -name bridge-name

b. Verify that the bridge has been added and is properly configured:

storage bridge show

It might take as long as 15 minutes to reflect all data because of the polling interval. The ONTAP health monitor can contact and monitor the bridge if the value in the "Status" column is "ok", and other information, such as the worldwide name (WWN), is displayed.

The following example shows that the FC-to-SAS bridges are configured:

```
controller A 1::> storage bridge show
Bridge
               Symbolic Name Is Monitored Monitor Status
Vendor Model
                    Bridge WWN
_____ ____
_____ ____
                    _____
ATTO 10.10.20.10 atto01 true ok
                                              Atto
FibreBridge 7500N 2000010867038c0
ATTO_10.10.20.11 atto02 true
                                ok
                                             Atto
FibreBridge 7500N 2000010867033c0
ATTO 10.10.20.12 atto03 true
                                  ok
                                              Atto
FibreBridge 7500N 2000010867030c0
ATTO 10.10.20.13 atto04 true
                                  ok
                                              Atto
FibreBridge 7500N 2000001086703b80
4 entries were displayed
controller A 1::>
```

Moving a metadata volume in MetroCluster configurations

You can move a metadata volume from one aggregate to another aggregate in a MetroCluster configuration. You might want to move a metadata volume when the source aggregate is decommissioned or unmirrored, or for other reasons that make the aggregate ineligible.

About this task

- You must have cluster administrator privileges to perform this task.
- The target aggregate must be mirrored and should not be in the degraded state.
- The available space in the target aggregate must be larger than the metadata volume that you are moving.

Steps

1. Set the privilege level to advanced:

```
set -privilege advanced
```

2. Identify the metadata volume that should be moved:

volume show MDV_CRS*

```
Cluster A::*> volume show MDV_CRS*
Vserver Volume
                    Aggregate
                                 State
                                                     Size
                                           Туре
Available Used%
  ----- -----
_____ ____
Cluster A
         MDV CRS 14c00d4ac9f311e7922800a0984395f1 A
                     Node A 1 aggr1
                                 online
                                           RW
                                                     10GB
9.50GB
         5%
Cluster A
         MDV CRS 14c00d4ac9f311e7922800a0984395f1 B
                     Node A 2 aggr1
                                 online
                                           RW
                                                     10GB
9.50GB
         5%
Cluster A
         MDV CRS 15035e66c9f311e7902700a098439625 A
                     Node_B_1_aggr1
                                           RW
_
Cluster A
         MDV CRS 15035e66c9f311e7902700a098439625_B
                     Node B 2 aggr1
                                           RW
4 entries were displayed.
Cluster A::>
```

3. Identify an eligible target aggregate:

```
metrocluster check config-replication show-aggregate-eligibility
```

The following command identifies the aggregates in cluster_A that are eligible to host metadata volumes:

In the previous example, Node_A_1_aggr2 and Node_A_2_aggr2 are eligible.

4. Start the volume move operation:

```
volume move start -vserver svm_name -volume metadata_volume_name -destination
-aggregate destination aggregate name*
```

The following command moves metadata volume "MDV_CRS_14c00d4ac9f311e7922800a0984395f1" from "aggregate Node_A_1_aggr1" to "aggregate Node_A_1_aggr2":

5. Verify the state of the volume move operation:

volume move show -volume vol constituent name

6. Return to the admin privilege level:

set -privilege admin

Checking the MetroCluster configuration

You can check that the components and relationships in the MetroCluster configuration are working correctly. You should do a check after initial configuration and after making any changes to the MetroCluster configuration. You should also do a check before a negotiated (planned) switchover or a switchback operation.

About this task

If the metrocluster check run command is issued twice within a short time on either or both clusters, a conflict can occur and the command might not collect all data. Subsequent metrocluster check show commands do not show the expected output.

Steps

1. Check the configuration:

metrocluster check run

The command runs as a background job and might not be completed immediately.

```
cluster_A::> metrocluster check run
The operation has been started and is running in the background. Wait
for
it to complete and run "metrocluster check show" to view the results. To
check the status of the running metrocluster check operation, use the
command,
"metrocluster operation history show -job-id 2245"
```

```
cluster A::> metrocluster check show
Component
               Result
----- -----
nodes
                ok
lifs
                 ok
config-replication ok
aggregates
                ok
clusters
                ok
connections
               ok
volumes
                ok
7 entries were displayed.
```

2. Display more detailed results from the most recent metrocluster check run command:

metrocluster check aggregate show
metrocluster check cluster show
metrocluster check config-replication show
metrocluster check lif show
metrocluster check node show

The metrocluster check show commands show the results of the most recent metrocluster check run command. You should always run the metrocluster check run command prior to using the metrocluster check show commands so that the information displayed is current.

The following example shows the metrocluster check aggregate show command output for a healthy four-node MetroCluster configuration:

```
cluster_A::> metrocluster check aggregate show
Last Checked On: 8/5/2014 00:42:58
Node Aggregate Check
```

Result		
 controller A 1	controller A 1 aggr0	
ok		mirroring-status
		disk-pool-allocation
ок		ownership-state
ok	controller_A_1_aggr1	
ok		mirroring-status
ok		disk-pool-allocation
ok		ownership-state
	controller_A_1_aggr2	mirroring_status
ok		milloling-status
ok		disk-pool-allocation
ok		ownership-state
controller_A_2	controller_A_2_aggr0	mirroring-status
ok		disk-pool-allocation
ok		ownership-state
ok		
	controller_A_2_aggri	mirroring-status
ok		disk-pool-allocation
ok		ownership-state
ok	controller A 2 aggr2	
ok		mirroring-status
ok		disk-pool-allocation
		ownership-state

ok

```
18 entries were displayed.
```

The following example shows the metrocluster check cluster show command output for a healthy four-node MetroCluster configuration. It indicates that the clusters are ready to perform a negotiated switchover if necessary.

```
Last Checked On: 9/13/2017 20:47:04
Cluster
                      Check
                                                     Result
   _____
                                                     _____
mccint-fas9000-0102
                      negotiated-switchover-ready
                                                     not-applicable
                      switchback-ready
                                                     not-applicable
                      job-schedules
                                                     ok
                      licenses
                                                     ok
                     periodic-check-enabled
                                                     ok
mccint-fas9000-0304
                      negotiated-switchover-ready
                                                     not-applicable
                      switchback-ready
                                                     not-applicable
                      job-schedules
                                                     ok
                      licenses
                                                     ok
                     periodic-check-enabled
                                                     ok
10 entries were displayed.
```

Checking for MetroCluster configuration errors with Config Advisor

You can go to the NetApp Support Site and download the Config Advisor tool to check for common configuration errors.

About this task

Config Advisor is a configuration validation and health check tool. You can deploy it at both secure sites and non-secure sites for data collection and system analysis.



Support for Config Advisor is limited, and available only online.

Steps

1. Go to the Config Advisor download page and download the tool.

NetApp Downloads: Config Advisor

Run Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.

Sending a custom AutoSupport message after to adding nodes to the MetroCluster configuration

You should issue an AutoSupport message to notify NetApp technical support that maintenance is complete.

About this task

This task must be performed on each MetroCluster site.

Steps

- 1. Log in to the cluster at Site_A.
- 2. Invoke an AutoSupport message indicating the end of the maintenance:

system node autosupport invoke -node * -type all -message MAINT=end

3. Repeat this step on the partner site.

Verifying switchover, healing, and switchback

You should verify the switchover, healing, and switchback operations of the MetroCluster configuration.

Steps

1. Use the procedures for negotiated switchover, healing, and switchback in MetroCluster management and disaster recovery.

Expanding a MetroCluster IP configuration

Depending on your ONTAP version, you can expand your MetroCluster IP configuration by adding four new nodes as a new DR group.

Beginning with ONTAP 9.13.1, you can temporarily expand an eight-node MetroCluster configuration to refresh the controllers and storage. See Refreshing a four-node or an eight-node MetroCluster IP configuration (ONTAP 9.8 and later) for more information.

Beginning with ONTAP 9.9.1, you can add four new nodes to the MetroCluster IP configuration as a second DR group. This creates an eight-node MetroCluster configuration.

Before you begin

- The old and new nodes must be running the same version of ONTAP.
- This procedure describes the steps required to add one four-node DR group to an existing MetroCluster IP configuration. If you are refreshing an eight-node configuration, you must repeat the entire procedure for each DR group, adding one at a time.
- Verify that the old and new platform models are supported for platform mixing.

NetApp Hardware Universe

• Verify that the old and new platform models are both supported by the IP switches.

NetApp Hardware Universe

- If you are refreshing a four-node or an eight-node MetroCluster IP configuration, the new nodes must have enough storage to accommodate the data of the old nodes, along with adequate disks for root aggregates and spare disks.
- Verify that you have a default broadcast domain created on the old nodes.

When you add new nodes to an existing cluster without a default broadcast domain, node management LIFs are created for the new nodes using universal unique identifiers (UUIDs) instead of the expected names. For more information, see the Knowledge Base article Node management LIFs on newly-added nodes generated with UUID names.

Example naming in this procedure

This procedure uses example names throughout to identify the DR groups, nodes, and switches involved.

DR groups	cluster_A at site_A	cluster_B at site_B
dr_group_1-old	node_A_1-oldnode_A_2-old	node_B_1-oldnode_B_2-old
dr_group_2-new	node_A_3-newnode_A_4-new	node_B_3-newnode_B_4-new

Supported platform combinations when adding a second DR group

The following table shows the supported platform combinations for eight-node IP configurations.

- All nodes in the MetroCluster configuration must be running the same ONTAP version. For example, if you have an eight-node configuration, all eight nodes must be running the same ONTAP version.
- The combinations in this table apply only to regular or permanent 8 node configurations.
- The platform combinations shown in this table **do not** apply if you are using the transition or refresh procedures.
- All nodes in one DR group must be of the same type and configuration.

(i

		8Node DrGroup 2									
		AFF A150 ASA A150	FAS2750 AFF A220	FAS500f AFF C250 ASA C250 AFF A250 ASA A250	FAS8200 AFF A300	AFF A320	FAS8300 AFF C400 ASA C400 AFF A400 ASA A400	FAS8700	FAS9000 AFF A700	AFF C800 ASA C800 AFF A800 ASA A800	FAS9500 AFF A900 ASA A900
	AFF A150										
	ASA A150										
	FAS2750										
	AFF A220										
	FAS500f		Note 2								
	AFF C250										
	ASA C250										
	AFF A250										
	ASA A250										
-	FA58200				Note 1						
	AFF A300										
	EAS8300										
8Node	AFF C400										
DrGroup 1	ASA C400						Note 1				
	AFF A400										
	ASA A400		1								
	FAS8700										
	FAS9000										
	AFF A700										
	AFF C800										
	ASA A800										
	AFF A800									Note 1	
	ASA A800										
	FAS9500										
	AFF A900										
	ASA A900										

- Note 1: ONTAP 9.9.1 or later (or the minimum ONTAP version supported on the platform) is required for these combinations.
- Note 2: ONTAP 9.13.1 or later (or the minimum ONTAP version supported on the platform) is required for these combinations.

Sending a custom AutoSupport message prior to maintenance

Before performing the maintenance, you should issue an AutoSupport message to notify NetApp technical support that maintenance is underway. Informing technical support that maintenance is underway prevents them from opening a case on the assumption that a disruption has occurred.

About this task

This task must be performed on each MetroCluster site.

Steps

- 1. To prevent automatic support case generation, send an Autosupport message to indicate the upgrade is underway.
 - a. Issue the following command:

```
system node autosupport invoke -node * -type all -message "MAINT=10h
Upgrading old-model to new-model"
```

This example specifies a 10 hour maintenance window. You might want to allow additional time, depending on your plan.

If the maintenance is completed before the time has elapsed, you can invoke an AutoSupport message indicating the end of the maintenance period:

system node autosupport invoke -node * -type all -message MAINT=end

b. Repeat the command on the partner cluster.

Verifying the health of the MetroCluster configuration

You must verify the health and connectivity of the MetroCluster configuration prior to performing the transition

Steps

- 1. Verify the operation of the MetroCluster configuration in ONTAP:
 - a. Check whether the system is multipathed:

node run -node node-name sysconfig -a

b. Check for any health alerts on both clusters:

system health alert show

c. Confirm the MetroCluster configuration and that the operational mode is normal:

metrocluster show

d. Perform a MetroCluster check:

metrocluster check run

e. Display the results of the MetroCluster check:

metrocluster check show

f. Run Config Advisor.

NetApp Downloads: Config Advisor

- g. After running Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.
- 2. Verify that the cluster is healthy:

cluster show

3. Verify that all cluster ports are up:

network port show -ipspace Cluster

```
cluster_A::> network port show -ipspace Cluster

Node: node_A_1-old

Port IPspace Broadcast Domain Link MTU Admin/Oper Status

e0a Cluster Cluster up 9000 auto/10000 healthy

e0b Cluster Cluster up 9000 auto/10000 healthy

Node: node_A_2-old

Port IPspace Broadcast Domain Link MTU Admin/Oper Status

e0a Cluster Cluster up 9000 auto/10000 healthy

e0b Cluster Status up 9000 auto/10000 healthy

e0b Cluster Status up 9000 auto/10000 healthy

e0b Cluster Status USA
```

4. Verify that all cluster LIFs are up and operational:

network interface show -vserver Cluster

Each cluster LIF should display true for Is Home and have a Status Admin/Oper of up/up

<pre>cluster_A::> network interface show -vserver cluster</pre>						
	Logical	Status	Network	Current		
Current Is Vserver Home	Interface	Admin/Oper	Address/Mask	Node	Port	
Cluster	node λ 1-0	ld clus1				
	noue_A_1 o	up/up	169.254.209.69/16	node_A_1	e0a	
true	node A 1-o	ld clus2				
h		up/up	169.254.49.125/16	node_A_1	e0b	
true	node_A_2-o	ld_clus1				
true		up/up	169.254.47.194/16	node_A_2	e0a	
01.00	node_A_2-o	ld_clus2 up/up	169.254.19.183/16	node A 2	e0b	
true		1 1				
4 entries were displayed.						
cluster_A::>						

5. Verify that auto-revert is enabled on all cluster LIFs:

network interface show -vserver Cluster -fields auto-revert

```
cluster A::> network interface show -vserver Cluster -fields auto-revert
         Logical
         Interface Auto-revert
Vserver
 _____ ____
Cluster
          node A 1-old clus1
                     true
          node A 1-old clus2
                     true
          node A 2-old clus1
                      true
          node A 2-old clus2
                      true
   4 entries were displayed.
cluster A::>
```

Removing the configuration from monitoring applications

If the existing configuration is monitored with the MetroCluster Tiebreaker software, the ONTAP Mediator or other third-party applications (for example, ClusterLion) that can initiate a switchover, you must remove the MetroCluster configuration from the monitoring software prior to upgrade.

Steps

1. Remove the existing MetroCluster configuration from Tiebreaker, Mediator, or other software that can initiate switchover.

If you are using	Use this procedure	
Tiebreaker	Removing MetroCluster Configurations.	
Mediator	Issue the following command from the ONTAP prompt: metrocluster configuration-settings	
	mediator remove	
Third-party applications	Refer to the product documentation.	

2. Remove the existing MetroCluster configuration from any third-party application that can initiate switchover.

Refer to the documentation for the application.

Preparing the new controller modules

You must prepare the four new MetroCluster nodes and install the correct ONTAP version.

About this task

This task must be performed on each of the new nodes:

- node_A_3-new
- node_A_4-new
- node_B_3-new
- node_B_4-new

In these steps, you clear the configuration on the nodes and clear the mailbox region on new drives.

Steps

- 1. Rack the new controllers.
- 2. Cable the new MetroCluster IP nodes to the IP switches as shown in the *MetroCluster installation and configuration.*

Cabling the IP switches

- 3. Configure the MetroCluster IP nodes using the following sections of the *MetroCluster installation and configuration.*
 - a. Gathering required information
 - b. Restoring system defaults on a controller module
 - c. Verifying the ha-config state of components
 - d. Manually assigning drives for pool 0 (ONTAP 9.4 and later)
- 4. From Maintenance mode, issue the halt command to exit Maintenance mode, and then issue the boot_ontap command to boot the system and get to cluster setup.

Do not complete the cluster wizard or node wizard at this time.

Upgrade RCF files

If you are installing new switch firmware, you must install the switch firmware before upgrading the RCF file.

About this task

This procedure disrupts traffic on the switch where the RCF file is upgraded. Traffic will resume once the new RCF file is applied.

Steps

- 1. Verify the health of the configuration.
 - a. Verify that the MetroCluster components are healthy:

metrocluster check run

cluster A::*> metrocluster check run

The operation runs in the background.

a. After the metrocluster check run operation completes, run metrocluster check show to view the results.

After approximately five minutes, the following results are displayed:

```
_____
::*> metrocluster check show
Component
                Result
_____ ____
nodes
                 ok
lifs
                 ok
config-replication ok
aggregates
               warning
clusters
                 ok
connections
            not-applicable
volumes
                 ok
7 entries were displayed.
```

b. Check the status of the running MetroCluster check operation:

metrocluster operation history show -job-id 38

c. Verify that there are no health alerts:

system health alert show

2. Prepare the IP switches for the application of the new RCF files.

Follow the steps for your switch vendor:

- Resetting the Broadcom IP switch to factory defaults
- Resetting the Cisco IP switch to factory defaults
- 3. Download and install the IP RCF file, depending on your switch vendor.



Update the switches in the following order: Switch_A_1, Switch_B_1, Switch_A_2, Switch_B_2

- Downloading and installing the Broadcom IP RCF files
- Downloading and installing the Cisco IP RCF files

()

If you have an L2 shared or L3 network configuration, you might need to adjust the ISL ports on the intermediate/customer switches. The switchport mode might change from 'access' to 'trunk' mode. Only proceed to upgrade the second switch pair (A_2, B_2) if the network connectivity between switches A_1 and B_1 is fully operational and the network is healthy.

Joining the new nodes to the clusters

You must add the four new MetroCluster IP nodes to the existing MetroCluster configuration.

About this task

You must perform this task on both clusters.

Steps

- 1. Add the new MetroCluster IP nodes to the existing MetroCluster configuration.
 - a. Join the first new MetroCluster IP node (node_A_1-new) to the existing MetroCluster IP configuration.

```
Welcome to the cluster setup wizard.
You can enter the following commands at any time:
  "help" or "?" - if you want to have a question clarified,
  "back" - if you want to change previously answered questions, and
  "exit" or "quit" - if you want to quit the cluster setup wizard.
    Any changes you made before quitting will be saved.
You can return to cluster setup at any time by typing "cluster
setup".
To accept a default or omit a question, do not enter a value.
This system will send event messages and periodic reports to NetApp
Technical
Support. To disable this feature, enter
autosupport modify -support disable
within 24 hours.
Enabling AutoSupport can significantly speed problem determination
and
resolution, should a problem occur on your system.
For further information on AutoSupport, see:
http://support.netapp.com/autosupport/
Type yes to confirm and continue {yes}: yes
Enter the node management interface port [eOM]: 172.17.8.93
172.17.8.93 is not a valid port.
```
```
The physical port that is connected to the node management network.
Examples of
node management ports are "e4a" or "e0M".
You can type "back", "exit", or "help" at any question.
Enter the node management interface port [eOM]:
Enter the node management interface IP address: 172.17.8.93
Enter the node management interface netmask: 255.255.254.0
Enter the node management interface default gateway: 172.17.8.1
A node management interface on port eOM with IP address 172.17.8.93
has been created.
Use your web browser to complete cluster setup by accessing
https://172.17.8.93
Otherwise, press Enter to complete cluster setup using the command
line
interface:
Do you want to create a new cluster or join an existing cluster?
{create, join}:
join
Existing cluster interface configuration found:
Port
       MTU
                               Netmask
               ΙP
              169.254.148.217 255.255.0.0
e0c
       9000
       9000 169.254.144.238 255.255.0.0
e0d
Do you want to use this configuration? {yes, no} [yes]: yes
```

b. Join the second new MetroCluster IP node (node_A_2-new) to the existing MetroCluster IP configuration.

2. Repeat these steps to join node_B_1-new and node_B_2-new to cluster_B.

Configuring intercluster LIFs, creating the MetroCluster interfaces, and mirroring root aggregates

You must create cluster peering LIFs, create the MetroCluster interfaces on the new MetroCluster IP nodes.

About this task

The home port used in the examples are platform-specific. You should use the appropriate home port specific to MetroCluster IP node platform.

Steps

1. On the new MetroCluster IP nodes, configure the intercluster LIFs using the following procedures:

Configuring intercluster LIFs on dedicated ports

Configuring intercluster LIFs on shared data ports

2. On each site, verify that cluster peering is configured:

cluster peer show

The following example shows the cluster peering configuration on cluster_A:

```
cluster_A:> cluster peer show

Peer Cluster Name Cluster Serial Number Availability

Authentication

------

cluster_B 1-80-00011 Available ok
```

The following example shows the cluster peering configuration on cluster_B:

```
cluster_B:> cluster peer show
Peer Cluster Name Cluster Serial Number Availability
Authentication
------
cluster_A 1-80-000011 Available ok
cluster_B::>
```

3. Create the DR group for the MetroCluster IP nodes:

metrocluster configuration-settings dr-group create -partner-cluster

For more information on the MetroCluster configuration settings and connections, see the following:

Considerations for MetroCluster IP configurations

Creating the DR group

```
cluster_A::> metrocluster configuration-settings dr-group create
-partner-cluster
cluster_B -local-node node_A_1-new -remote-node node_B_1-new
[Job 259] Job succeeded: DR Group Create is successful.
cluster_A::>
```

4. Verify that the DR group was created.

metrocluster configuration-settings dr-group show

cluster_A::> metrocluster configuration-settings dr-group show			
DR Group ID Node	Cluster	Node	DR Partner
1	cluster_A		
		node_A_1-old	node_B_1-old
		node_A_2-old	node_B_2-old
	cluster_B		
	_	node B 1-old	node A 1-old
		node B 2-old	node A 2-old
2	cluster A		
	—	node A 1-new	node B 1-new
		node A 2-new	node B 2-new
	cluster B		
	_	node B 1-new	node A 1-new
		node B 2-new	node A 2-new
8 entries were displayed.			
<pre>cluster_A::></pre>			

5. Configure the MetroCluster IP interfaces for the newly joined MetroCluster IP nodes:

metrocluster configuration-settings interface create -cluster-name

- Certain platforms use a VLAN for the MetroCluster IP interface. By default, each of the two ports use a different VLAN: 10 and 20. You can also specify a different (non-default)
 VLAN higher than 100 (between 101 and 4095) using the -vlan-id parameter in the metrocluster configuration-settings interface create command.
- Beginning with ONTAP 9.9.1, if you are using a layer 3 configuration, you must also specify the -gateway parameter when creating MetroCluster IP interfaces. Refer to Considerations for layer 3 wide-area networks.

The following platform models can be added to the existing MetroCluster configuration if the VLANs used

are 10/20 or greater than 100. If any other VLANs are used, then these platforms cannot be added to the existing configuration as the MetroCluster interface cannot be configured. If you are using any other platform, the VLAN configuration is not relevant as this is not required in ONTAP.

AFF platforms	FAS platforms
• AFF A220	• FAS2750
• AFF A250	• FAS500f
• AFF A400	• FAS8300
	• FAS8700



You can configure the MetroCluster IP interfaces from either cluster.

```
cluster A::> metrocluster configuration-settings interface create
-cluster-name cluster A -home-node node A 1-new -home-port ela -address
172.17.26.10 -netmask 255.255.255.0
[Job 260] Job succeeded: Interface Create is successful.
cluster A::> metrocluster configuration-settings interface create
-cluster-name cluster A -home-node node A 1-new -home-port elb -address
172.17.27.10 -netmask 255.255.255.0
[Job 261] Job succeeded: Interface Create is successful.
cluster A::> metrocluster configuration-settings interface create
-cluster-name cluster A -home-node node A 2-new -home-port ela -address
172.17.26.11 -netmask 255.255.255.0
[Job 262] Job succeeded: Interface Create is successful.
cluster A::> :metrocluster configuration-settings interface create
-cluster-name cluster A -home-node node A 2-new -home-port elb -address
172.17.27.11 -netmask 255.255.255.0
[Job 263] Job succeeded: Interface Create is successful.
cluster A::> metrocluster configuration-settings interface create
-cluster-name cluster B -home-node node B 1-new -home-port ela -address
172.17.26.12 -netmask 255.255.255.0
[Job 264] Job succeeded: Interface Create is successful.
cluster A::> metrocluster configuration-settings interface create
-cluster-name cluster B -home-node node B 1-new -home-port elb -address
172.17.27.12 -netmask 255.255.255.0
[Job 265] Job succeeded: Interface Create is successful.
cluster A::> metrocluster configuration-settings interface create
-cluster-name cluster B -home-node node B 2-new -home-port ela -address
172.17.26.13 -netmask 255.255.255.0
[Job 266] Job succeeded: Interface Create is successful.
cluster A::> metrocluster configuration-settings interface create
-cluster-name cluster B -home-node node B 2-new -home-port elb -address
172.17.27.13 -netmask 255.255.255.0
[Job 267] Job succeeded: Interface Create is successful.
```

6. Verify the MetroCluster IP interfaces are created:

metrocluster configuration-settings interface show

cluster_A::>metrocluster configuration-settings interface show

DR Config Group Cluster Node Network Address Netmask Gateway State _____ _____ _____ 1 cluster A node A 1-old Home Port: ela 172.17.26.10 255.255.255.0 completed Home Port: elb 172.17.27.10 255.255.255.0 completed node A 2-old Home Port: ela 172.17.26.11 255.255.255.0 completed Home Port: elb 172.17.27.11 255.255.255.0 completed cluster B node B 1-old Home Port: ela 172.17.26.13 255.255.255.0 completed Home Port: elb 172.17.27.13 255.255.255.0 completed node B 1-old Home Port: ela 172.17.26.12 255.255.255.0 _ completed Home Port: elb 172.17.27.12 255.255.255.0 completed 2 cluster A node A 3-new Home Port: ela 172.17.28.10 255.255.255.0 completed Home Port: elb 172.17.29.10 255.255.255.0 completed node A 3-new

Home Port: ela 172.17.28.11 255.255.255.0 _ completed Home Port: elb 172.17.29.11 255.255.255.0 completed cluster B node B 3-new Home Port: ela 172.17.28.13 255.255.255.0 completed Home Port: elb 172.17.29.13 255.255.255.0 completed node B 3-new Home Port: ela 172.17.28.12 255.255.255.0 completed Home Port: elb 172.17.29.12 255.255.255.0 completed 8 entries were displayed. cluster A>

7. Connect the MetroCluster IP interfaces:

metrocluster configuration-settings connection connect

(i)

This command might take several minutes to complete.

cluster_A::> metrocluster configuration-settings connection connect

cluster_A::>

8. Verify the connections are properly established: metrocluster configuration-settings connection show

```
cluster_A::> metrocluster configuration-settings connection show
DR Source Destination
Group Cluster Node Network Address Network Address Partner Type
Config State
-----
```

1 cluster A node A 1-old Home Port: ela 172.17.28.10 172.17.28.11 HA Partner completed Home Port: ela 172.17.28.10 172.17.28.12 DR Partner completed Home Port: ela 172.17.28.10 172.17.28.13 DR Auxiliary completed Home Port: elb 172.17.29.10 172.17.29.11 HA Partner completed Home Port: elb 172.17.29.10 172.17.29.12 DR Partner completed Home Port: elb 172.17.29.10 172.17.29.13 DR Auxiliary completed node A 2-old Home Port: ela 172.17.28.11 172.17.28.10 HA Partner completed Home Port: ela 172.17.28.11 172.17.28.13 DR Partner completed Home Port: ela 172.17.28.11 172.17.28.12 DR Auxiliary completed Home Port: elb 172.17.29.11 172.17.29.10 HA Partner completed Home Port: elb 172.17.29.11 172.17.29.13 DR Partner completed Home Port: elb 172.17.29.11 172.17.29.12 DR Auxiliary completed DR Source Destination Group Cluster Node Network Address Network Address Partner Type Config State _____ _____ _____ 1 cluster B

node B 2-old Home Port: ela 172.17.28.13 172.17.28.12 HA Partner completed Home Port: ela 172.17.28.13 172.17.28.11 DR Partner completed Home Port: ela 172.17.28.13 172.17.28.10 DR Auxiliary completed Home Port: elb 172.17.29.13 172.17.29.12 HA Partner completed Home Port: elb 172.17.29.13 172.17.29.11 DR Partner completed Home Port: elb 172.17.29.13 172.17.29.10 DR Auxiliary completed node B 1-old Home Port: ela 172.17.28.12 172.17.28.13 HA Partner completed Home Port: ela 172.17.28.12 172.17.28.10 DR Partner completed Home Port: ela 172.17.28.12 172.17.28.11 DR Auxiliary completed Home Port: elb 172.17.29.12 172.17.29.13 HA Partner completed Home Port: elb 172.17.29.12 172.17.29.10 DR Partner completed Home Port: elb 172.17.29.12 172.17.29.11 DR Auxiliary completed DR Source Destination Group Cluster Node Network Address Network Address Partner Type Config State _____ _____ _____ 2 cluster A node A 1-new**

Home Port: ela 172.17.26.10 172.17.26.11 HA Partner completed Home Port: ela 172.17.26.10 172.17.26.12 DR Partner completed Home Port: ela 172.17.26.10 172.17.26.13 DR Auxiliary completed Home Port: elb 172.17.27.10 172.17.27.11 HA Partner completed Home Port: elb 172.17.27.10 172.17.27.12 DR Partner completed Home Port: elb 172.17.27.10 172.17.27.13 DR Auxiliary completed node A 2-new Home Port: ela 172.17.26.11 172.17.26.10 HA Partner completed Home Port: ela 172.17.26.11 172.17.26.13 DR Partner completed Home Port: ela 172.17.26.11 172.17.26.12 DR Auxiliary completed Home Port: elb 172.17.27.11 172.17.27.10 HA Partner completed Home Port: elb 172.17.27.11 172.17.27.13 DR Partner completed Home Port: elb 172.17.27.11 172.17.27.12 DR Auxiliary completed Source DR Destination Group Cluster Node Network Address Network Address Partner Type Config State _____ _____ _____ 2 cluster B node B 2-new Home Port: ela

172.17.26.13 172.17.26.12 HA Partner completed Home Port: ela 172.17.26.13 172.17.26.11 DR Partner completed Home Port: ela 172.17.26.13 172.17.26.10 DR Auxiliary completed Home Port: elb 172.17.27.13 172.17.27.12 HA Partner completed Home Port: elb 172.17.27.13 172.17.27.11 DR Partner completed Home Port: elb 172.17.27.13 172.17.27.10 DR Auxiliary completed node B 1-new Home Port: ela 172.17.26.12 172.17.26.13 HA Partner completed Home Port: ela 172.17.26.12 172.17.26.10 DR Partner completed Home Port: ela 172.17.26.12 DR Auxiliary 172.17.26.11 completed Home Port: elb 172.17.27.12 172.17.27.13 HA Partner completed Home Port: elb 172.17.27.12 172.17.27.10 DR Partner completed Home Port: elb 172.17.27.12 172.17.27.11 DR Auxiliary completed 48 entries were displayed. cluster A::>

9. Verify disk auto-assignment and partitioning:

disk show -pool Pool1

cluster_A::> disk	show -pool	Pool1	L	Diek	Container	Container
Disk	Size S	helf	Bav	Type	Type	Name
Owner	0110 0		201	-150	- 7 - 0	
1.10.4	_	10	4	SAS	remote	-
node_B_2						
1.10.13	-	10	13	SAS	remote	-
node_B_2						
1.10.14	-	10	14	SAS	remote	-
node_B_1						
1.10.15	-	10	15	SAS	remote	-
node_B_1						
1.10.16	-	10	16	SAS	remote	-
node_B_1		1.0	1.0	~ ~ ~		
1.10.18	_	10	18	SAS	remote	-
··· 2 20 0	546 9CB	20	0	SZS	adareaate	aggr(rhal al
2.20.0	340.JOD	20	0	SAS	aggregate	aggro_inai_ai
2.20.3	546.9GB	20	З	SAS	aggregate	aggr0 rhal a2
node a 2	010.302	20	0	0110	aggregaee	aggro_mar_az
2.20.5	546.9GB	20	5	SAS	aggregate	rhal al aggrl
node a 1						
2.20.6	546.9GB	20	6	SAS	aggregate	rhal al aggrl
node_a_1						
2.20.7	546.9GB	20	7	SAS	aggregate	rha1_a2_aggr1
node_a_2						
2.20.10	546.9GB	20	10	SAS	aggregate	rhal_al_aggrl
node_a_1						
•••						
43 entries were di	splayed.					
cluster_A::>						

10. Mirror the root aggregates:

storage aggregate mirror -aggregate aggr0_node_A_1-new



You must complete this step on each MetroCluster IP node.

```
cluster A::> aggr mirror -aggregate aggr0 node A 1-new
Info: Disks would be added to aggregate "aggr0_node_A_1-new"on node
"node A 1-new"
    in the following manner:
    Second Plex
      RAID Group rg0, 3 disks (block checksum, raid_dp)
                                                 Usable
Physical
        Position Disk
                                       Туре
                                                  Size
Size
        _____ ____
_____
       dparity 4.20.0
                                      SAS
       parity 4.20.3
                                  SAS
       data 4.20.1
                               SAS 546.9GB
558.9GB
    Aggregate capacity available forvolume use would be 467.6GB.
Do you want to continue? {y|n}: y
cluster A::>
```

11. Verify that the root aggregates are mirrored:

storage aggregate show

aggr0_node_A_2-old 349.0GB 16.84GB 95% online 1 node_A_2-old raid dp, mirrored, normal aggr0_node_A_1-new 467.6GB 22.63GB 95% online 1 node A 1-new raid dp, mirrored, normal aggr0_node A_2-new 467.6GB 22.62GB 95% online 1 node A 2-new raid dp, mirrored, normal aggr_data_a1 1.02TB 1.01TB 1% online 1 node A 1-old raid dp, mirrored, normal aggr data a2 1.02TB 1.01TB 1% online 1 node A 2-old raid dp, mirrored,

Finalizing the addition of the new nodes

You must incorporate the new DR group into the MetroCluster configuration and create mirrored data aggregates on the new nodes.

Steps

- 1. Refresh the MetroCluster configuration:
 - a. Enter advanced privilege mode:

set -privilege advanced

b. Refresh the MetroCluster configuration on one of the new nodes:

```
metrocluster configure
```

The following example shows the MetroCluster configuration refreshed on both DR groups:

cluster_A::*> metrocluster configure -refresh true

[Job 726] Job succeeded: Configure is successful.

c. Reboot each of the new nodes:

node reboot -node <node name> -inhibit-takeover true

d. Return to admin privilege mode:

set -privilege admin

2. Create mirrored data aggregates on each of the new MetroCluster nodes:

```
storage aggregate create -aggregate aggregate-name -node node-name -diskcount
no-of-disks -mirror true
```



You must create at least one mirrored data aggregate per site. It is recommended to have two mirrored data aggregates per site on MetroCluster IP nodes to host the MDV volumes, however a single aggregate per site is supported (but not recommended). It is support that one site of the MetroCluster has a single mirrored data aggregate and the other site has more than one mirrored data aggregate.

The following example shows the creation of an aggregate on node_A_1-new.

```
cluster A::> storage aggregate create -aggregate data a3 -node node A 1-
new -diskcount 10 -mirror t
Info: The layout for aggregate "data a3" on node "node A 1-new" would
be:
      First Plex
       RAID Group rg0, 5 disks (block checksum, raid dp)
                                                            Usable
Physical
         Position Disk
                                                             Size
                                               Type
Size
          dparity 5.10.15
                                               SAS
         parity 5.10.16
                                               SAS
```

547.1GB	data	5.10.17	SAS	546.9GB
558 9CB	data	5.10.18	SAS	546.9GB
558.9GB	data	5.10.19	SAS	546.9GB
Sec	cond Plex			
F	RAID Group r	g0, 5 disks (block checksu	um, raid_dp)	Usable
Physical	Position	Disk	Туре	Size
_	dparity	4.20.17	SAS	-
_	parity	4.20.14	SAS	-
547 1CB	data	4.20.18	SAS	546.9GB
547 1CB	data	4.20.19	SAS	546.9GB
547.1GB	data	4.20.16	SAS	546.9GB
Aggregate capacity available for volume use would be 1.37TB.				
Do you want to continue? {y n}: y [Job 440] Job succeeded: DONE				
cluster_A::>				

3. Verify that the nodes are added to their DR group.

cluster_A::*> metrocluster node show					
DR Group	Cluster	Node 	Configuration State	DR Mirroring 	Mode
1	cluster	A			
		node_A_1-old	configured	enabled	normal
		node_A_2-old	configured	enabled	normal
	cluster	_B			
		node_B_1-old	configured	enabled	normal
		node_B_2-old	configured	enabled	normal
2	cluster	_A			
		node_A_3-new	configured	enabled	normal
		node_A_4-new	configured	enabled	normal
	cluster	_B			
		node_B_3-new	configured	enabled	normal
		node_B_4-new	configured	enabled	normal
8 entries were displayed.					
cluster_A::*>					

- 4. Move the MDV_CRS volumes from the old nodes to the new nodes in advanced privilege.
 - a. Display the volumes to identify the MDV volumes:



If you have a single mirrored data aggregate per site then move both the MDV volumes to this single aggregate. If you have two or more mirrored data aggregates, then move each MDV volume to a different aggregate.

The following example shows the MDV volumes in the volume show output:

cluster A::> volume show Vserver Volume Aggregate State Type Size Available Used% ----- ---- -----_____ ___ . . . cluster A MDV CRS 2c78e009ff5611e9b0f300a0985ef8c4 A aggr bl -RW cluster A MDV CRS 2c78e009ff5611e9b0f300a0985ef8c4 B aggr b2 RW _ cluster A MDV CRS d6b0b313ff5611e9837100a098544e51 A aggr_a1 online RW 10GB 9.50GB 0% cluster A MDV CRS d6b0b313ff5611e9837100a098544e51 B aggr a2 online RW 10GB 9.50GB 0% . . . 11 entries were displayed.mple

b. Set the advanced privilege level:

set -privilege advanced

c. Move the MDV volumes, one at a time:

volume move start -volume mdv-volume -destination-aggregate aggr-on-new-node
-vserver vserver-name

The following example shows the command and output for moving "MDV_CRS_d6b0b313ff5611e9837100a098544e51_A" to aggregate "data_a3" on "node_A_3".

d. Use the volume show command to check that the MDV volume has been successfully moved:

volume show *mdv-name*

The following output shows that the MDV volume has been successfully moved.

- 5. Move epsilon from an old node to a new node:
 - a. Identify which node currently has epsilon:

```
cluster show -fields epsilon
```

```
cluster_B::*> cluster show -fields epsilon
node epsilon
------
node_A_1-old true
node_A_2-old false
node_A_3-new false
node_A_4-new false
4 entries were displayed.
```

b. Set epsilon to false on the old node (node_A_1-old):

cluster modify -node old-node -epsilon false*

c. Set epsilon to true on the new node (node_A_3-new):

```
cluster modify -node new-node -epsilon true
```

d. Verify that epsilon has moved to the correct node:

```
cluster show -fields epsilon
```

```
cluster_A::*> cluster show -fields epsilon
node epsilon
-------
node_A_1-old false
node_A_2-old false
node_A_3-new true
node_A_4-new false
4 entries were displayed.
```

Removing a Disaster Recovery group

Beginning with ONTAP 9.8, you can remove a DR group from an eight-node MetroCluster configuration to create a four-node MetroCluster configuration.

This procedure is supported on ONTAP 9.8 and later. For systems running ONTAP 9.7 or earlier, see the Knowledge Base article

How to remove a DR group from a MetroCluster configuration

NetApp Support

An eight-node configuration includes eight-nodes organized as two four-node DR groups.



By removing a DR Group, four nodes remain in the configuration.



Removing the DR group nodes from each cluster

Before you begin

- You must perform this step on both clusters.
- The metrocluster remove-dr-group command is supported only on ONTAP 9.8 and later.

Steps

- 1. Prepare for the removal of the DR group, if you haven't already.
 - a. Move all data volumes to another DR group.
 - b. If the DR group to be removed contains load-sharing mirror volumes, they cannot be moved. Re-create all load-sharing mirror volumes in another DR group and then delete the load-sharing mirror volumes in the DR group to be removed.
 - c. Move all MDV_CRS metadata volumes to another DR group by following the Moving a metadata volume in MetroCluster configurations procedure.
 - d. Delete all MDV_aud metadata volumes that might exist in the DR group to be removed.
 - e. Delete all data aggregates in the DR group to be removed as shown in the following example:

```
ClusterA::> storage aggregate show -node ClusterA-01, ClusterA-02
-fields aggregate ,node
ClusterA::> aggr delete -aggregate aggregate_name
ClusterB::> storage aggregate show -node ClusterB-01, ClusterB-02
-fields aggregate ,node
ClusterB::> aggr delete -aggregate aggregate name
```



Root aggregates are not deleted.

- f. Move the data LIFs offline. network interface modify -vserver svm-name -lif data-lif -status-admin down
- g. Migrate all data LIFs to home nodes in another DR group. network interface show -home-node *old_node*

```
network interface modify -vserver svm-name -lif data-lif -home-node new_node
-home-port port-id
```

- h. Move the data LIFs back online. network interface modify -vserver svm-name -lif data-lif -status-admin up
- i. Migrate the cluster management LIF to a home node in another DR group.

network interface show -role cluster-mgmt

network interface modify -vserver svm-name -lif cluster_mgmt -home-node
new_node -home-port port-id

Node management and inter-cluster LIFs are not migrated.

j. Transfer epsilon to a node in another DR group if required.

```
ClusterA::> set advanced
ClusterA::*> cluster show
Move epsilon if needed
ClusterA::*> cluster modify -node nodename -epsilon false
ClusterA::*> cluster modify -node nodename -epsilon true
ClusterB::> set advanced
ClusterB::*> cluster show
ClusterB::*> cluster modify -node nodename -epsilon false
ClusterB::*> cluster modify -node nodename -epsilon false
ClusterB::*> set admin
```

- 2. Identify and remove the DR group.
 - a. Identify the correct DR group for removal:

metrocluster node show

b. Remove the DR group nodes: metrocluster remove-dr-group -dr-group-id 1

The following example shows the removal of the DR group configuration on cluster_A.

```
cluster A::*>
Warning: Nodes in the DR group that are removed from the MetroCluster
         configuration will lose their disaster recovery protection.
         Local nodes "node A 1-FC, node A 2-FC"will be removed from
the
         MetroCluster configuration. You must repeat the operation on
the
         partner cluster "cluster B"to remove the remote nodes in the
DR group.
Do you want to continue? \{y|n\}: y
Info: The following preparation steps must be completed on the local
and partner
      clusters before removing a DR group.
      1. Move all data volumes to another DR group.
      2. Move all MDV CRS metadata volumes to another DR group.
      3. Delete all MDV aud metadata volumes that may exist in the DR
group to
      be removed.
      4. Delete all data aggregates in the DR group to be removed.
Root
      aggregates are not deleted.
      5. Migrate all data LIFs to home nodes in another DR group.
      6. Migrate the cluster management LIF to a home node in another
DR group.
      Node management and inter-cluster LIFs are not migrated.
      7. Transfer epsilon to a node in another DR group.
      The command is vetoed if the preparation steps are not
completed on the
      local and partner clusters.
Do you want to continue? \{y|n\}: y
[Job 513] Job succeeded: Remove DR Group is successful.
cluster A::*>
```

- 3. Repeat the previous step on the partner cluster.
- If in a MetroCluster IP configuration, remove the MetroCluster connections on the nodes of the old DR group.

These commands can be issued from either cluster and apply to the entire DR group spanning both the clusters.

a. Disconnect the connections:

metrocluster configuration-settings connection disconnect dr-group-id

b. Delete the MetroCluster interfaces on the nodes of the old DR group:

metrocluster configuration-settings interface delete

- C. Delete the old DR group's configuration. metrocluster configuration-settings dr-group delete
- 5. Unjoin the nodes in the old DR group.

You must perform this step on each cluster.

a. Set the advanced privilege level:

set -privilege advanced

b. Disable the storage failover:

storage failover modify -node node-name -enable false

C. Unjoin the node: cluster unjoin -node node-name

Repeat this step for the other local node in the old DR group.

- d. Set the admin privilege level: set -privilege admin
- 6. Re-enable cluster HA in the new DR group:

cluster ha modify -configured true

You must perform this step on each cluster.

7. Halt, power down, and remove the old controller modules and storage shelves.

Where to find additional information

You can learn more about MetroCluster configuration and operation.

MetroCluster and miscellaneous information

Information	Subject	
MetroCluster Documentation	All MetroCluster information	

Fabric-attached MetroCluster installation and configuration	 Fabric-attached MetroCluster architecture Cabling the configuration Configuring the FC-to-SAS bridges Configuring the FC switches Configuring the MetroCluster in ONTAP
Stretch MetroCluster installation and configuration	 Stretch MetroCluster architecture Cabling the configuration Configuring the FC-to-SAS bridges Configuring the MetroCluster in ONTAP
MetroCluster management and disaster recovery	 Understanding the MetroCluster configuration Switchover, healing and switchback Disaster recovery
Maintain MetroCluster Components	 Guidelines for maintenance in a MetroCluster FC configuration Hardware replacement or upgrade and firmware upgrade procedures for FC-to-SAS bridges and FC switches Hot-adding a disk shelf in a fabric-attached or stretch MetroCluster FC configuration Hot-removing a disk shelf in a fabric-attached or stretch MetroCluster FC configuration Replacing hardware at a disaster site in a fabric-attached or stretch MetroCluster FC configuration Expanding a two-node fabric-attached or stretch MetroCluster FC configuration to a four-node MetroCluster FC configuration. Expanding a four-node fabric-attached or stretch MetroCluster FC configuration.
MetroCluster Upgrade, Transition, and Expansion	 Upgrading or refreshing a MetroCluster configuration Transitioning from a MetroCluster FC configuration to a MetroCluster IP configuration Expanding a MetroCluster configuration by adding additional nodes
MetroCluster Tiebreaker Software installation and configuration	Monitoring the MetroCluster configuration with the MetroCluster Tiebreaker software

ONTAP Hardware Systems Documentation		 Hot-adding a disk shelf 	
i	The standard storage shelf maintenance procedures can be used with MetroCluster IP configurations.	 Hot-removing a disk shelf 	
Copy-based transition		 Transitioning data from 7-Mode storage systems to clustered storage systems 	
ONTAP concepts		 How mirrored aggregates work 	

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.