



Configure the software

Install and maintain

NetApp
February 20, 2026

Table of Contents

- Configure the software 1
 - Software install workflow for Cisco Nexus 9336C-FX2 shared switches 1
 - Configure Cisco Nexus 9336C-FX2 shared switches 1
 - Prepare to install NX-OS software and RCF 4
 - Install the NX-OS software 13
 - Review requirements 13
 - Install the software 14
 - Install the Reference Configuration File (RCF) 40
 - Step 1: Install the RCF on the switches 41
 - Step 2: Verify the switch connections 43
 - Step 3: Set up your ONTAP cluster 49
 - Upgrade your reference configuration file (RCF) 49
 - Step 1: Prepare for the upgrade 50
 - Step 2: Configure ports 57
 - Step 3: Verify the cluster network configuration and cluster health 68
 - Reset the 9336C-FX2 shared switch to factory defaults 79

Configure the software

Software install workflow for Cisco Nexus 9336C-FX2 shared switches

To install and configure software for a Cisco Nexus 9336C-FX2 shared switch, follow these steps:

1

Configure the switch

Configure the 9336C-FX2 shared switch.

2

Prepare to install the NX-OS software and RCF

The Cisco NX-OS software and reference configuration files (RCFs) must be installed on Cisco 9336C-FX2 shared switches.

3

Install or upgrade the NX-OS software

Download and install or upgrade the NX-OS software on the Cisco 9336C-FX2 shared switch.

4

Install the RCF

Install the RCF after setting up the Cisco 9336C-FX2 shared switch for the first time.

5

Upgrade your RCF

Upgrade your RCF version when you have an existing version of the RCF file installed on your operational switches.

6

Reset the switch to factory defaults

Erase the 9336C-FX2 shared switch settings.

Configure Cisco Nexus 9336C-FX2 shared switches

Follow these instructions to configure Cisco Nexus 9336C-FX2 shared switches.

Before you begin

Make sure you have the following:

- Required shared switch documentation, controller documentation and ONTAP documentation. See [Documentation requirements for Cisco Nexus 9336C-FX2 shared switches](#) and [NetApp ONTAP documentation](#).
- Applicable licenses, network and configuration information, and cables.

- Completed cabling worksheets. See [Complete the Cisco Nexus 9336C-FX2 cabling worksheet](#). For more information on cabling, refer to the [Hardware Universe](#).

Steps

1. Perform an initial configuration of the switches.

For configuration, you need the appropriate number and type of cables and cable connectors for your switches.

Depending on the type of switch you are initially configuring, you need to connect to the switch console port with the included console cable; you also need to provide specific network information.

2. Boot the switch.

Provide the applicable responses to the following initial setup questions when you first boot the switch.

Your site's security policy defines the responses and services to enable.

- a. Abort Auto Provisioning and continue with normal setup? (yes/no)

Respond with **yes**. The default is no.

- b. Do you want to enforce secure password standard? (yes/no)

Respond with **yes**. The default is yes.

- c. Enter the password for admin.

The default password is admin; you must create a new, strong password.

A weak password can be rejected.

- d. Would you like to enter the basic configuration dialog? (yes/no)

Respond with **yes** at the initial configuration of the switch.

- e. Create another login account? (yes/no)

Your answer depends on your site's policies on alternate administrators. The default is no.

- f. Configure read-only SNMP community string? (yes/no)

Respond with **no**. The default is no.

- g. Configure read-write SNMP community string? (yes/no)

Respond with **no**. The default is no.

- h. Enter the switch name.

The switch name is limited to 63 alphanumeric characters.

- i. Continue with out-of-band (mgmt0) management configuration? (yes/no)

Respond with **yes** (the default) at that prompt. At the mgmt0 IPv4 address: prompt, enter your IP address: ip_address

j. Configure the default-gateway? (yes/no)

Respond with **yes**. At the IPv4 address of the default-gateway: prompt, enter your default_gateway.

k. Configure advanced IP options? (yes/no)

Respond with **no**. The default is no.

l. Enable the telnet service? (yes/no)

Respond with **no**. The default is no.

m. Enable SSH service? (yes/no)

Respond with **yes**. The default is yes.



SSH is recommended when using Ethernet Switch Health Monitor (CSHM) for its log collection features. SSHv2 is also recommended for enhanced security.

n. Enter the type of SSH key you want to generate (dsa/rsa/rsa1). The default is rsa.

o. Enter the number of key bits (1024- 2048).

p. Configure the NTP server? (yes/no)

Respond with **no**. The default is no.

q. Configure default interface layer (L3/L2):

Respond with **L2**. The default is L2.

r. Configure default switch port interface state (shut/noshut):

Respond with **noshut**. The default is noshut.

s. Configure CoPP system profile (strict/moderate/lenient/dense):

Respond with **strict**. The default is strict.

t. Would you like to edit the configuration? (yes/no)

You should see the new configuration at this point. Review and make any necessary changes to the configuration you just entered. Respond with no at the prompt if you are satisfied with the configuration. Respond with **yes** if you want to edit your configuration settings.

u. Use this configuration and save it? (yes/no)

Respond with **yes** to save the configuration. This automatically updates the kickstart and system images.

3. Verify the configuration choices you made in the display that appears at the end of the setup, and make sure that you save the configuration.



If you do not save the configuration at this stage, none of the changes will be in effect the next time you reboot the switch.

4. Check the version on the cluster network switches, and if necessary, download the NetApp-supported version of the software to the switches from the [Cisco software download](#) page.

What's next?

After you've configured your switches, you can [prepare to install NX-OS and RCF](#).

Prepare to install NX-OS software and RCF

Before you install the NX-OS software and the Reference Configuration File (RCF), follow this procedure.

Suggested documentation

- [Cisco Ethernet switch page](#)

Consult the switch compatibility table for the supported ONTAP and NX-OS versions.

- [Software Upgrade and downgrade guides](#)

Refer to the appropriate software and upgrade guides available on the Cisco website for complete documentation on the Cisco switch upgrade and downgrade procedures.

- [Cisco Nexus 9000 and 3000 Upgrade and ISSU Matrix](#)

Provides information on Disruptive Upgrade/Downgrade for Cisco NX-OS software on Nexus 9000 Series Switches based on your current and target releases.

On the page, select **Disruptive Upgrade** and select your current release and target release from the dropdown list.

About the examples

The examples in this procedure use the following switch and node nomenclature:

- The names of the two Cisco switches are cs1 and cs2.
- The node names are cluster1-01 and cluster1-02.
- The cluster LIF names are cluster1-01_clus1 and cluster1-01_clus2 for cluster1-01 and cluster1-02_clus1 and cluster1-02_clus2 for cluster1-02.
- The `cluster1::*>` prompt indicates the name of the cluster.

About this task

The procedure requires the use of both ONTAP commands and Cisco Nexus 9000 Series Switches commands; ONTAP commands are used unless otherwise indicated.

Steps

1. If AutoSupport is enabled on this cluster, suppress automatic case creation by invoking an AutoSupport message: `system node autosupport invoke -node * -type all -message MAINT=x h`

where x is the duration of the maintenance window in hours.



The AutoSupport message notifies technical support of this maintenance task so that automatic case creation is suppressed during the maintenance window.

2. Change the privilege level to advanced, entering **y** when prompted to continue:

```
set -privilege advanced
```

The advanced prompt (***>**) appears.

3. Display how many cluster interconnect interfaces are configured in each node for each cluster interconnect switch:

```
network device-discovery show -protocol cdp
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp

Node/          Local  Discovered
Protocol      Port   Device (LLDP: ChassisID)  Interface
Platform
-----
-----
cluster1-02/cdp
              e0a    cs1                      Eth1/2      N9K-
C9336C
              e0b    cs2                      Eth1/2      N9K-
C9336C
cluster1-01/cdp
              e0a    cs1                      Eth1/1      N9K-
C9336C
              e0b    cs2                      Eth1/1      N9K-
C9336C
.
.
```

4. Check the administrative or operational status of each cluster interface and each node storage port and storage shelf port.

a. Display the network port attributes:

```
network port show -ipspace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster
```

```
Node: cluster1-02
```

Health						Speed (Mbps)
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status						
-----	-----	-----	-----	-----	-----	-----

e0a	Cluster	Cluster		up	9000	auto/10000
healthy						
e0b	Cluster	Cluster		up	9000	auto/10000
healthy						

```
Node: cluster1-01
```

Health						Speed (Mbps)
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status						
-----	-----	-----	-----	-----	-----	-----

e0a	Cluster	Cluster		up	9000	auto/10000
healthy						
e0b	Cluster	Cluster		up	9000	auto/10000
healthy						
.						
.						

b. Display information about the LIFs:

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*> network interface show -vserver Cluster
```

Current Vserver Port	Logical Current Interface Home	Is	Status Admin/Oper	Network Address/Mask	Node
Cluster	cluster1-01_e0a	clus1 true	up/up	169.254.209.69/16	
cluster1-01	cluster1-01_e0b	clus2 true	up/up	169.254.49.125/16	
cluster1-01	cluster1-02_e0a	clus1 true	up/up	169.254.47.194/16	
cluster1-02	cluster1-02_e0b	clus2 true	up/up	169.254.19.183/16	
cluster1-02					
.					
.					

c. Verify that all the node storage ports are up with a healthy status:

```
storage port show -port-type ENET
```

Show example

```
cluster1::*> storage port show -port-type ENET
```

Node	Port	Type	Mode	Speed (Gb/s)	State	Status

cluster1-01	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
cluster1-02	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
.						
.						

- d. Verify that all the storage shelf ports are up with a healthy status:

```
storage shelf port show
```

Show example

```
cluster1::> storage shelf port show
```

Shelf ID	Module	State	Internal?

1.4			
0	A	connected	false
1	A	connected	false
2	B	connected	false
3	B	connected	false
.			
.			

- e. Verify that the switches are being monitored.

```
system switch ethernet show
```

Show example

```
cluster1::*> system switch ethernet show
Switch                               Type                               Address
Model
-----
s1
                                     storage-network                    10.228.143.216
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXB
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

s2
                                     storage-network                    10.228.143.219
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXC
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.6(2)
  Version Source: CDP/ISDP

cs1
                                     cluster-network                    10.228.184.39
N9K-C9336C-FX2
  Serial Number: FLMXXXXXXXXJ
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

cs2
                                     cluster-network                    10.228.184.40
N9K-C9336C-FX2
```

```
Serial Number: FLMXXXXXXXXG
  Is Monitored: true
    Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                  10.6(2)
Version Source: CDP/ISDP
```

5. Verify the connectivity of the remote cluster interfaces:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```

NOTE: Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show
```

Packet	Source	Destination
Node	Date	LIF
Loss		
-----	-----	-----
node1		
3/5/2022 19:21:18 -06:00	cluster1-01_clus2	cluster1-02-
clus1 none		
3/5/2022 19:21:20 -06:00	cluster1-01_clus2	cluster1-
02_clus2 none		
node2		
3/5/2022 19:21:18 -06:00	cluster1-02_clus2	cluster1-
01_clus1 none		
3/5/2022 19:21:20 -06:00	cluster1-02_clus2	cluster1-
01_clus2 none		

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster1::*> cluster ping-cluster -node local
Host is cluster1-02
Getting addresses from network interface table...
Cluster cluster1-01_clus1 169.254.209.69 cluster1-01 e0a
Cluster cluster1-01_clus2 169.254.49.125 cluster1-01 e0b
Cluster cluster1-02_clus1 169.254.47.194 cluster1-02 e0a
Cluster cluster1-02_clus2 169.254.19.183 cluster1-02 e0b
Local = 169.254.47.194 169.254.19.183
Remote = 169.254.209.69 169.254.49.125
Cluster Vserver Id = 4294967293
Ping status:

Basic connectivity succeeds on 4 path(s)
Basic connectivity fails on 0 path(s)

Detected 9000 byte MTU on 4 path(s):
    Local 169.254.19.183 to Remote 169.254.209.69
    Local 169.254.19.183 to Remote 169.254.49.125
    Local 169.254.47.194 to Remote 169.254.209.69
    Local 169.254.47.194 to Remote 169.254.49.125
Larger than PMTU communication succeeds on 4 path(s)
RPC status:
2 paths up, 0 paths down (tcp check)
2 paths up, 0 paths down (udp check)

```

6. Verify that the auto-revert command is enabled on all cluster LIFs:

```
network interface show -vserver Cluster -fields auto-revert
```

Show example

```
cluster1::*> network interface show -vserver Cluster -fields auto-revert
```

Vserver	Logical Interface	Auto-revert
Cluster	cluster1-01_clus1	true
	cluster1-01_clus2	true
	cluster1-02_clus1	true
	cluster1-02_clus2	true

What's next?

After you've prepared to install the NX-OS software and RCF, you can [install the NX-OS software](#).

Install the NX-OS software

Follow this procedure to install the NX-OS software on the Nexus 9336C-FX2 shared switch.

Before you begin, complete the procedure in [Prepare to install NX-OS and RCF](#).

Review requirements

Before you begin

Make sure you have the following:

- A current backup of the switch configuration.
- A fully functioning cluster (no errors in the logs or similar issues).

Suggested documentation

- [Cisco Ethernet switch page](#)

Consult the switch compatibility table for the supported ONTAP and NX-OS versions.

- [Software Upgrade and downgrade guides](#)

Refer to the appropriate software and upgrade guides available on the Cisco website for complete documentation on the Cisco switch upgrade and downgrade procedures.

- [Cisco Nexus 9000 and 3000 Upgrade and ISSU Matrix](#)

Provides information on Disruptive Upgrade/Downgrade for Cisco NX-OS software on Nexus 9000 Series Switches based on your current and target releases.

On the page, select **Disruptive Upgrade** and select your current release and target release from the dropdown list.

About the examples

The examples in this procedure use the following switch and node nomenclature:

- The names of the two Cisco switches are cs1 and cs2.
- The node names are cluster1-01, cluster1-02, cluster1-03, and cluster1-04.
- The cluster LIF names are cluster1-01_clus1, cluster1-01_clus2, cluster1-02_clus1, cluster1-02_clus2 , cluster1-03_clus1, cluster1-03_clus2, cluster1-04_clus1, and cluster1-04_clus2.
- The `cluster1::*>` prompt indicates the name of the cluster.

Install the software

The procedure requires the use of both ONTAP commands and Cisco Nexus 9000 Series Switches commands; ONTAP commands are used unless otherwise indicated.

Steps

1. Connect the cluster switch to the management network.
2. Use the `ping` command to verify connectivity to the server hosting the NX-OS software and the RCF.

Show example

This example verifies that the switch can reach the server at IP address 172.19.2.1:

```
cs2# ping 172.19.2.1 VRF management
Pinging 172.19.2.1 with 0 bytes of data:

Reply From 172.19.2.1: icmp_seq = 0. time= 5910 usec.
```

3. Display the cluster ports on each node that are connected to the cluster switches:

```
network device-discovery show
```

Show example

```
cluster1::*> network device-discovery show
Node/          Local  Discovered
Protocol      Port   Device (LLDP: ChassisID)  Interface
Platform
-----
-----
cluster1-01/cdp
              e0a    cs1                      Ethernet1/7      N9K-
C9336C-FX2
              e0d    cs2                      Ethernet1/7      N9K-
C9336C-FX2
cluster1-02/cdp
              e0a    cs1                      Ethernet1/8      N9K-
C9336C-FX2
              e0d    cs2                      Ethernet1/8      N9K-
C9336C-FX2
cluster1-03/cdp
              e0a    cs1                      Ethernet1/1/1    N9K-
C9336C-FX2
              e0b    cs2                      Ethernet1/1/1    N9K-
C9336C-FX2
cluster1-04/cdp
              e0a    cs1                      Ethernet1/1/2    N9K-
C9336C-FX2
              e0b    cs2                      Ethernet1/1/2    N9K-
C9336C-FX2
```

4. Check the administrative and operational status of each cluster port, node storage port, and storage shelf port.
 - a. Verify that all the cluster ports are **up** with a healthy status:

```
network port show -ipospace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster

Node: cluster1-01

Ignore

Health      Health
Port        IPspace    Broadcast Domain Link MTU  Admin/Oper
Status      Status
-----
e0a         Cluster    Cluster    up    9000  auto/100000
healthy    false
e0d         Cluster    Cluster    up    9000  auto/100000
healthy    false

Node: cluster1-02

Ignore

Health      Health
Port        IPspace    Broadcast Domain Link MTU  Admin/Oper
Status      Status
-----
e0a         Cluster    Cluster    up    9000  auto/100000
healthy    false
e0d         Cluster    Cluster    up    9000  auto/100000
healthy    false
8 entries were displayed.

Node: cluster1-03

Ignore

Health      Health
Port        IPspace    Broadcast Domain Link MTU  Admin/Oper
Status      Status
-----
e0a         Cluster    Cluster    up    9000  auto/10000
healthy    false
e0b         Cluster    Cluster    up    9000  auto/10000
healthy    false
```

Node: cluster1-04

Ignore

Health	Health					Speed (Mbps)
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status	Status					
e0a	Cluster	Cluster		up	9000	auto/10000
healthy	false					
e0b	Cluster	Cluster		up	9000	auto/10000
healthy	false					

b. Verify that all the cluster interfaces (LIFs) are on the home port:

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*> network interface show -vserver Cluster
```

Current	Logical	Status	Network	
Vserver	Current Is			
Port	Interface	Admin/Oper	Address/Mask	Node
Home				
Cluster				
cluster1-01	cluster1-01_clus1	up/up	169.254.3.4/23	
	e0a true			
cluster1-01	cluster1-01_clus2	up/up	169.254.3.5/23	
	e0d true			
cluster1-02	cluster1-02_clus1	up/up	169.254.3.8/23	
	e0a true			
cluster1-02	cluster1-02_clus2	up/up	169.254.3.9/23	
	e0d true			
cluster1-03	cluster1-03_clus1	up/up	169.254.1.3/23	
	e0a true			
cluster1-03	cluster1-03_clus2	up/up	169.254.1.1/23	
	e0b true			
cluster1-04	cluster1-04_clus1	up/up	169.254.1.6/23	
	e0a true			
cluster1-04	cluster1-04_clus2	up/up	169.254.1.7/23	
	e0b true			

c. Verify that all the node storage ports are up with a healthy status:

```
storage port show -port-type ENET
```

Show example

```
cluster1::*> storage port show -port-type ENET
```

Node	Port	Type	Mode	Speed (Gb/s)	State	Status

cluster1-01	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
cluster1-02	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
.						
.						

- d. Verify that all the storage shelf ports are up with a healthy status:

```
storage shelf port show
```

Show example

```
cluster1::> storage shelf port show
```

Shelf	ID	Module	State	Internal?

1.4				
	0	A	connected	false
	1	A	connected	false
	2	B	connected	false
	3	B	connected	false
.				
.				

- e. Verify that the switches are being monitored.

```
system switch ethernet show
```

Show example

```
cluster1::*> system switch ethernet show
Switch                               Type                               Address
Model
-----
s1
                                     storage-network                    10.228.143.216
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXB
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

s2
                                     storage-network                    10.228.143.219
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXC
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.6(2)
  Version Source: CDP/ISDP

cs1
                                     cluster-network                    10.228.184.39
N9K-C9336C-FX2
  Serial Number: FLMXXXXXXXXJ
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

cs2
                                     cluster-network                    10.228.184.40
N9K-C9336C-FX2
```

```
Serial Number: FLMXXXXXXXXG
Is Monitored: true
Reason: None
Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                10.6(2)
Version Source: CDP/ISDP
```

5. Disable auto-revert on the cluster LIFs. The cluster LIFs fail over to the partner cluster switch and remain there as you perform the upgrade procedure on the targeted switch:

```
network interface modify -vserver Cluster -lif * -auto-revert false
```

6. Copy the NX-OS software and EPLD images to the Nexus 9336C-FX2 switch.

Show example

```
cs2# copy sftp: bootflash: vrf management
Enter source filename: /code/nxos.9.3.5.bin
Enter hostname for the sftp server: 172.19.2.1
Enter username: user1

Outbound-ReKey for 172.19.2.1:22
Inbound-ReKey for 172.19.2.1:22
user1@172.19.2.1's password:
sftp> progress
Progress meter enabled
sftp> get /code/nxos.9.3.5.bin /bootflash/nxos.9.3.5.bin
/code/nxos.9.3.5.bin 100% 1261MB 9.3MB/s 02:15
sftp> exit
Copy complete, now saving to disk (please wait)...
Copy complete.

cs2# copy sftp: bootflash: vrf management
Enter source filename: /code/n9000-epld.9.3.5.img
Enter hostname for the sftp server: 172.19.2.1
Enter username: user1

Outbound-ReKey for 172.19.2.1:22
Inbound-ReKey for 172.19.2.1:22
user1@172.19.2.1's password:
sftp> progress
Progress meter enabled
sftp> get /code/n9000-epld.9.3.5.img /bootflash/n9000-
epld.9.3.5.img
/code/n9000-epld.9.3.5.img 100% 161MB 9.5MB/s 00:16
sftp> exit
Copy complete, now saving to disk (please wait)...
Copy complete.
```

7. Verify the running version of the NX-OS software:

```
show version
```

Show example

```
cs2# show version
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (C) 2002-2020, Cisco and/or its affiliates.
All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under their
own
licenses, such as open source. This software is provided "as is,"
and unless
otherwise stated, there is no warranty, express or implied,
including but not
limited to warranties of merchantability and fitness for a
particular purpose.
Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0 or
GNU General Public License (GPL) version 3.0 or the GNU
Lesser General Public License (LGPL) Version 2.1 or
Lesser General Public License (LGPL) Version 2.0.
A copy of each such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://opensource.org/licenses/gpl-3.0.html and
http://www.opensource.org/licenses/lgpl-2.1.php and
http://www.gnu.org/licenses/old-licenses/library.txt.

Software
  BIOS: version 08.38
  NXOS: version 9.3(4)
  BIOS compile time: 05/29/2020
  NXOS image file is: bootflash:///nxos.9.3.4.bin
  NXOS compile time: 4/28/2020 21:00:00 [04/29/2020 02:28:31]

Hardware
  cisco Nexus9000 C9336C-FX2 Chassis
  Intel(R) Xeon(R) CPU E5-2403 v2 @ 1.80GHz with 8154432 kB of
memory.
  Processor Board ID FOC20291J6K

  Device name: cs2
  bootflash: 53298520 kB
  Kernel uptime is 0 day(s), 0 hour(s), 3 minute(s), 42 second(s)
```

```
Last reset at 157524 usecs after Mon Nov  2 18:32:06 2020
Reason: Reset Requested by CLI command reload
System version: 9.3(4)
Service:

plugin
  Core Plugin, Ethernet Plugin

Active Package(s) :

cs2#
```

8. Install the NX-OS image.

Installing the image file causes it to be loaded every time the switch is rebooted.

Show example

```
cs2# install all nxos bootflash:nxos.9.3.5.bin
```

```
Installer will perform compatibility check first. Please wait.  
Installer is forced disruptive
```

```
Verifying image bootflash:/nxos.9.3.5.bin for boot variable "nxos".  
[] 100% -- SUCCESS
```

```
Verifying image type.  
[] 100% -- SUCCESS
```

```
Preparing "nxos" version info using image bootflash:/nxos.9.3.5.bin.  
[] 100% -- SUCCESS
```

```
Preparing "bios" version info using image bootflash:/nxos.9.3.5.bin.  
[] 100% -- SUCCESS
```

```
Performing module support checks.  
[] 100% -- SUCCESS
```

```
Notifying services about system upgrade.  
[] 100% -- SUCCESS
```

Compatibility check is done:

Module	Bootable	Impact	Install-type	Reason
1	yes	Disruptive	Reset	Default upgrade is not hitless

Images will be upgraded according to following table:

Module	Image	Running-Version(pri:alt)	New-
Version		Upg-Required	
1	nxos	9.3(4)	9.3(5)
yes			
1	bios	v08.37(01/28/2020):v08.23(09/23/2015)	
v08.38(05/29/2020)		yes	

```
Switch will be reloaded for disruptive upgrade.
```

```
Do you want to continue with the installation (y/n)? [n] y
```

```
Install is in progress, please wait.
```

```
Performing runtime checks.
```

```
[ ] 100% -- SUCCESS
```

```
Setting boot variables.
```

```
[ ] 100% -- SUCCESS
```

```
Performing configuration copy.
```

```
[ ] 100% -- SUCCESS
```

```
Module 1: Refreshing compact flash and upgrading  
bios/loader/bootrom.
```

```
Warning: please do not remove or power off the module at this time.
```

```
[ ] 100% -- SUCCESS
```

```
Finishing the upgrade, switch will reboot in 10 seconds.
```

9. Verify the new version of NX-OS software after the switch has rebooted:

```
show version
```

Show example

```
cs2# show version
```

```
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (C) 2002-2020, Cisco and/or its affiliates.
All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under their
own
licenses, such as open source. This software is provided "as is,"
and unless
otherwise stated, there is no warranty, express or implied,
including but not
limited to warranties of merchantability and fitness for a
particular purpose.
Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0 or
GNU General Public License (GPL) version 3.0 or the GNU
Lesser General Public License (LGPL) Version 2.1 or
Lesser General Public License (LGPL) Version 2.0.
A copy of each such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://opensource.org/licenses/gpl-3.0.html and
http://www.opensource.org/licenses/lgpl-2.1.php and
http://www.gnu.org/licenses/old-licenses/library.txt.
```

Software

```
BIOS: version 05.33
NXOS: version 9.3(5)
BIOS compile time: 09/08/2018
NXOS image file is: bootflash:///nxos.9.3.5.bin
NXOS compile time: 11/4/2018 21:00:00 [11/05/2018 06:11:06]
```

Hardware

```
cisco Nexus9000 C9336C-FX2 Chassis
Intel(R) Xeon(R) CPU E5-2403 v2 @ 1.80GHz with 8154432 kB of
memory.
Processor Board ID FOC20291J6K

Device name: cs2
bootflash: 53298520 kB
Kernel uptime is 0 day(s), 0 hour(s), 3 minute(s), 42 second(s)
```

```
Last reset at 277524 usecs after Mon Nov  2 22:45:12 2020
```

```
Reason: Reset due to upgrade
```

```
System version: 9.3(4)
```

```
Service:
```


```
plugin
```

```
Core Plugin, Ethernet Plugin
```

```
Active Package(s):
```

10. Upgrade the EPLD image and reboot the switch.

Show example



```
cs2# show version module 1 epld
```

```
EPLD Device                               Version
-----
MI   FPGA                                0x7
IO   FPGA                                0x17
MI   FPGA2                               0x2
GEM  FPGA                                0x2
GEM  FPGA                                0x2
GEM  FPGA                                0x2
GEM  FPGA                                0x2
```

```
cs2# install epld bootflash:n9000-epld.9.3.5.img module all
```

```
Compatibility check:
```

Module	Type	Upgradable	Impact	Reason
1	SUP	Yes	disruptive	Module Upgradable

```
Retrieving EPLD versions.... Please wait.
```

```
Images will be upgraded according to following table:
```

Module	Type	EPLD	Running-Version	New-Version	Upg-Required
1	SUP	MI FPGA	0x07	0x07	No
1	SUP	IO FPGA	0x17	0x19	Yes
1	SUP	MI FPGA2	0x02	0x02	No

```
The above modules require upgrade.
```

```
The switch will be reloaded at the end of the upgrade
```

```
Do you want to continue (y/n) ? [n] y
```

```
Proceeding to upgrade Modules.
```

```
Starting Module 1 EPLD Upgrade
```

```
Module 1 : IO FPGA [Programming] : 100.00% ( 64 of 64 sectors)
```

```
Module 1 EPLD upgrade is successful.
```

Module	Type	Upgrade-Result
1	SUP	Success

```
EPLDs upgraded.
```

```
Module 1 EPLD upgrade is successful.
```

11. After the switch reboot, log in again and verify that the new version of EPLD loaded successfully.

Show example

```
cs2# show version module 1 epld
```

EPLD	Device	Version
MI	FPGA	0x7
IO	FPGA	0x19
MI	FPGA2	0x2
GEM	FPGA	0x2

12. Verify the health of all ports on the cluster.

a. Verify that cluster ports are up and healthy across all nodes in the cluster:

```
network port show -ipSpace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster
```

```
Node: cluster1-01
```

```
Ignore
```

						Speed (Mbps)
Health	Health					
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status	Status					

e0a	Cluster	Cluster		up	9000	auto/10000
healthy	false					
e0b	Cluster	Cluster		up	9000	auto/10000
healthy	false					

```
Node: cluster1-02
```

```
Ignore
```

						Speed (Mbps)
Health	Health					
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status	Status					

e0a	Cluster	Cluster		up	9000	auto/10000
healthy	false					
e0b	Cluster	Cluster		up	9000	auto/10000
healthy	false					

```
Node: cluster1-03
```

```
Ignore
```

						Speed (Mbps)
Health	Health					
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status	Status					

e0a	Cluster	Cluster		up	9000	auto/100000
healthy	false					
e0d	Cluster	Cluster		up	9000	auto/100000
healthy	false					

```
Node: cluster1-04
```

```
Ignore
```

```
Health Health Speed (Mbps)
Port IPspace Broadcast Domain Link MTU Admin/Oper
Status Status
-----
e0a Cluster Cluster up 9000 auto/100000
healthy false
e0d Cluster Cluster up 9000 auto/100000
healthy false
```

b. Verify the switch health from the cluster.

```
network device-discovery show -protocol cdp
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp
Node/          Local  Discovered
Protocol      Port   Device (LLDP: ChassisID)  Interface
Platform
-----
-----
cluster1-01/cdp
              e0a    cs1                        Ethernet1/7
N9K-C9336C-FX2
              e0d    cs2                        Ethernet1/7
N9K-C9336C-FX2
cluster01-2/cdp
              e0a    cs1                        Ethernet1/8
N9K-C9336C-FX2
              e0d    cs2                        Ethernet1/8
N9K-C9336C-FX2
cluster01-3/cdp
              e0a    cs1                        Ethernet1/1/1
N9K-C9336C-FX2
              e0b    cs2                        Ethernet1/1/1
N9K-C9336C-FX2
cluster1-04/cdp
              e0a    cs1                        Ethernet1/1/2
N9K-C9336C-FX2
              e0b    cs2                        Ethernet1/1/2
N9K-C9336C-FX2
```

You might observe the following output on the cs1 switch console depending on the RCF version previously loaded on the switch:

```
2020 Nov 17 16:07:18 cs1 %$ VDC-1 %$ %STP-2-UNBLOCK_CONSIST_PORT:
Unblocking port port-channell on VLAN0092. Port consistency
restored.
2020 Nov 17 16:07:23 cs1 %$ VDC-1 %$ %STP-2-BLOCK_PVID_PEER:
Blocking port-channell on VLAN0001. Inconsistent peer vlan.
2020 Nov 17 16:07:23 cs1 %$ VDC-1 %$ %STP-2-BLOCK_PVID_LOCAL:
Blocking port-channell on VLAN0092. Inconsistent local vlan.
```

- c. Verify that all the node storage ports are up with a healthy status:

```
storage port show -port-type ENET
```

Show example

```
cluster1::*> storage port show -port-type ENET
```

Node	Port	Type	Mode	Speed (Gb/s)	State	Status

cluster1-01	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
cluster1-02	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
.						
.						

- d. Verify that all the storage shelf ports are up with a healthy status:

```
storage shelf port show
```

Show example

```
cluster1::> storage shelf port show
```

Shelf	ID	Module	State	Internal?

1.4				
	0	A	connected	false
	1	A	connected	false
	2	B	connected	false
	3	B	connected	false
.				
.				

- e. Verify that the switches are being monitored.

```
system switch ethernet show
```

Show example

```
cluster1::*> system switch ethernet show
Switch                               Type                               Address
Model
-----
s1
                                     storage-network                   10.228.143.216
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXB
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

s2
                                     storage-network                   10.228.143.219
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXC
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.6(2)
  Version Source: CDP/ISDP

cs1
                                     cluster-network                   10.228.184.39
N9K-C9336C-FX2
  Serial Number: FLMXXXXXXXXJ
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

cs2
                                     cluster-network                   10.228.184.40
N9K-C9336C-FX2
```

```
Serial Number: FLMXXXXXXXXG
  Is Monitored: true
    Reason: None
Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                  10.6(2)
Version Source: CDP/ISDP
```

13. Verify that the cluster is healthy:

```
cluster show
```

Show example

```
cluster1::*> cluster show
Node           Health  Eligibility  Epsilon
-----
cluster1-01    true   true         false
cluster1-02    true   true         false
cluster1-03    true   true         true
cluster1-04    true   true         false
4 entries were displayed.
cluster1::*>
```

14. Repeat steps 6 to 13 to install the NX-OS software on switch cs1.

15. Verify the connectivity of the remote cluster interfaces before enabling auto-revert on the cluster LIFs:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```

NOTE: Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show
```

Packet	Source	Destination
Node	Date	LIF
Loss		
-----	-----	-----
node1		
3/5/2022 19:21:18 -06:00	cluster1-01_clus2	cluster1-02-
clus1 none		
3/5/2022 19:21:20 -06:00	cluster1-01_clus2	cluster1-
02_clus2 none		
node2		
3/5/2022 19:21:18 -06:00	cluster1-02_clus2	cluster1-
01_clus1 none		
3/5/2022 19:21:20 -06:00	cluster1-02_clus2	cluster1-
01_clus2 none		

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster1::*> cluster ping-cluster -node local
Host is cluster1-02
Getting addresses from network interface table...
Cluster cluster1-01_clus1 169.254.209.69 cluster1-01 e0a
Cluster cluster1-01_clus2 169.254.49.125 cluster1-01 e0b
Cluster cluster1-02_clus1 169.254.47.194 cluster1-02 e0a
Cluster cluster1-02_clus2 169.254.19.183 cluster1-02 e0b
Local = 169.254.47.194 169.254.19.183
Remote = 169.254.209.69 169.254.49.125
Cluster Vserver Id = 4294967293
Ping status:

Basic connectivity succeeds on 4 path(s)
Basic connectivity fails on 0 path(s)

Detected 9000 byte MTU on 4 path(s):
    Local 169.254.19.183 to Remote 169.254.209.69
    Local 169.254.19.183 to Remote 169.254.49.125
    Local 169.254.47.194 to Remote 169.254.209.69
    Local 169.254.47.194 to Remote 169.254.49.125
Larger than PMTU communication succeeds on 4 path(s)
RPC status:
2 paths up, 0 paths down (tcp check)
2 paths up, 0 paths down (udp check)

```

16. Enable auto-revert on the cluster LIFs.

```
network interface modify -vserver Cluster -lif * -auto-revert true
```

17. Verify that the cluster LIFs have reverted to their home port:

```
network interface show -role cluster
```

Show example

```
cluster1::*> network interface show -role cluster
```

Current	Is	Logical	Status	Network	Current
Vserver	Port	Interface	Admin/Oper	Address/Mask	Node
Home					

Cluster					
		cluster1-01_clus1	up/up	169.254.3.4/23	
cluster1-01		e0d	true		
		cluster1-01_clus2	up/up	169.254.3.5/23	
cluster1-01		e0d	true		
		cluster1-02_clus1	up/up	169.254.3.8/23	
cluster1-02		e0d	true		
		cluster1-02_clus2	up/up	169.254.3.9/23	
cluster1-02		e0d	true		
		cluster1-03_clus1	up/up	169.254.1.3/23	
cluster1-03		e0b	true		
		cluster1-03_clus2	up/up	169.254.1.1/23	
cluster1-03		e0b	true		
		cluster1-04_clus1	up/up	169.254.1.6/23	
cluster1-04		e0b	true		
		cluster1-04_clus2	up/up	169.254.1.7/23	
cluster1-04		e0b	true		

If any cluster LIFs have not returned to their home ports, revert them manually from the local node:

```
network interface revert -vserver Cluster -lif <lif_name>
```

What's next?

After you've installed the NX-OS software, you can [install the RCF](#).

Install the Reference Configuration File (RCF)

You can install the reference configuration file (RCF) after setting up the Nexus 9336C-FX2 switch for the first time.

Before you begin, complete the procedure in [Prepare to install NX-OS and RCF](#).

Before you begin

Verify the following installations and connections:

- A console connection to the switch. The console connection is optional if you have remote access to the

switch.

- Switch cs1 and switch cs2 are powered up and the initial switch setup is complete (the Management IP address and SSH is set up).
- The desired NX-OS version has been installed.
- Inter-switch link (ISL) connections between switches are connected.
- ONTAP node cluster ports are not connected.

Available RCF configuration

- **ClusterStorageRCF** - Supports a partitioned cluster plus two storage zones on the switches (Cluster-Storage RCF 1.xx).

Step 1: Install the RCF on the switches

1. Login to switch cs1 using SSH or by using a serial console.
2. Copy the RCF to the bootflash of switch cs1 using one of the following transfer protocols: FTP, TFTP, SFTP, or SCP.

For more information on Cisco commands, see the appropriate guide in the [Cisco Nexus 9000 Series NX-OS Command Reference](#).

Show example

This example shows TFTP being used to copy an RCF to the bootflash on switch cs1:

```
cs1# copy tftp: bootflash: vrf management
Enter source filename: Nexus_9336C_RCF_v1.6-Cluster-HA-Breakout.txt
Enter hostname for the tftp server: 172.22.201.50
Trying to connect to tftp server.....Connection to Server
Established.
TFTP get operation was successful
Copy complete, now saving to disk (please wait)...
```

3. Apply the RCF previously downloaded to the bootflash.

For more information on Cisco commands, see the appropriate guide in the [Cisco Nexus 9000 Series NX-OS Command Reference](#).

Show example

This example shows the RCF file `Nexus_9336C_RCF_v1.6-Cluster-HA-Breakout.txt` being installed on switch cs1:

```
cs1# copy Nexus_9336C_RCF_v1.6-Cluster-HA-Breakout.txt running-
config echo-commands
```

4. Examine the banner output from the `show banner motd` command. You must read and follow these instructions to ensure the proper configuration and operation of the switch.

Show example

```
cs1# show banner motd

*****
*****
* NetApp Reference Configuration File (RCF)
*
* Switch   : Nexus N9K-C9336C-FX2
* Filename : Nexus_9336C_RCF_v1.6-Cluster-HA-Breakout.txt
* Date     : 10-23-2020
* Version  : v1.6
*
* Port Usage:
* Ports 1- 3: Breakout mode (4x10G) Intra-Cluster Ports, int
e1/1/1-4, e1/2/1-4
, e1/3/1-4
* Ports 4- 6: Breakout mode (4x25G) Intra-Cluster/HA Ports, int
e1/4/1-4, e1/5/
1-4, e1/6/1-4
* Ports 7-34: 40/100GbE Intra-Cluster/HA Ports, int e1/7-34
* Ports 35-36: Intra-Cluster ISL Ports, int e1/35-36
*
* Dynamic breakout commands:
* 10G: interface breakout module 1 port <range> map 10g-4x
* 25G: interface breakout module 1 port <range> map 25g-4x
*
* Undo breakout commands and return interfaces to 40/100G
configuration in confi
g mode:
* no interface breakout module 1 port <range> map 10g-4x
* no interface breakout module 1 port <range> map 25g-4x
* interface Ethernet <interfaces taken out of breakout mode>
* inherit port-profile 40-100G
* priority-flow-control mode auto
* service-policy input HA
* exit
*
*****
*****
```

5. Verify that the RCF file is the correct newer version:

```
show running-config
```

When you check the output to verify you have the correct RCF, make sure that the following information is correct:

- The RCF banner
- The node and port settings
- Customizations

The output varies according to your site configuration. Check the port settings and refer to the release notes for any changes specific to the RCF that you have installed.

6. Record any custom additions between the current `running-config` file and the RCF file in use.
7. After you verify that the RCF versions and switch settings are correct, copy the `running-config` file to the `startup-config` file.

```
cs1# copy running-config startup-config
[#####] 100% Copy complete
```

8. Reboot switch cs1.

```
cs1# reload
```

This command will reboot the system. (y/n)? [n] **y**

9. Repeat steps 1 through 8 on switch cs2.
10. Connect the cluster ports of all nodes in the ONTAP cluster to switches cs1 and cs2.

Step 2: Verify the switch connections

1. Verify that the switch ports connected to the cluster ports are **up**.

```
show interface brief
```

Show example

```
cs1# show interface brief | grep up
.
.
Eth1/1/1      1      eth  access up    none
10G(D)  --
Eth1/1/2      1      eth  access up    none
10G(D)  --
Eth1/7        1      eth  trunk  up    none
100G(D)  --
Eth1/8        1      eth  trunk  up    none
100G(D)  --
.
.
```

2. Verify that the cluster nodes are in their correct cluster VLANs using the following commands:

```
show vlan brief
```

```
show interface trunk
```

Show example

```
cs1# show vlan brief
```

VLAN Name	Status	Ports
1 default	active	Pol, Eth1/1, Eth1/2, Eth1/3 Eth1/4, Eth1/5, Eth1/6, Eth1/7 Eth1/8, Eth1/35, Eth1/36 Eth1/9/1, Eth1/9/2, Eth1/9/3 Eth1/9/4, Eth1/10/1, Eth1/10/2 Eth1/10/3, Eth1/10/4
17 VLAN0017	active	Eth1/1, Eth1/2, Eth1/3, Eth1/4 Eth1/5, Eth1/6, Eth1/7, Eth1/8 Eth1/9/1, Eth1/9/2, Eth1/9/3 Eth1/9/4, Eth1/10/1, Eth1/10/2 Eth1/10/3, Eth1/10/4
18 VLAN0018	active	Eth1/1, Eth1/2, Eth1/3, Eth1/4 Eth1/5, Eth1/6, Eth1/7, Eth1/8 Eth1/9/1, Eth1/9/2, Eth1/9/3 Eth1/9/4, Eth1/10/1, Eth1/10/2 Eth1/10/3, Eth1/10/4
31 VLAN0031	active	Eth1/11, Eth1/12, Eth1/13 Eth1/14, Eth1/15, Eth1/16 Eth1/17, Eth1/18, Eth1/19 Eth1/20, Eth1/21, Eth1/22
32 VLAN0032	active	Eth1/23, Eth1/24, Eth1/25

```

Eth1/28                               Eth1/26, Eth1/27,
Eth1/31                               Eth1/29, Eth1/30,
Eth1/34                               Eth1/32, Eth1/33,
33   VLAN0033                         active   Eth1/11, Eth1/12,
Eth1/13                               Eth1/14, Eth1/15,
Eth1/16                               Eth1/17, Eth1/18,
Eth1/19                               Eth1/20, Eth1/21,
Eth1/22                               Eth1/23, Eth1/24,
34   VLAN0034                         active   Eth1/26, Eth1/27,
Eth1/25                               Eth1/29, Eth1/30,
Eth1/28                               Eth1/32, Eth1/33,
Eth1/31
Eth1/34

```

```
cs1# show interface trunk
```

```

-----
Port          Native  Status      Port
              Vlan               Channel
-----
Eth1/1        1       trunking    --
Eth1/2        1       trunking    --
Eth1/3        1       trunking    --
Eth1/4        1       trunking    --
Eth1/5        1       trunking    --
Eth1/6        1       trunking    --
Eth1/7        1       trunking    --
Eth1/8        1       trunking    --
Eth1/9/1      1       trunking    --
Eth1/9/2      1       trunking    --
Eth1/9/3      1       trunking    --
Eth1/9/4      1       trunking    --
Eth1/10/1     1       trunking    --
Eth1/10/2     1       trunking    --
Eth1/10/3     1       trunking    --
Eth1/10/4     1       trunking    --
Eth1/11       33      trunking    --

```

Eth1/12	33	trunking	--
Eth1/13	33	trunking	--
Eth1/14	33	trunking	--
Eth1/15	33	trunking	--
Eth1/16	33	trunking	--
Eth1/17	33	trunking	--
Eth1/18	33	trunking	--
Eth1/19	33	trunking	--
Eth1/20	33	trunking	--
Eth1/21	33	trunking	--
Eth1/22	33	trunking	--
Eth1/23	34	trunking	--
Eth1/24	34	trunking	--
Eth1/25	34	trunking	--
Eth1/26	34	trunking	--
Eth1/27	34	trunking	--
Eth1/28	34	trunking	--
Eth1/29	34	trunking	--
Eth1/30	34	trunking	--
Eth1/31	34	trunking	--
Eth1/32	34	trunking	--
Eth1/33	34	trunking	--
Eth1/34	34	trunking	--
Eth1/35	1	trnk-bndl	Pol
Eth1/36	1	trnk-bndl	Pol
Pol	1	trunking	--

Port	Vlans Allowed on Trunk
Eth1/1	1,17-18
Eth1/2	1,17-18
Eth1/3	1,17-18
Eth1/4	1,17-18
Eth1/5	1,17-18
Eth1/6	1,17-18
Eth1/7	1,17-18
Eth1/8	1,17-18
Eth1/9/1	1,17-18
Eth1/9/2	1,17-18
Eth1/9/3	1,17-18
Eth1/9/4	1,17-18
Eth1/10/1	1,17-18
Eth1/10/2	1,17-18
Eth1/10/3	1,17-18
Eth1/10/4	1,17-18

```
Eth1/11      31, 33
Eth1/12      31, 33
Eth1/13      31, 33
Eth1/14      31, 33
Eth1/15      31, 33
Eth1/16      31, 33
Eth1/17      31, 33
Eth1/18      31, 33
Eth1/19      31, 33
Eth1/20      31, 33
Eth1/21      31, 33
Eth1/22      31, 33
Eth1/23      32, 34
Eth1/24      32, 34
Eth1/25      32, 34
Eth1/26      32, 34
Eth1/27      32, 34
Eth1/28      32, 34
Eth1/29      32, 34
Eth1/30      32, 34
Eth1/31      32, 34
Eth1/32      32, 34
Eth1/33      32, 34
Eth1/34      32, 34
Eth1/35      1
Eth1/36      1
Po1          1
..
..
..
..
..
```



For specific port and VLAN usage details, refer to the banner and important notes section in your RCF.

3. Verify that the ISL between cs1 and cs2 is functional:

```
show port-channel summary
```

Show example

```
cs1# show port-channel summary
Flags:  D - Down          P - Up in port-channel (members)
        I - Individual   H - Hot-standby (LACP only)
        s - Suspended    r - Module-removed
        b - BFD Session Wait
        S - Switched     R - Routed
        U - Up (port-channel)
        p - Up in delay-lacp mode (member)
        M - Not in use. Min-links not met

-----
-----
Group Port-          Type      Protocol  Member Ports      Channel
-----
-----
1      Po1 (SU)      Eth       LACP          Eth1/35 (P)       Eth1/36 (P)
cs1#
```

Step 3: Set up your ONTAP cluster

NetApp recommends that you use System Manager to set up new clusters.

System Manager provides a simple and easy workflow for cluster set up and configuration including assigning a node management IP address, initializing the cluster, creating a local tier, configuring protocols and provisioning initial storage.

Go to [Configure ONTAP on a new cluster with System Manager](#) for setup instructions.

What's next?

After you've installed the RCF, you can [configure switch health monitoring](#).

Upgrade your reference configuration file (RCF)

You upgrade your RCF version when you have an existing version of the RCF file installed on your operational switches.

Before you begin

Make sure you have the following:

- A current backup of the switch configuration.
- A fully functioning cluster (no errors in the logs or similar issues).
- The current RCF.
- If you are updating your RCF version, you need a boot configuration in the RCF that reflects the desired boot images.

If you need to change the boot configuration to reflect the current boot images, you must do so before reapplying the RCF so that the correct version is instantiated on future reboots.



No operational inter-switch link (ISL) is needed during this procedure. This is by design because RCF version changes can affect ISL connectivity temporarily. To ensure non-disruptive cluster operations, the following procedure migrates all of the cluster LIFs to the operational partner switch while performing the steps on the target switch.



Before installing a new switch software version and RCFs, you must erase the switch settings and perform basic configuration. You must be connected to the switch using the serial console or have preserved basic configuration information before erasing the switch settings.

Step 1: Prepare for the upgrade

1. Display the cluster ports on each node that are connected to the cluster switches:

```
network device-discovery show
```

Show example

```
cluster1::*> network device-discovery show
Node/          Local  Discovered
Protocol      Port   Device (LLDP: ChassisID)  Interface
Platform
-----
-----
cluster1-01/cdp
              e0a    cs1                      Ethernet1/7      N9K-
C9336C
              e0d    cs2                      Ethernet1/7      N9K-
C9336C
cluster1-02/cdp
              e0a    cs1                      Ethernet1/8      N9K-
C9336C
              e0d    cs2                      Ethernet1/8      N9K-
C9336C
cluster1-03/cdp
              e0a    cs1                      Ethernet1/1/1    N9K-
C9336C
              e0b    cs2                      Ethernet1/1/1    N9K-
C9336C
cluster1-04/cdp
              e0a    cs1                      Ethernet1/1/2    N9K-
C9336C
              e0b    cs2                      Ethernet1/1/2    N9K-
C9336C
```

2. Check the administrative and operational status of each cluster port, node storage port, and storage shelf port.
 - a. Verify that all the cluster ports are **up** with a healthy status:

```
network port show -ipospace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster

Node: cluster1-01

Ignore

Health      Health      Speed (Mbps)
Port        IPspace      Broadcast Domain Link MTU Admin/Oper
Status      Status
-----
e0a         Cluster      Cluster      up    9000 auto/100000
healthy    false
e0d         Cluster      Cluster      up    9000 auto/100000
healthy    false

Node: cluster1-02

Ignore

Health      Health      Speed (Mbps)
Port        IPspace      Broadcast Domain Link MTU Admin/Oper
Status      Status
-----
e0a         Cluster      Cluster      up    9000 auto/100000
healthy    false
e0d         Cluster      Cluster      up    9000 auto/100000
healthy    false
8 entries were displayed.

Node: cluster1-03

Ignore

Health      Health      Speed (Mbps)
Port        IPspace      Broadcast Domain Link MTU Admin/Oper
Status      Status
-----
e0a         Cluster      Cluster      up    9000 auto/10000
healthy    false
e0b         Cluster      Cluster      up    9000 auto/10000
healthy    false
```

```
Node: cluster1-04

Ignore

Health Health
Port IPspace Broadcast Domain Link MTU Admin/Oper
Status Status
-----
-----
e0a Cluster Cluster up 9000 auto/10000
healthy false
e0b Cluster Cluster up 9000 auto/10000
healthy false
```

b. Verify that all the cluster interfaces (LIFs) are on the home port:

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*> network interface show -vserver Cluster
```

Current Vserver Port	Logical Current Home	Is Interface	Status Admin/Oper	Network Address/Mask	Node
Cluster					
cluster1-01	cluster1-01_e0a	clus1 true	up/up	169.254.3.4/23	
cluster1-01	cluster1-01_e0d	clus2 true	up/up	169.254.3.5/23	
cluster1-02	cluster1-02_e0a	clus1 true	up/up	169.254.3.8/23	
cluster1-02	cluster1-02_e0d	clus2 true	up/up	169.254.3.9/23	
cluster1-03	cluster1-03_e0a	clus1 true	up/up	169.254.1.3/23	
cluster1-03	cluster1-03_e0b	clus2 true	up/up	169.254.1.1/23	
cluster1-04	cluster1-04_e0a	clus1 true	up/up	169.254.1.6/23	
cluster1-04	cluster1-04_e0b	clus2 true	up/up	169.254.1.7/23	

c. Verify that all the node storage ports are up with a healthy status:

```
storage port show -port-type ENET
```

Show example

```
cluster1::*> storage port show -port-type ENET
```

Node	Port	Type	Mode	Speed (Gb/s)	State	Status

cluster1-01	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
cluster1-02	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
.						
.						

- d. Verify that all the storage shelf ports are up with a healthy status:

```
storage shelf port show
```

Show example

```
cluster1::> storage shelf port show
```

Shelf	ID	Module	State	Internal?

1.4				
	0	A	connected	false
	1	A	connected	false
	2	B	connected	false
	3	B	connected	false
.				
.				

- e. Verify that the switches are being monitored.

```
system switch ethernet show
```

Show example

```
cluster1::*> system switch ethernet show
Switch                               Type                               Address
Model
-----
s1
                                     storage-network                    10.228.143.216
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXB
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

s2
                                     storage-network                    10.228.143.219
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXC
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.6(2)
  Version Source: CDP/ISDP

cs1
                                     cluster-network                     10.228.184.39
N9K-C9336C-FX2
  Serial Number: FLMXXXXXXXXJ
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

cs2
                                     cluster-network                     10.228.184.40
N9K-C9336C-FX2
```

```
Serial Number: FLMXXXXXXXXG
  Is Monitored: true
    Reason: None
Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                  10.6(2)
Version Source: CDP/ISDP
```

3. Disable auto-revert on the cluster LIFs.

```
cluster1::*> network interface modify -vserver Cluster -lif * -auto-revert
false
```

Step 2: Configure ports

1. On cluster switch cs1, shut down the ports connected to the cluster ports of the nodes.

```
cs1(config)# interface eth1/1/1-2,eth1/7-8
```

```
cs1(config-if-range)# shutdown
```



Make sure to shutdown **all** connected cluster ports to avoid any network connection issues. See the Knowledge Base article [Node out of quorum when migrating cluster LIF during switch OS upgrade](#) for further details.

2. Verify that the cluster LIFs have failed over to the ports hosted on cluster switch cs1. This might take a few seconds.

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*> network interface show -vserver Cluster
          Logical          Status      Network          Current
Current Is
Vserver   Interface             Admin/Oper  Address/Mask     Node
Port      Home
-----
Cluster
cluster1-01  cluster1-01_clus1 up/up      169.254.3.4/23
           e0a             true
cluster1-01  cluster1-01_clus2 up/up      169.254.3.5/23
           e0a             false
cluster1-02  cluster1-02_clus1 up/up      169.254.3.8/23
           e0a             true
cluster1-02  cluster1-02_clus2 up/up      169.254.3.9/23
           e0a             false
cluster1-03  cluster1-03_clus1 up/up      169.254.1.3/23
           e0a             true
cluster1-03  cluster1-03_clus2 up/up      169.254.1.1/23
           e0a             false
cluster1-04  cluster1-04_clus1 up/up      169.254.1.6/23
           e0a             true
cluster1-04  cluster1-04_clus2 up/up      169.254.1.7/23
           e0a             false
```

3. Verify that the cluster is healthy:

```
cluster show
```

Show example

```
cluster1::*> cluster show
Node          Health  Eligibility  Epsilon
-----
cluster1-01   true    true         false
cluster1-02   true    true         false
cluster1-03   true    true         true
cluster1-04   true    true         false
```

4. If you have not already done so, save a copy of the current switch configuration by copying the output of the following command to a text file:

```
show running-config
```

- a. Record any custom additions between the current running-config and the RCF file in use (such as an SNMP configuration for your organization).
 - b. For NX-OS 10.2 and later, use the `show diff running-config` command to compare with the saved RCF file in the bootflash. Otherwise, use a third party diff or compare tool.
5. Save basic configuration details to the `write_erase.cfg` file on the bootflash.

```
cs1# show run | i "username admin password" > bootflash:write_erase.cfg
```

```
cs1# show run | section "vrf context management" >> bootflash:write_erase.cfg
```

```
cs1# show run | section "interface mgmt0" >> bootflash:write_erase.cfg
```

```
cs1# show run | section "switchname" >> bootflash:write_erase.cfg
```

6. For RCF version 1.12 and later, run the following commands:

```
cs1# echo "hardware access-list tcam region ing-racl 1024" >>  
bootflash:write_erase.cfg
```

```
cs1# echo "hardware access-list tcam region egr-racl 1024" >>  
bootflash:write_erase.cfg
```

```
cs1# echo "hardware access-list tcam region ing-l2-qos 1280" >>  
bootflash:write_erase.cfg
```

See the Knowledge Base article [How to clear configuration on a Cisco interconnect switch while retaining remote connectivity](#) for further details.

7. Verify that the `write_erase.cfg` file is populated as expected:

```
show file bootflash:write_erase.cfg
```

8. Issue the write erase command to erase the current saved configuration:

```
cs1# write erase
```

```
Warning: This command will erase the startup-configuration.
```

```
Do you wish to proceed anyway? (y/n) [n] y
```

9. Copy the previously saved basic configuration into the startup configuration.

```
cs1# copy bootflash:write_erase.cfg startup-config
```

10. Perform a reboot of the switch:

```
switch# reload
```

```
This command will reboot the system. (y/n)? [n] y
```

11. After the management IP address is reachable again, log in to the switch through SSH.

You might need to update host file entries related to the SSH keys.

12. Copy the RCF to the bootflash of switch cs1 using one of the following transfer protocols: FTP, TFTP, SFTP, or SCP.

For more information on Cisco commands, see the appropriate guide in the [Cisco Nexus 9000 Series NX-OS Command Reference](#) guides.

Show example

This example shows TFTP being used to copy an RCF to the bootflash on switch cs1:

```
cs1# copy tftp: bootflash: vrf management
Enter source filename: Nexus_9336C_RCF_v1.6-Cluster-HA-Breakout.txt
Enter hostname for the tftp server: 172.22.201.50
Trying to connect to tftp server.....Connection to Server
Established.
TFTP get operation was successful
Copy complete, now saving to disk (please wait)...
```

13. Apply the RCF previously downloaded to the bootflash.

For more information on Cisco commands, see the appropriate guide in the [Cisco Nexus 9000 Series NX-OS Command Reference](#) guides.

Show example

This example shows the RCF file `Nexus_9336C_RCF_v1.6-Cluster-HA-Breakout.txt` being installed on switch cs1:

```
cs1# copy Nexus_9336C_RCF_v1.6-Cluster-HA-Breakout.txt running-
config echo-commands
```

14. Examine the banner output from the `show banner motd` command. You must read and follow these instructions to ensure the proper configuration and operation of the switch.

Show example

```
cs1# show banner motd

*****
*****
* NetApp Reference Configuration File (RCF)
*
* Switch    : Nexus N9K-C9336C-FX2
* Filename  : Nexus_9336C_RCF_v1.6-Cluster-HA-Breakout.txt
* Date      : 10-23-2020
* Version   : v1.6
*
* Port Usage:
* Ports 1- 3: Breakout mode (4x10G) Intra-Cluster Ports, int
e1/1/1-4, e1/2/1-4
, e1/3/1-4
* Ports 4- 6: Breakout mode (4x25G) Intra-Cluster/HA Ports, int
e1/4/1-4, e1/5/
1-4, e1/6/1-4
* Ports 7-34: 40/100GbE Intra-Cluster/HA Ports, int e1/7-34
* Ports 35-36: Intra-Cluster ISL Ports, int e1/35-36
*
* Dynamic breakout commands:
* 10G: interface breakout module 1 port <range> map 10g-4x
* 25G: interface breakout module 1 port <range> map 25g-4x
*
* Undo breakout commands and return interfaces to 40/100G
configuration in confi
g mode:
* no interface breakout module 1 port <range> map 10g-4x
* no interface breakout module 1 port <range> map 25g-4x
* interface Ethernet <interfaces taken out of breakout mode>
* inherit port-profile 40-100G
* priority-flow-control mode auto
* service-policy input HA
* exit
*
*****
*****
```

15. Verify that the RCF file is the correct newer version:

```
show running-config
```

When you check the output to verify you have the correct RCF, make sure that the following information is correct:

- The RCF banner
- The node and port settings
- Customizations

The output varies according to your site configuration. Check the port settings and refer to the release notes for any changes specific to the RCF that you have installed.

16. Reapply any previous customizations to the switch configuration.
17. Refer to [Review cabling and configuration considerations](#) for details of any further changes required.
18. After you verify the RCF versions, custom additions, and switch settings are correct, copy the running-config file to the startup-config file.

For more information on Cisco commands, see the appropriate guide in the [Cisco Nexus 9000 Series NX-OS Command Reference](#) guides.

```
cs1# copy running-config startup-config
```

```
[ ] 100% Copy complete
```

19. Reboot switch cs1. You can ignore the “cluster switch health monitor” alerts and “cluster ports down” events reported on the nodes while the switch reboots.

```
cs1# reload
```

```
This command will reboot the system. (y/n)? [n] y
```

20. Verify the health of all ports on the cluster.
 - a. Verify that cluster ports are up and healthy across all nodes in the cluster:

```
network port show -ipspace Cluster
```

Show example

```
cluster1::*> network port show -ipspace Cluster
```

```
Node: cluster1-01
```

```
Ignore
```

						Speed (Mbps)
Health	Health					
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status	Status					
-----	-----	-----	-----	-----	-----	-----
e0a	Cluster	Cluster		up	9000	auto/10000
healthy	false					
e0b	Cluster	Cluster		up	9000	auto/10000
healthy	false					

```
Node: cluster1-02
```

```
Ignore
```

						Speed (Mbps)
Health	Health					
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status	Status					
-----	-----	-----	-----	-----	-----	-----
e0a	Cluster	Cluster		up	9000	auto/10000
healthy	false					
e0b	Cluster	Cluster		up	9000	auto/10000
healthy	false					

```
Node: cluster1-03
```

```
Ignore
```

						Speed (Mbps)
Health	Health					
Port	IPspace	Broadcast	Domain	Link	MTU	Admin/Oper
Status	Status					
-----	-----	-----	-----	-----	-----	-----
e0a	Cluster	Cluster		up	9000	auto/100000
healthy	false					
e0d	Cluster	Cluster		up	9000	auto/100000
healthy	false					

```
Node: cluster1-04

Ignore

Health Health Speed (Mbps)
Port IPspace Broadcast Domain Link MTU Admin/Oper
Status Status
-----
e0a Cluster Cluster up 9000 auto/100000
healthy false
e0d Cluster Cluster up 9000 auto/100000
healthy false
8 entries were displayed.
```

b. Verify the switch health from the cluster.

```
network device-discovery show -protocol cdp
```

Show example

```
cluster1::*> network device-discovery show -protocol cdp
Node/          Local  Discovered
Protocol      Port   Device (LLDP: ChassisID)  Interface
Platform
-----
-----
cluster1-01/cdp
              e0a    cs1                        Ethernet1/7
N9K-C9336C
              e0d    cs2                        Ethernet1/7
N9K-C9336C
cluster01-2/cdp
              e0a    cs1                        Ethernet1/8
N9K-C9336C
              e0d    cs2                        Ethernet1/8
N9K-C9336C
cluster01-3/cdp
              e0a    cs1                        Ethernet1/1/1
N9K-C9336C
              e0b    cs2                        Ethernet1/1/1
N9K-C9336C
cluster1-04/cdp
              e0a    cs1                        Ethernet1/1/2
N9K-C9336C
              e0b    cs2                        Ethernet1/1/2
N9K-C9336C
```

You might observe the following output on the cs1 switch console depending on the RCF version previously loaded on the switch:

```
2020 Nov 17 16:07:18 cs1 %$ VDC-1 %$ %STP-2-UNBLOCK_CONSIST_PORT:
Unblocking port port-channell on VLAN0092. Port consistency
restored.
2020 Nov 17 16:07:23 cs1 %$ VDC-1 %$ %STP-2-BLOCK_PVID_PEER:
Blocking port-channell on VLAN0001. Inconsistent peer vlan.
2020 Nov 17 16:07:23 cs1 %$ VDC-1 %$ %STP-2-BLOCK_PVID_LOCAL:
Blocking port-channell on VLAN0092. Inconsistent local vlan.
```

- c. Verify that all the node storage ports are up with a healthy status:

```
storage port show -port-type ENET
```

Show example

```
cluster1::*> storage port show -port-type ENET
```

Node	Port	Type	Mode	Speed (Gb/s)	State	Status

cluster1-01	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
cluster1-02	e5a	ENET	-	100	enabled	online
	e3b	ENET	-	100	enabled	online
.						
.						

- d. Verify that all the storage shelf ports are up with a healthy status:

```
storage shelf port show
```

Show example

```
cluster1::> storage shelf port show
```

Shelf	ID	Module	State	Internal?

1.4				
	0	A	connected	false
	1	A	connected	false
	2	B	connected	false
	3	B	connected	false
.				
.				

- e. Verify that the switches are being monitored.

```
system switch ethernet show
```

Show example

```
cluster1::*> system switch ethernet show
Switch                               Type                               Address
Model
-----
s1
                                     storage-network                   10.228.143.216
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXB
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

s2
                                     storage-network                   10.228.143.219
N9K-C9336C-FX2
  Serial Number: FDOXXXXXXXXC
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.6(2)
  Version Source: CDP/ISDP

cs1
                                     cluster-network                   10.228.184.39
N9K-C9336C-FX2
  Serial Number: FLMXXXXXXXXJ
  Is Monitored: true
  Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                                     10.4(6)
  Version Source: CDP/ISDP

cs2
                                     cluster-network                   10.228.184.40
N9K-C9336C-FX2
```

```
Serial Number: FLMXXXXXXXXG
  Is Monitored: true
    Reason: None
  Software Version: Cisco Nexus Operating System (NX-OS)
Software, Version
                  10.6(2)
  Version Source: CDP/ISDP
```

21. Verify that the cluster is healthy:

```
cluster show
```

Show example

```
cluster1::*> cluster show
Node           Health  Eligibility  Epsilon
-----
cluster1-01    true   true         false
cluster1-02    true   true         false
cluster1-03    true   true         true
cluster1-04    true   true         false
4 entries were displayed.
cluster1::*>
```

22. Repeat steps 1 to 21 on switch cs2.

23. Enable auto-revert on the cluster LIFs.

```
cluster1::*> network interface modify -vserver Cluster -lif * -auto-revert
True
```

Step 3: Verify the cluster network configuration and cluster health

1. Verify that the switch ports connected to the cluster ports are up.

```
show interface brief
```

Show example

```
cs1# show interface brief | grep up
.
.
Eth1/1/1      1      eth  access up      none
10G(D) --
Eth1/1/2      1      eth  access up      none
10G(D) --
Eth1/7        1      eth  trunk  up      none
100G(D) --
Eth1/8        1      eth  trunk  up      none
100G(D) --
.
.
```

2. Verify that the expected nodes are still connected:

```
show cdp neighbors
```

Show example

```
cs1# show cdp neighbors

Capability Codes: R - Router, T - Trans-Bridge, B - Source-Route-
Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater,
                  V - VoIP-Phone, D - Remotely-Managed-Device,
                  s - Supports-STP-Dispute

Device-ID          Local Intrfce  Hldtme  Capability  Platform
Port ID
node1              Eth1/1        133     H           FAS2980
e0a
node2              Eth1/2        133     H           FAS2980
e0a
cs1                Eth1/35       175     R S I s     N9K-C9336C
Eth1/35
cs1                Eth1/36       175     R S I s     N9K-C9336C
Eth1/36

Total entries displayed: 4
```

3. Verify that the cluster nodes are in their correct cluster VLANs using the following commands:

```
show vlan brief
```

```
show interface trunk
```

Show example

```
cs1# show vlan brief
```

VLAN Name	Status	Ports
1 default	active	Pol, Eth1/1, Eth1/2, Eth1/3 Eth1/4, Eth1/5, Eth1/6, Eth1/7 Eth1/8, Eth1/35, Eth1/36 Eth1/9/1, Eth1/9/2, Eth1/9/3 Eth1/9/4, Eth1/10/1, Eth1/10/2 Eth1/10/3, Eth1/10/4
17 VLAN0017	active	Eth1/1, Eth1/2, Eth1/3, Eth1/4 Eth1/5, Eth1/6, Eth1/7, Eth1/8 Eth1/9/1, Eth1/9/2, Eth1/9/3 Eth1/9/4, Eth1/10/1, Eth1/10/2 Eth1/10/3, Eth1/10/4
18 VLAN0018	active	Eth1/1, Eth1/2, Eth1/3, Eth1/4 Eth1/5, Eth1/6, Eth1/7, Eth1/8 Eth1/9/1, Eth1/9/2, Eth1/9/3 Eth1/9/4, Eth1/10/1, Eth1/10/2 Eth1/10/3, Eth1/10/4
31 VLAN0031	active	Eth1/11, Eth1/12, Eth1/13 Eth1/14, Eth1/15, Eth1/16 Eth1/17, Eth1/18, Eth1/19 Eth1/20, Eth1/21, Eth1/22
32 VLAN0032	active	Eth1/23, Eth1/24, Eth1/25

```

Eth1/28                               Eth1/26, Eth1/27,
Eth1/31                               Eth1/29, Eth1/30,
Eth1/34                               Eth1/32, Eth1/33,
33   VLAN0033                         active   Eth1/11, Eth1/12,
Eth1/13                               Eth1/14, Eth1/15,
Eth1/16                               Eth1/17, Eth1/18,
Eth1/19                               Eth1/20, Eth1/21,
Eth1/22                               Eth1/23, Eth1/24,
34   VLAN0034                         active   Eth1/26, Eth1/27,
Eth1/25                               Eth1/29, Eth1/30,
Eth1/28                               Eth1/32, Eth1/33,
Eth1/31
Eth1/34

```

```
cs1# show interface trunk
```

```

-----
Port          Native  Status      Port
              Vlan               Channel
-----
Eth1/1        1       trunking    --
Eth1/2        1       trunking    --
Eth1/3        1       trunking    --
Eth1/4        1       trunking    --
Eth1/5        1       trunking    --
Eth1/6        1       trunking    --
Eth1/7        1       trunking    --
Eth1/8        1       trunking    --
Eth1/9/1      1       trunking    --
Eth1/9/2      1       trunking    --
Eth1/9/3      1       trunking    --
Eth1/9/4      1       trunking    --
Eth1/10/1     1       trunking    --
Eth1/10/2     1       trunking    --
Eth1/10/3     1       trunking    --
Eth1/10/4     1       trunking    --
Eth1/11       33      trunking    --

```

Eth1/12	33	trunking	--
Eth1/13	33	trunking	--
Eth1/14	33	trunking	--
Eth1/15	33	trunking	--
Eth1/16	33	trunking	--
Eth1/17	33	trunking	--
Eth1/18	33	trunking	--
Eth1/19	33	trunking	--
Eth1/20	33	trunking	--
Eth1/21	33	trunking	--
Eth1/22	33	trunking	--
Eth1/23	34	trunking	--
Eth1/24	34	trunking	--
Eth1/25	34	trunking	--
Eth1/26	34	trunking	--
Eth1/27	34	trunking	--
Eth1/28	34	trunking	--
Eth1/29	34	trunking	--
Eth1/30	34	trunking	--
Eth1/31	34	trunking	--
Eth1/32	34	trunking	--
Eth1/33	34	trunking	--
Eth1/34	34	trunking	--
Eth1/35	1	trnk-bndl	Pol
Eth1/36	1	trnk-bndl	Pol
Pol	1	trunking	--

Port	Vlans Allowed on Trunk
------	------------------------

Eth1/1	1,17-18
Eth1/2	1,17-18
Eth1/3	1,17-18
Eth1/4	1,17-18
Eth1/5	1,17-18
Eth1/6	1,17-18
Eth1/7	1,17-18
Eth1/8	1,17-18
Eth1/9/1	1,17-18
Eth1/9/2	1,17-18
Eth1/9/3	1,17-18
Eth1/9/4	1,17-18
Eth1/10/1	1,17-18
Eth1/10/2	1,17-18
Eth1/10/3	1,17-18
Eth1/10/4	1,17-18

```
Eth1/11      31, 33
Eth1/12      31, 33
Eth1/13      31, 33
Eth1/14      31, 33
Eth1/15      31, 33
Eth1/16      31, 33
Eth1/17      31, 33
Eth1/18      31, 33
Eth1/19      31, 33
Eth1/20      31, 33
Eth1/21      31, 33
Eth1/22      31, 33
Eth1/23      32, 34
Eth1/24      32, 34
Eth1/25      32, 34
Eth1/26      32, 34
Eth1/27      32, 34
Eth1/28      32, 34
Eth1/29      32, 34
Eth1/30      32, 34
Eth1/31      32, 34
Eth1/32      32, 34
Eth1/33      32, 34
Eth1/34      32, 34
Eth1/35      1
Eth1/36      1
Po1          1
..
..
..
..
..
```



For specific port and VLAN usage details, refer to the banner and important notes section in your RCF.

4. Verify that the ISL between cs1 and cs2 is functional:

```
show port-channel summary
```

Show example

```
cs1# show port-channel summary
Flags:  D - Down          P - Up in port-channel (members)
        I - Individual    H - Hot-standby (LACP only)
        s - Suspended     r - Module-removed
        b - BFD Session Wait
        S - Switched      R - Routed
        U - Up (port-channel)
        p - Up in delay-lacp mode (member)
        M - Not in use. Min-links not met

-----
-----
Group Port-          Type      Protocol  Member Ports      Channel
-----
-----
1      Po1 (SU)      Eth       LACP           Eth1/35 (P)       Eth1/36 (P)
cs1#
```

5. Verify that the cluster LIFs have reverted to their home port:

```
network interface show -vserver Cluster
```

Show example

```
cluster1::*> network interface show -vserver Cluster
          Logical          Status      Network          Current
Current Is
Vserver   Interface             Admin/Oper  Address/Mask     Node
Port      Home
-----
Cluster
cluster1-01 cluster1-01_clus1 up/up      169.254.3.4/23
           e0d           true
cluster1-01 cluster1-01_clus2 up/up      169.254.3.5/23
           e0d           true
cluster1-02 cluster1-02_clus1 up/up      169.254.3.8/23
           e0d           true
cluster1-02 cluster1-02_clus2 up/up      169.254.3.9/23
           e0d           true
cluster1-03 cluster1-03_clus1 up/up      169.254.1.3/23
           e0b           true
cluster1-03 cluster1-03_clus2 up/up      169.254.1.1/23
           e0b           true
cluster1-04 cluster1-04_clus1 up/up      169.254.1.6/23
           e0b           true
cluster1-04 cluster1-04_clus2 up/up      169.254.1.7/23
           e0b           true
```

If any cluster LIFs have not returned to their home ports, revert them manually from the local node:

```
network interface revert -vserver vsrv_name -lif lif_name
```

6. Verify that the cluster is healthy:

```
cluster show
```

Show example

```
cluster1::*> cluster show
Node           Health Eligibility Epsilon
-----
cluster1-01   true   true        false
cluster1-02   true   true        false
cluster1-03   true   true         true
cluster1-04   true   true        false
```

7. Verify the connectivity of the remote cluster interfaces:

ONTAP 9.9.1 and later

You can use the `network interface check cluster-connectivity` command to start an accessibility check for cluster connectivity and then display the details:

```
network interface check cluster-connectivity start and network interface check cluster-connectivity show
```

```
cluster1::*> network interface check cluster-connectivity start
```

NOTE: Wait for a number of seconds before running the `show` command to display the details.

```
cluster1::*> network interface check cluster-connectivity show
```

Packet	Source	Destination
Node	Date	LIF
Loss		
-----	-----	-----
node1		
3/5/2022 19:21:18 -06:00	cluster1-01_clus2	cluster1-02-
clus1 none		
3/5/2022 19:21:20 -06:00	cluster1-01_clus2	cluster1-
02_clus2 none		
node2		
3/5/2022 19:21:18 -06:00	cluster1-02_clus2	cluster1-
01_clus1 none		
3/5/2022 19:21:20 -06:00	cluster1-02_clus2	cluster1-
01_clus2 none		

All ONTAP releases

For all ONTAP releases, you can also use the `cluster ping-cluster -node <name>` command to check the connectivity:

```
cluster ping-cluster -node <name>
```

```

cluster1::*> cluster ping-cluster -node local
Host is cluster1-03
Getting addresses from network interface table...
Cluster cluster1-03_clus1 169.254.1.3 cluster1-03 e0a
Cluster cluster1-03_clus2 169.254.1.1 cluster1-03 e0b
Cluster cluster1-04_clus1 169.254.1.6 cluster1-04 e0a
Cluster cluster1-04_clus2 169.254.1.7 cluster1-04 e0b
Cluster cluster1-01_clus1 169.254.3.4 cluster1-01 e0a
Cluster cluster1-01_clus2 169.254.3.5 cluster1-01 e0d
Cluster cluster1-02_clus1 169.254.3.8 cluster1-02 e0a
Cluster cluster1-02_clus2 169.254.3.9 cluster1-02 e0d
Local = 169.254.1.3 169.254.1.1
Remote = 169.254.1.6 169.254.1.7 169.254.3.4 169.254.3.5 169.254.3.8
169.254.3.9
Cluster Vserver Id = 4294967293
Ping status:
.....
Basic connectivity succeeds on 12 path(s)
Basic connectivity fails on 0 path(s)
.....
Detected 9000 byte MTU on 12 path(s):
    Local 169.254.1.3 to Remote 169.254.1.6
    Local 169.254.1.3 to Remote 169.254.1.7
    Local 169.254.1.3 to Remote 169.254.3.4
    Local 169.254.1.3 to Remote 169.254.3.5
    Local 169.254.1.3 to Remote 169.254.3.8
    Local 169.254.1.3 to Remote 169.254.3.9
    Local 169.254.1.1 to Remote 169.254.1.6
    Local 169.254.1.1 to Remote 169.254.1.7
    Local 169.254.1.1 to Remote 169.254.3.4
    Local 169.254.1.1 to Remote 169.254.3.5
    Local 169.254.1.1 to Remote 169.254.3.8
    Local 169.254.1.1 to Remote 169.254.3.9
Larger than PMTU communication succeeds on 12 path(s)
RPC status:
6 paths up, 0 paths down (tcp check)
6 paths up, 0 paths down (udp check)

```

What's next?

After you've upgraded the RCF, you can [configure switch health monitoring](#).

Reset the 9336C-FX2 shared switch to factory defaults

To reset the 9336C-FX2 shared switch to factory defaults, you must erase the 9336C-FX2

switch settings.

About this task

- You must be connected to the switch using the serial console.
- This task resets the configuration of the management network.

Steps

1. Erase the existing configuration:

```
write erase
```

```
(cs2)# write erase
```

```
Warning: This command will erase the startup-configuration.  
Do you wish to proceed anyway? (y/n) [n] y
```

2. Reload the switch software:

```
reload
```

```
(cs2)# reload
```

```
This command will reboot the system. (y/n)? [n] y
```

The system reboots and enters the configuration wizard. During the boot, if you receive the prompt “Abort Auto Provisioning and continue with normal setup? (yes/no)[n]”, you should respond **yes** to proceed.

What's next

After you've reset your switches, you can [reconfigure](#) them as needed.

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.