



Configure SVM-scoped NDMP

ONTAP 9

NetApp
January 22, 2026

This PDF was generated from <https://docs.netapp.com/us-en/ontap/ndmp/enable-svm-scoped-ndmp-cluster-task.html> on January 22, 2026. Always check docs.netapp.com for the latest.

Table of Contents

Configure SVM-scoped NDMP	1
Enable SVM-scoped NDMP on the ONTAP cluster	1
Enable backup users for ONTAP NDMP authentication	1
Configure ONTAP LIFs for SVM-scoped NDMP	3

Configure SVM-scoped NDMP

Enable SVM-scoped NDMP on the ONTAP cluster

If the DMA supports the Cluster Aware Backup (CAB) extension, you can back up all the volumes hosted across different nodes in a cluster by enabling SVM-scoped NDMP, enabling NDMP service on the cluster (admin SVM), and configuring LIFs for data and control connection.

Before you begin

The CAB extension must be supported by the DMA.

About this task

Turning off node-scoped NDMP mode enables SVM-scoped NDMP mode on the cluster.

Steps

1. Enable SVM-scoped NDMP mode:

```
cluster1::> system services ndmp node-scope-mode off
```

SVM-scoped NDMP mode is enabled.

2. Enable NDMP service on the admin SVM:

```
cluster1::> vserver services ndmp on -vserver cluster1
```

The authentication type is set to `challenge` by default and plaintext authentication is disabled.



For secure communication, you should keep plaintext authentication disabled.

3. Verify that NDMP service is enabled:

```
cluster1::> vserver services ndmp show
```

Vserver	Enabled	Authentication type
cluster1	true	challenge
vs1	false	challenge

Enable backup users for ONTAP NDMP authentication

To authenticate SVM-scoped NDMP from the backup application, there must be an

administrative user with sufficient privileges and an NDMP password.

About this task

You must generate an NDMP password for backup admin users. You can enable backup admin users at the cluster or SVM level, and if necessary, you can create a new user. By default, the users with the following roles can authenticate for NDMP backup:

- Cluster-wide: admin or backup
- Individual SVMs: vsadmin or vsadmin-backup

If you are using an NIS or LDAP user, the user must exist on the respective server. You cannot use an Active Directory user.

Steps

1. Display the current admin users and permissions:

```
security login show
```

Learn more about `security login show` in the [ONTAP command reference](#).

2. If needed, create a new NDMP backup user with the `security login create` command and the appropriate role for cluster-wide or individual SVM privileges.

You can specify a local backup user name or an NIS or LDAP user name for the `-user-or-group-name` parameter.

The following command creates the backup user `backup_admin1` with the `backup` role for the entire cluster:

```
cluster1::> security login create -user-or-group-name backup_admin1  
-application ssh -authmethod password -role backup
```

The following command creates the backup user `vsbackup_admin1` with the `vsadmin-backup` role for an individual SVM:

```
cluster1::> security login create -user-or-group-name vsbackup_admin1  
-application ssh -authmethod password -role vsadmin-backup
```

Enter a password for the new user and confirm.

Learn more about `security login create` in the [ONTAP command reference](#).

3. Generate a password for the admin SVM by using the `vserver services ndmp generate password` command.

The generated password must be used to authenticate the NDMP connection by the backup application.

```
cluster1::> vserver services ndmp generate-password -vserver cluster1
-user backup_admin1

Vserver: cluster1
User: backup_admin1
Password: qG5CqQHYxw7tE57g
```

Configure ONTAP LIFs for SVM-scoped NDMP

You must identify the LIFs that will be used for establishing a data connection between the data and tape resources, and for control connection between the admin SVM and the backup application. After identifying the LIFs, you must verify the service and failover policies are set.



Beginning with ONTAP 9.10.1, firewall policies are deprecated and wholly replaced with LIF service policies. For more information, see [Manage supported traffic](#).

ONTAP 9.10.1 or later

Steps

1. Identify the intercluster LIF hosted on the nodes by using the `network interface show` command with the `-service-policy` parameter.

```
network interface show -service-policy default-intercluster
```

Learn more about `network interface show` in the [ONTAP command reference](#).

2. Identify the management LIF hosted on the nodes by using the `network interface show` command with the `-service-policy` parameter.

```
network interface show -service-policy default-management
```

3. Ensure that the intercluster LIF includes the `backup-ndmp-control` service:

```
network interface service-policy show
```

Learn more about `network interface service-policy show` in the [ONTAP command reference](#).

4. Ensure that the failover policy is set appropriately for all the LIFs:

- a. Verify that the failover policy for the cluster-management LIF is set to `broadcast-domain-wide`, and the policy for the intercluster and node-management LIFs is set to `local-only` by using the `network interface show -failover` command.

The following command displays the failover policy for the cluster-management, intercluster, and node-management LIFs:

```

cluster1::> network interface show -failover

      Logical          Home          Failover      Failover
Vserver  Interface      Node:Port    Policy       Group
-----
cluster   cluster1_clus1  cluster1-1:e0a  local-only  cluster
                                         Failover

Targets:
      .....
cluster1  cluster_mgmt    cluster1-1:e0m  broadcast-  Default
                                         domain-wide
                                         Failover

Targets:
      .....
IC1          cluster1-1:e0a  local-only  Default
                                         Failover

Targets:
IC2          cluster1-1:e0b  local-only  Default
                                         Failover

Targets:
      .....
cluster1-1 c1-1_mgmt1    cluster1-1:e0m  local-only  Default
                                         Failover

Targets:
      .....
cluster1-2 c1-2_mgmt1    cluster1-2:e0m  local-only  Default
                                         Failover

Targets:
      .....

```

b. If the failover policies are not set appropriately, modify the failover policy by using the `network interface modify` command with the `-failover-policy` parameter.

```

cluster1::> network interface modify -vserver cluster1 -lif IC1
-failover-policy local-only

```

Learn more about `network interface modify` in the [ONTAP command reference](#).

5. Specify the LIFs that are required for data connection by using the `vserver services ndmp modify` command with the `preferred-interface-role` parameter.

```

cluster1::> vserver services ndmp modify -vserver cluster1
-preferred-interface-role intercluster,cluster-mgmt,node-mgmt

```

6. Verify that the preferred interface role is set for the cluster by using the vserver services ndmp show command.

```
cluster1::> vserver services ndmp show -vserver cluster1

        Vserver: cluster1
        NDMP Version: 4
        .....
        .....
Preferred Interface Role: intercluster, cluster-mgmt, node-mgmt
```

ONTAP 9.9 or earlier

Steps

1. Identify the intercluster, cluster-management, and node-management LIFs by using the network interface show command with the -role parameter.

The following command displays the intercluster LIFs:

```
cluster1::> network interface show -role intercluster

        Logical          Status        Network        Current
Current Is
Vserver      Interface      Admin/Oper Address/Mask      Node
Port        Home
-----  -----
-----  -----
cluster1      IC1          up/up        192.0.2.65/24      cluster1-1
e0a        true
cluster1      IC2          up/up        192.0.2.68/24      cluster1-2
e0b        true
```

The following command displays the cluster-management LIF:

```
cluster1::> network interface show -role cluster-mgmt

        Logical          Status        Network        Current
Current Is
Vserver      Interface      Admin/Oper Address/Mask      Node
Port        Home
-----  -----
-----  -----
cluster1      cluster_mgmt  up/up        192.0.2.60/24      cluster1-2
e0M        true
```

The following command displays the node-management LIFs:

```
cluster1::> network interface show -role node-mgmt

      Logical          Status      Network      Current
Current Is
Vserver    Interface      Admin/Oper Address/Mask      Node
Port      Home
-----  -----
-----  -----
cluster1  cluster1-1_mgmt1  up/up      192.0.2.69/24  cluster1-1
e0M      true
          cluster1-2_mgmt1  up/up      192.0.2.70/24  cluster1-2
e0M      true
```

Learn more about `network interface show` in the [ONTAP command reference](#).

2. Ensure that the firewall policy is enabled for NDMP on the intercluster, cluster-management (cluster-mgmt), and node-management (node-mgmt) LIFs:
 - a. Verify that the firewall policy is enabled for NDMP by using the `system services firewall policy show` command.

The following command displays the firewall policy for the cluster-management LIF:

```
cluster1::> system services firewall policy show -policy cluster

Vserver    Policy      Service      Allowed
-----  -----
cluster    cluster
          dns          0.0.0.0/0
          http         0.0.0.0/0
          https        0.0.0.0/0
          ndmp         0.0.0.0/0
          ndmps        0.0.0.0/0
          ntp          0.0.0.0/0
          rsh          0.0.0.0/0
          snmp         0.0.0.0/0
          ssh          0.0.0.0/0
          telnet        0.0.0.0/0
10 entries were displayed.
```

The following command displays the firewall policy for the intercluster LIF:

```
cluster1::> system services firewall policy show -policy
intercluster

Vserver      Policy      Service      Allowed
-----      -----
cluster1      intercluster dns      -
                           http      -
                           https     -
                           ndmp      0.0.0.0/0, ::/0
                           ndmps     -
                           ntp       -
                           rsh       -
                           ssh       -
                           telnet    -

9 entries were displayed.
```

The following command displays the firewall policy for the node-management LIF:

```
cluster1::> system services firewall policy show -policy mgmt

Vserver      Policy      Service      Allowed
-----      -----
cluster1-1    mgmt       dns      0.0.0.0/0, ::/0
                           http      0.0.0.0/0, ::/0
                           https     0.0.0.0/0, ::/0
                           ndmp      0.0.0.0/0, ::/0
                           ndmps     0.0.0.0/0, ::/0
                           ntp       0.0.0.0/0, ::/0
                           rsh       -
                           snmp      0.0.0.0/0, ::/0
                           ssh       0.0.0.0/0, ::/0
                           telnet    -

10 entries were displayed.
```

b. If the firewall policy is not enabled, enable the firewall policy by using the `system services firewall policy modify` command with the `-service` parameter.

The following command enables firewall policy for the intercluster LIF:

```
cluster1::> system services firewall policy modify -vserver
cluster1 -policy intercluster -service ndmp 0.0.0.0/0
```

3. Ensure that the failover policy is set appropriately for all the LIFs:

a. Verify that the failover policy for the cluster-management LIF is set to broadcast-domain-wide, and the policy for the intercluster and node-management LIFs is set to local-only by using the network interface show -failover command.

The following command displays the failover policy for the cluster-management, intercluster, and node-management LIFs:

```
cluster1::> network interface show -failover

      Logical          Home          Failover
Failover
Vserver   Interface      Node:Port      Policy
Group

-----
-----
cluster   cluster1_clus1   cluster1-1:e0a   local-only
cluster

Targets:
      .....

cluster   cluster_mgmt      cluster1-1:e0m   broadcast-domain-
wide Default

Targets:
      .....

      IC1          cluster1-1:e0a   local-only
Default

Targets:
      .....

      IC2          cluster1-1:e0b   local-only
Default

Targets:
      .....

cluster1 cluster1_mgmt1   cluster1-1:e0m   local-only
Default

Targets:
      .....

cluster1 cluster1-2_mgmt1   cluster1-2:e0m   local-only
Default

Targets:
      .....
```

b. If the failover policies are not set appropriately, modify the failover policy by using the `network interface modify` command with the `-failover-policy` parameter.

```
cluster1::> network interface modify -vserver cluster1 -lif IC1  
-failover-policy local-only
```

Learn more about `network interface modify` in the [ONTAP command reference](#).

4. Specify the LIFs that are required for data connection by using the `vserver services ndmp modify` command with the `preferred-interface-role` parameter.

```
cluster1::> vserver services ndmp modify -vserver cluster1  
-preferred-interface-role intercluster,cluster-mgmt,node-mgmt
```

5. Verify that the preferred interface role is set for the cluster by using the `vserver services ndmp show` command.

```
cluster1::> vserver services ndmp show -vserver cluster1  
  
          Vserver: cluster1  
          NDMP Version: 4  
          .....  
          .....  
          Preferred Interface Role: intercluster, cluster-mgmt,  
          node-mgmt
```

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—with prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.