



Cluster creation API methods

Element Software

NetApp

November 18, 2025

This PDF was generated from https://docs.netapp.com/us-en/element-software-128/api/reference_element_api_checkproposedcluster.html on November 18, 2025. Always check docs.netapp.com for the latest.

Table of Contents

- Cluster creation API methods 1
 - CheckProposedCluster 1
 - Parameters 1
 - Return values 1
 - Request example 1
 - Response example 2
 - New since version 2
 - CreateCluster 2
 - Parameters 2
 - Return values 4
 - Request example 4
 - Response example 5
 - New since version 5
 - GetBootstrapConfig 5
 - Parameters 5
 - Return values 5
 - Request example 6
 - Response example 7
 - New since version 9
 - Find more information 9

Cluster creation API methods

CheckProposedCluster

You can use the `CheckProposedCluster` method to test a set of storage nodes before creating a storage cluster with them to identify possible errors or faults that would occur from the attempt, such as unbalanced mixed node capabilities or node types that are not supported for two-node storage clusters.

Parameters

This method has the following input parameter:

Name	Description	Type	Default value	Required
nodes	A list of storage IP addresses of the initial set of storage nodes making up the storage cluster.	string array	None	Yes
force	Set to true to run on all storage nodes in the storage cluster.	boolean	None	No

Return values

This method has the following return values:

Name	Description	Type
proposedClusterValid	Indicates whether or not the proposed storage nodes would make up a valid storage cluster. Possible values: • true • false	boolean
proposedClusterErrors	Errors that would occur if a storage cluster was created using the proposed storage nodes.	string array

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CheckProposedCluster",
  "params": {
    "nodes": [
      "192.168.1.11",
      "192.168.1.12",
      "192.168.1.13",
      "192.168.1.14"
    ]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id": 1,
  "result": {
    "proposedClusterValid": true,
    "proposedClusterErrors": [ ]
  }
}
```

New since version

11.0

CreateCluster

You can use the `CreateCluster` method to initialize the node in a cluster that has ownership of the "mvip" and "svip" addresses. Each new cluster is initialized using the management IP (MIP) of the first node in the cluster. This method also automatically adds all the nodes being configured into the cluster. You only need to use this method once each time a new cluster is initialized.



After you log in to the master node for the cluster and run the [GetBootStrapConfig](#) method to get the IP addresses for the rest of the nodes that you want to include in the cluster, you can run the `CreateCluster` method against the master node for the cluster.

Parameters

This method has the following input parameters:

Name	Description	Type	Default value	Required
acceptEula	Indicate your acceptance of the End User License Agreement when creating this cluster. To accept the EULA, set this parameter to true.	boolean	None	Yes
attributes	List of name-value pairs in JSON object format.	JSON object	None	No
enableSoftwareEncryptionAtRest	Enable this parameter to use software-based encryption at rest. Defaults to false on all clusters. After software encryption at rest is enabled, it cannot be disabled on the cluster.	boolean	true	No
mvip	Floating (virtual) IP address for the cluster on the management network.	string	None	Yes
nodes	CIP/SIP addresses of the initial set of nodes making up the cluster. This node's IP must be in the list.	string array	None	Yes
orderNumber	Alphanumeric sales order number. Required on software-based platforms.	string	None	No (hardware-based platforms) Yes (software-based platforms)
password	Initial password for the cluster admin account.	string	None	Yes

Name	Description	Type	Default value	Required
serialNumber	Nine-digit alphanumeric Serial Number. May be required on software-based platforms.	string	None	No (hardware-based platforms) Yes (software-based platforms)
svip	Floating (virtual) IP address for the cluster on the storage (iSCSI) network.	string	None	Yes
username	User name for the cluster admin.	string	None	Yes

Return values

This method has no return values.

Request example

Requests for this method are similar to the following example:

```
{
  "method": "CreateCluster",
  "params": {
    "acceptEula": true,
    "mvip": "10.0.3.1",
    "svip": "10.0.4.1",
    "username": "Admin1",
    "password": "9R7ka4rEPa2uREtE",
    "attributes": {
      "clusteraccountnumber": "axdf323456"
    },
    "nodes": [
      "10.0.2.1",
      "10.0.2.2",
      "10.0.2.3",
      "10.0.2.4"
    ]
  },
  "id": 1
}
```

Response example

This method returns a response similar to the following example:

```
{
  "id" : 1,
  "result" : {}
}
```

New since version

9.6

Find more information

- [GetBootstrapConfig](#)
- [SolidFire and Element Software Documentation](#)
- [Documentation for earlier versions of NetApp SolidFire and Element products](#)

GetBootstrapConfig

You can use the `GetBootstrapConfig` method to get cluster and node information from the bootstrap configuration file. Use this API method on an individual node before it has been joined with a cluster. The information this method returns is used in the cluster configuration interface when you create a cluster.

Parameters

This method has no input parameters.

Return values

This method has the following return values:

Name	Description	Type
clusterName	Name of the cluster.	string
mvip	Cluster MVIP address. Empty if the node is not part of a cluster.	string
nodeName	Name of the node.	string

Name	Description	Type
nodes	List of information about each node that is actively waiting to join the cluster. Possible values: • chassisType: (string) Hardware platform of the node. • cip: (string) Cluster IP address of the node. • compatible: (boolean) Indicates if the node is compatible with the node the API call was executed against. • hostname: (string) Host name of the node. • mip: (string) The IPv4 management IP address of the node. • mipV6: (string) The IPv6 management IP address of the node. • nodeType: (string) Model name of the node. • version: (string) Version of software currently installed on the node.	JSON object array
svip	Cluster SVIP address. Null if the node is not part of a cluster.	string
version	Version of Element software currently installed on the node that was called by this API method.	string

Request example

Requests for this method are similar to the following example:

```
{
  "method": "GetBootstrapConfig",
  "params": {},
  "id" : 1
}
```

Response example

This method returns a response similar to the following example:

```

{
  "id":1,
  "result":{
    "clusterName":"testname",
    "nodeName":"testnode",
    "svip": "10.117.1.5",
    "mvip": "10.117.1.6",
    "nodes":[
      {
        "chassisType":"R630",
        "cip":"10.117.115.16",
        "compatible":true,
        "hostname":"NLABP1132",
        "mip":"10.117.114.16",
        "mipV6":"fd20:8b1e:b256:45a::16",
        "nodeType":"SF2405",
        "role":"Storage",
        "version":"11.0"
      },
      {
        "chassisType":"R630",
        "cip":"10.117.115.17",
        "compatible":true,
        "hostname":"NLABP1133",
        "mip":"10.117.114.17",
        "mipV6":"fd20:8b1e:b256:45a::17",
        "nodeType":"SF2405",
        "role":"Storage",
        "version":"11.0"
      },
      {
        "chassisType":"R630",
        "cip":"10.117.115.18",
        "compatible":true,
        "hostname":"NLABP1134",
        "mip":"10.117.114.18",
        "mipV6":"fd20:8b1e:b256:45a::18",
        "nodeType":"SF2405",
        "role":"Storage",
        "version":"11.0"
      }
    ],
    "version":"11.0"
  }
}

```

New since version

9.6

Find more information

[CreateCluster](#)

Copyright information

Copyright © 2025 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.