



Configuring cron job schedules on the remote site after transitioning a MetroCluster configuration

ONTAP 7-Mode Transition

Ivana Devine
March 25, 2021

Table of Contents

Configuring cron job schedules on the remote site after transitioning a MetroCluster configuration 1

Configuring cron job schedules on the remote site after transitioning a MetroCluster configuration

The cron job schedules created during transition are not replicated to the remote site, and therefore negotiated switchover fails after transition. You must manually create the cron job schedules on the remote site after transition.

Storage cutover for the 7-Mode active site must have been completed successfully.

Steps

1. Record the cron job messages generated at the storage cutover to identify the job schedules that must be replicated to the remote site.

ID	Type(Tags)	Message	Recommended Action	Affected Objects
88101	Warning	Cron jobs have been configured by the 7-Mode Transition Tool on the local site of this MetroCluster configuration. These cron jobs on the local cluster must be applied to the remote cluster of this MetroCluster configuration to support negotiated switchover and switchback operations.	Execute the following cluster commands on the remote site of this MetroCluster configuration.	Affected Objects
90702	Warning	Affected Objects : MetroCluster Cron Jobs		
91061	Information	<pre># Cron job schedules # For Transition to MetroCluster, the following schedules must be applied to the remote site to enable negotiated switchover and switchback. job schedule cron create -name CronJob_mcc_vserver1_mcc_vol1_0 -hour 0 -minute 0 job schedule cron create -name CronJob_mcc_vserver1_mcc_vol1_1 -hour 8,12,16,20 -minute 0</pre>		

2. From the cluster CLI of the remote site, run the `job schedule cron create` commands recorded in [Step 1](#).

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.