



Continuing with the transition if ignorable errors occur

ONTAP 7-Mode Transition

NetApp
February 11, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-7mode-transition/copy-free/reference_ignorable_errors_during_transition.html on February 11, 2024. Always check docs.netapp.com for the latest.

Table of Contents

Continuing with the transition if ignorable errors occur	1
Ignorable errors during transition	1

Continuing with the transition if ignorable errors occur

During the transition, you might encounter some errors that block the transition. You can choose to ignore some of these errors by acknowledging the issues through the 7-Mode Transition Tool CLI. You should rerun the failed operation after ignoring the error to continue with the transition.

When you acknowledge an error, it means that you have understood the impact of these errors and acknowledged them.

You must rerun the transition operation after ignoring the error. In some cases, after you acknowledge the issue, Data ONTAP performs corrective actions on the affected aggregates and volumes when the operation is run the next time.

Steps

1. If the transition operation results in any ignorable errors, run the following command from the 7-Mode Transition Tool CLI:

```
transition cft ignorableerrors add -p project_name -c ignorable_errorcategory
```

ignorable_errorcategory is the type of error that you can ignore.

[Ignorable errors during transition](#)

2. Rerun the transition operation.

The blocking error changes to a warning and the error is shown as `acknowledged`. You can continue the transition with the warning.

Ignorable errors during transition

You might encounter some ignorable errors during the transition. These errors can occur during the precheck, cabling, import, or commit operation of a copy-free transition project. You must acknowledge these errors before continuing with transition.

When you add any ignorable error category to the copy-free transition project by using the 7-Mode Transition Tool CLI, it means that you have understood the impact of the error. You must rerun the transition operation after ignoring the error. At this time, the blocking error changes to a warning message, and the error is shown as “acknowledged”. You can continue the transition with the warning.

Precheck operation: ignorable error categories

Category	When the error is displayed
<code>ignore-source-not-multipath</code>	7-Mode disk shelves are not in a multipath configuration.

Category	When the error is displayed
ignore-target-not-multipath	Disk shelves in the target cluster nodes are not in a multipath configuration.
ignore-source-storage-fault	7-Mode disk shelves have some fault (as displayed in the output of the <code>storage show fault</code> command).
ignore-target-storage-fault	Disk shelves in the target cluster nodes have some fault (as displayed in the output of the <code>system node run -node node_name -command storage show fault</code> command).
ignore-target-port-requirement	Target cluster nodes do not have a sufficient number of ports available to connect the 7-Mode disk shelves.
ignore-aggr-space-less-than-5-percent	7-Mode aggregates are out of space because the free space in the 7-Mode aggregates is less than 5% of physical space.
ignore-aggr-logical-space-more-than-97-percent	7-Mode aggregates are out of space because the logical space in the aggregate is more than 97% full.
ignore-aggr-snapshot-spill-more-than-4-percent	7-Mode aggregates are out of space because Snapshot copies occupy more space than that allocated for the Snapshot copy reserve.
ignore-aggr-physical-space-more-than-89-percent-and-snapshot-spill	7-Mode aggregates are out of space because the total used physical space is more than 89% and the Snapshot copies occupy more space than that allocated for the Snapshot copy reserve.
ignore-volumes-with-file-guarantee	7-Mode volumes have space guarantee set to <code>file</code> , which is not supported in ONTAP.
ignore-volumes-with-disabled-guarantees	Space guarantee of volumes is currently disabled due to lack of space in the volumes.
nfs-qtrees-exported	<p>Qtree export rules are present in the 7-Mode system.</p> <p>Acknowledging this error means that you have understood the differences in the qtree export rules between Data ONTAP operating in 7-Mode and ONTAP. You might have to perform some manual steps after the NFS exports rules are applied by the 7-Mode Transition Tool.</p> <p>7MTT Precheck 10111 - Transitioning 7-Mode volumes that have qtree-level exports</p>

Category	When the error is displayed
ignore-configuration-limits-check	<p>Objects and configurations to be transitioned exceed a certain limit. The storage cutover can take a long time and you must prepare for the downtime.</p> <p>Considerations for reducing the storage cutover time during Copy-Free Transition</p>
ignore-cifs-ad-domain-mismatch	<p>The 7-Mode Transition Tool continues with the transition of the CIFS configuration even if the CIFS Active Directory domain of the 7-Mode system is different from the CIFS Active Directory domain of the target SVM.</p> <p>You must ensure that the CIFS Active Directory domains of the 7-Mode system and the target SVM are trusted domains. Otherwise, the transition of CIFS configurations to the target SVM fails.</p> <p>How to transition CIFS configurations when Active Directory Domain of CIFS server on 7-Mode and target SVM are different</p>

Cabling verification operation: ignorable error categories

Category	When the error is displayed
ignore-missing-spare-disks	One or more 7-Mode spare disks are not detected by the target cluster nodes.
ignore-missing-degraded-aggr-disks	<p>Cannot detect up to two disks from any of the 7-Mode RAID-DP RAID groups or one disk from any of the 7-Mode RAID-4 RAID groups on the target cluster nodes.</p> <p>Continuing with the transition makes such aggregates degraded after the aggregates are transitioned.</p>

Import operation: ignorable error categories

If you add an ignorable error category to the copy-free transition project during the import operation, Data ONTAP performs some corrective action on the aggregates and volumes in addition to changing the blocking error to a warning.

Category	When the error is displayed	Corrective action if the error is acknowledged and import operation is run again
ignore-aggregates-with-32bit-snapshot-for-import	32-bit Snapshot copies are detected in the 7-Mode aggregate.	32-bit Snapshot copies are deleted from all of the 7-Mode aggregates that are part of this project.
transition-dirty-aggregates-during-import	One of the transitioning aggregates was not cleanly shut down on the 7-Mode storage system.	All of the 7-Mode aggregates that were not cleanly shut down are transitioned. This might result in data loss after transition.
ignore-aggregates-not-being-online-for-import	The aggregate was not online when the 7-Mode storage system was halted.	All of the offline aggregates are brought online.
ignore-volumes-with-32bit-snapshot-for-import	32-bit Snapshot copies are detected in the 7-Mode volume.	32-bit Snapshot copies are deleted from all of the 7-Mode volumes that are part of this project.
ignore-volumes-with-dirty-file-system-for-import	One of the transitioning volumes was not cleanly shut down on the 7-Mode storage system.	All of the 7-Mode volumes that were not cleanly shut down are transitioned. This might result in data loss after transition.
transition-offline-volumes-during-import	The volume was not online when the 7-Mode storage system was halted.	All of the offline volumes are brought online.
transition-restricted-volumes-during-import	The volume was in the restricted state when the 7-Mode storage system was halted.	All of the restricted volumes are brought online.

Commit operation: ignorable error categories

If you add an ignorable error category to the copy-free transition project during the commit operation, ONTAP performs some corrective action on the aggregates and volumes in addition to changing the blocking error to a warning.

Category	When the error is displayed	Corrective action if the error is acknowledged and commit operation is run again
ignore-commit-offline-aggregates	Some of the transitioned aggregates are offline.	All of the offline aggregates are brought online.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.