



Transitioning RHEL DMMP devices without file systems

ONTAP 7-Mode Transition

NetApp
May 31, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-7mode-transition/san-host/task_verifying_that_rhel_luns_are_ready_for_transition_using_inventory_assessment_workbook.html on May 31, 2021. Always check docs.netapp.com for the latest.

Table of Contents

- Transitioning RHEL DMMP devices without file systems 1
 - Verifying that RHEL LUNs are ready for transition using the Inventory Assessment Workbook 1
 - Verifying that RHEL 5 LUNs are ready for transition using the CLI 1
 - Verifying that RHEL 6 DDMP devices are ready for transition using CLI 2
 - Testing DMMP devices without file systems on RHEL hosts before the cutover phase of copy-based transitions 2
 - Preparing for cutover when transitioning a Linux host DMMP device without a file system 4
 - Replacing 7-Mode LUN WWIDs on Linux hosts after transition of LUNs 4

Transitioning RHEL DMMP devices without file systems

Before transition of a Red Hat Enterprise Linux (RHEL) DMMP device without a file system, you must verify that the DMMP device does not have a file system. You must also perform specific steps to prepare for the cutover phase, and after transition you must replace the WWID.

Related information

[Verifying that RHEL LUNs are ready for transition using the Inventory Assessment Workbook](#)

[Verifying that RHEL 5 LUNs are ready for transition using the CLI](#)

[Verifying that RHEL 6 DDMP devices are ready for transition using CLI](#)

[Preparing for cutover when transitioning a Linux host DMMP device without a file system](#)

[Replacing 7-Mode LUN WWIDs on Linux hosts after transition of LUNs](#)

Verifying that RHEL LUNs are ready for transition using the Inventory Assessment Workbook

If your Red Hat Enterprise Linux (RHEL) 5 or RHEL 6 LUN is configured with a device mapper multipath (DMMP), you should verify that a file system is not configured before you transition the LUN from Data ONTAP operating in 7-Mode to clustered Data ONTAP.

This procedure applies to copy-based transitions and copy-free transitions.

Steps

1. Gather pretransition information from the *Inventory Assessment Workbook*.
2. Check whether the DMMP device entry is present under the **SAN Host File system** tab.

If the DMMP device entry is not present, a file system is not configured and you can transition the LUN.

Verifying that RHEL 5 LUNs are ready for transition using the CLI

If your Red Hat Enterprise Linux (RHEL) 5 LUN is configured with a device mapper multipath (DMMP), you should verify that a file system is not configured before you transition the LUN from Data ONTAP operating in 7-Mode to clustered Data ONTAP.

Steps

1. Locate the SCSI device name for the LUN to be transitioned:

```
sanlun lunshow
```

2. Identify the DMMP device name for the LUN:

```
multipath -ll
```

The DMMP device name can be a device handle ID (WWID) such as `360a980003753456258244538554b4b53`, or it can be an alias, such as, `dmmp_raw_lun`.

3. Verify that the LUN does not have a file system:

```
dumpe2fs/dev/mapper/DMMP device name
```

If the LUN does not have a file system, `Couldn't find valid filesystem superblock` is displayed in the output.

Verifying that RHEL 6 DMMP devices are ready for transition using CLI

Before you transition your Red Hat Enterprise Linux (RHEL) 6 DMMP device, you must verify that it is not part of a Logical Volume Manager (LVM) and that it does not have a file system.

Steps

1. Gather pretransition information from the *Inventory Assessment Workbook*.
2. Verify that the DMMP device exists in the `/dev/mapper` directory:

```
ls /dev/mapper/ DMMP_device_name
```

If the DMMP device is not displayed, the device might be using an alias or a user-friendly name.

3. Determine whether the DMMP device is part of an LVM and whether the DMMP device has a file system:

```
blkid
```

If the DMMP device is not part of an LVM and has no file system the device entry should not be displayed in `blkid` output.

Testing DMMP devices without file systems on RHEL hosts before the cutover phase of copy-based transitions

If you are using the 7-Mode Transition Tool (7MTT) 2.2 or later and Data ONTAP 8.3.2 or later to transition your Red Hat Enterprise Linux (RHEL) 5 host, you can test your transitioned clustered Data ONTAP LUNs to verify that you can bring your host and applications online before the cutover phase. Your source host can continue to run I/O to your source 7-Mode LUNs during testing.

Your new clustered Data ONTAP LUNs must be mapped to your test host and your LUNs must be ready for transition.

You should maintain hardware parity between the test host and the source host and you should perform the

following steps on the test host.

Your clustered Data ONTAP LUNs are in read/write mode during testing. They convert to read-only mode when testing is complete and you are preparing for the cutover phase.

Steps

1. After the baseline data copy is complete, select **Test Mode** in the 7MTT user interface (UI).
2. In the 7MTT UI, click **Apply Configuration**.
3. Rescan your new clustered Data ONTAP LUNs on the test host:

```
rescan-scsi-bus.sh
```

4. Obtain the new SCSI device names for the clustered Data ONTAP LUNs:

```
sanlun lun show
```

In the following example, `/dev/sdl` is the SCSI device name for the `lun_dmmp_raw` LUN, and `/dev/sdk` is the SCSI device name for the `lun_dmmp_raw_alias` LUN:

```
[root@ibmx3550-229-108 /]# sanlun lun show
controller(7mode/E-Series)/
vserver (cDOT/FlashRay lun-pathname filename
-----
vs_brb   /vol/dmmp_raw_vol/lun_dmmp_raw           /dev/sdl
vs_brb   /vol/dmmp_raw_alias_vol/lun_dmmp_raw_alias /dev/sdk
```

5. Obtain the device handle IDs (WWIDs) for the clustered Data ONTAP LUNs:

```
/sbin/scsi_id -g-u-s /block/SCSI_device_name
```

The following is an example of a WWID: "3600a09804d532d79565d47617679764d"

6. Check whether an alias is defined in the `/etc/multipath.conf` file on the source host.
7. If there is an alias defined on the source host, add the alias to the `/etc/multipath.conf` file on the test host, but replace the 7-Mode device handle ID with the clustered Data ONTAP LUN ID.
8. Update the DMMP alias settings:

```
multipath
```

9. Verify that the DMMP alias name correctly references the clustered Data ONTAP LUN:

```
multipath -ll
```

10. Perform your testing as needed.
11. After you have completed your testing, shut down the test host:

```
shutdown -h -t0 now
```

12. In the 7MTT UI, click **Finish Testing**.

If your clustered Data ONTAP LUNs are to be remapped to your source host, you must prepare your source host for the cutover phase. If your clustered Data ONTAP LUNs are to remain mapped to your test host, no further steps are required on the test host.

Related information

[Gathering pretransition information from the Inventory Assessment Workbook](#)

[Verifying that RHEL LUNs are ready for transition using the Inventory Assessment Workbook](#)

[Preparing for cutover when transitioning a Linux host DMMP device without a file system](#)

Preparing for cutover when transitioning a Linux host DMMP device without a file system

If you are transitioning a DMMP device without a file system from a Linux host, there are several steps you must perform before entering the cutover phase.

For FC configurations, you must have fabric connectivity and zoning to clustered Data ONTAP controllers.

For iSCSI configurations, your iSCSI sessions must be discovered and logged in to your clustered Data ONTAP controllers.

- For copy-based transitions, perform these steps before initiating the Storage Cutover operation in the 7-Mode Transition Tool (7MTT).
- For copy-free transitions, perform these steps before initiating the Export & Halt 7-Mode operation in 7MTT.

Steps

1. Stop I/O to the mount points.
2. Shut down the applications that are accessing the LUNs according to the application vendor's recommendations.
3. Flush the 7-Mode LUN DMMP device or alias:

```
multipath -f device_name
```

If needed, you can get the DMMP device name from the **OS Device ID** column under the SAN Host LUNs tab in the *Inventory Assessment Workbook*.

Replacing 7-Mode LUN WWIDs on Linux hosts after transition of LUNs

After LUN transition, the 7-Mode LUN WWID changes. You must replace it with the corresponding ONTAP LUN WWID before you can begin servicing data.

If you are doing a copy-free transition (CFT), then procedures for vol rehost must be complete.

See the [7-Mode Transition Tool Copy-Free Transition Guide](#) for details.

- For copy-based transitions (CBTs), perform these steps after completing the Storage cutover operation in the 7MTT.

- For CFTs, perform these steps after the Import Data & Configuration operation in the 7MTT is complete.

Steps

1. Generate the 7-Mode to ONTAP LUN mapping file:

- For CBTs, run the following command from the Linux host where the 7MTT is installed:

```
transition cbt export lunmap -p project-name -o file_path
```

For example:

```
transition cbt export lunmap -p SanWorkLoad -o c:/Libraires/Documents/7-to-C-LUN-MAPPING.csv
```

- For CFTs, run the following command from the system where the 7MTT is installed:

```
transition cft export lunmap -p project-name -s svm-name -o output-file
```

For example:

```
transition cft export lunmap -p SanWorkLoad -s svml -o c:/Libraries/Documents/7-to-C-LUN-MAPPING-svml.csv
```



You must run this command for each of your storage virtual machines (SVMs).

2. Make a note of the new ONTAP LUN device handle ID from the LUN mapping file.

3. Remove the SCSI devices created for 7-Mode LUNs:

- To remove all of the SCSI devices:

```
rescan-scsi-bus.sh -r
```

- To remove each SCSI device individually:

```
echo 1> /sys/block/SCSI_ID/delete
```

This command must be executed on all 7-Mode LUN SCSI devices. See the SCSI Device ID column on the SAN Host LUNs tab of the *Inventory Assessment Workbook* to identify the SCSI device IDs for the LUNs.

4. Discover new ONTAP LUNs:

```
rescan-scsi-bus.sh
```

5. Identify the SCSI devices of the new ONTAP LUNs:

```
sanlun lun show
```

6. Get the WWIDs for the new ONTAP LUNs:

```
/lib/udev/scsi_id -g -u -d /dev SCSI_dev
```

7. If a DMMP alias is defined, then update the `/etc/multipath.conf` file to replace the 7-Mode LUN WWID with its corresponding ONTAP LUN WWID, so that the DMMP alias points to the clustered Data ONTAP LUN:

```
cat /etc/multipath.conf
```

8. Configure the DMMP devices:

multipath

9. Verify that the DMMP alias is correctly referencing the ONTAP LUN WWID:

multipath -ll

In the following sample output, the DMMP alias `dmmp_raw_lun` is referencing `3600a098051764b2d4f3f453135452d31` as the ONTAP WWID:

```
root@IBMX3550M3-229-169 ~]# multipath -ll dmmp_raw_lun
dmmp_raw_lun (3600a098051764b2d4f3f453135452d31) dm-8 NETAPP, LUN C-Mode
[size=1.0G] [features=3 queue_if_no_path pg_init_retries 50]
[hwhandler=1 alua] [rw]
\_round-robin 0 [prio=50][enabled]
  \_5:0:0:6 sdx 65:112 [active][ready]
    \_8:0:0:6 sdab 65:176 [active][ready]
\_round-robin 0 [prio=10][enabled]
  \_6:0:0:6 sdy 65:128 [active][ready]
    \_7:0:0:6 sdaa 65:160 [active][ready]
```


Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.