



storage load commands

ONTAP 9.3 commands

NetApp
September 27, 2022

Table of Contents

- storage load commands 1
- storage load balance 1
- storage load show 1

storage load commands

storage load balance

Balance storage I/O across controller's initiator ports

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

This command is obsolete. I/O load is balanced automatically every five minutes.

Parameters

-node {<nodename>|local} - Node to balance on

The name of the clustered node for which information is being displayed.

Examples

This command has no effect.

storage load show

Display I/O statistics to array LUNs, grouped by initiator port.

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

This command is obsolete. The `storage load show` command displays the load distribution of I/O on the cluster.

Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>, ...` parameter, the command output also includes the specified field or fields. You can use `'-fields ?'` to display the fields to specify.

| [-switch]

The `switch` parameter adds switch information to the display.

| [-instance] }

If you specify the `-instance` parameter, the command displays detailed information about all fields.

[-node {<nodename>|local}] - Controller name

The name of the clustered node for which information is being displayed.

[-initiator-port <text>] - Initiator Port

The initiator port of the array LUN for which I/O stats are being displayed.

[-wwpn <text>] - Target Port WWPN

The World Wide Port Name of the array LUN for which I/O stats are being displayed.

[-serialnumber <text>] - Serial Number

The serial number of the array LUN for which I/O stats are being displayed.

[-lun <integer>] - LUN

The array LUN for which I/O stats are being displayed.

[-pct-io <text>] - %I/O

Percent of I/O bandwidth consumed by this array LUN.

[-io-blocks <integer>] - I/O (blocks)

Number of I/O blocks transferred.

[-switch-port <text>] - Switch Port

The initiator side switch port for this array LUN.

[-target-side-switch-port <text>] - Target Side Switch Port

The target side switch port for this array LUN.

Examples

```
cluster1::> storage load show -switch
Initiator port: 0a connected to vnbr3850s4:7.
```

LUN	Serial #	Target Port	Target Side Switch Port
1	D600020C00D3	50060e80004291c0	vnbr3850s5:12
0	0		
2	D600020C00D4	50060e80004291c0	vnbr3850s5:12
100	21		
5	D600020C00EF	50060e80004291c0	vnbr3850s5:12
0	0		

```
Initiator port: 0c connected to vnci9124s54:1-11.
```

LUN	Serial #	Target Port	Target Side Switch Port
3	D600020C00D9	50060e80004291c2	vnci9124s54:1-22
42	8		

```

  4 D600020C00DA          50060e80004291c2      vnci9124s54:1-22
36              7
  6 D600020C00F0          50060e80004291c2      vnci9124s54:1-22
15              3
Initiator port: 0a connected to vnbr3850s4:8.

LUN Serial #              Target Port              Target Side
%I/O I/O (blocks)        Switch Port
-----
-----
  2 D600020C00D4          50060e80004291c0      vnbr3850s5:12
0              0
Initiator port: 0a connected to vnbr3850s4:8.

LUN Serial #              Target Port              Target Side
%I/O I/O (blocks)        Switch Port
-----
-----
  5 D600020C00EF          50060e80004291c0      vnbr3850s5:12
0              0
  6 D600020C00F0          50060e80004291c0      vnbr3850s5:12
100            31
Initiator port: 0c connected to vnci9124s54:1-12.

LUN Serial #              Target Port              Target Side
%I/O I/O (blocks)        Switch Port
-----
-----
  1 D600020C00D3          50060e80004291c2      vnci9124s54:1-22
0              0
Initiator port: 0c connected to vnci9124s54:1-12.

LUN Serial #              Target Port              Target Side
%I/O I/O (blocks)        Switch Port
-----
-----
  3 D600020C00D9          50060e80004291c2      vnci9124s54:1-22
42              3
  4 D600020C00DA          50060e80004291c2      vnci9124s54:1-22
42              3
12 entries were displayed.

```

Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.