



metrocluster configuration-settings commands

ONTAP 9.5 commands

NetApp
November 11, 2022

Table of Contents

- metrocluster configuration-settings commands 1
 - metrocluster configuration-settings show-status 1
 - metrocluster configuration-settings connection check 3
 - metrocluster configuration-settings connection connect 4
 - metrocluster configuration-settings connection disconnect 8
 - metrocluster configuration-settings connection show 11
 - metrocluster configuration-settings dr-group create 16
 - metrocluster configuration-settings dr-group delete 18
 - metrocluster configuration-settings dr-group show 20
 - metrocluster configuration-settings interface create 21
 - metrocluster configuration-settings interface delete 25
 - metrocluster configuration-settings interface show 28

metrocluster configuration-settings commands

metrocluster configuration-settings show-status

Display the configuration settings status for a MetroCluster setup

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings show-status` command displays the configuration settings status for nodes in a MetroCluster setup. If a DR group has not been created, then status for nodes in the local cluster only are displayed.

Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command displays only the fields that you specify.

| [-instance] }

If this parameter is specified, the command displays detailed information about all entries.

[-cluster-uuid <UUID>] - Cluster UUID

If this parameter is specified, the command displays detailed information about all nodes in the cluster matching the specified `cluster-uuid`.

[-cluster <Cluster name>] - Cluster Name

If this parameter is specified, the command displays detailed information about all the nodes in the specified cluster.

[-node <text>] - Node Name

If this parameter is specified, the command displays information for the matching nodes.

[-configuration-status <text>] - Configuration Settings Status

If this parameter is specified, the command displays detailed information about all nodes with the specified configuration status.

[-config-error-info <text>] - Configuration Error Information

If this parameter is specified, the command displays detailed information about all nodes with the specified configuration error information.

Examples

The following example shows the display of MetroCluster setup status:

```
Nodes do not have a valid platform-specific personality value (equivalent to HAOSC parameter on non-Apollo platforms) for a MetroCluster setup.
```

```
clusA::> metrocluster configuration-settings show-status
Cluster          Node          Configuration Settings
Status
-----
clusA            A1            not a MetroCluster setup
                A2            not a MetroCluster setup
```

2 entries were displayed.

MetroCluster setup uses FC links rather than IP

```
xref:{relative_path}clusA::> metrocluster configuration-settings show-
status
```

```
Cluster          Node          Configuration Settings
Status
-----
clusA            A1            not applicable for FC and
SAS
                A2            not applicable for FC and
SAS
```

2 entries were displayed.

Output of the command when MetroCluster setup uses IP links and before
`"metrocluster configuration-settings dr-group create"` command is run:

```
clusA::> metrocluster configuration-settings show-status
Cluster          Node          Configuration Settings
Status
-----
```

```
clusA            A1            ready for DR group create
                A2            ready for DR group create
```

2 entries were displayed.

Output of the command after `"metrocluster configuration-settings dr-group
create"` command is run:

```
clusA::> metrocluster configuration-settings show-status
Cluster          Node          Configuration Settings
Status
-----
```

```
clusA
                A1            ready for interface create
                A2            ready for interface create
clusB
                B1            ready for interface create
                B2            ready for interface create
```

4 entries were displayed.

Output of the command after `"metrocluster configuration-settings
interface create"` command is run for every node:

```

clusA::> metrocluster configuration-settings show-status
Cluster          Node          Configuration Settings
Status
-----
clusA
              A1          ready for next interface
create
              A2          ready for connection connect
clusB
              B1          ready for connection connect
              B2          ready for connection connect

4 entries were displayed.
Output of the command after ` "metrocluster configuration-settings
connection connect" ` command is run:
usA::> metrocluster configuration-settings show-status
Cluster          Node          Configuration Settings
Status
-----
clusA
              A1          completed
              A2          completed
clusB
              B1          completed
              B2          completed

4 entries were displayed.
Output of the command after ` "metrocluster configuration-settings
connection connect" ` command is run and there are connection errors:
clusA::> metrocluster configuration-settings show-status
Cluster          Node          Configuration Settings
Status
-----
clusA
              A1          connection error
              A2          completed
clusB
              B1          connection error
              B2          completed

4 entries were displayed.

```

metrocluster configuration-settings connection check

Check the network connections between partner nodes

Availability: This command is available to *cluster* administrators at the *advanced* privilege level.

Description

The `metrocluster configuration-settings connection check` command checks the settings of a MetroCluster over IP configuration.

This command is used for MetroCluster configurations that are connected through IP links.

Examples

The following example shows the output for the check command in MetroCluster over IP configurations:

```
clusA::*> metrocluster configuration-settings connection check
[Job 68] Job succeeded: Connect is successful.
```

```
Begin connection check.
```

```
Start checking the partner cluster.
```

```
    Check partner cluster: PASS.
```

```
Start checking the configuration settings.
```

```
    Check configuration settings: PASS.
```

```
Start pinging the network endpoints from cluster "clusA".
```

```
    Ping network endpoints: PASS.
```

```
Start pinging the network endpoints from cluster "clusB".
```

```
    Ping network endpoints: PASS.
```

```
Start checking the network MTU sizes from cluster "clusA".
```

```
    Check network MTU sizes: PASS.
```

```
Start checking the network MTU sizes from cluster "clusB".
```

```
    Check network MTU sizes: PASS.
```

```
Start checking the network subnets from cluster "clusA".
```

```
    Check network subnets: PASS.
```

```
Start checking the network subnets from cluster "clusB".
```

```
    Check network subnets: PASS.
```

```
Start checking the storage daemons on cluster "clusA".
```

```
    Check storage daemons: PASS.
```

```
Start checking the storage daemons on cluster "clusB".
```

```
    Check storage daemons: PASS.
```

```
End of connection check.
```

metrocluster configuration-settings connection connect

Configure the network connections between partner nodes

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings connection connect` command configures the connections that mirror NV logs and access remote storage between partner nodes in a MetroCluster setup.

This command is used for MetroCluster setups that are connected through IP links. MetroCluster setups that are connected through FC links will configure the FC connections automatically.

The `metrocluster configuration-settings` commands are run in the following order to set up MetroCluster:

- `metrocluster configuration-settings dr-group create` ,
- `metrocluster configuration-settings interface create` ,
- `metrocluster configuration-settings connection connect` .

Before this command is run

- The DR groups must have been configured. Run the `metrocluster configuration-settings dr-group show` command to verify that every node is partnered in a DR group.
- The network logical interfaces must have been configured on every node. Use the `metrocluster configuration-settings interface show` command to verify that every node has network logical interfaces configured to mirror NV logs and access remote storage.

After this command completes successfully, every node will:

- Have NV log mirroring configured and mirroring disabled. NV log mirroring will be enabled by the `metrocluster configure` command.
- Have access to remote storage. Use the `storage disk show -pool Pool1` command to view the remote disks that are hosted on DR partner nodes.

The DR groups and network logical interfaces that were configured by the `metrocluster configuration-settings` commands cannot be deleted after the connections have been configured. The `metrocluster configuration-settings connection disconnect` command must be run to remove the connections before the DR groups and network logical interfaces can be deleted.

Examples

The following example shows configuration of connections in a MetroCluster over IP setup:

```
clusA::> metrocluster configuration-settings connection connect
[Job 269] Job succeeded: Connect is successful.
clusA::> metrocluster configuration-settings connection show
DR                               Source           Destination
Group Cluster Node      Network Address Network Address Partner Type Config
State
-----
-----
```

```

1      clusA A1
      Home Port: e0f
      10.140.113.214  10.140.113.216  HA Partner
completed

      Home Port: e0f
      10.140.113.214  10.140.113.218  DR Partner
completed

      Home Port: e0f
      10.140.113.214  10.140.113.249  DR Auxiliary
completed

      Home Port: e0g
      10.140.113.215  10.140.113.217  HA Partner
completed

      Home Port: e0g
      10.140.113.215  10.140.113.248  DR Partner
completed

      Home Port: e0g
      10.140.113.215  10.140.113.25  DR Auxiliary
completed

      A2
      Home Port: e0f
      10.140.113.216  10.140.113.214  HA Partner
completed

      Home Port: e0f
      10.140.113.216  10.140.113.249  DR Partner
completed

      Home Port: e0f
      10.140.113.216  10.140.113.218  DR Auxiliary
completed

      Home Port: e0g
      10.140.113.217  10.140.113.215  HA Partner
completed

      Home Port: e0g
      10.140.113.217  10.140.113.25  DR Partner
completed

      Home Port: e0g
      10.140.113.217  10.140.113.248  DR Auxiliary
completed
      clusB B2
      Home Port: e0f
      10.140.113.249  10.140.113.218  HA Partner
completed

      Home Port: e0f
      10.140.113.249  10.140.113.216  DR Partner
completed

      Home Port: e0f

```



```

10.140.113.249 10.140.113.214 DR Auxiliary
completed
Home Port: e0g
10.140.113.25 10.140.113.248 HA Partner
completed
Home Port: e0g
10.140.113.25 10.140.113.217 DR Partner
completed
Home Port: e0g
10.140.113.25 10.140.113.215 DR Auxiliary
completed
B1
Home Port: e0f
10.140.113.218 10.140.113.249 HA Partner
completed
Home Port: e0f
10.140.113.218 10.140.113.214 DR Partner
completed
Home Port: e0f
10.140.113.218 10.140.113.216 DR Auxiliary
completed
Home Port: e0g
10.140.113.248 10.140.113.25 HA Partner
completed
Home Port: e0g
10.140.113.248 10.140.113.215 DR Partner
completed
Home Port: e0g
10.140.113.248 10.140.113.217 DR Auxiliary

```

```

completed
24 entries were displayed.

```

```

clusA::> metrocluster configuration-settings show-status
Cluster          Node          Configuration Settings
Status
-----
clusA
           A1          completed
           A2          completed
clusB
           B1          completed
           B2          completed

```

```

4 entries were displayed.

```

Related Links

- [metrocluster configuration-settings dr-group create](#)
- [metrocluster configuration-settings interface create](#)
- [metrocluster configuration-settings dr-group show](#)
- [metrocluster configuration-settings interface show](#)
- [metrocluster configure](#)
- [storage disk show](#)
- [metrocluster configuration-settings connection disconnect](#)

metrocluster configuration-settings connection disconnect

Tear down the network connections between partner nodes

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings connection disconnect` command removes the connections between nodes in a DR group that are used to mirror NV logs and access remote storage.

This command cannot be run if a node in the DR group has remote disks assigned to the node. The assigned ownership of remote disks can be removed by running the `storage disk removeowner` command.

The `metrocluster configuration-settings` commands are run in the following order to remove MetroCluster over IP configuration:

- `metrocluster configuration-settings connection disconnect`,
- [metrocluster configuration-settings interface delete](#),
- [metrocluster configuration-settings dr-group delete](#).

Parameters

-dr-group-id <integer> - DR Group ID

This parameter identifies the DR group to be disconnected.

Examples

The following example illustrates removal of connections in a four-node MetroCluster setup:

```
clusA::> metrocluster configuration-settings connection disconnect -dr
-group-id 1
[Job 270] Job succeeded: Disconnect is successful.

clusA::> metrocluster configuration-settings show-status
Cluster          Node          Configuration Settings
Status
```

```

-----
clusA
          A1          ready for connection connect
          A2          ready for connection connect
clusB
          B1          ready for connection connect
          B2          ready for connection connect

```

4 entries were displayed.

```
clusA::> metrocluster configuration-settings connection show
```

```

DR          Source          Destination
Group Cluster Node   Network Address Network Address Partner Type Config
State
-----

```

```

1      clusA A1
      Home Port: e0f
      10.140.113.214  10.140.113.216  HA Partner
disconnected
      Home Port: e0f
      10.140.113.214  10.140.113.218  DR Partner
disconnected
      Home Port: e0f
      10.140.113.214  10.140.113.249  DR Auxiliary
disconnected
      Home Port: e0g
      10.140.113.215  10.140.113.217  HA Partner
disconnected
      Home Port: e0g
      10.140.113.215  10.140.113.248  DR Partner
disconnected
      Home Port: e0g
      10.140.113.215  10.140.113.25   DR Auxiliary
disconnected
          A2
      Home Port: e0f
      10.140.113.216  10.140.113.214  HA Partner
disconnected
      Home Port: e0f
      10.140.113.216  10.140.113.249  DR Partner
disconnected
      Home Port: e0f
      10.140.113.216  10.140.113.218  DR Auxiliary
disconnected
      Home Port: e0g
      10.140.113.217  10.140.113.215  HA Partner

```

```

disconnected
    Home Port: e0g
    10.140.113.217  10.140.113.25  DR Partner
disconnected
    Home Port: e0g
    10.140.113.217  10.140.113.248  DR Auxiliary
disconnected
    clusB B2
    Home Port: e0f
    10.140.113.249  10.140.113.218  HA Partner
disconnected
    Home Port: e0f
    10.140.113.249  10.140.113.216  DR Partner
disconnected
    Home Port: e0f
    10.140.113.249  10.140.113.214  DR Auxiliary
disconnected
    Home Port: e0g
    10.140.113.25  10.140.113.248  HA Partner
disconnected
    Home Port: e0g
    10.140.113.25  10.140.113.217  DR Partner
disconnected
    Home Port: e0g
    10.140.113.25  10.140.113.215  DR Auxiliary
disconnected
    B1
    Home Port: e0f
    10.140.113.218  10.140.113.249  HA Partner
disconnected
    Home Port: e0f
    10.140.113.218  10.140.113.214  DR Partner
disconnected
    Home Port: e0f
    10.140.113.218  10.140.113.216  DR Auxiliary
disconnected
    Home Port: e0g
    10.140.113.248  10.140.113.25  HA Partner
disconnected
    Home Port: e0g
    10.140.113.248  10.140.113.215  DR Partner
disconnected
    Home Port: e0g
    10.140.113.248  10.140.113.217  DR Auxiliary
disconnected
24 entries were displayed.

```

Related Links

- [storage disk removeowner](#)
- [metrocluster configuration-settings interface delete](#)
- [metrocluster configuration-settings dr-group delete](#)

metrocluster configuration-settings connection show

Display the connections between partner nodes in a MetroCluster setup

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings connection show` command displays the connection configuration information between the nodes in a MetroCluster setup.

Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command displays only the fields that you specify.

| [-instance] }

If this parameter is specified, the command displays detailed information about all entries.

[-dr-group-id <integer>] - DR Group ID

If this parameter is specified, the command displays information for the matching DR group.

[-cluster-uuid <UUID>] - Cluster UUID

If this parameter is specified, the command displays information for the matching cluster specified by uuid.

[-cluster <Cluster name>] - Cluster Name

If this parameter is specified, the command displays information for the matching cluster.

[-node-uuid <UUID>] - Node UUID

If this parameter is specified, the command displays information for the matching node specified by uuid.

[-node <text>] - Node Name

If this parameter is specified, the command displays information for the matching nodes.

[-home-port {<netport>|<ifgrp>}] - Home Port

If this parameter is specified, the command displays information for the matching home-port.

[-relationship-type <Roles of MetroCluster Nodes>] - Relationship Role Type

If this parameter is specified, the command displays information for the matching relationship-type.

[-source-address <IP Address>] - Source Network Address

If this parameter is specified, the command displays information for the matching source address.

[-destination-address <IP Address>] - Destination Network Address

If this parameter is specified, the command displays information for the matching destination address.

[-partner-cluster-uuid <UUID>] - Partner Cluster UUID

If this parameter is specified, the command displays information for the matching partner-cluster-uuid.

[-partner-node-uuid <UUID>] - Partner Node UUID

If this parameter is specified, the command displays information for the matching partner-node-uuid.

[-partner-node <text>] - Partner Node Name

If this parameter is specified, the command displays information for the matching partner-node.

[-partner-type <text>] - Partner Relationship Type

If this parameter is specified, the command displays information for the matching partner-type.

[-config-state <text>] - Configuration State

If this parameter is specified, the command displays information for the matching config-state.

[-config-error-info <text>] - Configuration Error Information

If this parameter is specified, the command displays information for the matching config-error-info.

Examples

The following example shows the output of `metrocluster configuration-settings connection connect` command:

```
Output of the command before the connections are established using the
xref:{relative_path}metrocluster-configuration-settings-connection-
connect.html[metrocluster configuration-settings connection connect]
command:
clusA::> metrocluster configuration-settings connection show
DR
Group Cluster Node      Source          Destination
State              Network Address Network Address Partner Type Config
-----
-----
1      clusA A1
      Home Port: e0f
      10.140.113.214  10.140.113.216  HA Partner
disconnected
      Home Port: e0f
      10.140.113.214  10.140.113.218  DR Partner
disconnected
      Home Port: e0f
      10.140.113.214  10.140.113.249  DR Auxiliary
```

```

disconnected
    Home Port: e0g
    10.140.113.215  10.140.113.217  HA Partner
disconnected
    Home Port: e0g
    10.140.113.215  10.140.113.248  DR Partner
disconnected
    Home Port: e0g
    10.140.113.215  10.140.113.25   DR Auxiliary
disconnected
    A2
    Home Port: e0f
    10.140.113.216  10.140.113.214  HA Partner
disconnected
    Home Port: e0f
    10.140.113.216  10.140.113.249  DR Partner
disconnected
    Home Port: e0f
    10.140.113.216  10.140.113.218  DR Auxiliary
disconnected
    Home Port: e0g
    10.140.113.217  10.140.113.215  HA Partner
disconnected
    Home Port: e0g
    10.140.113.217  10.140.113.25   DR Partner
disconnected
    Home Port: e0g
    10.140.113.217  10.140.113.248  DR Auxiliary
disconnected
    clusB B2
    Home Port: e0f
    10.140.113.249  10.140.113.218  HA Partner
disconnected
    Home Port: e0f
    10.140.113.249  10.140.113.216  DR Partner
disconnected
    Home Port: e0f
    10.140.113.249  10.140.113.214  DR Auxiliary
disconnected
    Home Port: e0g
    10.140.113.25   10.140.113.248  HA Partner
disconnected
    Home Port: e0g
    10.140.113.25   10.140.113.217  DR Partner
disconnected
    Home Port: e0g

```

```

10.140.113.25 10.140.113.215 DR Auxiliary
disconnected
    B1
    Home Port: e0f
10.140.113.218 10.140.113.249 HA Partner
disconnected
    Home Port: e0f
10.140.113.218 10.140.113.214 DR Partner
disconnected
    Home Port: e0f
10.140.113.218 10.140.113.216 DR Auxiliary
disconnected
    Home Port: e0g
10.140.113.248 10.140.113.25 HA Partner
disconnected
    Home Port: e0g
10.140.113.248 10.140.113.215 DR Partner
disconnected
    Home Port: e0g
10.140.113.248 10.140.113.217 DR Auxiliary

```

disconnected

24 entries were displayed.

Output of the command after the connections are established using the
xref:{relative_path}metrocluster-configuration-settings-connection-
connect.html[metrocluster configuration-settings connection connect]
command:

```
clusA::> metrocluster configuration-settings connection show
```

```

DR                Source          Destination
Group Cluster Node   Network Address Network Address Partner Type Config
State
-----

```

```

1      clusA A1
    Home Port: e0f
    10.140.113.214 10.140.113.216 HA Partner
completed
    Home Port: e0f
    10.140.113.214 10.140.113.218 DR Partner
completed
    Home Port: e0f
    10.140.113.214 10.140.113.249 DR Auxiliary
completed
    Home Port: e0g
    10.140.113.215 10.140.113.217 HA Partner
completed
    Home Port: e0g

```



```

10.140.113.215 10.140.113.248 DR Partner
completed
Home Port: e0g
10.140.113.215 10.140.113.25 DR Auxiliary
completed
A2
Home Port: e0f
10.140.113.216 10.140.113.214 HA Partner
completed
Home Port: e0f
10.140.113.216 10.140.113.249 DR Partner
completed
Home Port: e0f
10.140.113.216 10.140.113.218 DR Auxiliary
completed
Home Port: e0g
10.140.113.217 10.140.113.215 HA Partner
completed
Home Port: e0g
10.140.113.217 10.140.113.25 DR Partner
completed
Home Port: e0g
10.140.113.217 10.140.113.248 DR Auxiliary
completed
clusB B2
Home Port: e0f
10.140.113.249 10.140.113.218 HA Partner
completed
Home Port: e0f
10.140.113.249 10.140.113.216 DR Partner
completed
Home Port: e0f
10.140.113.249 10.140.113.214 DR Auxiliary
completed
Home Port: e0g
10.140.113.25 10.140.113.248 HA Partner
completed
Home Port: e0g
10.140.113.25 10.140.113.217 DR Partner
completed
Home Port: e0g
10.140.113.25 10.140.113.215 DR Auxiliary
completed
B1
Home Port: e0f
10.140.113.218 10.140.113.249 HA Partner

```

```

completed
      Home Port: e0f
      10.140.113.218  10.140.113.214  DR Partner
completed
      Home Port: e0f
      10.140.113.218  10.140.113.216  DR Auxiliary
completed
      Home Port: e0g
      10.140.113.248  10.140.113.25   HA Partner
completed
      Home Port: e0g
      10.140.113.248  10.140.113.215  DR Partner
completed
      Home Port: e0g
      10.140.113.248  10.140.113.217  DR Auxiliary
completed
24 entries were displayed.

```

Related Links

- [metrocluster configuration-settings connection connect](#)

metrocluster configuration-settings dr-group create

Create a DR group in a MetroCluster setup

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings dr-group create` command partners the nodes that will comprise a DR group in a MetroCluster setup.

This command is used for MetroCluster setups that are connected though IP links. MetroCluster setups that are connected through FC links will configure DR groups automatically and do not require the `metrocluster configuration-settings` commands.

The `metrocluster configuration-settings` commands are run in the following order to set up MetroCluster:

- `metrocluster configuration-settings dr-group create` ,
- [metrocluster configuration-settings interface create](#) ,
- [metrocluster configuration-settings connection connect](#) .

Before running this command, cluster peering must be configured between the local and partner clusters. Run the `cluster peer show` command to verify that peering is available between the local and partner clusters.

This command configures a local node and a remote node as DR partner nodes. The command also

configures the HA partner of the local node and the HA partner of the remote node as the other DR partner nodes in the DR group.

Parameters

-partner-cluster <Cluster name> - Partner Cluster Name

Use this parameter to specify the name of the partner cluster.

-local-node {<nodename>|local} - Local Node Name

Use this parameter to specify the name of a node in the local cluster.

-remote-node <text> - Remote Node Name

Use this parameter to specify the name of a node in the partner cluster that is to be the DR partner of the specified local node.

Examples

The following example shows the creation of the MetroCluster DR group:

```

clusA::> metrocluster configuration-settings dr-group create -partner
-cluster clusB -local-node A1 -remote-node B1
[Job 268] Job succeeded: DR Group Create is successful.

clusA::> metrocluster configuration-settings dr-group show
DR Group ID Cluster Node DR Partner Node
-----
-----
1 clusA
A1 B1
A2 B2
clusB
B2 A2
B1 A1

4 entries were displayed.
clusA::> metrocluster configuration-settings show-status
Cluster Node Configuration Settings
Status
-----
-----
clusA
A1 ready for interface create
A2 ready for interface create
clusB
B1 ready for interface create
B2 ready for interface create

4 entries were displayed.

```

Related Links

- [metrocluster configuration-settings interface create](#)
- [metrocluster configuration-settings connection connect](#)
- [cluster peer show](#)

metrocluster configuration-settings dr-group delete

Delete a DR group in a MetroCluster setup

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings dr-group delete` command deletes a DR group and its node partnerships that were configured using the [metrocluster configuration-settings dr-group create](#) command.

This command cannot be run if the `metrocluster configuration-settings interface create` command has configured a network logical interface on a network port provisioned for MetroCluster. The `metrocluster configuration-settings interface delete` command must then be run to delete the network logical interfaces on every node in the DR group.

The `metrocluster configuration-settings` commands are run in the following order to remove the MetroCluster over IP configuration:

- `metrocluster configuration-settings connection disconnect` ,
- `metrocluster configuration-settings interface delete` ,
- `metrocluster configuration-settings dr-group delete` .

Parameters

-dr-group-id <integer> - Dr group Id

This parameter identifies the DR group to be deleted.

Examples

The following example shows the deletion of the MetroCluster DR group:

```
clusA::> metrocluster configuration-settings dr-group delete -dr-group-id 1
```

```
Warning: This command deletes the existing DR group relationship. Are you sure
```

```
        you want to proceed ? {y|n}: y
```

```
[Job 279] Job succeeded: DR Group Delete is successful.
```

```
clusA::> metrocluster configuration-settings dr-group show
No DR groups exist.
```

```
clusA::> metrocluster configuration-settings show-status
```

Cluster	Node	Configuration Settings
Status		

clusA	A1	ready for DR group create
	A2	ready for DR group create
clusB	B1	ready for DR group create
	B2	ready for DR group create

```
4 entries were displayed.
```

Related Links

- [metrocluster configuration-settings dr-group create](#)
- [metrocluster configuration-settings interface create](#)
- [metrocluster configuration-settings interface delete](#)
- [metrocluster configuration-settings connection disconnect](#)

metrocluster configuration-settings dr-group show

Display the DR groups in a MetroCluster setup

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings dr-group show` command displays the DR groups and their nodes.

Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command displays only the fields that you specify.

| [-instance] }

If this parameter is specified, the command displays detailed information about all entries.

[-dr-group-id <integer>] - DR Group ID

If this parameter is specified, the command displays information for the matching DR group.

[-cluster-uuid <UUID>] - Cluster UUID

If this parameter is specified, the command displays information for the matching cluster uuid.

[-cluster <Cluster name>] - Cluster Name

If this parameter is specified, the command displays information for the specified cluster.

[-node-uuid <UUID>] - Node UUID

If this parameter is specified, the command displays information for the matching nodes uuid.

[-node <text>] - Node Name

If this parameter is specified, the command displays information for the matching nodes.

[-dr-partner-node-uuid <UUID>] - DR Partner Node UUID

If this parameter is specified, the command displays information for the matching DR partner node uuid.

[-dr-partner-node <text>] - DR Partner Node Name

If this parameter is specified, the command displays information for the matching DR partner nodes.

Examples

The following example illustrates the display of DR group configuration in a four-node MetroCluster setup:

```
clusA::> metrocluster configuration-settings dr-group show
DR Group ID Cluster                               Node                               DR Partner Node
-----
1          clusA
           A1                                   B1
           A2                                   B2
           clusB
           B2                                   A2
           B1                                   A1
4 entries were displayed.
```

metrocluster configuration-settings interface create

Create a MetroCluster interface

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings interface create` command configures the network logical interfaces that will be used on a node in a MetroCluster setup to mirror NV logs and access remote storage.

This command is used for MetroCluster setups that are connected through IP links. MetroCluster setups that are connected through FC links do not require the user to provision network logical interfaces to mirror NV logs and access remote storage.

The `metrocluster configuration-settings` commands are run in the following order to set up MetroCluster:

- [metrocluster configuration-settings dr-group create](#) ,
- `metrocluster configuration-settings interface create` ,
- [metrocluster configuration-settings connection connect](#) .

Before running this command , the node's DR group must be configured using the [metrocluster configuration-settings dr-group create](#) command. Run the [metrocluster configuration-settings dr-group show](#) command to verify that the node's DR group has been configured.

Parameters

-cluster-name <Cluster name> - Cluster Name

Use this parameter to specify the name of the local or partner cluster.

-home-node <text> - Home Node

Use this parameter to specify the home node in the cluster which hosts the interface.

-home-port {<netport>|<ifgrp>} - Home Port

Use this parameter to specify the home port provisioned for MetroCluster.

-address <IP Address> - Network Address

Use this parameter to specify the network address to be assigned to the home port.

-netmask <Contiguous IP Mask> - Netmask

Use this parameter to specify the network mask to be assigned to the interface.

Examples

This example shows configuring logical interface on MetroCluster IP capable port:

```
clusA::> metrocluster configuration-settings interface create -cluster
-name clusA -home-node A1 -home-port e0f -address 10.140.113.214 -netmask
255.255.192.0
[Job 281] Job succeeded: Interface Create is successful.

clusA::> metrocluster configuration-settings interface show
DR
Config
Group Cluster Node      Network Address Netmask      Gateway
State
-----
-----
1      clusA A1
                Home Port: e0f
                                10.140.113.214  255.255.192.0  -
completed
Output after configuring all the interfaces:
clusA::> metrocluster configuration-settings interface show
DR
Config
Group Cluster Node      Network Address Netmask      Gateway
State
-----
-----
1      clusA A1
                Home Port: e0f
                                10.140.113.214  255.255.192.0  -
completed
                Home Port: e0g
                                10.140.113.215  255.255.192.0  -
completed
```



```

                A2
      Home Port: e0f
                10.140.113.216  255.255.192.0  -
completed

      Home Port: e0g
                10.140.113.217  255.255.192.0  -
completed
      clusB B2
      Home Port: e0f
                10.140.113.249  255.255.192.0  -
completed

      Home Port: e0g
                10.140.113.25   255.255.192.0  -
completed

                B1
      Home Port: e0f
                10.140.113.218  255.255.192.0  -
completed

      Home Port: e0g
                10.140.113.248  255.255.192.0  -
completed
8 entries were displayed.

```

```
clusA::> metrocluster configuration-settings show-status
```

```

Cluster          Node          Configuration Settings
Status
-----
clusA
          A1          ready for connection connect
          A2          ready for connection connect
clusB
          B1          ready for connection connect
          B2          ready for connection connect

```

```
4 entries were displayed.
```

```
clusA::> metrocluster configuration-settings connection show
```

```

DR          Source          Destination
Group Cluster Node   Network Address Network Address Partner Type Config
State
-----
1      clusA A1
      Home Port: e0f
      10.140.113.214  10.140.113.216  HA Partner
disconnected

```

```

disconnected      Home Port: e0f
                  10.140.113.214  10.140.113.218  DR Partner

disconnected      Home Port: e0f
                  10.140.113.214  10.140.113.249  DR Auxiliary

disconnected      Home Port: e0g
                  10.140.113.215  10.140.113.217  HA Partner

disconnected      Home Port: e0g
                  10.140.113.215  10.140.113.248  DR Partner

disconnected      Home Port: e0g
                  10.140.113.215  10.140.113.25   DR Auxiliary

disconnected      A2
                  Home Port: e0f
                  10.140.113.216  10.140.113.214  HA Partner

disconnected      Home Port: e0f
                  10.140.113.216  10.140.113.249  DR Partner

disconnected      Home Port: e0f
                  10.140.113.216  10.140.113.218  DR Auxiliary

disconnected      Home Port: e0g
                  10.140.113.217  10.140.113.215  HA Partner

disconnected      Home Port: e0g
                  10.140.113.217  10.140.113.25   DR Partner

disconnected      Home Port: e0g
                  10.140.113.217  10.140.113.248  DR Auxiliary

disconnected      clusB B2
                  Home Port: e0f
                  10.140.113.249  10.140.113.218  HA Partner

disconnected      Home Port: e0f
                  10.140.113.249  10.140.113.216  DR Partner

disconnected      Home Port: e0f
                  10.140.113.249  10.140.113.214  DR Auxiliary

disconnected      Home Port: e0g
                  10.140.113.25   10.140.113.248  HA Partner

```

```

disconnected
      Home Port: e0g
      10.140.113.25   10.140.113.217   DR Partner
disconnected
      Home Port: e0g
      10.140.113.25   10.140.113.215   DR Auxiliary
disconnected
      B1
      Home Port: e0f
      10.140.113.218  10.140.113.249   HA Partner
disconnected
      Home Port: e0f
      10.140.113.218  10.140.113.214   DR Partner
disconnected
      Home Port: e0f
      10.140.113.218  10.140.113.216   DR Auxiliary
disconnected
      Home Port: e0g
      10.140.113.248  10.140.113.25    HA Partner
disconnected
      Home Port: e0g
      10.140.113.248  10.140.113.215   DR Partner
disconnected
      Home Port: e0g
      10.140.113.248  10.140.113.217   DR Auxiliary
disconnected
24 entries were displayed.

```

Related Links

- [metrocluster configuration-settings dr-group create](#)
- [metrocluster configuration-settings connection connect](#)
- [metrocluster configuration-settings dr-group show](#)

metrocluster configuration-settings interface delete

Delete a MetroCluster interface

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings interface delete` command deletes the network logical interface that was configured on a network port provisioned for MetroCluster.

This command cannot be run if the [metrocluster configuration-settings connection connect](#) command has set up the connections between the nodes in a DR group. The [metrocluster configuration-settings connection](#)

`disconnect` command must then be run to remove the connections.

The `metrocluster configuration-settings` commands are run in the following order to remove the MetroCluster over IP configuration:

- `metrocluster configuration-settings connection disconnect` ,
- `metrocluster configuration-settings interface delete` ,
- `metrocluster configuration-settings dr-group delete` .

Parameters

-cluster-name <Cluster name> - Cluster Name

Use this parameter to specify the name of the local or partner cluster.

-home-node <text> - Home Node

Use this parameter to specify the home node in the cluster which hosts the interface.

-home-port {<netport>|<ifgrp>} - Home Port

Use this parameter to specify the home port provisioned for MetroCluster.

Examples

The following example shows the deletion of interface in a MetroCluster setup:

```
clusA::> metrocluster configuration-settings interface delete -cluster
-name clusA -home-node A1 -home-port e0f
[Job 271] Job succeeded: Interface Delete is successful.

clusA::> metrocluster configuration-settings interface show
DR
Config
Group Cluster Node      Network Address Netmask      Gateway
State
-----
-----
1      clusA A1
      Home Port: e0g
      10.140.113.215  255.255.192.0  -
completed

      A2
      Home Port: e0f
      10.140.113.216  255.255.192.0  -
completed

      Home Port: e0g
      10.140.113.217  255.255.192.0  -
completed
      clusB B2
```

```

Home Port: e0f
10.140.113.249 255.255.192.0 -
completed

Home Port: e0g
10.140.113.25 255.255.192.0 -
completed

B1
Home Port: e0f
10.140.113.218 255.255.192.0 -
completed

Home Port: e0g
10.140.113.248 255.255.192.0 -
completed
7 entries were displayed.

```

```
clusA::> metrocluster configuration-settings show-status
```

Cluster	Node	Configuration Settings
clusA	A1	ready for next interface
create	A2	ready for connection connect
clusB	B1	ready for connection connect
	B2	ready for connection connect

4 entries were displayed.

Output of the command after deleting all the interfaces:

```
clusA::> metrocluster configuration-settings interface show
No interfaces exist.
```

```
clusA::> metrocluster configuration-settings show-status
```

Cluster	Node	Configuration Settings
clusA	A1	ready for interface create
	A2	ready for interface create
clusB	B1	ready for interface create
	B2	ready for interface create

4 entries were displayed.

Related Links

- [metrocluster configuration-settings connection connect](#)
- [metrocluster configuration-settings connection disconnect](#)
- [metrocluster configuration-settings dr-group delete](#)

metrocluster configuration-settings interface show

Display the network logical interfaces provisioned for MetroCluster

Availability: This command is available to *cluster* administrators at the *admin* privilege level.

Description

The `metrocluster configuration-settings interface show` command displays the network logical interfaces that were provisioned for MetroCluster.

Parameters

{ [-fields <fieldname>,...]

If you specify the `-fields <fieldname>,...` parameter, the command displays only the fields that you specify.

| [-instance] }

If this parameter is specified, the command displays detailed information about all entries.

[-dr-group-id <integer>] - DR Group ID

If this parameter is specified, the command displays information for the matching DR group.

[-cluster-uuid <UUID>] - Cluster UUID

If this parameter is specified, the command displays information for the matching cluster specified by uuid.

[-cluster <Cluster name>] - Cluster Name

If this parameter is specified, the command displays information for the matching cluster..

[-node-uuid <UUID>] - Node UUID

If this parameter is specified, the command displays information for the matching nodes uuid.

[-node <text>] - Node Name

If this parameter is specified, the command displays information for the matching nodes.

[-home-port {<netport>|<ifgrp>}] - Home Port

If this parameter is specified, all interfaces with home-port set to this value are displayed.

[-address <IP Address>] - Network Address

If this parameter is specified, the command displays information for the matching network address.

[-netmask <Contiguous IP Mask>] - Netmask

If this parameter is specified, all interfaces with netmask set to this value are displayed.

[-gateway <IP Address>] - Gateway

If this parameter is specified, all interfaces with gateway set to this value are displayed.

[-config-state <text>] - Configuration State

If this parameter is specified, all interfaces with this field set to the specified value are displayed.

[-config-error-info <text>] - Configuration Error Information

If this parameter is specified, all interfaces with this field set to the specified value are displayed.

Examples

The following example illustrates display of logical interfaces configured in a four-node MetroCluster setup:

```

clusA::> metrocluster configuration-settings interface show
DR
Config
Group Cluster Node      Network Address Netmask      Gateway
State
-----
1      clusA A1
      Home Port: e0f
      10.140.113.214 255.255.192.0 -
completed
      Home Port: e0g
      10.140.113.215 255.255.192.0 -
completed
      A2
      Home Port: e0f
      10.140.113.216 255.255.192.0 -
completed
      Home Port: e0g
      10.140.113.217 255.255.192.0 -
completed
      clusB B2
      Home Port: e0f
      10.140.113.249 255.255.192.0 -
completed
      Home Port: e0g
      10.140.113.25  255.255.192.0 -
completed
      B1
      Home Port: e0f
      10.140.113.218 255.255.192.0 -
completed
      Home Port: e0g
      10.140.113.248 255.255.192.0 -
completed
8 entries were displayed.

```


Copyright information

Copyright © 2022 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.