



## **xfcvi events**

### ONTAP EMS reference

NetApp  
May 13, 2026

# Table of Contents

xfcvi events	1
xfcvi.attr events	1
xfcvi.attr.changed	1
xfcvi.cm events	1
xfcvi.cm.timedout	1
xfcvi.cross events	2
xfcvi.cross.connect.detected	2
xfcvi.disabled events	2
xfcvi.disabled	2
xfcvi.fcrenabled events	2
xfcvi.fcrEnabled	2
xfcvi.initfailed events	3
xfcvi.initFailed	3
xfcvi.invalid events	3
xfcvi.invalid.advertisement	3
xfcvi.invalid.sfp	4
xfcvi.link events	4
xfcvi.link.down	4
xfcvi.link.up	5
xfcvi.qlgc events	5
xfcvi.qlgc.async.event.overflow	5
xfcvi.qlgc.connErr	5
xfcvi.qlgc.cpr.reset.cancelled	6
xfcvi.qlgc.cpr.reset.failed	6
xfcvi.qlgc.cpr.reset.unsupported	7
xfcvi.qlgc.FrameDiscardErr	7
xfcvi.qlgc.hard.reset.failed	7
xfcvi.qlgc.invalid.data	8
xfcvi.qlgc.invalid.exch.address	8
xfcvi.qlgc.invalid.qp	9
xfcvi.qlgc.invalid.response	9
xfcvi.qlgc.ioErr	10
xfcvi.qlgc.login.timedout	10
xfcvi.qlgc.ls.reject	10
xfcvi.qlgc.mbox.cmd.pending	11
xfcvi.qlgc.mbox.cmd.timedout	11
xfcvi.qlgc.no.iu.buffer	12
xfcvi.qlgc.no.recv.buffer	12
xfcvi.qlgc.oodErr	13
xfcvi.qlgc.PCIErr	13
xfcvi.qlgc.port.reset	14
xfcvi.qlgc.qp.create.err	14
xfcvi.qlgc.qp.destroy.failed	14

xfcvi.qlgc.qpErr	15
xfcvi.qlgc.rcvd.invalid.iu.buffer	15
xfcvi.qlgc.receive.error	16
xfcvi.qlgc.received.disconnect	16
xfcvi.qlgc.received.reject	17
xfcvi.qlgc.recvIUErr	17
xfcvi.qlgc.regDumped	18
xfcvi.qlgc.RespFrameErr	18
xfcvi.qlgc.risc.paused	18
xfcvi.qlgc.rmt.link.down	19
xfcvi.qlgc.rmt.link.up	19
xfcvi.qlgc.sendIUError	20
xfcvi.qlgc.sent.disconnect	20
xfcvi.qlgc.soft.reset.failed	21
xfcvi.qlgc.system.error	21
xfcvi.qlgc.TimeOutErr	21
xfcvi.qlgc.transfer.error	22
xfcvi.qlgc_regdumpfailed events	22
xfcvi.qlgc_regDumpFailed	22
xfcvi.unsupported events	23
xfcvi.unsupported.config	23
xfcvi.update events	23
xfcvi.update.link.state	23

# xfcvi events

## xfcvi.attr events

### xfcvi.attr.changed

#### Severity

NOTICE

#### Description

This message occurs when any of the xfcvi attributes changes.

#### Corrective Action

(None).

#### Syslog Message

FC-VI adapter: %s changed on port %s. %s

#### Parameters

**attr\_type** (STRING): Attribute type.

**port** (STRING): xfcvi Interconnect NIC.

**info** (STRING): Additional info.

## xfcvi.cm events

### xfcvi.cm.timedout

#### Severity

NOTICE

#### Description

This message occurs when connection requests times out.

#### Corrective Action

(None).

#### Syslog Message

FC-VI adapter: Connection request timedout on port %s. QP name = %s, QP index = %d, Remote node's system id = %llu. %s

#### Parameters

**port** (STRING): xfcvi Interconnect NIC.

**qpname** (STRING): QP name.

**qpnum** (INT): QP index.

**system\_id** (LONGINT): Remote node's system id.

**info** (STRING): Additional info.

## xfcvi.cross events

### xfcvi.cross.connect.detected

#### Severity

ERROR

#### Description

This message occurs when the xfcvi driver detects a cross connection

#### Corrective Action

Check the xfcvi interconnect cabling at the local and remote nodes. xfcvi adapter ports xfcvi\_device\_0s and xfcvi\_device\_1s should not be connected to the same fabric. Contact NetApp technical support if the problem persists.

#### Syslog Message

FC-VI adapter: Cross Connection detected between local port %s and remote port %s. Local System ID = %llu, Remote System ID = %llu.

#### Parameters

**lname** (STRING): Local node's port name.

**rname** (STRING): Remote node's port name.

**lsid** (LONGINT): Local node's system id.

**rsid** (LONGINT): Remote node's system id.

## xfcvi.disabled events

### xfcvi.disabled

#### Severity

ALERT

#### Description

This message occurs when the HA interconnect card is disabled by the ic-type environment variable.

#### Corrective Action

Either remove the HA interconnect card from the controller or change the ic-type environment variable.

#### Syslog Message

FC-VI adapter: Port %s has been disabled because of the ic-type environment variable.

#### Parameters

**port** (STRING): xfcvi Interconnect NIC.

## xfcvi.fcrenabled events

### xfcvi.fcrEnabled

**Severity**

NOTICE

**Description**

This message occurs if Fiber Channel Routing (FCR) functionality is enabled on the system.

**Corrective Action**

(None).

**Syslog Message**

FC-VI adapter: Fiber Channel Routing (FCR) is enabled.

**Parameters**

(None).

## **xfcvi.initfailed events**

### **xfcvi.initFailed**

**Severity**

ERROR

**Description**

This message occurs when the driver fails to initialize a FC-VI port.

**Corrective Action**

Reboot the controller. Contact NetApp technical support if the problem persists.

**Syslog Message**

FC-VI adapter: %s failed for port %s.

**Parameters**

**operation** (STRING): Type of operation  
**port** (STRING): xfcvi Interconnect NIC.

## **xfcvi.invalid events**

### **xfcvi.invalid.advertisement**

**Severity**

ERROR

**Description**

This message occurs when xfcvi driver receives invalid advertisement.

**Corrective Action**

(None).

## Syslog Message

FC-VI adapter: Port %s received invalid advertisement. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.

**info** (STRING): Additional info.

## xfcvi.invalid.sfp

### Severity

ERROR

### Description

This message occurs when the SFP (Small Form-Factor Pluggable) module of the Fibre Channel Virtual Interface (FC-VI) is invalid or incompatible.

### Corrective Action

Replace the SFP with a compatible one.

## Syslog Message

FC-VI adapter: Invalid SFP - Reason: %s on port %s.

## Parameters

**reason** (STRING): Reason for the incompatibility.

**port** (STRING): Interconnect NIC.

## xfcvi.link events

### xfcvi.link.down

### Severity

NOTICE

### Description

This message occurs when the physical link of the Fibre Channel Virtual Interface (FC-VI) adapter goes down.

### Corrective Action

1. Ensure that the FC-VI link has not been tampered with.
2. Verify that the physical status of the FC-VI adapter is "Up" by using the command "metrocluster interconnect adapter show".
3. If the configuration includes fabric switches, ensure that they are properly cabled and configured.

## Syslog Message

(None).

## Parameters

**alertId** (STRING): Alert ID.

**alertingResource** (STRING): Alerting resource unique name.

**alertingResourceName** (STRING): Alerting resource name.

**possibleEffect** (STRING): Possible effect for link transition.

**probableCause** (STRING): Probable cause of the event.

**probableCauseDescription** (STRING): Probable cause description of the event.  
**additionalInfo** (STRING): Any additional information for the event.

## **xfcvi.link.up**

### **Severity**

NOTICE

### **Description**

This message occurs when the physical link of the Fibre Channel Virtual Interface (FC-VI) adapter comes up.

### **Corrective Action**

(None).

### **Syslog Message**

(None).

### **Parameters**

**alertId** (STRING): Alert ID.  
**alertingResource** (STRING): Alerting resource unique name.

## **xfcvi qlgc events**

### **xfcvi.qlgc.async.event.overflow**

#### **Severity**

ERROR

#### **Description**

This message occurs when total number of async events are overflowed.

#### **Corrective Action**

(None).

#### **Syslog Message**

FC-VI adapter: Port %s async event overflowed. Resetting the adapter.

#### **Parameters**

**port** (STRING): xfcvi Interconnect NIC.

### **xfcvi.qlgc.connErr**

#### **Severity**

ERROR

#### **Description**

This message occurs when the FC-VI adapter detects a connection error. The FC-VI driver will attempt to retry the connection.

## Corrective Action

If this message repeats frequently, there may be an issue with the FC fabric or the adapter. Contact NetApp technical support.

## Syslog Message

FC-VI adapter: Port %s detects connection error. FC-VI opcode = %s(0x%x), QP name = %s, QP index = %d, Remote node's system id = %llu. %s

## Parameters

**port** (STRING): Interconnect NIC.  
**opcode\_str** (STRING): xfcvi opcode.  
**opcode** (INHEX): xfcvi opcode.  
**qpname** (STRING): QP name.  
**qpnum** (INT): QP number.  
**systemID** (LONGINT): Remote node's system ID.  
**info** (STRING): Additional info.

## xfcvi.qlgc.cpr.reset.cancelled

### Severity

ERROR

### Description

This message occurs when the CPR reset initiated by the FC-VI port got cancelled.

### Corrective Action

Reboot the filer. If issue still persists then replace the xfcvi adapter.

### Syslog Message

FC-VI adapter: CPR reset initiated by port %s got cancelled. Offlining the port.

### Parameters

**port** (STRING): xfcvi Interconnect adapter.

## xfcvi.qlgc.cpr.reset.failed

### Severity

ERROR

### Description

This message occurs when the CPR reset initiated by the FC-VI port fails.

### Corrective Action

Reboot the filer. If issue still persists then replace the xfcvi adapter.

### Syslog Message

FC-VI adapter: CPR reset initiated by port %s failed.

### Parameters

**port** (STRING): xfcvi Interconnect adapter.

## **xfcvi.qlgc.cpr.reset.unsupported**

### **Severity**

ERROR

### **Description**

This message occurs when the CPR reset is not supported by the adapter.

### **Corrective Action**

Reboot the filer. If issue still persists then replace the xfcvi adapter.

### **Syslog Message**

FC-VI adapter: CPR reset is not supported by port %s.

### **Parameters**

**port** (STRING): xfcvi Interconnect adapter.

## **xfcvi.qlgc.FrameDiscardErr**

### **Severity**

ERROR

### **Description**

This message occurs when the FC-VI adapter firmware discards a received frame because of a receive frame error.

### **Corrective Action**

(None).

### **Syslog Message**

FC-VI adapter: Discarded a received frame because of a receive frame error. Port %s, QP name = %s, QP index = %d, exchange ID 0x%x, address offset 0x%x, remote node's system id = %llu. %s

### **Parameters**

**port** (STRING): xfcvi Interconnect NIC.  
**qp\_name** (STRING): QP name.  
**qp\_index** (INT): QP number.  
**exchange\_id** (INTHEX): Exchange ID.  
**address** (INTHEX): Address offset of the last good frame.  
**system\_id** (LONGINT): Remote node's system id.  
**info** (STRING): Additional info.

## **xfcvi.qlgc.hard.reset.failed**

### **Severity**

ERROR

### **Description**

This message occurs when an FC-VI port's soft reset fails.

### Corrective Action

If CPR reset is not supported in the platform, then reboot the filer to recover from this issue. If issue persists then replace the xfcvi adapter.

### Syslog Message

FC-VI adapter: Hard reset failed at port %s.

### Parameters

**port** (STRING): xfcvi Interconnect adapter.

## xfcvi.qlgc.invalid.data

### Severity

ERROR

### Description

This message occurs when xfcvi driver receives invalid data from firmware.

### Corrective Action

(None).

### Syslog Message

FC-VI adapter: Port %s received invalid data. QP index = %d, completion status = %s(status code = %d), opcode = %s(%d), remote node's system id = %llu. %s

### Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**qpnum** (INT): QP index.  
**status** (STRING): Completion status.  
**status\_code** (INT): Completion status code.  
**opcode\_str** (STRING): xfcvi opcode in string.  
**opcode** (INT): xfcvi opcode.  
**systemID** (LONGINT): Remote node's system Id.  
**info** (STRING): Additional info.

## xfcvi.qlgc.invalid.exch.address

### Severity

ERROR

### Description

This message occurs when xfcvi driver receives a response with invalid exchange address.

### Corrective Action

(None).

### Syslog Message

FC-VI adapter: Port %s received invalid exchange address for %s. QP name = %s, QP index = %d, expected exchange address = 0x%x, received exchange address = 0x%x. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**resp\_type** (STRING): Response type.  
**qpname** (STRING): QP name.  
**qpnum** (INT): QP number.  
**exp\_oxid** (INTHEX): Expected exchange address.  
**rcvd\_oxid** (INTHEX): Received exchange address.  
**info** (STRING): Additional info.

## xfcvi.qlgc.invalid.qp

### Severity

ERROR

### Description

This message occurs when xfcvi driver receives invalid QP index from firmware.

### Corrective Action

(None).

### Syslog Message

FC-VI adapter: Port %s received invalid QP. Received QP index = %d, completion status = %s(status code = %d), entry type = %s(entry code = %d). %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**qpnum** (INT): QP index.  
**status** (STRING): Completion status.  
**status\_code** (INT): Completion status code.  
**entry\_type** (STRING): Request/Response entry type.  
**entry\_code** (INT): Request/Response entry code.  
**info** (STRING): Additional info.

## xfcvi.qlgc.invalid.response

### Severity

ERROR

### Description

This message occurs when xfcvi driver receives invalid response from firmware.

### Corrective Action

(None).

### Syslog Message

FC-VI adapter: Port %s received invalid response. %s. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**error\_type** (STRING): Type of error.  
**info** (STRING): Additional info.

## **xfcvi.qlgc.ioErr**

### **Severity**

ERROR

### **Description**

This message occurs when the FC-VI driver receives some IO error.

### **Corrective Action**

No corrective action is required. The driver internally resets the adapter if required. However, if you see this message frequently, there might be an issue with the FC fabric or the adapter. Contact NetApp technical support.

### **Syslog Message**

FC-VI adapter: xfcvi driver on port %s received IO error. Status = %s(status code = 0x%x), xfcvi opcode = %s(0x%x), QP name = %s, QP index = %d, Remote node's system id = %llu.

### **Parameters**

**port** (STRING): Interconnect NIC.  
**status\_str** (STRING): Completion status in string.  
**status** (INHEX): Completion status code.  
**opcode\_str** (STRING): xfcvi opcode in string.  
**opcode** (INHEX): xfcvi opcode.  
**qpName** (STRING): QP name.  
**qpIndex** (INT): QP number.  
**systemID** (LONGINT): Remote node's system ID.

## **xfcvi.qlgc.login.timedout**

### **Severity**

NOTICE

### **Description**

This message occurs when port login request times out.

### **Corrective Action**

(None).

### **Syslog Message**

FC-VI adapter: Remote port login timedout on port %s. Remote port id = 0x%x, Remote port handle = %d.  
%s

### **Parameters**

**port** (STRING): xfcvi Interconnect NIC.  
**portid** (INHEX): Remote port identifier.  
**porthandle** (INT): Remote port handle.  
**info** (STRING): Additional info.

## **xfcvi.qlgc.ls.reject**

**Severity**

ERROR

**Description**

This message occurs when the xfcvi firmware rejects a link service.

**Corrective Action**

(None).

**Syslog Message**

FC-VI adapter: Link service = %s(code = %d), rejected on port %s. %s

**Parameters**

**ls** (STRING): Link service name.

**ls\_code** (INT): Link service code.

**port** (STRING): xfcvi Interconnect NIC.

**info** (STRING): Additional info.

**xfcvi.qlgc.mbox.cmd.pending****Severity**

ERROR

**Description**

This message occurs when a mailbox command is pending for a long time.

**Corrective Action**

(None).

**Syslog Message**

FC-VI adapter: Mailbox command '%s(code = 0x%x)' pending on port %s. %s

**Parameters**

**cmd** (STRING): Mailbox command.

**cmd\_code** (INTHEX): Mailbox command code.

**port** (STRING): xfcvi Interconnect NIC.

**info** (STRING): Additional info.

**xfcvi.qlgc.mbox.cmd.timedout****Severity**

ERROR

**Description**

This message occurs when a mailbox command times out.

**Corrective Action**

(None).

## Syslog Message

FC-VI adapter: Mailbox command '%s(code = 0x%x)' timedout on port %s. %s

## Parameters

**cmd** (STRING): Mailbox command.  
**cmd\_code** (INTHEX): Mailbox command code.  
**port** (STRING): xfcvi Interconnect NIC.  
**info** (STRING): Additional info.

## xfcvi.qlgc.no.iu.buffer

### Severity

ERROR

### Description

This message occurs when the xfcvi firmware identifies no more incoming IU buffers in the free pool.

### Corrective Action

(None).

## Syslog Message

FC-VI adapter: Port %s doesn't have free IU buffer. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**info** (STRING): Additional info.

## xfcvi.qlgc.no.recv.buffer

### Severity

ERROR

### Description

This message occurs when the xfcvi firmware identifies no more receive buffers available for the incoming receive frames.

### Corrective Action

(None).

## Syslog Message

FC-VI adapter: Port %s doesn't have free receive buffer. QP name = %s, QP index = %d, Message ID = 0x%x. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**qpname** (STRING): QP name.  
**qpnum** (INT): QP index.  
**msg\_id** (INTHEX): Message id of the incoming message.  
**info** (STRING): Additional info.

## xfcvi qlgc.oodErr

### Severity

ERROR

### Description

This message occurs when the FC-VI driver receives out of order completions.

### Corrective Action

No corrective action is required. The driver internally resets the adapter if required. However, if you see this message frequently, there might be an issue with the FC fabric or the adapter. Contact NetApp technical support.

### Syslog Message

FC-VI adapter: xfcvi driver on port %s receives out of order completions. xfcvi opcode = %s(0x%x), QP name = %s, QP index = %d, Remote node's system id = %llu.

### Parameters

**port** (STRING): Interconnect NIC.  
**opcode\_str** (STRING): xfcvi opcode in string.  
**opcode** (INTHEX): xfcvi opcode.  
**qpName** (STRING): QP name.  
**qpIndex** (INT): QP number.  
**systemID** (LONGINT): Remote node's system ID.

## xfcvi qlgc.PCIErr

### Severity

ERROR

### Description

This message occurs when the FC-VI adapter firmware encounters a PCI error because it cannot write a frame to host memory.

### Corrective Action

(None).

### Syslog Message

FC-VI adapter: PCI error while writing a frame to host memory. Port %s, QP name = %s, QP index = %d, exchange ID 0x%x, address offset 0x%x, remote node's system id = %llu. %s

### Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**qp\_name** (STRING): QP name.  
**qp\_index** (INT): QP number.  
**exchange\_id** (INTHEX): Exchange ID.  
**address** (INTHEX): Address offset of the last good frame.  
**system\_id** (LONGINT): Remote node's system id.  
**info** (STRING): Additional info.

## **xfcvi.qlgc.port.reset**

### **Severity**

ERROR

### **Description**

This message occurs when a xfcvi port resets.

### **Corrective Action**

(None).

### **Syslog Message**

FC-VI adapter: Resetting the port %s. %s

### **Parameters**

**port** (STRING): xfcvi Interconnect NIC.  
**reason** (STRING): Reason for port reset.

## **xfcvi.qlgc.qp.create.err**

### **Severity**

ERROR

### **Description**

This message occurs when QP creation fails.

### **Corrective Action**

(None).

### **Syslog Message**

FC-VI adapter: Failed to create QP on port %s. Requested QP index = %d, completion status = %s(status code = %d). %s

### **Parameters**

**port** (STRING): xfcvi Interconnect NIC.  
**qpnum** (INT): QP index.  
**status** (STRING): Completion status.  
**status\_code** (INT): Completion status code.  
**info** (STRING): Additional info.

## **xfcvi.qlgc.qp.destroy.failed**

### **Severity**

ERROR

### **Description**

This message occurs when the QP destroy request failed.

### **Corrective Action**

(None).

## Syslog Message

FC-VI adapter: QP destroy failed on port %s. QP index = %d. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.

**qpnum** (INT): QP index.

**info** (STRING): Additional info.

## xfcvi.qlgc.qpErr

### Severity

ERROR

### Description

This message occurs when the FC-VI driver receives a QP error from the Firmware. The FC-VI driver will attempt to retry the connection.

### Corrective Action

If this message repeats frequently, there may be an issue with the FC fabric or the adapter. Contact NetApp technical support.

## Syslog Message

FC-VI adapter: xfcvi driver on port %s received QP Error. QP name = %s, QP index = 0x%x, VI state = %s(state code = 0x%x), sub-error = %s(error code = 0x%x). Remote node's system id = %llu. This error has occurred %d times. %s

## Parameters

**port** (STRING): Interconnect Adapter.

**qpname** (STRING): QP name.

**qpnum** (INTHEX): QP number.

**state\_str** (STRING): QP state.

**state** (INTHEX): QP state code.

**suberror** (STRING): Sub-error.

**code** (INTHEX): Sub-error code.

**system\_id** (LONGINT): Remote node's system ID.

**errcnt** (INT): Number of times QP async error was encountered.

**info** (STRING): Additional info.

## xfcvi.qlgc.rcvd.invalid.iu.buffer

### Severity

ERROR

### Description

This message occurs when the FC-VI adapter receives invalid information unit buffer.

### Corrective Action

No corrective action is required. The driver internally resets the adapter if required. However, if you see this message frequently, there might be an issue with the FC fabric or the adapter. Contact NetApp technical support.

## Syslog Message

FC-VI adapter: Port %s received invalid IU buffer. Status = %s(status code = 0x%x), xfcvi opcode = %s(0x%x), QP name = %s, QP index = %d, buffer handle = %d, Remote node's system id = %llu. %s

## Parameters

**port** (STRING): Interconnect NIC.  
**status\_str** (STRING): Completion status in string.  
**status** (INHEX): Completion status code.  
**opcode\_str** (STRING): xfcvi opcode in string.  
**opcode** (INHEX): xfcvi opcode.  
**qpname** (STRING): QP name.  
**qpnum** (INT): QP number.  
**bufhdl** (INT): Buffer handle.  
**systemID** (LONGINT): Remote node's system ID.  
**info** (STRING): Additional info.

## xfcvi.qlqc.receive.error

### Severity

ERROR

### Description

This message occurs when the xfcvi firmware detects an error in the received frame.

### Corrective Action

(None).

## Syslog Message

FC-VI adapter: Received bad frame on port %s. Mailbox-1 = %d, Mailbox-2 = %d. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**mbox1** (INT): Content of mailbox-1.  
**mbox2** (INT): Content of mailbox-2.  
**info** (STRING): Additional info.

## xfcvi.qlqc.received.disconnect

### Severity

NOTICE

### Description

This message occurs when xfcvi driver receives disconnect request from partner.

### Corrective Action

(None).

## Syslog Message

FC-VI adapter: Disconnect request received on port %s. QP name = %s, QP index = %d, Remote node's system id = %llu. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**qpname** (STRING): QP name.  
**qpnum** (INT): QP index.  
**system\_id** (LONGINT): Remote node's system id.  
**info** (STRING): Additional info.

## xfcvi.qlgc.received.reject

### Severity

NOTICE

### Description

This message occurs when xfcvi driver receives connection reject from partner.

### Corrective Action

(None).

### Syslog Message

FC-VI adapter: Connect request rejected on port %s. QP name = %s, QP index = %d, Remote node's system id = %llu. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**qpname** (STRING): QP name.  
**qpnum** (INT): QP index.  
**system\_id** (LONGINT): Remote node's system id.  
**info** (STRING): Additional info.

## xfcvi.qlgc.recvIUErr

### Severity

ERROR

### Description

This message occurs when the FC-VI adapter receives some error in received information unit.

### Corrective Action

No corrective action is required. The driver internally resets the adapter if required. However, if you see this message frequently, there might be an issue with the FC fabric or the adapter. Contact NetApp technical support.

### Syslog Message

FC-VI adapter: Port %s received IU error. Status = %s(status code = 0x%x), xfcvi opcode = %s(0x%x), QP name = %s, QP index = %d, buffer handle = %d, Remote node's system id = %llu.

## Parameters

**port** (STRING): Interconnect NIC.  
**status\_str** (STRING): Completion status in string.  
**status** (INHEX): Completion status code.  
**opcode\_str** (STRING): xfcvi opcode in string.  
**opcode** (INHEX): xfcvi opcode.

**qpname** (STRING): QP name.  
**qpnum** (INT): QP number.  
**bufhdl** (INT): Buffer handle.  
**systemID** (LONGINT): Remote node's system ID.

## **xfcvi.qlgc.regDumped**

### **Severity**

NOTICE

### **Description**

This message occurs when the xfcvi driver saves a diagnostic dump in a file.

### **Corrective Action**

(None).

### **Syslog Message**

FC-VI adapter: Diagnostic dump for port %s saved to file %s.

### **Parameters**

**port** (STRING): xfcvi Interconnect NIC.  
**filename** (STRING): File to which the diagnostic dump was saved.

## **xfcvi.qlgc.RespFrameErr**

### **Severity**

ERROR

### **Description**

This message occurs when the adapter firmware sends a response frame with the error bit set.

### **Corrective Action**

(None).

### **Syslog Message**

FC-VI adapter: Firmware sent a response with the error bit set. Port %s, QP name = %s, QP index = %d, exchange ID 0x%x, address offset 0x%x, remote node's system id = %llu. %s

### **Parameters**

**port** (STRING): xfcvi Interconnect NIC.  
**qpname** (STRING): QP name.  
**qp\_index** (INT): QP number.  
**exchange\_id** (INTHEX): Exchange ID.  
**address** (INTHEX): Address offset of the last good frame.  
**system\_id** (LONGINT): Remote node's system id.  
**info** (STRING): Additional info.

## **xfcvi.qlgc.risc.paused**

### **Severity**

ERROR

**Description**

This message occurs when xfcvi RISC is paused.

**Corrective Action**

(None).

**Syslog Message**

FC-VI adapter: Port %s detected a RISC pause error. %s

**Parameters**

**port** (STRING): xfcvi Interconnect NIC.

**info** (STRING): Additional info.

**xfcvi.qlgc.rmt.link.down****Severity**

NOTICE

**Description**

This message occurs when xfcvi driver lost link to partner port.

**Corrective Action**

(None).

**Syslog Message**

FC-VI adapter: Link to partner node over port %s is down. Partner port id = 0x%x, partner node's system id = %llu. %s

**Parameters**

**port** (STRING): xfcvi Interconnect NIC.

**port\_id** (INHEX): Partner port id.

**system\_id** (LONGINT): Partner node's system id.

**info** (STRING): Additional info.

**xfcvi.qlgc.rmt.link.up****Severity**

NOTICE

**Description**

This message occurs when xfcvi driver gets link to partner port.

**Corrective Action**

(None).

**Syslog Message**

FC-VI adapter: Link to partner node over port %s is up. Partner port id = 0x%x, partner node's system id = %llu. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**port\_id** (INHEX): Partner port id.  
**system\_id** (LONGINT): Partner node's system id.  
**info** (STRING): Additional info.

## xfcvi.qlgc.sendIUError

### Severity

ERROR

### Description

This message occurs when the FC-VI adapter fails to send an information unit.

### Corrective Action

No corrective action is required. The driver internally retries. However, if you see this message frequently, there might be an issue with the FC fabric or the adapter. Contact NetApp technical support.

### Syslog Message

FC-VI adapter: Port %s sendIU status = %s(status code = 0x%x), xfcvi opcode = %s(0x%x), QP name = %s, QP index = %d, Remote node's system id = %llu. %s

## Parameters

**port** (STRING): Interconnect NIC.  
**status\_str** (STRING): Completion status in string.  
**status** (INHEX): Completion status code in hex.  
**opcode\_str** (STRING): xfcvi opcode in string.  
**opcode** (INHEX): xfcvi opcode in hex.  
**qpName** (STRING): QP name.  
**qpIndex** (INT): QP number.  
**systemID** (LONGINT): Remote node's system id.  
**info** (STRING): Additional info.

## xfcvi.qlgc.sent.disconnect

### Severity

NOTICE

### Description

This message occurs when xfcvi driver sends disconnect request to remote partner.

### Corrective Action

(None).

### Syslog Message

FC-VI adapter: Disconnect request sent on port %s. QP name = %s, QP index = %d, Remote node's system id = %llu. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**qpname** (STRING): QP name.  
**qpnum** (INT): QP index.

**system\_id** (LONGINT): Remote node's system id.  
**info** (STRING): Additional info.

## **xfcvi.qlgc.soft.reset.failed**

### **Severity**

ERROR

### **Description**

This message occurs when an FC-VI port's soft reset fails.

### **Corrective Action**

None.

### **Syslog Message**

FC-VI adapter: Soft reset failed at port %s.

### **Parameters**

**port** (STRING): xfcvi Interconnect adapter.

## **xfcvi.qlgc.system.error**

### **Severity**

ERROR

### **Description**

This message occurs when xfcvi driver receives system error from xfcvi firmware.

### **Corrective Action**

No corrective action is required. The driver internally resets the adapter. However, if you see this message frequently, there might be an issue with the adapter/firmware. Contact NetApp technical support.

### **Syslog Message**

FC-VI adapter: System Error on port %s. %s

### **Parameters**

**port** (STRING): xfcvi Interconnect NIC.

**info** (STRING): Additional info.

## **xfcvi.qlgc.TimeOutErr**

### **Severity**

ERROR

### **Description**

This message occurs when the adapter firmware cannot send a request.

### **Corrective Action**

(None).

## Syslog Message

FC-VI adapter: Firmware could not send a request. Port %s, QP name = %s, QP index = %d, exchange ID 0x%x, address offset 0x%x, remote node's system id = %llu. %s

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**qp\_name** (STRING): QP name.  
**qp\_index** (INT): QP number.  
**exchange\_id** (INTHEX): Exchange ID.  
**address** (INTHEX): Address offset of the last good frame.  
**system\_id** (LONGINT): Remote node's system id.  
**info** (STRING): Additional info.

## xfcvi.qlgc.transfer.error

### Severity

ERROR

### Description

This message occurs when the xfcvi firmware detects a transfer error.

### Corrective Action

(None).

## Syslog Message

FC-VI adapter: %s transfer error on port %s. Affected queue number = %d. %s

## Parameters

**trans\_type** (STRING): Transfer type.  
**port** (STRING): xfcvi Interconnect NIC.  
**queue\_num** (INT): Queue number.  
**info** (STRING): Additional info.

## xfcvi.qlgc\_regdumpfailed events

### xfcvi.qlgc\_regDumpFailed

### Severity

NOTICE

### Description

This message occurs when the HA interconnect driver could not save a diagnostic dump.

### Corrective Action

(None).

## Syslog Message

FC-VI adapter: Failed to save diagnostic dump for port %s. %s.

## Parameters

**port** (STRING): xfcvi Interconnect NIC.  
**reason** (STRING): Reason for the failure.

# xfcvi.unsupported events

## xfcvi.unsupported.config

### Severity

ERROR

### Description

This message occurs when a network adapter port behavior type is set to use FC-VI on a platform that has not been validated for its use and is therefore unsupported.

### Corrective Action

Change the port behavior type to a value other than "FC-VI". Use the "system hardware unified-connect show" command to view network adaptor port information, including the current behavior type. Use the "system hardware unified-connect modify" command to change the network adapter port behavior type.

### Syslog Message

FC-VI port behavior type not supported on network adapter port %s.

## Parameters

**port** (STRING): The network adapter port whose behavior type is set to use FC-VI.

# xfcvi.update events

## xfcvi.update.link.state

### Severity

NOTICE

### Description

This message occurs when there is a change in physical link state of the Fibre Channel Virtual Interface (FC-VI) adapter.

### Corrective Action

(None).

### Syslog Message

FC-VI adapter: Physical link is %s on port %s.

## Parameters

**link\_state** (STRING): New link state.  
**port** (STRING): Interconnect NIC.

## Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.