



## **scsi events**

### **ONTAP EMS reference**

NetApp  
November 18, 2025

# Table of Contents

scsi events	1
scsi.cmd events	1
scsi.cmd.aborted	1
scsi.cmd.abortedByHost	1
scsi.cmd.adapterFatal	2
scsi.cmd.adapterHardwareError	2
scsi.cmd.adapterHardwareErrorEMSONly	3
scsi.cmd.adapterResources	3
scsi.cmd.checkCondition	4
scsi.cmd.checkCondition.ATATimeout	5
scsi.cmd.checkCondition.ATATimeout.Failure	5
scsi.cmd.checkCondition.ATATimeout.HardReset	6
scsi.cmd.checkCondition.ATATimeout.InternalReset	7
scsi.cmd.checkCondition.ATATimeout.SoftReset	8
scsi.cmd.checkCondition.SATA.DriveDown	8
scsi.cmd.checkCondition.SATA.Timeout	9
scsi.cmd.contingentAllegiance	10
scsi.cmd.driveFailureError	10
scsi.cmd.excessiveVictim	10
scsi.cmd.failDevice	11
scsi.cmd.floatTimeout	12
scsi.cmd.fw.download.failed.butReverted	12
scsi.cmd.fw.download.failed.notRecoverable	13
scsi.cmd.fw.download.successful	13
scsi.cmd.fw.download.successful.onRetry	13
scsi.cmd.noMorePaths	14
scsi.cmd.notReadyCondition	14
scsi.cmd.overrun	15
scsi.cmd.pastTimeToLive	15
scsi.cmd.requestSenseFailed	16
scsi.cmd.selectionTimeout	16
scsi.cmd.senseDataDump	17
scsi.cmd.SFRPCrestartError	18
scsi.cmd.SFRPCtransportError	18
scsi.cmd.slotfailureError	19
scsi.cmd.targetStatus	19
scsi.cmd.transportError	20
scsi.cmd.transportErrorEMSONly	21
scsi.cmd.underrun	21
scsi.cmd.unexpectedAdapterError	22
scsi.mcc events	22
scsi.mcc.adt.ioTransportError	22
scsi.path events	23

scsi.path.excessiveErrors .....	23
scsi.scan events .....	24
scsi.scan.bus.halted .....	24
scsi.scan.lun.halted .....	24
scsi.security events .....	24
scsi.security.authLockOut .....	24
scsi.sim events .....	25
scsi.sim.checkCondition .....	25

# scsi events

## scsi.cmd events

### scsi.cmd.aborted

#### Deprecated

This event has been removed as it does not provide any useful information for a customer.

#### Severity

ERROR

#### Description

The aborted event is issued if an I/O request is aborted by a class driver.

#### Corrective Action

(None).

#### Syslog Message

%s device %s: Command aborted: cdb %s (%d).

#### Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command was aborted.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ(10) or a WRITE(10), the logical block address and the transfer length are included as well.

**dTime** (INT): The delta time from when the command was first issued.

### scsi.cmd.abortedByHost

#### Severity

ERROR

#### Description

This message occurs when the host adapter aborts an I/O request, either because it was a victim or because of an HA timeout.

#### Corrective Action

This condition does not necessarily mean that the target device is problematic. High workloads can cause loop saturation, leading to device contention for the bus. Transport issues can also cause loop throughput to decrease, thereby causing I/Os to take longer than normal. Seen occasionally, no action is required; the system handles the condition automatically by retrying the I/O that was aborted. Seen in association with a persistent error condition, such as device resets or transport errors, it is likely the symptom of a loop stability problem.

#### Syslog Message

%s device %s: Command aborted by host adapter: HA status 0x%x: cdb %s. %s

#### Parameters

**deviceType** (STRING): Device type.

**deviceName** (STRING): Electrical path name of the device on which the command failed.

**ha\_status** (INHEX): Value returned by the host adapter driver describing the completion status of the I/O request execution at the transport or physical link layer.

**cdb** (STRING): String containing the opcode byte of the CDB that was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.adapterFatal

**Severity**  
ERROR

**Description**  
The adapter fatal event is issued when the host adapter has detected a problem with either the buffer list or has exceeded the DMA size.

**Corrective Action**  
(None).

**Syslog Message**  
%s device %s: Adapter fatal error: HA status 0x%x: cdb %s.

**Parameters**

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**haStatus** (INHEX): The value of the HA status field for the failed command.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

## scsi.cmd.adapterHardwareError

**Severity**  
ERROR

**Description**  
The adapter hardware error is issued when the host adapter has detected a loop is down, the scsi bus transport had an error or a problem with the adapter hardware itself.

**Corrective Action**  
Evaluate for partial component failure the following loop hardware involved in the Fibre Channel transport: cables, transceivers, and I/O modules (LRC, ESH/ESH2, AT-FC, AT-FC2, and AT-FCX). If this error occurs in conjunction with transport errors on the same loop, ensure that all drive carriers are seated firmly in their enclosure bays, and verify that all cables are properly connected and undamaged. Also check the backplane connectors—if they are bent or broken, you must replace them. If the error persists for a specific device or I/O module from multiple adapters, you should replace that hardware module.

**Syslog Message**  
%s device %s: Adapter detected hardware error: HA status 0x%x: cdb %s.

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**haStatus** (INHEX): The value of the HA status field for the failed command.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

## scsi.cmd.adapterHardwareErrorEMSOOnly

### Severity

ERROR

### Description

This message occurs when the host adapter detects that a loop is down, the scsi bus transport has an error, or the adapter hardware itself has a problem, such as with a disk drive, cable, and so on.

### Corrective Action

Evaluate for partial component failure the following loop hardware involved in the Fibre Channel transport: cables, transceivers, and I/O modules (LRC, ESH/ESH2, AT-FC, AT-FC2, and AT-FCX). If this error occurs in conjunction with transport errors on the same loop, ensure that all drive carriers are seated firmly in their enclosure bays, and verify that all cables are properly connected and undamaged. Also check the backplane connectors—if they are bent or broken, you must replace them. If the error persists for a specific device or I/O module from multiple adapters, you should replace that hardware module.

### Syslog Message

%s device %s: Adapter detected hardware error: HA status 0x%x: cdb %s. %s

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): Physical path name of the device on which the command failed. It is in the format "path\_id.device\_id", where "path\_id := switch:port | adapter". For example, switch1:5:40 or 8b.40.

**haStatus** (INHEX): Value of the HA status field for the failed command. For this error message, the value is 6.

**cdb** (STRING): String containing the opcode byte of the command descriptor block (CDB) that was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are also included. For example, a hardware error during READ is in the format "0x28:logical\_block\_address:transfer\_length".

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.adapterResources

### Severity

ERROR

### Description

The adapter resource event is issued when the host adapter has run out of resources.

### Corrective Action

(None).

## Syslog Message

%s device %s: Adapter detected resource issue: HA status 0x%x: cdb %s.

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**haStatus** (INTHEX): The value of the HA status field for the failed command.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

## scsi.cmd.checkCondition

### Severity

ERROR

### Description

This message occurs when the system receives a "check condition" status from a device. "Check condition" status is the mechanism whereby a target device reports an informational condition or error status to the requesting host. Either the condition that generated this event is an error that occurred during execution of the command and was not cleared by retrying the request or an informational condition reporting status of the present operation or media state.

### Corrective Action

A target status of check condition normally indicates an error at the device during execution of the requested command. Such cases are often the result of an intermittent device hardware or firmware problem that is automatically handled by the Data ONTAP drivers through command retries. Check condition statuses can also be seen during shelf firmware update operations. In cases of repeated events, the specified device should be evaluated for proper operation and possible repair or replacement. A check condition with a SenseKey of "no sense" indicates an informational condition that is automatically handled by the Data ONTAP driver associated with the target device. These are normally not reported as error events. However, on occasion an unexpected informational condition may be reported by a target device. These cases should not be interpreted as a failure of the target device.

## Syslog Message

%s device %s: Check Condition: CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x)(%d). %s

## Parameters

**deviceType** (STRING): Device type.

**deviceName** (STRING): Electrical path name of the device on which the command failed.

**cdb** (STRING): String containing the opcode byte of the Command block which encountered the error. For opcodes of READ (0x28) or WRITE (0x2a), the logical block address and the transfer length are also included.

**sSenseKey** (STRING): String containing a description of the sense key for the failed command.

**sSenseCode** (STRING): String containing a description of the sense code for the failed command. If no description is available, this is a null string.

**iSenseKey** (INTHEX): Integer value of the sense key for the failed command.

**iASC** (INTHEX): Integer value of the sense code for the failed command.

**iASCQ** (INTHEX): Integer value of the sense code qualifier for the failed command.

**iFRU** (INTHEX): Integer value of the fru for the failed command.

**DTime** (INT): Delta time from first issued to sense logged.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.checkCondition.ATATimeout

### Severity

ERROR

### Description

An ATATimeout error typically indicates a problem in communicating with a disk in an ATFCX-bridged shelf.

### Corrective Action

An initial ATA I/O Timeout will result in a SOFT RESET being issued to the disk in question. Subsequent ATA I/O Timeouts will result in a HARD RESET being performed to the disk followed by a POWER CYCLE of the disk. When any of these errors are encountered, ATFCX shelflog information is also updated. Check shelflog dynamic and persistent log information for controller details on the event. Check environment shelf\_stats output for additional error statistics from the disk in question. Check disk shm\_stats and disk shm\_stats ha.disk\_id for SMART log information from the disk in question. Collating this information will help determine if this is an isolated disk problem or a controller related problem. If the environment shelf\_stats are clean along with the shelflog entries, then the error is probably a misbehaving disk. If the problem continues, RMA of the disk is recommended. However, if shelf\_stats are not clean and/or shelflog errors are present, RMA of the ATFCX module is recommended.

### Syslog Message

%s device %s: Check Condition: ATA I/O Timeout CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x)(%d).

### Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cdb** (STRING): A string containing the opcode byte of the Command block which encountered the error. For opcodes of READ (0x28) or WRITE (0x2a), the logical block address and the transfer length are also included.

**sSenseKey** (STRING): A string containing a description of the sense key for the failed command.

**sSenseCode** (STRING): A string containing a description of the sense code for the failed command. If no description is available, this is a null string.

**iSenseKey** (INTEX): The integer value of the sense key for the failed command.

**iASC** (INTEX): The integer value of the sense code for the failed command.

**iASCQ** (INTEX): The integer value of the sense code qualifier for the failed command.

**iFRU** (INTEX): The integer value of the fru for the failed command.

**DTime** (INT): Delta time from first issued to sense logged.

## scsi.cmd.checkCondition.ATATimeout.Failure

### Severity

ERROR

### Description

An ATATimeout error typically indicates a problem in communicating with a disk in an ATFCX-bridged shelf. A Failure message indicates that error recovery was unable to recover access to the drive and hence it is being actively failed.

### Corrective Action

An initial ATA I/O Timeout will result in a SOFT RESET being issued to the disk in question. Subsequent ATA I/O Timeouts will result in a HARD RESET being performed to the disk followed by a POWER CYCLE of the disk. When any of these errors are encountered, ATFCX shelflog information is also updated. Check



shelflog dynamic and persistent log information for controller details on the event. Check environment shelf\_stats output for additional error statistics from the disk in question. Check disk shm\_stats and disk shm\_stats ha.disk\_id for SMART log information from the disk in question. Collating this information will help determine if this is an isolated disk problem or a controller related problem. If the environment shelf\_stats are clean along with the shelflog entries, then the error is probably a misbehaving disk. If the problem continues, RMA of the disk is recommended. However, if shelf\_stats are not clean and/or shelflog errors are present, RMA of the ATFCX module is recommended.

### Syslog Message

%s device %s: Check Condition: ATA I/O Timeout - Failure CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x)(%d).

### Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cdb** (STRING): A string containing the opcode byte of the Command block which encountered the error. For opcodes of READ (0x28) or WRITE (0x2a), the logical block address and the transfer length are also included.

**sSenseKey** (STRING): A string containing a description of the sense key for the failed command.

**sSenseCode** (STRING): A string containing a description of the sense code for the failed command. If no description is available, this is a null string.

**iSenseKey** (INTHEX): The integer value of the sense key for the failed command.

**iASC** (INTHEX): The integer value of the sense code for the failed command.

**iASCQ** (INTHEX): The integer value of the sense code qualifier for the failed command.

**IFRU** (INTHEX): The integer value of the fru for the failed command.

**DTime** (INT): Delta time from first issued to sense logged.

## scsi.cmd.checkCondition.ATATimeout.HardReset

### Severity

ERROR

### Description

An ATATimeout error typically indicates a problem in communicating with a disk in an ATFCX-bridged shelf. A Hard Reset will be performed to the drive to attempt to clear the problem.

### Corrective Action

An initial ATA I/O Timeout will result in a SOFT RESET being issued to the disk in question. Subsequent ATA I/O Timeouts will result in a HARD RESET being performed to the disk followed by a POWER CYCLE of the disk. When any of these errors are encountered, ATFCX shelflog information is also updated. Check shelflog dynamic and persistent log information for controller details on the event. Check environment shelf\_stats output for additional error statistics from the disk in question. Check disk shm\_stats and disk shm\_stats ha.disk\_id for SMART log information from the disk in question. Collating this information will help determine if this is an isolated disk problem or a controller related problem. If the environment shelf\_stats are clean along with the shelflog entries, then the error is probably a misbehaving disk. If the problem continues, RMA of the disk is recommended. However, if shelf\_stats are not clean and/or shelflog errors are present, RMA of the ATFCX module is recommended.

### Syslog Message

%s device %s: Check Condition: ATA I/O Timeout - Hard Reset CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x)(%d).

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cdb** (STRING): A string containing the opcode byte of the Command block which encountered the error. For opcodes of READ (0x28) or WRITE (0x2a), the logical block address and the transfer length are also included.

**sSenseKey** (STRING): A string containing a description of the sense key for the failed command.

**sSenseCode** (STRING): A string containing a description of the sense code for the failed command. If no description is available, this is a null string.

**iSenseKey** (INTHEX): The integer value of the sense key for the failed command.

**iASC** (INTHEX): The integer value of the sense code for the failed command.

**iASCQ** (INTHEX): The integer value of the sense code qualifier for the failed command.

**iFRU** (INTHEX): The integer value of the fru for the failed command.

**DTime** (INT): Delta time from first issued to sense logged.

## scsi.cmd.checkCondition.ATATimeout.InternalReset

### Severity

ERROR

### Description

An ATATimeout error typically indicates a problem in communicating with a disk in an ATFCX-bridged shelf. An internal reset (aka power cycle) will be performed to the drive to attempt to clear the problem.

### Corrective Action

An initial ATA I/O Timeout will result in a SOFT RESET being issued to the disk in question. Subsequent ATA I/O Timeouts will result in a HARD RESET being performed to the disk followed by a POWER CYCLE of the disk. When any of these errors are encountered, ATFCX shelflog information is also updated. Check shelflog dynamic and persistent log information for controller details on the event. Check environment shelf\_stats output for additional error statistics from the disk in question. Check disk shm\_stats and disk shm\_stats ha.disk\_id for SMART log information from the disk in question. Collating this information will help determine if this is an isolated disk problem or a controller related problem. If the environment shelf\_stats are clean along with the shelflog entries, then the error is probably a misbehaving disk. If the problem continues, RMA of the disk is recommended. However, if shelf\_stats are not clean and/or shelflog errors are present, RMA of the ATFCX module is recommended.

### Syslog Message

%s device %s: Check Condition: ATA I/O Timeout - Internal Reset CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x)(%d).

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cdb** (STRING): A string containing the opcode byte of the Command block which encountered the error. For opcodes of READ (0x28) or WRITE (0x2a), the logical block address and the transfer length are also included.

**sSenseKey** (STRING): A string containing a description of the sense key for the failed command.

**sSenseCode** (STRING): A string containing a description of the sense code for the failed command. If no description is available, this is a null string.

**iSenseKey** (INTHEX): The integer value of the sense key for the failed command.

**iASC** (INTHEX): The integer value of the sense code for the failed command.

**iASCQ** (INTHEX): The integer value of the sense code qualifier for the failed command.

**iFRU** (INTHEX): The integer value of the fru for the failed command.

**DTime** (INT): Delta time from first issued to sense logged.

## **scsi.cmd.checkCondition.ATATimeout.SoftReset**

### **Severity**

ERROR

### **Description**

An ATATimeout error typically indicates a problem in communicating with a disk in an ATFCX-bridged shelf. A Soft Reset will be performed to the drive to attempt to clear the problem.

### **Corrective Action**

An initial ATA I/O Timeout will result in a SOFT RESET being issued to the disk in question. Subsequent ATA I/O Timeouts will result in a HARD RESET being performed to the disk followed by a POWER CYCLE of the disk. When any of these errors are encountered, ATFCX shelflog information is also updated. Check shelflog dynamic and persistent log information for controller details on the event. Check environment shelf\_stats output for additional error statistics from the disk in question. Check disk shm\_stats and disk shm\_stats ha.disk\_id for SMART log information from the disk in question. Collating this information will help determine if this is an isolated disk problem or a controller-related problem. If the environment shelf\_stats are clean along with the shelflog entries, then the error is probably a misbehaving disk. If the problem continues, RMA of the disk is recommended. However, if shelf\_stats are not clean and/or shelflog errors are present, RMA of the ATFCX module is recommended.

### **Syslog Message**

%s device %s: Check Condition: ATA I/O Timeout - Soft Reset CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x)(%d).

### **Parameters**

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cdb** (STRING): A string containing the opcode byte of the Command block which encountered the error. For opcodes of READ (0x28) or WRITE (0x2a), the logical block address and the transfer length are also included.

**sSenseKey** (STRING): A string containing a description of the sense key for the failed command.

**sSenseCode** (STRING): A string containing a description of the sense code for the failed command. If no description is available, this is a null string.

**iSenseKey** (INTHEX): The integer value of the sense key for the failed command.

**iASC** (INTHEX): The integer value of the sense code for the failed command.

**iASCQ** (INTHEX): The integer value of the sense code qualifier for the failed command.

**iFRU** (INTHEX): The integer value of the fru for the failed command.

**DTime** (INT): Delta time from first issued to sense logged.

## **scsi.cmd.checkCondition.SATA.DriveDown**

### **Severity**

ERROR

### **Description**

An SATA.DriveDown error typically indicates a problem in communicating with a disk behind a SAS to SATA bridge. A power cycle will be performed on the drive to attempt to clear the problem.

## Corrective Action

A SATA Drive Down condition should clear after a drive power cycle. If the problem persists, the drive will be failed at which point RMA of the disk is recommended.

## Syslog Message

device %s: Check Condition: SATA Drive Down CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x)(%d).

## Parameters

**deviceName** (STRING): The electrical path name of the device on which the command failed.  
**cdb** (STRING): A string containing the opcode byte of the Command block which encountered the error. For opcodes of READ (0x28) or WRITE (0x2a), the logical block address and the transfer length are also included.  
**sSenseKey** (STRING): A string containing a description of the sense key for the failed command.  
**sSenseCode** (STRING): A string containing a description of the sense code for the failed command. If no description is available, this is a null string.  
**iSenseKey** (INTHEX): The integer value of the sense key for the failed command.  
**iASC** (INTHEX): The integer value of the sense code for the failed command.  
**iASCQ** (INTHEX): The integer value of the sense code qualifier for the failed command.  
**IFRU** (INTHEX): The integer value of the fru for the failed command.  
**DTime** (INT): Delta time from first issued to sense logged.

## scsi.cmd.checkCondition.SATA.Timeout

## Severity

ERROR

## Description

An SATA.Timeout error typically indicates a problem in communicating with a disk behind a SAS to SATA bridge. A hard reset will be performed on the drive to attempt to clear the problem.

## Corrective Action

A SATA Timeout condition should clear after a drive reset. If the problem persists, the drive report a drive down condition at which point it will be power cycle.

## Syslog Message

device %s: Check Condition: SATA Drive Timeout CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x)(%d).

## Parameters

**deviceName** (STRING): The electrical path name of the device on which the command failed.  
**cdb** (STRING): A string containing the opcode byte of the Command block which encountered the error. For opcodes of READ (0x28) or WRITE (0x2a), the logical block address and the transfer length are also included.  
**sSenseKey** (STRING): A string containing a description of the sense key for the failed command.  
**sSenseCode** (STRING): A string containing a description of the sense code for the failed command. If no description is available, this is a null string.  
**iSenseKey** (INTHEX): The integer value of the sense key for the failed command.  
**iASC** (INTHEX): The integer value of the sense code for the failed command.  
**iASCQ** (INTHEX): The integer value of the sense code qualifier for the failed command.  
**IFRU** (INTHEX): The integer value of the fru for the failed command.  
**DTime** (INT): Delta time from first issued to sense logged.

## scsi.cmd.contingentAllegiance

### Severity

ERROR

### Description

This message occurs when an I/O request receives a check condition, but there is no sense data.

### Corrective Action

If there are command check conditions with no associated sense data with the device specified in this event and there are no other devices on the same bus/loop experiencing similar problems, the device should be evaluated for proper operation and possible repair/replacement.

### Syslog Message

%s device %s: Contingent allegiance: cdb %s. %s

### Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command received the contingent allegiance condition.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.driveFailureError

### Severity

ERROR

### Description

The drive reports failure after startup. Some i/o operation has failed on it and it should be removed.

### Corrective Action

(None).

### Syslog Message

%s device %s has failed during operation. Device %s is now unusable as a data or parity disk. It should be removed.

### Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The pathname to the device that has failed the operation.

**slotName** (STRING): The name of the slot in which the event occurred.

## scsi.cmd.excessiveVictim

### Severity

ERROR

## Description

This message occurs when the Storage Area Network (SAN) target or fabric continually aborts I/O operations. An initial victim abort results in the retry of the I/O operation without logging any messages. Subsequent victim aborts result in the logging of messages and additional retries. These messages are logged if there are continual aborts from the fabric or the target.

## Corrective Action

Check the fabric ports and the target ports for problems in any of the components, and if necessary, take corrective actions. Check the fabric and the target logs for any event that caused the fabric or the target to abort the I/O operations. If the problem persists, troubleshoot the fabric or target.

## Syslog Message

device %s: excessive victim abort: delta time %d: retry CDB %s: victim retry count %d: retry count %d: timeout retry count %d: path retry count %d: adapter status 0x%0x: target status 0x%0x: sense data %s - %s (0x%x - 0x%x 0x%x ). %s

## Parameters

**deviceName** (STRING): Path name of the device on which the command failed.  
**DTime** (INT): Time, in milliseconds, from when the command was first issued until this message was logged.  
**cdb** (STRING): String containing the opcode byte of the Command Descriptor Block (CDB) that was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are also included.  
**victimRetryCount** (INT): Number of retries due to I/O failure not related to this I/O operation.  
**retryCount** (INT): Number of retries from the SCSI layer.  
**timeoutRetryCount** (INT): Number of times the I/O operation was timed out and retried.  
**pathRetryCount** (INT): Number of retries for the path.  
**adapterStatus** (INTHEX): Host adapter status.  
**targetStatus** (INTHEX): Target status.  
**sSenseKey** (STRING): String containing a description of the sense key for the failed command.  
**sSenseCode** (STRING): String containing a description of the sense code for the failed command. If no description is available, this is an empty string.  
**iSenseKey** (INTHEX): Integer value of the sense key for the failed command.  
**iASC** (INTHEX): Integer value of the sense code for the failed command.  
**iASCQ** (INTHEX): Integer value of the sense code qualifier for the failed command.  
**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.failDevice

### Severity

ERROR

### Description

The failed device event is issued when a device emits a vendor specific sense key.

### Corrective Action

The failed device should be replaced immediately.

### Syslog Message

- ALERT! \*\* %s device %s has failed! Replace device at once!

## Parameters

**deviceType** (STRING): The type of device which has failed.

**deviceName** (STRING): The electrical path name of the device which failed.

## scsi.cmd.floatTimeout

### Severity

NOTICE

### Description

This message occurs when an Azure page blob I/O operation fails due to a timeout. ONTAP retries the I/O command for a maximum of five retries, until the command succeeds or fails. Successive retries increase the timeout period.

### Corrective Action

(None).

### Syslog Message

"%s" device "%s": The page blob I/O operation timeout increased to "%d" seconds: HA status "0x%x": OSC Error "%d": retry count "%d": elapsed time "%d" milliseconds: cdb %s. %s

## Parameters

**deviceType** (STRING): Device type.

**deviceName** (STRING): Electrical path name of the device on which the command failed.

**basicTimeout** (INT): Basic timeout, in seconds, set for the I/O operation.

**haStatus** (INTHEX): Value of the high-availability (HA) status field for the failed command.

**oscError** (INT): Value of the Object Store Client (OSC) error for the failed command.

**retryCount** (INT): Number of retries from the SCSI layer.

**ETime** (INT): Time, in milliseconds, from when the command was first issued until this I/O operation failed.

**cdb** (STRING): String containing the opcode byte of the Command Descriptor Block (CDB) that was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**diskInformation** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.fw.download.failed.butReverted

### Severity

ERROR

### Description

This event indicates that the download process was unsuccessful and thus the original running firmware is, again, the current running version.

### Corrective Action

If this error continues to be encountered, replace the FC-AT module in the shelf.

### Syslog Message

Firmware download failed, but successfully reverted to the previous running version on %s%d

## Parameters

**shelfName** (STRING): The name of the shelf in which the firmware download status is being provided.

**shelf\_num** (INT): The value of the shelf number.

## scsi.cmd.fw.download.failed.notRecoverable

### Severity

ERROR

### Description

This event indicates that the download process failed and the previous running version of the firmware was not recoverable.

### Corrective Action

Replace the FC-AT module in the shelf.

### Syslog Message

Firmware download was unsuccessful and the previous running shelf firmware was not recoverable on %s%d. Once the shelf is power cycled, the FC-AT module may not be operational.

## Parameters

**shelfName** (STRING): The name of the shelf in which the firmware download status is being provided.

**shelf\_num** (INT): The value of the shelf number.

## scsi.cmd.fw.download.successful

### Severity

INFORMATIONAL

### Description

This event indicates that the firmware download process completed successfully.

### Corrective Action

(None).

### Syslog Message

Firmware download was successful on %s%d

## Parameters

**shelfName** (STRING): The name of the shelf in which the firmware download status is being provided.

**shelf\_num** (INT): The value of the shelf number.

## scsi.cmd.fw.download.successful.onRetry

### Severity

NOTICE

### Description

This event indicates that the download process was successful after being retried.



## Corrective Action

(None).

## Syslog Message

Firmware download was successful after being retried on %s%d

## Parameters

**shelfName** (STRING): The name of the shelf in which the firmware download status is being provided.

**shelf\_num** (INT): The value of the shelf number.

## scsi.cmd.noMorePaths

### Severity

ERROR

### Description

The no more paths event is issued when all paths to a device have been tried without success.

### Corrective Action

(None).

## Syslog Message

%s device %s: No more paths to device: cdb %s. All retries have failed.

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

## scsi.cmd.notReadyCondition

### Severity

NOTICE

### Description

This message occurs when an I/O request receives a check condition where the device reports that it is not ready to process the I/O request. The I/O request is delayed to wait for the device to become ready, and then it is tried again.

### Corrective Action

If command not ready check conditions associated with the device specified in this event persist, the device should be evaluated for proper operation and possible repair/replacement.

## Syslog Message

%s device %s: Device returns not yet ready: CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x)(%d). %s

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**sSenseKey** (STRING): A string containing a description of the sense key for the failed command.

**sSenseCode** (STRING): A string containing a description of the sense code for the failed command. If no description is available, this is a null string.

**iSenseKey** (INTHEX): The integer value of the sense key for the failed command.

**iASC** (INTHEX): The integer value of the sense code for the failed command.

**iASCQ** (INTHEX): The integer value of the sense code qualifier for the failed command.

**iFRU** (INTHEX): The integer value of the fru for the failed command.

**dTime** (INT): The delta time from when the command was first issued.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.overrun

### Severity

ERROR

### Description

This message occurs when an I/O request receives an overrun error. Too much data was received. I/O will be retried.

### Corrective Action

If there are command overruns associated with the device specified in this event and there are no other devices on the same bus/loop experiencing similar problems, the device should be evaluated for proper operation and possible repair/replacement.

### Syslog Message

%s device %s: Received a data overrun: cdb %s. Too much data was received. Possible transmission error. I/O will be retried. %s

### Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.pastTimeToLive

### Severity

ERROR

### Description

This message occurs when an I/O request is not completed in the maximum time allowed. It is possible that the target device is attempting an error recovery operation that is impeding the progress of other I/O requests. Often these conditions are not permanent and can be cleared by retrying the request. However, the system must limit the maximum time it waits for a device to successfully complete a request. Similarly, the number of retries is also limited. If the number of retries is not exhausted before the maximum time

allowed is exceeded, this event is generated.

### Corrective Action

If there are command timeouts associated with the device specified in this event and there are no other devices on the same bus/loop experiencing similar problems, the device should be evaluated for proper operation and possible repair/replacement.

### Syslog Message

%s device %s: request failed after try #%%d: cdb %s. %s

### Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**retryCount** (INT): The number of times the command was retried before its timer expired.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.requestSenseFailed

### Severity

ERROR

### Description

The request sense failed event is issued when the HA can not the auto request sense for a command which has failed.

### Corrective Action

(None).

### Syslog Message

%s device %s: Request sense failed: out status 0x%%x: cdb %s.

### Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cmdStatus** (INTHEX): The error flags which were set for the command which failed.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

## scsi.cmd.selectionTimeout

### Severity

ERROR

### Description

This message occurs when the host adapter returns either a selection time out error (SCSI) or an invalid target error (FC). In effect, the specified device failed to acknowledge a request.

## Corrective Action

Either the targeted device failed to respond or the address of the targeted device is no longer valid. If an alternate path to the device exists, the I/O will be automatically retried on the alternate path. If seen in conjunction with other timeouts on the same bus/loop, there may be a problem with the bus/loop, not the specific device. If this event is not seen in conjunction with any other error recovery activity on the same bus/loop, the specified device should be evaluated for proper operation and possible replacement.

## Syslog Message

%s device %s: Adapter/target error: HA status 0x%x: cdb %s. Targeted device did not respond to requested I/O. I/O will be retried. %s

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**haStatus** (INTHEX): The value of the HA status field for the failed command.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.senseDataDump

## Severity

ERROR

## Description

This message occurs when a device emits a vendor-specific sense key. The returned sense data is dumped to provide the vendor with enough information to track down the problem.

## Corrective Action

Because the sense key is vendor-specific, the vendor of the device should be contacted for any corrective actions.

## Syslog Message

class 0x%x segment 0x%x sense\_key 0x%x info 0x%x 0x%x 0x%x 0x%x length 0x%x resv\_1 0x%x sense\_code 0x%x sense\_code\_qualifier 0x%x fru\_failed 0x%x flags 0x%x field\_pointer 0x%x. %s

## Parameters

**class** (INTHEX): The response code byte of the request sense data.

**segment** (INTHEX): The segment number byte of the request sense data.

**senseKey** (INTHEX): The Sense key byte of the request sense data.

**info0** (INTHEX): The most significant byte of the information field of the request sense data.

**info1** (INTHEX): The second most significant byte of the information field of the request sense data.

**info2** (INTHEX): The third most significant byte of the information field of the request sense data.

**info3** (INTHEX): The least significant byte of the information field of the request sense data.

**length** (INTHEX): The additional sense length field of the request sense data.

**resv\_1** (INTHEX): The command specific information field of the request sense data.

**senseCode** (INTHEX): The additional sense code field of the request sense data.

**senseCodeQualifier** (INTHEX): The additional sense code qualifier field of the request sense data.

**fruFailed** (INTHEX): The field replaceable unit code field of the request sense data.

**flags** (INTHEX): The flags byte of the sense key specific field of the request sense data.

**fieldPointer** (INTHEX): The field pointer bytes of the sense key specific field of the request sense data.  
**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.SFRPCrestartError

### Severity

EMERGENCY

### Description

This message occurs when an SFRPC I/O request failure is being retried and the request exceeds the maximum time allowed for the request ("Max Time to Live"). The system will restart to attempt recovery.

### Corrective Action

No additional action is required.

### Syslog Message

%s device %s: Transport error exceeded "Max Time to Live" limit during the execution of the command. The system will attempt to restart to clear the requests: HA status 0x%x: ffm\_status: %s:%d CDB %s (%d). %s

### Parameters

**deviceType** (STRING): Device type.

**deviceName** (STRING): Electrical path name of the device on which the command failed.

**ha\_status** (INTHEX): Value returned by the host adapter driver describing completion status of I/O request execution at the transport or physical link layer.

**ffm\_statusName** (STRING): Name of the status returned by the FFM services describing the completion status of the I/O request at the FFM layer.

**ffm\_status** (INTHEX): Value returned by the FFM services describing the completion status of the I/O request at the FFM layer.

**cdb** (STRING): String containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a) command, the logical block address and the transfer length are also included.

**dTime** (INT): Delta time from when the command was first issued.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, serial number and slice ID.

## scsi.cmd.SFRPCtransportError

### Severity

ERROR

### Description

This message occurs when an SFRPC I/O request encounters a transport error during command execution. Transport errors are typically the result of the SFRPC layer's inability to complete a request successfully.

### Corrective Action

Transport errors are typically unexpected events. System software takes appropriate recovery actions by retrying the I/O. No additional action is required.

### Syslog Message

%s device %s: Transport error during execution of command: HA status 0x%x: ffm\_status: %s:%d CDB %s (%d). %s

## Parameters

**deviceType** (STRING): Device type.

**deviceName** (STRING): Electrical path name of the device on which the command failed.

**ha\_status** (INTHEX): Value returned by the host adapter driver describing completion status of I/O request execution at the transport or physical link layer.

**ffm\_statusName** (STRING): Name of status returned by the FFM services describing the completion status of the I/O request at the FFM layer.

**ffm\_status** (INTHEX): Value returned by the FFM services describing the completion status of the I/O request at the FFM layer.

**cdb** (STRING): String containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a) command, the logical block address and the transfer length are included as well.

**dTime** (INT): Delta time from when the command was first issued.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, serial number and slice ID.

## scsi.cmd.slotfailureError

### Severity

ERROR

### Description

The slot failure error event is issued if an I/O request got (0x02, 0x04, 0x05) returned from the sense information.

### Corrective Action

(None).

### Syslog Message

%s device %s has detected a slot failure. Device %s is now inaccessible. Shelf must be replaced to resolve problem.

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**slotName** (STRING): The name of the slot in which the event occurred.

## scsi.cmd.targetStatus

### Severity

ERROR

### Description

This message occurs when an I/O request receives a status that is neither a reservation conflict nor a check condition, and represents an error that can not be retried.

### Corrective Action

If the command target status associated with the device specified in this event persists and/or the device is failed, the device should be evaluated for proper operation and possible repair/replacement.

## Syslog Message

%s device %s: Target Status %s: cdb %s. %s

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**targetStatus** (STRING): A string containing the target status received from the command.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.transportError

### Severity

ERROR

### Description

This message occurs when an I/O request encounters a transport error during command execution.

Transport errors are typically the result of an incomplete data transfer (e.g., device expected more data than was received from the host adapter, or the adapter expected more data than was received from the device), a data overrun meaning that more data was transferred than was expected, a physical link transmission (parity or CRC) error, or a bus protocol error (phase error or an unexpected bus state transition.)

### Corrective Action

Transport errors are typically unexpected events. The exception is when drives are physically added or removed from the bus or drive enclosure. However, transport protocols do account for detection and recovery of transmission errors through CRC or Parity mechanisms. When such an error is reported to the adapter driver, the associated request is retried. For example, on a Fibre Channel link, an occasional transmission error is consistent with the expected Bit Error Rate specifications of the link. Output from the `fcadmin link_stats` command can be used to obtain error counts for CRC and transport errors. If they exceed observed values from normally operating loops, loop hardware should be evaluated for partial failure of a component involved in the Fibre Channel transport. Common things to check include complete seating of drive carriers in enclosure bays, properly secured cable connections, LRC/ESH seating, and crimped or otherwise damaged cables.

## Syslog Message

%s device %s: Transport error during execution of command: HA status 0x%x: cdb %s.

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**ha\_status** (INHEX): Value returned by the host adapter driver describing completion status of I/O request execution at the transport or physical link layer.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a) command, the logical block address and the transfer length are included as well.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.transportErrorEMSOOnly

### Severity

ERROR

### Description

This message occurs when an I/O request encounters a transport error during command execution. Transport errors are typically unexpected events, unless you added or removed disk drives from the bus or drive enclosure. Unexpected transport errors are typically the result of the following conditions: An incomplete data transfer where the device expected more data from the host adapter than it received (or the adapter expected more data from the device than it received); A data overrun where more data than expected was transferred; A physical link transmission (parity or CRC [cyclic redundancy check]) error; Or a bus protocol error (phase error or unexpected bus state transition).

### Corrective Action

Transport protocols do account for detection and recovery of transmission errors through CRC or parity mechanisms. When this error is reported to the adapter driver, the associated request is retried. For example, on a Fibre Channel link, an occasional transmission error is consistent with the expected Bit Error Rate specifications of the link. Therefore, use output from the "fcadmin link\_stats" command to obtain error counts for CRC and transport errors. If the error counts exceed observed values from normally operating loops, evaluate for partial component failure the loop hardware involved in the Fibre Channel transport. Common things to check include complete seating of drive carriers in enclosure bays, properly secured cable connections, complete LRC/ESH module seating, and crimped or otherwise damaged cables.

### Syslog Message

%s device %s: Transport error during execution of command: HA status 0x%x: cdb %s. %s

### Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): Physical path name of the device on which the command failed. It is in the format "path\_id.device\_id", where "path\_id := switch:port | adapter". For example, switch1:5:40 or 8b.40.

**ha\_status** (INHEX): Value returned by the host adapter driver describing completion status of the I/O request execution at the transport layer or physical link layer. For this error message, the value is 9.

**cdb** (STRING): String containing the opcode byte of the command descriptor block (CDB) that was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a) command, the logical block address and the transfer length are also included. For example, 0x28:logical\_block\_address:transfer\_length.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.underrun

### Severity

ERROR

### Description

This message occurs when an I/O request receives an underrun error and has not specifically instructed the SCSI layer to ignore underrun errors.

### Corrective Action

If there are command underruns associated with the device specified in this event and there are no other devices on the same bus/loop experiencing similar problems, the device should be evaluated for proper operation and possible repair/replacement.



## Syslog Message

%s device %s: Received a data underrun: cdb %s. Not all the data was received. Possible transmission error. I/O will be retried. %s

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.cmd.unexpectedAdapterError

### Severity

ERROR

### Description

This message occurs when a hardware adapter returns an error that is unknown to the SCSI layer.

### Corrective Action

The associated hardware adapter should be evaluated for proper operation and possible repair/replacement.

## Syslog Message

%s device %s: Unexpected adapter error: HA status 0x%x: cdb %s. %s

## Parameters

**deviceType** (STRING): The device type.

**deviceName** (STRING): The electrical path name of the device on which the command failed.

**haStatus** (INTEX): The value of the HA status field for the failed command.

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (0x2a), the logical block address and the transfer length are included as well.

**disk\_information** (STRING): Formatted information about the disk, including the disk's vendor, model, firmware revision, and serial number.

## scsi.mcc events

### scsi.mcc.adt.ioTransportError

### Severity

ERROR

### Description

Generated when an I/O request encounters an error because of an iSCSI Protocol Error, a end device error, or some stack internal error.

## Corrective Action

Transport errors are typically unexpected events; the exception being when drives are physically added or removed from the bus or drive enclosure. However, transport protocols do account for detection and recovery of transmission errors through CRC or Parity mechanisms. When such an error is reported to the adapter driver, the associated request is retried. Common things to check include complete seating of drive carriers in enclosure bays, properly secured cable connections, LRC/ESH seating, and crimped or otherwise damaged cables.

## Syslog Message

mcc\_adt[%u] - Transport error during execution of command: HA status 0x%x: CAM transport status 0x%x : cdb %s.

## Parameters

**path\_instance** (INTEX): Value returned by the host adapter driver describing path instance.

**ha\_status** (INTEX): Value returned by the host adapter driver describing completion status of I/O request execution at the transport or physical link layer.

**cam\_status** (INTEX): Value returned by the host adapter driver in the FreeBSD CAM transport layer

**cdb** (STRING): A string containing the opcode byte of the CDB which was sent to the device. If the opcode was for a READ (0x28) or a WRITE (x02a) command, the logical block address and the transfer length are included as well.

# scsi.path events

## scsi.path.excessiveErrors

### Severity

ERROR

### Description

This message occurs when excessive errors are encountered on this device within a short-enough time period to raise concern that there might be a faulty component between the storage initiator and device. You can use the option 'ra.path\_switch.threshold' to control how sensitive Data ONTAP® is to device errors. Setting it to a higher value requires more errors to trigger this event.

## Corrective Action

Device errors are a common indication of storage domain stability problems. In some cases, the interconnect is operating normally and the specified device is having trouble processing I/O requests in a timely manner. In such cases, evaluate the specified device for possible replacement. Quite often the problem results from the partial failure of a component involved in the storage transport. Common things to check include complete seating of drive carriers in enclosure bays, properly secured cable connections, shelf IOM seating, failing Fibre Channel switch components, failing FC SAS bridge components and crimped or otherwise damaged cables.

## Syslog Message

Excessive errors encountered by adapter %s on %s device %s.

## Parameters

**adapterName** (STRING): Name of the associated storage host bus adapter.

**deviceType** (STRING): Device type.

**deviceName** (STRING): Name of the storage device.

## scsi.scan events

### scsi.scan.bus.halted

#### Severity

NOTICE

#### Description

This message occurs when the creation of the SCSI transport (xpt) path fails.

#### Corrective Action

Check whether the device is connected correctly.

#### Syslog Message

The path that is creating the xpt path has failed with status 0x%x. Bus scan halted.

#### Parameters

**status** (INTEXT): SCSI scan bus halt status.

### scsi.scan.lun.halted

#### Severity

NOTICE

#### Description

This message occurs when the creation of the SCSI transport (xpt) path fails.

#### Corrective Action

Check whether the device is connected correctly.

#### Syslog Message

The path that is creating the xpt path has failed with status 0x%x. Bus scan halted.

#### Parameters

**status** (INTEXT): SCSI scan LUN halted status.

## scsi.security events

### scsi.security.authLockOut

#### Deprecated

This event is removed to disassociate from SCSI, with the advent of NVMe encrypting drives. See replacement message EMS\_nse\_authLockedOut.

#### Severity

ERROR

#### Description

This message occurs when a self-encrypting drive (SED) reports excessive sequential failed authentication attempts with an incorrect Authentication Key (AK). To prevent brute-force AK attacks, the SED will no

longer accept even the correct AK. Access and control of the SED are affected. BandMaster1 authority lockout affects protection controls on user data. The system cannot authenticate using the data AK. A device power-cycle will result in data loss on the drive. For other lockouts, some aspect of compliance with Federal Information Processing Standard (FIPS) PUB 140-2 is compromised. Erase Master lockout disables cryptographic sanitize and destroy.

### Corrective Action

For BandMaster1 authority lockout, reset the AK to its default value and simultaneously erase user data using the "storage encryption disk sanitize" command or the (advanced privilege) "disk encrypt sanitize" command in node shell/maintenance mode. Power-cycle clears Physical Ownership lockout in some SEDs. For other lockouts, reset the SED to its as-manufactured state and erase user data using the "storage encryption disk revert-to-original-state" command or the (advanced privilege) "disk encrypt revert\_original" command in node shell/maintenance mode with the PSID value from the device label. If the PSID is not available, replace the drive. After clearing lockout, make the drive a spare by using the "storage disk assign" command and (advanced privilege) "storage disk unfail [-spare]" command as needed. To prevent lockouts, ensure that all cluster NSE nodes have all SED AKs. Display SED key IDs by using the "storage encryption disk show [-fips]" command. Verify them against those retrieved from the AK storage method: KMIP servers: Use the "security key-manager restore" command. Onboard key management: Use the "security key-manager key show" command.

### Syslog Message

Lockout on Storage Encryption device %s; security provider: %s, authority: %s, during operation "%s".

### Parameters

**deviceName** (STRING): Name of the device.  
**securityProvider** (STRING): Name of the security provider.  
**authority** (STRING): Name of the authority.  
**operation** (STRING): Description of the operation that attempted authentication.

## scsi.sim events

### scsi.sim.checkCondition

#### Severity

ERROR

#### Description

A Check Condition is the mechanism whereby a target device reports an informational condition or error status to the requesting host. Either the condition that generated this event is an error that occurred during execution of the command and was not cleared by retrying the request or an informational condition reporting status of the present operation or media state.

#### Corrective Action

A target status of Check Condition normally indicates an error at the device during execution of the requested command. Such cases are often the result of an intermittent device hardware or firmware problem that is automatically handled by the Data ONTAP drivers through command retries. In cases of repeated events, the specified device should be evaluated for proper operation and possible repair or replacement. A Check Condition with a SenseKey of "no sense" indicates an informational condition that is automatically handled by the Data ONTAP driver associated with the target device. These are normally not reported as error events. However, on occasion an unexpected informational condition may be reported by a target device. These cases should not be interpreted as a failure of the target device.

## Syslog Message

%s device %s: Check Condition: CDB %s: Sense Data %s - %s (0x%x - 0x%x 0x%x 0x%x) Retry: %d/%d (%d).

## Parameters

**deviceType** (STRING): Device type.

**deviceName** (STRING): Electrical path name of the device on which the command failed.

**cdb** (STRING): String containing the opcode byte of the Command block which encountered the error. For opcodes of READ (0x28) or WRITE (0x2a), the logical block address and the transfer length are also included.

**sSenseKey** (STRING): String containing a description of the sense key for the failed command.

**sSenseCode** (STRING): String containing a description of the sense code for the failed command. If no description is available, this is a null string.

**iSenseKey** (INTHEX): Integer value of the sense key for the failed command.

**iASC** (INTHEX): Integer value of the sense code for the failed command.

**iASCQ** (INTHEX): Integer value of the sense code qualifier for the failed command.

**iFRU** (INTHEX): Integer value of the fru for the failed command.

**retryCount** (INT): Number of times the command was retried

**freeRetryCount** (INT): Number of free retries the command was given before it was successful.

**DTime** (INT): Delta time from first issued to sense logged.

## Copyright information

Copyright © 2025 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.