



# Where to find information for configurations with storage arrays

ONTAP FlexArray

NetApp  
September 20, 2021

This PDF was generated from [https://docs.netapp.com/us-en/ontap-flexarray/install/concept\\_limits\\_information\\_for\\_a\\_configuration\\_with\\_storage\\_arrays.html](https://docs.netapp.com/us-en/ontap-flexarray/install/concept_limits_information_for_a_configuration_with_storage_arrays.html) on September 20, 2021. Always check docs.netapp.com for the latest.

# Table of Contents

- Where to find information for configurations with storage arrays . . . . . 1
- Limit types for configurations with storage arrays . . . . . 1
- Where to find information about ONTAP support for storage arrays . . . . . 1
- 32xx system configuration restrictions . . . . . 2

# Where to find information for configurations with storage arrays

When planning your configuration for using ONTAP systems with storage arrays, you should check various sources for information about array LUN configuration in addition to the product documentation.

Tools available on the NetApp Support Site provide, in a central location, specific information about which features, configurations, and storage array models are supported in particular releases.

## Related information

[NetApp Support](#)

## Limit types for configurations with storage arrays

You must consider certain storage array limits when planning for an ONTAP configuration.

The *Hardware Universe* contains specific limit values for storage arrays and native disks.

The following types of limits apply only to storage arrays and not to native disks:

- Minimum and maximum array LUN size that ONTAP supports
- Minimum size for the array LUN for the root volume
- Spare core array LUN minimum size
- Limits for RAID groups with array LUNs
- Minimum aggregate size for an aggregate of array LUNs
- Maximum number of array LUNs and disks combined, per platform

## Related information

[NetApp Hardware Universe](#)

## Where to find information about ONTAP support for storage arrays

Not all ONTAP releases support the same features, configurations, system models, and storage array models. During your deployment planning, you must check ONTAP support information to verify that your deployment conforms to ONTAP hardware and software requirements for all systems in the deployment.

The following table lists the information sources that contain the details of the hardware and software requirements associated with ONTAP systems:

For information about...	You should look here...
<p>ONTAP working with devices, including the following:</p> <ul style="list-style-type: none"> <li>• Supported storage arrays and storage array firmware</li> <li>• Supported switches and switch firmware</li> <li>• Whether your storage array supports nondisruptive (live) upgrade of the storage array firmware</li> <li>• Whether a MetroCluster configuration is supported with your storage array</li> </ul>	<p><a href="#">NetApp Interoperability Matrix Tool</a></p>
<p>ONTAP limits for releases and platforms, including the following:</p> <ul style="list-style-type: none"> <li>• Minimum and maximum array LUN sizes, including the minimum array LUN size for the root volume and spare core array LUNs</li> <li>• Minimum aggregate size for aggregates with array LUNs</li> <li>• Supported block size</li> <li>• Minimum and maximum capacity</li> <li>• Neighborhood limits</li> </ul>	<p><a href="#">NetApp Hardware Universe</a></p>
<p>Setting up E-Series storage arrays, including the following:</p> <ul style="list-style-type: none"> <li>• Site preparation requirements</li> <li>• Cabling instructions</li> <li>• SANtricity software installation and configuration instructions</li> </ul>	<p>The following E-Series documentation:</p> <ul style="list-style-type: none"> <li>• <i>E-Series Storage Systems Site Preparation Guide</i></li> <li>• <i>E-Series Storage Systems Hardware Cabling Guide</i></li> <li>• <i>SANtricity ES Storage Manager documentation</i></li> </ul> <p>You can access these documents from the NetApp Support site.</p> <p><a href="#">NetApp Support</a></p>
<p>What is supported for specific storage arrays, including supported configurations</p>	<ul style="list-style-type: none"> <li>• <a href="#">FlexArray virtualization implementation for third-party storage</a></li> <li>• <a href="#">FlexArray virtualization implementation for NetApp E-Series storage</a></li> </ul>

## 32xx system configuration restrictions

There are some restrictions for 32xx systems that do not apply to other models. You must be aware of these while configuring the systems.

The two onboard FC ports labeled 0c and 0d, are not on independent busses. Therefore, they do not provide storage redundancy. Some port failures can cause the system to panic. To configure redundant port pairs, you need to use an FC HBA in an available expansion slot.

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.