



## **Manage shelves**

### ONTAP 9.10.1 REST API Documentation

NetApp  
January 31, 2025

This PDF was generated from [https://docs.netapp.com/us-en/ontap-restapi-9101/ontap/storage\\_shelves\\_endpoint\\_overview.html](https://docs.netapp.com/us-en/ontap-restapi-9101/ontap/storage_shelves_endpoint_overview.html) on January 31, 2025. Always check [docs.netapp.com](https://docs.netapp.com) for the latest.

# Table of Contents

- Manage shelves ..... 1
  - Storage shelves endpoint overview ..... 1
  - Retrieve shelves ..... 19
  - Retrieve a shelf ..... 44
  - Update a shelf location LED ..... 57

# Manage shelves

## Storage shelves endpoint overview

### Retrieving storage shelf information

The storage shelf GET API retrieves all of the shelves in the cluster.

### Examples

#### 1) Retrieve a list of shelves from the cluster

The following example shows the response with a list of shelves in the cluster:

```
# The API:
/api/storage/shelves

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/shelves" -H "accept:
application/hal+json"

# The response:
{
  "records": [
    {
      "uid": "3109174803597886800",
      "_links": {
        "self": {
          "href": "/api/storage/shelves/3109174803597886800"
        }
      }
    },
    {
      "uid": "9237728366621690448",
      "_links": {
        "self": {
          "href": "/api/storage/shelves/9237728366621690448"
        }
      }
    },
    {
      "uid": "9946762738829886800",
      "_links": {
```

```

    "self": {
      "href": "/api/storage/shelves/9946762738829886800"
    }
  },
  {
    "uid": "10318311901725526608",
    "_links": {
      "self": {
        "href": "/api/storage/shelves/10318311901725526608"
      }
    }
  },
  {
    "uid": "13477584846688355664",
    "_links": {
      "self": {
        "href": "/api/storage/shelves/13477584846688355664"
      }
    }
  }
],
"num_records": 5,
"_links": {
  "self": {
    "href": "/api/storage/shelves/"
  }
}
}

```

## 2) Retrieve a specific shelf from the cluster

The following example shows the response of the requested shelf. If there is no shelf with the requested uid, an error is returned.

```

# The API:
/api/storage/shelves/{uid}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/shelves/3109174803597886800" -H
"accept: application/hal+json"

# The response:

```

```

{
  "uid": "3109174803597886800",
  "name": "6.10",
  "id": "10",
  "serial_number": "SHU0954292N0HAH",
  "model": "DS4246",
  "module_type": "iom6",
  "internal": false,
  "local": true,
  "manufacturer": {
    "name": "NETAPP"
  },
  "state": "ok",
  "connection_type": "sas",
  "disk_count": 24,
  "location_led": "off",
  "paths": [
    {
      "name": "0e",
      "node": {
        "uid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
        "name": "node-1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
          }
        }
      },
      "_links": {
        "self": {
          "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0e"
        }
      }
    },
    {
      "name": "0g",
      "node": {
        "uid": "0530d6c1-8c6d-11e8-907f-00a0985a72ee",
        "name": "node-1",
        "_links": {
          "self": {
            "href": "/api/cluster/nodes/0530d6c1-8c6d-11e8-907f-00a0985a72ee"
          }
        }
      }
    }
  ]
}

```

```
    }
  },
  "_links": {
    "self": {
      "href": "/api/storage/ports/0530d6c1-8c6d-11e8-907f-00a0985a72ee/0g"
    }
  }
],
"bays": [
  {
    "id": 0,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 1,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 2,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 3,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 4,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 5,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  }
]
```

```
},
{
  "id": 6,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 7,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 8,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 9,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 10,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 11,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 12,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 13,
  "has_disk": true,
```

```
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 14,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 15,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 16,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 17,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 18,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 19,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
    "id": 20,
    "has_disk": true,
    "type": "single_disk",
    "state": "ok"
  },
  {
```



```
"id": 21,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 22,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
},
{
  "id": 23,
  "has_disk": true,
  "type": "single_disk",
  "state": "ok"
}
],
"frus": [
  {
    "type": "module",
    "id": 0,
    "state": "ok",
    "part_number": "111-00690+B2",
    "serial_number": "8001900099",
    "firmware_version": "0191",
    "installed": true
  },
  {
    "type": "module",
    "id": 1,
    "state": "ok",
    "part_number": "111-00190+B0",
    "serial_number": "7903785183",
    "firmware_version": "0191",
    "installed": true
  },
  {
    "type": "psu",
    "id": 1,
    "state": "ok",
    "part_number": "0082562-12",
    "serial_number": "PMW82562007513E",
    "firmware_version": "0311",
    "installed": true,
    "psu": {
```

```
    "model": "9C"
  }
},
{
  "type": "psu",
  "id": 2,
  "state": "ok",
  "part_number": "0082562-12",
  "serial_number": "PMW825620075138",
  "firmware_version": "0311",
  "installed": true,
  "psu": {
    "model": "9C"
  }
},
{
  "type": "psu",
  "id": 3,
  "state": "ok",
  "part_number": "0082562-12",
  "serial_number": "PMW8256200750BA",
  "firmware_version": "0311",
  "installed": true,
  "psu": {
    "model": "9C"
  }
},
{
  "type": "psu",
  "id": 4,
  "state": "ok",
  "part_number": "0082562-12",
  "serial_number": "PMW8256200750A2",
  "firmware_version": "0311",
  "installed": true,
  "psu": {
    "model": "9C"
  }
}
],
"ports": [
  {
    "id": 0,
    "module_id": "a",
    "designator": "square",
    "state": "connected",
```

```
"internal": false,
"wnn": "500A098000C9EDBF",
"cable": {
  "identifier": "5001086000702488-500a098000c9edbf",
  "part_number": "112-00430+A0",
  "length": "2m",
  "serial_number": "APF16510229807"
},
"remote": {
  "wnn": "5001086000702488",
  "phy": "08"
}
},
{
  "id": 1,
  "module_id": "a",
  "designator": "circle",
  "state": "connected",
  "internal": false,
  "wnn": "500A098000C9EDBF",
  "cable": {
    "identifier": "500a098000d5c4bf-500a098000c9edbf",
    "part_number": "112-00176+A0",
    "length": "0.5-1.0m",
    "serial_number": "APF133917610YT"
  },
  "remote": {
    "wnn": "500A098000D5C4BF",
    "phy": "00"
  }
},
{
  "id": 2,
  "module_id": "b",
  "designator": "square",
  "state": "connected",
  "internal": false,
  "wnn": "500A098004F208BF",
  "cable": {
    "identifier": "5001086000702648-500a098004f208bf",
    "part_number": "112-00430+A0",
    "length": "2m",
    "serial_number": "APF16510229540"
  },
  "remote": {
    "wnn": "5001086000702648",
```

```

    "phy": "08"
  }
},
{
  "id": 3,
  "module_id": "b",
  "designator": "circle",
  "state": "connected",
  "internal": false,
  "wwn": "500A098004F208BF",
  "cable": {
    "identifier": "500a0980062ba33f-500a098004f208bf",
    "part_number": "112-00176+20",
    "length": "0.5-1.0m",
    "serial_number": "832210017"
  },
  "remote": {
    "wwn": "500A0980062BA33F",
    "phy": "00"
  }
}
],
"fans": [
  {
    "id": 1,
    "location": "rear of the shelf on the upper left power supply",
    "rpm": 3150,
    "state": "ok"
  },
  {
    "id": 2,
    "location": "rear of the shelf on the upper left power supply",
    "rpm": 3000,
    "state": "ok"
  },
  {
    "id": 3,
    "location": "rear of the shelf on the upper right power supply",
    "rpm": 3220,
    "state": "ok"
  },
  {
    "id": 4,
    "location": "rear of the shelf on the upper right power supply",
    "rpm": 3000,
    "state": "ok"
  }
]

```

```

},
{
  "id": 5,
  "location": "rear of the shelf on the lower left power supply",
  "rpm": 3000,
  "state": "ok"
},
{
  "id": 6,
  "location": "rear of the shelf on the lower left power supply",
  "rpm": 3150,
  "state": "ok"
},
{
  "id": 7,
  "location": "rear of the shelf on the lower right power supply",
  "rpm": 3150,
  "state": "ok"
},
{
  "id": 8,
  "location": "rear of the shelf on the lower right power supply",
  "rpm": 3000,
  "state": "ok"
}
],
"temperature_sensors": [
  {
    "id": 1,
    "location": "front of the shelf on the left, on the OPS panel",
    "temperature": 20,
    "ambient": true,
    "state": "ok",
    "threshold": {
      "high": {
        "critical": 42,
        "warning": 40
      },
      "low": {
        "critical": 0,
        "warning": 5
      }
    }
  },
  {
    "id": 2,

```

```

"location": "inside of the shelf on the midplane",
"temperature": 29,
"ambient": false,
"state": "ok",
"threshold": {
  "high": {
    "critical": 55,
    "warning": 50
  },
  "low": {
    "critical": 5,
    "warning": 10
  }
}
},
{
  "id": 3,
  "location": "rear of the shelf on the upper left power supply",
  "temperature": 33,
  "ambient": false,
  "state": "ok",
  "threshold": {
    "high": {
      "critical": 55,
      "warning": 50
    },
    "low": {
      "critical": 5,
      "warning": 10
    }
  }
}
},
{
  "id": 4,
  "location": "rear of the shelf on the upper left power supply",
  "temperature": 41,
  "ambient": false,
  "state": "ok",
  "threshold": {
    "high": {
      "critical": 70,
      "warning": 65
    },
    "low": {
      "critical": 5,
      "warning": 10
    }
  }
}

```

```
    }
  },
  {
    "id": 5,
    "location": "rear of the shelf on the upper right power supply",
    "temperature": 32,
    "ambient": false,
    "state": "ok",
    "threshold": {
      "high": {
        "critical": 55,
        "warning": 50
      },
      "low": {
        "critical": 5,
        "warning": 10
      }
    }
  },
  {
    "id": 6,
    "location": "rear of the shelf on the upper right power supply",
    "temperature": 41,
    "ambient": false,
    "state": "ok",
    "threshold": {
      "high": {
        "critical": 70,
        "warning": 65
      },
      "low": {
        "critical": 5,
        "warning": 10
      }
    }
  },
  {
    "id": 7,
    "location": "rear of the shelf on the lower left power supply",
    "temperature": 34,
    "ambient": false,
    "state": "ok",
    "threshold": {
      "high": {
        "critical": 55,
```

```

        "warning": 50
    },
    "low": {
        "critical": 5,
        "warning": 10
    }
}
},
{
    "id": 8,
    "location": "rear of the shelf on the lower left power supply",
    "temperature": 45,
    "ambient": false,
    "state": "ok",
    "threshold": {
        "high": {
            "critical": 70,
            "warning": 65
        },
        "low": {
            "critical": 5,
            "warning": 10
        }
    }
}
},
{
    "id": 9,
    "location": "rear of the shelf on the lower right power supply",
    "temperature": 30,
    "ambient": false,
    "state": "ok",
    "threshold": {
        "high": {
            "critical": 55,
            "warning": 50
        },
        "low": {
            "critical": 5,
            "warning": 10
        }
    }
}
},
{
    "id": 10,
    "location": "rear of the shelf on the lower right power supply",
    "temperature": 40,

```



```
"ambient": false,
"state": "ok",
"threshold": {
  "high": {
    "critical": 70,
    "warning": 65
  },
  "low": {
    "critical": 5,
    "warning": 10
  }
}
},
{
  "id": 11,
  "location": "rear of the shelf at the top left, on shelf module A",
  "temperature": 30,
  "ambient": false,
  "state": "ok",
  "threshold": {
    "high": {
      "critical": 60,
      "warning": 55
    },
    "low": {
      "critical": 5,
      "warning": 10
    }
  }
}
},
{
  "id": 12,
  "location": "rear of the shelf at the top right, on shelf module B",
  "temperature": 33,
  "ambient": false,
  "state": "ok",
  "threshold": {
    "high": {
      "critical": 60,
      "warning": 55
    },
    "low": {
      "critical": 5,
      "warning": 10
    }
  }
}
}
```

```
    }
  ],
  "voltage_sensors": [
    {
      "id": 1,
      "location": "rear of the shelf on the upper left power supply",
      "voltage": 5.11,
      "state": "ok"
    },
    {
      "id": 2,
      "location": "rear of the shelf on the upper left power supply",
      "voltage": 12.38,
      "state": "ok"
    },
    {
      "id": 3,
      "location": "rear of the shelf on the upper right power supply",
      "voltage": 5.11,
      "state": "ok"
    },
    {
      "id": 4,
      "location": "rear of the shelf on the upper right power supply",
      "voltage": 12.26,
      "state": "ok"
    },
    {
      "id": 5,
      "location": "rear of the shelf on the lower left power supply",
      "voltage": 5.7,
      "state": "ok"
    },
    {
      "id": 6,
      "location": "rear of the shelf on the lower left power supply",
      "voltage": 12.26,
      "state": "ok"
    },
    {
      "id": 7,
      "location": "rear of the shelf on the lower right power supply",
      "voltage": 5.15,
      "state": "ok"
    },
    {
```

```
    "id": 8,  
    "location": "rear of the shelf on the lower right power supply",  
    "voltage": 12.3,  
    "state": "ok"  
  }  
],  
"current_sensors": [  
  {  
    "id": 1,  
    "location": "rear of the shelf on the upper left power supply",  
    "current": 6990,  
    "state": "ok"  
  },  
  {  
    "id": 2,  
    "location": "rear of the shelf on the upper left power supply",  
    "current": 5150,  
    "state": "ok"  
  },  
  {  
    "id": 3,  
    "location": "rear of the shelf on the upper right power supply",  
    "current": 4600,  
    "state": "ok"  
  },  
  {  
    "id": 4,  
    "location": "rear of the shelf on the upper right power supply",  
    "current": 4800,  
    "state": "ok"  
  },  
  {  
    "id": 5,  
    "location": "rear of the shelf on the lower left power supply",  
    "current": 4140,  
    "state": "ok"  
  },  
  {  
    "id": 6,  
    "location": "rear of the shelf on the lower left power supply",  
    "current": 7770,  
    "state": "ok"  
  },  
  {  
    "id": 7,  
    "location": "rear of the shelf on the lower right power supply",
```

```

    "current": 4140,
    "state": "ok"
  },
  {
    "id": 8,
    "location": "rear of the shelf on the lower right power supply",
    "current": 4720,
    "state": "ok"
  }
],
"acps": [
  {
    "enabled": true,
    "channel": "in_band",
    "connection_state": "active",
    "node": {
      "uuid": "cf62d23c-6100-11eb-9852-00a098fd725d",
      "name": "cat33-01",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/cf62d23c-6100-11eb-9852-00a098fd725d"
        }
      }
    }
  },
  {
    "enabled": true,
    "channel": "in_band",
    "connection_state": "active",
    "node": {
      "uuid": "d0892dd7-6100-11eb-9cdb-d039ea010238",
      "name": "cat33-02",
      "_links": {
        "self": {
          "href": "/api/cluster/nodes/d0892dd7-6100-11eb-9cdb-d039ea010238"
        }
      }
    }
  }
],
"_links": {
  "self": {
    "href": "/api/storage/shelves/3109174803597886800"
  }
}

```

```
}  
}
```

---

## Modifying storage shelf

The storage shelf PATCH API modifies the shelf location LED.

---

### Example

---

```
# The API:  
/api/storage/shelves  
  
# The call:  
curl -X PATCH "https://<mgmt-ip>/api/storage/shelves/3109174803597886800"  
-H "accept: application/hal+json" -H "Content-Type: application/hal+json"  
-d '{"location_led": "on"}'  
  
# The response:  
{  
}
```

---

## Retrieve shelves

GET /storage/shelves

**Introduced In:** 9.6

Retrieves a collection of shelves.

### Related ONTAP commands

- storage shelf show
- storage shelf port show
- storage shelf drawer show
- storage shelf acp show

## Learn more

- [DOC /storage/shelves](#)

## Parameters

Name	Type	In	Required	Description
bays.id	integer	query	False	Filter by bays.id
bays.state	string	query	False	Filter by bays.state
bays.has_disk	boolean	query	False	Filter by bays.has_disk
bays.type	string	query	False	Filter by bays.type
local	boolean	query	False	Filter by local <ul style="list-style-type: none"><li>• Introduced in: 9.8</li></ul>
location_led	string	query	False	Filter by location_led <ul style="list-style-type: none"><li>• Introduced in: 9.10</li></ul>
current_sensors.id	integer	query	False	Filter by current_sensors.id <ul style="list-style-type: none"><li>• Introduced in: 9.10</li></ul>
current_sensors.current	integer	query	False	Filter by current_sensors.current <ul style="list-style-type: none"><li>• Introduced in: 9.10</li></ul>
current_sensors.state	string	query	False	Filter by current_sensors.state <ul style="list-style-type: none"><li>• Introduced in: 9.10</li></ul>

Name	Type	In	Required	Description
current_sensors.location	string	query	False	Filter by current_sensors.location  • Introduced in: 9.10
voltage_sensors.id	integer	query	False	Filter by voltage_sensors.id  • Introduced in: 9.10
voltage_sensors.state	string	query	False	Filter by voltage_sensors.state  • Introduced in: 9.10
voltage_sensors.voltage	number	query	False	Filter by voltage_sensors.voltage  • Introduced in: 9.10
voltage_sensors.location	string	query	False	Filter by voltage_sensors.location  • Introduced in: 9.10
errors.reason.arguments.message	string	query	False	Filter by errors.reason.arguments.message  • Introduced in: 9.10
errors.reason.arguments.code	string	query	False	Filter by errors.reason.arguments.code  • Introduced in: 9.10

Name	Type	In	Required	Description
errors.reason.message	string	query	False	Filter by errors.reason.message  • Introduced in: 9.9
errors.reason.code	string	query	False	Filter by errors.reason.code  • Introduced in: 9.9
errors.reason.target	string	query	False	Filter by errors.reason.target  • Introduced in: 9.10
state	string	query	False	Filter by state
temperature_sensors.state	string	query	False	Filter by temperature_sensors.state  • Introduced in: 9.10
temperature_sensors.threshold.high.warning	integer	query	False	Filter by temperature_sensors.threshold.high.warning  • Introduced in: 9.10
temperature_sensors.threshold.high.critical	integer	query	False	Filter by temperature_sensors.threshold.high.critical  • Introduced in: 9.10



Name	Type	In	Required	Description
temperature_sensors.threshold.low.critical	integer	query	False	Filter by temperature_sensors.threshold.low.critical  • Introduced in: 9.10
temperature_sensors.threshold.low.warning	integer	query	False	Filter by temperature_sensors.threshold.low.warning  • Introduced in: 9.10
temperature_sensors.temperature	integer	query	False	Filter by temperature_sensors.temperature  • Introduced in: 9.10
temperature_sensors.id	integer	query	False	Filter by temperature_sensors.id  • Introduced in: 9.10
temperature_sensors.ambient	boolean	query	False	Filter by temperature_sensors.ambient  • Introduced in: 9.10
temperature_sensors.location	string	query	False	Filter by temperature_sensors.location  • Introduced in: 9.10
paths.node.uuid	string	query	False	Filter by paths.node.uuid
paths.node.name	string	query	False	Filter by paths.node.name

Name	Type	In	Required	Description
paths.name	string	query	False	Filter by paths.name
frus.state	string	query	False	Filter by frus.state
frus.installed	boolean	query	False	Filter by frus.installed  • Introduced in: 9.10
frus.id	integer	query	False	Filter by frus.id
frus.firmware_version	string	query	False	Filter by frus.firmware_version
frus.serial_number	string	query	False	Filter by frus.serial_number
frus.psu.power_drawn	integer	query	False	Filter by frus.psu.power_drawn  • Introduced in: 9.10
frus.psu.model	string	query	False	Filter by frus.psu.model  • Introduced in: 9.10
frus.psu.power_rating	integer	query	False	Filter by frus.psu.power_rating  • Introduced in: 9.10
frus.psu.crest_factor	integer	query	False	Filter by frus.psu.crest_factor  • Introduced in: 9.10
frus.type	string	query	False	Filter by frus.type

Name	Type	In	Required	Description
frus.part_number	string	query	False	Filter by frus.part_number
connection_type	string	query	False	Filter by connection_type
module_type	string	query	False	Filter by module_type
vendor.serial_number	string	query	False	Filter by vendor.serial_number  • Introduced in: 9.8
vendor.manufacturer	string	query	False	Filter by vendor.manufacturer  • Introduced in: 9.8
vendor.part_number	string	query	False	Filter by vendor.part_number  • Introduced in: 9.8
vendor.product	string	query	False	Filter by vendor.product  • Introduced in: 9.8
vendor.name	string	query	False	Filter by vendor.name  • Introduced in: 9.10
acps.channel	string	query	False	Filter by acps.channel  • Introduced in: 9.10

Name	Type	In	Required	Description
acps.address	string	query	False	Filter by acps.address  • Introduced in: 9.10
acps.subnet	string	query	False	Filter by acps.subnet  • Introduced in: 9.10
acps.node.uuid	string	query	False	Filter by acps.node.uuid  • Introduced in: 9.10
acps.node.name	string	query	False	Filter by acps.node.name  • Introduced in: 9.10
acps.netmask	string	query	False	Filter by acps.netmask  • Introduced in: 9.10
acps.port	string	query	False	Filter by acps.port  • Introduced in: 9.10
acps.enabled	boolean	query	False	Filter by acps.enabled  • Introduced in: 9.10
acps.error.type	string	query	False	Filter by acps.error.type  • Introduced in: 9.10

Name	Type	In	Required	Description
acps.error.reason.arguments.message	string	query	False	Filter by acps.error.reason.arguments.message  • Introduced in: 9.10
acps.error.reason.arguments.code	string	query	False	Filter by acps.error.reason.arguments.code  • Introduced in: 9.10
acps.error.reason.message	string	query	False	Filter by acps.error.reason.message  • Introduced in: 9.10
acps.error.reason.code	string	query	False	Filter by acps.error.reason.code  • Introduced in: 9.10
acps.error.reason.target	string	query	False	Filter by acps.error.reason.target  • Introduced in: 9.10
acps.error.severity	string	query	False	Filter by acps.error.severity  • Introduced in: 9.10
acps.connection_state	string	query	False	Filter by acps.connection_state  • Introduced in: 9.10
uid	string	query	False	Filter by uid

Name	Type	In	Required	Description
fans.id	integer	query	False	Filter by fans.id  • Introduced in: 9.9
fans.state	string	query	False	Filter by fans.state  • Introduced in: 9.9
fans.rpm	integer	query	False	Filter by fans.rpm  • Introduced in: 9.9
fans.location	string	query	False	Filter by fans.location  • Introduced in: 9.9
model	string	query	False	Filter by model
name	string	query	False	Filter by name
drawers.serial_number	string	query	False	Filter by drawers.serial_number
drawers.error	string	query	False	Filter by drawers.error
drawers.part_number	string	query	False	Filter by drawers.part_number
drawers.disk_count	integer	query	False	Filter by drawers.disk_count
drawers.id	integer	query	False	Filter by drawers.id
drawers.closed	boolean	query	False	Filter by drawers.closed
drawers.state	string	query	False	Filter by drawers.state

<b>Name</b>	<b>Type</b>	<b>In</b>	<b>Required</b>	<b>Description</b>
ports.cable.part_number	string	query	False	Filter by ports.cable.part_number
ports.cable.identifier	string	query	False	Filter by ports.cable.identifier
ports.cable.serial_number	string	query	False	Filter by ports.cable.serial_number
ports.cable.length	string	query	False	Filter by ports.cable.length
ports.module_id	string	query	False	Filter by ports.module_id
ports.state	string	query	False	Filter by ports.state
ports.internal	boolean	query	False	Filter by ports.internal
ports.id	integer	query	False	Filter by ports.id
ports.wwn	string	query	False	Filter by ports.wwn
ports.designator	string	query	False	Filter by ports.designator
ports.remote.chassis	string	query	False	Filter by ports.remote.chassis
ports.remote.wwn	string	query	False	Filter by ports.remote.wwn
ports.remote.phy	string	query	False	Filter by ports.remote.phy
ports.remote.mac_address	string	query	False	Filter by ports.remote.mac_address
ports.remote.port	string	query	False	Filter by ports.remote.port

Name	Type	In	Required	Description
ports.remote.device	string	query	False	Filter by ports.remote.device  • Introduced in: 9.8
ports.mac_address	string	query	False	Filter by ports.mac_address
disk_count	integer	query	False	Filter by disk_count
internal	boolean	query	False	Filter by internal
id	string	query	False	Filter by id
serial_number	string	query	False	Filter by serial_number
manufacturer.name	string	query	False	Filter by manufacturer.name  • Introduced in: 9.10
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.  • Default value: 1



Name	Type	In	Required	Description
return_timeout	integer	query	False	<p>The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.</p> <ul style="list-style-type: none"> <li>• Default value: 1</li> <li>• Max value: 120</li> <li>• Min value: 0</li> </ul>
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Type	Description
_links	<a href="#">_links</a>	
num_records	integer	Number of records
records	array[ <a href="#">shelf</a> ]	

## Example response

```
{
  "_links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "records": [
    {
      "acps": [
        {
          "address": "192.168.1.104",
          "channel": "out_of_band",
          "connection_state": "full_connectivity",
          "error": {
            "reason": {
              "arguments": [
                {
                  "code": "string",
                  "message": "string"
                }
              ],
              "code": "4",
              "message": "entry doesn't exist",
              "target": "uuid"
            },
            "severity": "string",
            "type": "string"
          },
          "netmask": "255.255.252.0",
          "node": {
            "_links": {
              "self": {
                "href": "/api/resourcelink"
              }
            },
            "name": "node1",
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
          },
          "port": "e0P",
          "subnet": "192.168.0.1"
        }
      ]
    }
  ]
}
```

```

],
"bays": [
  {
    "id": 0,
    "state": "ok",
    "type": "single_disk"
  }
],
"connection_type": "sas",
"current_sensors": [
  {
    "current": 14410,
    "id": 1,
    "location": "rear of the shelf on the lower left power
supply",
    "state": "ok"
  }
],
"disk_count": 12,
"drawers": [
  {
    "disk_count": 12,
    "error": "string",
    "part_number": "111-03071",
    "serial_number": "021604008263",
    "state": "ok"
  }
],
"errors": [
  {
    "reason": {
      "arguments": [
        {
          "code": "string",
          "message": "string"
        }
      ],
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
  }
],
"fans": [
  {
    "id": 1,

```

```

    "location": "rear of the shelf on the lower left power
supply",
    "rpm": 3020,
    "state": "ok"
  }
],
"frus": [
  {
    "firmware_version": "0191",
    "installed": 1,
    "part_number": "111-00690+A2",
    "psu": {
      "crest_factor": 92,
      "model": "00",
      "power_drawn": 210,
      "power_rating": 1600
    },
    "serial_number": "8000166294",
    "state": "error",
    "type": "module"
  }
],
"id": "1",
"location_led": "off",
"manufacturer": {
  "name": "NETAPP"
},
"model": "DS2246",
"module_type": "iom6",
"name": "1.1",
"paths": [
  {
    "_links": {
      "self": {
        "href": "/api/resourcelink"
      }
    },
    "name": "2a",
    "node": {
      "_links": {
        "self": {
          "href": "/api/resourcelink"
        }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    }
  }
]

```

```

    }
  ],
  "ports": [
    {
      "cable": {
        "identifier": "500a0980000b6c3f-50000d1703544b80",
        "length": "2m",
        "part_number": "112-00431+A0",
        "serial_number": "616930439"
      },
      "designator": "square",
      "id": 0,
      "mac_address": "string",
      "module_id": "a",
      "remote": {
        "chassis": "string",
        "device": "string",
        "mac_address": "string",
        "phy": "12",
        "port": "string",
        "wwn": "50000D1703544B80"
      },
      "state": "connected",
      "wwn": "500A0980000B6C3F"
    }
  ],
  "serial_number": "SHFMS1514000895",
  "state": "ok",
  "temperature_sensors": [
    {
      "ambient": "",
      "id": 1,
      "location": "temp sensor on midplane left",
      "state": "ok",
      "temperature": 32,
      "threshold": {
        "high": {
          "critical": 60,
          "warning": 55
        },
        "low": {
          "critical": 0,
          "warning": 5
        }
      }
    }
  ]
}

```

```

    }
  ],
  "uid": "7777841915827391056",
  "vendor": {
    "manufacturer": "XYZ",
    "name": "XYZ",
    "part_number": "A92831142733",
    "product": "LS2246",
    "serial_number": "891234572210221"
  },
  "voltage_sensors": [
    {
      "id": 1,
      "location": "rear of the shelf on the lower left power
supply",
      "state": "ok",
      "voltage": "12.18"
    }
  ]
}
]
}

```

## Error

Status: Default, Error

Name	Type	Description
error	error	

## Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

href

Name	Type	Description
href	string	

\_links

Name	Type	Description
next	<a href="#">href</a>	
self	<a href="#">href</a>	

error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

error

Error object is populated when connection\_state becomes non-optimal

Name	Type	Description
reason	<a href="#">error</a>	
severity	string	
type	string	

\_links



Name	Type	Description
self	<a href="#">href</a>	

node

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
uuid	string	

acps

Name	Type	Description
address	string	
channel	string	
connection_state	string	
enabled	boolean	
error	<a href="#">error</a>	Error object is populated when connection_state becomes non-optimal
netmask	string	
node	<a href="#">node</a>	
port	string	
subnet	string	

bays

Name	Type	Description
has_disk	boolean	
id	integer	
state	string	
type	string	

current\_sensors

Name	Type	Description
current	integer	Current, in milliamps
id	integer	
location	string	

Name	Type	Description
state	string	

#### drawers

Name	Type	Description
closed	boolean	
disk_count	integer	
error	string	
id	integer	
part_number	string	
serial_number	string	
state	string	

#### errors

Name	Type	Description
reason	<a href="#">error</a>	

#### fans

Name	Type	Description
id	integer	
location	string	
rpm	integer	
state	string	

#### psu

Name	Type	Description
crest_factor	integer	The ratio of the peak voltage to the root-mean-square voltage
model	string	
power_drawn	integer	Power drawn, in watts
power_rating	integer	Power rating, in watts

#### frus

Name	Type	Description
firmware_version	string	
id	integer	
installed	boolean	
part_number	string	
psu	<a href="#">psu</a>	
serial_number	string	
state	string	
type	string	

manufacturer

Name	Type	Description
name	string	

paths

Storage port

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
node	<a href="#">node</a>	

cable

Name	Type	Description
identifier	string	
length	string	
part_number	string	
serial_number	string	

remote

Name	Type	Description
chassis	string	
device	string	
mac_address	string	
phy	string	
port	string	

Name	Type	Description
wwn	string	

#### ports

Name	Type	Description
cable	<a href="#">cable</a>	
designator	string	
id	integer	
internal	boolean	
mac_address	string	
module_id	string	
remote	<a href="#">remote</a>	
state	string	
wwn	string	

#### high

Name	Type	Description
critical	integer	High critical threshold, in degrees Celsius
warning	integer	High warning threshold, in degrees Celsius

#### low

Name	Type	Description
critical	integer	Low critical threshold, in degrees Celsius
warning	integer	Low warning threshold, in degrees Celsius

#### threshold

Name	Type	Description
high	<a href="#">high</a>	
low	<a href="#">low</a>	

#### temperature\_sensors

Name	Type	Description
ambient	boolean	Sensor that measures the ambient temperature
id	integer	
location	string	
state	string	
temperature	integer	Temperature, in degrees Celsius
threshold	<a href="#">threshold</a>	

#### vendor

Name	Type	Description
manufacturer	string	Support for this field will be removed in a future release. Please use vendor.name for this field.
name	string	
part_number	string	Part number
product	string	Product name
serial_number	string	Serial number

#### voltage\_sensors

Name	Type	Description
id	integer	
location	string	
state	string	
voltage	number	Voltage, in volts

#### shelf

Name	Type	Description
acps	array[ <a href="#">acps</a> ]	Alternate Control Paths to ACP processors/functions in shelf modules and expanders
bays	array[ <a href="#">bays</a> ]	

Name	Type	Description
connection_type	string	
current_sensors	array[ <a href="#">current_sensors</a> ]	
disk_count	integer	
drawers	array[ <a href="#">drawers</a> ]	
errors	array[ <a href="#">errors</a> ]	
fans	array[ <a href="#">fans</a> ]	
frus	array[ <a href="#">frus</a> ]	
id	string	
internal	boolean	
local	boolean	
location_led	string	
manufacturer	<a href="#">manufacturer</a>	
model	string	
module_type	string	
name	string	
paths	array[ <a href="#">paths</a> ]	
ports	array[ <a href="#">ports</a> ]	
serial_number	string	
state	string	
temperature_sensors	array[ <a href="#">temperature_sensors</a> ]	
uid	string	
vendor	<a href="#">vendor</a>	
voltage_sensors	array[ <a href="#">voltage_sensors</a> ]	

## Retrieve a shelf

GET /storage/shelves/{uid}

**Introduced In:** 9.6

Retrieves a specific shelf.

### Related ONTAP commands

- `storage shelf show`
- `storage shelf port show`

- storage shelf drawer show
- storage shelf acp show

## Learn more

- [DOC /storage/shelves](#)

## Parameters

Name	Type	In	Required	Description
uid	string	path	True	Shelf UID
fields	array[string]	query	False	Specify the fields to return.

## Response

Status: 200, Ok

Name	Type	Description
acps	array[acps]	Alternate Control Paths to ACP processors/functions in shelf modules and expanders
bays	array[bays]	
connection_type	string	
current_sensors	array[current_sensors]	
disk_count	integer	
drawers	array[drawers]	
errors	array[errors]	
fans	array[fans]	
frus	array[frus]	
id	string	
internal	boolean	
local	boolean	
location_led	string	
manufacturer	<a href="#">manufacturer</a>	
model	string	
module_type	string	

Name	Type	Description
name	string	
paths	array[paths]	
ports	array[ports]	
serial_number	string	
state	string	
temperature_sensors	array[temperature_sensors]	
uid	string	
vendor	vendor	
voltage_sensors	array[voltage_sensors]	



## Example response

```
{
  "acps": [
    {
      "address": "192.168.1.104",
      "channel": "out_of_band",
      "connection_state": "full_connectivity",
      "error": {
        "reason": {
          "arguments": [
            {
              "code": "string",
              "message": "string"
            }
          ],
          "code": "4",
          "message": "entry doesn't exist",
          "target": "uuid"
        },
        "severity": "string",
        "type": "string"
      },
      "netmask": "255.255.252.0",
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "port": "e0P",
      "subnet": "192.168.0.1"
    }
  ],
  "bays": [
    {
      "id": 0,
      "state": "ok",
      "type": "single_disk"
    }
  ],
  "connection_type": "sas",
  "current_sensors": [
```

```

    {
      "current": 14410,
      "id": 1,
      "location": "rear of the shelf on the lower left power supply",
      "state": "ok"
    }
  ],
  "disk_count": 12,
  "drawers": [
    {
      "disk_count": 12,
      "error": "string",
      "part_number": "111-03071",
      "serial_number": "021604008263",
      "state": "ok"
    }
  ],
  "errors": [
    {
      "reason": {
        "arguments": [
          {
            "code": "string",
            "message": "string"
          }
        ],
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
    }
  ],
  "fans": [
    {
      "id": 1,
      "location": "rear of the shelf on the lower left power supply",
      "rpm": 3020,
      "state": "ok"
    }
  ],
  "frus": [
    {
      "firmware_version": "0191",
      "installed": 1,
      "part_number": "111-00690+A2",
      "psu": {

```

```

        "crest_factor": 92,
        "model": "00",
        "power_drawn": 210,
        "power_rating": 1600
    },
    "serial_number": "8000166294",
    "state": "error",
    "type": "module"
}
],
"id": "1",
"location_led": "off",
"manufacturer": {
    "name": "NETAPP"
},
"model": "DS2246",
"module_type": "iom6",
"name": "1.1",
"paths": [
    {
        "_links": {
            "self": {
                "href": "/api/resourcelink"
            }
        },
        "name": "2a",
        "node": {
            "_links": {
                "self": {
                    "href": "/api/resourcelink"
                }
            },
            "name": "node1",
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
    }
],
"ports": [
    {
        "cable": {
            "identifier": "500a0980000b6c3f-50000d1703544b80",
            "length": "2m",
            "part_number": "112-00431+A0",
            "serial_number": "616930439"
        },
        "designator": "square",
    }
]

```

```

    "id": 0,
    "mac_address": "string",
    "module_id": "a",
    "remote": {
      "chassis": "string",
      "device": "string",
      "mac_address": "string",
      "phy": "12",
      "port": "string",
      "wwn": "50000D1703544B80"
    },
    "state": "connected",
    "wwn": "500A0980000B6C3F"
  }
],
"serial_number": "SHFMS1514000895",
"state": "ok",
"temperature_sensors": [
  {
    "ambient": "",
    "id": 1,
    "location": "temp sensor on midplane left",
    "state": "ok",
    "temperature": 32,
    "threshold": {
      "high": {
        "critical": 60,
        "warning": 55
      },
      "low": {
        "critical": 0,
        "warning": 5
      }
    }
  }
]
},
"uid": "7777841915827391056",
"vendor": {
  "manufacturer": "XYZ",
  "name": "XYZ",
  "part_number": "A92831142733",
  "product": "LS2246",
  "serial_number": "891234572210221"
},
"voltage_sensors": [
  {

```

```
    "id": 1,  
    "location": "rear of the shelf on the lower left power supply",  
    "state": "ok",  
    "voltage": "12.18"  
  }  
]  
}
```

## Error

Status: Default, Error

Name	Type	Description
error	error	

## Example error

```
{  
  "error": {  
    "arguments": [  
      {  
        "code": "string",  
        "message": "string"  
      }  
    ],  
    "code": "4",  
    "message": "entry doesn't exist",  
    "target": "uuid"  
  }  
}
```

## Definitions

## See Definitions

### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

### error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

### error

Error object is populated when connection\_state becomes non-optimal

Name	Type	Description
reason	<a href="#">error</a>	
severity	string	
type	string	

### href

Name	Type	Description
href	string	

### \_links

Name	Type	Description
self	<a href="#">href</a>	

### node

Name	Type	Description
_links	<a href="#">_links</a>	

Name	Type	Description
name	string	
uuid	string	

#### acps

Name	Type	Description
address	string	
channel	string	
connection_state	string	
enabled	boolean	
error	<a href="#">error</a>	Error object is populated when connection_state becomes non-optimal
netmask	string	
node	<a href="#">node</a>	
port	string	
subnet	string	

#### bays

Name	Type	Description
has_disk	boolean	
id	integer	
state	string	
type	string	

#### current\_sensors

Name	Type	Description
current	integer	Current, in milliamps
id	integer	
location	string	
state	string	

#### drawers

Name	Type	Description
closed	boolean	

Name	Type	Description
disk_count	integer	
error	string	
id	integer	
part_number	string	
serial_number	string	
state	string	

#### errors

Name	Type	Description
reason	<a href="#">error</a>	

#### fans

Name	Type	Description
id	integer	
location	string	
rpm	integer	
state	string	

#### psu

Name	Type	Description
crest_factor	integer	The ratio of the peak voltage to the root-mean-square voltage
model	string	
power_drawn	integer	Power drawn, in watts
power_rating	integer	Power rating, in watts

#### frus

Name	Type	Description
firmware_version	string	
id	integer	
installed	boolean	
part_number	string	
psu	<a href="#">psu</a>	



Name	Type	Description
serial_number	string	
state	string	
type	string	

manufacturer

Name	Type	Description
name	string	

paths

Storage port

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
node	<a href="#">node</a>	

cable

Name	Type	Description
identifier	string	
length	string	
part_number	string	
serial_number	string	

remote

Name	Type	Description
chassis	string	
device	string	
mac_address	string	
phy	string	
port	string	
wwn	string	

ports

Name	Type	Description
cable	<a href="#">cable</a>	

Name	Type	Description
designator	string	
id	integer	
internal	boolean	
mac_address	string	
module_id	string	
remote	<a href="#">remote</a>	
state	string	
wwn	string	

#### high

Name	Type	Description
critical	integer	High critical threshold, in degrees Celsius
warning	integer	High warning threshold, in degrees Celsius

#### low

Name	Type	Description
critical	integer	Low critical threshold, in degrees Celsius
warning	integer	Low warning threshold, in degrees Celsius

#### threshold

Name	Type	Description
high	<a href="#">high</a>	
low	<a href="#">low</a>	

#### temperature\_sensors

Name	Type	Description
ambient	boolean	Sensor that measures the ambient temperature
id	integer	

Name	Type	Description
location	string	
state	string	
temperature	integer	Temperature, in degrees Celsius
threshold	<a href="#">threshold</a>	

vendor

Name	Type	Description
manufacturer	string	Support for this field will be removed in a future release. Please use vendor.name for this field.
name	string	
part_number	string	Part number
product	string	Product name
serial_number	string	Serial number

voltage\_sensors

Name	Type	Description
id	integer	
location	string	
state	string	
voltage	number	Voltage, in volts

## Update a shelf location LED

PATCH /storage/shelves/{uid}

**Introduced In:** 9.10

Updates a shelf location LED.

### Related ONTAP commands

- `storage shelf location-led modify`

## Learn more

- [DOC /storage/shelves](#)

## Parameters

Name	Type	In	Required	Description
uid	string	path	True	Shelf UID

## Request Body

Name	Type	Description
acps	array[ <a href="#">acps</a> ]	Alternate Control Paths to ACP processors/functions in shelf modules and expanders
bays	array[ <a href="#">bays</a> ]	
connection_type	string	
current_sensors	array[ <a href="#">current_sensors</a> ]	
disk_count	integer	
drawers	array[ <a href="#">drawers</a> ]	
errors	array[ <a href="#">errors</a> ]	
fans	array[ <a href="#">fans</a> ]	
frus	array[ <a href="#">frus</a> ]	
id	string	
internal	boolean	
local	boolean	
location_led	string	
manufacturer	<a href="#">manufacturer</a>	
model	string	
module_type	string	
name	string	
paths	array[ <a href="#">paths</a> ]	
ports	array[ <a href="#">ports</a> ]	
serial_number	string	
state	string	
temperature_sensors	array[ <a href="#">temperature_sensors</a> ]	
uid	string	

Name	Type	Description
vendor	vendor	
voltage_sensors	array[voltage_sensors]	

## Example request

```
{
  "acps": [
    {
      "address": "192.168.1.104",
      "channel": "out_of_band",
      "connection_state": "full_connectivity",
      "error": {
        "reason": {
          "arguments": [
            {
              "code": "string",
              "message": "string"
            }
          ],
          "code": "4",
          "message": "entry doesn't exist",
          "target": "uuid"
        },
        "severity": "string",
        "type": "string"
      },
      "netmask": "255.255.252.0",
      "node": {
        "_links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      },
      "port": "e0P",
      "subnet": "192.168.0.1"
    }
  ],
  "bays": [
    {
      "id": 0,
      "state": "ok",
      "type": "single_disk"
    }
  ],
  "connection_type": "sas",
  "current_sensors": [
```

```

    {
      "current": 14410,
      "id": 1,
      "location": "rear of the shelf on the lower left power supply",
      "state": "ok"
    }
  ],
  "disk_count": 12,
  "drawers": [
    {
      "disk_count": 12,
      "error": "string",
      "part_number": "111-03071",
      "serial_number": "021604008263",
      "state": "ok"
    }
  ],
  "errors": [
    {
      "reason": {
        "arguments": [
          {
            "code": "string",
            "message": "string"
          }
        ],
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
    }
  ],
  "fans": [
    {
      "id": 1,
      "location": "rear of the shelf on the lower left power supply",
      "rpm": 3020,
      "state": "ok"
    }
  ],
  "frus": [
    {
      "firmware_version": "0191",
      "installed": 1,
      "part_number": "111-00690+A2",
      "psu": {

```

```

        "crest_factor": 92,
        "model": "00",
        "power_drawn": 210,
        "power_rating": 1600
    },
    "serial_number": "8000166294",
    "state": "error",
    "type": "module"
}
],
"id": "1",
"location_led": "off",
"manufacturer": {
    "name": "NETAPP"
},
"model": "DS2246",
"module_type": "iom6",
"name": "1.1",
"paths": [
    {
        "_links": {
            "self": {
                "href": "/api/resourcelink"
            }
        },
        "name": "2a",
        "node": {
            "_links": {
                "self": {
                    "href": "/api/resourcelink"
                }
            },
            "name": "node1",
            "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
    }
],
"ports": [
    {
        "cable": {
            "identifier": "500a0980000b6c3f-50000d1703544b80",
            "length": "2m",
            "part_number": "112-00431+A0",
            "serial_number": "616930439"
        },
        "designator": "square",
    }
]

```



```
"id": 0,
"mac_address": "string",
"module_id": "a",
"remote": {
  "chassis": "string",
  "device": "string",
  "mac_address": "string",
  "phy": "12",
  "port": "string",
  "wwn": "50000D1703544B80"
},
"state": "connected",
"wwn": "500A0980000B6C3F"
}
],
"serial_number": "SHFMS1514000895",
"state": "ok",
"temperature_sensors": [
  {
    "ambient": "",
    "id": 1,
    "location": "temp sensor on midplane left",
    "state": "ok",
    "temperature": 32,
    "threshold": {
      "high": {
        "critical": 60,
        "warning": 55
      },
      "low": {
        "critical": 0,
        "warning": 5
      }
    }
  }
]
},
"uid": "7777841915827391056",
"vendor": {
  "manufacturer": "XYZ",
  "name": "XYZ",
  "part_number": "A92831142733",
  "product": "LS2246",
  "serial_number": "891234572210221"
},
"voltage_sensors": [
  {
```

```
    "id": 1,
    "location": "rear of the shelf on the lower left power supply",
    "state": "ok",
    "voltage": "12.18"
  }
]
```

## Response

Status: 200, Ok

## Error

Status: Default

### ONTAP Error Response Codes

Error Code	Description
17825872	Shelf locate request failed because shelf "<name>" was not found.</name>
17825873	Shelf locate request failed because shelf "<name>" does not support this command.</name>
17825874	Shelf locate request failed for shelf "<name>" with an unknown error.</name>
17825875	Shelf locate request failed for shelf "<name>" because shelf modules are unreachable.</name>

Name	Type	Description
error	error	

## Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

## Definitions

## See Definitions

### error\_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

### error

Name	Type	Description
arguments	array[ <a href="#">error_arguments</a> ]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

### error

Error object is populated when connection\_state becomes non-optimal

Name	Type	Description
reason	<a href="#">error</a>	
severity	string	
type	string	

### href

Name	Type	Description
href	string	

### \_links

Name	Type	Description
self	<a href="#">href</a>	

### node

Name	Type	Description
_links	<a href="#">_links</a>	

Name	Type	Description
name	string	
uuid	string	

#### acps

Name	Type	Description
address	string	
channel	string	
connection_state	string	
enabled	boolean	
error	<a href="#">error</a>	Error object is populated when connection_state becomes non-optimal
netmask	string	
node	<a href="#">node</a>	
port	string	
subnet	string	

#### bays

Name	Type	Description
has_disk	boolean	
id	integer	
state	string	
type	string	

#### current\_sensors

Name	Type	Description
current	integer	Current, in milliamps
id	integer	
location	string	
state	string	

#### drawers

Name	Type	Description
closed	boolean	

Name	Type	Description
disk_count	integer	
error	string	
id	integer	
part_number	string	
serial_number	string	
state	string	

#### errors

Name	Type	Description
reason	<a href="#">error</a>	

#### fans

Name	Type	Description
id	integer	
location	string	
rpm	integer	
state	string	

#### psu

Name	Type	Description
crest_factor	integer	The ratio of the peak voltage to the root-mean-square voltage
model	string	
power_drawn	integer	Power drawn, in watts
power_rating	integer	Power rating, in watts

#### frus

Name	Type	Description
firmware_version	string	
id	integer	
installed	boolean	
part_number	string	
psu	<a href="#">psu</a>	

Name	Type	Description
serial_number	string	
state	string	
type	string	

manufacturer

Name	Type	Description
name	string	

paths

Storage port

Name	Type	Description
_links	<a href="#">_links</a>	
name	string	
node	<a href="#">node</a>	

cable

Name	Type	Description
identifier	string	
length	string	
part_number	string	
serial_number	string	

remote

Name	Type	Description
chassis	string	
device	string	
mac_address	string	
phy	string	
port	string	
wwn	string	

ports

Name	Type	Description
cable	<a href="#">cable</a>	

Name	Type	Description
designator	string	
id	integer	
internal	boolean	
mac_address	string	
module_id	string	
remote	<a href="#">remote</a>	
state	string	
wwn	string	

#### high

Name	Type	Description
critical	integer	High critical threshold, in degrees Celsius
warning	integer	High warning threshold, in degrees Celsius

#### low

Name	Type	Description
critical	integer	Low critical threshold, in degrees Celsius
warning	integer	Low warning threshold, in degrees Celsius

#### threshold

Name	Type	Description
high	<a href="#">high</a>	
low	<a href="#">low</a>	

#### temperature\_sensors

Name	Type	Description
ambient	boolean	Sensor that measures the ambient temperature
id	integer	



Name	Type	Description
location	string	
state	string	
temperature	integer	Temperature, in degrees Celsius
threshold	<a href="#">threshold</a>	

#### vendor

Name	Type	Description
manufacturer	string	Support for this field will be removed in a future release. Please use vendor.name for this field.
name	string	
part_number	string	Part number
product	string	Product name
serial_number	string	Serial number

#### voltage\_sensors

Name	Type	Description
id	integer	
location	string	
state	string	
voltage	number	Voltage, in volts

#### shelf

Name	Type	Description
acps	array[ <a href="#">acps</a> ]	Alternate Control Paths to ACP processors/functions in shelf modules and expanders
bays	array[ <a href="#">bays</a> ]	
connection_type	string	
current_sensors	array[ <a href="#">current_sensors</a> ]	
disk_count	integer	

Name	Type	Description
drawers	array[drawers]	
errors	array[errors]	
fans	array[fans]	
frus	array[frus]	
id	string	
internal	boolean	
local	boolean	
location_led	string	
manufacturer	manufacturer	
model	string	
module_type	string	
name	string	
paths	array[paths]	
ports	array[ports]	
serial_number	string	
state	string	
temperature_sensors	array[temperature_sensors]	
uid	string	
vendor	vendor	
voltage_sensors	array[voltage_sensors]	

## Copyright information

Copyright © 2025 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.