



Manage role privilege path

REST API reference

NetApp
February 11, 2026

Table of Contents

Manage role privilege path	1
Manage role privilege path	1
Overview	1
Examples	1
Delete a privilege tuple (of rest uri and its access level) from the role	2
Required parameters	3
Related ONTAP commands	3
Learn more	3
Parameters	3
Response	3
Error	3
Definitions	4
Retrieves the privilege level for a rest api path for the specified role	5
Related ONTAP commands	5
Learn more	5
Parameters	6
Response	6
Error	6
Definitions	7
Updates the privilege level for a rest api path	8
Required parameters	9
Related ONTAP commands	9
Learn more	9
Parameters	9
Request Body	9
Response	10
Error	10
Definitions	11

Manage role privilege path

Manage role privilege path

Overview

A role can comprise of multiple tuples and each tuple consists of the REST API path and its access level. These APIs can be used to retrieve and modify the access level or delete one of the constituent REST API paths within a role.

The role can be SVM-scoped or cluster-scoped.

Specify the owner UUID and the role name in the URL path. The owner UUID corresponds to the UUID of the SVM for which the role has been created and can be obtained from the response body of a GET call performed on one of the following APIs: `/api/security/roles` for all roles
`/api/security/roles/?scope=svm` for SVM-scoped roles
`/api/security/roles/?owner.name=<svm-name></i>` for roles in a specific SVM This API response contains the complete URI for each tuple of the role and can be used for GET, PATCH, or DELETE operations.`</svm-name>`



The access level for paths in pre-defined roles cannot be updated.

Examples

Updating the access level for a path in the privilege tuple of an existing role

```
# The API:  
PATCH "/api/security/roles/{owner.uuid}/{name}/privileges/{path}"  
  
# The call:  
curl -k -u <cluster_admin>:<password> -X PATCH "https://<mgmt-  
ip>/api/security/roles/aaef7c38-4bd3-11e9-b238-  
0050568e2e25/svm_role1/privileges/%2Fapi%2Fprotocols" -d  
'{"access":"all"}'
```

Retrieving the access level for a path in the privilege tuple of an existing role

```

# The API:
GET "/api/security/roles/{owner.uuid}/{name}/privileges/{path}"

# The call:
curl -k -u <cluster_admin>:<password> -X GET "https://<mgmt-
ip>/api/security/roles/aaef7c38-4bd3-11e9-b238-
0050568e2e25/svm_role1/privileges/%2Fapi%2Fprotocols"

# The response:
{
  "owner": {
    "uuid": "aaef7c38-4bd3-11e9-b238-0050568e2e25"
  },
  "name": "svm_role1",
  "path": "/api/protocols",
  "access": "all",
  "_links": {
    "self": {
      "href": "/api/security/roles/aaef7c38-4bd3-11e9-b238-
0050568e2e25/svm_role1/privileges/%2Fapi%2Fprotocols"
    }
  }
}

```

Deleting a privilege tuple from an existing role

```

# The API:
DELETE "/api/security/roles/{owner.uuid}/{name}/privileges/{path}"

# The call:
curl -k -u <cluster_admin>:<password> -X DELETE "https://<mgmt-
ip>/api/security/roles/aaef7c38-4bd3-11e9-b238-
0050568e2e25/svm_role1/privileges/%2Fapi%2Fprotocols"

```

Delete a privilege tuple (of rest uri and its access level) from the role

required parameters

- owneruuid - uuid of the svm which houses this role
- name - name of the role to be updated
- path - constituent rest api path to be deleted from this role **#** related ontap commands

- security login rest-role delete [# learn more](#)
- [doc /security/roles/{owneruuid}/{name}/privileges/{path}]({#docs-security-security_roles_{owneruuid}_{name}_privileges_{path}})
- [doc /security/roles]({#docs-security-security_roles})

DELETE /security/roles/{owner.uuid}/{name}/privileges/{path}

Delete a privilege tuple (of REST URI and its access level) from the role.

Required parameters

- owner.uuid - UUID of the SVM which houses this role.
- name - Name of the role to be updated.
- path - Constituent REST API path to be deleted from this role.

Related ONTAP commands

- security login rest-role delete

Learn more

- [DOC /security/roles/{owner.uuid}/{name}/privileges/{path}](#)
- [DOC /security/roles](#)

Parameters

Name	Type	In	Required	Description
owner.uuid	string	path	True	
name	string	path	True	
path	string	path	True	

Response

Status: 200, Ok

Error

Status: Default

ONTAP Error Response Codes

Error Code	Description
5636173	Features requires an effective cluster version of 9.6 or later.
5636172	User accounts detected with this role assigned. Modify/delete those accounts before deleting this role.
13434893	SVM does not exist.
13434890	Vserver-Id failed for Vserver roles.

Name	Type	Description
error	error	

Example error

```
{
  "error": {
    "arguments": [
      {
        "code": "string",
        "message": "string"
      }
    ],
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
  }
}
```

Definitions

See Definitions

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieves the privilege level for a rest api path for the specified role

related ontap commands

- `security login rest-role show` [# learn more](#)
- [\[doc /security/roles/{owneruuid}/{name}/privileges/{path}\]](#) ([#docs-security-security_roles_{owneruuid}_{name}_privileges_{path}](#))
- [\[doc /security/roles\]](#) ([#docs-security-security_roles](#))

`GET /security/roles/{owner.uuid}/{name}/privileges/{path}`

Retrieves the privilege level for a REST API path for the specified role.

Related ONTAP commands

- `security login rest-role show`

Learn more

- [DOC /security/roles/{owner.uuid}/{name}/privileges/{path}](#)
- [DOC /security/roles](#)

Parameters

Name	Type	In	Required	Description
owner.uuid	string	path	True	
name	string	path	True	
path	string	path	True	

Response

Status: 200, Ok

Name	Type	Description
_links	_links	
access	string	Access level for the REST endpoint.
path	string	REST URI/endpoint

Example response

```
{
  "_links": {
    "self": {
      "href": "/api/resourcelink"
    }
  },
  "access": "readonly",
  "path": "/api/storage/volumes"
}
```

Error

Status: Default, Error

Name	Type	Description
error	error	

Example error

```
{  
  "error": {  
    "arguments": [  
      {  
        "code": "string",  
        "message": "string"  
      }  
    ],  
    "code": "4",  
    "message": "entry doesn't exist",  
    "target": "uuid"  
  }  
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Updates the privilege level for a rest api path

required parameters

- owneruuid - uuid of the svm that houses this role
- name - name of the role to be updated
- path - constituent rest api path whose access level has to be updated
- access - access level for the path (one of "all", "readonly", or "none") **#** related ontap commands
- security login rest-role modify **#** learn more
- [doc /security/roles/{owneruuid}/{name}/privileges/{path}]**(#docs-security-roles_{owneruuid}_{name}_privileges_{path})**

- [doc /security/roles](#docs-security-security_roles)

PATCH /security/roles/{owner.uuid}/{name}/privileges/{path}

Updates the privilege level for a REST API path.

Required parameters

- owner.uuid - UUID of the SVM that houses this role.
- name - Name of the role to be updated.
- path - Constituent REST API path whose access level has to be updated.
- access - Access level for the path (one of "all", "readonly", or "none")

Related ONTAP commands

- security login rest-role modify

Learn more

- [DOC /security/roles/{owner.uuid}/{name}/privileges/{path}](#)
- [DOC /security/roles](#)

Parameters

Name	Type	In	Required	Description
owner.uuid	string	path	True	Owner UUID of the role.
name	string	path	True	Role name
path	string	path	True	REST API path

Request Body

Name	Type	Description
_links	_links	
access	string	Access level for the REST endpoint.
path	string	REST URI/endpoint

Example request

```
{  
  "_links": {  
    "self": {  
      "href": "/api/resourcelink"  
    }  
  },  
  "access": "readonly",  
  "path": "/api/storage/volumes"  
}
```

Response

Status: 200, Ok

Error

Status: Default, Error

Name	Type	Description
error	error	

Example error

```
{  
  "error": {  
    "arguments": [  
      {  
        "code": "string",  
        "message": "string"  
      }  
    ],  
    "code": "4",  
    "message": "entry doesn't exist",  
    "target": "uuid"  
  }  
}
```

Definitions

See Definitions

href

Name	Type	Description
href	string	

_links

Name	Type	Description
self	href	

role_privilege

A tuple containing the REST endpoint and the access level assigned to that endpoint.

Name	Type	Description
_links	_links	
access	string	Access level for the REST endpoint.
path	string	REST URI/endpoint

error_arguments

Name	Type	Description
code	string	Argument code
message	string	Message argument

error

Name	Type	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2026 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.